

Software Reference for x600 Series Switches

AlliedWare Plus™ Operating System

Version 5.3.3-0.1



x600-24Ts
x600-24Ts/XP
x600-48Ts
x600-48Ts/XP
x600-24Ts-POE

Acknowledgments

This product includes software developed by the University of California, Berkeley and its contributors.

Copyright ©1982, 1986, 1990, 1991, 1993 The Regents of the University of California.
All rights reserved.

This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit (<http://www.openssl.org/>).

Copyright ©1998-2008 The OpenSSL Project. All rights reserved.

This product includes software licensed under the GNU General Public License available from: <http://www.gnu.org/licenses/gpl2.html>

Source code for all GPL licensed software in this product can be obtained from the Allied Telesis GPL Code Download Center at: <http://www.alliedtelesis.com/support/default.aspx>

Allied Telesis is committed to meeting the requirements of the open source licenses including the GNU General Public License (GPL) and will make all required source code available.

If you would like a copy of the GPL source code contained in Allied Telesis products, please send us a request by registered mail including a check for US\$15 to cover production and shipping costs and a CD with the GPL code will be mailed to you.

GPL Code Request
Allied Telesis Labs (Ltd)
PO Box 8011
Christchurch.
New Zealand

©2009 Allied Telesis Inc. All rights reserved.

This documentation is subject to change without notice. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or any means electronic or mechanical, including photocopying and recording for any purpose other than the purchaser's internal use without the written permission of Allied Telesis, Inc.

Allied Telesis, AlliedWare Plus, EPSRing, SwitchBlade, and VCStack are trademarks or registered trademarks in the United States and elsewhere of Allied Telesis, Inc. Adobe, Acrobat, and Reader are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries. Additional brands, names and products mentioned herein may be trademarks of their respective companies.

Getting the Most from this Manual

Although you can view this document using Acrobat version 5, to get the best from this manual, we recommend using Adobe Acrobat Reader version 8. You can download Acrobat Reader 8 free from <http://www.adobe.com/>.

New Features in Version 5.3.3-0.1

For a list of new and enhanced features and commands in this version, see [Appendix B: Changes in this Software Version](#) (with links to corresponding sections in this Software Reference), or the Software Release Note for Version 5.3.3-0.1. Documentation can be downloaded from the Support area of our website at <http://www.alliedtelesis.com>. Note that to download software files, you need a valid user account.

Table of Contents

Part 1 Setting up the Switch

Chapter 1. Getting Started	1.1
Introduction.....	1.2
How to log-in.....	1.2
How to get command help	1.3
Viewing a list of valid parameters	1.3
Completing keywords.....	1.7
Viewing command error messages.....	1.8
How to work with command modes.....	1.9
Entering Privileged Exec commands when in a configuration mode	1.12
How to see the current configuration.....	1.14
Default settings.....	1.15
The default configuration script.....	1.16
How to change the password	1.17
How to set a management IP address	1.17
How to save and boot from the current configuration.....	1.19
How to save to the default configuration file.....	1.19
How to create and use a new configuration file	1.19
How to return to the factory defaults.....	1.21
How to see system information.....	1.22
Viewing overall system information.....	1.22
Viewing temperature, voltage, and fan status.....	1.23
Viewing the serial number	1.24
How to set system parameters.....	1.24
How to change the telnet session timeout.....	1.24
How to name the switch	1.25
How to display a text banner at login	1.26
How to set the time and date	1.27
How to show current settings	1.27
How to set the time and date	1.27
How to set the timezone.....	1.28
How to configure summer-time	1.28
How to add and remove users.....	1.29
Pre-encrypted passwords.....	1.30
How to undo settings.....	1.31
How to use the <i>no</i> parameter	1.31
How to use the <i>default</i> parameter	1.31
How to upgrade the firmware	1.32
Controlling “show” command output	1.33
Commands available in each mode.....	1.35
User Exec mode.....	1.35
Privileged Exec mode	1.36
Global Configuration mode.....	1.37
AlliedWare Plus GUI.....	1.39

Chapter 2. Command Syntax Conventions in this Software Reference	2.1
Chapter 3. Start-up Sequence	3.1
AlliedWare Plus™ Start-up.....	3.2
Diagnostic menu.....	3.2
Bootloader menu	3.4
Start-up sequence.....	3.8
Chapter 4. CLI Navigation Commands	4.1
Command List	4.2
Chapter 5. User Access Commands	5.1
Command List	5.2
Chapter 6. Creating and Managing Files.....	6.1
Introduction.....	6.2
Working with files.....	6.2
Listing files	6.2
Displaying the contents of configuration and text files	6.4
Navigating through the file system.....	6.4
Using the editor	6.6
Creating and Using Configuration Files.....	6.8
Creating a Configuration File	6.8
Specifying the Start-up Configuration Script	6.8
Working with Configuration Files.....	6.9
Copying Files To and From Your Device	6.10
URL Syntax.....	6.10
Copying files.....	6.10
Copying from a Server to Running Configuration	6.13
Chapter 7. File Management Commands	7.1
Introduction.....	7.3
Command List	7.4
Chapter 8. System Configuration and Monitoring Commands	8.1
Command List	8.2
Chapter 9. Debugging and Logging	9.1
Introduction.....	9.2
Debugging	9.2
Logging to terminal.....	9.2
Turning off debugging.....	9.2
Logging	9.3
Log Outputs.....	9.3
Chapter 10. Logging Commands.....	10.1
Command List	10.2
Chapter 11. Scripting Commands.....	11.1
Command List	11.2

Chapter 12. Interface Commands.....	12.1
Command List	12.2
Chapter 13. Interface Testing Commands.....	13.1
Command List	13.2

Part 2 Layer Two Switching

Chapter 14. Switching Introduction.....	14.1
Introduction.....	14.2
Physical Layer Information	14.3
Switch Ports	14.3
Port ranges.....	14.3
Activating and Deactivating Switch Ports.....	14.4
Autonegotiation.....	14.4
Duplex mode	14.4
Speed options.....	14.4
Configuring the port speed.....	14.5
MDI MDIX Connection Modes (10BASE-T)	14.5
The Layer 2 Switching Process	14.7
The Ingress Rules	14.7
The Learning Process	14.8
The Forwarding Process	14.9
The Egress Rules	14.9
Layer 2 Filtering.....	14.10
Ingress Filtering	14.10
Channel Groups (Link Aggregation)	14.11
Static Channel Groups.....	14.11
LACP Channel Groups.....	14.12
Storm Control	14.14
Loop Protection.....	14.15
Loop Detection	14.15
Thrash Limiting	14.16
Port Mirroring	14.17
Port Security	14.18
MAC Address Learn Limits.....	14.18
IEEE 802.1X.....	14.18
Quality of Service.....	14.19
IGMP Snooping.....	14.20
Chapter 15. Switching Commands.....	15.1
Command List	15.2
Chapter 16. VLAN Introduction.....	16.1
Introduction.....	16.2
Virtual LANs (VLANs).....	16.2
Configuring VLANs.....	16.3
VLAN Double Tagging (VLAN Stacking).....	16.5
How Double-Tagged VLANs Work.....	16.5
VLAN Rules for Double Tagging.....	16.5
Restrictions when using Double-Tagged VLANs	16.6
Configuring Double-Tagged VLANs.....	16.6

Private VLANs	16.8
Membership Rules.....	16.8
Promiscuous Ports.....	16.9
Host Ports.....	16.9
Private VLAN Operation	16.10
Example Configuration	16.11
VLAN Statistics.....	16.13
Counter Operation	16.13
Chapter 17. VLAN Commands	17.1
Command List	17.2
Chapter 18. Spanning Tree Introduction: STP, RSTP, and MSTP	18.1
Introduction.....	18.2
Overview of Spanning Trees.....	18.2
Spanning tree operation.....	18.2
Spanning tree modes.....	18.4
Spanning Tree Protocol (STP)	18.5
Configuring STP	18.6
Rapid Spanning Tree Protocol (RSTP)	18.7
Configuring RSTP	18.8
Multiple Spanning Tree Protocol (MSTP).....	18.10
Multiple Spanning Tree Instances (MSTI).....	18.11
MSTP Regions.....	18.12
Common and Internal Spanning Tree (CIST)	18.14
MSTP Bridge Protocol Data Units (BPDUs).....	18.16
Configuring MSTP	18.18
Chapter 19. Spanning Tree Commands	19.1
Command List	19.2
Chapter 20. Link Aggregation Configuration.....	20.1
Introduction.....	20.2
Configuring LACP	20.2
Chapter 21. Link Aggregation Commands	21.1
Command List	21.2
Chapter 22. Power over Ethernet Introduction	22.1
Introduction.....	22.2
Power over Ethernet (PoE)	22.2
The Advantages of PoE.....	22.3
PoE powered devices.....	22.3
PoE standard.....	22.4
How PoE works.....	22.4
Power Device (PD) discovery.....	22.4
Power classes	22.4
Power through the cable.....	22.5
AlliedWare Plus PoE Implementation.....	22.6
Power capacity	22.6
Power threshold.....	22.6
Power through the cable.....	22.7

PoE port management.....	22.7
Powered Device (PD) detection.....	22.7
Powered Device (PD) classification.....	22.7
Port prioritization.....	22.8
Software monitoring.....	22.9
AlliedWare Plus PoE Configuration.....	22.10
Configure a PD description for a PoE port.....	22.10
Configuring capacity and priority on a PoE port.....	22.11
Remotely monitoring power for all connected PDs.....	22.12
Chapter 23. Power over Ethernet Commands.....	23.1
Introduction.....	23.2
Command List.....	23.2

Part 3 Layer Three, Switching and Routing

Chapter 24. Internet Protocol (IP) Addressing and Protocols.....	24.1
Introduction.....	24.2
Address Resolution Protocol (ARP).....	24.3
Static ARP Entries.....	24.3
Timing Out ARP Entries.....	24.3
Deleting ARP Entries.....	24.4
Proxy ARP.....	24.4
Domain Name System (DNS).....	24.7
Internet Control Message Protocol (ICMP).....	24.9
ICMP Router Discovery Protocol (IRDP).....	24.10
Checking IP Connections.....	24.13
Ping.....	24.13
Traceroute.....	24.13
IP Helper.....	24.15
IP Directed Broadcast.....	24.15
Chapter 25. IP Addressing and Protocol Commands.....	25.1
Command List.....	25.2
Chapter 26. IPv6 Introduction.....	26.1
Introduction.....	26.2
Overview.....	26.2
IPv6 Addresses and Prefixes.....	26.3
Address types.....	26.3
IPv6 Headers.....	26.4
The Internet Control Message Protocol (ICMPv6).....	26.7
IPv6 Routing.....	26.9
Integration of IPv4 and IPv6.....	26.10
IPv6 on your Switch.....	26.10
Enabling IPv6.....	26.10
The 6bone Network.....	26.10
Chapter 27. IPv6 Commands.....	27.1
Command List.....	27.2

Chapter 28. IPv6to4 Tunneling Configuration.....	28.1
Introduction.....	28.2
6to4 Automatic Tunnel Configuration	28.2
Tunneling Operation.....	28.2
6to4 tunnels operation and configuration summary	28.3
Sample 6to4 configuration.....	28.4
Chapter 29. IPv6to4 Tunneling Commands.....	29.1
Command List	29.2
Chapter 30. Routing Protocol Overview	30.1
Introduction.....	30.2
RIP	30.2
OSPF	30.2
BGP	30.3
PIM-SM.....	30.4
VRRP	30.4
Chapter 31. Route Selection.....	31.1
Introduction.....	31.2
Types of Routes.....	31.2
Interface Routes.....	31.2
Static Routes.....	31.2
Dynamic Routes.....	31.2
RIB and FIB Routing Tables	31.4
Administrative Distance	31.4
Equal Cost Multipath Routing.....	31.7
How AlliedWare Plus Deletes Routes.....	31.7
How AlliedWare Plus Adds Routes	31.8
Chapter 32. Routing Commands.....	32.1
Command List	32.2
Chapter 33. RIP Configuration	33.1
Introduction.....	33.2
Enabling RIP	33.2
Specifying the RIP version	33.3
RIPv2 authentication (single key).....	33.5
RIPv2 text authentication (multiple keys)	33.7
RIPv2 md5 authentication (multiple keys)	33.11
Chapter 34. RIP Commands	34.1
Command List	34.2
Chapter 35. RIPng Configuration	35.1
Introduction.....	35.2
Enabling RIPng.....	35.2
Troubleshooting RIPng Adjacency.....	35.4

Chapter 36. RIPng Commands	36.1
Introduction.....	36.2
Command List	36.2
 Chapter 37. OSPF Configuration	 37.1
Introduction.....	37.2
Terminology.....	37.2
Enabling OSPF on an Interface.....	37.3
Setting priority.....	37.5
Configuring an Area Border Router.....	37.7
Redistributing routes into OSPF.....	37.8
OSPF Cost.....	37.9
Configuring Virtual Links	37.12
OSPF Authentication	37.14
 Chapter 38. OSPF Commands	 38.1
Command List	38.3
 Chapter 39. BGP Configuration	 39.1
Introduction.....	39.2
Enabling BGP Peers in the same AS	39.2
Enabling BGP between different Autonomous Systems.....	39.3
Route-Map.....	39.4
Route Reflector.....	39.7
Confederations.....	39.9
 Chapter 40. BGP Commands	 40.1
Command List	40.4
 Chapter 41. Route Map Commands.....	 41.1
Command List	41.2

Part 4 Multicast Applications

Chapter 42. IGMP Snooping Introduction and Configuration	42.1
Introduction.....	42.2
Configuring IGMP snooping.....	42.3
Introduction to Query Solicitation.....	42.4
How Query Solicitation Works	42.4
Query Solicitation Operation	42.5
Speeding up IGMP convergence in a non-looped topology.....	42.6
Enabling Query Solicitation on multiple switches in a looped topology.....	42.7
 Chapter 43. IGMP Multicast Commands.....	 43.1
Introduction.....	43.2
Command List	43.2

Chapter 44. Common Multicast Commands	44.1
Command List	44.2
Chapter 45. PIM-SM Configuration.....	45.1
Introduction.....	45.2
Roles in PIM Sparse Mode.....	45.3
Operation of PIM Sparse Mode	45.4
Chapter 46. PIM-SM Commands.....	46.1
Command List	46.2
Chapter 47. PIM-DM Configuration	47.1
Introduction.....	47.2
Characteristics of PIM-DM	47.2
PIM-DM Terminology.....	47.2
PIM-DM Configuration	47.4
Configuration Example	47.4
Verifying Configuration	47.8
Chapter 48. PIM-DM Commands	48.1
Command List	48.2
Chapter 49. MLD Snooping Commands.....	49.1
Introduction.....	49.2
Command List	49.2

Part 5 Access and Security

Chapter 50. Access Control Lists Introduction	50.1
Introduction.....	50.2
Classifying Your Traffic.....	50.3
Security Access Control Lists.....	50.3
QoS Access Control Lists.....	50.3
ACL Types.....	50.4
Hardware MAC Access Control Lists	50.4
Hardware IP Access Control Lists	50.5
Actions for Hardware Access Control Lists.....	50.6
Applying Access Control Lists.....	50.7
Attaching Access Control Lists to a Port.....	50.8
Filtering with the QoS Match Commands.....	50.10
TCP Flags.....	50.10
Chapter 51. Access Control List (ACL) Commands.....	51.1
Command List	51.2
Chapter 52. Quality of Service (QoS)	52.1
Introduction.....	52.2
QoS Operations.....	52.2

QoS Packet Information	52.3
Link Layer QoS	52.3
Differentiated Services Architecture	52.4
The Differential Services Field	52.5
Processing pre-marked packets	52.6
Applying QoS on Your Switch	52.7
Classifying your Data	52.7
Class Maps	52.7
Policy Maps	52.10
Premark and Remark your Traffic	52.11
CoS to egress queue premarking	52.11
DSCP to egress queue premarking	52.13
Policing (Metering) Your Data	52.15
Single-rate three-color policing	52.15
Two rate three-color policing	52.16
Configuring and Applying a Policer	52.17
Remark Your Data	52.18
Configuring the Egress Queues	52.19
Egress Queues and QoS markers	52.19
Egress Queue Commands Hierarchy	52.19
Egress Queue Shaping	52.21
Drop Mode	52.22
Storm Protection	52.23
Policy-Based Routing	52.24
Practical Example	52.24
 Chapter 53. QoS Commands	53.1
Command List	53.2
 Chapter 54. 802.1X Configuration	54.1
Introduction	54.2
The 802.1X Implementation	54.2
Configuring 802.1X	54.2
 Chapter 55. 802.1X Commands	55.1
Command List	55.2
 Chapter 56. Authentication Configuration	56.1
Authentication Introduction	56.2
Tri-Authentication Introduction	56.2
Tri-Authentication Configuration	56.2
Configuring a Guest VLAN	56.3
Roaming Authentication	56.4
Roaming Authentication Overview	56.5
Roaming Authentication Feature Interactions	56.6
Unauthenticated Supplicant Traffic	56.7
Deciding when a supplicant fails authentication	56.9
 Chapter 57. Authentication Commands	57.1
Command List	57.3

Chapter 58. AAA Introduction and Configuration.....	58.1
AAA Introduction.....	58.2
Available functions and server types.....	58.2
Server Groups and Method Lists.....	58.2
Configuring AAA Login Authentication.....	58.4
AAA Configuration Tasks.....	58.4
 Chapter 59. AAA Commands.....	 59.1
Command List	59.2
 Chapter 60. RADIUS Commands.....	 60.1
Command List	60.2
 Chapter 61. Local RADIUS Server Introduction and Configuration.....	 61.1
Local RADIUS Server Introduction.....	61.2
Enable the Local RADIUS Server.....	61.2
Add the Local RADIUS Server as a RADIUS Server.....	61.3
Add authenticators to the list of authenticators.....	61.3
Configure the Local RADIUS Server User Database	61.4
Authenticating login sessions.....	61.4
Creating certificates for single users and all users.....	61.6
Defined RADIUS attributes list.....	61.7
 Chapter 62. Local RADIUS Server Commands.....	 62.1
Command List	62.2
 Chapter 63. Secure Shell (SSH) Introduction.....	 63.1
Introduction.....	63.2
Secure Shell on the AlliedWare Plus™ OS.....	63.2
Configuring the SSH Server	63.4
Creating a Host Key	63.4
Enabling the Server	63.4
Modifying the Server.....	63.5
Validating the Server Configuration	63.6
Adding SSH Users.....	63.6
Authenticating SSH Users.....	63.7
Adding a Login Banner	63.7
Monitoring the Server and Managing Sessions.....	63.8
Debugging the Server.....	63.8
Configuring the SSH Client	63.9
Modifying the Client.....	63.9
Adding SSH Servers	63.10
Authenticating with a Server	63.10
Connecting to a Server and Running Commands.....	63.11
Copying files to and from the Server.....	63.11
Debugging the Client.....	63.11
 Chapter 64. Secure Shell (SSH) Configuration.....	 64.1
SSH Server Configuration Example.....	64.2

Chapter 65. Secure Shell (SSH) Commands.....	65.1
Command List	65.2

Part 6 Network Availability

Chapter 66. VRRP Introduction	66.1
Introduction.....	66.2
Virtual Router Redundancy Protocol	66.3
VRRP Configuration.....	66.4
VRRP Election and Preempt.....	66.6
VRRP Authentication.....	66.7
VRRP Debugging.....	66.8
Configuration Examples	66.9
 Chapter 67. VRRP Commands	 67.1
Command List	67.2
 Chapter 68. EPSR Introduction	 68.1
Introduction.....	68.2
Ring Components and Operation	68.2
Fault Detection and Recovery	68.4
Fault Recovery	68.4
Restoring Normal Operation.....	68.6
Managing Rings with Two Breaks	68.7
Recovery When One Break is Restored	68.8
Configuration Examples	68.10
Single Domain, Single Ring Network.....	68.10
Single Ring, Dual Domain Network.....	68.15
EPSR and Spanning Tree Operation.....	68.16
 Chapter 69. EPSR Commands.....	 69.1
Command List	69.2

Part 7 Network Management

Chapter 70. NTP Introduction	70.1
Introduction.....	70.2
Overview	70.2
NTP on the Switch	70.3
Troubleshooting.....	70.4
Configuration Example	70.5
 Chapter 71. NTP Commands	 71.1
Command List	71.2
 Chapter 72. Dynamic Host Configuration Protocol (DHCP) Introduction.....	 72.1
Introduction.....	72.2
BOOTP	72.2

DHCP	72.2
DHCP Relay Agents.....	72.2
Configuring the DHCP Server.....	72.3
Create the Pool.....	72.3
Define the Network.....	72.3
Define the Range.....	72.4
Set the Lease.....	72.4
Set the Options.....	72.4
Configuring the DHCP Relay Agent.....	72.6
Configuring the DHCP Relay Agent.....	72.6
DHCP Relay Agent Option 82.....	72.7
Configuring the DHCP Client.....	72.10
 Chapter 73. Dynamic Host Configuration Protocol (DHCP) Commands.....	73.1
Command List	73.2
 Chapter 74. SNMP Introduction.....	74.1
Introduction.....	74.2
Network Management Framework.....	74.2
Structure of Management Information	74.4
Names.....	74.5
Instances.....	74.6
Syntax	74.6
Access.....	74.6
Status.....	74.7
Description	74.7
The SNMP Protocol.....	74.8
SNMP Versions	74.8
SNMP Messages.....	74.8
Polling versus Event Notification.....	74.9
Message Format for SNMPv1 and SNMPv2c.....	74.9
SNMP Communities (Version v1 and v2c).....	74.10
SNMPv3 Entities.....	74.10
SNMP Engine	74.10
SNMPv3 Message Protocol Format.....	74.11
SNMPv1 and SNMPv2c	74.12
SNMP MIB Views for SNMPv1 and SNMPv2c.....	74.12
SNMP Communities.....	74.12
Configuration Example (SNMPv1 and v2).....	74.14
SNMPv3	74.16
SNMP MIB Views for SNMPv3.....	74.16
SNMP Groups.....	74.16
SNMP Users	74.16
SNMP Target Addresses	74.16
SNMP Target Params.....	74.16
Configuration Example (SNMPv3)	74.17
Using SNMP to Manage Files and Software.....	74.17
Copy a File to or from a TFTP Server.....	74.18
Upgrade Software and Configuration Files.....	74.19
 Chapter 75. SNMP Commands	75.1
Command List	75.2

Chapter 76. SNMP MIBs.....	76.1
Introduction.....	76.2
About MIBs.....	76.2
About SNMP.....	76.2
Obtaining MIBs.....	76.2
Loading MIBs.....	76.3
Allied Telesis Enterprise MIB.....	76.5
AT-SMI-MIB.....	76.6
AT-PRODUCT-MIB.....	76.9
AT-BOARDS-MIB.....	76.10
AT-SYSINFO-MIB.....	76.12
AT-XEM-MIB.....	76.14
AT-ENVMONv2-MIB.....	76.15
AT-VCSTACK-MIB.....	76.21
AT-MIBVERSION-MIB.....	76.25
AT-USER-MIB.....	76.26
AT-RESOURCE-MIB.....	76.27
AT-LICENSE-MIB.....	76.28
AT-TRIGGER-MIB.....	76.31
AT-LOOPPROTECT-MIB.....	76.33
AT-SETUP-MIB.....	76.35
AT-DNS-CLIENT-MIB.....	76.38
AT-NTP-MIB.....	76.39
AT-EPSRv2-MIB.....	76.42
AT-FILEv2-MIB.....	76.45
AT-LOG-MIB.....	76.52
AT-IP-MIB.....	76.54
AT-VLAN-MIB.....	76.56
Public MIBs.....	76.58
 Chapter 77. LLDP Introduction.....	 77.1
Introduction.....	77.2
Link Layer Discovery Protocol.....	77.2
LLDP-MED.....	77.3
Voice VLAN.....	77.3
LLDP Advertisements.....	77.4
Type-Length-Value (TLV).....	77.4
LLDP-MED: Location Identification TLV.....	77.7
Transmission and Reception.....	77.8
LLDP-MED Operation.....	77.9
Storing LLDP Information.....	77.10
Configuring LLDP.....	77.11
Configure LLDP.....	77.12
Configure LLDP-MED.....	77.14
Configure Authentication for Voice VLAN.....	77.18
 Chapter 78. LLDP Commands	 78.1
Introduction.....	78.2
Command List.....	78.2
 Chapter 79. SMTP Commands.....	 79.1
Command List.....	79.2

Chapter 80. RMON Introduction	80.1
Introduction.....	80.2
Overview	80.2
Configuration Example	80.3
Chapter 81. RMON Commands	81.1
Command List	81.2
Chapter 82. Triggers Introduction	82.1
Introduction.....	82.2
Configuring a Trigger	82.2
Troubleshooting Triggers	82.4
Chapter 83. Triggers Configuration	83.1
Introduction.....	83.2
Restrict Internet Access.....	83.2
Capturing Unusual CPU and RAM Activity	83.3
Seeing Daily Statistics.....	83.5
Chapter 84. Trigger Commands	84.1
Command List	84.2
Chapter 85. Ping Polling Introduction	85.1
Introduction.....	85.2
How Ping Polling Works.....	85.2
Configuring Ping Polling.....	85.4
Creating a Polling Instance.....	85.4
Customizing a Polling Instance	85.5
Troubleshooting Ping Polling.....	85.6
Interaction with Other Protocols	85.6
Chapter 86. Ping Polling Commands	86.1
Command List	86.2

Part 8 Virtual Chassis Stacking

Chapter 87. Stacking Introduction.....	87.1
VCS Introduction	87.2
VCS Supported Platforms.....	87.2
Features of Virtual Chassis Stacking	87.2
The Physical Stack.....	87.3
Two Switch Stack Configuration.....	87.3
Resilient Stacked Topology	87.6
Stack Formation	87.8
The Role of the Stack Master	87.8
Stack Management VLAN	87.9
Stack Member Failure and Recovery	87.12
Fixed or Virtual MAC Addressing	87.12
Stack Resiliency Link.....	87.13

VCS Failure Recovery.....	87.15
Stack Maintenance.....	87.16
Software Version Auto Synchronization	87.17
Introduction.....	87.17
How Autosynchronization Works.....	87.17
Chapter 88. Stacking Commands.....	88.1
Introduction.....	88.2

Appendix A: Command List

Appendix B: Changes in this Software Version

Appendix C: GUI Reference

Introduction.....	C.2
Installing and Setting-up the GUI	C.3
System Requirements.....	C.3
Installing the GUI to your switch using an SD card.....	C.3
Installing the GUI to Your Switch Via TFTP server	C.5
Using the GUI	C.7
System > Status > System Details.....	C.8
System > Status > System Date and Time	C.9
System > Status > Top Ten Utilised Ports.....	C.9
System > File Management > Copy File	C.13
System > File Management > Move File	C.14
System > Stacking > Configure Stacking	C.16
System > Stacking > Configure Stack Member	C.17
System > License Management > Add Feature License	C.19
Switching > Ports > Monitor Port.....	C.22
Switching > Ports > Configure Port.....	C.23
Switching > VLANs > Add VLAN	C.26
Switching > Link Aggregation > Add Static Channel	C.29
Switching > Link Aggregation > Add Dynamic Channel.....	C.29
IP > IP Interfaces > Configure Primary IP Address.....	C.32
IP > IP Interfaces > Add Secondary IP Address.....	C.32
IP > Static Routes > Add Static Route	C.34
IP > DNS > Add DNS Server.....	C.37
IP > IGMP Snooping > Configure Interface.....	C.39
Management > NTP > Add NTP Association.....	C.46
Management > Logs > Export Logs.....	C.51

Part 1: Setting up the Switch



- Chapter 1 Getting Started
- Chapter 2 Command Syntax Conventions in this Software Reference
- Chapter 3 Start-up Sequence
- Chapter 4 CLI Navigation Commands
- Chapter 5 User Access Commands
- Chapter 6 Creating and Managing Files
- Chapter 7 File Management Commands
- Chapter 8 System Configuration and Monitoring Commands
- Chapter 9 Debugging and Logging
- Chapter 10 Logging Commands
- Chapter 11 Scripting Commands
- Chapter 12 Interface Commands
- Chapter 13 Interface Testing Commands

Chapter 1: Getting Started

Introduction.....	1.2
How to log-in.....	1.2
How to get command help	1.3
Viewing a list of valid parameters.....	1.3
Completing keywords.....	1.7
Viewing command error messages.....	1.8
How to work with command modes.....	1.9
Entering Privileged Exec commands when in a configuration mode.....	1.12
How to see the current configuration.....	1.14
Default settings.....	1.15
The default configuration script.....	1.16
How to change the password.....	1.17
How to set a management IP address.....	1.17
How to save and boot from the current configuration.....	1.19
How to save to the default configuration file	1.19
How to create and use a new configuration file.....	1.19
How to return to the factory defaults.....	1.21
How to see system information.....	1.22
Viewing overall system information.....	1.22
Viewing temperature, voltage, and fan status.....	1.23
Viewing the serial number.....	1.24
How to set system parameters.....	1.24
How to change the telnet session timeout.....	1.24
How to name the switch.....	1.25
How to display a text banner at login.....	1.26
How to set the time and date	1.27
How to show current settings.....	1.27
How to set the time and date.....	1.27
How to set the timezone	1.28
How to configure summer-time.....	1.28
How to add and remove users	1.29
Pre-encrypted passwords	1.30
How to undo settings	1.31
How to use the <i>no</i> parameter	1.31
How to use the <i>default</i> parameter.....	1.31
How to upgrade the firmware.....	1.32
Controlling “show” command output.....	1.33
Commands available in each mode	1.35
User Exec mode	1.35
Privileged Exec mode.....	1.36
Global Configuration mode.....	1.37
AlliedWare Plus GUI	1.39

Introduction

This chapter introduces a number of commonly-used management features of the AlliedWare Plus™ operating system (OS).

How to log-in

Step 1: Set the console baud rate

The default baud rate is 9600.

By default the AlliedWare Plus™ OS supports VT100 compatible terminals on the console port. This means that the terminal size is 80 columns by 24 rows.

Step 2: Login with manager/friend

The defaults are:

```
username: manager
```

```
password: friend
```

The switch logs you into User Exec mode. From User Exec mode, you can perform high-level diagnostics (some show commands, ping, traceroute etc), start sessions (Telnet, SSH), and change mode.

How to get command help

The following kinds of command help are available:

- lists of valid parameters with brief descriptions (the ? key)
- completion of keywords (the Tab key)
- error messages for incomplete or incorrect syntax

Command Abbreviations

The AlliedWare Plus CLI contains a number of abbreviations for its commands. For example, the show interface command can be entered in the abbreviated form shown below:

awplus#	
sh in vlan100	sh in vlan100
awplus#	
configure terminal24	Enter the Global Configuration mode.
awplus(config)#	
router rip24	Define a RIP routing process and enter the Router mode.
awplus(config-router)#	
network 10.10.11.0/24	Associate networks with the RIP process
awplus(config-router)#	
network 10.10.12.0/24	Associate networks with the RIP process

Viewing a list of valid parameters

To get syntax help, type ? (i.e. "space question mark") after:

- the prompt. This will list all commands available in the mode you are in.
- one or more parameters. This will list parameters that can come next in the partial command.
- one or more letters of a parameter. This will list matching parameters.

Note: The AlliedWare Plus OS only displays one screenful of text at a time, with the prompt "--More--" at the end of each screenful. Press the space bar to display the next screenful or the Q key to return to the command prompt.

Example

To see which commands are available in Privileged Exec mode, enter "?" at the Privileged Exec mode command prompt:

```
awplus# ?
```

This results in the following output:

Figure 1-1: Example output from the ? command

```

Exec commands:
activate      Activate a script
cd            Change the current working directory
clear         Reset functions
clock         Manage clock
configure     Enter configuration mode
copy          Copy from one file to another
debug         Debugging functions (see also 'undebug')
delete        Delete a file
dir           List the files on a filesystem
disable       Turn off privileged mode command
dot1x         IEEE 802.1X Port-Based Access Control
echo          Echo a string
edit          Text Editor
enable        Turn on privileged mode command
erase         Erase the system startup configuration
exit          End current mode and down to previous mode
help          Description of the interactive help system
license       Activate software feature license
logout        Exit from the EXEC
mail          Send an email
mkdir         Make a new directory
move          Rename or move a file
mstat         Show statistics after multiple multicast
              traceroutes
mtrace        Trace multicast path from source to destination
no            Negate a command or set its defaults
ping          Send echo messages
platform      Execute built-in self-tests
pwd           Print the current working directory
quit          Exit current mode and down to previous mode
reboot        Halt and perform a cold restart
reload        Halt and perform a cold restart
remote-command Remote stack member command execution
restart       Restart routing protocol
rmdir         Remove a directory
rmon          Debugging functions (see also 'undebug')
show          Show running system information
ssh           Open an SSH connection
tcpdump       Execute tcpdump
telnet        Open a telnet connection
terminal      Set terminal line parameters
test          Test device functionality
traceroute    Trace route to destination
trigger       Automatic scripted responses to device events
undebug       Disable debugging functions (see also 'debug')
wait          Wait for a specified number of seconds
write         Write running configuration to memory, file or
              terminal

```

Example To see which commands are available in Configuration mode, enter “?” at the Config mode command prompt.

```

awplus# configure terminal
awplus(config)# ?

```

This results in the following output:

Figure 1-2: Example output from the ? command

```
Configure commands:
aaa                Authentication, Authorization and Accounting
access-list        Add an access list entry
arp                Address Resolution Protocol (ARP)
auth-web-server    Web authentication server configuration
                  commands
banner             Define a login banner
bgp                Border Gateway Protocol (BGP)
boot               Boot configuration
class-map          Class map command
clock              Manage clock
crypto             Security Specific Commands
cvlan              Configure C-VLAN parameters
debug              Debugging functions (see also 'undebug')
default            Restore default settings
do                To run exec commands in config mode
dot1x              IEEE 802.1X Port-Based Access Control
enable             Modify enable password parameters
epsr               Ethernet Protection Switching Ring (EPSR)
exception          Configure exception settings
exit               End current mode and down to previous mode
fib                FIB information
help               Description of the interactive help system
hostname           Set system's network name
interface          Select an interface to configure
ip                 Internet Protocol (IP)
ipv6               Internet Protocol version 6 (IPv6)
key                Authentication key management
lacp               LACP commands
line               Configure a terminal line
log                Logging control
loop-protection    Loop Protection
mac                mac address
mail               Send an email
max-fib-routes     Set maximum fib routes number
max-static-routes  Set maximum static routes number
maximum-access-list Maximum access-list entries
maximum-paths      Set multipath numbers installed to FIB
mls                Multi-Layer Switch(L2/L3)
no                 Negate a command or set its defaults
ntp                Configure NTP
ospf               Open Shortest Path First (OSPF)
ping-poll          Ping Polling
platform           Configure global settings for the switch
                  asic
policy-map         Policy map command
radius-server       Radius server
remote-command      Remote stack member command execution
rip                Routing Information Protocol (RIP)
rmon               Remote Monitoring Protocol (RMON)
route-map           Create route-map or enter route-map command
                  mode
router             Enable a routing process
router-id           Router identifier for this system
service            Modify use of network based services
show               Show running system information
snmp-server         Enable the snmp agent
spanning-tree       Spanning tree commands
ssh                Secure Shell
stack              Manage VCS feature
system             System properties
telnet             Configure telnet
trigger            Automatic scripted responses to device
                  events
undebug            Disable debugging functions (see also
                  'debug')
username           Establish User Name Authentication
virtual-server      Virtual-server configuration
vlan               Configure VLAN parameters
vrrp               VRRP configuration
```

Example To see which show commands that start with “i” are available in Privileged Exec mode, enter “?” after show i:

```
awplus# show i?
```

This results in the following output:

Figure 1-3: Example output from the **show i?** command

interface	Select an interface to configure
ip	Internet Protocol (IP)
ipv6	Internet Protocol version 6 (IPv6)

Example To use the ? help to work out the syntax for the clock timezone command, enter the following sequence of commands:

```
awplus(config)# clock ?
```

```
summer-time  Manage summer-time
timezone      Set clock timezone
```

```
awplus(config)# cloc timezone ?
```

```
TIMEZONE  Timezone name, up to 5 characters
```

```
awplus(config)# clock timezone NZST ?
```

```
minus  negative offset
plus   positive offset
```

```
awplus(config)# clock timezone NZST plus ?
```

```
<0-12>  Time zone offset to UTC
```

```
awplus(config)# clock timezone NZST plus 12
```

The above example demonstrates that the ? help only indicates what you can type *next*. For commands that have a series of parameters, like clock timezone, the ? help does not make the number of parameters obvious.

Completing keywords

To complete keywords, type Tab after part of the command.

If only one keyword matches the partial command, the AlliedWare Plus OS fills in that keyword. If multiple keywords match, it lists them.

Example In this example we use Tab completion in successive steps to build the complete command show ip dhcp server summary. We have included “<Tab>” to show where to type the Tab key - this is not displayed on screen.

```
awplus# show ip <Tab>
```

Figure 1-4: Example output after entering the command, **show ip <Tab>**

as-path-access-list	bgp	community-list
dhcp	dhcp-relay	domain-list
domain-name	extcommunity-list	filter
forwarding	igmp	interface
irdp	mroute	mvif
name-server	nat	ospf
pim	protocols	rip
route	rpf	

```
awplus# show ip d<Tab>
```

Figure 1-5: Example output after entering the command, **show ip d<Tab>**

dhcp	dhcp-relay	domain-list	domain-name

```
awplus# show ip dhcp <Tab>
```

Figure 1-6: Example output from the **show ip dhcp <Tab>** command

binding	pool	server

```
awplus# show ip dhcp server s<Tab>
```

Figure 1-7: Example output from the **show ip dhcp s<Tab>** command

statistics	summary

Viewing command error messages

The switch displays the following generic error messages about command input:

% Incomplete command—this message indicates that the command requires more parameters. Use the ? help to find out what other parameters are available.

```
awplus# interface
```

```
% Incomplete command.
```

% Invalid input detected at '^' marker—this indicates that the switch could not process the command you entered. The switch also prints the command and marks the first invalid character by putting a '^' under it. Note that you may get this error if you enter a command in the wrong mode, as the following output shows.

```
awplus# interface port1.0.1
```

```
interface port1.0.1
```

```
^
```

```
% Invalid input detected at '^' marker.
```

% Unrecognized command—when you try to use ? help and get this message, it indicates that the switch can not provide help on the command because it does not recognize it. This means the command does not exist, or that you have entered it in the wrong mode, as the following output shows.

```
awplus# interface ?
```

```
% Unrecognized command
```


Note: The AlliedWare Plus OS does not tell you when commands are successful. If it does not display an error message, you can assume the command was successful.

How to work with command modes

The following figure shows the command mode hierarchy and the commands you use to move to lower-level modes.

Multiple users can telnet and issue commands using the Exec mode and the Privileged Exec mode. However, only one user is allowed to use the Configure mode at a time. This prevents multiple users from issuing configuration commands simultaneously.

Figure 1-8: AlliedWare Plus CLI modes



User Exec mode User Exec mode is the mode you log into on the switch.

It lets you perform high-level diagnostics (show commands, ping, traceroute etc), start sessions (Telnet, SSH), and change mode.

The default User Exec mode prompt is `awplus>`.

Privileged Exec mode To change from User Exec to Privileged Exec mode, enter the command:

```
awplus> enable
```

Privileged Exec mode is the main mode for monitoring—for example, running show commands and debugging. From Privileged Exec mode, you can do all the commands from User Exec mode plus many system commands.

The default Privileged Exec mode prompt is `awplus#`.

Global Configuration mode

To change from Privileged Exec to Global Configuration mode, enter the command:

```
awplus# configure terminal
```

From Global Configuration mode, you can configure most aspects of the switch.

The default Global Configuration mode prompt is `awplus(config)#`.

Lower-level configuration modes

A number of features are configured by entering a lower-level mode from Global Configuration mode. The following table lists these features.

Table 1-1: Features configured using the lower level modes

Mode	What it configures	Command	Default prompt
Interface	Switch ports, VLANs, the management Eth port.	<code>interface <name></code>	<code>awplus(config-if)#</code>
Class map	QoS classes, which isolate and name specific traffic flows (classes) from all other traffic.	<code>class-map <name></code>	<code>awplus(config-cmap)#</code>
EPSR	Ethernet Protection Switching Ring, a loop protection mechanism with extremely fast convergence times.	<code>epsr configuration</code>	<code>awplus(config-epsr)#</code>
Line	Console port settings or virtual terminal settings for telnet.	<code>line console 0</code> <code>line vty number</code>	<code>awplus(config-line)#</code>
Ping poll	Ping polling, which checks whether specified devices are reachable or not.	<code>ping-poll <number></code>	<code>awplus(config-ping-poll)#</code>
Policy map	QoS policies, a collection of user-defined QoS classes and the default class.	<code>policy-map <name></code>	<code>awplus(config-pmap)#</code>
Policy map class	The QoS actions to take on a class-map, and which class-maps to associate with a QoS policy. This mode is a sub-mode of Policy map mode.	(in Policy map mode) <code>class <name></code>	<code>awplus(config-pmap-c)#</code>
Route map	Route maps, which select routes to include or exclude from the switch's routing table and/or route advertisements.	<code>route-map name deny permit <entry-number></code>	<code>awplus(config-route-map)#</code>
Router	Routing using BGP, IP, IPv6, OSPF, RIP, or VRRP.	<code>router <protocol> other-parameters></code>	<code>awplus(config-router)#</code>
MST	Multiple Spanning Tree Protocol.	<code>spanning-tree mst configuration</code>	<code>awplus(config-mst)#</code>
Trigger	Triggers, which run configuration scripts in response to events.	<code>trigger <number></code>	<code>awplus(config-trigger)#</code>
VLAN database	VLANs.	<code>vlan database</code>	<code>awplus(config-vlan)#</code>


Some protocols have commands in both Global Configuration mode and lower-level configuration modes. For example, to configure MSTP, you use:

- Global Configuration mode to select MSTP as the spanning tree mode
- MST mode to create instances and specify other MSTP settings
- Interface Configuration mode to associate the instances with the appropriate ports.

Returning to higher-level modes

The following figure shows the commands to use to move from a lower-level mode to a higher-level mode.

Figure 1-9: Returning to higher-level modes



Examples To go from Interface Configuration to Global Configuration mode:

```
awplus(config-if)# exit
awplus(config)#
```

To go from Interface Configuration to Privileged Exec mode:

```
awplus(config-if)# end
awplus#
```

To go from Privileged Exec to User Exec:

```
awplus# exit
awplus>
```

Entering Privileged Exec commands when in a configuration mode

As you configure the switch you will be constantly entering various show commands to confirm your configuration. This requires constantly changing between configuration modes and Privileged Exec mode.

However, you can run Privileged Exec commands without changing mode, by using the command:

```
do <command you want to run>
```

You cannot use the ? help to find out command syntax when using the **do** command.

Example To display information about the IP interfaces when in Global Configuration mode, enter the command:

This results in the following output:

```
awplus(config)# do show ip int brief
```

Figure 1-10: Example output after entering the command, do show ip int brief

Interface	IP-Address	Status	Protocol
eth0	unassigned	admin up	running
vlan2	unassigned	admin up	running

Main Command Modes Summary

Table 1-2 lists the main command modes, how to access each mode, the prompt for each command mode. From any mode, use exit to move up a mode, or end to move to the Privileged Exec mode.

Table 1-2: Main command modes and modal prompts

Present Mode	Prompt	Command	New Mode
User Exec	awplus>	enable	Privileged Exec
Privileged Exec	awplus#	configure terminal	Global Configuration
Global Configuration	awplus(config)#	vlan database	VLAN Configuration
Global Configuration	awplus(config)#	line vt <line-number>	Line Configuration

Sub-modes Summary The table below lists the sub-modes, how to access each mode, the prompt for each command mode, and how to exit that mode. Prompts listed use the default awplus.

Table 1-3: Sub-modes, prompt for each sub-mode, how to access each sub-mode, and how to exit each sub-mode

Mode	Prompt and Command Examples	How to Enter Mode	How to Exit Mode
Ping Poll Configuration	awplus#configure terminal awplus(config)#ping-poll awplus(config-ping-poll)#	Use the ping-poll command available from the Global Configuration mode.	Use the exit command to return to the Global Configuration mode. Use the end command to return to the Privileged Exec mode.
Route Map Configuration	awplus#configure terminal awplus(config)#route-map route1 permit 1 awplus(config-route-map)#	Use the route-map command available from the Global Configuration mode.	Use the exit command to return to the Global Configuration mode. Use the end command to return to the Privileged Exec mode.
Router Configuration	awplus#configure terminal awplus(config)#router rip awplus(config-router)#	Use one of the following commands available from the Global Configuration mode: ■ router rip ■ router ipv6 rip ■ router ospf ■ router bgp ■ router vrrp	Use the exit command to return to the Global Configuration mode. Use the end command to return to the Privileged Exec mode.
MST (Multiple Spanning Tree) Configuration	awplus#configure terminal awplus(config)#spanning-tree mst configuration awplus(config-mst)#	Use the spanning-tree mst configuration command available from the Global Configuration mode.	Use the exit command to return to the Global Configuration mode. Use the end command to return to the Privileged Exec mode.
Trigger Configuration	awplus#configure terminal awplus(config)#trigger 1 awplus(config-trigger)#	Use the trigger command from Global Configuration mode.	Use the exit command to return to the Global Configuration mode. Use the end command to return to the Privileged Exec mode.
EPSR Configuration	awplus#configure terminal awplus(config)#epsr configuration awplus(config-epsr)#	Use the epsr configuration command available from the Global Configuration mode.	Use the exit command to return to the Global Configuration mode. Use the end command to return to the Privileged Exec mode.
Class Map Configuration (QoS)	awplus#configure terminal awplus(config)#class map cmap1 awplus(config-cmap)#	Use the class-map command available from the Global Configuration mode.	Use the exit command to return to the Global Configuration mode. Use the end command to return to the Privileged Exec mode.
Policy Map Configuration (QoS)	awplus#configure terminal awplus(config)#policy-map pmap1 awplus(config-pmap)#	Use the policy-map command available from the Global Configuration mode.	Use the exit command to return to the Global Configuration mode. Use the end command to return to the Privileged Exec mode.

Table 1-3: Sub-modes, prompt for each sub-mode, how to access each sub-mode, and how to exit each sub-mode

Mode	Prompt and Command Examples	How to Enter Mode	How to Exit Mode
Policy Map	<code>awplus#configure</code>	Use the <code>class</code> command available from the Policy map mode.	Use the <code>exit</code> command to return to the Policy Map Configuration mode. Use the <code>end</code> command to return to the Privileged Exec mode.
Class	<code>terminal</code>		
Configuration (QoS)	<code>awplus(config)#policy-map</code> <code>pmap1</code>		
	<code>awplus(config-pmap)#class</code> <code>cmap1</code>		
	<code>awplus(config-pmap-c)#</code>		

How to see the current configuration

The current configuration is called the running-config. To see it, enter the following command in either Privileged Exec mode or any configuration mode:

```
awplus# show running-config
```

To see only part of the current configuration, enter the command:

```
awplus# show running-config |include <word>
```

This displays only the lines that contain *word*.

To start the display at a particular place, enter the command:

```
awplus# show running-config |begin <word>
```

This searches the running-config for the first instance of *word* and begins the display with that line.

Note: The **show running-config** command works in all modes except User Exec mode.

Default settings

When the switch first starts up with the AlliedWare Plus OS, it applies default settings and copies these defaults dynamically into its running-config.

These default settings mean that the AlliedWare Plus OS:

- encrypts passwords, such as user passwords
- records log message priority in log messages
- turns on the telnet server so that you can telnet to the switch
- enables the switch to look up domain names (but for domain name lookups to work, you have to configure a DNS server)
- turns off L3 multicast packet switching in the switch's hardware. This prevents L3 multicast from flooding the switch's CPU in its default state as an L2 switch
- sets the maximum number of ECMP routes to 8
- turns on RSTP on all ports. Note that the ports are not set to be edge ports
- sets all the switch ports to access mode. This means they are untagged ports, suitable for connecting to hosts
- creates VLAN 1 and adds all the switch ports to it
- allows logins on the serial console port
- allows logins on VTY sessions (for telnet etc)
- has switching enabled, so layer 2 traffic is forwarded appropriately without further configuration
- allocates all the routing table memory space to IPv4 and IPv6 routes
- has ports set to autonegotiate their speed and duplex mode
- has copper ports set to auto MDI/MDI-X mode

The default configuration script

Most of the above default settings are in the form of commands, which the switch copies to its running-config when it first boots up.

The switch stores a copy of the default configuration commands in the file, default.cfg and uses this as its default start-up file.

For more information about start-up files, see [“How to save and boot from the current configuration” on page 1.19.](#)

The following table shows the contents of the default file.

Contents of default file	Description
!	An empty comment line (comments begin with an !).
service password-encryption	Forces passwords in the script to be encrypted.
!	
log record-priority	Records log message priority.
username manager privilege 15 password 8 \$1\$b!oVec4D\$!wO!GPr7YqoExA0GVasdEO	Specifies the password for the manager user
service telnet	Turns on the telnet server.
!	
ip domain-lookup	Allows domain name lookups.
!	
no ip multicast-routing	Turns off L3 multicast packet switching in the switch hardware.
!	
maximum-paths 8	Sets maximum number of ECMP routes.
spanning-tree mode rstp	Turns on RSTP.
!	
interface eth0	A heading for any configuration settings for the management eth0 port. There are no eth0 settings.
!	
interface port1.0.1-1.0.24	Sets each switch port to access mode.
switchport	
switchport mode access	
!	
interface vlan1	Creates VLAN 1.
!	
line con 0	A heading for any configuration settings for the console port. There are no console port settings.
line vty 0 32	A heading for any configuration settings for VTY sessions. There are no VTY session settings.
!	
end	

How to change the password

To change the password for the manager account, enter Global Configuration mode and enter the following command:

```
awplus(config)# username manager password <new-password>
```

The password can contain any printable character and is case sensitive.

How to set a management IP address

This section describes how to set an IP address on the eth0 management port.

Step 1: If desired, check the current configuration

After logging in, enter Privileged Exec mode by using the command:

```
awplus>enable
```

Then check the current configuration by using one of the following commands:

```
awplus# show ip interface eth0 brief
```

This results in the following output:

Interface	IP-Address	Status	Protocol
eth0	172.28.8.200	admin up	running

```
awplus# show running-config interface eth0
```

This results in the following output:

```
!
interface eth0
 ip address 172.28.8.200/16
!
```

Step 2: Enter Interface Configuration mode for the eth0 interface

Enter Global Configuration mode and enter the command:

```
awplus(config)# interface eth0
```

Step 3: Enter the IP address and mask

Enter the command:

```
awplus(config-if)# ip address <address/mask>
```

For example, to set the address to 172.28.8.210/16, enter the command:

```
awplus(config-if)# ip address 172.28.8.210/16
```

How to save and boot from the current configuration

This section tells you how to save your configuration and run the saved configuration when the switch starts up.

You can either:

- save the configuration to the switch's default configuration file (called "default.cfg"). By default, the switch uses that file at start-up.
- create a new configuration file and set the switch to use the new configuration file at start-up.

How to save to the default configuration file

Enter Privileged Exec mode and enter the command:

```
awplus# copy running-config startup-config
```

The parameter startup-config is a short-cut for the current boot configuration file, which will be the default configuration file unless you have changed it, as described in the next section.

How to create and use a new configuration file

Step 1: Copy the current configuration to a new file

Enter Privileged Exec mode and enter the command:

```
awplus# copy running-config <filename>.cfg
```

Example To save the current configuration in a file called example.cfg, enter the command

```
awplus# copy running-config example.cfg
```

Step 2: Set the switch to use the new file at startup

To run the new file's configuration when the switch starts up, enter Global Configuration mode and enter the command:

```
awplus(config)# boot config-file <filename>.cfg
```

Example To run the commands in example.cfg on startup, enter the command

```
awplus(config)# boot config-file example.cfg
```

Step 3: Display the new settings

To see the files that the switch uses at startup, enter Privileged Exec mode and enter the command:

```
awplus# show boot
```

The output looks like this:

```
Boot configuration
-----
Current software   : r1-5.3.2.rel
Current boot image : flash:/r1-5.3.2.rel
Backup boot image : Not set
Default boot config: flash:/.configs/default.cfg
Current boot config: flash:/example.cfg (file exists)
```

Step 4: Continue updating the file when you change the configuration

When you next want to save the current configuration, enter Privileged Exec mode and enter the command:

```
awplus# copy running-config startup-config
```

The parameter startup-config is a short-cut for the current boot configuration file.

How to return to the factory defaults

The switch dynamically adds the default settings to the running-config at start-up if the default file is not present. This section describes how to use this feature to return to the factory defaults.

Note: After reboot the show running-config output will show the default factory settings for your switch once you have removed the default.cfg file. To recreate the default.cfg file enter copy running-config startup-config. When you enter copy running-config startup-config commands the default.cfg file is updated with the startup-config.

Completely restore defaults

To completely remove your configuration and return to the factory default configuration, delete or rename the default file and make sure no other file is set as the start-up configuration file.

To find the location of the default boot configuration file, enter Privileged Exec mode and enter the command:

```
awplus# show boot
```

To delete the default file when it is the current boot configuration file, enter Privileged Exec mode and enter either of the commands:

```
awplus# delete force <filename>
```

or:

```
awplus# erase startup-config
```

Note that erasing startup-config deletes the current boot configuration file—it does not simply stop the file from being the boot file.

To make sure that no other file is loaded at start-up, enter Global Configuration mode and enter the command:

```
awplus(config)# no boot config-file
```

Partially restore defaults

To partially restore the default settings, make a configuration file that contains the settings you want to keep and set this as the start-up configuration file. On start-up, the switch will add the missing settings to the running-config.

For example, to use default settings but still keep an IP address on the eth0 management port, create a file like the following one and set it as the boot configuration file:

```
awplus# show file eth0-ip.cfg
```

The output looks like this:

```
!
interface eth0
 ip address 172.28.8.210/16
!
ip route 0.0.0.0/0 172.28.0.1
!
end
```

How to see system information

This section describes how to view the following system information:

- overview information
- details of temperature and voltage
- serial number

Viewing overall system information

To display an overview of the switch hardware, software, and system settings, enter User Exec or Privileged Exec mode and enter the command:

```
awplus# show system
```

The output looks like this:

Figure 1-11:

```
Switch System Status                               Wed Dec  3 13:01:55 2008
Board      ID  Bay  Board Name                      Rev  Serial number
-----
Base       289      x600-24Ts                      A-0  G1Q67B002
-----

RAM:  Total: 514260 kB Free: 397916 kB
Flash: 63.0MB Used: 32.2MB Available: 30.8MB
-----

Environment Status : Normal
Uptime              : 0 days 02:20:16
Bootloader version  : 1.1.0

Current software    : r6-5.3.1.rel
Software version    : 5.3.1
Build date          : Mon Dec  13:00:27 NZDT 2008

Current boot config: flash:/default.cfg (file exists)
Territory           : usa

System Name

System Contact

System Location
```

Viewing temperature, voltage, and fan status

The switch monitors the environmental status of the switch and its power supplies and fan. To display this information, enter User Exec or Privileged Exec mode and enter the command:

```
awplus# show system environment
```

The output looks like the following figure.

Environment Monitoring Status

Overall Status: Normal

Resource ID: 2 Name: RPS

ID	Sensor (Units)	Reading	Low Limit	High Limit	Status
1	Primary Power Output	Yes	-	-	Ok
2	RPS Present	No	-	-	Ok
3	RPS Power Output	No	-	-	Ok
4	RPS Fan 1 Good	No	-	-	Ok
5	RPS Fan 2 Good	No	-	-	Ok

Resource ID: 3 Name: x600-24Ts

ID	Sensor (Units)	Reading	Low Limit	High Limit	Status
1	Fan: Fan 1 (Rpm)	6818	5000	-	Ok
2	Fan: Fan 2 (Rpm)	6818	5000	-	Ok
3	Voltage: 2.5V (Volts)	2.474	2.344	2.865	Ok
4	Voltage: Battery (Volts)	3.108	2.700	3.586	Ok
5	Voltage: 3.3V (Volts)	3.266	2.973	3.627	Ok
6	Voltage: 5V (Volts)	5.026	4.505	5.495	Ok
7	Voltage: 12V (Volts)	11.625	10.813	13.188	Ok
8	Voltage: 1.25V (Volts)	1.223	1.125	1.378	Ok
9	Temp: Internal (Degrees C)	31	45 (Hyst)	50	Ok
10	Fan: Fan 3 (Rpm)	6750	5000	-	Ok
11	Fan: Fan 4 (Rpm)	6618	5000	-	Ok
12	Voltage: 2.5V (Volts)	2.461	2.344	2.865	Ok
13	Voltage: 1.2V (Volts)	1.167	1.083	1.322	Ok
14	Voltage: 3.3V (Volts)	3.266	2.973	3.627	Ok
15	Voltage: 5V (Volts)	5.026	4.505	5.495	Ok
16	Voltage: 12V (Volts)	11.563	10.813	13.188	Ok
17	Voltage: 1.8V (Volts)	1.772	1.617	1.983	Ok
18	Temp: Internal (Degrees C)	29	40 (Hyst)	45	Ok

Viewing the serial number

The switch's serial number is displayed in the output of the [show system command on page 8.32](#), but for convenience, you can also display it by itself. To do this, enter User Exec or Privileged Exec mode and enter the command:

```
awplus# show system serialnumber
```

The output looks like this:

```
P1FY7502C
```

How to set system parameters

You can set system parameters to personalize the switch and make it easy to identify it when troubleshooting. This section describes how to configure the following system parameters:

- [telnet session timeout](#)
- [switch name](#)
- [login banner](#)

How to change the telnet session timeout

By default, telnet sessions time out after 10 minutes of idle time. If desired, you can change this.

To change the timeout for all telnet sessions, enter Global Configuration mode and enter the commands:

```
awplus(config)# line vty 0 32
awplus(config-line)# exec-timeout <new-timeout>
```

The new timeout value only applies to new sessions, not current sessions.

Examples To set the timeout to 30 minutes, enter the command:

```
awplus(config-line)# exec-timeout 30
```

To set the timeout to 30 seconds, enter the command:

```
awplus(config-line)# exec-timeout 0 30
```

To set the timeout to infinity, so that sessions never time out, enter either of the commands:

```
awplus(config-line)# no exec-timeout
```

```
awplus(config-line)# exec-timeout 0 0
```


How to name the switch

To give the switch a name, enter Global Configuration mode and enter the command:

```
awplus(config)# hostname <name>
```

For example, to name the switch “switch1.mycompany.com”:

```
awplus(config)# hostname switch1.mycompany.com
```

The prompt displays the new name:

```
awplusswitch1.mycompany.com(config)#
```

The name can contain hyphens and underscore characters.

However, the name must be a single word, as the following example shows.

```
awplus(config)#hostname switch1.mycompany.com more words
hostname switch1.mycompany.com more words
                                ^
% Invalid input detected at '^' marker.
```

It also cannot be surrounded by quote marks, as the following example shows.

```
awplus(config)#hostname "switch1.mycompany.com more words"
% Please specify string starting with alphabet
```

Removing the name

To remove the hostname, enter the command:

```
awplusswitch1.mycompany.com(config)# no hostname
```

The prompt changes back to the default prompt:

```
awplus(config)#
```

How to display a text banner at login

By default, the switch displays the AlliedWare Plus OS version and build date at login. You can customize this by changing the *Message of the Day* (MOTD) banner.

To enter a new MOTD banner, enter Global Configuration mode and enter the command:

```
awplus(config)# banner motd <banner-text>
```

The text can contain spaces and other printable characters. You do not have to surround words with quote marks.

Example To display “this is a new banner” when someone logs in, enter the command:

```
awplus(config)# banner motd this is a new banner
```

This results in the following output at login:

```
awplus login: manager
Password:
this is a new banner
awplus>
```

Removing the banner

To return to the default banner (AlliedWare Plus OS version and build date), enter the command:

```
awplus(config)# banner motd default
```

To remove the banner instead of replacing it, enter the command:

```
awplus(config)# no banner motd
```

How to set the time and date

There are three aspects to setting the time and date:

- setting the current time and date (“How to set the time and date” on page 1.27)
- setting the timezone (“How to set the timezone” on page 1.28)
- configuring the switch to automatically change the time when summer-time begins and ends (“How to configure summer-time” on page 1.28)

Instead of manually setting the time, you can use NTP to automatically get the time from another device.

How to show current settings

To display the current time, timezone and date, enter Privileged Exec mode and enter the command:

```
awplus# show clock
```

The output looks like this:

```
UTC Time:   Wed,  3 Dec 2008 16:08:14 +0000
Timezone:   UTC
Timezone Offset: +00:00
Summer time zone: None
```

How to set the time and date

To set the time and date, enter Privileged Exec mode and enter the `clock set` command:

```
clock set <hh:mm:ss> <day> <month> <year>
```

where:

- *hh* is two digits giving the hours in 24-hour format (e.g. **14**)
- *mm* is two digits giving the minutes
- *ss* is two digits giving the seconds
- *day* is two digits giving the day of the month
- *month* is the first three letters of the month name (e.g. **sep**)
- *year* is four digits giving the year

Example To set the time to 14:00:00 on 25 January 2008, use the command:

```
awplus# clock set 14:00:00 25 jan 2008
```

How to set the timezone

To set the timezone, enter Global Configuration mode and enter the `clock timezone` command:

```
clock timezone <timezone-name> {plus|minus} <0-12>
```

The `<timezone-name>` can be any string up to 6 characters long.

To return the timezone to UTC+0, enter the command:

```
awplus(config)# no clock timezone
```

Example To set the timezone to Eastern Standard Time, use the command:

```
awplus(config)# clock timezone EST minus 5
```

How to configure summer-time

There are two approaches for setting summer-time:

- *recurring*, when you specify the week when summer-time starts and ends and each year the switch changes the time at those weeks. For example, Eastern Daylight Time (EDT) starts at 2 am on the second Sunday in March and ends at 2 am on the first Sunday in November.
- *date-based*, when you specify the start and end dates for summer-time for a particular year. For example, Eastern Daylight Time (EDT) starts at 2 am on Sunday, 8 March 2008 and ends at 2 am on Sunday, 2 November 2008.

Recurring To set summer-time with recurring dates, enter Global Configuration mode and enter the `clock summer-time recurring` command:

```
clock summer-time <zone-name> recurring <start-week> <start-day> <start-month> <start-time> <end-week> <end-day> <end-month> <end-time> <1-180>
```

The `<zone-name>` can be any string up to 6 characters long.

The `<start-time>` and `<end-time>` are in the form `hh:mm`, in 24-hour time.

Note that if you specify 5 for the week, this changes the time on the last day of the month, not the 5th week.

Example To configure EDT, enter the command:

```
awplus(config)# clock summer-time EDT recurring 2 Sun Mar 02:00
1 Sun Nov 02:00 60
```

Date-based To set summer-time for a single year, enter Global Configuration mode and enter the `clock summer-time date` command:

```
clock summer-time <zone-name> date <start-day> <start-month> <start-year> <start-time> <end-day> <end-month> <end-year> <end-time> <1-180>
```

The `<zone-name>` can be any string up to 6 characters long.

The `<start-time>` and `<end-time>` are in the form `hh:mm`, in 24-hour time.

Example For example, to configure EDT for 2008 enter the command:

```
awplus(config)# clock summer-time EDT date 8 Mar 2008 02:00 2
Nov 2008 02:00 60
```

How to add and remove users

Adding users To add a new user with administrative rights, enter Global Configuration mode and enter the command:

```
awplus(config)# username <name> privilege 15 password
<password>
```

Both <name> and <password> can contain any printable character and are case sensitive.

The AlliedWare Plus OS gives you a choice of 1 or 15 for the privilege level. Level 1 users are limited to User Exec mode so you need to set most users to level 15.

For example, to add user Bob with password 123\$%^, enter the command:

```
awplus(config)# username Bob privilege 15 password
123$%^
```

Removing users To remove a user, enter Global Configuration mode and enter the command:

```
no username <name>
```

For example, to remove user Bob, enter the command:

```
awplus(config)# no username Bob
```

You can delete any user except the user called “manager”, including the user you are currently logged in as.

Displaying users To list the currently logged-in users, enter User Exec or Privileged Exec mode and enter the command:

```
awplus# show users
```

The output looks like this:

Line	User	Host(s)	Idle	Location
130 vty 0	manager	idle	01:36:37	10.33.27.11
131 vty 1	Bob	idle	00:00:00	10.33.22.13

To list all configured users, enter User Exec or Privileged Exec mode and enter the command:

```
awplus# show running-config |include username
```

The output looks like this:

```
username manager privilege 15 password 8 $1$bJoVec4D$JwOJGPr7YqoExA0GVasdE0
username Bob privilege 15 password 8 $1$gXJLY8dw$iqkMXLgQxbzSOutNUa5E2.
```

Pre-encrypted passwords

The running-config output above includes the number 8 after the password parameter. This indicates that the password is displayed in its encrypted form.

You can enter the number 8 and a pre-encrypted password on the command line. You may want to pre-encrypt passwords if you need to load them onto switches via an insecure method (such as HTTP, or by emailing them to remote users).

Caution *Only enter the number 8 if you are entering a pre-encrypted password—otherwise, you will be unable to log in using the password and will be unable to access the switch through that username. The next section describes why.*

Testing this feature

If you want to test the effect of this, create a new user for the test instead of using the manager user. The test stops you from logging in as the test user, so you need to have the manager user available to log in as.

The following output shows how specifying the number 8 puts the password into the running-config exactly as you typed it:

```
awplus(config)#username Bob privilege 15 password 8 friend
awplus(config)#show running-config |include username Bob
username Bob privilege 15 password 8 friend
```

After entering the command above, logging in as “Bob” with a password of “friend” does not work. This is because the switch takes the password you enter (“friend”), hashes it, and compares the hash with the string in the running-config (“friend”). The hashed value and “friend” are not the same, so the switch rejects the login.

How to undo settings

There are two possibilities for undoing settings: the `no` parameter and the default parameter.

How to use the *no* parameter

To undo most settings, simply re-enter the first parameters of the configuration command with the parameter `no` before them.

Example You can set the timezone to Eastern Standard Time by entering the command:

```
awplus(config)# clock timezone EST minus 5
```

To remove the timezone setting, enter the command:

```
awplus(config)# no clock timezone
```

How to use the *default* parameter

Some commands have a default parameter that returns the feature to its default setting.

Example You can change the login banner to “this is a new banner” by entering the command:

```
awplus(config)# banner motd this is a new banner
```

To return to the default banner, enter the command:

```
awplus(config)# banner motd default
```

Note that this command also has a `no` parameter that lets you remove the banner altogether.

How to upgrade the firmware

New releases of the AlliedWare Plus OS become available regularly. Contact your customer support representative for more information.

Step 1: [Put the new release onto your TFTP server](#)

Step 2: [If necessary, create space in the switch's Flash memory for the new release](#)

Note that you cannot delete the current release file.

To see how much space is free, use the command:

```
awplus# show file system
```

Step 3: [Copy the new release from your TFTP server onto the switch](#)

Follow the instructions in [“Copying with Trivial File Transfer Protocol \(TFTP\)”](#) on page 6.12.

Step 4: [Set the switch to boot from the new release](#)

Enter Global Configuration mode and enter the command:

```
awplus(config)# boot system <filename>.rel
```

Step 5: [Check the boot settings](#)

Enter Privileged Exec mode and enter the command:

```
awplus# show boot
```

Step 6: [Reboot](#)

Enter Privileged Exec mode and enter the command:

```
awplus# reload
```


Controlling “show” command output

You can control the output of show commands by using the | and > or >> tokens in the following ways:

- To display only part of the output, follow the command with | and then other keywords (see [Output Modifiers](#) below)
- To save the output to a file, follow the command with > *filename*
- To append the output to an existing file, follow the command with >> *filename*

Using the ? after typing the show command displays the following information about these tokens:

```
awplus# show users
```

```
| Output modifiers
> Output redirection
>> Output redirection (append)
```

Output Modifiers Type the | (vertical bar) to use Output modifiers.

```
append      Append output
begin       Begin with the first line that contains matching output
exclude     Exclude lines that contain matching output
include     Include lines that contain matching output
redirect    Redirect output
```

Begin The begin parameter causes the display to begin at the first line that contains the input string.

```
awplus# show run | begin eth0
```

```
...skipping
interface eth0
 ip address 192.168.14.1
!!
line con 0
 login
line vty 0 4
 login
!
end
```

Exclude The exclude parameter excludes all lines of output that contain the input string. In the following output all lines containing the word “input” are excluded:

```
awplus# show interface eth0 | exclude input
```

```
Interface eth0
Scope: both
Hardware is Ethernet, address is 192.168.14.1
index 3 metric 1 mtu 1500 <UP,BROADCAST,RUNNING,MULTICAST>
VRF Binding: Not bound
Label switching is disabled
No Virtual Circuit configured
Administrative Group(s): None
DSTE Bandwidth Constraint Mode is MAM
  output packets 4438, bytes 394940, dropped 0
  output errors 0, aborted 0, carrier 0, fifo 0, heartbeat 0,
window 0
  collisions 0
```

Include The include parameter includes only those lines of output that contain the input string. In the output below, all lines containing the word “input” are included:

```
awplus# show interface eth0 | include input
```

```
  input packets 80434552, bytes 2147483647, dropped 0, multicast
packets 0
  input errors 0, length 0, overrun 0, CRC 0, frame 0, fifo 1,
missed 0
```

Redirect The redirect parameter puts the lines of output into the specified file. If the file already exists, the new output overwrites the file's contents; the new output is not appended to the existing file contents.

| redirect and > are synonyms.

```
awplus# show history | redirect history.txt
```

Output Redirection The output redirection token > puts the lines of output into the specified file. If the file already exists, the new output overwrites the file's contents; the new output is not appended to the existing file contents.

| redirect and > are synonyms.

```
awplus# show history > history.txt
```

Append Output The append output token >> adds the lines of output into the specified file. The file must already exist, for the new output to be added to the end of the file's contents; the new output is appended to the existing file contents.

| append and >> are synonyms.

```
awplus# show history >> history.txt
```

Commands available in each mode

This appendix lists the commands available in the following command modes:

- “User Exec mode” on page 1.35
- “Privileged Exec mode” on page 1.36
- “Global Configuration mode” on page 1.37

User Exec mode

> ?

Exec commands:

clear	Reset functions
debug	Debugging functions (see also 'undebug')
disable	Turn off privileged mode command
echo	Echo a string
enable	Turn on privileged mode command
exit	End current mode and down to previous mode
help	Description of the interactive help system
logout	Exit from the EXEC
mstat	Show statistics after multiple multicast traceroutes
mtrace	Trace multicast path from source to destination
no	Negate a command or set its defaults
ping	Send echo messages
quit	Exit current mode and down to previous mode
remote-command	Remote stack member command execution
rmon	Debugging functions (see also 'undebug')
show	Show running system information
ssh	Open an SSH connection
telnet	Open a telnet connection
terminal	Set terminal line parameters
traceroute	Trace route to destination

Privileged Exec mode

awplus# ?

Exec commands:

activate	Activate a script
cd	Change the current working directory
clear	Reset functions
clock	Manage clock
configure	Enter configuration mode
copy	Copy from one file to another
debug	Debugging functions (see also 'undebug')
delete	Delete a file
dir	List the files on a filesystem
disable	Turn off privileged mode command
dot1x	IEEE 802.1X Port-Based Access Control
echo	Echo a string
edit	Text Editor
enable	Turn on privileged mode command
erase	Erase the system startup configuration
exit	End current mode and down to previous mode
help	Description of the interactive help system
license	Activate software feature license
logout	Exit from the EXEC
mail	Send an email
mkdir	Make a new directory
move	Rename or move a file
mstat	Show statistics after multiple multicast traceroutes
mtrace	Trace multicast path from source to destination
no	Negate a command or set its defaults
ping	Send echo messages
platform	Execute built-in self-tests
pwd	Print the current working directory
quit	Exit current mode and down to previous mode
reboot	Halt and perform a cold restart
reload	Halt and perform a cold restart
remote-command	Remote stack member command execution
restart	Restart routing protocol
rmdir	Remove a directory
rmon	Debugging functions (see also 'undebug')
show	Show running system information
ssh	Open an SSH connection
tcpdump	Execute tcpdump

telnet	Open a telnet connection
terminal	Set terminal line parameters
test	Test device functionality
traceroute	Trace route to destination
trigger	Automatic scripted responses to device events
undebug	Disable debugging functions (see also 'debug')
wait	Wait for a specified number of seconds
write	Write running configuration to memory, file or terminal

Global Configuration mode

awplus(config)# ?

Configure commands:

access-list	Add an access list entry
arp	Address Resolution Protocol (ARP)
auth-web-server	Web authentication server configuration commands
banner	Define a login banner
bgp	Border Gateway Protocol (BGP)
boot	Boot configuration
class-map	Class map command
clock	Manage clock
crypto	Security Specific Commands
cvlan	Configure C-VLAN parameters
debug	Debugging functions (see also 'undebug')
default	Restore default settings
do	To run exec commands in config mode
dot1x	IEEE 802.1X Port-Based Access Control
enable	Modify enable password parameters
epsr	Ethernet Protection Switching Ring (EPSR)
exception	Configure exception settings
exit	End current mode and down to previous mode
fib	FIB information
help	Description of the interactive help system
hostname	Set system's network name
interface	Select an interface to configure
ip	Internet Protocol (IP)
ipv6	Internet Protocol version 6 (IPv6)
key	Authentication key management
lACP	LACP commands
line	Configure a terminal line

log	Logging control
loop-protection	Loop Protection
mac	mac address
mail	Send an email
max-fib-routes	Set maximum fib routes number
max-static-routes	Set maximum static routes number
maximum-access-list	Maximum access-list entries
maximum-paths	Set multipath numbers installed to FIB
mls	Multi-Layer Switch(L2/L3)
no	Negate a command or set its defaults
ntp	Configure NTP
ospf	Open Shortest Path First (OSPF)
ping-poll	Ping Polling
platform	Configure global settings for the switch asic
policy-map	Policy map command
radius-server	RADIUS server configuration commands
rip	Routing Information Protocol (RIP)
rmon	Remote Monitoring Protocol (RMON)
route-map	Create route-map or enter route-map command mode
router	Enable a routing process
router-id	Router identifier for this system
service	Modify use of network based services
show	Show running system information
snmp-server	Manage snmp server
spanning-tree	Spanning tree commands
ssh	Secure Shell
stack	Virtual Chassis Stacking (VCS)
system	System properties
telnet	Configure telnet
trigger	Select a trigger to configure
undebg	Disable debugging functions (see also 'debug')
username	Establish User Name Authentication
virtual-server	Virtual-server configuration
vlan	Configure VLAN parameters
vrrp	VRRP configuration

AlliedWare Plus GUI

Information on loading and using the AlliedWare Plus GUI is outside the scope of the main body of this reference manual. This topic is covered in a separate appendix to this document. See [Appendix C: GUI Reference](#).

Chapter 2: Command Syntax Conventions in this Software Reference

The following table describes how command line interface syntax is shown in this Software Reference.

Syntax element	Example	What to enter in the command line
Keywords are shown in lowercase fixed-width font or bold variable-width font	show spanning-tree mst or show ip route	Some keywords are required, and others are optional parameters. Type keywords exactly as they appear in the command syntax.
Number ranges are enclosed in angle-brackets < > and separated by a hyphen.	<0-255>	Enter a number from the range. Do not enter the angle brackets.
Placeholders are shown in lowercase italics within angle-brackets < >, or in uppercase italics	<port-list> or ip dhcp pool <i>NAME</i>	Replace the placeholder with the value you require. The place holder may be an IP address, a text string, or some other value. See the parameter table for the command for information about the type of value to enter. Do not enter the angle-brackets.
Repeats are shown with ellipsis.	param1...	Enter the parameter one or more times.
Optional elements are shown in brackets: []	vlan <vid> [name <vlan-name>]	If you need the optional parameter, enter it. Do not enter the brackets.
Required choices are enclosed in braces and separated by a vertical bar (pipe): { }.	spanning-tree {mstp rstp stp} enable	Enter one only of the options. Do not enter the braces or vertical bar.
Optional choices are enclosed in or brackets and separated by a vertical bar (pipe): []	[param1 param2]	If needed, enter one only of the options. Do not enter the brackets or vertical bar.
Inclusive options are enclosed in braces, and separated by brackets: { [] }.	{ [param1] [param2] [param3] }	Enter one or more of the options and separate them with a space. Do not enter the braces or brackets.

Chapter 3: Start-up Sequence



AlliedWare Plus™ Start-up.....	3.2
Diagnostic menu.....	3.2
Bootloader menu.....	3.4
Start-up sequence.....	3.8

AlliedWare Plus™ Start-up

Every switch has a start-up process. A specified version of product software must be loaded and executed. The bootloader is the executable code responsible for setting up the system and loading the release software.

The bootloader is the software that runs the unit when it first powers up, performing basic initialization and executing the product software release. As part of the start-up process of the switch, the bootloader allows you various options before running the product release software.

Previous versions of AlliedWare provide the option to boot to EPROM if a software release cannot be loaded, is unlicensed, or if selected by the user. The EPROM provides enough basic functionality to get a working software release loaded and operational on the switch. In AlliedWare Plus™ this task is handled by the bootloader.

As AlliedWare Plus™ begins its start-up process, there are two options that allow you to access either the diagnostic menu, or the bootloader menu. The following prompt is displayed when these options are temporarily available:

```
Bootloader 1.1.0 loaded
Press <Ctrl+B> for the Boot Menu
```

You can now enter one of the following two options to determine how the start-up process proceeds:

- Enter Ctrl+D to display the diagnostic menu.
- Enter Ctrl+B to display the bootloader menu.

Diagnostic menu

Enter Ctrl+D during start-up to access the bootloader diagnostic menu, and provide options for performing various hardware tests. This can be useful as a tool for confirming a suspected hardware problem at the direction of network engineering personnel. When you enter Ctrl+D, the stage 1 diagnostics menu is displayed:

```
Bootup Stage 1 Diagnostics Menu:
0. Restart
1. Full RAM test
2. Quick RAM test
3. Battery backed RAM (NVS) test
4. Bootloader ROM checksum test
-----
7. Bootup stage 2 diagnostics menu
-----
8. Quit to U-Boot shell
9. Quit and continue booting
Enter selection ==>
```

The options in the stage 1 diagnostics menu allow you to initiate the following tests:

- **RAM**
The Bootloader fully tests any/all SDRAM installed in the system.
- **NVS**
The Bootloader fully tests any/all non-volatile (battery backed) SRAM installed in the system.
- **checksum**
The Bootloader checksum ROM memory for error detection.

For example, enter “2” to select a Quick RAM test:

```
Quick RAM test - press Q to quit, S to skip when failing
Writing pattern .....
Checking pattern .....
Writing complemented pattern .....
Checking complemented pattern .....
Pass 1 total errors 0
```

Enter “7” to display the stage 2 diagnostics menu:

```
Entering stage 2...
Bootup Stage 2 Diagnostics Menu:
0. Restart
2. Test FLASH (Filesystem only)
4. Erase FLASH (Filesystem only)
5. Card slot test
-----
8. Quit to U-Boot shell
9. Quit and continue booting
```

The options in the stage 2 diagnostics menu allow you to initiate the following tests:

- **Flash**
The Bootloader tests the user file system area of flash. The bootloader is stored in a protected area of flash that is not accessed by the user file system.
- **Flash Erase**
The Bootloader erases the user file system area of flash only.
- **SD Card slot**
The Bootloader tests the SD Card slot.

Once any required tests are completed from the diagnostics menu, enter “9” to quit the diagnostic menu and continue the switch boot-up process.

Bootloader menu

Enter Ctrl+B during start-up to access the bootloader menu where boot options can be set. The boot options shown are explained in detail under this example.

Boot Menu:

```
-----
B. Boot backup software
-----
0. Restart
1. Perform one-off boot from alternate source
2. Change the default boot source (for advanced users)
3. Update Bootloader
4. Adjust the console baud rate
5. Special boot options
6. System information
7. Restore Bootloader factory settings
-----
9. Quit and continue booting
```

Boot options A powerful feature of AlliedWare Plus™ is the ability to boot from a variety of sources. Previously the switch was constrained to just booting off the release loaded into flash memory. The only software release upgrade path being to load a new release into flash memory and then set this release to be loaded at the next restart.

With AlliedWare Plus™ the switch can boot from other sources, such as a memory card or network server. This provides a very flexible system, with multiple options to upgrade software releases and for system recovery.

Details of the bootloader menu options are as follows:

1. Perform one-off boot from alternate source

Enter “1” to provide the following one-off boot options:

```
Enter selection ==> 1
Select device:
  0. Return to previous menu
  -----
  1. Flash    (flash:)
  2. SD Card  (card:)
  3. TFTP     (tftp://)
  4. YMODEM   (ymodem:)
Enter selection ==>
```

You can select a one-off boot from flash, SD card, network server (TFTP), or ymodem. The selected option will be used for the next restart (only) of the switch. If you select to boot from the network, the bootloader prompts the user for the required network address details:

Note: *These settings are specific to the Bootloader. They are not related in any way to what may be configured by the main software release.*

```
Enter physical download port (1-24)... []: 1
Enter IP version [4|6]..... [4]: 4
Enter IP address for this device ..... [0.0.0.0]: 172.28.8.210
Enter subnet mask ..... [0.0.0.0]: 255.255.0.0
Enter gateway IP ..... [0.0.0.0]: 172.28.0.1
Enter TFTP server IP ..... [0.0.0.0]: 172.30.1.242
Enter filename ..... [r6-main-20081114-2.rel]: r6-5.3.1.rel
Loading tftp://172.30.1.242/r6-5.3.1.rel...
```

When the switch is booted up using the 'one-off' selected source for the software release, it provides the option to copy the release just used to flash for further/ permanent use:

```
login: manager
Password: *****
The system has been booted using the one off boot/recovery
mechanism.
Bootup has successfully completed.
Write this release to flash? (y/n):
```

2. Change the default boot source (for advanced users)

Entering "2" provides the option to set the boot source permanently.

```
NOTE: These settings are specific to the Bootloader.
They are not related in any way to what may be configured
by the 'boot system' command in the main software release.
Select device:

0. Return to previous menu
-----
1. Flash (flash:)
2. SD Card (card:)
3. TFTP (tftp://)
4. YMODEM (ymodem:)
-----
9. Boot from default (determined by main CLI)

Enter selection ==>
```

The same four boot source options are provided as with the one-off selection, but this time every restart of the switch will result in the unit booting from the selected source.

3. Update Bootloader

This option allows for the bootloader code to be updated. It is not detailed here, as it is envisioned that this would rarely need to be done, and only at the request of (and with support from) Allied Telesis engineering.

4. Adjust the console baud rate

The baud rate of the console session is set here to match the terminal program being used for management of the switch when connected directly to the asynchronous port. The switches default value is 9600. The baud rate selected can be set as the 'new' default for future use if preferred.

```
Select baud rate:
```

```
0. Return to previous menu
```

```
-----  
1. 9600  
2. 19200  
3. 38400  
4. 57600  
5. 115200  
6. 230400 (Setting can't be made permanent)  
7. 460800 (Setting can't be made permanent)
```

```
Enter selection ==> 1
```

```
Change your terminal program baud rate to 9600 and press  
enter... if for some reason you are unable to do this,  
power cycle the device and the existing baud rate will be  
restored.
```

```
Use this baud rate by default? (Y/N) ==> n
```

5. Special boot options

The special boot options allow for system recovery in the event of a forgotten password or to the default configuration.

```
Special boot options menu:
```

```
0. Return to previous menu
```

```
-----  
1. Skip startup script (Use system defaults)
```

```
Enter selection ==>
```


6. System information

The system information option provides some details on the hardware platform in use, such as CPU, memory, hardware (MAC) address and so on.

```
System information:

System (Detected values)
-----
CPU:
  Type .....: MPC8347E
  Speed .....: 399 MHz
Memory:
  Total installed ....: 512 MB
  Speed .....: 266 MHz
Flash:
  Total installed ....: 64 MB
-----

Product information
-----
Compatible software ...: 6 (r6)
Serial .....: G1Q67B002
Manufacture date .....: 01/2008
Product .....: 289
Product name .....: x600-24Ts
Revision .....: A-0
First MAC address ....: 00:15:77:93:20:C3
-----

Boot software information
-----
Version .....: 1.1.0
Build time .....: Jul 4 2008 - 15:20:07
Built by .....: markto
Build host .....: markto-dl
Build key .....: x600
Compatible products:
  289 .....: x600-24Ts
  290 .....: x600-24Ts/XP
  293 .....: x600-48Ts
  294 .....: x600-48Ts/XP
-----

Press any key to continue...
```

7. Restore Bootloader factory settings

This option allows the bootloader to be set back to factory defaults

Warning *This option erases any settings that may have been configured by this menu*

Are you sure? (Y/N) ==>

The bootloader menu provides a powerful set of options for flexibility in the way software releases are upgraded on the switch, and system recovery is performed.

Start-up sequence

The start-up sequence for a device running AlliedWare Plus™ under normal circumstances will be as seen below - this sequence will be seen when everything loads and runs as expected.


Note: To enter the bootloader or diagnostic menus discussed previously, Ctrl+B or Ctrl+D must be entered when prompted before the software modules start loading.

```
Reading flash:r6-main-20081114-2.rel...
```

```
Verifying release... OK
```

```
Booting...
```

```
Starting base/first... [ OK ]
```



```
Allied Telesis Inc.
```

```
AlliedWare Plus (TM) v5.3.1
```

```
Original release filename: r6-main-20081114-2.rel
```

```
Built: Fri Nov 14 13:00:27 NZDT 2008 by: maker@awpmaker05-d1
```

```
Mounting virtual filesystems... [ OK ]
```

```
Mounting static filesystems... [ OK ]
```

```
Mounting flash... [ OK ]
```

```
Checking NVS filesystem... [ OK ]
```

```
Mounting NVS filesystem... [ OK ]
```

```
Starting base/dbus... [ OK ]
```

```
Starting base/klogd... [ OK ]
```

```
Starting base/loopback... [ OK ]
```

```
Starting base/sysctl... [ OK ]
```

```
Starting base/syslog... [ OK ]
```

```
Starting base/appmond... [ OK ]
```

```
Starting base/portmapper... [ OK ]
```

```
Starting base/cron... [ OK ]
```

```
Starting hardware/openhpi... [ OK ]
```

```
Starting hardware/timeout... [ OK ]
```

```
Starting base/autofs... [ OK ]
```

```
Starting base/inet... [ OK ]
```

```
Starting base/modules... [ OK ]
```

```
Received event baseboard.found
```

```
Received event hardware.done
```

```
Starting network/startup... [ OK ]
```

```
Starting hardware/openhpilog... [ OK ]
```

```
Starting network/trigger... [ OK ]
```

```
Starting network/election.timeout... [ OK ]
```

```
Starting network/stackd... [ OK ]
```

```
Received event network.enabled
```

```
Initializing HA processes:
```

```
auth, bgpd, cntrd, epsr, hostd, hsl, imi
```

```
irdpd, lacp, loopprot, mstp, nsm, openhpid, ospfd
```

```
pdmd, pimdp, ripd, ripngd, rmon, vrrpd
```

```
Received event network.initialized
```

```
Received event vcs.elected-master
```

```
09:39:40 awplus VCS[997]: Member 1 (0015.7793.20c3) has become the Active Master
```

```
Assigning Active Workload to HA processes:
```

```
authd, bgpd, epsrd, hsl, irdpd, lacpd, loopprot
```

```
mstpd, nsm, ospfd, pdmd, pimdp, ripd, ripngd
```

```
rmond, vrrpd, imi
```

```
Received event network.activated
```

```
Loading default configuration
```

```
.
```

```
done!
```

```
Received event network.configured
```

```
awplus login: manager
```

```
Password:
```

```
AlliedWare Plus (TM) 5.3.1 11/14/08 13:00:27
```

```
Bootloader 1.1.0 loaded
```

```
Press <Ctrl+B> for the Boot Menu
```

There are three possible status results displayed for each module loaded - OK, INFO, ERROR:

- OK means that the module has loaded correctly.
- INFO means that an error occurred, but the device is usable.
- ERROR means that an error occurred and device operation may be affected.

Additional specific information accompanies an INFO or ERROR status result. For example, if a corrupt release file was set as the startup release, the following error message would be seen:

```
Bootloader 1.1.0 loaded
Press <Ctrl+B> for the Boot Menu
Reading filesystem...
Error: Release filename is invalid (should be <release>.rel)
Error: There is no backup release file set
Error: Boot failed. Please recover the system using the Boot Menu
Restarting...Bootloader 1.1.0 loaded
Press <Ctrl+B> for the Boot Menu
```

Whether an error message results in a case of the device being unusable will depend on the specific error and message, so will need to be dealt with on a case by case basis. If a software release has been corrupted, as shown on start-up, a new release may need to be loaded.

Chapter 4: CLI Navigation Commands



Command List	4.2
configure terminal	4.2
disable (Privileged Exec mode)	4.2
do	4.3
enable (Privileged Exec mode)	4.3
end	4.4
exit	4.4
help	4.5
logout	4.5
show cli	4.6
show history	4.6
show list	4.7

Command List

This chapter provides an alphabetical reference for the commands used to navigate between different modes. This chapter also provides a reference for the help and show commands used to help navigate within the CLI.

configure terminal

This command enters the Global Configuration command mode.

Syntax `configure terminal`

Mode Privileged Exec

Examples The following example shows the use of this command to enter the Global Configuration command mode (note the change in the command prompt).

```
awplus# configure terminal
awplus(config)#
```

disable (Privileged Exec mode)

This command exits the Privileged Exec mode, returning the prompt to the Exec mode. To end a session, use the [exit](#) command.

Syntax `disable`

Mode Privileged Exec

Examples

```
awplus# disable
>
```

Related Commands [enable \(Privileged Exec mode\)](#)
[end](#)
[exit](#)

do

This command lets you to run Exec and Privileged Exec mode commands when you are in a Configuration mode.

Syntax `do <command>`

Parameter	Description
<code><command></code>	Specify the command and its parameters.

Command Mode Any configuration mode

Example

```
awplus# configure terminal
awplus(config)# do ping 192.0.2.23
```

enable (Privileged Exec mode)

This command enters the Privileged Exec mode.

Syntax `enable`

Mode Exec

Examples The following example shows the use of the `enable` command to enter the Privileged Exec mode (note the change in the command prompt).

```
awplus> enable
awplus#
```

Related Commands [disable \(Privileged Exec mode\)](#)
[exit](#)

end

This command returns the prompt to the Privileged Exec command mode from any other advanced command mode.

Syntax `end`

Mode All command modes

Examples The following example shows the use of the `end` command to return to the Privileged Exec mode directly from Interface mode.

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# end
awplus#
```

Related Commands [disable \(Privileged Exec mode\)](#)
[enable \(Privileged Exec mode\)](#)
[exit](#)

exit

This command exits the current mode, and returns the prompt to the mode at the previous level. When used in Exec mode, the `exit` command terminates the session.

Syntax `exit`

Mode All command modes.

Examples The following example shows the use of `exit` command to exit Interface mode, and return to Configure mode.

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# exit
awplus(config)#
```

Related Commands [disable \(Privileged Exec mode\)](#)
[enable \(Privileged Exec mode\)](#)
[end](#)

help

This command displays a description of the AlliedWare Plus™ OS help system.

Syntax help

Mode All command modes

Output Figure 4-1: Example output from the **help** command

```
When you need help at the command line, press '?'.

If nothing matches, the help list will be empty. Delete
characters until entering a '?' shows the available options.

Enter '?' after a complete parameter to show remaining valid
command parameters (e.g. 'show ?').

Enter '?' after part of a parameter to show parameters that
complete the typed letters (e.g. 'show ip?').
```

Examples To display a description on how to use the system help, use the command:

```
awplus# help
```

logout

This command exits the Exec or Privileged Exec modes and ends the session.

Syntax logout

Mode Exec and Privileged Exec

Example To exit the Exec mode, use the command:

```
awplus# logout
```

show cli

Use this command to display the CLI tree of the current mode.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show cli`

Mode All command modes

Example To display the CLI tree of the current mode, use the command:

```
awplus# show cli
```

Output Figure 4-2: Example output from the **show cli** command

```
+--ospf
  +-A.B.C.D
    +-authentication [no ip ospf (A.B.C.D|) authentication]
    +-authentication-key [no ip ospf (A.B.C.D|) authentication-
key]
    +-cost [no ip ospf (A.B.C.D|) cost]
    +-database-filter [no ip ospf (A.B.C.D|) database-filter]
    +-hello-interval [no ip ospf (A.B.C.D|) hello-interval]
    +-message-digest-key
```

show history

This command lists the commands entered in the current session. The history buffer is cleared automatically upon reboot.

The output lists all command line entries, including commands that returned an error.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show history`

Mode Exec and Privileged Exec

Example To display the commands entered during the current session, use the command:

```
awplus# show history
```

Output Figure 4-3: Example output from the **show history** command

```
1 en
2 show ru
3 con t
4 route-map er deny 3
5 exit
6 ex
7 di
```

show list

Use this command to display a list of all the commands relevant to the current mode.

For information on output options, see [“Controlling “show” command output” on page 1.33](#).

Syntax `show list`

Command Mode All command modes.

Examples To run the show list command:

```
awplus# show list
```

Output Figure 4-4: Example output from the show list command in Configure mode

```
echo LINE
edit
edit URL
enable
erase startup-config
```


Chapter 5: User Access Commands



Command List	5.2
clear line console	5.2
clear line vty	5.2
enable password	5.3
exec-timeout	5.5
length (console display)	5.6
line	5.7
privilege level	5.7
service advanced-vty	5.8
service http	5.9
service password-encryption	5.10
service telnet	5.11
service terminal-length	5.12
show privilege	5.12
show telnet	5.13
show users	5.13
telnet	5.14
telnet server	5.15
terminal length	5.16
username	5.17

Command List

This chapter provides an alphabetical reference of commands used to configure user access.

clear line console

This command resets a console line. If a terminal session exists on the line then it is closed.

Syntax `clear line console 0`

Mode Privileged Exec

Example To reset the console use the command:

```
awplus# clear line console 0
```

Related Commands [clear line vty](#)
[show users](#)

clear line vty

This command resets a VTY line. If a session exists on the line then it is closed.

Syntax `clear line vty <0-32>`

Parameter	Description
<0-32>	Line number

Mode Privileged Exec

Example To reset the first vty line, use the command:

```
awplus# clear line vty 1
```

Related Commands [privilege level](#)
[show telnet](#)
[show users](#)

enable password

To set a local password to control access to various privilege levels, use the enable password global configuration command. Use the enable password command to modify or create a password to be used, and use the no enable password command to remove the password.

Note: Do not use encrypted passwords for GUI users. The GUI requires unencrypted user passwords only - not encrypted user passwords. Do not use option 8 for GUI users.

Syntax enable password [<plain>|8 <hidden>|level <0-15> 8 <hidden>]

Parameter	Description
<plain>	Specifies the unencrypted password.
8	Specifies a hidden password will follow.
<hidden>	Specifies the hidden encrypted password.
level	Privilege level <0-15>. Level for which the password applies. You can specify up to 16 privilege levels, using numbers 0 through 15. Level 1 is normal EXEC-mode user privileges for Exec mode. If this argument is not specified in the command or the no form of the command, the privilege level defaults to 15 (enable mode privileges) for Privileged Exec mode.

Mode Global Configuration

Default The privilege level for enable password is level 15 by default. Previously the default was level 1.

Usage This command enables the Network Administrator to set a password for entering the enable mode. There are three methods to enable a password. In the examples below, for each method, the configuration is different: the configuration file output is different, but the password string to be used to enter the enable mode is the same (mypasswd).

Using Plain Passwords

The plain password is a clear text string that appears in the configuration file as configured.

```
awplus# configure terminal
awplus(config)# enable password mypasswd
awplus(config)# end
```

This results in the following show output

```
awplus#show run
Current configuration:
hostname awplus
enable password mypasswd
!
interface lo
```

Using Encrypted Passwords

Configure an encrypted password using the service encrypted-password command. First, use the enable password command to specify the string that you want to use as a password (mypasswd). Then, use the service encrypted-password command to encrypt the specified string (mypasswd). The advantage of using an encrypted password is that the configuration file does not show mypasswd, it will only show the encrypted string fU7zHzuutY2SA

Note: Do not use encrypted passwords for GUI users. The GUI requires unencrypted user passwords only - not encrypted user passwords. Do not use option 8 for GUI users.

```
awplus# configure terminal
awplus(config)# enable password mypasswd
awplus(config)# service password-encryption
awplus(config)# end
```

This results in the following show output

```
awplus#show run
Current configuration:
hostname awplus
enable password 8 fU7zHzuutY2SA
service password-encryption
!
interface lo
```

Using Hidden Passwords

Configure an encrypted password using the HIDDEN parameter (8) with the enable password command. Use this method if you already know the encrypted string corresponding to the plain text string that you want to use as a password. It is not required to use the service password-encryption command for this method. The output in the configuration file will show only the encrypted string, and not the text string

```
awplus# configure terminal
awplus(config)# enable password 8 fU7zHzuutY2SA
awplus(config)# end
```

This results in the following show output

```
awplus#show run
Current configuration:
hostname awplus
enable password 8 fU7zHzuutY2SA
!
interface lo
```

Related Commands service password-encryption
 username
 show running-config

exec-timeout

This command sets the interval your device waits for user input from either a console or VTY connection. Once the timeout interval is reached, the connection is dropped. This command sets the time limit when the console or VTY connection automatically logs off after no activity.

The no parameter removes a specified timeout and resets to the default timeout (10 minutes).

Syntax `exec-timeout {<minutes>} [<seconds>]`

`no exec-timeout`

Parameter	Description
<minutes>	<0-35791> Required integer timeout value in minutes
<seconds>	<0-2147483> Optional integer timeout value in seconds

Mode Line Configuration

Default The default for the exec-timeout command is 10 minutes and 0 seconds (exec-timeout 10 0)

Usage This command is used set the time the telnet session waits for an idle VTY session, before it times out. An exec-timeout 0 0 setting will cause the telnet session to wait indefinitely. The command exec-timeout 0 0 is useful while configuring a device, but reduces device security.

If no input is detected during the interval then the current connection resumes. If no connections exist then the terminal returns to an idle state and disconnects incoming sessions.

Example To set VTY connections to timeout after 2 minutes, 30 seconds if there is no response from the user, use the following commands:

```
awplus# configure terminal
awplus(config)# line vty 0 32
awplus(config-line)# exec-timeout 2 30
```

To reset the console connection to the default timeout of 10 minutes 0 seconds if there is no response from the user, use the following commands:

```
awplus# configure terminal
awplus(config)# line console 0
awplus(config-line)# no exec-timeout
```

Related Commands [line](#)
[service telnet](#)

Validation Commands [show running-config](#)

length (console display)

Use this command to specify the number of rows of output that the device will display before pausing, for the console or VTY line that you are configuring.

If the output from a command is longer than the length of the line the output will be paused and the ‘–More–’ prompt allows you to move to the next screen full of data.

A length of 0 will turn off pausing and data will be displayed to the console as long as there is data to display.

The no parameter restores the length of a line (terminal session) attached to a console port or to a VTY to its default.

Syntax length <0-512>

no length

Parameter	Description
<0-512>	Number of lines on screen. Specify 0 for no pausing.

Mode Line Configuration

Example To set the terminal session length on the console to 10 rows, use the command:

```
awplus# configure terminal
awplus(config)# line console 0
awplus(config-line)# length 10
```

To display output to the console continuously, use the command:

```
awplus# configure terminal
awplus(config)# line console 0
awplus(config-line)# length 0
```

Related Commands service terminal-length
terminal length

line

Use this command to move to line configuration mode for the specified VTYS or the console.

Syntax `line vty <first-line> [<last-line>]`
`line console 0`

Parameter	Description
<code><first-line></code>	<code><0-32></code> Specify the first line number.
<code><last-line></code>	<code><0-32></code> Specify the last line number.

Mode Global Configuration

Example The following example shows the use of the `line` command to enter the Line command mode in order to configure all VTYS (note the change in the prompt).

```
awplus# configure terminal
awplus(config)# line vty 0 32
awplus(config-line)#
```

privilege level

This command sets a privilege level for VTY or console connections. This privilege level overrides a specific user's privilege.

Syntax `privilege level <0-15>`

Mode Line Configuration

Example To set the console connection to have the maximum privilege level, use the following commands:

```
awplus# configure terminal
awplus(config)# line console 0
awplus(config-line)# privilege level 15
```

To set all vty connections to have the minimum privilege level, use the following commands:

```
awplus# configure terminal
awplus(config)# line vty 0 5
awplus(config-line)# privilege level 1
```

Related Commands [line](#)
[username](#)

service advanced-vty

This command enables the advanced-vty help feature. This allows you to use TAB completion for commands. Where multiple options are possible, the help feature displays the possible options.

The no service advanced-vty command disables the advanced-vty help feature.

Syntax service advanced-vty
 no service advanced-vty

Mode Global Configuration

Default The advanced-vty help feature is enabled by default.

Examples To disable the advanced-vty help feature, use the command:

```
awplus# configure terminal
awplus(config)# no service advanced-vty
```

To re-enable the advanced-vty help feature after it has been disabled, use the following commands:

```
awplus# configure terminal
awplus(config)# service advanced-vty
```

service http

This command enables the HTTP (Hypertext Transfer Protocol) service. The HTTP service is enabled by default and is required to support the AlliedWare Plus GUI Java applet on a Java enabled browser. See [Appendix C: GUI Reference](#) for further information about installing and using the AlliedWare Plus GUI.

The no service http command disables the HTTP feature.

Syntax service http
 no service http

Mode Global Configuration

Default The HTTP service is enabled by default.

Examples To disable the HTTP service, use the command:

```
awplus# configure terminal
awplus(config)# no service http
```

To re-enable the HTTP service after it has been disabled, use the following commands:

```
awplus# configure terminal
awplus(config)# service http
```

service password-encryption

Use this command to enable password encryption. This is enabled by default. When password encryption is enabled, the device displays passwords in the running config in encrypted form instead of in plain text.

Use the `no service password-encryption` command to stop the device from displaying newly-entered passwords in encrypted form. This does not change the display of existing passwords.

Note: Do not use encrypted passwords for GUI users. The GUI requires unencrypted user passwords only - not encrypted user passwords.

Syntax `service password-encryption`
 `no service password-encryption`

Mode Global Configuration

Example

```
awplus# configure terminal
awplus(config)# service password-encryption
```

**Validation
Commands** `show running-config`

Related Commands `enable password`

service telnet

Use this command to enable the telnet server. The server is enabled by default. Enabling the telnet server starts the switch listening for incoming telnet sessions on the configured port.

The server listens on port 23, unless you have changed the port by using the [privilege level command on page 5.7](#).

Use the no form to disable the telnet server. Disabling the telnet server will stop the switch listening for new incoming telnet sessions. However, existing telnet sessions will still be active.

Syntax `service telnet [ip|ipv6]`
 `no service telnet [ip|ipv6]`

Mode Global Configuration

Default Both the IPv4 and IPv6 telnet servers are enabled by default.
The configured telnet port is TCP port 23 by default.

Example To enable both the IPv4 and IPv6 telnet servers, use the following commands:

```
awplus# configure terminal
awplus(config)# service telnet
```

To enable the IPv6 telnet server only, use the following commands:

```
awplus# configure terminal
awplus(config)# service telnet ipv6
```

To disable both the IPv4 and IPv6 telnet servers, use the following commands:

```
awplus# configure terminal
awplus(config)# no service telnet
```

To disable the IPv6 telnet server only, use the following commands:

```
awplus# configure terminal
awplus(config)# no service telnet ipv6
```

Related Commands [clear line vty](#)
 [show telnet](#)
 [telnet server](#)

service terminal-length

Use this command to specify the number of rows of output that the device will display before pausing, for all console and VTY lines.

Use the `no` parameter to remove the length specified by this command. The default length will apply unless you have changed the length for some or all lines by using the [length \(console display\) command on page 5.6](#).

Syntax `service terminal-length <lines>`
`no service terminal-length <lines>`

Parameter	Description
<code>terminal-length</code>	Establish system-wide terminal length configuration.
<code><lines></code>	<code><0-512></code> Number of rows that the device will display before pausing.

Mode Global Configuration

Usage This command overrides any lengths set by using the [length \(console display\) command on page 5.6](#) in Line mode.

Example To display 60 rows of text before pausing, use the following command:

```
awplus# configure terminal
awplus(config)# service terminal-length 60
```

Related Commands [service terminal-length](#)
[terminal length](#)

show privilege

This command displays the current privilege level of the user, either 1 (limited access) or 15 (full access).

Syntax `show privilege`

Mode Exec and Privileged Exec

Example

```
awplus# show privilege
```

```
Current privilege level is 15
```


show telnet

This command shows the Telnet server settings.

Syntax `show telnet`

Mode Exec and Privileged Exec

Example To show the Telnet server settings use the command:

```
awplus# show telnet
```

Output Figure 5-1: Example output from the **show telnet** command

```
Telnet Server Configuration
-----
Telnet server           : Enabled
Protocol                : IPv4, IPv6
Port                    : 23
```

Related Commands

- `clear line vty`
- `service telnet`
- `show users`
- `telnet server`

show users

This command shows information about the users who are currently logged into the device.

Syntax `show users`

Mode Exec and Privileged Exec

Output Figure 5-2: Example output from the **show users** command

Line	User	Host(s)	Idle	Location
con 0	manager	idle	00:00:00	ttyS0
vty 0	bob	idle	00:00:03	172.16.11.1

Example To show the users currently connected to the device, use the command:

```
awplus# show users
```

telnet

Use this command to open a telnet session to a remote device.

Syntax `telnet {<hostname>|ip <ipv4-addr>|ipv6 <ipv6-addr>} [<port>]`

Parameter	Description
<hostname>	The host name of the remote system.
ip	Keyword used to specify the IPv4 address or host name of a remote system.
<ipv4-addr>	An IPv4 address of the remote system.
ipv6	Keyword used to specify the IPv6 address of a remote system
<ipv6-addr>	Placeholder for an IPv6 address in the format <code>x:x:x:x:x:x</code> , for example, <code>2001:db8::8a2e:7334</code>
<port>	Specify a TCP port number (well known ports are in the range 1-1023, registered ports are 1024-49151, and private ports are 49152-65535).

Mode Exec and Privileged Exec

Examples To connect to TCP port 2602 on the device at 10.2.2.2, use the command:

```
awplus# telnet 10.2.2.2 2602
```

To connect to the telnet server `host.example`, use the command:

```
awplus# telnet host.example
```

To connect to the telnet server `host.example` on TCP port 100, use the command:

```
awplus# telnet host.example 100
```

To connect to the telnet server `host.example` with an IPv6 connection, use the command:

```
awplus# telnet ipv6 host.example
```

telnet server

This command enables the telnet server on the specified TCP port. If the server is already enabled then it will be restarted on the new port. Changing the port number does not affect the port used by existing sessions.

Syntax `telnet server {<1-65535>|default}`

Parameter	Description
<code><1-65535></code>	The TCP port to listen on.
<code>default</code>	Use the default TCP port number 23.

Mode Global Configuration

Example To enable the telnet server on TCP port 2323, use the following commands:

```
awplus# configure terminal
awplus(config)# telnet server 2323
```

Related Commands `show telnet`

terminal length

Use the terminal length command to specify the number of rows of output that the device will display before pausing, for the currently-active terminal only.

Use the terminal no length command to remove the length specified by this command. The default length will apply unless you have changed the length for some or all lines by using the [length \(console display\) command on page 5.6](#).

Syntax `terminal length <length>`
`terminal no length [<length>]`

Parameter	Description
<length>	<0-512> Number of rows that the device will display on the currently-active terminal before pausing.

Mode Exec and Privileged Exec

Example The following example sets the number of lines to 15.

```
awplus# terminal length 15
```

The following example removes terminal length set previously.

```
awplus# terminal no length
```

Related Commands [length \(console display\)](#)
[service terminal-length](#)

username

This command creates or modifies a user.

Note: Do not use encrypted passwords for GUI users. The GUI requires unencrypted user passwords only - not encrypted user passwords. Do not use option 8 for GUI users.

Syntax username <name> privilege <1-15> [guiuser] password [8] <password>
 username <name> privilege <1-15> [guiuser]
 username <name> password [8] <password>
 no username <name>

Parameter	Description
<name>	The login name for the user.
privilege	The user's privilege level. Use the privilege levels to set the access rights for each user.
<1-15>	A privilege level: either 1-14 (limited access) or 15 (full access). The default manager account on your device cannot be set to a lower privilege level than 15. A user with privilege level 1-14 can only enter Privileged Exec mode if an enable password has been configured and they enter the password.
guiuser	Setup the user account for use with the GUI.
password	A password that the user must enter when logging in.
8	Specifies that you are entering a password as a string that has already been encrypted, instead of entering a plain-text password. The running-config displays the new password as an encrypted string even if password encryption is turned off. Note that the user enters the plain-text version of the password when logging in.
<password>	The user's password. The password is an alpha-numeric string up to 80 characters in length and can include spaces.

Mode Global Configuration

Example To create the user bob with a privilege level of 15, and the password bobs_secret, use the command:

```
awplus# configure terminal
awplus(config)# username bob privilege 15 password bobs_secret
```

To create the GUI user bob with a privilege level of 15, and the password bobs_secret, use the command:

```
awplus# configure terminal
awplus(config)# username bob privilege 15 guiuser password
bobs_secret
```

Related Commands enable password

Chapter 6: Creating and Managing Files



Introduction.....	6.2
Working with files.....	6.2
Listing files.....	6.2
Displaying the contents of configuration and text files.....	6.4
Navigating through the file system.....	6.4
Using the editor.....	6.6
Creating and Using Configuration Files.....	6.8
Creating a Configuration File.....	6.8
Specifying the Start-up Configuration Script.....	6.8
Working with Configuration Files.....	6.9
Copying Files To and From Your Device.....	6.10
URL Syntax.....	6.10
Copying files.....	6.10
Copying from a Server to Running Configuration.....	6.13

Introduction

This chapter provides information on:

- Working with files
- Creating and Using Configuration Files
- Copying Files To and From Your Device

Working with files

The AlliedWare Plus OS lets you create directory trees for file storage. This section shows:

- “Listing files” on page 6.2—listing files and seeing how much free space you have
- “Displaying the contents of configuration and text files” on page 6.4
- “Navigating through the file system” on page 6.4—identifying the current directory, changing directories, and creating and deleting directories
- “Using the editor” on page 6.6

Flash compaction

The flash memory on the switch automatically compacts itself to recover space available from deleted files. The switch only does this when necessary, and not every file deletion causes flash compaction. Flash compaction can occur after a file of any size is added to or deleted from the switch.



While flash is compacting, the console is unresponsive. Do not restart the switch, as interrupting flash compaction can damage files.

Listing files

To list files, enter Privileged Exec mode and enter the command:

```
awplus# dir
```

The output lists files and directories in order of modification date, descending. It looks like this:

```
-rw-      534 Jul 12 2007 17:52:50  stp.cfg
-rw-      534 Jul 12 2007 17:12:50  example.cfg
-rw- 12429011 Jul 12 2007 16:26:06  r1-5.2.2-rc3.rel
```

Listing files including hidden system files

The `dir` command does not list all files—it hides system files and directories because users generally do not need to create or edit them. To list all files including system files, enter Privileged Exec mode and enter the command:

```
awplus# dir all
```


The output looks like this:

```
drwx      0 Jul 12 2008 17:16:32 ./
-rw-     401 Jul 12 2008 17:16:32 example.cfg
-rw-     534 Jul 12 2008 17:52:50 stp.cfg
-rw- 12429011 Jul 12 2008 16:26:06 r1-5.2.2-rc3.rel
drwx     216 Jul  9 2008 11:31:18 ../
drwx      0 Jun 13 2008 04:31:51 .configs/
-rw-     17 Jun 13 2008 04:27:27 .release
drwx      0 Jul 10 1978 23:40:00 .ssh/
```

The hidden files and directories begin with a dot.

Seeing information about the file system

To display information about the different memory types on the switch, enter Privileged Exec mode and enter the command:

```
awplus# show file systems
```

The output includes the amount of free memory and the prefix you type to access that memory type, and looks like this:

Size(b)	Free(b)	Type	Flags	Prefixes	S/D/V	Lcl/Ntwk	Avail
31.0M	6.0M	flash	rw	flash:	static	local	Y
-	-	system	rw	system:	virtual	local	-
499.0k	444.0k	nvs	rw	nvs:	static	local	Y
-	-	sdcard	rw	card:	dynamic	local	N
-	-	tftp	rw	tftp:	-	network	-
-	-	scp	rw	scp:	-	network	-
-	-	sftp	ro	sftp:	-	network	-
-	-	http	ro	http:	-	network	-

Listing files in a subdirectory

To list the contents of a directory, enter Privileged Exec mode and enter the command:

```
awplus#dir <directory-name>
```

Tip You can specify the directory with or without a / after the directory name.

Example To display the contents of a directory called "example", enter the command:

```
awplus# dir example
```

Listing files in NVS memory or on an SD card

To list the contents of a directory in NVS, enter Privileged Exec mode and enter the command:

```
awplus#dir nvs:<directory-name>
```

To list the contents of a directory on an SD card, enter the command:

```
awplus#dir card:<directory-name>
```

Example To display the contents of a directory in NVS called “example”, enter the command:

```
awplus#dir nvs:example
```

Displaying the contents of configuration and text files

To display the contents of a file, enter Privileged Exec mode and enter the command:

```
awplus# show file <filename>
```

Example To display the contents of the file called “example.cfg”, enter the command:

```
awplus# show file example.cfg
```

Navigating through the file system

Showing the current directory

To see which directory you are currently in, enter Privileged Exec mode and enter the command:

```
awplus# pwd
```

For the top-level directory, the output looks like this:

```
flash:/
```

Changing directories

To change to another directory, enter Privileged Exec mode and enter the command:

```
awplus#cd <directory-name>
```

To go to a directory one level higher in the directory tree, enter the command:

```
awplus# cd ..
```

Example To change to a directory called “example”, enter the command:

```
awplus# cd example
```

To go up one level, which returns you to the top level directory, enter the command :

```
awplus# cd ..
```

Changing to a directory in NVS memory or on an SD card

To change to the top-level directory in the NVS memory file system, enter Privileged Exec mode and enter the command:

```
awplus# cd nvs:
```

To change to the top-level directory on an SD card, enter the command:

```
awplus# cd card:/
```

Note that the prefix for the SD card is “card” not “sdcard”.

Next, you can change to other directories in NVS memory or on the SD card, by entering the command:

```
awplus# cd <directory-name>
```

Alternatively, you can go straight from Flash to a subdirectory in the alternative file system, by entering one of the commands:

```
awplus# cd nvs:<directory-name>
```

```
awplus# cd card:/<directory-name>
```

To return to the Flash file system, enter the command:

```
awplus# cd flash:/
```

Example To change to the directory within NVS called “example”, enter the command:

```
awplus# cd nvs:example
```

To go up one level, which returns you to the top-level directory of NVS memory, enter the command:

```
awplus# cd ..
```

Creating new directories

To create a directory, enter Privileged Exec mode and enter the command:

```
awplus# mkdir <directory-name>
```

Example To make a directory called “example” within the Flash file system, enter the command::

```
awplus# mkdir example
```

Deleting directories

To delete an empty directory, enter Privileged Exec mode and enter the command:

```
awplus# rmdir <directory-name>
```

To delete a directory and all its contents, enter Privileged Exec mode and enter the command:

```
awplus#delete recursive <directory-name>
```

The switch prompts you for confirmation.

Example To delete an empty directory called “example” from within the Flash file system, enter the command:

```
awplus#rmdir example
```

Using the editor

The inbuilt editor is JOE (Joe's Own Editor).

To edit an existing file, enter Privileged Exec mode and enter the command:

```
edit <filename>
```

To open the editor with an empty file, enter the command:

```
edit
```

When you save the new file, you may need to specify the file system to store it on. For Flash, use flash:/<filename>.

Using JOE To format and manipulate text in JOE, you use control-character sequences. The following table summarizes a few useful sequences—for details, see: joe-editor.sourceforge.net/manpage.html.

Function	Control-character sequence
Access the help	Ctrl-K-H
Save the file without exiting (for new files, this prompts for a filename)	Ctrl-K-D
Save the file and exit (this prompts for a filename)	Ctrl-K-X
Exit without saving the file	Ctrl-C
Go to the beginning of the file	Ctrl-K-U
Go to the end of the file	Ctrl-K-V
Go up one full screen of text in the file	Ctrl-U
Go down one full screen of text in the file	Ctrl-V
Select a block of text:	
Mark the beginning of the block	Ctrl-K-B
Mark the end of the block	Ctrl-K-K

Function	Control-character sequence
Copy and paste a selected block of text	Place cursor at destination then enter Ctrl-K-C
Move a selected block of text	Place cursor at destination then enter Ctrl-K-M
Delete a selected block of text	Ctrl-K-Y

Creating and Using Configuration Files

This section provides instructions on:

- [Creating a Configuration File](#)
- [Specifying the Start-up Configuration Script](#)
- [Working with Configuration Files](#)

Creating a Configuration File

A *configuration file* is a text file that contains a sequence of standard commands for a specific purpose. Configuration files have a .cfg extension. Your device has a default configuration script called *default.cfg*.

You can create and edit configuration files on your device by:

- saving the dynamic configuration on the device, known as the *running-config* (see [“Working with Configuration Files”](#)). Use the command:

```
awplus#copy running-config (destination-URL)
```

Where URL specifies a file in flash.

- using the device's text editor. Use the command:

```
awplus#edit (source-URL)
```

where source-URL is the name of the copied file in Flash memory.

- creating a file on a remote PC, then copying it to onto your device. See [“Copying files”](#) for more information about using the copy commands.

Once you have created a configuration file, you can use it as the *startup-config* file. See [“Specifying the Start-up Configuration Script”](#) for more information.

Specifying the Start-up Configuration Script

When you restart your device, or when it automatically restarts, it executes the pre-configured commands in a configuration script known as the *boot config* or *startup-config* file.

When you first start your device, the script set as the startup-config file is *default.cfg*. If desired, you can overwrite *default.cfg* with another configuration. Alternatively, you can change the startup-config by specifying a new file as the startup-config. Use the command:

```
awplus(config)#boot config-file URL
```

where URL specifies the name and location of a configuration file. At the next restart, the device executes the commands in the specified file.

You can change the content of the file set as the startup-config file by:

- entering commands directly into the CLI, then saving this configuration using the command:

```
awplus#copy running-config startup-config
```

This command saves the device's dynamic configuration into the file that is currently configured as the startup-config file.

- writing commands into a configuration file (see “Creating a Configuration File” below), then using the command:

```
awplus#copy SOURCE-URL startup-config
```

This command saves the script from the source file into the file that is currently configured as the startup-config file.

To display the name of the configuration file that is set to execute when the device restarts, enter the command:

```
awplus#show boot
```

To see the commands in the startup-config file, use the command:

```
awplus#show startup-config
```

To erase the file set as the startup-config file, use the command:

```
awplus#erase startup-config
```

At the next restart that occurs after you've erased the file, the device loads the configuration in the file *default.cfg*. This file is set on the system as a backup configuration file that loads if no other file is set as the startup-config file.

Working with Configuration Files

When you use the CLI or GUI to configure your device, it stores this dynamic configuration as a list of commands called the *running-config*. To view the device's running-config, use the command:

```
awplus#show running-config
```

If you turn off the device or restart it, any unsaved changes to the running-config are lost. To save the running-config as a configuration script, use the command:

```
awplus#copy running-config DESTINATION-URL
```

You may have many configuration files. Storing them on a device allows you to keep a backup device with configuration scripts for every device in the network to speed up network recovery time. Multiple scripts also let you test new configuration scripts before setting them as the startup-config. For example, to test a new script named test.cfg, enter the command:

```
awplus#copy flash:/test.cfg running-config
```

This allows you to run a configuration file any time without restarting the device, by replacing the system's current dynamic configuration with the script in the configuration file. However, note that some commands require you to restart the device before they can take effect, such as the platform commands.

You can also set a trigger to automatically execute a configuration script when a predetermined event occurs. For information about creating triggers, see [Chapter 82, Triggers Introduction](#).

Copying Files To and From Your Device

This section provides instructions on:

- [URL Syntax](#)
- [Copying files](#)

URL Syntax

Many of the file management commands use the placeholder “URL” to represent the name and location of the file that you want to act on. The following table explains the syntax of this URL for each different type of file location.

When you copy a file...	Use this syntax:
In local Flash memory	<code>flash: [/] [DIRECTORY /] FILENAME</code>
Stored on an SD card	<code>card: [/] [DIRECTORY /] FILENAME</code>
Copying with Hypertext Transfer Protocol (HTTP)	<code>http: [/] [[USERNAME : PASSWORD] @] { HOSTNAME HOST-IP } [/ FILEPATH] / FILENAME</code>
Copying with Trivial File Transfer Protocol (TFTP)	<code>tftp: [[/] / LOCATION] / DIRECTORY / FILENAME</code>
Copying with Secure Copy (SCP)	<code>scp: [/] [USERNAME @ LOCATION] [/ DIRECTORY] [/ FILENAME]</code>
Copying with SSH File Transfer Protocol (SFTP)	<code>sftp: [[/] / LOCATION] / DIRECTORY / FILENAME</code>

Copying files

To copy files, use the copy commands. These commands allow you to copy files:

- between different memory types attached to your device. Use the command:

```
awplus#copy LOCAL-SOURCE LOCAL-DEST FILENAME
```

See “Copying within a file system” and “” for further details.

- across a serial connection using ZMODEM. Use the command:

```
awplus#copy zmodem
```

See “Copying with ZMODEM” for further details.

- from your device onto a remote device, or to your device from a remote device. To copy a file across an interface with IP configured, use the command:

```
awplus#copy SOURCE-URL DESTINATION-URL
```

To copy files across these interfaces you can use the following protocols:

- « “Copying with Hypertext Transfer Protocol (HTTP)”
- « “Copying with Trivial File Transfer Protocol (TFTP)”
- « “Copying with Secure Copy (SCP)”
- « “Copying with SSH File Transfer Protocol (SFTP)”

Copying within a file system

Within a directory

To copy a file within the same directory, enter Privileged Exec mode and enter the command:

```
awplus#copy <source-filename> <destination-filename>
```

If the file already exists, the switch asks whether to overwrite it, with a message like this:

```
Overwrite flash:/example.cfg? (y/n) [n]:
```

To overwrite, press the “y” key then the Enter key.

Between directories

To copy a file to another directory within the same file system, enter the command:

```
awplus#copy <source-filename> <directory-name>/
```

The / after the directory name is required. Otherwise the switch displays an error (“37: Destination file is a directory”).

The switch then prompts you for the destination filename. To give the copy a new name, type the name at the prompt. You can include directory names in the path.

To use the same filename as the original, press the Enter key (do not press the “y” key—that names the copy “y”).

Example

To put a copy of example.cfg into the example directory, enter the command:

```
awplus#copy example.cfg example/
```

The prompt and messages look like this:

```
Enter destination file name [example.cfg]:
Copying from source file, please wait...
Copying to destination file, please wait...
0: Successful operation
```

Copying To and From NVS or SD card

To copy between file systems, you need to specify the file system prefix (NVS: or card:).

For example, to copy from Flash to NVS when your current directory is the top-level Flash directory, enter Privileged Exec mode and enter the command:

```
awplus#copy <source-filename> nvs:
```

The switch prompts you for the filename, as described in the previous section.

To copy from NVS to Flash when your current directory is the top-level Flash directory, enter the command:

```
awplus#copy nvs:<source-filename> <destination-filename>
```

Example

To copy the file “example.txt” from the directory in NVS called “example” to the top level of Flash, enter the command:

```
awplus#copy nvs:example/example.txt example.txt
```

Copying with ZMODEM

ZMODEM allows you to copy files from a network host over an asynchronous port. Use the command:

```
awplus#copy zmodem
```

to open Minicom and transfer a file. Alternatively you can specify the file name within the command:

```
awplus#copy SOURCE-URL zmodem
```

For example, to copy the file "july.cfg" from Flash memory using ZMODEM, use the command:

```
awplus#copy flash:/july.cfg zmodem
```

Copying with Hypertext Transfer Protocol (HTTP)

Your device has a built-in HTTP client. The HTTP client enables the device to act as a browser by sending HTTP "get" or "post" requests to an HTTP server. The client is enabled by default.

For example, to load the file "bob.key" onto Flash from the security directory on the web server at www.company.com, use the command:

```
awplus# copy http://www.company.com/security/bob.key flash:/bob.key
```

Copying with Trivial File Transfer Protocol (TFTP)

TFTP runs over User Datagram Protocol (UDP). It is simpler and faster than FTP but has minimal capability, such as no provisions for user authentication.

To copy a file from a TFTP server to Flash memory, enter Privileged Exec mode and enter the command:

Note: You can specify the server and filename in the command instead of waiting for prompts. Use a format like the following:

```
copy tftp://172.1.1.1/example.cfg flash
```

```
awplus#copy tftp flash
```

The switch prompts you for the:

- TFTP server hostname (you can enter its IP address instead)
- source filename on the TFTP server
- destination filename in Flash on the switch

To copy a file from Flash to a TFTP server, enter the command:

```
awplus#copy flash tftp
```

Follow the prompts for source filename, server, and destination filename.

If the file is not in the top level of the TFTP server, include the path as part of the filename.

Example To copy example.cfg to the TFTP server at 172.1.1.1, enter the command:

```
awplus#copy flash tftp
```

The prompts, responses, and messages look like this:

```
Enter source file name []:example.cfg
Enter destination host name []:172.1.1.1
Enter destination file name [example.cfg]:
Copying from source file, please wait...
Copying to destination file, please wait...
0: Successful operation
```

To load the file “bob.key” from a TFTP server, where the file is in the folder “security”, use the command:

```
awplus. copy tftp://security/bob.key flash:/bob.key
```

Copying with Secure Copy (SCP)

Secure Copy (SCP) provides a secure way to copy files to and from a remote device using SSH. The AlliedWare Plus™ OS includes both a SSH server and a SSH client. You must enable the SSH server before your device accepts connections from SCP clients.

For example, to load the file “beth.key” onto Flash from the key directory on a remote SSH server at 10.10.0.12, using the username “bob”, use the command:

```
awplus#copy scp://bob@10.10.0.12/key/beth.key flash:/beth.key
```

Copying with SSH File Transfer Protocol (SFTP)

SSH File Transfer Protocol (SFTP) provides a secure way to copy files onto your device from a remote device. The AlliedWare Plus™ OS includes both a SSH server and a SSH client. SFTP provides additional features from SCP, such as allowing you to manipulate the remote files, and halt or resume file transfers without closing the session.

For example, to load the file “rei.cfg” onto Flash memory from the remote server at 10.0.0.5, use the command:

```
awplus#copy sftp://10.0.0.5/rei.cfg flash:/rei.cfg
```

Copying from a Server to Running Configuration

Use the copy tftp variant of the [copy running-config command on page 7.9](#) to load a configuration file from a server to the running configuration of the switch.

The configuration will be added to the running configuration as if the commands were typed in the command line interface.

The resulting configuration file will be a combination of the previous running configuration and the loaded configuration file. The loaded configuration file has precedence.

Chapter 7: File Management Commands

Introduction.....	7.3
Command List.....	7.4
boot backup.....	7.4
boot config-file.....	7.4
boot system	7.5
cd.....	7.5
copy current-software.....	7.6
copy debug.....	7.7
copy (local).....	7.8
copy running-config	7.9
copy startup-config.....	7.10
copy (URL).....	7.11
copy zmodem.....	7.12
delete	7.13
delete debug.....	7.14
dir	7.15
edit.....	7.16
edit URL	7.17
erase startup-config	7.17
license	7.18
mkdir	7.19
move	7.20
move debug	7.21
pwd.....	7.21
rmdir.....	7.22
show boot.....	7.23
show file	7.24
show file systems.....	7.25
show license.....	7.27
show running-config	7.29
show running-config access-list	7.30
show running-config as-path access-list.....	7.31
show running-config bgp.....	7.32
show running-config community-list	7.33
show running-config full	7.34
show running-config interface.....	7.35
show running-config ip pim dense-mode	7.37
show running-config ip pim sparse-mode.....	7.37
show running-config ip route	7.38
show running-config ipv6 access-list.....	7.38
show running-config ipv6 mroute	7.39
show running-config ipv6 prefix-list.....	7.39
show running-config ipv6 route.....	7.40
show running-config key chain	7.40
show running-config lldp.....	7.41
show running-config prefix-list.....	7.42
show running-config power-inline.....	7.43

show running-config route-map.....	7.44
show running-config router	7.45
show running-config router-id	7.46
show running-config switch	7.47
show running-config switch lacp.....	7.48
show running-config switch radius-server	7.48
show running-config switch vlan.....	7.49
show startup-config.....	7.50
show version	7.51
write file	7.52
write memory.....	7.52
write terminal	7.52

Introduction

This chapter provides an alphabetical reference of AlliedWare Plus™ OS file management commands.

URL Syntax and Keyword Usage

Many of the commands in this chapter use the placeholder “URL” to represent the name and location of the file that you want to act on. The following table explains the syntax of this URL for each different type of file location.

When you copy a file...	Use this syntax:
In local Flash memory	[DIRECTORY /] FILENAME or flash[:][/] [DIRECTORY /] FILENAME
Stored on an SD card	card[:][/] [DIRECTORY /] FILENAME
Using Hypertext Transfer Protocol (HTTP)	http[:][/] [[USERNAME: PASSWORD] @] { HOSTNAME HOST-IP } [/ FILEPATH] / FILENAME
Using Trivial File Transfer Protocol (TFTP)	tftp[:][/] [/ LOCATION] / DIRECTORY / FILENAME
Using Secure Copy (SCP)	scp[:][/] USERNAME@LOCATION [/ DIRECTORY] [/ FILENAME]
Using SSH File Transfer Protocol (SFTP)	sftp[:][/] [/ LOCATION] / DIRECTORY / FILENAME
Stored on stack member Flash to stack master Flash	<stack_member_id>/flash:[/] [DIRECTORY] <stack_member_filename> <stack_master_filename>

Note: When the flash base directory is required for local file systems (**flash**, **nvs**, and **card**) you may use **flash** or **flash:** or **flash:/** and similarly when the SD card base directory is required you may use **card** or **card:** or **card:/**

The keywords **flash**, **nvs**, **card**, **tftp**, **scp**, **sftp** and **http** are reserved for tab completion when using the **copy**, **move**, **delete**, **cd**, and **dir** commands.

Keywords **flash**, **nvs**, **card**, **tftp**, **scp**, **sftp** and **http** cannot be applied as directory or subdirectory names when using a **mkdir** command.

A leading slash (/) indicates the root of the current filesystem location.

Command List

boot backup

This command specifies a backup release file to load during the next boot cycle. If your device cannot load the main release file, then the file specified with this command is used.

Syntax `boot backup <filename>`

Parameter	Description
<code><filename></code>	Name of a release file. The specified file must exist in the root directory of the flash file system. Valid release files must have a .rel extension.

Mode Global Configuration

Examples To set the release file `r1-5.3.3.rel` as the device's backup release, use the command:

```
awplus(config)# boot backup r1-5.3.3.rel
```

Related Commands [boot config-file](#)
[boot system](#)
[show boot](#)

boot config-file

This command sets the configuration file to use during the next boot cycle.

Syntax `boot config-file <filename>`

Parameter	Description
<code><filename></code>	Name of a configuration file. The specified file must exist in the root directory of the flash file system. Valid configuration files must have a .cfg extension.

Mode Global Configuration

Examples To run the configuration file `branch.cfg` the next time the device boots up, use the command:

```
awplus(config)# boot config-file flash:/branch.cfg
```

Related Commands [boot backup](#)
[boot system](#)
[show boot](#)

boot system

This command specifies the release file to load during the next boot cycle.

Syntax `boot system <filename>`

Parameter	Description
<code><filename></code>	Name of a release file. The specified file must exist in the root directory of the flash file system. Valid release files must have a .rel extension.

Mode Global Configuration

Examples To run the release file `r1-5.3.1.rel` the next time the device boots up, use the command:

```
awplus(config)# boot system r1-5.3.1.rel
```

Related Commands [boot config-file](#)
[boot backup](#)
[show boot](#)

cd

This command changes the current working directory.

Syntax `cd <directory-url>`

Parameter	Description
<code><directory-url></code>	URL of the directory.

Mode Privileged Exec

Examples To change to the directory called `images`, use the command:

```
awplus# cd images
```

Related Commands [dir](#)
[pwd](#)
[show file systems](#)

copy current-software

This command copies the AlliedWare Plus™ OS software that the device has booted from to a destination file. Specify whether the destination is Flash or Card when saving the software to the local file system.

Syntax `copy current-software <destination-url>`

Parameter	Description
<code><destination-url></code>	The URL where you would like the current running-release saved. This command creates a file if no file exists with the specified filename. If a file already exists, then the CLI prompts you before overwriting the file. See “URL Syntax and Keyword Usage” on page 7.3 for valid URL syntax.

Mode Privileged Exec

Examples To copy the current software as installed in the working directory with the file name `my-release.rel`, use the command:

```
awplus# copy current-software my-release.rel
```

Related Commands [boot system](#)
[show boot](#)

copy debug

This command copies a specified debug file to a destination file. Specify whether the destination is Flash or Card when saving the software to the local file system.

Syntax `copy debug {<destination-url>|card|debug|flash|nvs|scp|tftp}
{<source-url>|card|debug|flash|nvs|scp|tftp}`

Parameter	Description
<code><destination-url></code>	The URL where you would like the debug output saved. See “URL Syntax and Keyword Usage” on page 7.3 for valid URL syntax.
<code><source-url></code>	The URL where the debug output originates. See “URL Syntax and Keyword Usage” on page 7.3 for valid URL syntax.

Mode Privileged Exec

Examples To copy debug output to SD card with a filename `my-debug`, use the following command:

```
awplus# copy debug card:mydebug
```

Enter source file name []:

Related Commands [delete debug](#)
[move debug](#)

copy (local)

This command copies a file between local file systems. This allows you to copy a file stored on flash memory to or from a different memory type attached to your device, such as an SD card. By default, the destination filename is the same as the source file.

Syntax `copy <local-source> <local-destination> <filename>`

Parameter	Description
<local-source>	File system where the original file is stored.
	card Copies the file from an attached SD card.
	flash Copies the file from Flash memory.
<local-destination>	File system where the file is copied to.
	card Copies the file from an attached SD card
	flash Copies the file to Flash memory.
<filename>	Filename of the file you are copying.

Mode Privileged Exec

Examples To copy the file `newconfig.cfg` onto your device's flash from an SD Card, use the command:

```
awplus# copy card flash newconfig.cfg
```

Related Commands [copy \(URL\)](#)
[copy zmodem](#)
[show file](#)
[show file systems](#)

copy running-config

This command copies the running-config to a destination file, or copies a source file into the running-config. Commands entered in the running-config do not survive a device reboot unless they are saved in a configuration file.

Syntax

```
copy <source-url> running-config
copy running-config <destination-url>
copy running-config startup-config
```

Parameter	Description
<source-url>	The URL of a configuration file. This must be a valid configuration file with a .cfg filename extension. Specify this when you want the script in the file to become the new running-config. The URL can contain the following protocols or location words. See “URL Syntax and Keyword Usage” on page 7.3 for valid URL syntax.
<destination-url>	The URL where you would like the current running-config saved. This command creates a file if no file exists with the specified filename. If a file already exists, then the CLI prompts you before overwriting the file. See “URL Syntax and Keyword Usage” on page 7.3 for valid URL syntax.
startup-config	Copies the running-config into the file set as the current startup-config file.

Mode Privileged Exec

Examples To copy the file layer3.cfg into the running-config:

```
awplus# copy layer3.cfg running-config
```

To use SCP to copy the running-config as current.cfg to the remote server listening on TCP port 2000, use the command:

```
awplus# copy running-config scp://user@server:2000/
config_files/current.cfg
```

Related Commands

- copy startup-config
- write file
- write memory

copy startup-config

This command copies the startup-config script into a destination file, or alternatively copies a configuration script from a source file into the startup-config file. Specify whether the destination is flash or card when loading from the local file system.

Syntax `copy <source-url> startup-config`
`copy startup-config <destination-url>`

Parameter	Description
<code><source-url></code>	The URL of a configuration file. This must be a valid configuration file with a <code>.cfg</code> filename extension. Specify this to copy the script in the file into the <i>startup-config</i> file. Note that this does not make the copied file the new startup file, so any further changes made in the configuration file are not added to the startup-config file unless you reuse this command. See “URL Syntax and Keyword Usage” on page 7.3 for valid URL syntax.
<code><destination-url></code>	The destination and filename that you are saving the startup-config as. This command creates a file if no file exists with the specified filename. If a file already exists, then the CLI prompts you before overwriting the file. See “URL Syntax and Keyword Usage” on page 7.3 for valid URL syntax.

Mode Privileged Exec

Examples To copy the file `Layer3.cfg` to the *startup-config*, use the command:

```
awplus# copy Layer3.cfg startup-config
```

To copy the *startup-config* as the file `oldconfig.cfg` in the current directory, use the command:

```
awplus# copy startup-config oldconfig.cfg
```

Related Commands [copy running-config](#)

copy (URL)

This command copies a file. This allows you to:

- copy files from your device to a remote device
- copy files from a remote device to your device
- copy files stored on flash memory to or from a different memory type, such as an SD card
- create two copies of the same file on your device

Syntax `copy <source-url> <destination-url>`

Parameter	Description
<code><source-url></code>	The URL of the source file. See “URL Syntax and Keyword Usage” on page 7.3 for valid URL syntax.
<code><destination-url></code>	The URL for the destination file. See “URL Syntax and Keyword Usage” on page 7.3 for valid URL syntax.

Mode Privileged Exec

Examples To use TFTP to copy the file `bob.key` into the current directory from the remote server at `10.0.0.1`, use the command:

```
awplus# copy tftp://10.0.0.1/bob.key bob.key
```

To use SFTP to copy the file `new.cfg` into the current directory from a remote server at `10.0.1.2`, use the command:

```
awplus# copy sftp://10.0.1.2/new.cfg bob.key
```

To use SCP with the username `beth` to copy the file `old.cfg` into the directory `config_files` on a remote server that is listening on TCP port 2000, use the command:

```
awplus# copy scp://beth@serv:2000/config_files/old.cfg old.cfg
```

To copy the file `config.cfg` into the current directory from an SD Card, and rename it to `configtest.cfg`, use the command:

```
awplus# copy card:/config.cfg configtest.cfg
```

Stacked Devices In a stacked environment you can use the CLI on a stack master to access file systems that are located on another stack member. In this case, when you enter the command, specify the stack member's file system by using the following syntax:
`<hostname>-<member-id>/`
(for example, `awplus-1/` for a file or directory on stack member 1, `awplus-2/` for member 2 etc).

Example To copy the file `test.txt` from the top level of Flash on stack member 4 to the current directory in the stack master, use the command:

```
awplus# copy awplus-4/flash:/test.txt test.txt
```

Note that you must specify the filesystem on the slave stack member (`flash:` in this example).

Related Commands [copy \(local\)](#)
[copy zmodem](#)
[show file systems](#)

copy zmodem

This command allows you to copy files using ZMODEM using Minicom. ZMODEM works over a serial connection and does not need any interfaces configured to do a file transfer.

Syntax `copy <source-url> zmodem`
`copy zmodem`

Parameter	Description
<code><source-url></code>	The URL of the source file. See “URL Syntax and Keyword Usage” on page 7.3 for valid URL syntax.

Mode Privileged Exec

Examples To copy the local file `asuka.key` using ZMODEM, use the command:

```
awplus# copy asuka.key zmodem
```

Related Commands [copy \(local\)](#)
[copy \(URL\)](#)
[show file systems](#)

delete

This command deletes files or directories.

Syntax `delete [force] [recursive] <url>`

Parameter	Description
<code>force</code>	Ignore nonexistent filenames and never prompt before deletion.
<code>recursive</code>	Remove the contents of directories recursively.
<code><url></code>	URL of the file to delete. See “URL Syntax and Keyword Usage” on page 7.3 for valid URL syntax.

Mode Privileged Exec

Examples To delete the file `temp.cfg` from the current directory, use the command:

```
awplus# delete temp.cfg
```

To delete the read-only file `one.cfg` from the current directory, use the command:

```
awplus# delete force one.cfg
```

To delete the directory `old_configs`, which is not empty, use the command:

```
awplus# delete recursive old_configs
```

To delete the directory `new_configs`, which is not empty, without prompting if any read-only files are being deleted, use the command:

```
awplus# delete force recursive new_configs
```

Related Commands [erase startup-config](#)
[rmdir](#)

delete debug

Use this command to delete a specified debug output file.

Syntax `delete debug <source-url>`

Parameter	Description
<code><source-url></code>	The URL where the debug output originates. See “URL Syntax and Keyword Usage” on page 7.3 for valid URL syntax.

Mode Privileged Exec

Examples To delete debug output, use the following command:

```
awplus# delete debug
```

Enter source file name []:

Related Commands [copy debug](#)
[move debug](#)

dir

This command lists the files on a filesystem. If no directory or file is specified then this command lists the files in the current working directory.

Syntax `dir [all] [recursive] [<url>|flash|nvs|card|debug]`

Parameter	Description
all	List all files.
recursive	List the contents of directories recursively.
<url>	URL of the directory or file. If no directory or file is specified, then this command lists the files in the current working directory.
flash	Flash memory root directory
nvs	NVS memory root directory
card	SD card root directory
debug	Debug root directory

Mode Privileged Exec

Usage In a stacked environment you can use the CLI on a stack master to access file systems that are located on another stack member. In this case, when you enter the command, specify the stack member's file system by using the following syntax:
`<hostname>-<member-id>/`
(for example, `awplus-1/` for a file or directory on stack member 1, `awplus-2/` for member 2 etc).

Examples To list the files in the current working directory, use the command:

```
awplus# dir
```

To list the non-hidden files in the root of the Flash filesystem, use the command:

```
awplus# dir flash:
```

To list all the files in the root of the Flash filesystem, use the command:

```
awplus# dir all flash:
```

To list recursively the files in the Flash file system, use the command:

```
awplus# dir recursive flash:
```

To list the files within the flash file system for stack member 3, use the command:

```
awplus# dir awplus-3/flash:/
```

Note that you must specify the filesystem on the stack member (`flash` in this example).

Related Commands [cd](#)
[pwd](#)

edit

This command opens a text file in the AlliedWare Plus™ text editor. Once opened you can use the editor to alter to the file.

If a filename is specified and it already exists, then the editor opens it in the text editor.

If no filename is specified, the editor prompts you for one when you exit it.

Before starting the editor make sure your terminal, terminal emulation program, or Telnet client is 100% compatible with a VT100 terminal. The editor uses VT100 control sequences to display text on the terminal.

For more information about using the editor, including control sequences, see [“Using the editor” on page 6.6](#).

Syntax `edit [<filename>]`

Parameter	Description
<code><filename></code>	Name of a file in the local flash file system.

Mode Privileged Exec

Examples To create and edit a new text file, use the command:

```
awplus# edit
```

To edit the existing configuration file `myconfig.cfg` stored on your device's flash memory, use the command:

```
awplus# edit myconfig.cfg
```

Related Commands [edit URL](#)
[show file](#)

edit URL

This command opens a remote text file as read-only in the AlliedWare Plus™ text editor.

Before starting the editor make sure your terminal, terminal emulation program, or Telnet client is 100% compatible with a VT100 terminal. The editor uses VT100 control sequences to display text on the terminal.

Syntax `edit <url>`

Parameter	Description
<code><url></code>	The URL of the remote file. See “ URL Syntax and Keyword Usage ” on page 7.3 for valid URL syntax.

Mode Privileged Exec

Examples To view the file `bob.key` stored in the security directory of a TFTP server, use the command:

```
awplus# edit tftp://security/bob.key
```

Related Commands [edit](#)
[show file](#)

erase startup-config

This command deletes the file that is set as the startup-config file, which is the configuration file that the system runs when it boots up.

At the next restart, the device loads the default configuration file, `default.cfg`. If `default.cfg` no longer exists, then the device loads with the factory default configuration. This provides a mechanism for you to return the device to the factory default settings.

Syntax `erase startup-config`

Mode Privileged Exec

Examples To delete the file currently set as the startup-config, use the command:

```
awplus# erase startup-config
```

Related Commands [boot backup](#)
[boot config-file](#)
[copy running-config](#)
[copy startup-config](#)
[show boot](#)

license

These commands enable or disable the specified licensed software feature set. For feature licenses, contact your authorized distributor or reseller.

If a license key expires or a proper key is not installed, some software features will not be available.

Note: See the *AlliedWare Plus datasheet* for a list of current feature licenses available by product, and the *AlliedWare Plus How To* notes for information on obtaining them.

Syntax `license <name> <key>`
`no license [<name>|index <index-number>]`

Parameter	Description
<name>	The license name of the software feature. To display enabled license names, use the show license command. The default license names are issued with encrypted keys that enable the features. Default names can be changed but must be 15 characters or less.
<key>	The encrypted license key to enable this software feature.
<index-number>	The index number of the software feature. To display the index number, use the show license command.

Mode Privileged Exec

Usage Default feature license names are issued along with encrypted license keys by email for you to apply using this command to enable features. These default feature license names can be changed, but must be 15 characters or less in length to be accepted with the issued key.

For example, you may want to change the license name 'AT-FL-SBX9-01' to 'x900 L3 license'. The license name and license index is displayed with the [show license](#) command.

Related Commands [show license](#)

mkdir

This command makes a new directory.

Syntax `mkdir <url>`

Parameter	Description
<code><url></code>	URL of the directory that you are creating.

Mode Privileged Exec

Usage The keywords flash, nvs, card, tftp, scp, sftp and http are reserved for tab completion when using the copy, move, delete, cd and dir command. Keywords flash, nvs, card, tftp, scp, sftp and http cannot be applied as directory or subdirectory names when using a mkdir command.

Examples To make a new directory called `images` in the current directory, use the command:

```
awplus# mkdir images
```

Related Commands `cd`
`dir`
`pwd`

move

This command renames or moves a file.

Syntax `move <source-url> <destination-url>`

Parameter	Description
<code><source-url></code>	The URL of the source file. See “URL Syntax and Keyword Usage” on page 7.3 for valid URL syntax.
<code><destination-url></code>	The URL of the destination file. See “URL Syntax and Keyword Usage” on page 7.3 for valid URL syntax.

Mode Privileged Exec

Examples To rename the file `temp.cfg` to `startup.cfg`, use the command:

```
awplus# move temp.cfg startup.cfg
```

To move the file `temp.cfg` from the root of the flash filesystem to the directory `myconfigs`, use the command:

```
awplus# move temp.cfg myconfigs/temp.cfg
```

Related Commands [delete](#)
[edit](#)
[show file](#)
[show file systems](#)

move debug

This command moves a specified debug file to a destination debug file. Specify whether the destination is Flash or Card when saving the software to the local file system.

Syntax `move debug {<destination-url>|card|debug|flash|nvs}
{<source-url>|card|debug|flash|nvs}`

Parameter	Description
<code><destination-url></code>	The URL where you would like the debug output moved to. See “URL Syntax and Keyword Usage” on page 7.3 for valid URL syntax.
<code><source-url></code>	The URL where the debug output originates. See “URL Syntax and Keyword Usage” on page 7.3 for valid URL syntax.

Mode Privileged Exec

Examples To move debug output onto a SD card with a filename `my-debug`, use the following command:

```
awplus# move debug card:my-debug
```

Enter source file name []:

Related Commands [copy debug](#)
[delete debug](#)

pwd

This command prints the current working directory.

Syntax `pwd`

Mode Privileged Exec

Examples To print the current working directory, use the command:

```
awplus# pwd
```

Related Commands [cd](#)

rmkdir

This command removes a directory. The directory must be empty for the command to work unless the optional force keyword is used to remove all subdirectories or files in a directory.

Syntax `rmkdir [force] <url>`

Parameter	Description
force	Optional keyword that allows you to delete any directories that are not empty and may contain files or subdirectories.
<url>	The URL of the directory.

Mode Privileged Exec

Example To remove the directory `images` from the top level of the Flash file system, use the command:

```
awplus# rmkdir flash:/images
```

To force the removal of directory `level1` containing subdirectory `level2`, use the command:

```
awplus# mkdir level1
awplus# mkdir level1/level2
awplus# rmkdir force level1
```

Usage In a stacked environment you can use the CLI on a stack master to access file systems that are located on another stack member. In this case, when you enter the command, specify the stack member's file system by using the following syntax:
`<hostname>-<member-id>/`
(for example, `awplus-1/` for a file or directory on stack member 1, `awplus-2/` for member 2 etc).

Example To remove a directory called `test` from the top level of the Flash filesystem in stack member 3, use the command:

```
awplus# rmkdir awplus-3/flash:/test
```

Note that you must specify the filesystem ("flash:" in this example).

Related Commands `cd`
`dir`
`mkdir`
`pwd`

show boot

This command displays the current boot configuration.

Syntax `show boot`

Mode Privileged Exec

Output Figure 7-1: Example output from the **show boot** command

```
Boot configuration
-----
Current software   : r1-5.3.1.rel
Current boot image : flash:/r1-5.3.1.rel
Backup boot image  : flash:/r1-5.2.2.rel
Default boot config: flash:/default.cfg
Current boot config: flash:/my.cfg (file exists)
```

Parameters in output of the show boot command

Parameter	Meaning
Current software	The current software release that the device is using.
Current boot image	The boot image currently configured for use during the next boot cycle.
Backup boot image	The boot image to use during the next boot cycle if the device cannot load the main image.
Default boot config	The default startup configuration file. The device loads this configuration script if no file is set as the startup-config file.
Current boot config	The configuration file currently configured as the startup-config file. The device loads this during the next boot cycle.

Example To show the current boot configuration, use the command:

```
awplus# show oldconfig.cfg
```

Related Commands

- [boot backup](#)
- [boot config-file](#)
- [boot system](#)

show file

This command displays the contents of a specified file.

Syntax `show {<filename> | <url>}`

Parameter	Description
<filename>	Name of a file on the local Flash file system.
<url>	URL of a file.

Mode Privileged Exec

Example To display the contents of the file `oldconfig.cfg`, which is in the current directory, use the command:

```
awplus# show oldconfig.cfg
```

Related Commands

- [edit](#)
- [edit URL](#)
- [show file systems](#)

show file systems

This command lists the file systems and their utilization information where appropriate.

If this command is entered on the stack master, it will list the file systems for all the stack members. A stack member heading is displayed to distinguish the different lists shown for each stack member. If it is entered on a specific stack member, as a host-directed command, it will list the file systems for only that stack member.

Syntax show file systems

Mode Privileged Exec

Output Figure 7-2: Example output from the **show file systems** command

STACK member 1:								
Size(B)	Free(B)	Type	Flags	Prefixes	S/D/V	Lcl/Ntwk		
Avail								
30.0M	6.7M	flash	rw	flash:	static	local	Y	
-	-	system	rw	system:	virtual	local	-	
499.0k	0	nvs	rw	nvs:	static	local	Y	
-	-	sdcard	rw	card:	dynamic	local	N	
-	-	tftp	rw	tftp:	-	network	-	
-	-	scp	rw	scp:	-	network	-	
-	-	sftp	ro	sftp:	-	network	-	
-	-	http	ro	http:	-	network	-	
STACK member 2:								
Size(B)	Free(B)	Type	Flags	Prefixes	S/D/V	Lcl/Ntwk		
Avail								
30.0M	6.7M	flash	rw	flash:	static	local	Y	
-	-	system	rw	system:	virtual	local	-	
499.0k	0	nvs	rw	nvs:	static	local	Y	
-	-	sdcard	rw	card:	dynamic	local	N	
-	-	tftp	rw	tftp:	-	network	-	
-	-	scp	rw	scp:	-	network	-	
-	-	sftp	ro	sftp:	-	network	-	
-	-	http	ro	http:	-	network	-	
.								
.								
.								

Table 7-1: Parameters in output of the show file systems command

Parameter	Meaning
Size (B) Available	The total memory available to this file system. The units are given after the value and are M for Megabytes or k for kilobytes.
Free (B)	The total memory free within this file system. The units are given after the value and are M for Megabytes or k for kilobytes.
Type	The memory type used for this file system: flash, system, nvs, sdcard, tftp, scp, sftp, or http.
Flags	The file setting options: rw (read write), ro (read only).

Table 7-1: Parameters in output of the show file systems command(Continued)

Parameter	Meaning
Prefixes	The prefixes used when entering commands to access the file systems: flash, system, nvs, sdcard, tftp, scp, sftp, or http.
S/V/D	The memory type: static, virtual, dynamic.
Lcl / Ntwk	Whether the memory is located locally or via a network connection.
Y / N	Whether the memory is accessible: Y (yes), N (no), - (not appropriate)

Example To display the file systems for either a standalone device, or a complete stack, use the command:

```
awplus# show file systems
```

To list the file system for stack member 3, use the command:

```
awplus# remote-command 3 show file systems
```

Related Commands [edit](#)
[edit URL](#)
[show file](#)

show license

This command displays license information about a specified licensed software feature, or all enabled software feature licenses.

Syntax `show license [<name>|index <index-number>] [brief]`

Parameter	Description
<name>	The license name of the software feature to show information about.
<index-number>	The index number of the software feature to display information about.
brief	Displays a brief summary of license information.

Mode Exec and Privileged Exec

Figure 7-3: Example output from the **show license index** command

```
awplus#show license index 0
Software Feature Licenses
-----
Index                               : 0
License name                        : Base License
Customer name                       : Base License
Quantity of licenses                : 1
Type of license                     : Full
License issue date                  : 07-Jul-2000
License expiry date                 : N/A
Features include                     : VRRP OSPF-64
```

Figure 7-4: Example output from the **show license brief** command

```
awplus>show license brief
Software Feature Licenses
-----
Index License name      Quantity  Customer name
      Type                                     Period
-----
0      Base License      1         Base License
      Full                                     N/A

Current enabled features:
  VRRP
  OSPF-64
```

Table 7-2: Parameters in the output of the show license command

Output parameter	Output parameter meaning
Index	Index identifying entry
License name	Name of the license key bundle (case-sensitive)
Customer name	Customer name

Table 7-2: Parameters in the output of the show license command

Output parameter	Output parameter meaning
Quantity of licenses	Quantity of the licenses included in the feature key
Type of license	Full or Temporary
License issue date	Date the key was generated
License expiry date	Expiry date for Temporary feature key
Features include	List of features included in the feature key

Examples To display a brief summary of information about all enabled licenses, use the command:

```
awplus# show license brief
```

To display full information about all enabled licenses, use the command:

```
awplus# show license
```

To display full information about the licenses with index number 1, use the command:

```
awplus# show license index 1
```

Related Commands [license](#)

show running-config

This command displays the current configuration of the device. You can control the output in any one of the following ways:

- To display only lines that contain a particular word, follow the command with `| include word`
- To start the display at the first line that contains a particular word, follow the command with `| begin word`
- To save the output to a file, follow the command with `> filename`

For more information, see “Controlling “show” command output” on page 1.33.

Syntax `show running-config`

Mode All modes

Output Figure 7-5: Example output from the **show running-config** command

```
!
service password-encryption
!
username manager privilege 15 password 8 $1$bJoVec4D$JwOJGPr7YqoExA0GVasdE0
!
service telnet
!
no clock timezone
ip domain-lookup
!
spanning-tree mode rstp
no platform e2efc
!
interface port1.0.1-1.0.24
  switchport
  switchport mode access
!
!
service telnet
!
no clock timezone
!
!
stack virtual-mac
stack virtual-chassis-id 2111
!
!
ip domain-lookup
!
spanning-tree mode rstp
no platform e2efc
!
interface port1.0.1-1.0.24
  switchport
  switchport mode access
!
interface vlan2
  ip address 172.28.8.210/16
!
ip route 0.0.0.0/0 172.28.0.1
!
line con 0
line vty 0 4
!
end
```

Examples To display the current dynamic configuration of your device, use the command:

```
awplus# show running-config
```

Related Commands [copy running-config](#)
[show running-config access-list](#)

show running-config access-list

Use this command to show the running system status and configuration details for access-list.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show running-config access-list`

Mode Privileged Exec and Global Configuration

Example

```
awplus# show running-config access-list
```

Output Figure 7-6: Example output from the **show running-config access-list** command

```
!  
access-list abc remark annai  
access-list abc deny any  
access-list abd deny any  
!
```

Related Commands [copy running-config](#)
[show running-config](#)

show running-config as-path access-list

Use this command to show the running system status and configuration details for as-path access-list.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show running-config as-path access-list`

Mode Privileged Exec and Global Configuration

Example

```
awplus# show running-config as-path access-list
```

Output Figure 7-7: Example output from the **show running-config as-path access-list** command

```
!  
ip as-path access-list wer permit knsmk  
!
```

Related Commands [copy running-config](#)
[show running-config](#)

show running-config bgp

Use this command to show the running system BGP related configuration.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show running-config bgp`

Mode Privileged Exec and Global Configuration

Example

```
awplus# show running-config bgp
```

Output Figure 7-8: Example output from the **show running-config bgp** command

```
!  
bgp config-type standard  
bgp rfc1771-path-select  
bgp rfc1771-strict  
bgp aggregate-nexthop-check  
!  
router bgp 1  
no auto-summary  
no synchronization  
bgp router-id 1.2.3.4  
!
```

Related Commands [copy running-config](#)
[show running-config](#)

show running-config community-list

Use this command to show the running system status and configuration details for community-list

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show running-config community-list`

Mode Privileged Exec and Global Configuration

Example

```
awplus# show running-config community-list
```

Output Figure 7-9: Example output from the show running-config community list command

```
!
ip community-list standard aspd permit internet
ip community-list expanded cspd deny ljj
ip community-list expanded cspd permit dcv
ip community-list expanded wde permit njhd
ip community-list expanded wer deny sde
```

Related Commands [copy running-config](#)
[show running-config](#)

show running-config full

Use this command to show the complete status and configuration of the running system.

For information on output options, see [“Controlling “show” command output”](#) on page 1.33.

Syntax show running-config full

Mode Privileged Exec and Global Configuration

Example

```
awplus# show running-config full
```

Output Figure 7-10: Example output from the **show running-config full** command

```
!
no service password-encryption
!
interface lo
ip address 127.0.0.1/8
ipv6 address ::1/128
!
interface vlan1
ip address 10.92.0.16/24
ipv6 address fe80::202:b3ff:fea1:2159/64
!
interface vlan2
ip address 20.10.10.54/24
ipv6 address fe80::200:5eff:fe00:101/64
ipv6 address fe80::202:b3ff:fea1:1567/64
ipv6 address fe80::204:76ff:fee6:6c1c/64
ip rip authentication string abcdefghijklmnop
!
router ospf
ospf router-id 100.100.100.100
no capability opaque
redistribute static
network 10.10.10.0/24 area 3
network 10.10.11.0/24 area 1
network 10.10.16.0/24 area 2
network 192.168.0.0/24 area 1
!
router rip
network vlan2
distance 10
!
router ipv6 rip
!
ip route 5.5.5.0/24 10.10.16.2
!
line con 0
login
line vty 0 4
login
!
end
```

Related Commands [copy running-config](#)
[show running-config](#)

show running-config interface

This command displays the current configuration of one or more interfaces on the switch.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show running-config interface [<interface-list>]
[dot1x|ip igmp|ip multicast|ip pim dense-mode|ip pim sparse-mode|
ipv6 rip|lacp|mstp|ospf|rip|rstp|stp]`

Parameter	Description
<code><interface-list></code>	The interfaces or ports to display information about. An interface-list can be: ■ an interface, a switch port, or a channel group (e.g., vlan2, port1.1.12, sa3, or po4) ■ a contiguous range of interfaces, ports, or channel groups separated by a hyphen, e.g. vlan2-vlan8 or port1.1.1-port1.1.24 or sa2-4, po1-3 ■ a comma-separated list of the above, e.g., port1.0.1,port1.1.1-1.2.24. Do not mix interface types in a list. The specified interfaces must exist.
<code>dot1x</code>	displays running configuration for 802.1X port authentication for the specified interfaces.
<code>lacp</code>	displays running configuration for LACP (Link Aggregation Control Protocol) for the specified interfaces.
<code>ip igmp</code>	displays running configuration for IGMP (Internet Group Management Protocol) for the specified interfaces.
<code>ip multicast</code>	displays running configuration for general multicast settings for the specified interfaces.
<code>ip pim sparse-mode</code>	displays running configuration for PIM-SM (Protocol Independent Multicast - Sparse Mode) for the specified interfaces.
<code>ip pim dense-mode</code>	displays running configuration for PIM-DM (Protocol Independent Multicasting - Dense Mode) for the specified interfaces.
<code>mstp</code>	displays running configuration for MSTP (Multiple Spanning Tree Protocol) for the specified interfaces.
<code>ospf</code>	displays running configuration for OSPF (Open Shortest Path First) for the specified interfaces.
<code>rip</code>	displays running configuration for RIP (Routing Information Protocol) for the specified interfaces.
<code>ipv6 rip</code>	displays running configuration for RIPng (RIPng for IPv6) for the specified interfaces.
<code>rstp</code>	displays running configuration for RSTP (Rapid Spanning Tree Protocol) for the specified interfaces.
<code>stp</code>	displays running configuration for STP (Spanning Tree Protocol) for the specified interfaces.

Mode Privileged Exec

Output Figure 7-11: Example output from a **show running-config interface port1.0.2** command

```
awplus#sh running-config interface port1.0.2
!
interface port1.0.2
 switchport
 switchport mode access
!
```

Figure 7-12: Example output from the **show running-config interface** command

```
awplus#sh running-config interface
interface port1.0.1-1.0.24
 switchport
 switchport mode access
!
interface vlan1
 ip address 192.168.1.1/24
 ip rip authentication mode md5
 ip rip authentication string mykey
 ip irdp
!
interface vlan2
 ip address 192.168.2.2/24
 ip rip authentication mode md5
 ip rip authentication key-chain cars
```

Examples To display current running configuration of your switch for ports 1 to 24, use the command:

```
awplus# show running-config interface port1.0.1-port1.0.24
```

To display current running configuration of a switch for VLAN 1, use the command:

```
awplus# show running-config interface vlan1
```

To display current running configuration of a switch for VLANs 1 and 3-5, use the command:

```
awplus# show running-config interface vlan1,vlan3-vlan5
```

To display current OSPF configuration of your switch for ports 1 to 24, use the command:

```
awplus# show running-config interface port1.0.1-port1.0.24
ospf
```

To display current IGMP configuration for ports 1 to 12 on XEM 1 and 3, use the command:

```
awplus# show running-config interface port1.0.1-
1.0.12,port1.3.1-1.3.12 ip igmp
```

Related Commands [copy running-config](#)
[show running-config](#)

show running-config ip pim dense-mode

Use this command to show the running system status and configuration details for PIM-DM.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show running-config ip pim dense-mode`

Mode Privileged Exec and Global Configuration

Example

```
awplus# show running-config ip pim dense-
mode
```

Output Figure 7-13: Example output from the **show running-config ip pim dense-mode** command

```
!
ip pim spt-threshold
ip pim accept-register list 1
!
```

Related Commands [copy running-config](#)
[show running-config](#)

show running-config ip pim sparse-mode

Use this command to show the running system status and configuration details for PIM-SM.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show running-config ip pim sparse-mode`

Mode Privileged Exec and Global Configuration

Example

```
awplus# show running-config ip pim sparse-
mode
```

Output Figure 7-14: Example output from the **show running-config ip pim sparse-mode** command

```
!
ip pim spt-threshold
ip pim accept-register list 1
!
```

Related Commands [copy running-config](#)
[show running-config](#)

show running-config ip route

Use this command to show the running system static IPv4 route configuration.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show running-config ip route`

Mode Privileged Exec and Global Configuration

Example

```
awplus# show running-config ip route
```

Output Figure 7-15: Example output from the **show running-config ip route** command

```
!  
ip route 3.3.3.3/32 vlan3  
ip route 3.3.3.3/32 vlan2  
!
```

Related Commands `copy running-config`
`show running-config`

show running-config ipv6 access-list

Use this command to show the running system status and configuration for ipv6 access-list.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show running-config ipv6 access-list`

Mode Privileged Exec and Global Configuration

Example

```
awplus# show running-config ipv6 access-list
```

Output Figure 7-16: Example output from the **show running-config ipv6 access-list** command

```
!  
ipv6 access-list abc permit any  
!
```

Related Commands `copy running-config`
`show running-config`

show running-config ipv6 mroute

Use this command to show the running system IPv6 multicast route configuration.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax show running-config ipv6 mroute

Mode Privileged Exec and Global Configuration

Example

```
awplus# show running-config ipv6 mroute
```

Output Figure 7-17: Example output from the **show running-config ipv6 mroute** command

```
!
ipv6 route 3e11::/64 lo
ipv6 route 3e11::/64 vlan2
ipv6 route fe80::/64 vlan3
!
```

Related Commands copy running-config
show running-config

show running-config ipv6 prefix-list

Use this command to show the running system status and configuration details for ipv6 prefix-list.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax show running-config ipv6 prefix-list

Mode Privileged Exec and Global Configuration

Example

```
awplus# show running-config ipv6 prefix-list
```

Output Figure 7-18: Example output from the **show running-config ipv6 prefix-list** command

```
!
ipv6 prefix-list sde seq 5 permit any
!
```

Related Commands copy running-config
show running-config

show running-config ipv6 route

Use this command to show the running system static IPv6 route configuration.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show running-config ipv6 route`

Mode Privileged Exec and Global Configuration

Example

```
awplus# show running-config ipv6 route
```

Output Figure 7-19: Example output from the **show running-config ipv6 route** command

```
!  
ipv6 route 3e11::/64 lo  
ipv6 route 3e11::/64 vlan2  
ipv6 route fe80::/64 vlan3  
!
```

Related Commands `copy running-config`
`show running-config`

show running-config key chain

Use this command to show the running system key-chain related configuration.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show running-config key chain`

Mode Privileged Exec and Global Configuration

Example

```
awplus# show running-config key chain
```

Output Figure 7-20: Example output from the **show running-config key chain** command

```
!  
key chain 12  
key 2  
key-string 234  
!  
key chain 123  
key 3  
key-string 345  
!
```

Related Commands `copy running-config`
`show running-config`

show running-config lldp

This command shows the current running configuration of LLDP.

Syntax `show running-config lldp`

Mode Privileged Exec

Examples To display the current configuration of LLDP, use the command:

```
awplus# show running-config lldp
```

Output Figure 7-21: Example output from the **show running-config lldp** command

```
awplus#show running-config lldp
lldp notification-interval 10
lldp timer 20
!
interface port1.0.1
  lldp notifications
  lldp tlv-select port-description
  lldp tlv-select system-name
  lldp tlv-select system-description
  lldp tlv-select management-address
  lldp transmit receive
```

Related Commands [show lldp](#)
[show lldp interface](#)

show running-config prefix-list

Use this command to show the running system status and configuration details for prefix-list.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show running-config prefix-list`

Mode Privileged Exec and Global Configuration

Example

```
awplus# show running-config prefix-list
```

Output Figure 7-22: Example output from the **show running-config prefix-list** command

```
!  
ip prefix-list abc seq 5 permit any  
ip prefix-list as description annal  
ip prefix-list wer seq 45 permit any  
!
```

Related Commands `copy running-config`
`show running-config`

show running-config power-inline

Use this command to show the Power over Ethernet (PoE) running system status and configuration details. The PoE usage-threshold percentage as specified by the [power-inline usage-threshold](#) command is displayed in the running-config using this command.

See [Chapter 22, Power over Ethernet Introduction](#) and [Chapter 23, Power over Ethernet Commands](#) for more information about PoE.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show running-config power-inline`

Mode Privileged Exec and Global Configuration

Example

```
awplus# show running-config power-inline
```

Output Figure 7-23: Example output from the **show running-config power-inline** command

```
!  
power-inline usage-threshold 90  
!
```

Related Commands [power-inline usage-threshold](#)
[show power-inline](#)

show running-config route-map

Use this command to show the running system status and configuration details for route-map.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show running-config route-map`

Mode Privileged Exec and Global Configuration

Example

```
awplus# show running-config route-map
```

Output Figure 7-24: Example output from the **show running-config route-map** command

```
!  
route-map abc deny 2  
match community 2  
!  
route-map abc permit 3  
match route-type external type-2  
set metric-type type-1  
!
```

Related Commands `copy running-config`
`show running-config`

show running-config router

Use the show running-config router command to display the current running configuration for a given router.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax show running-config router <protocol>

Parameter	Description
<router-protocol>	bgp ospf rip ipv6 rip vrrp
bgp	Border Gateway Protocol (BGP)
ospf	Open Shortest Path First (OSPF)
rip	Routing Information Protocol (RIP)
ipv6 rip	rip IPv6 RIP
vrrp	Virtual Redundancy Routing Protocol (VRRP)

Mode Privileged Exec and Global Configuration

Example

```
awplus# show running-config router bgp
```

Output Figure 7-25: Example output from the **show running-config router** command

```
!
router bgp 1
network 172.1.0.0/16
neighbor 10.10.10.1 remote-as 1
!
```

Related Commands copy running-config
show running-config

show running-config router-id

Use this command to show the running system global router ID configuration.

For information on output options, see [“Controlling “show” command output”](#) on page 1.33.

Syntax `show running-config router-id`

Mode Privileged Exec and Global Configuration

Example

```
awplus# show running-config router-id
```

Output Figure 7-26: Example output from the **show running-config router-id** command

```
!  
router-id 3.3.3.3  
!
```

Related Commands `copy running-config`
`show running-config`

show running-config switch

Use this command to show the running system status and configuration details for a given switch.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show running-config switch <switch-protocol>`

Parameter	Description
<switch-protocol>	dot1x mstp rstp stp
dot1x	802.1X Port-Based Authentication
mstp	Multiple Spanning Tree Protocol (MSTP)
rstp	Rapid Spanning Tree Protocol (RSTP)
stp	Spanning Tree Protocol (RSTP)

Mode Privileged Exec and Global Configuration

Example

```
awplus# show running-config switch stp
```

Output Figure 7-27: Example output from the **show running-config switch** command

```
!
bridge 6 ageing-time 45
bridge 6 priority 4096
bridge 6 max-age 7
```

Related Commands [copy running-config](#)
[show running-config](#)

show running-config switch lacp

Use this command to show the running system LACP related configuration.

For information on output options, see [“Controlling “show” command output”](#) on page 1.33.

Syntax `show running-config switch lacp`

Mode Privileged Exec and Global Configuration

Example

```
awplus# show running-config switch lacp
```

Output Figure 7-28: Example output from the **show running-config switch lacp** command

```
!  
lacp system-priority 23  
!
```

Related Commands [copy running-config](#)
[show running-config](#)

show running-config switch radius-server

Use this command to show the running system radius-server related configuration.

For information on output options, see [“Controlling “show” command output”](#) on page 1.33.

Syntax `show running-config switch radius-server`

Mode Privileged Exec and Global Configuration

Example

```
awplus# show running-config switch radius-server
```

Output Figure 7-29: Example output from the **show running-config switch radius-server** command

```
!  
radius-server key abc  
!
```

Related Commands [copy running-config](#)
[show running-config](#)

show running-config switch vlan

Use this command to show the running system VLAN related configuration.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show running-config switch vlan`

Mode Privileged Exec and Global Configuration

Example

```
awplus# show running-config switch vlan
```

Output Figure 7-30: Example output from the **show running-config switch vlan** command

```
!
vlan database
vlan 4 bridge 2 name VLAN0004
vlan 4 bridge 2 state enable
```

Related Commands [copy running-config](#)
[show running-config](#)

show startup-config

This command displays the contents of the start-up configuration file, which is the file that the device runs on start-up.

For information on output options, see [“Controlling “show” command output” on page 1.33](#).

Syntax show startup-config

Mode Privileged Exec

Output Figure 7-31: Example output from the **show startup-config** command

```
!
service password-encryption
!
username manager privilege 15 password 8 $1$bJoVec4D$JwOJGPr7YqoExA0GVasdE0
!

platform routingratio ipv4only
!
service telnet
!
no clock timezone
ip domain-lookup
.
.
.
end
```

Examples To display the contents of the current start-up configuration file, use the command:

```
awplus# show startup-config
```

Related Commands boot config-file
 copy running-config
 copy startup-config
 erase startup-config
 show boot

show version

This command displays the version number and copyright details of the current AlliedWare Plus™ OS your device is running.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax show version

Mode Privileged Exec and Exec

Output Figure 7-32: Example output from the **show version** command

```
AlliedWare Plus (TM) 5.2.2 06/06/08 00:47:48

Build name : r1-5.2.2-20080606-1.rel
Build date : Mon Aug 6 00:47:48 NZST 2008
Build type : RELEASE

NET-SNMP SNMP agent software
(c) 1989, 1991, 1992 by Carnegie Mellon University;
(c) 1996, 1998-2000 The Regents of the University of California.
All Rights Reserved;
(c) 2001, Networks Associates Technology, Inc. All rights reserved;
(c) 2001, Cambridge Broadband Ltd. All rights reserved.
  RSA Data Security, Inc. MD5 Message-Digest Algorithm
(c) 1991-2, RSA Data Security, Inc. Created 1991. All rights reserved.
Libedit Library
(c) 1992, 1993 The Regents of the University of California. All rights reserved.
OpenSSL Library
Copyright (C) 1998-2002 The OpenSSL Project. All rights reserved.
Original SSLeay License
Copyright (C) 1995-1998 Eric Young (eay@cryptsoft.com)
```

Example To display the version details of your currently installed software, use the command:

```
awplus# show version
```

Related Commands [boot system](#)
 [show boot](#)

write file

This command copies the running-config into the file that is set as the current startup-config file. This command is a synonym of the write memory and copy running-config startup-config commands.

Syntax write [file]

Mode Privileged Exec

Examples To write configuration data to the start-up configuration file, use the command:

```
awplus# write file
```

Related Commands copy running-config
write memory
show running-config

write memory

This command copies the running-config into the file that is set as the current startup-config file. This command is a synonym of the write file and copy running-config startup-config commands.

Syntax write [memory]

Mode Privileged Exec

Examples To write configuration data to the start-up configuration file, use the command:

```
awplus# write memory
```

Related Commands copy running-config
write file
show running-config

write terminal

This command displays the current configuration of the device. This command is a synonym of the show running-config command.

Syntax write terminal

Mode Privileged Exec

Examples To display the current configuration of your device, use the command:

```
awplus# write terminal
```

Related Commands show running-config

Chapter 8: System Configuration and Monitoring Commands



Command List	8.2
banner exec	8.2
banner login (system)	8.4
banner motd	8.5
clock set	8.6
clock summer-time date	8.7
clock summer-time recurring	8.8
clock timezone	8.9
debug nsm	8.10
debug nsm packet	8.10
hostname	8.11
no debug all	8.12
max-fib-routes	8.12
max-static-routes	8.13
show clock	8.14
show cpu	8.15
show cpu history	8.19
show debugging nsm	8.21
show memory	8.22
show memory allocations	8.24
show memory history	8.26
show memory pools	8.28
show nsm client	8.29
show process	8.29
show router-id	8.31
show system	8.32
show system environment	8.34
show system interrupts	8.35
show system pci device	8.36
show system pci tree	8.37
show system pluggable	8.38
show system pluggable detail	8.39
show system serialnumber	8.41
show tech-support	8.42
system territory	8.45
terminal monitor	8.46
undebg nsm	8.46
undebg nsm packet	8.47

Command List

This chapter provides an alphabetical reference of commands for configuring and monitoring the system.

banner exec

This command configures the Exec mode banner that is displayed on the console after you login. The banner exec default command restores the Exec banner to the default banner. Use the no banner exec command to disable the Exec banner and remove the default Exec banner.

Syntax banner exec <banner-text>

banner exec default

no banner exec

Mode Global Configuration

Default By default, the AlliedWare Plus version and build date is displayed at console login, such as:

AlliedWare Plus (TM) 5.3.1 07/27/08 00:44:25

Examples To configure a Exec mode banner after login, issue the following commands:

```
awplus#configure terminal
awplus(config)#banner exec enable to move to Priv Exec mode
awplus(config)#exit
awplus#exit

awplus login: manager
Password:
enable to move to Priv Exec mode
awplus>
```

To restore the default Exec mode banner after login, issue the following commands:

```
awplus#configure terminal
awplus(config)#banner exec default
awplus(config)#exit
awplus#exit

awplus login: manager
Password:
AlliedWare Plus (TM) 5.3.1 11/14/08 13:03:59
awplus>
```

To remove the Exec mode banner after login, issue the following commands:

```
awplus#configure terminal
awplus(config)#banner exec default
awplus(config)#exit
awplus#exit

awplus login: manager
Password:
awplus>
```

Related Commands [banner login \(system\)](#)
[banner motd](#)

banner login (system)

This command configures the login banner that is displayed on the console when you login. The login banner is displayed on all connected terminals. The login banner is displayed after the MOTD (Message-of-the-Day) banner and before the login username and password prompts.

Use the no banner login command to disable the login banner.

Syntax banner login
no banner login

Mode Global Configuration

Default By default, no login banner is displayed at console login.

Examples To configure a login banner to be displayed when you login, issue the following commands:

```
awplus#configure terminal
awplus(config)#banner login
Type CNTL/D to finish.
authorised users only
awplus(config)#exit
awplus#exit

authorised users only
awplus login: manager
Password:

AlliedWare Plus (TM) 5.3.1 11/14/08 13:03:59

awplus>
```

To remove the login banner, issue the following commands:

```
awplus#configure terminal
awplus(config)#no banner login
awplus(config)#exit
awplus#exit

awplus login: manager
Password:

awplus>
```

Related Commands banner exec
banner motd

banner motd

This command displays a text MOTD (Message-of-the-Day) banner on login. The MOTD banner is displayed on all connected terminals. The MOTD banner is useful for sending messages that affect all network users, for example, any imminent system shutdowns.

Use the `no` parameter to not display a text MOTD (Message-of-the-Day) banner on login.

Syntax `banner motd <motd-text>`

`no banner motd`

Mode Global Configuration

Default By default, no motd is displayed at console login.

Examples To configure a motd banner to be displayed when you login, issue the following commands:

```
awplus>enable
awplus#configure terminal
awplus(config)#banner motd system shutdown at 6pm
awplus(config)#exit
awplus#exit

system shutdown at 6pm
awplus login: manager
Password:

AlliedWare Plus (TM) 5.3.1 11/14/08 13:03:59
```

To remove the login banner, issue the following commands:

```
awplus>enable
awplus#configure terminal
awplus(config)#no banner motd
awplus(config)#exit
awplus#exit

awplus login: manager
Password:

AlliedWare Plus (TM) 5.3.1 11/14/08 13:03:59

awplus>
```

Related Commands `banner exec`
`banner login (system)`

clock set

This command sets the time and date for the system clock.

Syntax `clock set <hh:mm:ss> <day> <month> <year>`

Parameter	Description
<hh:mm:ss>	Local time in 24-hour format
<day>	Day of the current month <1-31>
<month>	The first three letters of the current month.
<year>	Current year <2000-2035>

Mode Privileged Exec

Usage Configure the timezone before setting the local time. Otherwise, when you change the timezone, the device applies the new offset to the local time.

Note: If Network Time Protocol (NTP) is enabled, then you cannot change the time or date using this command. NTP maintains the clock automatically using an external time source. If you wish to manually alter the time or date, you must first disable NTP.

Example To set the time and date on your system to 2pm on the 2nd of April 2007, use the command:

```
awplus# clock set 14:00:00 2 apr 2007
```

Related Commands [clock timezone](#)
[show clock](#)

clock summer-time date

This command defines the start and end of summertime for a specific year only, and specifies summertime's offset value to Standard Time for that year.

The no parameter removes the device's summertime setting. This clears both specific summertime dates and recurring dates (set with the [clock summer-time recurring command on page 8.8](#)).

By default, the device has no summertime definitions set.

Syntax `clock summer-time <timezone-name> date <start-day> <start-month>
<start-year> <start-time> <end-day> <end-month> <end-year>
<end-time> <1-180>`

`no clock summer-time`

Parameter	Description
<code><timezone-name></code>	A description of the summertime zone, up to 6 characters long.
<code>date</code>	Specifies that this is a date-based summertime setting for just the specified year.
<code><start-day></code>	Day that the summertime starts, in the range 1-31.
<code><start-month></code>	First three letters of the name of the month that the summertime starts.
<code><start-year></code>	Year that summertime starts, in the range 2000-2035.
<code><start-time></code>	Time of the day that summertime starts, in the 24-hour time format HH:MM.
<code><end-day></code>	Day that summertime ends, in the range 1-31.
<code><end-month></code>	First three letters of the name of the month that the summertime ends.
<code><end-year></code>	Year that summertime ends, in the range 2000-2035.
<code><end-time></code>	Time of the day that summertime ends, in the 24-hour time format HH:MM.
<code><1-180></code>	The offset in minutes.

Mode Global Configuration

Examples To set a summertime definition for New Zealand using NZST (UTC+12:00) as the standard time, and NZDT (UTC+13:00) as summertime, with the summertime set to begin on the 1st October 2007 and end on the 18th of March 2008:

```
awplus(config)# clock summer-time NZDT date 1 oct 2:00 2007 18
mar 2:00 2008 60
```

To remove any summertime settings on the system, use the command:

```
awplus(config)# no clock summer-time
```

Related Commands [clock summer-time recurring](#)
[clock timezone](#)
[show clock](#)

clock summer-time recurring

This command defines the start and end of summertime for every year, and specifies summertime's offset value to Standard Time.

The no parameter removes the device's summertime setting. This clears both specific summertime dates (set with the [clock summer-time date command on page 8.7](#)) and recurring dates.

By default, the device has no summertime definitions set.

Syntax `clock summer-time <timezone-name> recurring <start-week> <start-day>
 <start-month> <start-time> <end-week> <end-day> <end-month>
 <end-time> <1-180>`

`no clock summer-time`

Parameter	Description
<code><timezone-name></code>	A description of the summertime zone, up to 6 characters long.
<code>recurring</code>	Specifies that this summertime setting applies every year from now on.
<code><start-week></code>	Week of the month when summertime starts, in the range 1-5. The value 5 indicates the last week that has the specified day in it for the specified month. For example, to start summertime on the last Sunday of the month, enter 5 for <code><start-week></code> and sun for <code><start-day></code> .
<code><start-day></code>	Day of the week when summertime starts. Valid values are mon, tue, wed, thu, fri, sat or sun.
<code><start-month></code>	First three letters of the name of the month that summertime starts.
<code><start-time></code>	Time of the day that summertime starts, in the 24-hour time format HH:MM.
<code><end-week></code>	Week of the month when summertime ends, in the range 1-5. The value 5 indicates the last week that has the specified day in it for the specified month. For example, to end summertime on the last Sunday of the month, enter 5 for <code><end-week></code> and sun for <code><end-day></code> .
<code><end-day></code>	Day of the week when summertime ends. Valid values are mon, tue, wed, thu, fri, sat or sun.
<code><end-month></code>	First three letters of the name of the month that summertime ends.
<code><end-time></code>	Time of the day that summertime ends, in the 24-hour time format HH:MM.
<code><1-180></code>	The offset in minutes.

Mode Global Configuration

Examples To set a summertime definition for New Zealand using NZST (UTC+12:00) as the standard time, and NZDT (UTC+13:00) as summertime, with summertime set to start on the 1st Sunday in October, and end on the 3rd Sunday in March, use the command:

```
awplus(config)# clock summer-time NZDT recurring 1 sun oct 2:00
3 sun mar 2:00 60
```

To remove any summertime settings on the system, use the command:

```
awplus(config)# no clock summer-time
```

Related Commands [clock summer-time date](#)
[clock timezone](#)
[show clock](#)

clock timezone

This command defines the device's clock timezone. The timezone is set as a offset to the UTC.

The no parameter resets the system time to UTC.

By default, the system time is set to UTC.

Syntax `clock timezone <timezone-name> {minus|plus} <0-12>`
`no clock timezone`

Parameter	Description
<timezone-name>	A description of the timezone, up to 6 characters long.
minus or plus	The direction of offset from UTC. The minus option indicates that the timezone is behind UTC. The plus option indicates that the timezone is ahead of UTC.
<0-12>	The offset in hours from UTC.

Mode Global Configuration

Usage Configure the timezone before setting the local time. Otherwise, when you change the timezone, the device applies the new offset to the local time.

Examples To set the timezone to New Zealand Standard Time with an offset from UTC of +12 hours, use the command:

```
awplus(config)# clock timezone NZST plus 12
```

To set the timezone back to UTC with no offsets, use the command:

```
awplus(config)# no clock timezone
```

Related Commands [clock set](#)
[clock summer-time date](#)
[clock summer-time recurring](#)
[show clock](#)

debug nsm

This command specifies a set of debug options for use by Allied Telesis authorized service personnel only. Use this command to specify the debug options set for the routing manager.

Syntax `debug nsm [all|events|kernel|mcast|mcast6]`
`no debug nsm [all|events]`

Parameter	Description
all	Enables all the nsm debugging options.
events	Enables the nsm events debugging options.
ha	Enables the nsm high availability debugging options.
kernel	Enables the nsm kernel debugging options.
mcast	Enables the nsm IPv4 multicast debugging options.
mcast6	Enables the nsm IPv6 multicast debugging options.

Mode Privileged Exec and Global Configuration

Related Commands [show debugging nsm](#)

debug nsm packet

This command specifies a set of debug options for use by Allied Telesis authorized service personnel only. Use this command to specify the debug options for the nsm packet.

Syntax `debug nsm packet [recv|send] [detail]`
`no debug nsm packet`

Mode Privileged Exec and Global Configuration

Related Commands [show debugging nsm](#)

hostname

This command sets the name applied to the device as shown at the prompt. The hostname is:

- displayed in the output of the `show system` command
- displayed in the CLI prompt so you know which device you are configuring
- stored in the MIB object `sysName`

Use the `no` parameter to reset the hostname to the default value (`awplus`).

On a stack, after the stack master is elected, the master will have a host name: `awplus` by default, and this also becomes the name of the stack. Individual stack members (excluding the master) will have a host name that is the stack name hyphenated with a numeric suffix. For example, `awplus-1`, `awplus-2` and so on.

The hostname command can then be used to change the stack name and the stack master's host name. For example, for the hostname `Lab` the stack master's host name will be `Lab` and the other stack members will have host names `Lab-1`, `Lab-2` and so on.

In case of stack master fail-over, or stack split, the new stack will use the previous stack name as its host name and the stack name, unless it is changed by executing hostname command on the new stack master.

Syntax `hostname <hostname>`

`no hostname`

Parameter	Description
<code><hostname></code>	Specifies the network name of the system.
<code>no</code>	Reverts the hostname setting to its default value

Mode Global Configuration

Default The default hostname is `awplus`.

Usage To specify or modify the host name, use the hostname global configuration command. The host name is used in prompts and default configuration filenames.

The name must also follow the rules for ARPANET host names. The name must start with a letter, end with a letter or digit, and use only letters, digits, and hyphens. Refer to RFC 1035.

Example To set the system name to "HQ-Sales", use the command:

```
awplus(config)# hostname HQ-Sales
```

This changes the prompt to:

```
HQ-Sales(config)#
```

Related Commands `show system`

no debug all

This command disables the debugging facility for all features on your device. This stops the device from generating any diagnostic debugging messages.

The debugging facility is disabled by default.

Syntax `no debug all`

Mode Global Configuration and Privileged Exec

Example To disable debugging facility for all features, use the command:

```
awplus# no debug all
```

max-fib-routes

Use this command to set the maximum number of fib (forwarding information base) routes, excluding static routes. Note that static routes are set and reset using [max-static-routes](#).

Use the no max-fib-routes command to set the maximum number of fib routes to the default value of 4294967294 fib routes.

Syntax `max-fib-routes <1-4294967294>`
`no max-fib-routes`

Mode Global Configuration

Default The default number of fib routes is the maximum number of fib routes (4294967294).

Example To reset the maximum number of forwarding information base routes issue the command:

```
awplus# configure terminal
awplus(config)# no max-fib-routes
```

Related Commands [max-static-routes](#)

max-static-routes

Use this command to set the maximum number of static routes, excluding fib routes. Note that fib routes are set and reset using [max-fib-routes](#).

Use the no max-static-routes command to set the maximum number of static routes to the default value of 1000 static routes.

Syntax max-static-routes <1-1000>
 no max-static-routes

Mode Global Configuration

Default The default number of static routes is the maximum number of static routes (1000).

Examples To reset the maximum number of static routes to the default maximum issue the command:

```
awplus# configure terminal
awplus(config)# no max-static-routes
```

Related Commands [max-fib-routes](#)

show clock

This command displays the system's current configured local time and date. It also displays other clock related information such as timezone and summertime configuration.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show clock`

Mode Exec and Privileged Exec

Examples To display the system's current local time, use the command:

```
awplus# show clock
```

Output Figure 8-1: Example output from the **show clock** command for a switch using New Zealand time

```
Local Time: Mon,  6 Aug 2007 13:56:06 +1200
UTC Time:  Mon,  6 Aug 2007 01:56:06 +0000
Timezone: NZST
Timezone Offset: +12:00
Summer time zone: NZDT
Summer time starts: Last Sunday in September at 02:00:00
Summer time ends: First Sunday in April at 02:00:00
Summer time offset: 60 mins
Summer time recurring: Yes
```

Table 8-1: Parameters in output of the show clock command

Parameter	Meaning
Local Time	Current local time.
UTC Time	Current UTC time.
Timezone	The current configured timezone name.
Timezone Offset	Number of hours offset to UTC.
Summer time zone	The current configured summertime zone name.
Summer time starts	Date and time set as the start of summer time.
Summer time ends	Date and time set as the end of summer time.
Summer time offset	Number of minutes that summer time is offset from the system's timezone.
Summer time recurring	Whether the device will apply the summer time settings every year or only once.

Related Commands

- [clock set](#)
- [clock summer-time date](#)
- [clock summer-time recurring](#)
- [clock timezone](#)

show cpu

This command displays a list of running processes with their CPU utilization.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show cpu [sort {thrds|pri|sleep|runtime}]`

Parameter	Description
sort	Whether to sort the list by a specified field. If you do not specify this, then the list is sorted by percentage CPU utilization.
thrds	The list is sorted by the number of threads.
pri	The list is sorted by the process priority.
sleep	The list is sorted by the average time sleeping.
runtime	The list is sorted by the runtime of the process.

Mode Exec and Privileged Exec

Usage Entering this command on the stack master will display the information of all the stack members. A stack member heading will distinguish the different information for every stack member device.

Entering this command for a specific stack member (as a host-directed command) will display the information for that stack member.

Examples To show the cpu utilization of current processes, sorting them by the number of threads the processes are using, use the command:

```
awplus# show cpu sort thrds
```

Note that in a stack environment, executing this command on the stack master will show CPU utilization for all stack members.

To show CPU utilization for a specific stack member (in this case stack member 3), use the following command:

```
awplus# remote-command 3 show cpu
```

Output Figure 8-2: Example output from the **show cpu** command

```

Stack member 1:

CPU averages:
 1 second: 5%, 20 seconds: 0%, 60 seconds: 0%
System load averages:
 1 minute: 0.00, 5 minutes: 0.00, 15 minutes: 0.00
Current CPU load:
 userspace: 4%, kernel: 1%, interrupts: 0% iowaits: 0%

user processes
=====
 pid name          thrds  cpu%   pri state sleep% runtime
1532 hostd          1    1.9    20  run    0     103
1113 exfx           18    0.9    20 sleep  0    3374
1225 aixexec        44    0.9    -2 sleep  0    2290
1630 mstpd           1    0.9    20 sleep  0     86
   1 init            1    0.0    20 sleep  0    799
6149 sh              1    0.0    20 sleep  0     0
6150 corerotate      1    0.0    20 sleep  0     0
 801 syslog-ng       1    0.0    20 sleep  0    287
 807 klogd            1    0.0    20 sleep  0     1
 858 inetd            1    0.0    20 sleep  0    21
 868 portmap         1    0.0    20 sleep  0     0
 879 crond            1    0.0    20 sleep  0     1
1038 openhpid        10    0.0    20 sleep  0    161
1057 hpilogd          1    0.0    20 sleep  0     0
1147 stackd           1    0.0    20 sleep  0    10
1170 hsl              1    0.0    20 sleep  0     1
1258 rpc.statd        1    0.0    20 sleep  0     0
1262 rpc.statd        1    0.0    20 sleep  0     0
1268 rpc.mountd      1    0.0    20 sleep  0     0
1361 automount        1    0.0    20 sleep  0    84
1395 ntpd             1    0.0    20 sleep  0    18
1440 authd            1    0.0    20 sleep  0    89
1463 bgpd             1    0.0    20 sleep  0    88
1483 cntrd            1    0.0    20 sleep  0    89
1509 epsrd            1    0.0    20 sleep  0    90
1560 imi              1    0.0    20 sleep  0    87
1581 irdpd            1    0.0    20 sleep  0    90
1603 lacpd           1    0.0    20 sleep  0    86
1653 nsm              1    0.0    20 sleep  0   111
1678 ospfd           1    0.0    20 sleep  0    89
1700 pdmd             1    0.0    20 sleep  0    88
1722 pimd             1    0.0    20 sleep  0    87
1743 ripd             1    0.0    20 sleep  0    90
1765 ripngd          1    0.0    20 sleep  0    88
1786 rmond            1    0.0    20 sleep  0    91
1798 sshd             1    0.0    20 sleep  0     0
1905 atlgetty        1    0.0    20 sleep  0     0
1906 getty            1    0.0    20 sleep  0     0

kernel threads
=====
 pid name          cpu%   pri state sleep% runtime
 87 aio/0           0.0    15 sleep  0         0
  5 events/0        0.0    15 sleep  0      575
673 fsl-cpm-spi.1   0.0    15 sleep  0         0
 58 kblockd/0       0.0    15 sleep  0         0
  6 khelper         0.0    15 sleep  0         1
667 kmmcd           0.0    15 sleep  0         0
  3 ksoftirqd/0     0.0    15 sleep  0      78
 86 kswapd0         0.0    15 sleep  0         0
  2 kthreadd        0.0    15 sleep  0         0
989 loop0           0.0     0 sleep  0      16
648 mtdblockd       0.0    15 sleep  0         5
 84 pdflush         0.0    20 sleep  0         0
732 rpciod/0        0.0    15 sleep  0         0
689 wl_control       0.0    15 sleep  0         2
  4 watchdog/0     0.0   -100 sleep  0         0
768 jffs2_gcd_mtd0  0.0    30 sleep  0         5
1264 lockd           0.0    20 sleep  0         0
1265 nfsd            0.0    20 sleep  0     130

```


Stack member 3:

CPU averages:

1 second: 12%, 20 seconds: 2%, 60 seconds: 2%

System load averages:

1 minute: 0.03, 5 minutes: 0.02, 15 minutes: 0.00

Current CPU load:

userspace: 6%, kernel: 4%, interrupts: 1% iowaits: 0%

user processes

=====

pid	name	thrds	cpu%	pri	state	sleep%	runtime
1544	hostd	1	2.8	20	run	0	120
1166	exfx	17	1.8	20	sleep	0	3846
1198	stackd	1	0.9	20	sleep	0	459
1284	aisexec	44	0.9	-2	sleep	0	2606
1	init	1	0.0	20	sleep	0	120
9772	sh	1	0.0	20	sleep	0	0
9773	corerotate	1	0.0	20	sleep	0	0
853	syslog-ng	1	0.0	20	sleep	0	356
859	klogd	1	0.0	20	sleep	0	1
910	inetd	1	0.0	20	sleep	0	3
920	portmap	1	0.0	20	sleep	0	0
931	crond	1	0.0	20	sleep	0	1
1090	openhpid	11	0.0	20	sleep	0	233
1111	hpidogd	1	0.0	20	sleep	0	0
1240	hsl	1	0.0	20	sleep	0	79
1453	authd	1	0.0	20	sleep	0	85
1477	bgpd	1	0.0	20	sleep	0	40
1497	cntrd	1	0.0	20	sleep	0	2
1520	epsrd	1	0.0	20	sleep	0	56
1571	imi	1	0.0	20	sleep	0	275
1594	irdpd	1	0.0	20	sleep	0	23
1617	lcpd	1	0.0	20	sleep	0	87
1638	mstpd	1	0.0	20	sleep	0	75
1662	nsm	1	0.0	20	sleep	0	163
1685	ospfd	1	0.0	20	sleep	0	35
1708	pdmd	1	0.0	20	sleep	0	23
1729	pimd	1	0.0	20	sleep	0	32
1751	ripd	1	0.0	20	sleep	0	33
1775	ripngd	1	0.0	20	sleep	0	25
1797	rmond	1	0.0	20	sleep	0	64
1963	ntpd	1	0.0	20	sleep	0	15
2102	atlgetty	1	0.0	20	sleep	0	0
2712	rpc.statd	1	0.0	20	sleep	0	0
2716	rpc.statd	1	0.0	20	sleep	0	0
2722	rpc.mountd	1	0.0	20	sleep	0	0
2821	automount	1	0.0	20	sleep	0	82
2892	ntpd	1	0.0	20	sleep	0	17
2912	sshd	1	0.0	20	sleep	0	0
9774	login	1	0.0	20	sleep	0	2
12689	more	1	0.0	20	sleep	0	0

kernel threads

=====

pid	name	cpu%	pri	state	sleep%	runtime
3	ksoftirqd/0	1.9	15	sleep	0	2605
87	aio/0	0.0	15	sleep	0	0
5	events/0	0.0	15	sleep	0	588
673	fsl-cpm-spi.1	0.0	15	sleep	0	0
58	kblockd/0	0.0	15	sleep	0	0
6	khelper	0.0	15	sleep	0	1
667	kmmcd	0.0	15	sleep	0	0
86	kswapd0	0.0	15	sleep	0	0
2	kthreadd	0.0	15	sleep	0	0
1041	loop0	0.0	0	sleep	0	18
648	mtdblockd	0.0	15	sleep	0	5
84	pdflush	0.0	20	sleep	0	0
784	rpciod/0	0.0	15	sleep	0	0
689	wl_control	0.0	15	sleep	0	3
4	watchdog/0	0.0	-100	sleep	0	0
820	jffs2_gcd_mtd0	0.0	30	sleep	0	1
2718	lockd	0.0	20	sleep	0	0
2719	nfsd	0.0	20	sleep	0	0

Table 8-2: Parameters in the output of the **show cpu** command

Parameter	Meaning
Stack member	The ID of the stack member. Displayed if the switch is in a stack.
System load averages	The average number of processes waiting for CPU time for the periods stated.
Current CPU load	Current CPU utilization specified by load types.
CPU averages	Average CPU utilization for the periods stated.
pid	Identifier number of the process.
name	A shortened name for the process
thrs	Number of threads in the process.
cpu%	Percentage of CPU utilization that this process is consuming.
pri	Process priority state.
state	Process state; one of “run”, “sleep”, “zombie”, and “dead”.
sleep%	Percentage of time that the process is in the sleep state.
runtime	The time that the process has been running for, measured in jiffies. A jiffy is the duration of one tick of the system timer interrupt.

Related Commands [remote-command](#)
[show memory](#)
[show memory allocations](#)
[show memory history](#)
[show memory pools](#)
[show process](#)

show cpu history

This command prints a graph showing the historical CPU utilization.

For information on output options, see [“Controlling “show” command output”](#) on page 1.33.

Syntax `show cpu history`

Mode Exec and Privileged Exec

Usage This command's output displays three graphs of the percentage CPU utilization:

- per second for the last minute, then
- per minute for the last hour, then
- per 30 minutes for the last 30 hours.

If this command is entered on the stack master, it will print graphs for all the stack members. A stack member heading will be displayed to distinguish the different graphs for every stack member.

If the command is entered on a specific stack member, as a host-directed command, it will print the graph for that particular stack member.

Examples To display a graph showing the historical CPU utilization of the device, use the command:

```
awplus# show cpu history
```

To display the CPU utilization history graph for another stack member, use the command:

```
awplus# remote-command 3 show cpu history
```

where 3 is the node id of the stack member.

Output Figure 8-3: Example output from the **show cpu history** command

[illegible]

Related Commands

- remote-command
- show memory
- show memory allocations
- show memory pools
- show process

show debugging nsm

This command displays system details for use by Allied Telesis authorized service personnel only.

For information on output options, see [“Controlling “show” command output” on page 1.33](#).

Syntax `show debugging nsm`

Mode Exec and Privileged Exec

Related Commands [debug nsm](#)

show memory

This command displays the memory used by each process that is currently running

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show memory [sort {size|peak|stk}]`

Parameter	Description
sort	Changes the sorting order for the list of processes. If you do not specify this, then the list is sorted by percentage memory utilization.
size	Sorts the list by the amount of memory the process is currently using.
peak	Sorts the list by the peak amount of memory the process has ever used.
stk	Sorts the list by the stack size of the process.

Mode Exec and Privileged Exec

Usage If this command is entered on the stack master, it will display corresponding memory utilization information for all the stack members. A stack member heading will be displayed to distinguish the different lists for every stack member.

If it is entered on a specific stack member, as host-directed commands, it will display corresponding memory utilization information for that stack member.

Examples To display the memory used by the current running processes, use the command:

```
amp1us# show memory
```

Output Figure 8-4: Example output from the **show memory** command

```
RAM total: 514920 kB; free: 382716; buffers: 16368 kB

user processes
=====
pid name                mem%   size   peak   data   stk
962 pss                  6    33112  36260  27696  244
1  init                  0     348   1092   288    84
797 syslog-ng            0     816   2152   752    84
803 klogd                 0     184   1244   124    84
843 inetd                 0     256   1256   136    84
```

Table 8-3: Parameters in the output of the show memory command

Parameter	Meaning
RAM total	Total amount of RAM memory free.
free	Available memory size.
buffers	Memory allocated kernel buffers.
pid	Identifier number for the process.
name	Short name used to describe the process.

Table 8-3: Parameters in the output of the show memory command (Continued)

Parameter	Meaning
mem%	Percentage of memory utilization the process is currently using.
size	Amount of memory currently used by the process.
peak	Greatest amount of memory ever used by the process.
data	Amount of memory used for data.
stk	The stack size.

Related Commands [show memory allocations](#)
[show memory history](#)
[show memory pools](#)

show memory allocations

This command displays the memory allocations used by processes.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show memory allocations [<process>]`

Parameter	Description
<process>	Displays the memory allocation used by the specified process.

Mode Exec and Privileged Exec

Usage If entered on the stack master, this command will display corresponding memory utilization information for all the stack members. A stack member heading will be displayed to distinguish the different lists for every stack member.

If it is entered on a specific stack member, as host-directed commands, it will display corresponding memory utilization information for that stack member.

Examples To display the memory allocations used by all processes on your device, use the command:

```
awplus# show memory allocations
```

To display the memory allocations used by BGP, use the command:

```
awplus# show memory allocations bgp
```

Output Figure 8-5: Example output from the **show memory allocations** command

```
Memory allocations for BGP
-----
name bgpd; pid 1155; size 2860; peak 8988; data 2360; stack 84
LDP Id
filename:line    allocated      freed
+               lib.c:614        296
=====
296
Memory diagnostics
filename:line    allocated      freed
+               gmem_diag.c:149   1820
+               gmem_diag.c:199   3024
=====
4860
```

Table 8-4: Parameters in the output from the **show memory allocations** command

Parameter	Meaning
name	Short name used to describe the process.
pid	Identifier number for the process.
size	Amount of memory in kB used by the process.
peak	The peak amount of memory in kB ever used by the process.

Table 8-4: Parameters in the output from the **show memory allocations** command

Parameter	Meaning
data	Amount of memory used for data.
stack	The stack size.

Related Commands [show memory](#)
 [show memory history](#)
 [show memory pools](#)

show memory history

This command prints a graph showing the historical memory usage.

For information on output options, see [“Controlling “show” command output”](#) on page 1.33.

Syntax `show memory history`

Mode Exec and Privileged Exec

Usage This command's output displays three graphs of the percentage memory utilization:

- per second for the last minute, then
- per minute for the last hour, then
- per 30 minutes for the last 30 hours.

If entered on the stack master, this command will display corresponding memory utilization information for all the stack members. A stack member heading will be displayed to distinguish the different lists for every stack member.

If it is entered on a specific stack member, as host-directed commands, it will display corresponding memory utilization information for that stack member.

Examples To show a graph displaying the historical memory usage for either a single unstacked device, or a complete stack, use the command:

```
awplus# show memory history
```

To show a graph displaying the historical memory usage for a single device (device 3 in this example) within a stack, use the command:

```
awplus# remote-command 3 show memory history
```

Output Figure 8-6: Example output from the **show memory history** command

```

STACK member 1:

Per minute memory utilization history

100
 90
 80
 70
 60
 50
 40 *****
 30
 20
 10
    |...|...|...|...|...|...|...|...|...|...|...|...
    Oldest                                     Newest
      Memory utilization% per minute (last 60 minutes)
        * = average memory utilisation%.
.
.
-----

STACK member 2:

Per minute memory utilization history

100
 90
 80
 70
 60
 50
 40 *****
 30
 20
 10
    |...|...|...|...|...|...|...|...|...|...|...|...
    Oldest                                     Newest
      Memory utilization% per minute (last 60 minutes)
        * = average memory utilisation%.
.
.

```

Related Commands [show memory allocations](#)
[show memory pools](#)

show memory pools

This command shows the memory pools used by processes.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show memory pools [<process>]`

Parameter	Description
<process>	Displays the memory pools used by the specified process.

Mode Exec and Privileged Exec

Examples To show the memory pools used by processes, use the command:

```
awplus# show memory pools
```

Output Figure 8-7: Example output from the **show memory pools** command

```
Memory pools for BGP
-----
name bgpd; pid 1207; size 1996; peak 8640; data 2012; stack 84
pool                                     allocated
----
LDP Id                                  296
Memory diagnostics                     2508
Message of The Day                      96
Host config                             8
Link list                               320
Rmap                                     64
Temporary memory                       113440
Vector                                  21992
.
.
.
Application Total (kb)                  283
```

Table 8-5: Parameters in the output from the **show memory pools** command

Parameter	Description
name	Short name used to describe the process.
pid	Identifier for the process.
size	Amount of memory in kB used by the process.
peak	Peak amount of memory in kB ever used by the process.
data	Amount of memory in kB used for data.
stack	The stack size in kB.

Related Commands [show memory allocations](#)
[show memory history](#)

show nsm client

This command displays system details for use by Allied Telesis authorized service personnel only.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show nsm client`

Mode Privileged Exec

show process

This command lists a summary of the current running processes.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show process [sort {cpu|mem}]`

Parameter	Description
sort	Changes the sorting order for the list of processes.
cpu	Sorts the list by the percentage of CPU utilization.
mem	Sorts the list by the percentage of memory utilization.

Mode Exec and Privileged Exec

Usage For a stacked configuration, if this command is entered on the stack master, it will display the information for all the stack members. A stack member heading will be displayed to distinguish the different information for every stack member.

If it is entered on a specific stack member, as a host-directed command, it will display the information for that stack member.

Examples To display a summary of the current running processes, use the command:

```
awplus# show process
```

Output Figure 8-8: Example output from the **show process** command

```

CPU load for 1 minute: 0%; 5 minutes: 3%; 15 minutes: 0%
RAM total: 514920 kB; free: 382600 kB; buffers: 16368 kB

user processes
=====
pid name          thrds  cpu%  mem%   pri  state  sleep%
962 pss             12     0     6    25  sleep     5
1  init              1     0     0    25  sleep     0
797 syslog-ng        1     0     0    16  sleep    88

kernel threads
=====
pid name          cpu%  pri  state  sleep%
71  aio/0           0    20  sleep   0
3   events/0        0    10  sleep  98

```

Table 8-6: Parameters in the output from the **show process** command

Parameter	Meaning
CPU load	Average CPU load for the given period.
RAM total	Total memory size.
free	Available memory.
buffers	Memory allocated to kernel buffers.
pid	Identifier for the process.
name	Short name to describe the process.
thrds	Number of threads in the process.
cpu%	Percentage of CPU utilization that this process is consuming.
mem%	Percentage of memory utilization that this process is consuming..
pri	Process priority.
state	Process state; one of “run”, “sleep”, “stop”, “zombie”, or “dead”.
sleep%	Percentage of time the process is in the sleep state.

Related Commands [remote-command](#)
[show cpu](#)
[show cpu history](#)

show router-id

Use this command to display the Router ID of the current system.

For information on output options, see [“Controlling “show” command output” on page 1.33](#).

Syntax `show router-id`

Mode Exec and Privileged Exec

Example

```
awplus# show router-id
```

Output Figure 8-9: Example output from the **show router-id** command

```
awplus>show router-id
Router ID: 10.55.0.2 (automatic)
```

show system

This command displays general system information about the device, including the hardware installed, memory, and software versions loaded. It also displays location and contact details when these have been set.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show system`

Mode Exec and Privileged Exec

Usage For a stacked configuration, if this command is entered on the stack master, it will display the information for all the stack members. A stack member heading will be displayed to distinguish the different information for every stack member.

If it is entered on a specific stack member, as a host-directed command, it will display the information for that stack member.

Example To display the system information for a single switch, or a whole stack, use the command:

```
awplus# show system
```

To display the system information of stack member 3, use the command:

```
awplus# remote-command 3 show system
```

Output Figure 8-10: Example output from the **show system** command

```
Switch System Status                                     Wed Dec 19 08:42:16 2007
Board      ID  Bay  Board Name                                     Rev  Serial number
-----
Base       219      AT-9924T-EMC                                     A-0  61556953
-----
Memory:    DRAM: 255196 kB   Flash: 30.0MB Used: 26.4MB Available: 3.6MB
-----
Environment Status : Normal
Uptime             : 25 days 11:41:58
Bootloader version : 1.0.9

Current software   : r2-main-20071011-1.rel
Software version   : main 20071011-1
Build date        : Thu Oct 11 02:41:04 NZDT 2007

Current boot config: flash:/default.cfg (file exists)
Territory         : usa

System Name
System Contact
System Location
```


Figure 8-11: Example output from the **show system** command for a stacked configuration

Stack System Status				Tue Aug 7 05:25:09 2007	
Stack member 1:					
Board	ID	Bay	Board Name	Rev	Serial number

Base	270		x900-24XT	B-0	41FY68006
Expansion	272	Bay1	XEM-1XP	B-0	41AR65001
Expansion	285	Bay2	XEM-STK	A-0	M1L174004
PSU	212	PSU1	AT-PWR01-AC	F-1	66354904
Fan module	214	PSU2	AT-FAN01	F-1	66098695

Memory:	DRAM: 514460 kB		Flash: 31.0MB Used: 25.1MB Available: 5.9MB		

Environment Status: Normal					
Uptime: 0 days 04:26:02					
Stack member 2:					
Board	ID	Bay	Board Name	Rev	Serial number

Base	271		x900-24XS	A-2	41HF6900U
Expansion	272	Bay1	XEM-1XP	A-0	41AR5B003
Expansion	285	Bay2	XEM-STK	(nul	M1L17400T
PSU	212	PSU1	AT-PWR01-AC	F-1	66354904
Fan module	214	PSU2	AT-FAN01	F-1	66098695

Memory:	DRAM: 514460 kB		Flash: 31.0MB Used: 25.2MB Available: 5.8MB		

Environment Status: Normal					
Uptime: 0 days 00:01:14					
Bootloader version : 1.0.9					
Current software : r1-5.2.2-20080807-2.rel					
Software version : 5.2.2 20070807-2					
Build date : Tue Aug 7 09:27:05 NZST 2008					
Current boot config: flash:/default.cfg (file exists)					
Territory : usa					
System Name					
System Contact					
System Location					

Related Commands [remote-command](#)
[show system environment](#)

show system environment

This command displays the current environmental status of your device and any attached PSU, XEM, or other expansion option. The environmental status covers information about temperatures, fans, and voltage.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show system environment`

Mode Exec and Privileged Exec

Usage For a stacked configuration, if this command is entered on the stack master, it will display the information for all the stack members. A stack member heading will be displayed to distinguish the different information for every stack member.

If it is entered on a specific stack member, as a host-directed command, it will display the information for that stack member.

Example To display the system's environmental status, use the command:

```
awplus# show system environment
```

Output Figure 8-12: Example output from the `show system environment` command

```
Environment Monitoring Status
Overall Status: ***Fault***

Resource ID: 1 Name: PSU bay 1
ID Sensor (Units)      Reading  Low Limit High Limit Status
1 Device Present       0        -        -        -        FAULT
2 PSU Overtemp         0        -        -        -        Ok
3 PSU Fan Fail         0        -        -        -        Ok
4 PSU Power Good       0        -        -        -        Ok

Resource ID: 2 Name: PSU bay 2
ID Sensor (Units)      Reading  Low Limit High Limit Status
1 Device Present       1        -        -        -        Ok
2 PSU Overtemp         0        -        -        -        Ok
3 PSU Fan Fail         0        -        -        -        Ok
4 PSU Power Good       1        -        -        -        Ok

Resource ID: 3 Name: x900-24XS
ID Sensor (Units)      Reading  Low Limit High Limit Status
1 Voltage: 2.5V (Volts) 2.578    0.000    3.320    Ok
2 Voltage: 1.65V (Volts) 1.629    0.000    2.988    Ok
3 Voltage: 3.3V (Volts) 3.369    0.000    4.383    Ok
4 Voltage: 1.8V (Volts) 1.771    0.000    6.641    Ok
5 Voltage: 1.2V (Volts) 12.000   0.000    15.938   Ok
6 Temp: Ambient (Degrees C) 30      -127     100      Ok
7 Temp: Sensor chip (Degrees C) 46      -127     85       Ok
8 Temp: Internal (Degrees C) 43      -127     127      Ok

Resource ID: 4 Name: XEM-12S
ID Sensor (Units)      Reading  Low Limit High Limit Status
1 Fan: XEM Fan 1 (Rpm) 5153     3516     -        Ok
2 Voltage: 2.5V (Volts) 2.539    2.344    2.865    Ok
3 Voltage: 1.65V (Volts) 1.603    1.491    1.814    Ok
4 Voltage: 3.3V (Volts) 3.334    2.973    3.627    Ok
5 Voltage: 5V (Volts) 4.948    4.505    5.495    Ok
6 Voltage: 12V (Volts) 11.563   10.813   13.188   Ok
7 Voltage: 1.8V (Volts) 1.828    1.617    1.983    Ok
8 Temp: Internal (Degrees C) 42      70 (Hyst) 85       Ok
```

Related Commands [show system](#)

show system interrupts

Use this command to display the number of interrupts for each IRQ (Interrupt Request) used to interrupt input lines on a PIC (Programmable Interrupt Controller) on your switch.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show system interrupts`

Parameter	Description
<code>show</code>	Show running system information
<code>system</code>	System properties
<code>interrupts</code>	interrupts per IRQ

Mode Exec and Privileged Exec

Example To display information about the number of interrupts for each IRQ in your device, use the command:

```
awplus# show system interrupts
```

Output [Figure 8-13: Example output from the `show system interrupts` command](#)

```
awplus>show system interrupts
      CPU0
  1:      2   CPM2 SIU  Level Enabled  0   i2c-mpc
  2:     145   CPM2 SIU  Level Enabled  0   spi-mpc
 77:      0   OpenPIC  Level Enabled  0   enet_tx
 78:      2   OpenPIC  Level Enabled  0   enet_rx
 82:      0   OpenPIC  Level Enabled  0   enet_error
 90:    5849   OpenPIC  Level Enabled  0   serial
 91:  2066672   OpenPIC  Level Enabled  0   i2c-mpc
 94:     147   OpenPIC  Level Enabled  0   cpm2_cascade
112:      5   OpenPIC  Edge  Enabled  0   phy_interrupt
114:  398714   OpenPIC  Level Enabled  0   mvPP
115:   26247   OpenPIC  Level Enabled  0   mvPP
119:      0   OpenPIC  Edge  Enabled  0   Power supply status
120:      0   OpenPIC  Edge  Enabled  0   Plugin XEM
BAD:      0
```

Related Commands [show system environment](#)

show system pci device

Use this command to display the PCI devices on your switch.

For information on output options, see [“Controlling “show” command output”](#) on page 1.33.

Syntax `show system pci device`

Parameter	Description
show	Show running system information
system	System properties
pci	PCI information
device	PCI device list

Mode Exec and Privileged Exec

Example To display information about the PCI devices on your switch, use the command:

```
awplus# show system pci device
```

Output Figure 8-14: Example output from the `show system pci device` command

```
awplus>show system pci device
00:0c.0 Class 0200: 11ab:00d1 (rev 01)
  Flags: bus master, 66Mhz, medium devsel, latency 128, IRQ 113
  Memory at 5ffff000 (32-bit, non-prefetchable) [size=4K]
  Memory at 58000000 (32-bit, non-prefetchable) [size=64M]

00:0d.0 Class 0200: 11ab:00d1 (rev 01)
  Flags: bus master, 66Mhz, medium devsel, latency 128, IRQ 116
  Memory at 57fff000 (32-bit, non-prefetchable) [size=4K]
  Memory at 50000000 (32-bit, non-prefetchable) [size=64M]
```

Related Commands [show system environment](#)
[show system pci tree](#)

show system pci tree

Use this command to display the PCI tree on your switch.

For information on output options, see [“Controlling “show” command output”](#) on page 1.33.

Syntax `show system pci tree`

Parameter	Description
show	Show running system information
system	System properties
pci	PCI information
tree	PCI tree view

Mode Exec and Privileged Exec

Example To display information about the PCI tree on your switch, use the command:

```
awplus# show system pci tree
```

Output Figure 8-15: Example output from the **show system pci tree** command

```
awplus>show system pci tree
-[00]--+-0c.0 11ab:00d1
      \-0d.0 11ab:00d1
```

Related Commands `show system environment`
`show system pci device`

show system pluggable

This command displays information about the pluggable transceivers, such as SFPs and XFPs, which are currently installed in your switch.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show system pluggable`

Mode Exec and Privileged Exec

Usage For a stacked configuration, if this command is entered on the stack master, it will display information about the pluggable transceiver for all the stack members. A stack member heading will be displayed to distinguish the different pluggable transceiver information for every stack member.

If it is entered on a specific stack member, as a host-directed command, it will display information about the pluggable transceiver for that stack member.

Example To display information about the pluggable transceiver installed in your switch, use the command:

```
awplus# show system pluggable
```

Output Figure 8-16: Example output from the `show system pluggable` command

System Pluggable Information					
Port	Manufacturer	Device	Serial Number	Datecode	Type
0.5	AGILENT	HBCU-5710R	AK051400PV	050408	1000BASE-T
0.9	FINISAR CORP.	FCMJ-8521-3	P6606MY	040803	1000BASE-T
0.14	AGILENT	HFBR-5710L	0401312315461272	040131	1000BASE-SX
0.17	AGILENT	QBCU-5730R	AK0614GKF7	060408	1000BASE-T
0.20	AGILENT	HFBR-5710L	0305130112182696	030513	1000BASE-SX
0.23	AGILENT	HBCU-5710R	AK051300SM	050402	1000BASE-T
2.1	AGILENT	HFCT-721XPD	MB01300D	05121201	10GBASE-LR

Related Commands [show system environment](#)
[show system pluggable detail](#)

show system pluggable detail

This command displays detailed information about the pluggable transceivers, such as SFPs or XFPs, which are currently installed in your switch.

In addition to the information about pluggable transceivers displayed using the [show system pluggable](#) command (port, manufacturer, serial number, manufacturing datecode, and type information), the show system pluggable detail command displays the following information:

- **Wavelength:** Specifies the laser wavelength of the installed pluggable transceiver
- **Single mode length:** Specifies the link length supported by the pluggable transceiver using single mode fiber
- **OM1 length:** Specifies the link length supported by the pluggable transceiver using 62.5 micron multi-mode fiber.
- **OM2 length:** Specifies the link length supported by the pluggable transceiver using 50 micron multi-mode fiber.

Note: For parameters that are not supported or not specified, a hyphen is displayed instead.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax show system pluggable detail

Mode Exec and Privileged Exec

Usage For a stacked configuration, if this command is entered on the stack master, it will display detailed information about the pluggable transceivers for all the stack members. A stack member heading will be displayed to distinguish the different pluggable transceiver information for every stack member.

If it is entered on a specific stack member, as a host-directed command, it will display detailed information about the pluggable transceiver for that stack member.

Example To display detailed information about the pluggable transceivers installed on a standalone switch, use the command:

```
awplus# show system pluggable detail
```

Output Figure 8-17: Example output from the **show system pluggable detail** command on a switch

```
System Pluggable Information Detail

Port1.0.45
=====
Vendor Name:           ATI
Device Name:           AT-SPLX10
Device Type:           1000BASE-LX
Serial Number:         0000071004100004
Manufacturing Datecode: 07040900
SFP Laser Wavelength:  1310nm
Link Length Supported
  Single Mode Fiber :   10000m
  OM1 (62.5um) Fiber:   -
  OM2 (50um) Fiber  :   -
```

Example To display detailed information about the pluggable transceivers installed on a stack, use the command:

```
awplus# show system pluggable detail
```

Output Figure 8-18: Example output from the **show system pluggable detail** command on a stack:

```
Stack member 1:

Port1.0.45
=====
Vendor Name:          AGILENT
Device Name:          HFCT-5710L
Device Type:          1000BASE-LX
Serial Number:        0402142241184360
Manufacturing Datecode: 040214
SFP Laser Wavelength: -
Link Length Supported
  Single Mode Fiber : 10Km
  OM1 (62.5um) Fiber: 550m
  OM2 (50um) Fiber : 550m

Stack member 2:

Port2.0.47
=====
Vendor Name:          FINISAR CORP.
Device Name:          FTRJ-8519-7D-CSC
Device Type:          1000BASE-SX
Serial Number:        P430KGY
Manufacturing Datecode: 030718
SFP Laser Wavelength: 850nm
Link Length Supported
  Single Mode Fiber : -
  OM1 (62.5um) Fiber: 300m
  OM2 (50um) Fiber : 550m
```

Related Commands [show system environment](#)
[show system pluggable](#)

show system serialnumber

This command shows the serial number information for the switch.

For information on output options, see [“Controlling “show” command output”](#) on page 1.33.

Syntax `show system serialnumber`

Mode Privileged Exec

Example

```
awplus# show system serialnumber
```

Output Figure 8-19: Example output from the **show system serialnumber** command:

```
awplus#show system serialnumber
45AX5300X
awplus#
```

show tech-support

The show tech-support command generates system and debugging information for the switch and saves it to a file. You can optionally limit it to display only information for a given protocol.

The command generates a large amount of output and the output is saved into a file. The output file name can be specified by outfile option. If the output file already exists, a new file name is generated with the current time stamp. Since output files may be too large for flash on the switch we recommend saving files to an SD card whenever possible to avoid switch lockup.

If all is specified the command captures the full list of information of the device. If bgp is specified the command captures information specific to BGP, and so on. If system is specified the command captures general system information of the device.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax

```
show tech-support [all] [outfile <filename>]

show tech-support {[bgp] [igmp] [ip] [ospf] [pim] [stack] [stp]
[system]} [outfile <filename>]
```

Parameter	Description
all	output full troubleshooting information for all protocols and the device
bgp	output only BGP protocol specific troubleshooting information
igmp	output only IGMP protocol specific troubleshooting information
ip	output only IP protocol specific troubleshooting information
ospf	output only OSPF protocol specific troubleshooting information
pim	output only PIM protocol specific troubleshooting information
stack	output only stacking device specific troubleshooting information
stp	output only STP protocol specific troubleshooting information
system	output general system (not protocol) troubleshooting information
outfile	keyword used to specify the file name for the output file
filename	placeholder used to specify the file name for the output file

Default The show tech-support command by default captures all information for the switch.

By default the output is saved to the file 'tech-support.txt.gz' in the current directory. If this file already exists in the current directory then a new file is generated with the time stamp appended to the file name, for example 'tech-support20080109.txt.gz', so the last saved file is retained.

Mode Privileged Exec

Usage The show tech-support command is useful for collecting a large amount of information about all protocols or specific protocols on your switch for troubleshooting purposes. The output of this command can be provided to technical support representatives when reporting a problem.

Examples To capture the full set of show output for the technical support, use the command:

```
awplus# show tech-support
```

To capture show output related to IP module and save it to a file named `support-ip.txt.gz` on the SD card, use the below command:

```
awplus# show tech-support ip outfile card:support-ip.txt.gz
```

To capture the system technical support information, use the below command:

```
awplus# show tech-support system
```

Output The output of this command may include the result of the following commands:

```
dir flash:
show arp
show boot
show clock
show cpu
show cpu history
show etherchannel
show etherchannel detail
show exception log
show interface
show interface brief
show ip bgp
show ip bgp neighbors
show ip bgp paths
show ip bgp summary
show ip igmp groups
show ip igmp interface
show ip igmp snooping mrouter vlan1
show ip interface brief
show ip ospf
show ip ospf database
show ip ospf interface
show ip ospf neighbor
show ip ospf route
show ip pim sparse-mode bsr-router
show ip pim sparse-mode interface detail
show ip pim sparse-mode mroute detail
show ip pim sparse-mode neighbor
show ip pim sparse-mode nexthop
show ip pim sparse-mode rp mapping
show ip route
show lacp sys-id
show lacp-counter
show license
show log
show log permanent
show memory
show ntp associations
show ntp status
show platform
show platform table
```

```
show power-inline
show running-config
show spanning-tree
show stack
show stack detail
show stack full-debug
show startup-config
show static-channel-group
show system
show system environment
show system pluggable
show table vlan
show users
show vlan brief
show vrrp
```

Related Commands [show debugging nsm](#)

system territory

This command sets the territory of the system.

Use the no parameter to return the territory to its default setting of japan.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `system territory {australia|nz|europe|japan|usa|china|korea}`
`no system territory`

Parameter	Description
system	System properties
territory	Territory of system
australia	Australia
nz	New Zealand
europe	Europe
japan	Japan
usa	USA
china	China
korea	Korea

Mode Global Configuration

Example
`awplus(config)# system territory usa`

Validation Commands `show system`

terminal monitor

Use this command to display debugging output on a terminal.

To display the cursor after a line of debugging output, press the Enter key.

Use the command `terminal no monitor` to stop displaying debugging output on the terminal, or use the `timeout` option to stop displaying debugging output on the terminal after a set time.

Syntax `terminal monitor [<1-60>]`
`terminal no monitor`

Parameter	Description
<1-60>	Set a timeout between 1-60 minutes for terminal output.

Mode Privileged Exec

Examples

```
awplus# terminal monitor
```

```
awplus# terminal monitor 60
```

```
awplus# terminal no monitor
```

Related Commands All debug commands

undebug nsm

This command specifies a set of debug options for use by Allied Telesis authorized service personnel only. This command disables the debugging option for the nsm events.

Syntax `undebug nsm [all|events|ha|kernel]`

Mode Privileged Exec

Related Commands `show debugging nsm`
`debug nsm`

undebbug nsm packet

This command specifies a set of debug options for use by Allied Telesis authorized service personnel only. This command disables the debugging option for the nsm packet.

Syntax undebbug nsm packet [recv|send] [detail]

Mode Privileged Exec

Related Commands show debugging nsm
 debug nsm

Chapter 9: Debugging and Logging



Introduction.....	9.2
Debugging	9.2
Logging to terminal.....	9.2
Turning off debugging	9.2
Logging	9.3
Log Outputs	9.3

Introduction

AlliedWare Plus™ has a comprehensive debugging and logging facility in various protocols and components. This chapter describes how to start/stop debugging and logging. For detailed descriptions of the commands used to configure logging, see [Chapter 10, Logging Commands](#).

Debugging

Many protocols have debug commands. Debug commands, when used with the parameters, log protocol-specific information. For example, using the debug mstp protocol command, results in the device writing all debugging messages generated by the MSTP algorithm to the logging system.

On using a debug command, the protocol continues to generate output until the no parameter is used with the command. To specify where logging output is sent, and the level of events to log, use the log commands in [Chapter 10, Logging Commands](#).

Logging to terminal

To start debugging to the terminal:

Step 1: Turn on the debug options by using the relevant debug command.

Step 2: Run the terminal monitor command.

```
awplus> enable
awplus# configure terminal
awplus(config)# debug <protocol> (parameter)
awplus(config)# exit
awplus# terminal monitor
```

Sample Output This is a sample output of the debug rsvp events command displayed on the terminal:

```
awplus#terminal monitor
Dec  2 16:41:49 localhost RSVP[6518]: RSVP: RSVP message sent to
10.10.23.60/32 via interface vlan2
Dec  2 16:41:57 localhost RSVP[6518]: RSVP: Received an RSVP message
of type RSVP Reservation from 192.168.0.60 via interface vlan2
Dec  2 16:41:57 localhost RSVP[6518]: RSVP: Received a RESV message
from 10.10.23.60/32
```

Turning off debugging

To turn off debugging, use the no debug or undebug command. When a protocol is specified with the no debug or undebug commands, debugging is stopped for the specified protocol. To stop all debugging, use the all parameter with these commands.

```
awplus(config)# no debug bgp events
or
awplus#undebug all
```

Logging

Protocols generate important debugging messages by default, and send them to the logging system. Additional more detailed messages can be generated by enabling debugging ([“Debugging” on page 9.2](#)).

Messages can be filtered based on: the program that generated the message, the severity level of the message, the type of facility that generated the message, substrings within the message text. The severity levels in order are:

- emergencies
- alerts
- critical
- errors
- warnings
- notifications
- informational
- debugging

The facility categories are:

- auth Security/authorization messages
- authpriv Security/authorization messages (private)
- cron Clock daemon
- daemon System daemons
- ftp FTP daemon
- kern Kernel messages
- lpr Line printer subsystem
- mail Mail system
- news Network news subsystem
- syslog Messages generated internally by syslogd
- user Random user-level messages
- uucp UUCP subsystem

Log Outputs

The following types of logging output are available:

- buffered
- permanent
- terminal
- console
- host
- email

Buffered log The buffered log is a file stored in RAM on the device. Because it is stored in RAM its content does not survive a reboot of the device. A device can only have one instance of the buffered log. The buffered log is enabled by default and has a filter to include messages with a severity level of 'notifications' and above. The buffered log can be enabled or disabled using the commands:

`log buffered`

`no log buffered`

Additional filters can be added and removed using the commands described in [log buffered \(filter\)](#):

`log buffered {facility|level|msgtext|program}`

`no log buffered {facility|level|msgtext|program}`

The following log buffered commands are available:

show log	Displays the entire contents of the buffered log
<code>show log tail</code>	Displays the 10 most recent entries in the buffered log.
<code>show log tail <10-250></code>	Displays a specified number of the most recent entries in the buffered log.
show log config	Displays the configuration of all log outputs
log buffered size	Specify the amount of memory the buffered log may use.
clear log	Remove the contents of the buffered log (and permanent log if it exists)
clear log buffered	Remove the contents of the buffered log only
default log buffered	Restore the buffered log to its default configuration

Permanent log The permanent log is a file stored in NVS on the device. This output type is only available on devices that have NVS. The contents on the permanent log is retained over a reboot. A device can only have one instance of the permanent log. The permanent log is enabled by default and has a filter to include messages with a severity level of 'warning' and above. The permanent log can be disabled using the command:

`no log permanent`

Additional filters can be added and removed using the commands described in [log permanent \(filter\)](#):

`log permanent {facility|level|msgtext|program}`

`no log permanent {facility|level|msgtext|program}`

Table 9-1: Permanent log commands

Command	Description
show log permanent	Display the entire contents of the permanent log
<code>show log permanent tail</code>	Display the 10 most recent entries in the permanent log
<code>show log permanent tail <10-250></code>	Display a specified number of the most recent entries in the permanent log
show log config	Display the configuration of all log outputs
log permanent size	Specify the amount of memory the permanent log may use
clear log	Remove the contents of the buffered log and permanent log

Table 9-1: Permanent log commands (Continued)

Command	Description
<code>clear log permanent</code>	Remove the contents of the permanent log only
<code>default log permanent</code>	Restore the permanent log to its default configuration

Host log A host log sends log messages to a remote syslog server. A device may have many syslog hosts configured. To configure or remove a host use the commands:

```
log host <ip-addr>
```

```
no log host <ip-addr>
```

where `<ip-addr>` is the IP address of the remote syslog server.

There are no default filters associated with host outputs when they are created. Filters can be added and removed with the [log host \(filter\) command on page 10.29](#).

It is not possible to view the log messages sent to this type of output as they are not retained on the device. They must be viewed on the remote device. The other host log commands are:

<code>show log config</code>	Displays the configuration of all log outputs
<code>log host time</code>	Adjust the time information in messages to a time zone other than the one configured on this device
<code>default log host <ip-address></code>	Restores the device default settings for log sent to a remote syslog server.

Email log An email log sends log messages to an email address. A device may have many email logs configured. To configure or remove an email log use the commands:

```
log email <email-address>
```

```
no log email <email-address>
```

where `<email-address>` is the destination email address.

There are no default filters associated with email outputs when they are created. Filters can be added and removed with the commands described in [log email \(filter\)](#):

```
log email <email-address> {facility|level|msgtext|program}
```

```
no log email <email-address> {facility|level|msgtext|program}
```

It is not possible to view the log messages sent to this type of output as they are not retained on the device. They must be viewed by the email recipient.

The other email log commands are:

<code>show log config</code>	Displays the configuration of all log outputs
<code>log email time</code>	Adjust the time information in messages to a time zone other than the one configured on this device
<code>default log email</code>	Restores the device default settings for log messages sent to an email address.

Note: An email server and “from” address must be configured on the device in order for email logs to work:

```
mail from <email-address>
```

```
mail smtpserver <ip-address>
```

where the *<email-address>* is the 'From:' field on the sent email, and the *<ip-address>* is the email's destination SMTP server.

Email logs are sent in batches of approximately 20 messages and have the subject line "Log messages"

Chapter 10: Logging Commands



Command List	10.2
clear exception log	10.2
clear log	10.3
clear log buffered	10.4
clear log permanent	10.5
default log buffered	10.6
default log console	10.7
default log email	10.8
default log host	10.9
default log monitor	10.10
default log permanent	10.11
exception core dump size	10.12
log buffered	10.13
log buffered (filter)	10.14
log buffered size	10.17
log console	10.18
log console (filter)	10.19
log email	10.22
log email (filter)	10.23
log email time	10.26
log host	10.28
log host (filter)	10.29
log host time	10.32
log monitor (filter)	10.34
log permanent	10.37
log permanent (filter)	10.38
log permanent size	10.41
show exception log	10.42
show log	10.43
show log config	10.45
show log permanent	10.48
show running-config log	10.50

Command List

This chapter provides an alphabetical reference of commands used to configure logging.

clear exception log

This command resets the contents of the exception log, but does not remove the associated core files.

Note: When this command is used within a virtual chassis stack (VCS), it will remove the contents of the exception logs in all stack members.

Syntax `clear exception log`

Parameter	Description
clear	Reset functions
exception	Clear exception information
log	Clear the exception log

Mode Privileged Exec

Example

```
awplus# clear exception log
```

clear log

This command removes the contents of the buffered and permanent logs.

Note: When this command is used within a virtual chassis stack (VCS), it will remove the contents of the buffered and permanent logs in all stack members.

Syntax clear log

Parameter	Description
clear	Remove dynamic information
log	The contents of the logs

Mode Privileged Exec

Examples To delete the contents of the buffered and permanent log use the command:

```
awplus# clear log
```

**Validation
Commands** show log

Related Commands clear log buffered
clear log permanent

clear log buffered

This command removes the contents of the buffered log.

Note: When this command is used within a virtual chassis stack (VCS), it will remove the contents of the buffered logs in all stack members.

Syntax `clear log buffered`

Parameter	Description
<code>clear</code>	Remove dynamic information
<code>log</code>	The contents of the logs
<code>buffered</code>	The RAM buffered log

Mode Privileged Exec

Examples To delete the contents of the buffered log use the following commands:

```
awplus# configure terminal
```

```
awplus(config)# clear log buffered
```

**Validation
Commands** `show log`

Related Commands `clear log`
`clear log permanent`

clear log permanent

This command removes the contents of the permanent log.

Note: When this command is used within a virtual chassis stack (VCS), it will remove the contents of the permanent logs in all stack members.

Syntax clear log permanent

Parameter	Description
clear	Remove dynamic information
log	The contents of the logs
permanent	The permanent NVS log

Mode Privileged Exec

Examples To delete the contents of the permanent log use the following commands:

```
awplus# configure terminal
```

```
awplus(config)# clear log permanent
```

**Validation
Commands** show log

Related Commands clear log
clear log buffered

default log buffered

This command restores the default settings for the buffered log stored in RAM. By default the size of the buffered log is 50 kB and it accepts messages with the severity level of "warnings" and above.

Syntax `default log buffered`

Parameter	Description
default	Restore default settings
log	Logging control
buffered	Store log messages in a RAM buffer

Mode Global Configuration

Default The buffered log is enabled by default.

Examples To restore the buffered log to its default settings use the following commands:

```
awplus# configure terminal
```

```
awplus(config)# default log buffered
```

**Validation
Commands** `show log config`

Related Commands `log buffered`
`log buffered size`

default log console

This command restores the default settings for log messages sent to the terminal when a [log console](#) command is issued. By default all messages are sent to the console when a log console command is issued.

Syntax `default log console`

Parameter	Description
default	Restore default settings
log	Logging control
console	Store log messages in a RAM buffer

Mode Global Configuration

Examples To restore the log console to its default settings use the following commands:

```
awplus# configure terminal
```

```
awplus(config)# default log console
```

**Validation
Commands** `show log config`

Related Commands [log console](#)
[log console \(filter\)](#)

default log email

This command restores the default settings for log messages sent to an email address. By default no filters are defined for email addresses. Filters must be defined before messages will be sent. This command also restores the remote syslog server time offset value to local (no offset).

Syntax `default log email <email-address>`

Parameter	Description
default	Restore default settings
log	Logging control
email	Send log messages to an email address
<email-address>	The email address to send log messages to

Mode Global Configuration

Examples To restore the default settings for log messages sent to the email address `admin@alliedtelesis.com` use the following commands:

```
awplus# configure terminal
awplus(config)# default log email admin@alliedtelesis.com
```

Related Commands [show log config](#)

default log host

This command restores the default settings for log sent to a remote syslog server. By default no filters are defined for remote syslog servers. Filters must be defined before messages will be sent. This command also restores the remote syslog server time offset value to local (no offset).

Syntax `default log host <ip-addr>`

Parameter	Description
default	Restore default settings
log	Logging control
host	Send log messages to a remote syslog server
<ip-addr>	The IP address of a remote syslog server

Mode Global Configuration

Examples To restore the default settings for messages sent to the remote syslog server with IP address 10.32.16.21 use the following commands:

```
awplus# configure terminal
awplus(config)# default log host 10.32.16.21
```

Validation Commands `show log config`

Related Commands `log email`

default log monitor

This command restores the default settings for log messages sent to the terminal when a [terminal monitor](#) command is used.

Syntax `default log monitor`

Parameter	Description
default	Restore default settings
log	Logging control
monitor	Store log messages permanently in NVS

Mode Global Configuration

Default All messages are sent to the terminal when a [terminal monitor](#) command is used.

Examples To restore the log monitor to its default settings use the following commands:

```
awplus# configure terminal
awplus(config)# default log monitor
```

Related Commands [log monitor \(filter\)](#)
[show log config](#)

default log permanent

This command restores the default settings for the permanent log stored in NVS. By default, the size of the permanent log is 50 kB and it accepts messages with the severity level of warnings and above.

Syntax `default log permanent`

Parameter	Description
default	Restore default settings
log	Logging control
permanent	Store log messages permanently in NVS

Mode Global Configuration

Default The permanent log is enabled by default.

Examples To restore the permanent log to its default settings use the following commands:

```
awplus# configure terminal
```

```
awplus(config)# default log permanent
```

Related Commands `log permanent`
`log permanent size`
`show log config`

exception coredump size

This command sets the size of core files, and can also be used to stop core files being created.

Use the no version of this command to restore the core file size to its default (unlimited).

This setting only applies to processes created after this command has been executed, to ensure this is applied to all processes the system will need to be restarted.

Syntax `exception coredump size {none|small|medium|large|unlimited}`
`no exception coredump size`

Parameter	Description
exception	Configure exception settings
coredump	Configure coredump attributes
size	Configure the size of coredump files
no	Negate a command or set its defaults
none	Don't create corefiles
small	Create small corefiles
medium	Create medium corefiles
large	Create large corefiles (default)
unlimited	Create corefiles as large as necessary

Mode Global Configuration

Default Unlimited

Usage Core files are generated when a process crashes. The size of a core file can vary, its upper limit is controlled by this command. Files larger than this limit will be truncated by reducing the amount of stack and variable information stored.

Truncated core files may make debugging the failure difficult if not impossible. Reducing the amount of data stored in a core file is not recommended, however the facility is provided to reduce the amount of flash used.

Examples To restrict the size of the core file created, use the command:

```
awplus# configure terminal
awplus(config)# exception coredump size small
```

To restore the size of the core files created to the default of `unlimited`, use the command:

```
awplus# configure terminal
awplus(config)# no exception coredump size
```

log buffered

This command configures the device to store log messages in RAM. Messages stored in RAM are not retained on the device over a restart. Once the buffered log reaches its configured maximum allowable size old messages will be deleted to make way for new ones.

Syntax `log buffered`
`no log buffered`

Parameter	Description
no	Configures the device to not store log messages in a RAM buffer
log	Logging control
buffered	Store log messages in a RAM buffer

Mode Global Configuration

Default The buffered log is configured by default.

Examples To configured the device to store log messages in RAM use the following commands:

```
awplus# configure terminal
awplus(config)# log buffered
```

To configure the device to not store log messages in a RAM buffer use the following commands:

```
awplus# configure terminal
awplus(config)# no log buffered
```

**Validation
Commands** `show log config`

Related Commands `default log buffered`
`log buffered (filter)`
`log buffered size`

log buffered (filter)

Use this command to create a filter to select messages to be sent to the buffered log. Selection can be based on the priority/ severity of the message, the program that generated the message, the logging facility used, a sub-string within the message or a combination of some or all of these.

The **no** version of the command removes the corresponding filter, so that the specified messages are no longer sent to the buffered log.

Syntax

```
log buffered
[level <level>]
[program <program-name>]
[facility <facility>]
[msgtext <text-string>]

no log buffered
[level <level>]
[program <program-name>]
[facility <facility>]
[msgtext <text-string>]
```

Parameter	Description																
log	Logging control																
buffered	Store log messages in a RAM buffer																
no	Deletes the specified filter, so that corresponding messages are no longer sent to the buffered log.																
level	Filter messages to the buffered log by severity level.																
<level>	The minimum severity of message to send to the buffered log. The level can be specified as one of the following numbers or level names, where 0 is the highest severity and 7 is the lowest severity: <table> <tr> <td>0 emergencies:</td><td>System is unusable</td></tr> <tr> <td>1 alerts</td><td>Action must be taken immediately</td></tr> <tr> <td>2 critical</td><td>Critical conditions</td></tr> <tr> <td>3 errors</td><td>Error conditions</td></tr> <tr> <td>4 warnings</td><td>Warning conditions</td></tr> <tr> <td>5 notices</td><td>Normal, but significant, conditions</td></tr> <tr> <td>6 informational</td><td>Informational messages</td></tr> <tr> <td>7 debugging</td><td>Debug-level messages</td></tr> </table>	0 emergencies:	System is unusable	1 alerts	Action must be taken immediately	2 critical	Critical conditions	3 errors	Error conditions	4 warnings	Warning conditions	5 notices	Normal, but significant, conditions	6 informational	Informational messages	7 debugging	Debug-level messages
0 emergencies:	System is unusable																
1 alerts	Action must be taken immediately																
2 critical	Critical conditions																
3 errors	Error conditions																
4 warnings	Warning conditions																
5 notices	Normal, but significant, conditions																
6 informational	Informational messages																
7 debugging	Debug-level messages																

Parameter(Continue	Description(Continued)																																				
<code>program</code>	Filter messages to the buffered log by program. Include messages from a specified program in the buffered log.																																				
<code><program-name></code>	The name of a program to log messages from, either one of the following predefined program names (not case-sensitive), or another program name (case -sensitive) that you find in the log output. <table> <tr><td><code>rip</code></td><td>Routing Information Protocol (RIP)</td></tr> <tr><td><code>ripng</code></td><td>Routing Information Protocol - next generation (RIPng)</td></tr> <tr><td><code>ospf</code></td><td>Open Shortest Path First (OSPF)</td></tr> <tr><td><code>ospfv3</code></td><td>Open Shortest Path First (OSPF) version 3 (OSPFv3)</td></tr> <tr><td><code>bgp</code></td><td>Border Gateway Protocol (BGP)</td></tr> <tr><td><code>rsvp</code></td><td>Resource Reservation Protocol (RSVP)</td></tr> <tr><td><code>pim-dm</code></td><td>Protocol Independent Multicast - Dense Mode (PIM-DM)</td></tr> <tr><td><code>pim-sm</code></td><td>Protocol Independent Multicast - Sparse Mode (PIM-SM)</td></tr> <tr><td><code>dot1x</code></td><td>IEEE 802.1X Port-Based Access Control</td></tr> <tr><td><code>lacp</code></td><td>Link Aggregation Control Protocol (LACP)</td></tr> <tr><td><code>stp</code></td><td>Spanning Tree Protocol (STP)</td></tr> <tr><td><code>rstp</code></td><td>Rapid Spanning Tree Protocol (RSTP)</td></tr> <tr><td><code>mstp</code></td><td>Multiple Spanning Tree Protocol (MSTP)</td></tr> <tr><td><code>imi</code></td><td>Integrated Management Interface (IMI)</td></tr> <tr><td><code>imish</code></td><td>Integrated Management Interface Shell (IMISH)</td></tr> <tr><td><code>epsr</code></td><td>Ethernet Protection Switched Rings (EPSR)</td></tr> <tr><td><code>irdp</code></td><td>ICMP Router Discovery Protocol (IRDP)</td></tr> <tr><td><code>rmon</code></td><td>Remote Monitoring</td></tr> </table>	<code>rip</code>	Routing Information Protocol (RIP)	<code>ripng</code>	Routing Information Protocol - next generation (RIPng)	<code>ospf</code>	Open Shortest Path First (OSPF)	<code>ospfv3</code>	Open Shortest Path First (OSPF) version 3 (OSPFv3)	<code>bgp</code>	Border Gateway Protocol (BGP)	<code>rsvp</code>	Resource Reservation Protocol (RSVP)	<code>pim-dm</code>	Protocol Independent Multicast - Dense Mode (PIM-DM)	<code>pim-sm</code>	Protocol Independent Multicast - Sparse Mode (PIM-SM)	<code>dot1x</code>	IEEE 802.1X Port-Based Access Control	<code>lacp</code>	Link Aggregation Control Protocol (LACP)	<code>stp</code>	Spanning Tree Protocol (STP)	<code>rstp</code>	Rapid Spanning Tree Protocol (RSTP)	<code>mstp</code>	Multiple Spanning Tree Protocol (MSTP)	<code>imi</code>	Integrated Management Interface (IMI)	<code>imish</code>	Integrated Management Interface Shell (IMISH)	<code>epsr</code>	Ethernet Protection Switched Rings (EPSR)	<code>irdp</code>	ICMP Router Discovery Protocol (IRDP)	<code>rmon</code>	Remote Monitoring
<code>rip</code>	Routing Information Protocol (RIP)																																				
<code>ripng</code>	Routing Information Protocol - next generation (RIPng)																																				
<code>ospf</code>	Open Shortest Path First (OSPF)																																				
<code>ospfv3</code>	Open Shortest Path First (OSPF) version 3 (OSPFv3)																																				
<code>bgp</code>	Border Gateway Protocol (BGP)																																				
<code>rsvp</code>	Resource Reservation Protocol (RSVP)																																				
<code>pim-dm</code>	Protocol Independent Multicast - Dense Mode (PIM-DM)																																				
<code>pim-sm</code>	Protocol Independent Multicast - Sparse Mode (PIM-SM)																																				
<code>dot1x</code>	IEEE 802.1X Port-Based Access Control																																				
<code>lacp</code>	Link Aggregation Control Protocol (LACP)																																				
<code>stp</code>	Spanning Tree Protocol (STP)																																				
<code>rstp</code>	Rapid Spanning Tree Protocol (RSTP)																																				
<code>mstp</code>	Multiple Spanning Tree Protocol (MSTP)																																				
<code>imi</code>	Integrated Management Interface (IMI)																																				
<code>imish</code>	Integrated Management Interface Shell (IMISH)																																				
<code>epsr</code>	Ethernet Protection Switched Rings (EPSR)																																				
<code>irdp</code>	ICMP Router Discovery Protocol (IRDP)																																				
<code>rmon</code>	Remote Monitoring																																				
<code>facility</code>	Filter messages to the buffered log by syslog facility.																																				
<code><facility></code>	Specify one of the following syslog facilities to include messages from in the buffered log: <table> <tr><td><code>kern</code></td><td>Kernel messages</td></tr> <tr><td><code>user</code></td><td>Random user-level messages</td></tr> <tr><td><code>mail</code></td><td>Mail system</td></tr> <tr><td><code>daemon</code></td><td>System daemons</td></tr> <tr><td><code>auth</code></td><td>Security/authorization messages</td></tr> <tr><td><code>syslog</code></td><td>Messages generated internally by syslogd</td></tr> <tr><td><code>lpr</code></td><td>Line printer subsystem</td></tr> <tr><td><code>news</code></td><td>Network news subsystem</td></tr> <tr><td><code>uucp</code></td><td>UUCP subsystem</td></tr> <tr><td><code>cron</code></td><td>Clock daemon</td></tr> <tr><td><code>authpriv</code></td><td>Security/authorization messages (private)</td></tr> <tr><td><code>ftp</code></td><td>FTP daemon</td></tr> </table>	<code>kern</code>	Kernel messages	<code>user</code>	Random user-level messages	<code>mail</code>	Mail system	<code>daemon</code>	System daemons	<code>auth</code>	Security/authorization messages	<code>syslog</code>	Messages generated internally by syslogd	<code>lpr</code>	Line printer subsystem	<code>news</code>	Network news subsystem	<code>uucp</code>	UUCP subsystem	<code>cron</code>	Clock daemon	<code>authpriv</code>	Security/authorization messages (private)	<code>ftp</code>	FTP daemon												
<code>kern</code>	Kernel messages																																				
<code>user</code>	Random user-level messages																																				
<code>mail</code>	Mail system																																				
<code>daemon</code>	System daemons																																				
<code>auth</code>	Security/authorization messages																																				
<code>syslog</code>	Messages generated internally by syslogd																																				
<code>lpr</code>	Line printer subsystem																																				
<code>news</code>	Network news subsystem																																				
<code>uucp</code>	UUCP subsystem																																				
<code>cron</code>	Clock daemon																																				
<code>authpriv</code>	Security/authorization messages (private)																																				
<code>ftp</code>	FTP daemon																																				
<code>msgtext</code>	Select messages containing a certain text string (maximum 128 characters).																																				
<code><text-string></code>	A text string to match (maximum 128 characters). This is case sensitive, and must be the last text on the command line.																																				

Mode Global Configuration

Default By default the buffered log has a filter to select messages whose severity level is "notices (5)" or higher. This filter may be removed using the **no** form of this command.

Examples To add a filter to send all messages generated by BGP that have a severity of notices or higher to the buffered log use the following commands:

```
awplus# configure terminal
```

```
awplus(config)# log buffered level notices program bgp
```

To add a filter to send all messages containing the text "Bridging initialization", to the buffered log use the following commands:

```
awplus# configure terminal
```

```
awplus(config)# log buffered msgtext Bridging initialization
```

To remove a filter that sends all messages generated by BGP that have a severity of notices or higher to the buffered log use the following commands:

```
awplus# configure terminal
```

```
awplus(config)# no log buffered level notices program bgp
```

To remove a filter that sends all messages containing the text "Bridging initialization", to the buffered log use the following commands:

```
awplus# configure terminal
```

```
awplus(config)# no log buffered msgtext Bridging initialization
```

**Validation
Commands** show log config

Related Commands default log buffered
log buffered
log buffered size

log buffered size

This command configures the amount of memory that the buffered log is permitted to use. Once this memory allocation has been filled old messages will be deleted to make room for new messages.

Syntax `log buffered size <50-250>`

Parameter	Description
log	Logging control
buffered	Store log messages in a RAM buffer
size	Set the maximum size of the RAM log
<50-250>	Size of the RAM log in kilobytes

Mode Global Configuration

Examples To allow the buffered log to use up to 100 kB of RAM use the following commands:

```
awplus# configure terminal
```

```
awplus(config)# log buffered size 100
```

**Validation
Commands** `show log config`

Related Commands `default log buffered`
`log buffered`

log console

This command Configures the device to send log messages to consoles. The console log is configured by default to send messages to the devices main console port.

Use the **no** version of this command to configure the device not to send log messages to consoles.

Syntax log console
 no log console

Parameter	Description
log	Logging control
console	Copy debug output to all consoles

Mode Global Configuration

Examples To configure the device to send log messages use the following commands:

```
awplus# configure terminal
awplus(config)# log console
```

To configure the device not to send log messages in all consoles use the following commands:

```
awplus# configure terminal
awplus(config)# no log console
```

**Validation
Commands** show log config

Related Commands log console (filter)

log console (filter)

This command creates a filter to select messages to be sent to all consoles when the log console command is given. Selection can be based on the priority/severity of the message, the program that generated the message, the logging facility used, a sub-string within the message or a combination of some or all of these.

Syntax

```
log console
    [level <level>]
    [program <program-name>]
    [facility <facility>]
    [msgtext <text-string>]

no log console
    [level <level>]
    [program <program-name>]
    [facility <facility>]
    [msgtext <text-string>]
```

Parameter	Description																
log	Logging control																
console	Set console logging parameters																
no	Deletes the specified filter, so that corresponding messages are no longer sent to the console.																
level	Filter messages by severity level.																
<level>	The minimum severity of message to send. The level can be specified as one of the following numbers or level names, where 0 is the highest severity and 7 is the lowest severity: <table> <tr> <td>0 emergencies:</td> <td>System is unusable</td> </tr> <tr> <td>1 alerts</td> <td>Action must be taken immediately</td> </tr> <tr> <td>2 critical</td> <td>Critical conditions</td> </tr> <tr> <td>3 errors</td> <td>Error conditions</td> </tr> <tr> <td>4 warnings</td> <td>Warning conditions</td> </tr> <tr> <td>5 notices</td> <td>Normal, but significant, conditions</td> </tr> <tr> <td>6 informational</td> <td>Informational messages</td> </tr> <tr> <td>7 debugging</td> <td>Debug-level messages</td> </tr> </table>	0 emergencies:	System is unusable	1 alerts	Action must be taken immediately	2 critical	Critical conditions	3 errors	Error conditions	4 warnings	Warning conditions	5 notices	Normal, but significant, conditions	6 informational	Informational messages	7 debugging	Debug-level messages
0 emergencies:	System is unusable																
1 alerts	Action must be taken immediately																
2 critical	Critical conditions																
3 errors	Error conditions																
4 warnings	Warning conditions																
5 notices	Normal, but significant, conditions																
6 informational	Informational messages																
7 debugging	Debug-level messages																

Parameter(Cont	Description(Continued)
<code>program</code>	Filter messages by program. Include messages from a specified program.
<code><program-name></code>	The name of a program to log messages from, either one of the following predefined program names (not case-sensitive), or another program name (case -sensitive) that you find in the log output.
<code>rip</code>	Routing Information Protocol (RIP)
<code>ripng</code>	Routing Information Protocol - next generation (RIPng)
<code>ospf</code>	Open Shortest Path First (OSPF)
<code>ospfv3</code>	Open Shortest Path First (OSPF) version 3 (OSPFv3)
<code>bgp</code>	Border Gateway Protocol (BGP)
<code>rsvp</code>	Resource Reservation Protocol (RSVP)
<code>pim-dm</code>	Protocol Independent Multicast - Dense Mode (PIM-DM)
<code>pim-sm</code>	Protocol Independent Multicast - Sparse Mode (PIM-SM)
<code>dot1x</code>	IEEE 802.1X Port-Based Access Control
<code>lACP</code>	Link Aggregation Control Protocol (LACP)
<code>stp</code>	Spanning Tree Protocol (STP)
<code>rstp</code>	Rapid Spanning Tree Protocol (RSTP)
<code>mstp</code>	Multiple Spanning Tree Protocol (MSTP)
<code>imi</code>	Integrated Management Interface (IMI)
<code>imish</code>	Integrated Management Interface Shell (IMISH)
<code>epsr</code>	Ethernet Protection Switched Rings (EPSR)
<code>irdp</code>	ICMP Router Discovery Protocol (IRDP)
<code>rmon</code>	Remote Monitoring
<code>facility</code>	Filter messages to the buffered log by syslog facility.
<code><facility></code>	Specify one of the following syslog facilities to include messages from:
<code>kern</code>	Kernel messages
<code>user</code>	Random user-level messages
<code>mail</code>	Mail system
<code>daemon</code>	System daemons
<code>auth</code>	Security/authorization messages
<code>syslog</code>	Messages generated internally by syslogd
<code>lpr</code>	Line printer subsystem
<code>news</code>	Network news subsystem
<code>uucp</code>	UUCP subsystem
<code>cron</code>	Clock daemon
<code>authpriv</code>	Security/authorization messages (private)
<code>ftp</code>	FTP daemon
<code>msgtext</code>	Select messages containing a certain text string
<code><text-string></code>	A text string to match. This is case sensitive, and must be the last text on the command line.

Mode Global Configuration

Default By default the buffered log has a filter to select messages whose severity level is `critical` or higher. This filter may be removed using the `no` form of this command. This filter may be removed and replaced by filters that are more selective.

Example To create a filter to send all messages generated by MSTP that have a severity of `info` or higher to console instances where the `log console` command has been given, remove the default filter that includes everything use the following commands:

```
awplus# configure terminal
awplus(config)# log console level info program mstp
```

and then use the command:

```
awplus(config)# log console level info program mstp
```

To create a filter to send all messages containing the text "Bridging initialization" to console instances where the `log console` command has been given use the following commands:

```
awplus# configure terminal
awplus(config)# log console msgtext "Bridging initialization"
```

To remove a filter that sends all messages generated by BGP that have a severity of `notices` or higher to consoles use the following commands:

```
awplus# configure terminal
awplus(config)# no log console level notices program bgp
```

To remove a default filter that includes sending `critical`, `alert` and `emergency` level messages to the console use the following commands:

```
awplus# configure terminal
awplus(config)# no log console level critical
```

**Validation
Commands** `show log config`

Related Commands `log console`

log email

This command configures the device to send log messages to an email address. The email address is specified in this command.

Syntax `log email <email-address>`

Parameter	Description
log	Logging control
email	Send log messages to an email address
<email-address>	The email address to send log messages to

Mode Global Configuration

Default By default no filters are defined for email log targets. Filters must be defined before messages will be sent.

Examples To have log messages emailed to the email address `admin@alliedtelesis.com` use the following commands:

```
awplus# configure terminal
```

```
awplus(config)# log email admin@alliedtelesis.com
```

**Validation
Commands** `show log config`

Related Commands `default log email`
`log email`

log email (filter)

This command creates a filter to select messages to be sent to an email address. Selection can be based on the priority/ severity of the message, the program that generated the message, the logging facility used, a sub-string within the message or a combination of some or all of these.

The `no log email` command configures the device to no longer send log messages to a specified email address. All configuration relating to this log target will be removed.

Syntax

```
log email <email-address>
    [level <level>]
    [program <program-name>]
    [facility <facility>]
    [msgtext <text-string>]

no log email <email-address>
    [level <level>]
    [program <program-name>]
    [facility <facility>]
    [msgtext <text-string>]
```

Parameter	Description																
log	Logging control																
email	Set email logging parameters																
<email-address>	The email address to send logging messages to																
no	Deletes the specified filter, so that corresponding messages are no longer sent to the specified email address.																
level	Filter messages by severity level.																
<level>	The minimum severity of messages to send. The level can be specified as one of the following numbers or level names, where 0 is the highest severity and 7 is the lowest severity: <table> <tr> <td>0 emergencies:</td><td>System is unusable</td></tr> <tr> <td>1 alerts</td><td>Action must be taken immediately</td></tr> <tr> <td>2 critical</td><td>Critical conditions</td></tr> <tr> <td>3 errors</td><td>Error conditions</td></tr> <tr> <td>4 warnings</td><td>Warning conditions</td></tr> <tr> <td>5 notices</td><td>Normal, but significant, conditions</td></tr> <tr> <td>6 informational</td><td>Informational messages</td></tr> <tr> <td>7 debugging</td><td>Debug-level messages</td></tr> </table>	0 emergencies:	System is unusable	1 alerts	Action must be taken immediately	2 critical	Critical conditions	3 errors	Error conditions	4 warnings	Warning conditions	5 notices	Normal, but significant, conditions	6 informational	Informational messages	7 debugging	Debug-level messages
0 emergencies:	System is unusable																
1 alerts	Action must be taken immediately																
2 critical	Critical conditions																
3 errors	Error conditions																
4 warnings	Warning conditions																
5 notices	Normal, but significant, conditions																
6 informational	Informational messages																
7 debugging	Debug-level messages																

Parameter(Continu	Description(Continued)																																				
<code>program</code>	Filter messages by program. Include messages from a specified program in the log.																																				
<code><program-name></code>	The name of a program to log messages from, either one of the following predefined program names (not case-sensitive), or another program name (case -sensitive) that you find in the log output. <table> <tr><td><code>rip</code></td><td>Routing Information Protocol (RIP)</td></tr> <tr><td><code>ripng</code></td><td>Routing Information Protocol - next generation (RIPng)</td></tr> <tr><td><code>ospf</code></td><td>Open Shortest Path First (OSPF)</td></tr> <tr><td><code>ospfv3</code></td><td>Open Shortest Path First (OSPF) version 3 (OSPFv3)</td></tr> <tr><td><code>bgp</code></td><td>Border Gateway Protocol (BGP)</td></tr> <tr><td><code>rsvp</code></td><td>Resource Reservation Protocol (RSVP)</td></tr> <tr><td><code>pim-dm</code></td><td>Protocol Independent Multicast - Dense Mode (PIM-DM)</td></tr> <tr><td><code>pim-sm</code></td><td>Protocol Independent Multicast - Sparse Mode (PIM-SM)</td></tr> <tr><td><code>dot1x</code></td><td>IEEE 802.1X Port-Based Access Control</td></tr> <tr><td><code>lACP</code></td><td>Link Aggregation Control Protocol (LACP)</td></tr> <tr><td><code>stp</code></td><td>Spanning Tree Protocol (STP)</td></tr> <tr><td><code>rstp</code></td><td>Rapid Spanning Tree Protocol (RSTP)</td></tr> <tr><td><code>mstp</code></td><td>Multiple Spanning Tree Protocol (MSTP)</td></tr> <tr><td><code>imi</code></td><td>Integrated Management Interface (IMI)</td></tr> <tr><td><code>imish</code></td><td>Integrated Management Interface Shell (IMISH)</td></tr> <tr><td><code>epsr</code></td><td>Ethernet Protection Switched Rings (EPSR)</td></tr> <tr><td><code>irdp</code></td><td>ICMP Router Discovery Protocol (IRDP)</td></tr> <tr><td><code>rmon</code></td><td>Remote Monitoring</td></tr> </table>	<code>rip</code>	Routing Information Protocol (RIP)	<code>ripng</code>	Routing Information Protocol - next generation (RIPng)	<code>ospf</code>	Open Shortest Path First (OSPF)	<code>ospfv3</code>	Open Shortest Path First (OSPF) version 3 (OSPFv3)	<code>bgp</code>	Border Gateway Protocol (BGP)	<code>rsvp</code>	Resource Reservation Protocol (RSVP)	<code>pim-dm</code>	Protocol Independent Multicast - Dense Mode (PIM-DM)	<code>pim-sm</code>	Protocol Independent Multicast - Sparse Mode (PIM-SM)	<code>dot1x</code>	IEEE 802.1X Port-Based Access Control	<code>lACP</code>	Link Aggregation Control Protocol (LACP)	<code>stp</code>	Spanning Tree Protocol (STP)	<code>rstp</code>	Rapid Spanning Tree Protocol (RSTP)	<code>mstp</code>	Multiple Spanning Tree Protocol (MSTP)	<code>imi</code>	Integrated Management Interface (IMI)	<code>imish</code>	Integrated Management Interface Shell (IMISH)	<code>epsr</code>	Ethernet Protection Switched Rings (EPSR)	<code>irdp</code>	ICMP Router Discovery Protocol (IRDP)	<code>rmon</code>	Remote Monitoring
<code>rip</code>	Routing Information Protocol (RIP)																																				
<code>ripng</code>	Routing Information Protocol - next generation (RIPng)																																				
<code>ospf</code>	Open Shortest Path First (OSPF)																																				
<code>ospfv3</code>	Open Shortest Path First (OSPF) version 3 (OSPFv3)																																				
<code>bgp</code>	Border Gateway Protocol (BGP)																																				
<code>rsvp</code>	Resource Reservation Protocol (RSVP)																																				
<code>pim-dm</code>	Protocol Independent Multicast - Dense Mode (PIM-DM)																																				
<code>pim-sm</code>	Protocol Independent Multicast - Sparse Mode (PIM-SM)																																				
<code>dot1x</code>	IEEE 802.1X Port-Based Access Control																																				
<code>lACP</code>	Link Aggregation Control Protocol (LACP)																																				
<code>stp</code>	Spanning Tree Protocol (STP)																																				
<code>rstp</code>	Rapid Spanning Tree Protocol (RSTP)																																				
<code>mstp</code>	Multiple Spanning Tree Protocol (MSTP)																																				
<code>imi</code>	Integrated Management Interface (IMI)																																				
<code>imish</code>	Integrated Management Interface Shell (IMISH)																																				
<code>epsr</code>	Ethernet Protection Switched Rings (EPSR)																																				
<code>irdp</code>	ICMP Router Discovery Protocol (IRDP)																																				
<code>rmon</code>	Remote Monitoring																																				
<code>facility</code>	Filter messages to the log by syslog facility.																																				
<code><facility></code>	Specify one of the following syslog facilities to include messages from in the log: <table> <tr><td><code>kern</code></td><td>Kernel messages</td></tr> <tr><td><code>user</code></td><td>Random user-level messages</td></tr> <tr><td><code>mail</code></td><td>Mail system</td></tr> <tr><td><code>daemon</code></td><td>System daemons</td></tr> <tr><td><code>auth</code></td><td>Security/authorization messages</td></tr> <tr><td><code>syslog</code></td><td>Messages generated internally by syslogd</td></tr> <tr><td><code>lpr</code></td><td>Line printer subsystem</td></tr> <tr><td><code>news</code></td><td>Network news subsystem</td></tr> <tr><td><code>uucp</code></td><td>UUCP subsystem</td></tr> <tr><td><code>cron</code></td><td>Clock daemon</td></tr> <tr><td><code>authpriv</code></td><td>Security/authorization messages (private)</td></tr> <tr><td><code>ftp</code></td><td>FTP daemon</td></tr> </table>	<code>kern</code>	Kernel messages	<code>user</code>	Random user-level messages	<code>mail</code>	Mail system	<code>daemon</code>	System daemons	<code>auth</code>	Security/authorization messages	<code>syslog</code>	Messages generated internally by syslogd	<code>lpr</code>	Line printer subsystem	<code>news</code>	Network news subsystem	<code>uucp</code>	UUCP subsystem	<code>cron</code>	Clock daemon	<code>authpriv</code>	Security/authorization messages (private)	<code>ftp</code>	FTP daemon												
<code>kern</code>	Kernel messages																																				
<code>user</code>	Random user-level messages																																				
<code>mail</code>	Mail system																																				
<code>daemon</code>	System daemons																																				
<code>auth</code>	Security/authorization messages																																				
<code>syslog</code>	Messages generated internally by syslogd																																				
<code>lpr</code>	Line printer subsystem																																				
<code>news</code>	Network news subsystem																																				
<code>uucp</code>	UUCP subsystem																																				
<code>cron</code>	Clock daemon																																				
<code>authpriv</code>	Security/authorization messages (private)																																				
<code>ftp</code>	FTP daemon																																				
<code>msgtext</code>	Select messages containing a certain text string																																				
<code><text-string></code>	A text string to match. This is case sensitive, and must be the last text on the command line.																																				

Mode Global Configuration

Examples To create a filter to send all messages generated by BGP that have a severity of `notices` or higher to the email address `admin@homebase.com` use the following commands:

```
awplus# configure terminal
awplus(config)# log email admin@homebase.com level notices
program bgp
```

To create a filter to send all messages containing the text "Bridging initialization", to the email address `admin@homebase.com` use the following commands:

```
awplus# configure terminal
awplus(config)# log email admin@homebase.com msgtext
"Bridging initialization"
```

To create a filter to send messages with a severity level of `informational` and above to the email address `admin@alliedtelesis.com` use the following commands:

```
awplus# configure terminal
awplus(config)# log email admin@alliedtelesis.com level
informational
```

To stop the device emailing log messages emailed to the email address `admin@alliedtelesis.com` use the following commands:

```
awplus# configure terminal
awplus(config)# no log email admin@homebase.com
```

To remove a filter that sends all messages generated by BGP that have a severity of `notices` or higher to the email address `admin@homebase.com` use the following commands:

```
awplus# configure terminal
awplus(config)# no log email admin@homebase.com level
notices program bgp
```

To remove a filter that sends messages with a severity level of `informational` and above to the email address `admin@alliedtelesis.com` use the following commands:

```
awplus# configure terminal
awplus(config)# no log email admin@alliedtelesis.com level
informational
```

Related Commands [default log email](#)
[log email](#)
[show log config](#)

log email time

This command configures the time used in messages sent to an email address. If the syslog server is in a different time zone to your switch then the time offset can be configured using either the `utc-offset` parameter option keyword or the `local-offset` parameter option keyword, where `utc-offset` is the time difference from UTC (Universal Time, Coordinated) and `local-offset` is the difference from local time.

Syntax `log email <email-address> time {local|local-offset|utc-offset
{plus|minus}<0-24>}`

Parameter	Description
<code>log</code>	Logging control
<code>email</code>	Send log messages to an email address
<code><email-address></code>	The email address to send log messages to
<code>time</code>	Specify the time difference between the email recipient and the switch you are configuring.
<code>local</code>	The switch is in the same time zone as the email recipient
<code>local-offset</code>	The switch is in a different time zone to the email recipient. Use the plus or minus keywords and specify the difference (offset) from local time of the switch to the email recipient in hours.
<code>utc-offset</code>	The switch is in a different time zone to the email recipient. Use the plus or minus keywords and specify the difference (offset) from UTC time of the switch to the email recipient in hours.
<code>plus</code>	Negative offset (difference) from the switch to the email recipient.
<code>minus</code>	Positive offset (difference) from the switch to the email recipient.
<code><0-24></code>	World Time zone offset in hours

Mode Global Configuration

Default The default is local time.

Usage Use the `local` option if the email recipient is in the same time zone as this device. Messages will display the time as on the local device when the message was generated.

Use the `offset` option if the email recipient is in a different time zone to this device. Specify the time offset of the email recipient in hours. Messages will display the time they were generated on this device but converted to the time zone of the email recipient.

Examples To send messages to the email address `test@home.com` in the same time zone as the switch's local time zone, use the following commands:

```
awplus# configure terminal
awplus(config)# log email admin@base.com time local 0
```


To send messages to the email address `admin@base.com` with the time information converted to the time zone of the email recipient, which is 3 hours ahead of the switch's local time zone, use the following commands:

```
awplus# configure terminal
awplus(config)# log email admin@base.com time local-offset
plus 3
```

To send messages to the email address `user@remote.com` with the time information converted to the time zone of the email recipient, which is 3 hours behind the switch's UTC time zone, use the following commands:

```
awplus# configure terminal
awplus(config)# log email user@remote.com time utc-offset
minus 3
```

**Validation
Commands** `show log config`

Related Commands `default log buffered`

log host

This command configures the device to send log messages to a remote syslog server via UDP port 514. The IP address of the remote server must be specified. By default no filters are defined for remote syslog servers. Filters must be defined before messages will be sent.

Syntax `log host <ip-addr>`
`no log host <ip-addr>`

Parameter	Description
log	Logging control
host	Send log messages to a remote syslog server
<ip-addr>	The IP address of a remote syslog server

Mode Global Configuration

Examples To configure the device to send log messages to a remote syslog server with IP address 10.32.16.99 use the following commands:

```
awplus# configure terminal
awplus(config)# log host 10.32.16.99
```

To stop the device from sending log messages to the remote syslog server with IP address 10.32.16.99 use the following commands:

```
awplus# configure terminal
awplus(config)# no log host 10.32.16.99
```

**Validation
Commands** `show log config`

Related Commands `default log host`

log host (filter)

This command creates a filter to select messages to be sent to a remote syslog server. Selection can be based on the priority/severity of the message, the program that generated the message, the logging facility used, a substring within the message or a combination of some or all of these.

The `no log host` command configures the device to no longer send log messages to a remote syslog server. The IP address of the syslog server must be specified. All configuration relating to this log target will be removed.

Syntax

```
log host <ip-addr>
    [level <level>]
    [program <program-name>]
    [facility <facility>]
    [msgtext <text-string>]

no log host <ip-addr>
    [level <level>]
    [program <program-name>]
    [facility <facility>]
    [msgtext <text-string>]
```

Parameter	Description																
log	Logging control																
host	Send log messages to a remote syslog server																
<ip-addr>	The IP address of a remote syslog server																
no	Deletes the specified filter, so that corresponding messages are no longer sent to the specified email address.																
level	Filter messages by severity level.																
<level>	The minimum severity of messages to send. The level can be specified as one of the following numbers or level names, where 0 is the highest severity and 7 is the lowest severity: <table> <tr> <td>0 emergencies:</td><td>System is unusable</td></tr> <tr> <td>1 alerts</td><td>Action must be taken immediately</td></tr> <tr> <td>2 critical</td><td>Critical conditions</td></tr> <tr> <td>3 errors</td><td>Error conditions</td></tr> <tr> <td>4 warnings</td><td>Warning conditions</td></tr> <tr> <td>5 notices</td><td>Normal, but significant, conditions</td></tr> <tr> <td>6 informational</td><td>Informational messages</td></tr> <tr> <td>7 debugging</td><td>Debug-level messages</td></tr> </table>	0 emergencies:	System is unusable	1 alerts	Action must be taken immediately	2 critical	Critical conditions	3 errors	Error conditions	4 warnings	Warning conditions	5 notices	Normal, but significant, conditions	6 informational	Informational messages	7 debugging	Debug-level messages
0 emergencies:	System is unusable																
1 alerts	Action must be taken immediately																
2 critical	Critical conditions																
3 errors	Error conditions																
4 warnings	Warning conditions																
5 notices	Normal, but significant, conditions																
6 informational	Informational messages																
7 debugging	Debug-level messages																

Parameter(Conti	Description(Continued)
<code>program</code>	Filter messages by program. Include messages from a specified program in the log.
<code><program-name></code>	The name of a program to log messages from, either one of the following predefined program names (not case-sensitive), or another program name (case -sensitive) that you find in the log output. <code>rip</code> Routing Information Protocol (RIP) <code>ripng</code> Routing Information Protocol - next generation (RIPng) <code>ospf</code> Open Shortest Path First (OSPF) <code>ospfv3</code> Open Shortest Path First (OSPF) version 3 (OSPFv3) <code>bgp</code> Border Gateway Protocol (BGP) <code>rsvp</code> Resource Reservation Protocol (RSVP) <code>pim-dm</code> Protocol Independent Multicast - Dense Mode (PIM-DM) <code>pim-sm</code> Protocol Independent Multicast - Sparse Mode (PIM-SM) <code>pim-smv6</code> Protocol Independent Multicast - Spare Mode version 6 (PIM-SMv6) <code>dot1x</code> IEEE 802.1X Port-Based Access Control <code>lacp</code> Link Aggregation Control Protocol (LACP) <code>stp</code> Spanning Tree Protocol (STP) <code>rstp</code> Rapid Spanning Tree Protocol (RSTP) <code>mstp</code> Multiple Spanning Tree Protocol (MSTP) <code>imi</code> Integrated Management Interface (IMI) <code>imish</code> Integrated Management Interface Shell (IMISH) <code>epsr</code> Ethernet Protection Switched Rings (EPSR) <code>irdp</code> ICMP Router Discovery Protocol (IRDP) <code>rmon</code> Remote Monitoring
<code>facility</code>	Filter messages to the log by syslog facility.
<code><facility></code>	Specify one of the following syslog facilities to include messages from in the log: <code>kern</code> Kernel messages <code>user</code> Random user-level messages <code>mail</code> Mail system <code>daemon</code> System daemons <code>auth</code> Security/authorization messages <code>syslog</code> Messages generated internally by syslogd <code>lpr</code> Line printer subsystem <code>news</code> Network news subsystem <code>uucp</code> UUCP subsystem <code>cron</code> Clock daemon <code>authpriv</code> Security/authorization messages (private) <code>ftp</code> FTP daemon
<code>msgtext</code>	Select messages containing a certain text string
<code><text-string></code>	A text string to match. This is case sensitive, and must be the last text on the command line.

Mode Global Configuration

Examples To create a filter to send all messages generated by BGP that have a severity of `notices` or higher to a remote syslog server with IP address `10.32.16.21` use the following commands:

```
awplus# configure terminal
awplus(config)# log host 10.32.16.21 level notices program bgp
```

To create a filter to send all messages containing the text "Bridging initialization", to a remote syslog server with IP address `10.32.16.21` use the following commands:

```
awplus# configure terminal
awplus(config)# log host 10.32.16.21 msgtext "Bridging
initialization"
```

To create a filter to send messages with a severity level of `informational` and above to the syslog server with IP address `10.32.16.21` use the following commands:

```
awplus# configure terminal
awplus(config)# log host 10.32.16.21 level informational
```

To remove a filter that sends all messages generated by BGP that have a severity of `notices` or higher to a remote syslog server with IP address `10.32.16.21` use the following commands:

```
awplus# configure terminal
awplus(config)# no log host 10.32.16.21 level notices program
bgp
```

To remove a filter that sends all messages containing the text "Bridging initialization", to a remote syslog server with IP address `10.32.16.21` use the following commands:

```
awplus# configure terminal
awplus(config)# no log host 10.32.16.21 msgtext "Bridging
initialization"
```

To remove a filter that sends messages with a severity level of `informational` and above to the syslog server with IP address `10.32.16.21` use the following commands:

```
awplusawplus# configure terminal
awplus(config)# no log host 10.32.16.21 level informational
```

Related Commands [default log host](#)
[show log config](#)

log host time

This command configures the time used in messages sent to a remote syslog server. If the syslog server is in a different time zone to your switch then the time offset can be configured using either the `utc-offset` parameter option keyword or the `local-offset` parameter option keyword, where `utc-offset` is the time difference from UTC (Universal Time, Coordinated) and `local-offset` is the difference from local time.

Syntax `log host <email-address> time {local|local-offset|utc-offset
{plus|minus}<0-24>}`

Parameter	Description
<code>log</code>	Logging control
<code>host</code>	Set remote syslog server logging parameters
<code><email-address></code>	The email address to send log messages to
<code>time</code>	Specify the time difference between the email recipient and the switch you are configuring.
<code>local</code>	The switch is in the same time zone as the email recipient
<code>local-offset</code>	The switch is in a different time zone to the email recipient. Use the plus or minus keywords and specify the difference (offset) from local time of the switch to the email recipient in hours.
<code>utc-offset</code>	The switch is in a different time zone to the email recipient. Use the plus or minus keywords and specify the difference (offset) from UTC time of the switch to the email recipient in hours.
<code>plus</code>	Negative offset (difference) from the switch to the syslog server.
<code>minus</code>	Positive offset (difference) from the switch to the syslog server.
<code><0-24></code>	World Time zone offset in hours

Mode Global Configuration

Default The default is local time.

Usage Use the `local` option if the remote syslog server is in the same time zone as the switch. Messages will display the time as on the local device when the message was generated.

Use the `offset` option if the email recipient is in a different time zone to this device. Specify the time offset of the remote syslog server in hours. Messages will display the time they were generated on this device but converted to the time zone of the remote syslog server.

Examples To send messages to the remote syslog server with the IP address 10.32.16.21 in the same time zone as the switch's local time zone, use the following commands:

```
awplus# configure terminal
awplus(config)# log host 10.32.16.21 time local 0
```

To send messages to the remote syslog server with the IP address 10.32.16.12 with the time information converted to the time zone of the remote syslog server, which is 3 hours ahead of the switch's local time zone, use the following commands:

```
awplus# configure terminal
awplus(config)# log host 10.32.16.12 time local-offset plus 3
```

To send messages to the remote syslog server with the IP address 10.32.16.02 with the time information converted to the time zone of the email recipient, which is 3 hours behind the switch's UTC time zone, use the following commands:

```
awplus# configure terminal
awplus(config)# log host 10.32.16.02 time utc-offset minus 3
```

**Validation
Commands** `show log config`

Related Commands `default log buffered`

log monitor (filter)

This command creates a filter to select messages to be sent to the terminal when the terminal monitor command is given. Selection can be based on the priority/severity of the message, the program that generated the message, the logging facility used, a sub-string within the message or a combination of some or all of these.

Syntax

```
log monitor
    [level <level>]
    [program <program-name>]
    [facility <facility>]
    [msgtext <text-string>]

no log monitor
    [level <level>]
    [program <program-name>]
    [facility <facility>]
    [msgtext <text-string>]
```

Parameter	Description																
log	Logging control																
monitor	Set monitor logging parameters																
no	Deletes the specified filter, so that corresponding messages are no longer sent to the permanent log.																
level	Filter messages to the permanent log by severity level.																
<level>	The minimum severity of message to send to the log. The level can be specified as one of the following numbers or level names, where 0 is the highest severity and 7 is the lowest severity: <table> <tr> <td>0 emergencies:</td> <td>System is unusable</td> </tr> <tr> <td>1 alerts</td> <td>Action must be taken immediately</td> </tr> <tr> <td>2 critical</td> <td>Critical conditions</td> </tr> <tr> <td>3 errors</td> <td>Error conditions</td> </tr> <tr> <td>4 warnings</td> <td>Warning conditions</td> </tr> <tr> <td>5 notices</td> <td>Normal, but significant, conditions</td> </tr> <tr> <td>6 informational</td> <td>Informational messages</td> </tr> <tr> <td>7 debugging</td> <td>Debug-level messages</td> </tr> </table>	0 emergencies:	System is unusable	1 alerts	Action must be taken immediately	2 critical	Critical conditions	3 errors	Error conditions	4 warnings	Warning conditions	5 notices	Normal, but significant, conditions	6 informational	Informational messages	7 debugging	Debug-level messages
0 emergencies:	System is unusable																
1 alerts	Action must be taken immediately																
2 critical	Critical conditions																
3 errors	Error conditions																
4 warnings	Warning conditions																
5 notices	Normal, but significant, conditions																
6 informational	Informational messages																
7 debugging	Debug-level messages																

Parameter(Cont	Description(Continued)
<code>program</code>	Filter messages to the permanent log by program. Include messages from a specified program in the log.
<code><program-name></code>	The name of a program to log messages from, either one of the following predefined program names (not case-sensitive), or another program name (case -sensitive) that you find in the log output. <code>rip</code> Routing Information Protocol (RIP) <code>ripng</code> Routing Information Protocol - next generation (RIPng) <code>ospf</code> Open Shortest Path First (OSPF) <code>ospfv3</code> Open Shortest Path First (OSPF) version 3 (OSPFv3) <code>bgp</code> Border Gateway Protocol (BGP) <code>rsvp</code> Resource Reservation Protocol (RSVP) <code>pim-dm</code> Protocol Independent Multicast - Dense Mode (PIM-DM) <code>pim-sm</code> Protocol Independent Multicast - Sparse Mode (PIM-SM) <code>pim-smv6</code> Protocol Independent Multicast - Spare Mode version 6 (PIM-SMv6) <code>dot1x</code> IEEE 802.1X Port-Based Access Control <code>lacp</code> Link Aggregation Control Protocol (LACP) <code>stp</code> Spanning Tree Protocol (STP) <code>rstp</code> Rapid Spanning Tree Protocol (RSTP) <code>mstp</code> Multiple Spanning Tree Protocol (MSTP) <code>imi</code> Integrated Management Interface (IMI) <code>imish</code> Integrated Management Interface Shell (IMISH) <code>epsr</code> Ethernet Protection Switched Rings (EPSR) <code>irdp</code> ICMP Router Discovery Protocol (IRDP) <code>rmon</code> Remote Monitoring
<code>facility</code>	Filter messages to the permanent log by syslog facility.
<code><facility></code>	Specify one of the following syslog facilities to include messages from in the log: <code>kern</code> Kernel messages <code>user</code> Random user-level messages <code>mail</code> Mail system <code>daemon</code> System daemons <code>auth</code> Security/authorization messages <code>syslog</code> Messages generated internally by syslogd <code>lpr</code> Line printer subsystem <code>news</code> Network news subsystem <code>uucp</code> UUCP subsystem <code>cron</code> Clock daemon <code>authpriv</code> Security/authorization messages (private) <code>ftp</code> FTP daemon
<code>msgtext</code>	Select messages containing a certain text string
<code><text-string></code>	A text string to match. This is case sensitive, and must be the last text on the command line.

Mode Global Configuration

Default By default there is a filter to select all messages. This filter may be removed and replaced by filters that are more selective.

Examples To create a filter to send all messages generated by MSTP that have a severity of `info` or higher to terminal instances where the terminal monitor command has been given use the following commands:

```
awplus# configure terminal
awplus(config)# log monitor level info program mstp
```

To remove a filter that sends all messages generated by BGP that have a severity of `notices` or higher to the terminal use the following commands:

```
awplus# configure terminal
awplus(config)# no log monitor level notices program bgp
```

To remove a default filter that includes sending everything to the terminal use the following commands:

```
awplus# configure terminal
awplus(config)# no log monitor level debugging
```

**Validation
Commands** `show log config`

Related Commands `terminal monitor`

log permanent

This command configures the device to send log messages to non-volatile storage (NVS) on the device. Log messages sent to NVS are retained on the device over a restart, that is they are permanent. Once the permanent log reaches its configured maximum allowable size old messages will be deleted to make way for new ones.

The no form of the command configures the device not to send any messages to the permanent log. Log messages will not be retained over a restart.

Syntax log permanent
no log permanent

Parameter	Description
log	Logging control
permanent	Send messages to the permanent log.
no	Stop sending messages to the permanent log.

Mode Global Configuration

Examples To enable permanent logging use the following commands:

```
awplus# configure terminal
awplus(config)# log permanent
```

To disable permanent logging use the following commands:

```
awplus# configure terminal
awplus(config)# no log permanent
```

**Validation
Commands** show log config

Related Commands default log permanent
log permanent (filter)
log permanent size
show log permanent

log permanent (filter)

This command creates a filter to select messages to be sent to the permanent log. Selection can be based on the priority/ severity of the message, the program that generated the message, the logging facility used, a sub-string within the message or a combination of some or all of these.

The **no** version of the command removes the corresponding filter, so that the specified messages are no longer sent to the permanent log.

Syntax

```
log permanent
    [level <level>]
    [program <program-name>]
    [facility <facility>]
    [msgtext <text-string>]

no log permanent
    [level <level>]
    [program <program-name>]
    [facility <facility>]
    [msgtext <text-string>]
```

Parameter	Description																
log	Logging control																
permanent	Send messages to the permanent log in non-volatile storage (NVS) memory.																
no	Deletes the specified filter, so that corresponding messages are no longer sent to the permanent log.																
level	Filter messages to the permanent log by severity level.																
<level>	The minimum severity of message to send to the log. The level can be specified as one of the following numbers or level names, where 0 is the highest severity and 7 is the lowest severity: <table> <tr> <td>0 emergencies:</td><td>System is unusable</td></tr> <tr> <td>1 alerts</td><td>Action must be taken immediately</td></tr> <tr> <td>2 critical</td><td>Critical conditions</td></tr> <tr> <td>3 errors</td><td>Error conditions</td></tr> <tr> <td>4 warnings</td><td>Warning conditions</td></tr> <tr> <td>5 notices</td><td>Normal, but significant, conditions</td></tr> <tr> <td>6 informational</td><td>Informational messages</td></tr> <tr> <td>7 debugging</td><td>Debug-level messages</td></tr> </table>	0 emergencies:	System is unusable	1 alerts	Action must be taken immediately	2 critical	Critical conditions	3 errors	Error conditions	4 warnings	Warning conditions	5 notices	Normal, but significant, conditions	6 informational	Informational messages	7 debugging	Debug-level messages
0 emergencies:	System is unusable																
1 alerts	Action must be taken immediately																
2 critical	Critical conditions																
3 errors	Error conditions																
4 warnings	Warning conditions																
5 notices	Normal, but significant, conditions																
6 informational	Informational messages																
7 debugging	Debug-level messages																

Parameter(Cont	Description(Continued)
<code>program</code>	Filter messages to the permanent log by program. Include messages from a specified program in the log.
<code><program-name></code>	The name of a program to log messages from, either one of the following predefined program names (not case-sensitive), or another program name (case -sensitive) that you find in the log output. <code>rip</code> Routing Information Protocol (RIP) <code>ripng</code> Routing Information Protocol - next generation (RIPng) <code>ospf</code> Open Shortest Path First (OSPF) <code>ospfv3</code> Open Shortest Path First (OSPF) version 3 (OSPFv3) <code>bgp</code> Border Gateway Protocol (BGP) <code>rsvp</code> Resource Reservation Protocol (RSVP) <code>pim-dm</code> Protocol Independent Multicast - Dense Mode (PIM-DM) <code>pim-sm</code> Protocol Independent Multicast - Sparse Mode (PIM-SM) <code>pim-smv6</code> Protocol Independent Multicast - Spare Mode version 6 (PIM-SMv6) <code>dot1x</code> IEEE 802.1X Port-Based Access Control <code>lacp</code> Link Aggregation Control Protocol (LACP) <code>stp</code> Spanning Tree Protocol (STP) <code>rstp</code> Rapid Spanning Tree Protocol (RSTP) <code>mstp</code> Multiple Spanning Tree Protocol (MSTP) <code>imi</code> Integrated Management Interface (IMI) <code>imish</code> Integrated Management Interface Shell (IMISH) <code>epsr</code> Ethernet Protection Switched Rings (EPSR) <code>irdp</code> ICMP Router Discovery Protocol (IRDP) <code>rmon</code> Remote Monitoring
<code>facility</code>	Filter messages to the permanent log by syslog facility.
<code><facility></code>	Specify one of the following syslog facilities to include messages from in the log: <code>kern</code> Kernel messages <code>user</code> Random user-level messages <code>mail</code> Mail system <code>daemon</code> System daemons <code>auth</code> Security/authorization messages <code>syslog</code> Messages generated internally by syslogd <code>lpr</code> Line printer subsystem <code>news</code> Network news subsystem <code>uucp</code> UUCP subsystem <code>cron</code> Clock daemon <code>authpriv</code> Security/authorization messages (private) <code>ftp</code> FTP daemon
<code>msgtext</code>	Select messages containing a certain text string
<code><text-string></code>	A text string to match. This is case sensitive, and must be the last text on the command line.

Mode Global Configuration

Default By default the buffered log has a filter to select messages whose severity level is `notices` (5) or higher. This filter may be removed using the **no** form of this command.

Examples To create a filter to send all messages generated by BGP that have a severity of `notices` or higher to the permanent log use the following commands:

```
awplus# configure terminal
```

```
awplus(config)# log permanent level notices program bgp
```

To create a filter to send all messages containing the text "Bridging initialization", to the permanent log use the following commands:

```
awplus# configure terminal
```

```
awplus(config)# log permanent msgtext Bridging initialization
```

**Validation
Commands**

`show log config`

Related Commands

- `default log permanent`
- `log permanent`
- `log permanent size`
- `show log permanent`

log permanent size

This command configures the amount of memory that the permanent log is permitted to use. Once this memory allocation has been filled old messages will be deleted to make room for new messages.

Syntax `log permanent size <50-250>`

Parameter	Description
log	Logging control
permanent	Store log messages permanently in NVS
size	Set the maximum size of the permanent log
<50-250>	Size of the permanent log in kilobytes

Mode Global Configuration

Examples To allow the permanent log to use up to 100 kB of NVS use the following commands:

```
awplus# configure terminal
awplus(config)# log permanent size 100
```

Validation Commands `show log config`

Related Commands `default log permanent`
`log permanent`

show exception log

This command displays the contents of the exception log. When used within a virtual chassis stack (VCS), this command will display the contents of the exception log for all the stack members.

Syntax show exception log

Mode Privileged Exec

Example To display the exception log, use the command:

```
awplus# show exception log
```

Figure 10-1: Example output from the exception log command

```
Stack member 1:
<date> <time> <facility>.<severity> <program[<pid>]>: <message>
-----
2008 May 29 04:08:46 local7.debug awplus corehandler: Process imish (PID:2200) s
ignal 5, core dumped to /flash/imish-r1-main-xinz-1212034124-2200.tgz
2008 May 29 04:10:21 local7.debug awplus corehandler: Process stackd (PID:1136)
signal 5, core dumped to /flash/stackd-r1-main-xinz-1212034216-1136.tgz
-----
Stack member 2:
<date> <time> <facility>.<severity> <program[<pid>]>: <message>
-----
2008 Mar 28 03:15:32 local7.debug awplus corehandler: Process imish (PID:2253) s
ignal 5, core dumped to /flash/imish-r1-main-xinz-7442130-2253.tgz
2008 Mar 28 03:16:06 local7.debug awplus corehandler: Process imish (PID:2416) s
ignal 5, core dumped to /flash/imish-r1-main-xinz-7442165-2416.tgz
2008 Mar 28 03:17:33 local7.debug awplus corehandler: Process aisexec (PID:1786)
signal 5, core dumped to /flash/aisexec-r1-main-xinz-7442251-1786.tgz
-----
```


show log

This command displays the contents of the buffered log.

Syntax `show log [tail [<10-250>]]`

Parameter	Description
show	Show running system information
log	Display logging information
tail	Display only the latest log entries
<10-250>	Specify the number of log entries to display

Mode Privileged Exec and Global Configuration

Default By default the entire contents of the buffered log is displayed.

Usage If the optional tail parameter is specified only the latest 10 messages in the buffered log are displayed. A numerical value can be specified after the tail parameter to select how many of the latest messages should be displayed.

Examples To display the contents of the buffered log use the command:

```
awplus# show log
```

```
<date> <time> <facility>.<severity> <program[<pid>]>: <message>
-----
2006 Nov 10 09:30:09 syslog.notice syslog-ng[67]: syslog-ng starting up;
version='2.0rc3\'
2006 Nov 10 09:30:09 auth.warning portmap[106]: user rpc not found, reverting to
user bin
2006 Nov 10 09:30:09 cron.notice crond[116]: crond 2.3.2 dillon, started, log level
8
2006 Nov 10 09:30:14 daemon.err snmpd[181]: /flash/.configs/snmpd.conf: line 20:
Error: bad SUBTREE object 2006 Nov 10 09:30:14 user.info HSL[192]: HSL: INFO:
Registering port port1.0.1
...
```

To display the 10 latest entries in the buffered log use the command:

```
awplus# show log tail 10
```

```
<date> <time> <facility>.<severity> <program[<pid>]>: <message>
-----
2006 Nov 10 13:30:01 cron.notice crond[116]: USER manager pid 469 cmd logrotate /
etc/logrotate.conf
2006 Nov 10 13:30:01 cron.notice crond[116]: USER manager pid 471 cmd nbqueue --
wipe
2006 Nov 10 13:35:01 cron.notice crond[116]: USER manager pid 472 cmd nbqueue --
wipe
2006 Nov 10 13:40:01 cron.notice crond[116]: USER manager pid 477 cmd nbqueue --
wipe
2006 Nov 10 13:44:36 syslog.notice syslog-ng[67]: Log statistics;
processed='center(queued)=70\ ', processed='2006 Nov 10 13:45:01 cron.notice
crond[116]: USER manager pid 478 cmd logrotate /etc/logrotate.conf
2006 Nov 10 13:45:01 cron.notice crond[116]: USER manager pid 480 cmd nbqueue --
wipe
2006 Nov 10 13:49:32 syslog.notice syslog-ng[67]: SIGHUP received, reloading
configuration;
2006 Nov 10 13:50:01 cron.notice crond[116]: USER manager pid 482 cmd nbqueue --
wipe
2006 Nov 10 13:55:01 cron.notice crond[116]: USER manager pid 483 cmd nbqueue --
wipe
...
```

Related Commands [show log config](#)
 [show log permanent](#)

show log config

This command displays information about the logging system. This includes the configuration of the various log destinations, buffered, permanent, syslog servers (hosts) and email addresses. This also displays the latest status information for each of these destinations.

Syntax `show log config`

Parameter	Description
show	Show running system information
log	Display logging information
config	Display the current logging configuration

Mode Privileged Exec and Global Configuration

Examples To display the logging configuration use the command:

```
awplus# show log config
```

```

Buffered log:
Status ..... enabled
Maximum size ... 100kb
Filters:
*1 Level ..... notices
  Program ..... any
  Facility ..... any
  Message text . any
  2 Level ..... informational
    Program ..... mstp
    Facility ..... daemon
    Message text . any
Statistics ..... 1327 messages received, 821 accepted by filter (2006 Dec 11
10:36:16)
Permanent log:
Status ..... enabled
Maximum size ... 60kb
Filters:
1 Level ..... error
  Program ..... any
  Facility ..... any
  Message text . any
*2 Level ..... warnings
  Program ..... dhcp
  Facility ..... any
  Message text . "pool exhausted"
Statistics ..... 1327 messages received, 12 accepted by filter (2006 Dec 11
10:36:16)
Host 10.32.16.21:
Time offset .... +2:00
Offset type .... UTC
Filters:
1 Level ..... critical
  Program ..... any
  Facility ..... any
  Message text . any
Statistics ..... 1327 messages received, 1 accepted by filter (2006 Dec 11
10:36:16)
Email admin@alliedtelesis.com:
Time offset .... +0:00
Offset type .... Local
Filters:
1 Level ..... emergencies
  Program ..... any
  Facility ..... any
  Message text . any
Statistics ..... 1327 messages received, 0 accepted by filter (2006 Dec 11
10:36:16)
Monitor log:
Filters:
*1 Level ..... debugging
  Program ..... any
  Facility ... any
  Msg text ... any
Statistics ..... Not available
Console log:
Status ..... enabled
List of consoles:
1 ..... ttyS0
Filters:
*1 Level ..... critical
  Program ..... any
  Facility ... any
  Msg text ... any
Statistics ..... 1327 messages received, 1 accepted by filter (2006 Dec 11
10:36:16)

```

In the above example the '*' next to filter 1 in the buffered log configuration indicates that this is the default filter. The permanent log has had its default filter removed, so none of the filters are marked with '*'.

Note: Statistics are updated periodically not in real time. Whenever logging configuration commands are issued the statistics are reset. Whenever automatic log rotation occurs the statistics are reset.

Note: Terminal log and console log cannot be set at the same time. If console logging is enabled then the terminal logging will be turned off.

Related Commands `show log`
 `show log permanent`

show log permanent

This command displays the contents of the permanent log. This command displays the contents of the permanent log. When used within a virtual chassis stack (VCS), this command will display the contents of the permanent log for all the stack members.

Syntax `show log permanent [tail [<10-250>]]`

Parameter	Description
tail	Display only the latest log entries
<10-250>	Specify the number of log entries to display

Mode Privileged Exec and Global Configuration

Default If the optional tail parameter is specified only the latest 10 messages in the permanent log are displayed. A numerical value can be specified after the tail parameter to select how many of the latest messages should be displayed.

Example To display the permanent log, use the command:

```
awplus# show log permanent
```

Figure 10-2: Example output from the show log permanent command

```
<date> <time> <facility>.<severity> <program[<pid>]>: <message>
-----
2006 Nov 10 09:30:09 syslog.notice syslog-ng[67]: syslog-ng starting up;
version=\'2.0rc3\'
2006 Nov 10 09:30:09 auth.warning portmap[106]: user rpc not found, reverting to
user bin
2006 Nov 10 09:30:09 cron.notice crond[116]: crond 2.3.2 dillon, started, log level
8
2006 Nov 10 09:30:14 daemon.err snmpd[181]: /flash/.configs/snmpd.conf: line 20:
Error: bad SUBTREE object
2006 Nov 10 09:30:14 user.info HSL[192]: HSL: INFO:
Registering port port1.0.1
...
To display the 10 latest entries in the permanent log use the command:
awplus>show log permanent tail
<date> <time> <facility>.<severity> <program[<pid>]>: <message>
-----
2006 Nov 10 13:30:01 cron.notice crond[116]: USER manager pid 469 cmd logrotate /
etc/logrotate.conf
2006 Nov 10 13:30:01 cron.notice crond[116]: USER manager pid 471 cmd nbqueue --
wipe
2006 Nov 10 13:35:01 cron.notice crond[116]: USER manager pid 472 cmd nbqueue --
wipe
2006 Nov 10 13:40:01 cron.notice crond[116]: USER manager pid 477 cmd nbqueue --
wipe
2006 Nov 10 13:44:36 syslog.notice syslog-ng[67]: Log statistics;
processed=\'center(queued)=70\' , processed=\'2006 Nov 10 13:45:01 cron.notice
crond[116]: USER manager pid 478 cmd logrotate /etc/logrotate.conf
2006 Nov 10 13:45:01 cron.notice crond[116]: USER manager pid 480 cmd nbqueue --
wipe
2006 Nov 10 13:49:32 syslog.notice syslog-ng[67]: SIGHUP received, reloading
configuration;
2006 Nov 10 13:50:01 cron.notice crond[116]: USER manager pid 482 cmd nbqueue --
wipe
2006 Nov 10 13:55:01 cron.notice crond[116]: USER manager pid 483 cmd nbqueue --
wipe
-----
...
```

Figure 10-3: Example output from the show log permanent command for a stack

```
Stack member 1:

<date> <time> <facility>.<severity> <program[<pid>]>: <message>
-----
2008 May 28 23:11:21 user.crit awplus-2 VCS[1190]: Member 2 (00-00-cd-24-ff-57)
has become the Active Master
2008 May 28 23:11:21 daemon.warning awplus-2 rpc.statd[1300]: gethostbyname erro
r for awplus-2
2008 May 28 23:11:21 daemon.warning awplus-2 rpc.statd[1304]: gethostbyname erro
r for awplus-2
2008 May 28 23:11:53 user.err awplus NSM[1950]: VRRP Error: Can't set pktinfo
2008 May 29 03:54:40 user.alert awplus corerotate[26733]: Exception information
saved to flash:/imish-r1-main-xinz-7441248-19868.tgz
2008 May 29 03:55:47 user.crit awplus-1 VCS[1143]: Contact with the Active Maste
r has been lost
2008 May 29 03:55:47 user.crit awplus-1 VCS[1143]: Member 1 (00-09-41-fb-c3-0f)
has become the Disabled Master
2008 May 29 03:55:47 daemon.err awplus-1 mountd[1282]: Caught signal 15, un-regi
stering and exiting.
2008 May 29 03:55:47 user.warning awplus-1 kernel: nfsd: last server has exited
2008 May 29 03:55:47 user.warning awplus-1 kernel: nfsd: unexporting all filesys
tems

Stack member 2:

<date> <time> <facility>.<severity> <program[<pid>]>: <message>
-----
1970 Mar 27 22:17:33 user.crit awplus-1 VCS[1143]: Member 2 (00-00-cd-24-ff-57)
has become the Active Master
1970 Mar 27 22:17:33 user.alert awplus-1 VCS[1143]: Slave Boot from non-default
location, SW version auto synchronization does not support.
1970 Mar 27 22:17:38 daemon.warning awplus-1 rpc.statd[1271]: gethostbyname erro
r for awplus-1
1970 Mar 27 22:17:38 daemon.warning awplus-1 rpc.statd[1276]: gethostbyname erro
r for awplus-1
1970 Mar 28 03:00:52 user.alert awplus corerotate[26733]: Exception information
saved to flash:/imish-r1-main-xinz-7441248-19868.tgz
1970 Mar 28 03:01:59 user.warning awplus NSM[1950]: imi_client_send_xem_removal
port1.0.1
1970 Mar 28 03:01:59 user.warning awplus NSM[1950]: imi_client_send_xem_removal
port1.2.1
1970 Mar 28 03:15:34 user.alert awplus corerotate[2380]: Exception information s
aved to flash:/imish-r1-main-xinz-7442130-2253.tgz
1970 Mar 28 03:16:08 user.alert awplus corerotate[2495]: Exception information s
aved to flash:/imish-r1-main-xinz-7442165-2416.tgz
1970 Mar 28 03:17:31 user.err awplus VCS[1200]: HA event handling failed with re
sult 9
1970 Mar 28 03:17:31 user.err awplus HSL[1246]: connection to aisexec lost (9)
1970 Mar 28 03:17:31 user.err awplus 802.1X[1451]: connection to aisexec lost (9)
```

Related Commands [remote-command](#)
[show log](#)

show running-config log

This command displays the current running configuration of the Log utility.

Syntax `show running-config log`

Parameter	Description
show	Show running-config information
running-config	Current operating configuration
log	Logging utility

Mode Privileged Exec

Examples To display the current configuration of the log utility, use the command:

```
awplus# show running-config log
```

Related Commands [show log](#)
[show log config](#)

Chapter 11: Scripting Commands



Command List	11.2
activate	11.2
echo	11.3
wait	11.4

Command List

This chapter provides commands used for command scripts.

activate

This command activates a script file.

Syntax `activate [background] <script>`

Parameter	Description
<code>activate</code>	Activate a script
<code>background</code>	Activate a script to run in the background. A process that is running in the background will operate as a separate task, and will not interrupt foreground processing. Generally, we recommend running short, interactive scripts in the foreground and longer scripts in the background. The default is to run the script in the foreground.
<code><script></code>	The file name of the script to activate. The script is a command script consisting of commands documented in this software reference. Note that you must use either a <code>.scp</code> or a <code>.sh</code> filename extension for a valid script text file, as described below in the usage section for this command.

Mode Privileged Exec

Usage In a stacked environment you can use the CLI on a stack master to access file systems that are located on a slave device. In this case the command specifies a file on the slave device. The slave's file system will be denoted by: `<hostname>-<member-id>` For example, `awplus-1` for member 1, `awplus-2` for member 2 etc.

When a script is activated, the privilege level is set to 1 enabling User Exec commands to run in the script. If you need to run Privileged Exec commands in your script you need to add an [enable \(Privileged Exec mode\)](#) command to the start of your script. If you need to run Global Configuration commands in your script you need to add a [configure terminal](#) command after the enable command at the start of your script.

The activate command executes the script in a new shell. A [terminal length](#) shell command, such as `terminal length 0` may also be required to disable a delay that would pause the display.

A script must be a text file with a filename extension of either `.sh` or `.scp` only for the AlliedWare Plus™ CLI to activate the script file. The `.sh` filename extension indicates the file is an ASH script, and the `.scp` filename extension indicates the file is an AlliedWare Plus™ script.

Examples To activate a command script to run as a background process, use the command:

```
awplus#activate background test.scp
```

To activate a script `/flash:/test.scp` in stack member 2, use the command:

```
awplus-2#activate awplus-2/flash:/test.scp
```

Related Commands [configure terminal](#)
[echo](#)
[enable \(Privileged Exec mode\)](#)
[wait](#)

echo

This command echoes a string to the terminal, followed by a blank line.

Syntax `echo <line>`

Parameter	Description
echo	Echo a string
<line>	The string to echo.

Mode Exec and Privileged Exec

Usage This command may be useful in CLI scripts, to make the script print user-visible comments.

Example To echo the string `Hello World` to the console, use the command:

```
awplus#echo Hello World  
Hello World
```

Related Commands [activate](#)
[wait](#)

wait

This command pauses execution of the active script for the specified period of time.

Syntax `wait <delay>`

Parameter	Description
<code>wait</code>	Wait for a specified number of seconds
<code><delay></code>	<1-65335> Specify the time delay in seconds.

Mode Privileged Exec (when executed from a script not directly from the command line)

Default No wait delay is specified by default to pause script execution.

Usage Use this command to pause script execution in an .scp (AlliedWare Plus™ script) or an .sh (ASH script) file executed by the [activate](#) command. The script must contain an [enable \(Privileged Exec mode\)](#) command since the wait command is only executed in the Privileged Exec mode. When a script is activated, the privilege level is set to 1 enabling User Exec commands to run in the script. If you need to run Privileged Exec commands in your script you need to add an [enable \(Privileged Exec mode\)](#) command to the start of your script.

Example See an example .scp script file extract below that will show port counters for interface port1.0.1 over a 10 second interval:

```
enable
show interface port1.0.1
wait 10
show interface port1.0.1
```

Related Commands [activate](#)
[echo](#)
[enable \(Privileged Exec mode\)](#)

Chapter 12: Interface Commands



Command List	12.2
description (interface)	12.2
interface (to configure)	12.3
mtu	12.4
show interface	12.5
show interface brief	12.6
show interface status	12.7
shutdown	12.9

Command List

This chapter provides an alphabetical reference of commands used to configure and display interfaces.

description (interface)

This command adds a description to a specific port or interface.

Syntax `description <description>`

Parameter	Description
<code><description></code>	Text describing the specific interface.

Mode Interface Configuration

Examples The following example uses this command to describe the device that a switch port is connected to.

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# description Boardroom PC
```

interface (to configure)

Use this command to select one or more interfaces to configure.

Syntax `interface <interface-list>`

`interface lo`

Parameter	Description
<code><interface-list></code>	The interfaces or ports to configure. An interface-list can be: ■ an interface, a switch port, or a channel group (e.g., vlan2, port1.1.12, sa3, or po4) ■ a continuous range of interfaces, ports, or channel groups separated by a hyphen, e.g. vlan2-vlan8 or port1.1.1-port1.1.24 or sa2-4, po1-3 ■ a comma-separated list of the above, e.g., port1.0.1,port1.1.1-1.2.24. Do not mix interface types in a list. The specified interfaces must exist.
<code>lo</code>	The local interface ¹ .

1. A local interface is one that is always available for higher layer protocols to use and advertise to the network. Although a local interface is assigned an IP address, it does not have the usual requirement of connecting to a lower layer physical entity. This lack of physical attachment creates the perception of a local interface always being accessible via the network.

Local interfaces can be utilized by a number of protocols for various purposes. They can be used to improve access to the switch and also increase its reliability, security, scalability and protection. In addition, local interfaces can add flexibility and simplify management, information gathering and filtering.

One example of this increased reliability is for OSPF to advertise a local interface as an interface-route into the network irrespective of the physical links that may be "up" or "down" at the time. This provides a higher probability that the routing traffic will be received and subsequently forwarded.

Mode Global Configuration

Examples The following example shows how to enter Interface mode to configure vlan1. Note how the prompt changes.

```
awplus# configure terminal
awplus(config)# interface vlan1
awplus(config-if)#
```

Related Commands `show interface`
`show interface brief`

mtu

Use this command to set the Maximum Transmission Unit (MTU) size for an interface, where MTU is the maximum packet size that an interface can handle.

Use the no command to remove a previously specified Maximum Transmission Unit (MTU) size for an interface, and restores the default MTU size (1500 bytes) for an interface.

Syntax `mtu <mtu_size>`

`no mtu`

Parameter	Description
<code><mtu_size></code>	<code><68-9208></code> Specifies the Maximum Transmission Unit (MTU) size in bytes, where: ■ 1500 bytes is the default Ethernet frame size for an interface.

Default The default MTU size for an interface is 1500 bytes.

Mode Interface Configuration

Example To configure an MTU of 1500 bytes on `vlan2`, use the commands:

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# mtu 1500
```

Related Commands [show interface](#)

show interface

Use this command to display interface configuration and status.

For information on output options, see [“Controlling “show” command output” on page 1.33](#).

Syntax `show interface [<interface-list>]`

Parameter	Description
<code><interface-list></code>	The interfaces to display information about. An interface list can be: ■ an interface, a switch port, or a channel group (e.g., vlan2, port1.1.12, sa3, or po4) ■ a continuous range of interfaces, switch ports, or channel groups separated by a hyphen, e.g. vlan2-vlan8 or port1.1.1-port1.1.24 or sa2-4, po1-3 ■ a comma-separated list of the above. The specified interfaces must exist.

Mode Exec and Privileged Exec

Example To display configuration and status information for port 1.0.1, use the command:

```
awplus# show interface port1.0.1
```

Figure 12-1: Example output from the show interface command

```
awplus# show interface 1.0.1
Interface port1.0.1
  Scope: both
  Link is UP, administrative state is UP
  Thrash-limiting
    Status Not Detected, Action link-down, Timeout 60(s)
  Hardware is Ethernet, address is 0000.cd24.daeb (bia 0000.cd24.daeb)
  VRRP Master of : VRRP is not configured on this interface.
  index 5001 metric 1 mtu 1500
  duplex-full speed 1000 polarity auto
  <UP,BROADCAST,RUNNING,MULTICAST>
  VRF Binding: Not bound
  SNMP link-status traps: Sending (Suppressed after 20 traps in 60 sec.)
  Bandwidth 1g
    input packets 2396, bytes 324820, dropped 0, multicast packets 2370
    output packets 73235, bytes 4906566, multicast packets 73218 broadcast packets 7
```

Related Commands [show interface brief](#)

show interface brief

Use this command to display brief interface configuration and status.

For information on output options, see [“Controlling “show” command output”](#) on page 1.33.

Syntax `show interface brief`

Parameter	Description
brief	Brief summary of interface status and configuration.

Mode Exec and Privileged Exec

Output Figure 12-2: Example output from the show interface brief command

```
awplus#show interface brief
Interface          Status          Protocol
port1.0.1          admin up        down
port1.0.2          admin up        down
port1.0.3          admin up        down
port1.0.4          admin up        down
port1.0.5          admin up        down
port1.0.6          admin up        down
port1.0.7          admin up        down
port1.0.8          admin up        down
port1.0.9          admin up        down
port1.0.10         admin up        down
port1.0.11         admin up        down
port1.0.12         admin up        down
port1.0.13         admin up        down
port1.0.14         admin up        down
port1.0.15         admin up        down
port1.0.16         admin up        down
port1.0.17         admin up        down
port1.0.18         admin up        down
port1.0.19         admin up        down
port1.0.20         admin up        down
port1.0.21         admin up        running
port1.0.22         admin up        down
port1.0.23         admin up        running
port1.0.24         admin up        down
lo                 admin up        running
vlan1              admin up        running
awplus#
```

Related Commands [show interface](#)

show interface status

Use this command to display the status of the specified interfaces, or, if no interfaces are specified, of all interfaces.

Syntax show interface [*<port-list>*] status

Parameter	Description
<i><port-list></i>	The ports to display information about. The port list can be: - a switch port (e.g. port1.2.12), static channel group (e.g., sa3), dynamic (LACP) channel group (e.g., po3), or a management port (e.g. eth0) - a continuous range of ports separated by a hyphen, e.g., port1.0.1-1.0.24, or port1.1.1-port1.1.24, or po1-po4 - a comma-separated list of ports and port ranges, e.g. port1.0.1,port1.1.1-1.2.24. Do not mix switch ports, static channel groups, LACP channel groups, and eth ports in the same list.

Examples To display the status of ports 1.0.1 to 1.0.5, use the commands:

```
awplus# show interface port1.0.1-1.0.5 status
```

To display the status of all ports, use the commands:

```
awplus# show interface status
```

Figure 12-3: Example output from the **show interface status** command

```
awplus>show interface status
Port      Name      Status      Vlan      Duplex      Speed      Type
port1.0.1 Trunk_Net connected   trunk      a-full      a-1000     1000BaseTX
port1.0.2 Access_Net1 connected   5          full        100         1000BaseTX
port1.0.3 Access_Net1 disabled    5          auto        auto        1000BaseTX
port1.0.4 Access_Net2 connected   6          a-half      a-100       1000BaseTX
port1.0.5 Private_Prom connected   10         a-full      a-100       1000BaseTX
port1.0.6 Private_Net1 connected   10,11      a-full      a-100       1000BaseTX
port1.0.7 Private_Net2 connected   10,12      a-full      a-100       1000BaseTX
port1.0.8 notconnect 1          auto        auto        1000BaseTX
.
.
port1.0.23 disabled    1          auto        auto        not present
port1.0.24 notconnect 1          auto        auto        unknown
eth0      connected   none       a-full      a-1000     1000BASE-T
sa1       notconnect trunk      auto        auto
```

Table 12-1: Parameters in the output from the show interface status command

Output Parameter	Description
Port	Name/Type of the interface.
Name	Description of the interface.

Table 12-1: Parameters in the output from the show interface status command(Continued)

Output Parameter	Description
Status	The administrative and operational status of the interface; one of: ■ disabled: the interface is administratively down. ■ connect: the interface is operationally up. ■ notconnect: the interface is operationally down.
Vlan	VLAN type or VLAN IDs associated with the port: ■ When the VLAN mode is trunk, it displays trunk (it does not display the VLAN IDs). ■ When the VLAN mode is access, it displays the VLAN ID. ■ When the VLAN mode is private promiscuous, it displays the primary VLAN ID if it has one, and promiscuous if it does not have a VLAN ID. ■ When the VLAN mode is private host, it displays the primary and secondary VLAN IDs. ■ When the port is an Eth port, it displays none: there is no VLAN associated with it. ■ When the VLAN is dynamically assigned, it displays the current dynamically assigned VLAN ID (not the access VLAN ID), or dynamic if it has multiple VLANs dynamically assigned.
Duplex	The actual duplex mode of the interface, preceded by a- if it has autonegotiated this duplex mode. If the port is disabled or not connected, it displays the configured duplex setting.
Speed	The actual link speed of the interface, preceded by a- if it has autonegotiated this speed. If the port is disabled or not connected, it displays the configured speed setting.
Type	The type of interface, e.g., 1000BaseTX. For SFP bays, it displays Unknown if it does not recognize the type of SFP installed, or Not present if an SFP is not installed or is faulty.

Related Commands [show interface](#)

shutdown

This command shuts down the selected interface. This administratively disables the link and takes the link down at the physical (electrical) layer.

Use the `no` form of this command to disable this function and therefore to bring the link back up again.

Syntax `shutdown`

`no shutdown`

Mode Interface Configuration

Examples The following example shows the use of the `shutdown` command to shut down `port1.0.20`.

```
awplus# configure terminal
awplus(config)# interface port1.0.20
awplus(config-if)# shutdown
```


Chapter 13: Interface Testing Commands



Command List	13.2
clear test interface	13.2
service test	13.3
test interface	13.4

Command List

This chapter provides an alphabetical reference of commands used for testing interfaces.

clear test interface

This command clears test results and counters after issuing a test interface command. Test results and counters must be cleared to issue subsequent test interface commands later on.

Syntax `clear test interface {<port-list>|all}`

Parameter	Description
clear	Resets functions
test	Test device functionality
interface	Test interface
<port-list>	The ports to test. A port-list can be: ■ a switch port (e.g. port1.1.12) ■ a continuous range of ports separated by a hyphen, e.g. port1.1.1-port1.1.24 ■ a comma-separated list of the above, e.g., port1.0.1,port1.1.1-1.2.24. The specified ports must exist.
all	All interfaces

Mode Privileged Exec

Examples To clear the counters for port1.0.1 use the command:

```
awplus# clear test interface port1.0.1
```

To clear the counters for all interfaces use the command:

```
awplus# clear test interface all
```

To clear the counters for ports 1 to 12 on XEM 1 (port1.1.1 through port1.1.12) apply:

```
awplus# clear test interface port1.1.1-port1.1.12
```

Related Commands [test interface](#)

service test

This command puts the device into the interface testing state, ready to begin testing. After entering this command, enter Interface Configuration mode for the desired interfaces and enter the command [test interface](#).

Do not test interfaces on a device that is part of a live network—disconnect the device first.

Use the no parameter to stop the test service.

Syntax `service test`
 `no service test`

Mode Global Configuration

Example To put the device into a test state, use the command:

```
awplus(config)# service test
```

Related Commands [test interface](#)

test interface

This command starts a test on a port or all ports or a selected range or list of ports. Use the `no` form of this command to disable this function. The test duration can be configured by specifying the time in minutes after specifying a port or ports to test.

For an example of all the commands required to test switch ports, see the Examples section in this command. To test the Eth port, set its speed to 100 by using the command `speed 100`.

- Do not run test interface on live networks because this will degrade network performance.

Syntax `test interface {<port-list>|all} [time{<1-60>|cont}]`
`no test interface {<port-list>|all}`

Parameter	Description
<code>no</code>	Negate test device functionality
<code>test</code>	Test device functionality
<code>interface</code>	Test interface
<code><port-list></code>	The ports to test. A port-list can be: ■ a switch port (e.g. port1.1.12) ■ a continuous range of ports separated by a hyphen, e.g. port1.1.1-port1.1.24 ■ a comma-separated list of the above, e.g., port1.0.1,port1.1.1-1.2.24. The specified ports must exist.
<code>all</code>	All ports
<code>time</code>	Keyword entered prior to the value for the time duration of the interface test.
<code><1-60></code>	Specifies duration of time to test the interface or interfaces in minutes (from a minimum of 1 minute to a maximum of 60 minutes). The default is 4 minutes.
<code>cont</code>	Specifies continuous interface testing until cancelled with command negation.

Mode Privileged Exec

Examples To test the switch ports in VLAN 1, install loopbacks in the ports, and enter the following commands:

```
awplus(config)# service test
awplus(config)# no spanning-tree rstp enable bridge-forward
awplus(config)# interface vlan
awplus(config-if)# shutdown
awplus(config-if)# end
awplus# test interface all
```

To see the output, use the commands:

```
awplus# show test
```

```
awplus# show test count
```

To start the test on all interfaces for 1 minute use the command:

```
awplus# test interface all time 1
```

To start the test on ports 1 to 12 for XEM 1 (port1.1.1 through port1.1.12) use the command:

```
awplus# test interface port1.1.1-port1.1.12
```

To stop testing ports 1 to 12 for XEM 1 (port1.1.1 through port1.1.12) use the command:

```
awplus# no test interface port1.1.1-port1.1.12
```

Related Commands [clear test interface](#)

Part 2: Layer Two Switching



- Chapter 14 Switching Introduction
- Chapter 15 Switching Commands
- Chapter 16 VLAN Introduction
- Chapter 17 VLAN Commands
- Chapter 18 Spanning Tree Introduction: STP, RSTP, and MSTP
- Chapter 19 Spanning Tree Commands
- Chapter 20 Link Aggregation Configuration
- Chapter 21 Link Aggregation Commands
- Chapter 22 Power over Ethernet Introduction
- Chapter 23 Power over Ethernet Commands

Chapter 14: Switching Introduction



Introduction.....	14.2
Physical Layer Information	14.3
Switch Ports.....	14.3
Port ranges	14.3
Activating and Deactivating Switch Ports	14.4
Autonegotiation	14.4
Duplex mode.....	14.4
Speed options	14.4
Configuring the port speed	14.5
MDI MDIX Connection Modes (10BASE-T)	14.5
The Layer 2 Switching Process	14.7
The Ingress Rules.....	14.7
The Learning Process.....	14.8
The Forwarding Process.....	14.9
The Egress Rules.....	14.9
Layer 2 Filtering.....	14.10
Ingress Filtering.....	14.10
Channel Groups (Link Aggregation)	14.11
Static Channel Groups	14.11
LACP Channel Groups	14.12
Storm Control	14.14
Loop Protection	14.15
Loop Detection	14.15
Thrash Limiting.....	14.16
Port Mirroring	14.17
Port Security	14.18
MAC Address Learn Limits	14.18
IEEE 802.1X	14.18
Quality of Service.....	14.19
IGMP Snooping	14.20

Introduction

This chapter gives an overview of Layer 1 and 2 switching.

Layer 2 switches are used to connect multiple Local Area Network (LAN) segments together to form an extended LAN. Stations connected to different LANs can be configured to communicate with one another as if they were on the same LAN. They can also divide one physical LAN into multiple Virtual LANs (VLANs). Stations connected to each other on the same extended LAN can be grouped in separate VLANs, so that a station in one VLAN can communicate directly with other stations in the same VLAN, but must go through higher layer routing protocols to communicate with those stations in other VLANs.

Layer 2 switches appear transparent to higher layer protocols, transferring frames between the data link layers of the networks to which they are attached. A layer 2 switch accesses each physical link according to the rules for that particular network. Access may not always be instant, so the switch must be capable of storing and forwarding frames.

Storing and forwarding enables the switch to examine both the VLAN tag fields and Ethernet MAC address fields in order to forward the frames to their appropriate destination. In this way, the switch can act as an intelligent filtering device, redirecting or blocking the movement of frames between networks.

Because switch ports can sometimes receive frames faster than it can forward them, the switch has Quality of Service (QoS) queues in which frames await transmission according to their priority. Such a situation could occur where data enters a number of input ports and all destined for the same output port.

The switch can be used to:

- Increase both the physical extent and the maximum number of stations on a LAN. LANs are limited in their physical extent by the signal distortion and propagation delay characteristics of the media. The switch overcomes this limitation by receiving a frame on one LAN and then retransmitting it to another. The physical characteristics of the LAN media also place a practical limit on the number of stations that can be connected to a single LAN segment. The switch overcomes this limitation by joining LAN segments to form an extended LAN capable of supporting more stations than either of the individual LAN segments.
- Connect LANs that have a common data link layer protocol but different physical media, for example, Ethernet 10BASET, 100BASET, and 10BASEF.
- Increase the availability of LANs by allowing multiple redundant paths to be physically configured, and selected dynamically, using the Spanning Tree algorithm.
- Reduce the load on a LAN or increase the effective bandwidth of a LAN, by filtering traffic.
- Prioritize the transmission of data with high Quality of Service requirements.

By using Virtual LANs (VLANs), a single physical LAN can be separated into multiple Virtual LANs. VLANs can be used to:

- Further improve LAN performance, as broadcast traffic is limited to LAN segments serving members of the VLAN to which the sender belongs.
- Provide security, as frames are forwarded to those stations belonging to the sender's VLAN, and not to stations in other VLANs on the same physical LAN.
- Reduce the cost of moving or adding stations to function or security based LANs, as this generally requires only a change in the VLAN configuration.

Physical Layer Information

Switch Ports

A unique port number identifies each switch port. The software supports a number of features at the physical level that allow it to be connected in a variety of physical networks. This physical layer (layer 1) versatility includes:

- Enabling and disabling of ports
- Auto negotiation of port speed and duplex mode for all 10/100 BASE ports
- Manual setting of port speed and duplex mode for all 10/100 BASE ports
- Link up and link down triggers
- Packet storm protection
- Port mirroring
- Support for SNMP management

Port Numbering

Ports are numbered using a 3 digit format x.y.z where x is the device number (within a stacked configuration), y is the module number within the device, and z is the port number within the module. Ports connected directly to the switch chassis (rather than a pluggable module) are given the module number 0. In an unstacked configuration all device numbers are 1. Example, port number 1.2.6 represents device 1, module 2, port 6.

Adding a description

You can add a description to an interface to help identify its purpose or position. For example, to add the description “connected to Nerv” to port1.0.3, use the commands:

```
awplus(config)#interface port1.0.3
awplus(config-if)#description connected to Nerv
```

Port ranges

Continuous

To configure a continuous range of ports at the same time, enter the range in the format:

```
portx.y.z-portx.y.z
```

For example, to configure the same interface setting on base switch ports 10-20, enter the Global Configuration mode command:

```
awplus(config)#interface port1.0.10-port1.0.20
```

Non-continuous

To configure a non-continuous set of ports at the same time, enter a comma-separated list:

```
portx.y.z,portx.y.z
```

For example, to configure the same interface setting on base switch ports 1 and 5, enter the Global Configuration mode command:

```
awplus(config)#interface port1.0.1,port1.0.5
```

You can combine a hyphen-separated range and a comma-separated list. To configure the same setting on base switch ports 1-3 and 5, enter the Global Configuration mode command:

```
awplus(config)#interface port1.0.1-port1.0.3,port1.0.5
```

Activating and Deactivating Switch Ports

An active switch port is one that is available for packet reception and transmission. Disabling a switch port does not affect the STP operation on the port. By default ports and VLANs are activated. To shutdown a port or VLAN use the [shutdown command on page 12.9](#). Use the no shutdown command to reactivate it.

Autonegotiation

Autonegotiation lets the port adjust its speed and duplex mode to accommodate the device connected to it. When the port connects to another autonegotiating device, they negotiate the highest possible speed and duplex mode for both of them.

By default, all ports autonegotiate. Setting the port to a fixed speed and duplex mode may be necessary when connecting to a device that cannot autonegotiate.

Duplex mode

Ports can operate in full duplex or half duplex mode depending on the type of port it is. When in full duplex mode, a port transmits and receives data simultaneously. When in half duplex mode, the port transmits or receives but not both at the same time.

You can set a port to use either of these options, or allow it to autonegotiate the duplex mode with the device at the other end of the link. To configure the duplex mode

```
awplus#
configure terminal  Enter Global Configuration mode
awplus(config)#
interface port1.0.1  Enter Interface Configuration mode for port 1.0.1
awplus(config-if)#
duplex {auto|full|half}  Enter the duplex mode for port 1.0.1
```

Speed options

Before configuring a port's speed, check the hardware limit for the particular port type. The following list can be used as a guide:

- copper or fibre SFPs: 1000Mbps
- non-SFP RJ-45 copper switch ports: 10, 100 or 1000 Mbps
- supported tri-speed copper SFPs: 10, 100 or 1000 Mbps
- fibre SFPs: 100 Mbps to 1000Mbps, depending on the SFP type.
- XFP modules: 10 Gbps

For the latest list of approved SFP transceivers either contact your authorized distributor or reseller, or visit <http://www.alliedtelesis.com>

You can set a port to use one of these speed options, or allow it to autonegotiate the speed with the device at the other end of the link.

Most types of switch port can operate in either full duplex or half duplex mode. In full duplex mode a port can transmit and receive data simultaneously. In half duplex mode the port can either transmit or receive, but not at the same time.

Make sure that the configuration of the switch matches the configuration of the device at the far end of the link. In particular, avoid having one end autonegotiate duplex mode while the other end is fixed. For example, if you set one end of a link to autonegotiate and fix the other end at full duplex, the autonegotiating end cannot determine that the fixed end is full duplex capable. Therefore, the autonegotiating end selects half-duplex operation. This results in a duplex mismatch and packet loss. To avoid this, either fix the mode at both ends, or use autonegotiation at both ends.

Configuring the port speed


To set the port speed to 1000 kbps on port 1.0.1

```
awplus#  
configure terminal  Enter the Global Configuration mode.  
awplus(config)#  
interface port1.0.1  Enter Interface Configuration mode for port 1.0.1  
awplus(config-if)#  
speed 1000  Set the port speed for port 1.0.1 to 1000 kbps.
```

MDI MDIX Connection Modes (10BASE-T)

The IEEE 802.3 standard defines a series of Media Dependant interface types and their physical connections. For twisted pair (10BASE-T) networking, the standard defines that connectors that conform to the IEC 60603-7 standard. The following diagram shows a connector of this type.

Figure 14-1: Connector used for 10BASE-T networks



Connections to 10BASE-T networks may either be straight through (MDI) or a crossover. The crossover connection can be achieved by using either a crossover cable or by integrating the crossover function within the device. In the latter situation, the connector referred to as an MDIX connection. Refer to your switch's hardware reference for more detailed information on physical connections cabling.

Configuring MDI MDIX

Although switch ports are set to MDIX by default, you can reconfigure them by using the [polarity command on page 15.20](#).

To set the MDI/MDIX mode for port 1.0.1, use the following commands:

```
awplus#  
configure terminal  Enter the Global Configuration mode.  
awplus(config-if)#  
interface port1.0.1  Enter Interface Configuration mode to configure port 1.0.1  
awplus(config-if)#  
polarity mdi  Set the polarity for port 1.0.1 to MDI.
```

Note that if you override a port's autonegotiation by setting it to a fixed speed and duplex mode, automatic MDI/MDI-X detection is also overridden. Ports have the MDI-X polarity by default.

The Layer 2 Switching Process

The Layer 2 switching process comprises these related but separate processes:

- The Ingress Rules
- The Learning Process
- The Forwarding Process
- The Egress Rules

Ingress rules admit or discard frames based on their VLAN tagging.

The Learning process learns the MAC addresses and VLAN membership of frames admitted on each port.

The Forwarding process determines which ports the frames are forwarded to, and the Quality of Service priority with which they are transmitted.

Finally, Egress rules determine for each frame whether VLAN tags are included in the Ethernet frames that are transmitted.

These processes assume that each station on the extended LAN has a unique data link layer address, and that all data link layer frames have a header which includes the source (sender's) MAC address and destination (recipient's) MAC address.

The Ingress Rules

All frames, tagged and untagged, that a VLAN-aware switch receives must be classified into a VLAN. Each received frame is mapped to exactly one VLAN. If an incoming frame is tagged with a valid VLAN identifier (VID) then that VID is used. If an incoming frame is untagged or is priority tagged (a tagged frame with a VID of all zeros), then the switch uses internal VLAN association rules to determine the VLAN it belongs to. The default settings for the ingress rules are to Admit All Frames, and for Ingress Filtering to be on.

Every port belongs to one or more VLANs so every incoming frame has a VID to show which VLAN it belongs. The final part of the Ingress Rules depends on whether Ingress Filtering is enabled for the port. If Ingress Filtering is disabled, all frames are passed on to the Learning process, regardless of which VLAN they belong to. If Ingress Filtering is enabled (by default), frame are admitted only when they have the VID of a VLAN to which the port belongs. Frames are discarded when they do not have an associated VID matching the VLAN assigned to a port.

The possible association rules, in order of precedence, are:

- IP subnet/IPX network classification
- protocol classification
- port classification

The default VLAN classification is based upon the port on which the incoming frame (untagged, or priority tagged) was received. It is possible for an incoming untagged, or priority tagged, frame to match more than one of the association rules.

Each port on the switch can be configured to be one of two modes:

- only untagged frames - access mode
- only VLAN-tagged frames - trunk mode

Access Mode

This mode can be used to connect to VLAN unaware devices. Frames to and from access mode ports carry no VLAN tagging information.

Trunk Mode

This mode is used to connect VLAN capable devices. All devices that connect using trunk mode ports must be VLAN aware.

The Learning Process

The learning process uses an adaptive learning algorithm, sometimes called *backward learning*, to discover the location of each station on the extended LAN.

All frames admitted by the ingress rules on any port are passed on to the forwarding process when they are for destinations in the same VLAN. Frames destined for other VLANs are passed to a Layer 3 protocol, such as IP. For every frame admitted, the frame's source MAC address and VID are compared with entries in the forwarding database for the VLAN (also known as a *MAC Address table*) maintained by the switch. When the frame's source address is not in the forwarding database for the VLAN, the address is added and an ageing timer for that entry is started. When the frame's source address is already in the forwarding database, the ageing timer for that entry is restarted.

By default, switch learning is enabled. It can be disabled with the `no mac address-table acquire` command, and re-enabled using the `mac address-table acquire` command on page 15.13.

If the ageing timer for an entry in the forwarding database expires before another frame with the same source address is received, the entry is removed from the forwarding database. This prevents the forwarding database from being filled with information about stations that are inactive or have been disconnected from the network. It also ensures that entries for active stations are kept alive in the forwarding database.

By default, the ageing timer is enabled with a default ageing-time. The ageing timer can be reset to the default with the `no mac address-table ageing-time` command. The ageing timer can be increased or decreased using the `mac address-table ageing-time` command.

If switch learning is disabled and the ageing timer has aged out all dynamically learned filter entries, only statically entered MAC source addresses decide the packets to forward or discard. When the switch finds no matching entries in the forwarding database during the forwarding process, all switch ports in the VLAN are flooded with the packet, except the port that received it.

The default value for the mac address-table ageing-time is 300 seconds (5 minutes) and can be modified by using the command `mac address-table ageing-time`. The `no mac address-table ageing-time` command will reset the ageing-time back to the default value (5 minutes).

To set the mac address-table ageing-time to 1000 seconds:

```
awplus#
configure terminal  Enter the config terminal mode
awplus(config)#
mac address-table ageing-time 1000  Set the ageing time to 1000 seconds
```

To display general switch settings, including settings for switch learning and the switch ageing timer, use the `show system` command on page 8.32.

The Forwarding Process

After a VID is assigned to a frame using the ingress rules, the switch forwards it to the destination MAC address specified in the frame. To do this the switch must learn which MAC addresses are available on each port for each VLAN. When the destination MAC address is not found, the switch floods the frame on all ports that are members of the VLAN except the port on which the frame was received.

The forwarding database (also known as the *MAC Address table*) determines the egress port on which the destination MAC address has been learned. MAC addresses are learned dynamically as part of the layer two switching process.

The forwarding database is ordered according to MAC address and VLAN identifier. This means a MAC address can appear more than once in the forwarding database having been learned on the same port but for different VLANs. This could occur if the IP address of an end station is changed thereby moving the end station to a different IP subnet-based VLAN while still connected to the same switch port. When the forwarding database ageing process is enabled, old entries in the forwarding database are deleted after a user-configurable period.

If the destination address is found, the switch discards the frame when the port is not in the STP forwarding or disabled state if the destination address is on the same port as the source address, or if there is a static filter entry for the destination address set to discard (see [“Layer 2 Filtering” on page 14.10](#)). Otherwise, the frame is forwarded on the indicated port.

Forwarding occurs only when the port on which the frame was received is in the Spanning Tree forwarding or disabled state. The destination address is then looked up in the forwarding database for the VLAN.

The Egress Rules

After the forwarding process has determined from which ports and transmission queues to forward a frame, the egress rules for each port determine whether the outgoing frame is VLAN-tagged with its numerical VLAN identifier (VID).

A port must belong to a VLAN at all times unless the port has been set as the mirror port for the switch.

A port can transmit VLAN-tagged frames for any VLAN to which the port belongs. A port can transmit untagged frames for any VLAN for which the port is configured, e.g. IP subnet-based or protocol-based, unless prevented by the port-based VLAN egress rules. A port that belongs to a port-based VLAN can transmit untagged packets for only one VLAN. For more information about VLANs and VLAN tagging, see [Chapter 16, VLAN Introduction](#).

For more information on port tagging see the following commands:

[switchport mode access command on page 17.11](#)

[switchport mode trunk command on page 17.13](#)

Layer 2 Filtering

The switch has a forwarding database (also known as the *MAC address table*) whose entries determine whether frames are forwarded or discarded over each port. Entries in the forwarding database are created dynamically by the learning process. A dynamic entry is automatically deleted from the forwarding database when its ageing timer expires.

The forwarding database supports queries by the forwarding process as to whether frames with given values of the destination MAC address field should be forwarded to a given port.

For each VLAN, the destination MAC address of a frame to be forwarded is checked against the forwarding database. If there is no entry for the destination address and VLAN, the frame is transmitted on all ports in the VLAN that are in the forwarding or disabled state, except the port on which the frame was received. This process is referred to as *flooding*. If an entry is found in the forwarding database but the entry is not marked *forwarding* or the entry points to the same port the frame was received on, the frame is discarded. Otherwise, the frame is transmitted on the port specified by the forwarding database.

Ingress Filtering

The ingress-filter parameter of the [switchport mode trunk command on page 17.13](#) and the [switchport mode access command on page 17.11](#), enables or disables ingress filtering of frames entering the specified port (or port range). Each port on the switch belongs to one or more VLANs. If ingress filtering is enabled, any frame received on the specified port is only admitted if its VID matches one for which the port is tagged. Any frame received on the port is discarded if its VID does not match one for which the port is tagged.

Untagged frames are admitted and are assigned the VLAN Identifier (VID) of the port's native VLAN. Ingress filtering can be turned off by setting the disable parameter of the above two commands. The default setting of the enable / disable parameter option is enable.

Note: Enabling the vlan-disable parameter of the [thrash-limiting command on page 15.45](#) will also enable ingress filtering, and will override the setting of the switchport mode access, and trunk commands.

Channel Groups (Link Aggregation)

Channels (either static or dynamic—LACP) increase channel reliability by distributing the data path over more than one physical link. Channels must be configured on both ends of a link or network loops may result. Ports in a channel group need not be contiguous. A mirror port cannot be a member of either a static or a dynamic channel group.

Aggregation criteria

For individual links to be aggregated into a channel group they must:

- originate on the same device or stack
- terminate on the same device or stack
- be members of the same VLANs (vlan command on page 17.24)
- have the same data rate (speed command on page 15.39)
- share the same admin port key (assigned by using the channel-group mode command on page 21.3 command)
- be operating in full duplex mode (duplex command on page 15.8)

The hardware must also be capable and have the capacity to handle the number of links to be aggregated.

Static Channel Groups

A static channel group (also known as a static aggregator) enables a number of ports to be manually configured to form a single logical connection of higher bandwidth. By using static channel groups you increase channel reliability by distributing the data path over more than one physical link.

The following example creates a static channel group and adds switch ports 1.0.1 and 1.0.2.

<code>awplus# configure terminal</code>	Enter Global Configuration mode.
<code>awplus(config)# interface port1.0.1</code>	Enter the Config-Interface mode to configure port 1.0.1
<code>awplus(config-if)# static-channel-group 2</code>	Add port 1. 0.1 to static-channel-group 2.
<code>awplus(config-if)# exit</code>	Return to Global Configuration mode.
<code>awplus(config)# interface port1.0.2</code>	Enter Interface Configuration mode to configure port 1. 0. 2.
<code>awplus(config-if)# static-channel-group 2</code>	Add port 1. 0. 2 to static-channel-group 2.

For details of static channel group commands, see [Chapter 21, Link Aggregation Commands](#).

LACP Channel Groups

An LACP channel group (also known as an ether-channel, an LACP aggregator, or a dynamic channel group) enables a number of ports to be dynamically combined to form a single higher bandwidth logical connection.

AlliedwarePlus™ supports IEEE 802.3ad link aggregation and uses the Link Aggregation Control Protocol (LACP).

Link Aggregation Control Protocol (LACP)

LACP operates where systems are connected over multiple communications links. Once LACP has been initially configured and enabled, it automatically creates Ether-channels and assigns appropriate links to their membership. LACP continues to monitor these groups and dynamically adds or removes links to them as network changes occur.

LACP achieves this by determining:

- which ports are under LACP control ([channel-group mode command on page 21.3](#))
- whether each port is in LACP active or LACP passive mode ([channel-group mode command on page 21.3](#))
- which system has the highest LACP priority ([lacp system-priority command on page 21.7](#))
- the LACP priority of ports ([lacp port-priority command on page 21.6](#))
- whether the LACP timeout is short or long ([lacp timeout command on page 21.7](#))

Channel group identification

In order to identify particular channel groups, each group is assigned a link aggregation identifier called a *lag ID*. The lag ID comprises the following components for both the local system (called the Actor) followed by their equivalent components for the remote system (called the Partner):

- system identifier - the MAC address of the system
- port key - An identifier - created by the LACP software
- port priority - set by the [lacp port-priority command on page 21.6](#)
- port number - determined by the device connection

The lag ID can be displayed for each aggregated link by entering the [show etherchannel command on page 21.10](#).

Configuring an LACP channel group

The following example creates LACP channel group 2 and enables link aggregation on switch ports 1.0.1 and 1.0.2 within this channel group. Note that all aggregated ports must belong to the same VLAN.

<code>awplus#</code>	
<code>configure terminal</code>	Enter Global Configuration mode.

<code>awplus(config)#</code>	
<code>interface port1.0.1-port1.0.2</code>	Enter the Interface Configuration mode for the switch ports to aggregate into the channel group.

<code>awplus(config-if)#</code>	
<code>channel-group 2 mode active</code>	Assign the switch ports to channel group 2 in active mode. This creates the channel group.

For a more detailed LACP configuration example, see [Chapter 20, Link Aggregation Configuration](#). For details of LACP channel group commands, see [Chapter 21, Link Aggregation Commands](#).

Storm Control

The packet storm protection feature enables you to set limits on the reception rate of broadcast, multicast frames and destination lookup failures. You can set separate limits beyond which each of the different packet types are discarded.

Note: A destination lookup failure (DLF) is the event of receiving a unicast Ethernet frame with an unknown destination address.

Note: On the AT-9900 applying this command to one port will apply it to all ports on the switch.

For more information on applying storm control, see the [storm-control level command on page 15.40](#) command.

To apply storm control by limiting broadcasts to 30% on port 1.0.4 (and all other port on the switch)

```
awplus(config-if)#
configure terminal
```

```
awplus(config-if)#
interface port1.0.4
```

```
awplus(config-if)#
storm-control broadcast level 30
```

Enter Global Configuration mode.

Enter the Interface Configuration mode for the selected port.

Configure the interface.

To turn off storm protection on port 1. 0. 4(and all other ports on the switch)

```
awplus(config-if)#
configure terminal
```

```
awplus(config-if)#
interface port1.0.4
```

```
awplus(config-if)#
no storm-control broadcast level
```

Enter Global Configuration mode.

Enter the Interface Configuration mode for the selected port.

Configure the interface.

Loop Protection

Loop protection is a general term that embraces several different methods you can apply to protect your network from effects such as broadcast storms that can result from data loops or equipment malfunction. Presently two methods of loop protection are available:

- Loop Detection
- Thrash Limiting

Loop Detection

Introduction

This feature is used to detect loops with a network segment. If a loop is detected then a selected protection mechanism is applied to limit the effect of the loop. The loop protection actions can be applied either to the port at which the loop is detected or to the VLAN within which the loop was detected.

Limiting Actions

You can configure loop detection to apply one of the following mechanisms when a loop condition is detected:

- Disable all MAC address learning.
- Block all traffic on the port (or aggregated link) that detected the loop, and take down the link.
- Block all traffic on the port (or aggregated link) that detected the loop, but keep the link in the up state.
- Block all traffic on a vlan. Note that setting this parameter will also enable ingress filtering. This is the default action.
- Take no action, but log the details.
- Take no action.

Operation

To detect loops this feature operates by transmitting a series of Loop Detection Frames (LDFs) from each switch port out into the network. If no loops exist, then none of these frame should ever return. If a frame returns to its original port, the detection mechanism assumes that there is a loop somewhere in the network and offers a number of protective options.

Each LDF is a layer 2 LLC frame that contains the following components:

- the source MAC address of the originating switch
- the destination MAC address of the non-existent end station 00-00-F4-27-71-01
- VLAN ID (where the port is a tagged member of a VLAN).
- a randomly generated LDF ID number.

You can set the detection mechanism to remember the LDF ID of up to 5 of the most recently transmitted LDF frames. Each of the 5 most recently transmitted frames is compared with every frame that arrives at that same port.

Configuration

To enable loop protection and configure its basic parameters, you use the [loop-protection command on page 15.11](#).

Example To enable the loop-detect mechanism, and generate loop-detect frames once every 5 seconds, use the command:

```
awplus(config)# loop-protection loop-detect ldf-interval 5
```

Note: LDFs are sent sequentially for each VLAN defined to a particular port. For example, if a particular port in this example is a member of 4 VLANs, then the LDFs will be sent from this port at the rate of 4 frames every 5 seconds.

You can now use the [loop-protection action command on page 15.12](#) configure the action that the switch will take if a loop is detected.

Example To disable an interface, and bring the link down, when a network loop is detected, use the command:

```
awplus(config-if)# loop-protection action link-down
```

Now decide how long you want the protective action to apply for. You configure this function by using the [loop-protection timeout command on page 15.13](#).

Example To configure a loop protection action timeout of 10 seconds, use the command:

```
awplus(config-if)# loop-protection timeout 10
```

Thrash Limiting

MAC address thrashing occurs when MAC addresses move rapidly between one or more ports or trunks, for example, due to a network loop.

Thrash limiting enables you to apply actions to a port when thrashing is detected. It is supported on all port types and also on aggregated ports.

Limiting Actions There are several different thrash actions that you can apply to a port when thrashing is detected. These actions are:

- **learnDisable**
Address learning is temporarily disabled on the port.
- **portDisable**
The port is logically disabled. Traffic flow is prevented, but the link remains up. The device at the other end does not notice that the port has changed status, and the link LEDs at both ends stay on.
- **linkDown**
The port is physically disabled and the link is down. This is equivalent to entering the shutdown command on page 12.9.
- **vlanDisable**
The port is disabled only for the VLAN on which thrashing has occurred. It can still receive and transmit traffic for any other VLANs of which it is a member.

When a MAC address is thrashing between two ports, one of these ports (the first to cross its thrashing threshold) is disabled. All other ports on the device will then have their threshold counters reset.

To set a thrash action for a port, use the [thrash-limiting command on page 15.45](#):

To view the thrash action that is set for a port, use the [show interface switchport command on page 15.22](#):

Re-enabling a port

When a port is disabled, either completely or for a specific VLAN, it remains disabled until it is manually re-enabled in any of the following ways:

- by using SNMP
- by rebooting the switch or stack
- by specifying a thrash timeout value along with the thrash action
- via the CLI

Port Mirroring

Port mirroring enables traffic being received and transmitted on a switch port to be sent to another switch port, the mirror port, usually for the purposes of capturing the data with a protocol analyzer.

The mirror port is the only switch port that does not belong to a VLAN, and therefore does not participate in any other switching. Before the mirror port can be set, it must be removed from all trunk groups and all VLANs except the default VLAN. The following example sets mirroring on ports 1.0.2 and 1.0.5 for both incoming and outgoing data.

Note: Due to the internal hardware properties of the switch, frames that are destined to leave the mirrored port untagged (i.e. will have their VLAN tag removed on egress) will be received by the mirror port with the tag retained. Consequently, if frames were being transmitted by the mirror port (into the network) at wire speed, then the mirror port might be unable to accept all the frames supplied to it.

To configure port 1.0.2 to mirror port 1.0.5

```

awplus# Enter Global Configuration mode.
configure terminal

awplus(config)# Enter the Interface Configuration mode for
interface port1.0.2 port 1.0.2.

awplus(config-if)# Configure this port to mirror port 1.0.5.
mirror interface port1.0.5
direction both
  
```

Port Security

The port security features provide control over the stations connected to each switch port. These comprise:

- MAC address learn limits
- IEEE 802.1X

MAC Address Learn Limits

MAC address limiting is applied using the [switchport port-security command on page 15.41](#). If enabled on a port, the switch will learn MAC addresses up to a user-defined limit from 1 to 256, then lock out all other MAC addresses. One of the following options can be specified for the action taken when an unknown MAC address is detected on a locked port:

- Discard the packet and take no further action.
- Discard the packet and notify management with an SNMP trap.
- Discard the packet, notify management with an SNMP trap and disable the port.

IEEE 802.1X

IEEE 802.1X restricts unauthenticated devices from connecting to the switch. After authentication is successful, traffic is allowed through the switch. For more information see [Chapter 54, 802.1X Configuration](#).

Quality of Service

Quality of Service (QoS) enables you to both prioritize traffic and limit its available bandwidth. The concept of QoS is a departure from the original networking protocols, in which all traffic on the Internet or within a LAN had the same available bandwidth. Without QoS, all traffic types are equally likely to be dropped if a link becomes oversubscribed. This approach is now inadequate in many networks, because traffic levels have increased and networks often carry time-critical applications such as streams of real-time video data. QoS also enables service providers to easily supply different customers with different amounts of bandwidth.

Configuring Quality of Service involves two separate stages:

1. Classifying traffic into flows, according to a wide range of criteria. Classification is performed by the switch's class maps.
2. Acting on these traffic flows.

The switch's QoS functionality includes the following:

- policies, to provide a QoS configuration for a port or ports
- traffic classes, for bandwidth limiting and user prioritization
- maximum bandwidth limiting on a traffic class
- flow groups within traffic classes, for user prioritization
- control of the egress scheduling algorithm
- priority relabelling of frames, at Layer 2, by replacing the VLAN tag User Priority field
- class of service relabelling of frames, at Layer 3, by replacing the DSCP (DiffServ Code Point) or the TOS precedence value in the IP header's Type of Service (TOS) field.

For more information on QoS see [Chapter 52, Quality of Service \(QoS\)](#) and [Chapter 53, QoS Commands](#).

IGMP Snooping

IGMP (Internet Group Management Protocol) is used by IP hosts to report their multicast group memberships to routers and switches. IP hosts join a multicast group to receive broadcast messages directed to the multicast group address. IGMP is an IP-based protocol and uses IP addresses to identify both the multicast groups and the host members. For a VLAN-aware devices, this means multicast group membership is on a per-VLAN basis. If at least one port in the VLAN is a member of a multicast group, by default multicast packets will be flooded onto all ports in the VLAN.

IGMP snooping enables the switch to forward multicast traffic intelligently on the switch. The switch listens to IGMP membership reports, queries and leave messages to identify the switch ports that are members of multicast groups. Multicast traffic will only be forwarded to ports identified as members of the specific multicast group.

IGMP snooping is performed at Layer 2 on VLAN interfaces automatically. By default, the switch will forward traffic only from those ports with multicast listeners, therefore it will not act as a simple hub and flood all multicast traffic out all ports. IGMP snooping is independent of the IGMP and Layer 3 configuration, so an IP interface does not have to be attached to the VLAN, and IGMP does not have to be enabled or configured.

IGMP snooping is enabled by default.

Chapter 15: Switching Commands



Command List	15.2
backpressure	15.2
clear loop-protection counters	15.3
clear mac address-table static	15.4
clear mac address-table dynamic	15.5
clear port counter	15.6
debug platform packet	15.7
duplex	15.8
flowcontrol	15.9
loop-protection	15.11
loop-protection action	15.12
loop-protection timeout	15.13
mac address-table acquire	15.13
mac address-table ageing-time	15.14
mac address-table static	15.15
mac address-table thrash-limit	15.16
mirror interface	15.17
platform bist	15.18
platform vlan-stacking-tpid	15.19
polarity	15.20
show flowcontrol interface	15.21
show interface switchport	15.22
show loop-protection	15.23
show mac address-table	15.24
show mac address-table thrash-limit	15.25
show mirror	15.26
show mirror interface	15.27
show platform	15.28
show platform bist	15.29
show platform classifier statistics utilization brief	15.30
show platform table port	15.32
show port-security interface	15.36
show port-security intrusion	15.37
show storm-control	15.38
speed	15.39
storm-control level	15.40
switchport port-security	15.41
switchport port-security aging	15.42
switchport port-security maximum	15.43
switchport port-security violation	15.44
thrash-limiting	15.45

Command List

This chapter provides an alphabetical reference of commands used to configure switching. For more information see [Chapter 14, Switching Introduction](#).

backpressure

This command provides a method of applying flow control to ports running in half duplex mode. The setting will only apply when the link is in the half-duplex state.

You can disable backpressure on an interface using the `off` parameter or the `no backpressure` command.

Syntax `backpressure {on|off}`

`no backpressure`

Parameters	Description
<code>no</code>	Disables half-duplex flow control.
<code>on</code>	Enables half-duplex flow control.
<code>off</code>	Disables half-duplex flow control.

Mode Interface Configuration

Default Backpressure is turned off by default. You can determine whether an interface has backpressure enabled by viewing the running-config output; backpressure on is shown for interfaces if this feature is enabled.

Usage The backpressure feature enables half duplex Ethernet ports to control traffic flow during congestion by preventing further packets arriving. Back pressure utilizes a pre-802.3x mechanism in order to apply ethernet flow control to switch ports that are configured in the half duplex mode.

The flow control applied by the [flowcontrol command on page 15.9](#) operates only on full-duplex links, whereas back pressure operates only on half-duplex links.

If a port has insufficient capacity to receive further frames, the switch will simulate a collision by transmitting a CSMACD jamming signal from this port until the buffer empties. The jamming signal causes the sending switch to stop transmitting and wait a random period of time, before retransmitting its data, thus providing time for the buffer to clear. Although this command is only valid for switch ports operating in half-duplex mode the remote switch (the one sending the data) can be operating in the full duplex mode.

To see the currently-negotiated duplex mode for ports whose links are up, use the command [show interface](#). To see the configured duplex mode (when different from the default), use the command [show running-config](#).

Examples To enable back pressure flow control on interfaces `port1.0.1-port1.0.24` enter the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1-port1.0.24
awplus(config-if)# backpressure on
```

To disable back pressure flow control on interface `port1.0.2` enter the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1-port1.0.24
awplus(config-if)# backpressure off
```

Validation Commands `show running-config`
`show interface`

Related Commands `duplex`

clear loop-protection counters

Use this command to clear the counters for the Loop Protection counters.

Syntax `clear loop-protection [interface <port-list>] counters`

Parameters	Description
<code>interface</code>	The interface whose counters are to be cleared.
<code><port-list></code>	A port, a port range, or an aggregated link.

Mode Exec and Privileged Exec

Example To clear the counter information:

```
awplus# clear loop-protection counters
awplus# clear loop-protection interface port1.0.1 counters
```

clear mac address-table static

Use this command to clear the filtering database of all statically configured entries for a selected MAC address, interface, or VLAN.

Syntax `clear mac address-table static`
`[address <mac-address>|vlan <vid>|interface <port>]`

Parameter	Description
vlan	Filtering database entries for the given VLAN.
interface	Filtering database entries for the given port.
<vid>	The VLAN IDs to be cleared from the database. Value range is 1-4094.
<port>	The port from which address entries will be cleared. This can be a single port, such as port1.1.4, a static channel group, such as sa3, or an LACP channel group, such as po4.
<mac-address>	The mac address to be cleared from the database.

Mode Privileged Exec

Usage Use this command with options to clear the filtering database of all entries made from the CLI for a given MAC address, interface or VLAN. Use this command without options to clear any entries made from the CLI. Compare this usage with [clear mac address-table dynamic command on page 15.5](#).

Examples This example shows how to clear all filtering database entries configured through the CLI.

```
awplus# clear mac address-table static
```

This example shows how to clear all filtering database entries for a given interface configured through the CLI.

```
awplus# clear mac address-table static interface port1.1.3
```

This example shows how to clear filtering database entries filtering database entries configured through the CLI for a given mac address.

```
awplus# clear mac address-table static address 0202.0202.0202
```

Related Commands [clear mac address-table dynamic](#)
[mac address-table static](#)
[show mac address-table](#)

clear mac address-table dynamic

Use this command to clear the filtering database of all entries learned for a selected MAC address, interface or VLAN.

Syntax `clear mac address-table dynamic`
`[address <mac-address>|vlan <vid>|interface <port>]`

Parameter	Description
interface	Filtering database entries for the given port.
<vid>	when filtering database entries are cleared based on VLANs. Value range is 1-4094.
<port>	The port from which address entries will be cleared. This can be a single port, such as port1.1.4, a static channel group, such as sa3, or an LACP channel group, such as po4.
<mac-address>	The mac address to be cleared from the database.

Mode Privileged Exec

Usage Use this command with options to clear the filtering database of all entries learned for a given MAC address, interface or VLAN. Use this command without options to clear any learned entries. Compare this usage and operation with the [clear mac address-table static command](#) on page 15.4.

Examples This example shows how to clear all dynamically learned filtering database entries for all interfaces, addresses, VLANs.

```
awplus# clear mac address-table dynamic
```

This example shows how to clear all dynamically learned filtering database entries when learned through switch operation for a given MAC address.

```
awplus# clear mac address-table dynamic address 0202.0202.0202
```

Related Commands [clear mac address-table static](#)
[show mac address-table](#)

clear port counter

Clears the packet counters of the port.

Syntax `clear port counter [<port>]`

Parameter	Description
<code><port></code>	The port number or range

Mode Exec and Privileged Exec

Example To clear the packet counter for `port1.0.1`

```
awplus# clear port counter port1.0.1
```

Related Commands [show platform table port](#)

debug platform packet

This command enables platform to CPU level packet debug.

This command can be used to trace packets sent and received by the CPU. If a timeout is not specified, then a default 5 minute timeout will be applied. If a timeout of 0 is specified, packet debug will be generated until the no debug platform packet command is used or another timeout value is specified. The timeout value applies to both send and receive debug and is updated whenever the debug platform packet command is used.

Use the no debug platform packet command to disable platform to CPU level packet debug. If the result means both send and receive packet debug are disabled, then any active timeout will be cancelled.

Syntax debug platform packet [recv|send] [timeout <0-3600>]
no debug platform packet [recv|send]

Parameter	Description
recv	Debug packets received.
send	Debug packets sent.
timeout	Stop debug after a specified time.
<0-3600>	The timeout period, specified in seconds.

Mode Privileged Exec and Global Configuration

Example To enable both receive and send packet debug for the default 5 minutes:

```
awplus# debug platform packet
```

To enable receive packet debug for 10 seconds:

```
awplus# debug platform packet recv timeout 10
```

To enable send packet debug with no timeout:

```
awplus# debug platform packet send timeout 0
```

To disable receive packet debug:

```
awplus# no debug platform packet recv
```

duplex

This command changes the duplex mode for the specified port.

By default, ports auto-negotiate duplex mode (except for 100Base-FX ports which do not support auto-negotiation, so default to full duplex mode).

To see the currently-negotiated duplex mode for ports whose links are up, use the command [show interface](#). To see the configured duplex mode (when different from the default), use the command [show running-config](#).

Syntax `duplex {auto|full|half}`

Parameter	Description
auto	Auto-negotiate duplex mode
full	Operate in full duplex mode only
half	Operate in half duplex mode only

Mode Interface Configuration

Usage Switch ports in a static or dynamic (LACP) channel group must have the same port speed and be in full duplex mode. Once switch ports have been aggregated into a channel group, you can set the duplex mode of all the switch ports in the channel group by applying this command to the channel group.

Examples To specify full duplex for `port1.0.4`, enter the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.4
awplus(config-if)# duplex full
```

To specify half duplex for `port1.0.4`, enter the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.4
awplus(config-if)# duplex half
```

To auto-negotiate duplex mode for `port1.0.4`, enter the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.4
awplus(config-if)# duplex auto
```

Related Commands [backpressure](#)
[speed](#)
[show interface](#)

flowcontrol

Use this command to enable flow control, and configure the flow control mode for the switch port.

Use the `no flowcontrol` command to disable flow control for the specified switch port.

Syntax

```
flowcontrol both
flowcontrol {send|receive} {off|on}
no flowcontrol
```

Parameter	Description
<code>both</code>	Use this parameter to specify send and receive flow control for the port.
<code>receive</code>	When the port receives pause frames, it temporarily stops (pauses) sending traffic.
<code>on</code>	Enable the specified flow control.
<code>off</code>	Disable the specified flow control.
<code>send</code>	When the port is congested (receiving too much traffic), it sends pause frames to request the other end to temporarily stop (pause) sending traffic.

Default By default, flow control is disabled.

Mode Interface Configuration

Usage The flow control mechanism specified by 802.3x is only for full duplex links. It operates by sending PAUSE frames to the link partner to temporarily suspend transmission on the link

Flow control enables connected Ethernet ports to control traffic rates during congestion by allowing congested nodes to pause link operation at the other end. If one port experiences congestion, and cannot receive any more traffic, it notifies the other port to stop sending until the condition clears. When the local device detects congestion at its end, it notifies the remote device by sending a pause frame. On receiving a pause frame, the remote device stops sending data packets, which prevents loss of data packets during the congestion period.

Flow control is not recommended when running QoS or ACLs, because the complex queuing, scheduling, and filtering configured by QoS or ACLs may be slowed by applying flow control.

For half-duplex links, an older form of flow control known as back pressure is supported. See the related [backpressure command on page 15.2](#).

Examples

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# flowcontrol receive on
```

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# flowcontrol send on
```

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# flowcontrol receive off
```

```
awplus# configure terminal
awplus(config)# interface port1.1.2
awplus(config-if)# flowcontrol send off
```

```
awplus# configure terminal
awplus(config)# interface port1.1.2
awplus(config-if)# flowcontrol both
```

```
awplus# configure terminal
awplus(config)# interface port1.1.2
awplus(config-if)# no flowcontrol
```

**Validation
Commands** [show running-config](#)

Related Commands [backpressure](#)

loop-protection

Use this command to enable the Loop Protection - loop detection - feature, and configure the detection mechanism parameters.

Syntax `loop-protection loop-detect [ldf-interval <period>] [ldf-rx-window <frames>]`

`no loop-protection`

Parameter	Description
<code>ldf-interval</code>	The time (in seconds) between successive loop-detect frames being sent.
<code><period></code>	A period between 5 and 600 seconds. The default is 10 seconds.
<code>ldf-rx-window</code>	The number of transmitted loop detection frames whose details are held for comparing with frames arriving at the same port.
<code><frames></code>	A value for the window size between 1 and 5 frames. The default is 3 frames.
<code>no</code>	This variant of the command disables the loop protection feature.

Mode Global Configuration

Default `no loop-protection`

Usage Use this command to enable the Loop Protection feature, and configure the detection mechanism, and the detection mechanism parameters.

Example To enable the loop-detect mechanism on the switch, and generate loop-detect frames once every 5 seconds, use the command:

```
awplus# configure terminal
awplus(config)# loop-protection loop-detect ldf-interval 5
```

loop-protection action

Use this command to specify the protective action to apply when a network loop is detected.

Syntax `loop-protection action {learn-disable|link-down|log-only|
port-disable|vlan-disable|none}`

`no loop-protection action`

Parameter	Description
learn-disable	Disable MAC address learning
link-down	Block all traffic on a port (or aggregated link) that detected the loop, and take down the link.
log-only	Details of loop conditions are logged. No action is applied to the port (or aggregated link).
port-disable	Block all traffic on interface for which the loop occurred, but keep the link in the up state.
vlan-disable	Block all traffic for the VLAN on which the loop traffic was detected. Note that setting this parameter will also enable ingress filtering. This is the default action.
none	Applies no protective action.
no	This variant of the command resets the loop protection actions to default values.

Mode Interface Configuration

Default `loop-protection action vlan-disable`

Example To disable an interface (port1.0.4), and bring the link down, when a network loop is detected, use the command:

```
awplus# configure terminal
awplus(config)# interface port1.0.4
awplus(config-if)# loop-protection action link-down
```

Note: *Currently the learn-disable parameter is not supported. If specified, an error message will be displayed.*

loop-protection timeout

Use this command to specify the Loop Protection recovery action duration.

Syntax `loop-protection timeout <duration>`
`no loop-protection timeout`

Parameter	Description
<code><duration></code>	The time (in seconds) for which the configured action will apply before being disabled. This duration can be set between 1 and 86400 seconds (24 hours). The default is 7 seconds.
<code>no</code>	This variation of the command sets the loop protection timeout to the default value.

Mode Interface Configuration

Example To configure a loop protection action timeout of 10 seconds for `port1.0.4`, use the command:

```
awplus# configure terminal
awplus(config)# interface port1.0.4
awplus(config-if)# loop-protection timeout 10
```

mac address-table acquire

Use this command to enable or disable MAC address learning on the device.

To disable learning, use the `no` parameter with this command.

Syntax `mac address-table acquire`
`no mac address-table acquire`

Mode Global Configuration

Default Learning is enabled by default for all instances.

Examples

```
awplus# configure terminal
awplus(config)# mac address-table acquire
```

mac address-table ageing-time

Use this command to specify an ageing-out time for a learned MAC address. The learned MAC address will persist for at least the specified time.

The no mac address-table ageing-time command will reset the ageing-out time back to the default value of 300 seconds (5 minutes).

Syntax mac address-table ageing-time <ageing-timer> none
 no mac address-table ageing-time

Parameter	Description
<ageing-timer>	<10-1000000> The number of seconds of persistence.
none	Disable learned MAC address timeout.

Default The default ageing time is 300 seconds.

Mode Global Configuration

Examples

```
awplus# configure terminal
awplus(config)# mac address-table ageing-time 1000
awplus# configure terminal
awplus(config)# mac address-table ageing-time none
awplus# configure terminal
awplus(config)# no mac address-table ageing-time
```


mac address-table static

Use this command to statically configure the MAC address-table to forward or discard frames with a matching destination MAC address.

Syntax

```
mac address-table static <mac-addr> {forward|discard} interface
    <port> [vlan <vid>]

no mac address-table static <mac-addr> {forward|discard} interface
    <port> [vlan <vid>]
```

Parameter	Description
<mac-addr>	The destination MAC address in HHHH.HHHH.HHHH format.
<port>	The port to display information about. The port may be a switch port (e.g., port1.1.4), a static channel group (e.g., sa3), or an LACP channel group (e.g., po4).
<vid>	The VLAN ID. If you do not specify a VLAN, its value defaults to vlan 1.

Mode Global Configuration

Usage The mac address-table static command is only applicable to layer 2 switched traffic within a single VLAN. Do not apply the mac address-table static command to layer 3 switched traffic passing from one VLAN to another VLAN. Frames will not be discarded across VLANs because packets are routed across VLANs. This command only works on layer 2 traffic.

Examples

```
awplus# configure terminal

awplus(config)# mac address-table static 2222.2222.2222 forward
interface port1.1.4 vlan 3
```

Related Commands

- clear mac address-table static
- show mac address-table

mac address-table thrash-limit

Use this command to set the thrash limit on the switch or stack. Thrashing occurs when a MAC address table rapidly “flips” its mapping of a single MAC address between two subnets, usually as a result of a network loop.

Syntax `mac address-table thrash-limit <rate>`
`no mac address-table thrash-limit`

Parameter	Description
<code><rate></code>	sets the maximum thrash rate at which limiting is applied. This rate can be set between 5 and 255 MAC thrashing flips per second. Once the thrash limit rate is reached, the port is considered to be thrashing.
<code>no</code>	sets the thrash limit to its default value

Mode Global Configuration

Default no thrash limiting

Usage Use this command to limit thrashing on the selected port range.

Example To apply a thrash limit of 100 MAC address flips per second:

```
awplus# configure terminal
awplus(config)# mac address-table thrash-limit 100
```

Related Commands [show mac address-table thrash-limit](#)

mirror interface

Use this command to define a mirror port and mirrored (monitored) ports and direction of traffic to be mirrored. The port for which you enter interface mode will be the mirror port.

The destination port is removed from all VLANs, and no longer participates in other switching.

Use the no parameter with this command to disable port mirroring by the destination port on the specified source port.

Syntax `mirror interface <source-port-list> direction {both|receive|transmit}`
`no mirror interface <source-port-list>`

Parameter	Description
<code><source-port-list></code>	The source switch ports to mirror. A port-list can be: ■ a port (e.g. port1.2.12) ■ a continuous range of ports separated by a hyphen, e.g. port1.0.1-1.0.24 or port1.1.1-port1.1.24 ■ a comma-separated list of ports and port ranges, e.g. port1.0.1,port1.1.1-1.2.24 The source port list cannot include dynamic or static channel groups (link aggregators).
<code>direction</code>	Specifies whether to mirror traffic that the source port receives, transmits, or both.
<code>both</code>	Mirroring traffic both received and transmitted by the source port.
<code>receive</code>	Mirroring traffic received by the source port.
<code>transmit</code>	Mirroring traffic transmitted by the source port.

Mode Interface Configuration

Usage Use this command to send traffic to another device connected to the mirror port for monitoring.

See [“Port Mirroring” on page 14.17](#).

A mirror port cannot be associated with a VLAN. If a switch port is configured to be a mirror port, it is automatically removed from any VLAN it was associated with.

This command can only be applied to a single mirror (destination) port, not to a range of ports, nor to a static or dynamic channel group. Do not apply multiple interfaces with an interface command before issuing the mirror interface command. One interface may have multiple mirror interfaces.

Example To mirror traffic received and transmitted on port1.1.4 and port1.1.5 to destination port1.1.3, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.1.3
awplus(config-if)# mirror interface port1.1.4,port1.1.5
direction both
```

platform bist

This command performs a self test on the switch. This command tests the ASIC (Application Specific Integrated Circuit) memory.

Syntax platform bist instance {<0-127>|all} [full]

Parameter	Description
instance	ASIC (Application Specific Integrated Circuit) instance
<0-127>	ASIC instance number
all	All platform instances
full	Run full BIST tests

Mode Privileged Exec

Examples To run the full built in self test for all memory in the ASIC on the switch, issue the command:

```
awplus# platform bist instance all full
```

Related Commands [show platform bist](#)

platform vlan-stacking-tpid

This command specifies the Tag Protocol Identifier (TPID) value that applies to all frames that are carrying double tagged VLANs. All nested VLANs must use the same TPID value. (This feature is sometimes referred to as VLAN stacking or VLAN double-tagging.)

Syntax `platform vlan-stacking-tpid <tpid>`

Parameter	Description
<code><tpid></code>	The Ethernet type of the tagged packet, as a two byte hexadecimal number. Default: 0x8100

Mode Global Configuration

Examples To set the VLAN stacking TPID to 0x9100, use the following commands:

```
awplus# configure terminal
```

```
awplus(config)# platform vlan-stacking-tpid 9100
```

Related Commands [switchport vlan-stacking \(double tagging\)](#)
[show platform](#)
[show running-config](#)

polarity

This command sets the polarity on a switch port.

Ports auto-negotiate polarity by default.

Syntax `polarity {mdi|mdix|auto}`

Parameter	Description
mdi	Sets the polarity to MDI (medium dependent interface).
mdix	Sets the polarity to MDI-X (medium dependent interface crossover).
auto	The switch port sets the polarity automatically.

Mode Interface Configuration

Usage Note that if you override a port's auto-negotiation by setting a fixed speed and duplex mode, automatic MDI/MDI-X detection is also overridden.

Examples To set the polarity for `port1.0.7` to MDI, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.7
awplus(config-if)# polarity mdi
```

show flowcontrol interface

Use this command to display flow control information.

Syntax `show flowcontrol interface <port>`

Parameter	Description
<port>	Specifies the name of the port to be displayed.

Mode Exec and Privileged Exec

Output Figure 15-1: Example output from the show flowcontrol interface command for a specific interface

Port	Send	FlowControl	Receive	FlowControl	RxPause	TxPause
	admin	oper	admin	oper		
-----	-----	-----	-----	-----	-----	-----
port1.1.5	on	on	on	on	0	0

Example To display the flow control for the port1.1.5, use the command:

```
awplus# show flowcontrol interface port1.1.5
```

show interface switchport

Use this command to display VLAN information about each switch port.

Syntax `show interface switchport`

Mode Exec and Privileged Exec

Example

```
awplus# show interface switchport
```

Output The following is an output of this command displaying the characteristics of this switch ports.

```
awplus#show interface switchport
Interface name       : port1.1.1
Switchport mode     : access
Ingress filter       : enable
Acceptable frame types : all
Default Vlan        : 2
Configured Vlans     : 2

Interface name       : port1.1.2
Switchport mode     : trunk
Ingress filter       : enable
Acceptable frame types : all
Default Vlan        : 1
Configured Vlans     : 1 4 5 6 7 8
...
```


show loop-protection

Use this command to display the current loop protection setup for the device.

Syntax `show loop-protection [interface <port-list>] [counters]`

Parameter	Description
interface	The interface selected for display.
<port-list>	A port, a port range, or an aggregated link.
counters	Displays counter information for loop protection.

Mode Exec and Privileged Exec

Usage This command is used to display the current configuration and operation of the Loop Protection feature

Example To display the current configuration status for `port1.0.1`, use the command:

```
awplus# show loop-protection interface port1.0.1
```

Figure 15-2: Example output from the show loop-protection command

```

Loop-Detection:      Enabled
LDF Interval:       10 [sec]
Interface:          port1.0.1
Action:             port-disable
Timeout:            300 [sec]
Vlan:               1
Status:             Blocking
Timeout Remaining:  115 [sec]
Vlan:               2
Status:             Normal
Timeout Remaining:  0 [sec]
```

To display the counter information for `port1.0.1`, use the command:

```
awplus# show loop-protection interface port1.0.1 counters
```

Figure 15-3: Example output from the show loop-protection interface counters command for port1.0.1

```

Interface:          port1.0.1
Vlan:               1
LDF Tx:             3
LDF Rx:             1
Invalid LDF Rx:     1
Action:             1
Vlan:               2
LDF Tx:             3
LDF Rx:             0
Invalid LDF Rx:     0
Action:             0
```

show mac address-table

Use this command to display the mac address-table for all configured VLANs.

Syntax `show mac address-table`

Mode Exec and Privileged Exec

Usage The show mac address-table command is only applicable to view a mac address-table for layer 2 switched traffic within VLANs.

Example To display the mac address-table, use the following command:

```
awplus# show mac address-table
```

Output See the below sample output captured when there was no traffic being switched:

```
awplus#show mac address-table

VLAN port          mac                type
1     unknown      0000.cd28.0752    forward
ARP   -             0000.cd00.0000    forward
```

See the sample output captured when packets were switched and mac addresses were learnt:

```
awplus#show mac address-table

VLAN port          mac                type
1     unknown      0000.cd28.0752    forward
1     port1.0.11    0030.846e.9bf4    forward
1     port1.0.9     0030.846e.bac7    forward
ARP   -             0000.cd00.0000    forward
```

Note the new mac addresses learnt for port1.0.9 and port1.0.11 added as dynamic entries.

Note the first column of the output below shows VLAN IDs if multiple VLANs are configured:

```
awplus#show mac address-table

VLAN port          mac                type
1     unknown      0000.cd28.0752    forward
1     port1.0.9     0030.846e.bac7    forward
2     unknown      0000.cd28.0752    forward
2     port1.0.11    0030.846e.9bf4    forward
ARP   -             0000.cd00.0000    forward
```

Also note manually configured static mac-addresses are shown to the right of the type column:

```
awplus(config)#mac address-table static 0000.1111.2222 for int
port1.0.11 vlan 2
awplus(config)#end
awplus#
awplus#show mac address-table
```

VLAN	port	mac	type	
1	unknown	0000.cd28.0752	forward	static
1	port1.0.9	0030.846e.bac7	forward	dynamic
2	port1.0.11	0000.1111.2222	forward	static
2	unknown	0000.cd28.0752	forward	static
2	port1.0.11	0030.846e.9bf4	forward	dynamic
ARP	-	0000.cd00.0000	forward	statics

Related Commands

- [clear mac address-table dynamic](#)
- [clear mac address-table static](#)
- [mac address-table static](#)

show mac address-table thrash-limit

Use this command to display the current thrash limit set for all interfaces on the device.

Syntax `show mac address-table thrash-limit`

Mode Exec and Privileged Exec

Example To display the current, use the following command:

```
awplus# show mac address-table thrash-limit
```

```
% Thrash-limit 7 movements per second
```

Related Commands [mac address-table thrash-limit](#)

show mirror

Use this command to display the status of all mirrored ports.

Syntax `show mirror`

Mode Exec and Privileged Exec

Example To display the status of all mirrored ports, use the following command:

```
awplus# show mirror
```

Output Figure 15-4: Example output from the **show mirror** command

```
Mirror Test Port Name: port1.1.1
Mirror option: Enabled
Mirror direction: both
Monitored Port Name: port1.1.2
Mirror Test Port Name: port1.1.3
Mirror option: Enabled
Mirror direction: receive
Monitored Port Name: port1.1.4
Mirror Test Port Name: port1.1.3
Mirror option: Enabled
Mirror direction: receive
Monitored Port Name: port1.1.1
Mirror Test Port Name: port1.1.1
Mirror option: Enabled
Mirror direction: receive
Monitored Port Name: port1.1.3
Mirror Test Port Name: port1.1.1
Mirror option: Enabled
Mirror direction: transmit
Monitored Port Name: port1.1.4
```

show mirror interface

Use this command to display port mirroring configuration for a mirrored (monitored) switch port.

Syntax `show mirror interface <port>`

Parameter	Description
<port>	The monitored switch port to display information about.

Mode Interface Configuration, Privileged Exec, and Exec.

Example To display port mirroring configuration for the `port1.0.4`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.4
awplus(config-if)# show mirror interface port1.0.4
```

Output Figure 15-5: Example output from the **show mirror interface** command

```
Mirror Test Port Name: port1.0.3
Mirror option: Enabled
Mirror direction: both
Monitored Port Name: port1.0.4
```

show platform

This command displays the settings configured using the platform commands.

Syntax `show platform`

Parameter	Description
show	Show running system information
platform	Information held in the switch-silicon tables.

Mode Exec and Privileged Exec

Example To check the settings configured with platform commands on the switch, use the following command:

```
awplus# show platform
```

Output Figure 15-6: Example output from the show platform command

Vlan-stacking TPID	0x8100

Parameter	Description
Vlan-stacking TPID	The value of the TPID set in the Ethernet type field when a frame has a double VLAN tag.

Related Commands `platform vlan-stacking-tpid`

show platform bist

This command displays the result of a previously run BIST (Built In Self Test) on the switch.

Syntax `show platform bist`

Parameter	Description
show	Show running system information
platform	Information held in the switch-silicon tables.
bist	Built In Self Test

Mode Privileged Exec

Examples To show the result of a previously run BIST on the switch, issue the following command:

```
awplus# show platform bist
```

```
Platform Built In Self Test Results
Switch Instance 0 ..... Passed
00  forward  static
```

Related Commands [platform bist](#)

show platform classifier statistics utilization brief

This command displays the total memory space, and free memory space of CAM (Content-Addressable Memory).

Syntax `show platform classifier statistics utilization brief`

Parameter	Description
<code>show</code>	Show running system information
<code>platform</code>	Information held in the switch-silicon tables.
<code>statistics utilization</code>	Display utilization statistics for various platform functions, such as ACLs QoS etc.

Mode Privileged Exec

Examples To display the platform classifier utilization statistics, use the following command:

```
awplus# show platform classifier statistics utilization brief
```

Figure 15-7: Output from the show platform classifier statistics utilization brief, with the DOS detection feature disabled.

```
> show platform classifier statistics utilization brief
[Instance 3.0]
(Port1.0.1-1.0.24)
Number of Entries:
Policy Type      Group ID    Used / Total
-----
ACL              1476395009   0 / 122 ( 0%)
DoS              -1          0 /   0 ( 0%)
VLAN Counter     -1          0 /   0 ( 0%)
QoS              0 / 768 ( 0%)

[Instance 3.1]
(Port1.0.25-1.0.48)
Number of Entries:
Policy Type      Group ID    Used / Total
-----
ACL              1476395009   0 / 122 ( 0%)
DoS              -1          0 /   0 ( 0%)
VLAN Counter     -1          0 /   0 ( 0%)
QoS              2 / 768 ( 0%)
```


Figure 15-8: Output from the show platform classifier statistics utilization brief, with the DOS detection feature enabled.

```
> show platform classifier statistics utilization brief
[Instance 3.0]
[Port1.0.1-1.0.24]
Number of Entries:
Policy Type      Group ID      Used / Total
-----
ACL              1476395009    0 / 122 ( 0%)
DoS              1476395011    0 / 128 ( 0%)
VLAN Counter     -1            0 / 0 ( 0%)
QoS              0 / 640 ( 0%)

[Instance 3.1]
[Port1.0.25-1.0.48]
Number of Entries:
Policy Type      Group ID      Used / Total
-----
ACL              1476395009    0 / 122 ( 0%)
DoS              1476395011    1 / 128 ( 0%)
VLAN Counter     -1            0 / 0 ( 0%)
QoS              2 / 640 ( 0%)
                  1            2 / 128 ( 1%)
```

show platform table port

This command displays the various port registers or platform counters for specified switchports.

Syntax `show platform table port [<port-list>|counters]`

Parameter	Description
port	show the ports
platform	Information held in the switch-silicon tables
<port-list>	The ports to display information about. A port-list can be: ■ a switch port (e.g. port1.2.12) a static channel group (e.g., sa3) or a dynamic (LACP) channel group (e.g., po3) ■ a continuous range of ports separated by a hyphen, e.g., port1.0.1-1.0.24 or port1.1.1-port1.1.24 or po1-po4 ■ a comma-separated list of ports and port ranges, e.g. port1.0.1,port1.1.1-1.2.24. Do not mix switch ports, static channel groups, and LACP channel groups in the same list.
counters	show the platform counters

Mode Exec and Privileged Exec

Examples To display table counters for port1.0.1 and port1.0.2 use the following command:

```
awplus# show platform table port port1.0.1-port1.0.2
```

Output Figure 15-9: Example output from the **show platform table** command

```
awplus#show platform table port port1.0.1
Phy register value for port1.0.1 (ifindex: 5001)

00:1140 01:7949 02:0020 03:60B1 04:01E1 05:0000 06:0004 07:2001
08:0000 09:0600 10:0000 11:0000 12:0000 13:0000 14:0000 15:0000
16:0000 17:0000 18:0000 19:0000 20:0000 21:0000 22:0000 23:0000
24:0000 25:0000 26:0000 27:0000 28:0000 29:0000 30:0000 31:0000

Port configuration for lport 0x08001000:
  enabled: 1
  loopback: 0
  link: 0
  speed: 0 max speed: 1000
  duplex: 0
  linkscan: 2
  autonegotiate: 1
  master: 2
  tx pause: 1 rx pause: 1
  untagged vlan: 1
  vlan filter: 3
  stp state: 1
  learn: 5
  discard: 0
  max frame size: 1522
  MC Disable SA: no
  MC Disable TTL: no
  MC egress untag: 0
  MC egress vid: 0
  MC TTL threshold: -1
```

Output Figure 15-10: Example output from the **show platform table counters** command

```
awplus#show platform table port port1.0.1 counters

Switch Port Counters
-----

Port port1.0.1 Ethernet MAC counters:
Combined receive/transmit packets by size (octets) counters:
 64                               0 1024 - MaxPktSz           0
 65 - 127                         0 1519 - 1522           0
128 - 255                         0 1519 - 2047           0
256 - 511                         0 2048 - 4095           0
512 - 1023                       0 4096 - 9216           0

General Counters:
Receive                               Transmit
Octets                               0 Octets               0
Pkts                                0 Pkts                 0
FCSErrors                           0
MulticastPkts                       0 MulticastPkts         0
BroadcastPkts                       0 BroadcastPkts        0
PauseMACCtlFrms                     0 PauseMACCtlFrms      0
OversizePkts                        0
Fragments                           0
Jabbers                             0
UnsupportOpcode                     0
AlignmentErrors                     0
SymErDurCarrier                     0
CarrierSenseErr                     0
UndersizePkts                       0
                                     FrameWDeferdTx          0
                                     FrmWExcesDefer         0
                                     SingleCollsnFrm       0
                                     MultCollsnFrm         0
                                     LateCollisions        0
                                     ExcessivCollsns       0
                                     Collisions             0

Layer 3 Counters:
ifInUcastPkts                       0 ifOutUcastPkts        0
ifInDiscards                         0 ifOutErrors            0
ipInHdrErrors                        0

Miscellaneous Counters:
DropEvents                           0
ifOutDiscards                        0
MTUExcdDiscard                       0
-----
```

Table 15-1: Parameters in the output from the **show platform table** command

Parameter	Meaning
Ethernet MAC counters	
Combined receive/transmit packets by size (octets) counters	Number of packets in each size range received and transmitted.
64	Number of 64 octet packets received and transmitted.
65 - 127	Number of 65 - 127 octet packets received and transmitted.
128 - 255	Number of 128 - 255 octet packets received and transmitted.
256 - 511	Number of 256 - 511 octet packets received and transmitted.
512 - 1023	Number of 512 - 1023 octet packets received and transmitted.
1024 - MaxPktSz	Number of packets received and transmitted with size 1024 octets to the maximum packet length.
1519 - 1522	Number of 1519 - 1522 octet packets received and transmitted.
1519 - 2047	Number of 1519 - 2047 octet packets received and transmitted.
2048 - 4095	Number of 2048 - 4095 octet packets received and transmitted.
4096 - 9216	Number of 4096 - 9216 octet packets received and transmitted.
General Counters	
Receive	Counters for traffic received.
Octets	Number of octets.
Pkts	Number of packets.
FCSErrors	Number of FCS (Frame Check Sequence) error events.
MulticastPkts	Number of multicast packets.
BroadcastPkts	Number of broadcast packets.
PauseMACCtrlFrms	Number of Pause MAC Control Frames received.
OversizePkts	Number of oversize packets.
Fragments	Number of fragments.
Jabbers	Number of jabber frames.
UnsupportOpcode	Number of MAC Control frames with unsupported opcode.
AlignmentErrors	Receive Alignment Error Frame Counter.
SysErDurCarrier	Receive Code Error Counter.
CarrierSenseErr	Receive False Carrier Counter.
UndersizePkts	Number of undersized packets.
Transmit	Counters for traffic transmitted.
Octets	Number of octets.
Pkts	Number of packets.
MulticastPkts	Number of multicast packets.
BroadcastPkts	Number of broadcast packets.

Table 15-1: Parameters in the output from the **show platform table** command

Parameter	Meaning
PauseMACCtlFrms	Number of Pause MAC Control Frames transmitted.
OversizePkts	Number of oversize packets.
FrameWDeferrdTx	Transmit Single Deferral Frame counter.
FrmWExcesDefer	Transmit Multiple Deferral Frame counter.
SingleCollsnFrm	Transmit Single Collision Frame counter.
MultCollsnFrm	Transmit Multiple Collision Frame counter.
LateCollisions	Transmit Late Collision Frame counter.
ExcessivCollsns	Transmit Excessive Collision Frame counter.
Collisions	Transmit Total Collision counter
Layer 3 Counters:	
ifInUcastPkts	Inbound interface Unicast counter.
ifInDiscards	Inbound interface Discarded Packets counter.
ipInHdrErrors	Inbound interface Header Errors counter.
ifOutUcastPkts	Outbound interface Unicast counter.
ifOutErrors	Outbound interface Error counter.
Miscellaneous Counters	
DropEvents	Drop Event counter
ifOutDiscards	Outbound interface Discarded Packets counter.
MTUExcdDiscard	Receive MTU Check Error Frame Counter

show port-security interface

Shows the current configuration and the switch port status.

Syntax `show port-security interface <port>`

Parameter	Description
show	Show running system information
port-security	Port Security
interface	Interface
<port>	The port to display information about. The port may be a switch port (e.g., port1.1.4), a static channel group (e.g., sa3), or an LACP channel group (e.g., po4).

Mode Exec and Privileged Exec

Example To see the port-security status on port1.0.1, use the following command:

```
awplus# show port-security interface port1.0.1
```

Output Figure 15-11: Example output from the show port-security interface command for port 1.0.1

```
Port Security configuration
Security Enabled           : YES
Port Status                : ENABLED
Violation Mode             : TRAP
Aging                     : OFF
Maximum MAC Addresses     : 3
Current Learned Addresses  : 1
Lock Status               : UNLOCKED
Security Violation Count   : 0
Last Violation Source Address: None
```

show port-security intrusion

Shows the intrusion list. If the port is not give, entire intrusion table is shown.

Syntax `show port-security intrusion [interface <port>]`

Parameter	Description
show	Show running system information
port-security	Port Security
intrusion	Display intrusion list
interface	Specify a port
<port>	The port to display information about. The port may be a switch port (e.g., port1.1.4), a static channel group (e.g., sa3), or an LACP channel group (e.g., po4).

Mode Exec and Privileged Exec

Example To see the intrusion list on port1.0.1, use the following command:

```
awplus# show port-security intrusion interface port1.0.1
```

Output Figure 15-12: Example output from the show port-security intrusion command for port 1.0.1

```
Port Security Intrusion List
Interface: port1.0.1 -3 intrusion(s) detected
11-22-33-44-55-04 11-22-33-44-55-06 11-22-33-44-55-08
```

show storm-control

Use this command to display storm control information for all interfaces or a particular interface.

Syntax `show storm-control [<port>]`

Parameter	Description
<port>	The port to display information about. The port may be a switch port (e.g., port1.1.4), a static channel group (e.g., sa3), or an LACP channel group (e.g., po4).

Mode Exec and Privileged Exec

Example 1 To display storm control information for port1.0.2, use the following command:

```
awplus# show storm-control port1.0.2
```

Output Figure 15-13: Example output from the **show storm-control** command for port1.0.2

Port	BcastLevel	McastLevel	DlfLevel
port1.1.2	40. 0%	100. 0%	100. 0%

Example 2 To display storm control information for all ports, use the following command:

```
awplus# show storm-control
```

Output Figure 15-14: Example output from the **show storm-control** command for all ports

```
awplus#show storm-control
Port          BcastLevel  McastLevel  DlfLevel
port1.0.1      100.0%      100.0%      100.0%
port1.0.2      100.0%      100.0%      100.0%
port1.0.3      100.0%      100.0%      100.0%
port1.0.4      100.0%      100.0%      100.0%
port1.0.5      100.0%      100.0%      100.0%
port1.0.6      100.0%      100.0%      100.0%
port1.0.7      100.0%      100.0%      100.0%
port1.0.8      100.0%      100.0%      100.0%
port1.0.9      100.0%      100.0%      100.0%
port1.0.10     100.0%      100.0%      100.0%
port1.0.11     100.0%      100.0%      100.0%
port1.0.12     100.0%      100.0%      100.0%
port1.0.13     100.0%      100.0%      100.0%
port1.0.14     100.0%      100.0%      100.0%
port1.0.15     100.0%      100.0%      100.0%
port1.0.16     100.0%      100.0%      100.0%
port1.0.17     100.0%      100.0%      100.0%
port1.0.18     100.0%      100.0%      100.0%
port1.0.19     100.0%      100.0%      100.0%
port1.0.20     100.0%      100.0%      100.0%
port1.0.21     100.0%      100.0%      100.0%
port1.0.22     100.0%      100.0%      100.0%
port1.0.23     100.0%      100.0%      100.0%
port1.0.24     100.0%      100.0%      100.0%
```


Related Commands [storm-control level](#)

speed

This command changes the speed of the specified port.

By default, ports auto-negotiate speed (except for 100Base-FX ports which do not support auto-negotiation, so default to 100M).

To see the currently-negotiated speed for ports whose links are up, use the command [show interface](#). To see the configured speed (when different from the default), use the command [show running-config](#).

Syntax `speed {auto|10|100|1000}`

The following table shows the speed options for each type of port.

Port type	Speed Options
non-SFP RJ-45 copper ports	auto (default) 10 100 1000
supported tri-speed copper SFPs	auto (default) 10 100 1000
100Mb fibre SFPs	100
1000Mb fibre SFPs	auto (default) 1000
XFP modules	auto (default) Note that XFG is fixed speed and runs at 10G. For example, XFG cannot be stepped down to run at the same port speed as a 1G SFP.

Mode Interface Configuration

Usage Switch ports in a static or dynamic (LACP) channel group must have the same port speed and be in full duplex mode. Once switch ports have been aggregated into a channel group, you can set the speed of all the switch ports in the channel group by applying this command to the channel group.

Examples To set the speed of a tri-speed port to 100Mbps, enter the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.4
awplus(config-if)# speed 100
```

To return the port to auto-negotiating its speed, enter the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.4
awplus(config-if)# speed auto
```

Related Commands [duplex](#)
[show interface](#)

storm-control level

Use this command to specify the threshold level for broadcasting, multicast, or destination lookup failure (DLF) traffic for the port. Storm control limits the specified traffic type to the specified threshold.

Use the no parameter with this command to disable storm control for broadcast, multicast or DLF traffic.

Syntax `storm-control {broadcast|multicast|dlf} level <level>`
`no storm-control {broadcast|multicast|dlf} level`

Parameter	Description
<level>	<0-100> Specifies the threshold as a percentage of the maximum port speed.
broadcast	Applies the storm control to broadcast frames.
multicast	Applies the storm control to multicast frames.
dlf	Applies the storm control to destination lookup failure traffic.

Default By default, storm control is disabled.

Mode Interface Configuration

Usage Flooding techniques are used to block the forwarding of unnecessary flooded traffic. A packet storm occurs when a large number of broadcast packets are received on a port. Forwarding these packets can cause the network to slow down or time out.

Example To limit broadcast traffic on port1.0.2 to 30% of the maximum port speed, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# storm-control broadcast level 30
```

Related Commands [show storm-control](#)

switchport port-security

Enables the port-security feature. This feature is also known as port-based learn limit. It allows the user to set the maximum number of MAC addresses that each port can learn.

Use the `no switchport port-security` command to disable the port-security feature.

Syntax `switchport port-security`
`no switchport port-security`

Parameter	Description
<code>no</code>	Negate a command or set its defaults
<code>switchport</code>	Set the switching characteristics of the Layer2 interface
<code>port-security</code>	Port-based learning limits

Mode Interface Configuration

Example To enable the port-security feature on `port1.0.4`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.4
awplus(config-if)# switchport port-security
```

To disable port-security feature on `port1.0.4`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.4
awplus(config-if)# no switchport port-security
```

switchport port-security aging

Sets the port-security MAC to time out.

Use the no switchport port-security aging command to set the port-security to not time out.

Syntax switchport port-security aging
 no switchport port-security aging

Parameter	Description
no	Negate a command or set its defaults
switchport	Set the switching characteristics of the Layer2 interface
port-security	Port-based learning limits
aging	Enables the MAC aging

Mode Interface Configuration

Example To set the MAC to time out, use the following command:

```
awplus# switchport port-security aging
```

To unset the MAC time out, use the following command:

```
awplus# no switchport port-security aging
```

switchport port-security maximum

Sets the maximum MAC address that each port can learn.

Use the `no switchport port-security maximum` command to unset the maximum number of MAC addresses that each port can learn. This is same as setting the maximum number to 0. This command also resets the intrusion list table.

Syntax `switchport port-security maximum <0-256>`
`no switchport port-security maximum`

Parameter	Description
<code>no</code>	Negate a command or set its defaults
<code>switchport</code>	Set the switching characteristics of the Layer2 interface
<code>port-security</code>	Port-based learning limits
<code>maximum</code>	Maximum number of address to learn
<code><0-256></code>	Maximum number of address to learn

Mode Interface Configuration

Example To learn 3 MAC addresses on `port1.0.4`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.4
awplus(config-if)# switchport port-security maximum 3
```

To remove the MAC learning limit on `port1.0.4`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.4
awplus(config-if)# no switchport port-security maximum
```

switchport port-security violation

Sets the violation action for a switch port. The port action can be either shutdown, restrict or protect. If shutdown is set, the physical link will be disabled and "shutdown" will be shown in the config. If restrict is set, the packet from the un-authorized MAC will be discarded and SNMP TRAP will be generated to alert management. If protect is set, the packet will simply be discarded by the packet processor silently.

The no switchport port-security violation command sets the violation action to default. The default violation action is protect.

Syntax switchport port-security violation {shutdown|restrict|protect}
no switchport port-security violation

Parameter	Description
no	Negate a command or set its defaults
violation	Action taken when the port exceeds the learning limits
shutdown	Disable the port
restrict	Alert the network administrator
protect	Discard the packet

Mode Interface Configuration

Example To set the action to be shutdown on port1.0.4, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.4
awplus(config-if)# switchport port-security violation shutdown
```

To set the port-security action to the default (protect) on port1.0.4, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.4
awplus(config-if)# no switchport port-security violation
```

thrash-limiting

Sets and configures the thrash limit action that will be applied to any port on the switch when a thrashing condition is detected. The thrash-limiting timeout specifies the time, in seconds, for which the thrash action is employed.

Syntax `thrash-limiting {[action {learn-disable|link-down|port-disable|vlan-disable|none}} [timeout <0-86400>]}`
`no thrash-limiting {action|timeout}`

Parameter	Description
thrash-limiting	Set mac address thrash limiting
action	The mac thrashing detected action. The default is vlan-disable.
learn-disable	Disable mac address learning
link-down	Block all traffic on an interface - link down
port-disable	Block all traffic on an interface - link remains up
vlan-disable	Block all traffic on a vlan Note that setting this parameter will also enable ingress filtering.
none	No thrash action
timeout	Set the duration for the thrash action
<0-86400>	The duration of the applied thrash action in seconds. The default is 1 seconds.
no	Sets either the selected thrash limiting action or its timeout to the default value.

Mode Interface Mode

Example To set the action to learn disable for port1.0.4, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# thrash-limiting action learn-disable
```

To set the thrash limiting timeout to 5 seconds, use the following command:

```
awplus(config-if)# thrash-limiting timeout 5
```

To set the thrash limiting action to its default, use the following command:

```
awplus(config-if)# no thrash-limiting action
```

To set the thrash limiting timeout to its default, use the following command:

```
awplus(config-if)# no thrash-limiting timeout
```


Chapter 16: VLAN Introduction



Introduction.....	16.2
Virtual LANs (VLANs).....	16.2
Configuring VLANs.....	16.3
VLAN Double Tagging (VLAN Stacking).....	16.5
How Double-Tagged VLANs Work.....	16.5
VLAN Rules for Double Tagging.....	16.5
Restrictions when using Double-Tagged VLANs.....	16.6
Configuring Double-Tagged VLANs.....	16.6
Private VLANs.....	16.8
Membership Rules.....	16.8
Promiscuous Ports.....	16.9
Host Ports.....	16.9
Private VLAN Operation.....	16.10
Example Configuration.....	16.11
VLAN Statistics.....	16.13
Counter Operation.....	16.13

Introduction

This chapter describes Virtual LANs (VLAN), VLAN features and configuration on the switch. For detailed descriptions of commands used to configure VLANs, see [Chapter 17, VLAN Commands](#). For information about Voice VLAN and LLDP-MED, see [Chapter 77, LLDP Introduction](#).

Virtual LANs (VLANs)

A Virtual LAN (VLAN) is a logical, software-defined subnetwork. It allows similar devices on the network to be grouped together into one broadcast domain, irrespective of their physical position in the network. Multiple VLANs can be used to group workstations, servers, and other network equipment connected to the switch, according to similar data and security requirements.

Decoupling logical broadcast domains from the physical wiring topology offers several advantages, including the ability to:

- Move devices and people with minimal, or no, reconfiguration
- Change a device's broadcast domain and access to resources without physically moving the device, by software reconfiguration or by moving its cable from one switch port to another
- Isolate parts of the network from other parts, by placing them in different VLANs
- Share servers and other network resources without losing data isolation or security
- Direct broadcast traffic to only those devices which need to receive it, to reduce traffic across the network
- Connect 802.1Q-compatible switches together through one port on each switch

Devices that are members of the same VLAN only exchange data with each other through the switch's layer 2 switching capabilities. To exchange data between devices that are located in different VLANs, the switch's layer 3 (routing) capabilities are used. The switch passes VLAN status information to the Internet Protocol (IP) module that indicates whether a VLAN is up or down. This information is used to determine route availability.

The device supports up to 4094 VLANs (the maximum allowed by the VID field in the 802.1Q tag). On some devices a few of these VLANs may be reserved for management purposes. When the switch is first powered up (and therefore unconfigured), it creates a default VLAN with a VID of 1 and an interface name of *vlan1*. In this initial condition, the switch attaches all its ports to this default VLAN. The default VLAN cannot be deleted, and ports can only be removed from it if they also belong to at least one other VLAN. If all the devices on the physical LAN belong to the same logical LAN, that is, the same broadcast domain, then the default settings will be acceptable, and no additional VLAN configuration is required.

Configuring VLANs

Defaults By default, all switch ports are in access mode, are associated with the default VLAN (*vlan1*), and have ingress filtering on. You cannot delete *vlan1*.

VLAN names When you create a VLAN ([vlan command on page 17.24](#)), you give it a numerical VLAN Identifier (VID)—a number from 2 to 4094, which is included in VLAN-tagged Ethernet frames to and from this VLAN. You may also give it an arbitrary alphanumeric name containing a meaningful description, which is not transmitted to other devices.

When referring to a VLAN, some commands require the VLAN to be specified by its VID while some commands require it to be specified by its interface name: *vlan<VID>*. In command output, the VLAN may be referred to by its VID, its interface name (*vlan<VID>*), or its VLAN name (the arbitrary alphanumeric string).

You can name a VLAN with a string containing “vlan” and its VLAN Identifier (VID). To avoid confusion, we recommend not naming it “vlan” followed by any number different from its VID.

Access mode A switch port in access mode sends untagged Ethernet frames, that is, frames without a VLAN tag. Each port is associated with one VLAN (the port-based VLAN, by default, *vlan1*), and when it receives untagged frames, it associates them with the VID of this VLAN. You can associate the port with another VLAN created by the [vlan](#) command, and this removes it from the default VLAN ([switchport access vlan](#) command).

Use access mode for any ports connected to devices that do not use VLAN tagging, for instance PC workstations.

Trunk mode A switch port in trunk mode is associated with one or more VLANs for which it transmits VLAN-tagged frames, and for which it identifies incoming tagged frames with these VIDs.

To allow a switch port to distinguish and identify traffic from different VLANs, put it in trunk mode ([switchport mode trunk](#)), and add the VLANs ([switchport trunk allowed vlan](#)). Use trunk mode for ports connected to other switches which send VLAN-tagged traffic from one or more VLANs.

A trunk mode port may also have a *native* VLAN (by default *vlan1*), for which it transmits untagged frames, and with which it associates incoming untagged frames ([switchport trunk native vlan](#)).

Mirror ports A mirror port cannot be associated with a VLAN. If a switch port is configured to be a mirror port ([mirror interface command on page 15.17](#)), it is automatically removed from any VLAN it was associated with.

VLANs and channel groups All the ports in a channel group must have the same VLAN configuration: they must belong to the same VLANs and have the same tagging status, and can only be operated on as a group.

Table 16-1: Configuration procedure for VLANs

Create VLANs

<code>awplus# configure terminal</code>	Enter Configuration mode.
<code>awplus(config)# vlan database</code>	Enter VLAN Database Configuration mode.
<code>awplus(config-vlan)# vlan <vid> [name <vlan-name>] [state {enable disable}] or vlan <vid-range> [state {enable disable}]</code>	Create VLANs.

Associate switch ports with VLANs

<code>awplus(config-vlan)# interface <port-list></code>	Associate switch ports in access mode with VLANs:
<code>awplus(config-if)# switchport access vlan <vlan-id></code>	■ Enter Interface Configuration mode for the switch ports that will be in access mode for a particular VLAN. ■ Associate the VLAN with these ports in access mode.
	Repeat for other VLANs and ports in access mode.
<code>awplus(config-if)# interface <port-list></code>	Associate switch ports in trunk mode with VLANs.
<code>awplus(config-if)# switchport mode trunk [ingress-filter {enable disable}]</code>	Enter Interface Configuration mode for all the switch ports that will be in trunk mode for a particular set of VLAN.
	Set these switch ports to trunk mode.
<code>awplus(config-if)# switchport trunk allowed vlan all or switchport trunk allowed vlan add <vid-list></code>	Allow these switch ports to trunk this set of VLANs.
<code>awplus(config-if)# switchport trunk native vlan {<vid> none}</code>	By default, a trunk mode switch port's native VLAN—the VLAN that the port uses for untagged packets—is VLAN 1. Some control packets are untagged, including MSTP CIST BPDUs. If required, change the native VLAN from the default. The new native VLAN must already be allowed for this switch port.
<code>awplus(config-if)# exit</code>	Return to Global Configuration mode.
<code>awplus(config)# exit</code>	Return to Privileged Exec mode.
<code>awplus# show vlan {all brief dynamic static}<1-4094></code>	Confirm VLAN configuration

VLAN Double Tagging (VLAN Stacking)

VLAN double tagging, also known as VLAN Stacking, Nested VLANs, or Q-in-Q VLANs, are used to operate a number of private Layer 2 networks within a single public Layer 2 network. This feature provides simple access infrastructure for network service providers to operate Metropolitan Area Networks (MANs) as commercial value added networks.

A nested VLAN implementation consists of the following port types:

- Provider ports - these connect to a service provider's Layer-2 network
- Customer edge ports - these connect to a customer's private Layer-2 network

How Double-Tagged VLANs Work

In a nested VLAN environment VLAN tagging exists at two levels:

- client tagging,
- service provider tagging.

When nested VLAN functionality is enabled, the service provider assigns to each of its clients, an individual 12 bit customer VID called an S-Tag. The S-Tag field has an identical structure to a conventional VLAN tag field.

The S-Tag is attached to a packet as it enters the service provider network at the customer edge port, and is removed as it leaves the destination customer edge port. From this point on, the S-Tag is used for transmission within the service provider, or public Layer-2, network. The VID that is used within the client's own network (now termed the C-Tag) is ignored by the service provider network and bridging is based on the value of the S-Tag. The ethertype of the S-Tag is set by changing the Tag Protocol Identifier (TPID).

Once the S-Tag is removed from the packet, it is forwarded "as is" out of the customer-edge port. The tagged status of the Customer port is ignored on egress.

VLAN Rules for Double Tagging

When double-tagged VLANs are created on the switch:

- a nested VLAN belongs to only one customer and can have multiple customer-edge ports
- a port must be either a customer-edge port or a provider port, but cannot be both

A service provider port:

- accepts only tagged packets
- transmits only tagged packets
- can be in many double-tagged VLANs

A customer edge port:

- accepts both tagged and untagged packets
- transmits both tagged and untagged packets
- can be a member of only one nested VLAN

Restrictions when using Double-Tagged VLANs

Restrictions when double-tagged VLANs are implemented are:

- Ethernet bridging is based on the S-Tag VID instead of the packet C-Tag VID. The packets C-Tag VID does not change
- ARP packet trapping is restricted.
- hardware filtering does not work above MAC address level

Configuring Double-Tagged VLANs

You need a special feature license to use double-tagged VLANs. Contact your authorized Allied Telesis distributor or reseller for more information.

To create the VLANs to be nested

Step 1: Create, and enable, service provider VLANs 10 and 20.

```
awplus# configure terminal
awplus(config)# vlan database
awplus(config-vlan)# vlan 10, 20 state enable
```

Step 2: Configure ports 1.0.1 and 102 as a provider-port members of VLAN 10 and 20.

```
awplus# configure terminal
awplus(config)# interface port port1.0.1-port1.0.2
awplus(config)# switchport mode trunk
awplus(config)# switchport trunk allowed vlan add 10
awplus(config)# switchport trunk allowed vlan add 20
awplus(config-if)# switchport vlan-stacking provider-port
```

Step 3: Configure port 1.0.3 as a customer edge port member of VLAN 10.

```
awplus# configure terminal
awplus(config)# interface port port1.0.3
awplus(config)# switchport mode access
awplus(config)# switchport access vlan 10
awplus(config-if)# switchport vlan-stacking customer-edge-port
```

Step 4: Configure port 1.0.4 as a customer edge port member of VLAN 20.

```
awplus# configure terminal
awplus(config)# interface port port1.0.4
awplus(config)# switchport mode access
awplus(config)# switchport access vlan 20
awplus(config-if)# switchport vlan-stacking customer-edge-port
```

Step 5: Set the Tag Protocol Identifier (TPID).

If you need to change the Tag Protocol Identifier (TPID) from its default (for VLAN stacking) of 0x8100 (specified as hex notation), use the following command. This example changes the TPID to 0x9100:

```
awplus(config)# platform vlan-stacking-tpid 9100
```

The nestedtpid parameter specifies the Ethernet type of the tagged packet. This is set to 0x8100 by default.

Note that this command specifies the TPID value that applies to all VLANs used for double-tagged VLANs (stacked VLANs). You cannot set individual TPID values for different VLANs within a multi double tagged VLAN network.

Private VLANs

Private VLANs combine the network advantages of conventional VLANs, with an added degree of privacy obtained by limiting the connectivity between selected ports.

An example application of a private VLAN would be a library in which user booths each have a PC with Internet access. In this situation it would usually be undesirable to allow communication between these individual PCs. Connecting the PC to ports within a private isolated VLAN would enable each PC to access the Internet or a library server via a single connection, whilst preventing access between the PCs in the booths.

Another application might be to use private VLANs to simplify IP address assignment. Ports can be isolated from each other whilst still belonging to the same subnet.

A private VLAN comprises the following components:

- a single promiscuous port (sometimes called an uplink port)
- one or more host ports (sometimes called private ports)
There are two types of host ports:
 - « **isolated ports**
These can only communicate with the promiscuous port that is associated with the isolated VLAN.
 - « **community ports**
These can communicate with their associated promiscuous port and other community ports within the community VLAN.
- a single primary VLAN
- one or more secondary VLANs
There are two types of secondary VLANs:
 - « **isolated VLANs** (
In this VLAN type, communication can only take place between each host port and its associated promiscuous port.
 - « **community VLANs**
In this VLAN type, communication can take place between host ports and between each host port and its associated promiscuous port.

Membership Rules

The following membership rules apply when creating and operating private VLANs

Each private VLAN:

- must contain one promiscuous port or (aggregated link)
- may contain multiple host ports
- can be configured to span switch instances
- can only contain either promiscuous or host ports.
- cannot use the default VLAN (vlan1)
- a private *isolated* VLAN can only contain a single promiscuous port
- a private *community* VLAN can contain more than one promiscuous port

A host port:

- can be a member of multiple private (community) VLANs, but all these VLANs must share the same promiscuous port
- cannot be a host port in some VLANs and a non-host port in others
- cannot be a promiscuous port in another VLAN

A promiscuous port:

- is a member of the primary VLAN and all its associated secondary VLANs
- cannot be a member of both private and non-private VLANs

A private or promiscuous port:

- may use any VLAN classification rule (port, subnet, or protocol)

Promiscuous Ports

A promiscuous port can communicate with all ports that are members of its associated secondary VLANs. Multiple promiscuous ports can exist in a primary VLAN, but only if the primary VLAN is only associated with community VLANs (that is, that there are no isolated VLANs associated with this port).

A promiscuous port is a member of the primary VLAN and all associated secondary VLANs. Its Port VID is set to the VLAN ID of the primary VLAN.

Host Ports

Host ports have two levels of connectivity depending on whether they exist in an isolated or a community VLAN.

Host ports within an isolated VLAN

These ports are only allowed to communicate with their VLAN's promiscuous port, even though they share their secondary (isolated) VLAN with other hosts. The host ports receive their data from the promiscuous port via the primary VLAN, and *individually* transmit their data to the promiscuous port via their common secondary VLAN.


Host ports within a community VLAN

These ports are able to communicate with both the promiscuous port and the other ports within the community VLAN that they are associated with. They receive their data from the promiscuous port via the primary VLAN, and transmit their data to both the promiscuous port and the other host ports (within their community VLAN) via their common secondary VLAN. However, the only external path from a community VLAN is from its promiscuous port.

Private VLAN Operation

A basic private VLAN operation is shown in [Figure 16-1](#). It comprises primary VLAN 20 plus three secondary VLANs, two community VLANs 21 and 22, and an isolated VLAN 23.

Figure 16-1: Private VLAN



The ports on this switch have the following configuration:

- Port 1.0.1 is the promiscuous port and is a member of the primary VLAN 20 and all its associated secondary VLANs.
- Ports 1.0.1 to 1.0.4 are members of the community VLAN 21 and are able to communicate with both the promiscuous port and all other ports in VLAN 21.
- Ports 1.0.10 to 1.0.12 are members of the community VLAN 22 and are able to communicate with both the promiscuous port and all other ports in VLAN 22.
- Ports 1.0.6 to 1.0.8 are members of the isolated VLAN 23. Each of these ports can only communicate with the promiscuous port.

Table 16-2: Private VLANs - Port Tagging

Port	Mode	Untagged VLAN Membership	PVID
1.0.1	Promiscuous	20, 21, 22, 23	20
1.0.2 to 1.0.4	Host	20, 21	21
1.0.10 to 1.0.12	Host	20, 22	22
1.0.6 to 1.0.8	Host	20, 23	23
1.0.5	Not members of the private VLAN		-
1.0.9	Not members of the private VLAN		-

Private VLANs operate within a single switch and comprise one primary VLAN plus a number of secondary VLANs. All data enters the private VLAN ports untagged. Using the example of figure [Figure 16-1](#), data enters the switch via the promiscuous port 1.0.1 and is forwarded to the host ports using VLAN 20, the primary VLAN. Data returning from the host ports to the promiscuous port (and exiting the switch) use the secondary VLAN associated with its particular host port, VLAN 21, 22, or 23 in the example. Thus the data flows into the switch via the primary VLAN and out of the switch via the secondary VLANs. This situation is not detected outside of the switch, because all its private ports are untagged. Note however, that data flowing between ports within the same community VLAN will do so using the VID of the community VLAN.

Portfast on Private VLANs

Within private VLANs, we recommend that you place all host ports into spanning-tree portfast mode and enable BPDU guard. Portfast assumes that because host ports will also be edge ports, they will have no alternative paths (loops) via other bridges. These ports are therefore allowed to move directly from the spanning-tree blocking state into the forwarding state, thus bypassing the intermediate states.

Applying BPDU guard is an extra precaution. This feature disables an edge port if it receives a BPDU frame, because receiving such a frame would indicate that the port has a connection to another network bridge.

For more information on BPDU guard and portfast, see their following commands:

- [spanning-tree portfast bpdu-filter command on page 19.41](#)
[spanning-tree portfast \(STP\) command on page 19.40](#)

Example Configuration

Step 1: Create the private VLANs

Create the four VLANs 20 to 23.

```
awplus# configure terminal
awplus(config)# vlan database
awplus(config-vlan)# vlan 20-23
```

Step 2: Set the private VLAN types

Set the VLANs to be private and either primary, community, or isolated.

```
awplus(config-vlan)# private-vlan 20 primary
awplus(config-vlan)# private-vlan 21 community
awplus(config-vlan)# private-vlan 22 community
awplus(config-vlan)# private-vlan 23 isolated
```

Step 3: Associate the secondary VLANs with the primary VLAN

```
awplus(config-vlan)# private-vlan 20 association add 21
awplus(config-vlan)# private-vlan 20 association add 22
awplus(config-vlan)# private-vlan 20 association add 23
```

Step 4: Set port 1.0.1 to be the promiscuous port.

Note that you must first return to the **(config)#** prompt.

```
awplus(config-vlan)# exit
awplus(config)# interface port1.0.1
awplus(config-if)# switchport mode private-vlan promiscuous
```

Step 5: Set the other ports to be host ports

```
awplus(config)# interface port1.0.2-1.0.4,port1.0.6-1.0.8,
port1.0.10-1.0.12
awplus(config-if)# switchport mode private-vlan host
```

Step 6: On the promiscuous port, map the primary VLAN to each of the secondary VLANs

Note that you must first return to the **(config)#** prompt.

```
awplus(config-vlan)# exit
awplus(config)# interface port1.0.1
awplus(config-if)# switchport private-vlan mapping 20 add 21
awplus(config-if)# switchport private-vlan mapping 20 add 22
awplus(config-if)# switchport private-vlan mapping 20 add 23
```

Step 7: Associate the community host ports with the community VLANs

Note that you must first return to the **(config)#** prompt.

```
awplus(config)# interface port1.0.2-1.0.4
awplus(config-if)# switchport private-vlan host-association 20
add 21
```

Associate the community host ports with the community VLAN 22.

```
awplus(config)# interface port1.0.10-1.0.12
awplus(config-if)# switchport private-vlan host-association 20
add 22
```

Step 8: Associate the isolated host ports with the isolated VLAN 23.

```
awplus(config)# interface port1.0.6-1.0.8
awplus(config-if)# switchport private-vlan host-association 20
add 23
```

VLAN Statistics

This feature provides a series of data counters each able to count both the number of received frames or the number of received bytes (octets) belonging to a particular VLAN. Data frames are counted as they enter the switch ports. By allocating VLANs to each customer, a service provider could use the VLAN counter output to provide the basis for a traffic based billing component.

Counter Operation

Two scenarios are detailed; in the first scenario the switch is being used at the edge of the network, and in the second it is directly connected to an edge switch. In each situation, separate counters are maintained for incoming traffic that is associated with a particular VLAN across a range of ports. This enables both incoming and outgoing traffic volumes to be measured.

A port may not be assigned to multiple counter instances so as to count frames (or bytes) within the same VLAN.

The byte count includes frame headers, therefore the byte counter for a VLAN tagged frame will be 4 bytes longer than for an untagged frame.

Where a VLAN VLAN statistics instance encompasses ports on a stacked member and the member is removed from the stack, these ports will automatically be removed from the counter instance. If this process removes all ports within a counter instance, then the instance will be deleted.

Edge Switch Scenario

This network is shown in [Figure 16-2 on page 16.14](#). The total data count is the upload count plus the download packet count

Customer A data count

The upload data count for customer A is determined by monitoring the inbound VLAN 10 packets on ports 1.0.2 and 1.0.8 (i.e. packets from Customer A's network). These ports must be untagged members of VLAN 10. Note that packets traveling between these ports will be included in the count.


The download data count for customer A is determined by monitoring inbound VLAN 10 packets on ports 1.0.17, 1.0.19, 1.0.21, and 1.0.23 (i.e. packets destined for Customer A's network from the Internet).

Customer B data count

The upload data count for customer B is determined by monitoring the inbound VLAN 20 packets on port 1.0.24 (i.e. packets from Customer B's network). This port must be an untagged member of VLAN 20.

The download data count for customer B is determined by monitoring inbound VLAN 20 packets on ports 1.0.17, 1.0.19, 1.0.21, and 1.0.23 (i.e. packets destined for Customer B's network from the Internet).

Figure 16-2: VLAN VLAN statistics - Edge Switch Scenario



Non Edge Switch Scenario

This network is shown in [Figure 16-3 on page 16.15](#). The total data count is the upload count plus the download packet count.

Customer A data count

The upload data count for customer A is determined by monitoring the inbound VLAN 10 packets on ports 1.0.18 and 1.0.20, 1.0.22, and 1.0.24 on switch Y (i.e. the traffic from customer A's network).


The download data count for customer A is determined by monitoring inbound VLAN 10 packets on ports 1.0.17, 1.0.19, 1.0.21, and 1.0.23.

Customer B data count

The upload data count for customer B is determined by monitoring the inbound VLAN 20 packets on ports 1.0.18 and 1.0.20, 1.0.22, and 1.0.24 on switch Y (i.e. the traffic from customer B's network).

The download data count for customer B is determined by monitoring inbound VLAN 20 packets on ports 1.0.17, 1.0.19, 1.0.21, and 1.0.23.

Figure 16-3: VLAN VLAN statistics - Non Edge Switch Scenario



Chapter 17: VLAN Commands



Command List	17.2
clear vlan statistics	17.2
private-vlan	17.3
private-vlan association	17.4
show vlan	17.5
show vlan classifier group	17.6
show vlan classifier interface group	17.6
show vlan classifier rule	17.7
show vlan private-vlan	17.7
show vlan statistics	17.8
switchport access vlan	17.9
switchport enable vlan	17.10
switchport mode access	17.11
switchport mode private-vlan	17.12
switchport mode trunk	17.13
switchport private-vlan host-association	17.14
switchport private-vlan mapping	17.15
switchport trunk allowed vlan	17.16
switchport trunk native vlan	17.18
switchport vlan-stacking (double tagging)	17.19
switchport voice dscp	17.20
switchport voice vlan	17.21
switchport voice vlan priority	17.23
vlan	17.24
vlan classifier activate	17.25
vlan classifier group	17.26
vlan classifier rule ipv4	17.27
vlan classifier rule proto	17.28
vlan database	17.30
vlan statistics	17.31

Command List

This chapter provides an alphabetical reference of commands used to configure VLANs. For more information see [Chapter 16, VLAN Introduction](#).

clear vlan statistics

This command resets the counters for either a specific vlan statistics instance or (by not specifying an instance) resets the counters for all instances.

Syntax `clear vlan statistics [name <instance_name>]`

Parameter	Description
<code>vlan statistics</code>	The count of incoming frames or bytes collected on a per VLAN basis. ¹
<code><instance-name></code>	The name of the instance for which incoming frames and their bytes are counted. ¹

1. The terms frame and packet are used interchangeably.

Mode Privileged Exec

Examples To reset all VLAN statistics instance for the VLAN statistics instance vlan2-data:

```
awplus# clear vlan statistics name vlan2-data
```

To reset all VLAN statistics instances.

```
awplus# clear vlan statistics
```

Related Commands [show vlan statistics](#)
[vlan statistics](#)

private-vlan

Use this command to create a private VLAN. Private VLANs can be either primary or secondary. Secondary VLANs can be either community or isolated.

Use the no form of this command to remove the specified private vlan.

For more information, see the section [“Private VLANs” on page 16.8](#).

Syntax `private-vlan <vlan-id> {community|isolated|primary}`
`no private-vlan <vlan-id> {community|isolated|primary}`

Parameter	Description
<vlan-id>	VLAN ID of the vlan which is to be made a private vlan.
community	Community vlan
isolated	Isolated vlan
primary	Primary vlan

Mode VLAN Configuration

Example

```
awplus# configure terminal
awplus(config)# vlan database
awplus(config-vlan)# vlan 2 name vlan2 state enable
awplus(config-vlan)# vlan 3 name vlan3 state enable
awplus(config-vlan)# vlan 4 name vlan3 state enable
awplus(config-vlan)# private-vlan 2 primary
awplus(config-vlan)# private-vlan 3 isolated
awplus(config-vlan)# private-vlan 4 community
```

private-vlan association

Use this command to associate a secondary VLAN to a primary VLAN. Only one isolated VLAN can be associated to a primary VLAN. Multiple community VLANs can be associated to a primary VLAN.

Use the no form of this command to remove association of all the secondary VLANs to a primary VLAN.

For more information, see the section [“Private VLANs” on page 16.8](#).

Syntax `private-vlan <primary-vlan-id> association
{add <secondary-vlan-id> | remove <secondary-vlan-id>}`

Parameter	Description
<code><primary-vlan-id></code>	VLAN ID of the primary VLAN
<code><secondary-vlan-id></code>	VLAN ID of the secondary VLAN (either isolated or community)

Mode VLAN Configuration

Example

```
awplus# configure terminal
awplus(config)# vlan database
awplus(config-vlan)# private-vlan 2 association add 3
awplus(config-vlan)# private-vlan 2 association remove 3
awplus(config-vlan)# no private-vlan 2 association
```

show vlan

Use this command to display information about a particular VLAN by specifying the VLAN ID. It displays information for all the VLANs configured.

Syntax `show vlan {all|brief|dynamic|static|<1-4094>}`

Parameter	Description
<1-4094>	Display information about the VLAN specified by the VLAN ID.
all	Display information about all VLANs on the device.
brief	Display information about all VLANs on the device.
dynamic	Display information about all VLANs learned dynamically.
static	Display information about all statically configured VLANs.

Mode Exec and Privileged Exec

Output

Figure 17-1: Example output from the **show vlan 2** command

VLAN ID	Name	Type	State	Member ports (u)-Untagged, (t)-Tagged
2	VLAN0002	STATIC	ACTIVE	port1.0.5(u) port1.0.6(u) port1.0.7(u) port1.0.8(u)

Example To display information about VLAN 2, use the command:

```
awplus# show vlan 2
```

Related Commands `vlan`

show vlan classifier group

Use this command to display information about all configured VLAN classifier groups or a specific group.

Syntax `show vlan classifier group [<1-16>]`

Parameter	Description
<1-16>	VLAN classifier group identifier

Mode Exec and Privileged Exec

Usage If a group ID is not specified, all configured VLAN classifier groups are shown. If a group ID is specified, a specific configured VLAN classifier group is shown.

Example

```
awplus# show vlan classifier group 1
```

Related Commands [vlan classifier group](#)

show vlan classifier interface group

Use this command to display information about all interfaces configured for a VLAN group or all the groups.

Syntax `show vlan classifier interface group [<1-16>]`

Parameter	Description
<1-16>	VLAN classifier interface group identifier

Mode Exec and Privileged Exec

Usage If a group ID is not specified, all interfaces configured for all VLAN classifier groups are shown. If a group ID is specified, the interfaces configured for this VLAN classifier group are shown.

Example

```
awplus#show vlan classifier interface group
vlan classifier group 1 interface port1.1.1
vlan classifier group 1 interface port1.1.2
vlan classifier group 2 interface port1.1.4
vlan classifier group 3 interface port1.1.5

awplus#show vlan classifier interface group 1
vlan classifier group 1 interface port1.1.1
vlan classifier group 1 interface port1.1.2
```

Related Commands [vlan classifier group](#)

show vlan classifier rule

Use this command to display information about all configured VLAN classifier rules or a specific rule.

Syntax `show vlan classifier rule [<1-256>]`

Parameter	Description
<1-256>	VLAN classifier rule identifier

Mode Exec and Privileged Exec

Usage If a rule ID is not specified, all configured VLAN classifier rules are shown. If a rule ID is specified, a specific configured VLAN classifier rule is shown.

Example

```
awplus# show vlan classifier rule 1
```

Related Commands [vlan classifier activate](#)
[vlan classifier rule ipv4](#)
[vlan classifier rule proto](#)

show vlan private-vlan

Use this command to display the private-vlan configuration and associations.

Syntax `show vlan private-vlan`

Mode Exec and Privileged Exec

Example

```
awplus#show vlan private-vlan
PRIMARY      SECONDARY      TYPE      INTERFACES
-----
          2          3      isolated
          2          4      community
```

Related Commands [private-vlan](#)
[private-vlan association](#)

show vlan statistics

Use this command to display the current configuration for either a specific VLAN statistics instance, or (by not specifying an instance) display all VLAN statistics instances.

Syntax `show vlan statistics [name <instance_name>]`

Mode Exec and Privileged Exec

Examples To display all statistics for the VLAN statistics instance vlan2-data

```
awplus# show vlan statistics name vlan2-data
```

To display all VLAN statistics instances.

```
awplus# show vlan statistics
```

Figure 17-2: Example output from the show vlan statistics command

```
VLAN Stats Collection: vlan2-data
VLAN ID: 2
Port Map: port1.0.1, port1.0.2, port1.0.4
Ingress Packets: total 941, bytes 66185
```

Related Commands [clear vlan statistics](#)
[vlan statistics](#)

switchport access vlan

Use this command to change the port-based VLAN of the current port.

Use the no parameter to change the port-based VLAN of this port to the default VLAN, *vlan1*.

Syntax `switchport access vlan <vlan-id>`
`no switchport access vlan`

Parameter	Description
<vlan-id>	<1-4094> The port-based VLAN ID for the port.

Mode Interface Configuration

Default Reset the default VLAN 1 to specified switchports using the negated form of this command.

Usage Any untagged frame received on this port will be associated with the specified VLAN.

Examples To change the port-based VLAN to VLAN 3 for `port1.0.2`, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# switchport access vlan 3
```

To reset the port-based VLAN to the default VLAN 1 for `port1.0.2`, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# no switchport access vlan
```

Validation Command `show interface switchport`

Related Commands `show vlan`

switchport enable vlan

This command enables the VLAN on the port manually once disabled by certain actions, such as QSP (QoS Storm Protection) or EPSR (Ethernet Protection Switching Ring). Note that if the VID is not given, all disabled VLANs are re-enabled.

Syntax `switchport enable vlan [<1-4094>]`

Parameter	Description
switchport	Switchport
enable	Re-enables the vlan on the port
vlan	Re-enables the vlan on the port
<1-4094>	VLAN ID

Mode Interface Configuration

Example To re-enable the port1.0.1 from VLAN 1:

```
awplus# configure terminal
awplus(config)# interface port1.0.1
awplus(config-if)# switchport enable vlan 1
```

Related Commands [show mls qos interface storm-status](#)
[storm-window](#)

switchport mode access

Use this command to set the switching characteristics of the port to access mode. Received frames are classified based on the VLAN characteristics, then accepted or discarded based on the specified filtering criteria.

Syntax `switchport mode access [ingress-filter {enable|disable}]`

Parameter	Description
<code>ingress-filter</code>	Set the ingress filtering for the received frames.
<code>enable</code>	Turn on ingress filtering for received frames. This is the default value
<code>disable</code>	Turn off ingress filtering to accept frames that do not meet the classification criteria.

Default By default, ports are in access mode with ingress filtering on.

Usage Use access mode to send untagged frames only.

Mode Interface Configuration

Examples

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# switchport mode access ingress-filter
enable
```

Validation Command `show interface switchport`

switchport mode private-vlan

Use this command to make a layer 2 port a private-vlan host port or a promiscuous port.

Use the no form of this command to remove the configuration.

Syntax `switchport mode private-vlan {host|promiscuous}`
`no switchport mode private-vlan {host|promiscuous}`

Parameter	Description
host	This port type can communicate with all other host ports assigned to the same community vlan, but it cannot communicate with the ports in the same isolated vlan. All communications outside of this vlan must pass through a promiscuous port in the associated primary vlan.
promiscuous	A promiscuous port can communicate with all interfaces, including the community and isolated ports within a private VLAN

Mode Interface Configuration

Example

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# switchport mode private-vlan host
awplus(config)# interface port1.0.3
awplus(config-if)# switchport mode private-vlan promiscuous
awplus(config)# interface port1.0.4
awplus(config-if)# no switchport mode private-vlan promiscuous
```

Related Commands [switchport private-vlan mapping](#)

switchport mode trunk

Use this command to set the switching characteristics of the port to trunk. Received frames are classified based on the VLAN characteristics, then accepted or discarded based on the specified filtering criteria.

Syntax `switchport mode trunk [ingress-filter {enable|disable}]`

Parameter	Description
<code>ingress-filter</code>	Set the ingress filtering for the frames received.
<code>enable</code>	Turn on ingress filtering for received frames. This is the default value.
<code>disable</code>	Turn off ingress filtering to accept frames that do not meet the classification criteria.

Default By default, ports are in access mode, are untagged members of the default VLAN (vlan1), and have ingress filtering on.

Mode Interface Configuration

Usage A port in trunk mode can be a tagged member of multiple VLANs, and an untagged member of one native VLAN.

To configure which VLANs this port will trunk for, use the [switchport trunk allowed vlan](#) command.

Example

```
awplus# configure terminal
awplus(config)# interface port1.1.3
awplus(config-if)# switchport mode trunk ingress-filter enable
```

Validation Command `show interface switchport`

switchport private-vlan host-association

Use this command to associate a primary vlan and a secondary VLAN to a host port. Only one primary and secondary vlan can be associated to a host port.

Use the no form of this command to remove the association.

Syntax `switchport private-vlan host-association <primary-vlan-id> add
<secondary-vlan-id>`

`no switchport private-vlan host-association`

Parameter	Description
<code><primary-vlan-id></code>	VLAN ID of the primary vlan
<code><secondary-vlan-id></code>	VLAN ID of the secondary vlan (either isolated or community)

Mode Interface Configuration

Examples

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# switchport private-vlan host-association 2
                    add 3

awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# no switchport private-vlan host-association
```

switchport private-vlan mapping

Use this command to associate a primary VLAN and a set of secondary VLANs to a promiscuous port.

Use the no form of this to remove all the association of secondary VLANs to primary VLANs for a promiscuous port.

Syntax

```
switchport private-vlan mapping <primary-vlan-id> add
<secondary-vid-list>

switchport private-vlan mapping <primary-vlan-id> remove
<secondary-vid-list>

no switchport private-vlan mapping
```

Parameter	Description
<primary-vlan-id>	VLAN ID of the primary vlan
<secondary-vid-list>	VLAN ID of the secondary vlan (either isolated or community), or a range of VLANs, or a comma-separated list of VLANs and ranges.

Mode Interface Configuration

Usage This command can be applied to a switch port or a static channel group, but not a dynamic (LACP) channel group. LACP channel groups (dynamic/LACP aggregators) cannot be promiscuous ports in private VLANs.

Example

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# switchport private-vlan mapping 2 add 3-4
awplus(config-if)# switchport private-vlan mapping 2 remove 3-4
awplus(config-if)# no switchport private-vlan mapping
```

Related Commands [switchport mode private-vlan](#)

switchport trunk allowed vlan

Use this command to add VLANs to be trunked over this switch port. Traffic for these VLANs can be sent and received on the port.

The all parameter sets the port to be a tagged member of all the VLANs configured on the device. The none parameter removes all VLANs from the port's tagged member set. The add and remove parameters will add and remove VLANs to and from the port's member set.

Use the no switchport trunk command to reset switching characteristics of a specified interface to negate a trunked configuration specified with switchport trunk allowed vlan.

Syntax

```
switchport trunk allowed vlan all
switchport trunk allowed vlan none
switchport trunk allowed vlan add <vid-list>
switchport trunk allowed vlan remove <vid-list>
switchport trunk allowed vlan except <vid-list>
no switchport trunk
```

Parameter	Description
all	Allow all VLANs to transmit and receive through the port.
none	Allow no VLANs to transmit and receive through the port.
add	Add a VLAN to transmit and receive through the port.
remove	Remove a VLAN from transmit and receive through the port.
except	All VLANs, except the VLAN for which the VID is specified, are part of its port member set.
<vid-list>	<2-4094> The ID of the VLAN or VLANs that will be added to, or removed from, the port. A single VLAN, VLAN range, or comma-separated VLAN list can be set. For a VLAN range, specify two VLAN numbers: lowest, then highest number in the range, separated by a hyphen. For a VLAN list, specify the VLAN numbers separated by commas. Do not enter spaces between hyphens or commas when setting parameters for VLAN ranges or lists.

Default By default, ports are untagged members of the default VLAN (vlan1).

Mode Interface Configuration

Examples The following shows adding a single VLAN to the port's member set.

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# switchport trunk allowed vlan add 2
```


The following shows adding a range of VLANs to the port's member set.

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# switchport trunk allowed vlan add 2-4
```

The following shows adding a list of VLANs to the port's member set.

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# switchport trunk allowed vlan add 2,3,4
```

switchport trunk native vlan

Use this command to configure the native VLAN for this port. The native VLAN is used for classifying the incoming untagged packets.

Use the `no` parameter to revert the native VLAN to the default VLAN ID 1. Command negation removes all tagged VLANs, and sets the native VLAN to the default VLAN.

Syntax `switchport trunk native vlan {<vid>|none}`
`no switchport trunk native vlan`

Parameter	Description
<vid>	<2-4094> The ID of the VLAN that will be used to classify the incoming untagged packets. The VLAN ID must be a part of the VLAN member set of the port.
none	No native VLAN. Use either the parameter none or no to revert to the default VLAN 1 as the native VLAN for the specified interface switchport.

Default VLAN 1 (the default VLAN)

Mode Interface Configuration

Examples The following commands show configuration of VLAN 2 as the native vlan for interface port1.0.2:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# switchport trunk native vlan 2
```

The following commands revert the native VLAN to the default VLAN 1 for interface port 1.0.2:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# no switchport trunk native vlan
```

switchport vlan-stacking (double tagging)

Use this command to enable VLAN stacking on a port and set it to be a customer-edge-port or provider-port. This is sometimes referred to as VLAN double-tagging, nested VLANs, or QinQ.

Use no parameter with this command to disable VLAN stacking on an interface.

Syntax `switchport vlan-stacking {customer-edge-port|provider-port}`
`no switchport vlan-stacking`

Parameter	Description
customer-edge-port	Set the port to be a customer edge port. This port must already be in access mode.
provider-port	Set the port to be a provider port. This port must already be in trunk mode.

Default By default, ports are not VLAN stacking ports.

Mode Interface Configuration

Usage Use VLAN stacking to separate traffic from different customers so that they can be managed over a provider network

Traffic with an extra VLAN header added by VLAN stacking cannot be routed.

Example

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# switchport vlan-stacking customer-edge-port
```

switchport voice dscp

Use this command to configure the layer 3 DSCP value advertised when the transmission of LLDP-MED Network Policy TLVs for voice devices is enabled. When LLDP-MED capable IP phones receive this network policy information, they transmit voice data with the specified DSCP value.

Use the no version of this command to reset the DSCP value to the default, 0.

Syntax `switchport voice dscp <0-63>`

`no switchport voice dscp`

Parameter	Description
<code>switchport</code>	Set the switching characteristics of the Layer 2 interface
<code>voice</code>	Configure attached IP phones via LLDP
<code>dscp</code>	Specify a DSCP value for voice data
<code><0-63></code>	DSCP value

Default A DSCP value of 0 will be advertised.

Mode Interface Configuration

Usage LLDP-MED advertisements including Network Policy TLVs are transmitted via a port if:

- LLDP is enabled ([lldp run command on page 78.15](#))
- Voice VLAN is configured for the port ([switchport voice vlan command on page 17.21](#))
- The port is configured to transmit LLDP advertisements—enabled by default ([lldp transmit receive command on page 78.19](#))
- The port is configured to transmit Network Policy TLVs—enabled by default ([lldp med-tlv-select command on page 78.9](#))
- There is an LLDP-MED device connected to the port

Examples To tell IP phones connected to port1.0.5 to send voice data with DSCP value 27, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.5
awplus(config-if)# switchport voice dscp 27
```

Related Commands [lldp med-tlv-select](#)
[show lldp](#)
[switchport voice vlan](#)

switchport voice vlan

Use this command to configure the Voice VLAN tagging advertised when the transmission of LLDP-MED Network Policy TLVs for voice endpoint devices is enabled. When LLDP-MED capable IP phones receive this network policy information, they transmit voice data with the specified tagging. This command also sets the ports to be spanning tree edge ports, that is, it enables spanning tree portfast on the ports.

Use the no version of this command to remove LLDP-MED network policy configuration for voice devices connected to these ports. This does not change the spanning tree edge port status.

Syntax `switchport voice vlan [<vid>|dot1p|dynamic|untagged]`
`no switchport voice vlan`

Parameter	Description
<vid>	VLAN identifier, in the range 1 to 4094.
dot1p	The IP phone should send User Priority tagged packets, that is, packets in which the tag contains a User Priority value, and a VID of 0. (The User Priority tag is also known as the 802.1p priority tag, or the Class of Service (CoS) tag.)
dynamic	The VLAN ID with which the IP phone should send tagged packets will be assigned by RADIUS authentication.
untagged	The IP phone should send untagged packets.

Default By default, no Voice VLAN is configured, and therefore no network policy is advertised for voice devices.

Mode Interface Configuration

Usage LLDP-MED advertisements including Network Policy TLVs are transmitted via a port if:

- LLDP is enabled ([lldp run command on page 78.15](#))
- Voice VLAN is configured for the port using this command ([switchport voice vlan](#))
- The port is configured to transmit LLDP advertisements—enabled by default ([lldp transmit receive command on page 78.19](#))
- The port is configured to transmit Network Policy TLVs—enabled by default ([lldp med-tlv-select command on page 78.9](#))
- There is an LLDP-MED device connected to the port.

To set the priority value to be advertised for tagged frames, use the [switchport voice vlan priority command on page 17.23](#).

If the Voice VLAN details are to be assigned by RADIUS, then the RADIUS server must be configured to send the attribute 'Egress-VLANID (56)' or 'Egress-VLAN-Name (58)' in the RADIUS Accept message when authenticating a phone attached to this port. To set these attributes on the local RADIUS server, use the [egress-vlan-id command on page 62.16](#) or the [egress-vlan-name command on page 62.17](#).

For more information about configuring authentication for Voice VLAN, “[Configuring LLDP](#)” on page 77.11.

If the ports have been set to be edge ports by the [switchport voice vlan](#) command, the no version of the command will leave them unchanged as edge ports. To set them back to their default non-edge port configuration, use the [spanning-tree edgeport \(RSTP and MSTP\) command](#) on page 19.24.

Examples To tell IP phones connected to port1.0.5 to send voice data tagged for VLAN 10, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.5
awplus(config-if)# switchport voice vlan 10
```

To tell IP phones connected to ports 1.0.8-1.0.12 to send priority tagged packets (802.1p priority tagged with VID 0, so that they will be assigned to the port VLAN) use the following commands. The priority value is 5 by default, but can be configured with the [switchport voice vlan priority](#) command.

```
awplus# configure terminal
awplus(config)# interface port1.0.8-port1.0.12
awplus(config-if)# switchport voice vlan dot1p
```

To dynamically configure the VLAN ID advertised to IP phones connected to port1.0.1 based on the VLAN assigned by RADIUS authentication (with RADIUS attribute 'Egress-VLANID' or 'Egress-VLAN-Name' in the RADIUS accept packet), use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1
awplus(config-if)# switchport voice vlan dynamic
```

To remove the Voice VLAN, and therefore disable the transmission of LLDP-MED network policy information for voice devices on port1.0.24, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.24
awplus(config-if)# no switchport voice vlan
```

Related Commands

- [egress-vlan-id](#)
- [egress-vlan-name](#)
- [lldp med-tlv-select](#)
- [spanning-tree edgeport \(RSTP and MSTP\)](#)
- [switchport voice dscp](#)
- [switchport voice vlan priority](#)
- [show lldp](#)

switchport voice vlan priority

Use this command to configure the Layer 2 user priority advertised when the transmission of LLDP-MED Network Policy TLVs for voice devices is enabled. This is the priority in the User Priority field of the IEEE 802.1Q VLAN tag, also known as the Class of Service (CoS), or 802.1p priority. When LLDP-MED capable IP phones receive this network policy information, they transmit voice data with the specified priority.

Syntax `switchport voice vlan priority <0-7>`
`no switchport voice vlan priority`

Parameter	Description
<code>switchport</code>	Set the switching characteristics of the Layer2 interface
<code>voice</code>	Configure attached IP phones via LLDP
<code>vlan</code>	Configure the VLAN IP phones should use
<code>priority</code>	Specify a user priority value for voice data
<code><0-7></code>	Priority value

Default By default, the Voice VLAN user priority value is 5.

Mode Interface Configuration

Usage LLDP-MED advertisements including Network Policy TLVs are transmitted via a port if:

- LLDP is enabled ([lldp run command on page 78.15](#))
- Voice VLAN is configured for the port ([switchport voice vlan command on page 17.21](#))
- The port is configured to transmit LLDP advertisements—enabled by default ([lldp transmit receive command on page 78.19](#))
- The port is configured to transmit Network Policy TLVs—enabled by default ([lldp med-tlv-select command on page 78.9](#))
- There is an LLDP-MED device connected to the port.

To set the Voice VLAN tagging to be advertised, use the [switchport voice vlan command on page 17.21](#).

Examples To tell IP phones connected to port1.0.5 to send voice data with a user priority value of 6, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.5
awplus(config-if)# switchport voice vlan priority 6
```

Related Commands [lldp med-tlv-select](#)
[show lldp](#)
[switchport voice vlan](#)

vlan

This command creates VLANs, assigns names to them, and enables or disables them. Specifying the `disable` state causes all forwarding over the specified VLAN ID to cease. Specifying the `enable` state allows forwarding of frames on the specified VLAN.

The `no` version of this command destroys the specified VLANs.

Syntax

```
vlan <vid> [name <vlan-name>] [state {enable|disable}]  
vlan <vid-range> [state {enable|disable}]  
no vlan {<vid>|<vid-range>}
```

Parameter	Description
<vid>	The VID of the VLAN that will be enabled or disabled <2-4094>.
<vlan-name>	The ASCII name of the VLAN. Maximum length: 32 characters.
<vid-range>	Specifies a range of VLAN identifiers.
enable	Sets VLAN into an enable state.
disable	Sets VLAN into a disable state.

Default By default, VLANs are enabled when they are created.

Mode VLAN Configuration

Examples

```
awplus# configure terminal  
awplus(config)# vlan database  
awplus(config-vlan)# vlan 45 name accounts state enable
```

Related Commands

- [vlan database](#)
- [show vlan](#)

vlan classifier activate

Use this command to associate a VLAN classifier group with the switch port.

Use the no version of this command to remove the group from the switch port.

Syntax `vlan classifier activate <vlan-class-grp-id>`
`no vlan classifier activate`

Parameter	Description
<code><vlan-class-grp-id></code>	VLAN classifier group identifier (1-16).

Mode Interface Configuration

Example To associate VLAN classifier group 3 with switch port 1.1.3

```
awplus# configure terminal
awplus(config)# interface port1.1.3
awplus(config-if)# vlan classifier activate 3
```

Related Commands `show vlan classifier rule`
`vlan classifier group`
`vlan classifier rule ipv4`
`vlan classifier rule proto`

vlan classifier group

Use this command to create a group of VLAN classifier rules. The rules must already have been created.

Use the no version of this command to delete a group of VLAN classifier rules.

Syntax `vlan classifier group <1-16> {add|delete} rule <vlan-class-rule-id>`
`no vlan classifier group <1-16>`

Parameter	Description
<1-16>	VLAN classifier group identifier
add	Add the rule to the group.
delete	Delete the rule from the group.
<vlan-class-rule-id>	The VLAN classifier rule identifier.

Mode Global Configuration mode

Example

```
awplus# configure terminal
awplus(config)# vlan classifier group 3 add rule 5
```

Related Commands `show vlan classifier rule`
`vlan classifier activate`
`vlan classifier rule ipv4`
`vlan classifier rule proto`

vlan classifier rule ipv4

Use this command to create an IPv4 subnet-based VLAN classifier rule and map it to a specific VLAN. Use the no version of this command to delete the VLAN classifier rule.

Syntax `vlan classifier rule <1-256> ipv4 <ip-addr/prefix-length> vlan <1-4094>`
`no vlan classifier rule <1-256>`

Parameter	Description
<1-256>	VLAN Classifier Rule identifier
<ip-addr/prefix-length>	The IP address and prefix length
<1-4094>	VLAN to which an untagged packet is mapped.

Mode Global Configuration

Usage If the source IP address matches the IP subnet specified in the VLAN classifier rule, the received packets are mapped to the specified VLAN.

Example

```
awplus# configure terminal
awplus(config)# vlan classifier rule 3 ipv4 3.3.3.3/8 vlan 5
```

Related Commands `show vlan classifier rule`
`vlan classifier activate`
`vlan classifier rule proto`

vlan classifier rule proto

Use this command to create a protocol type-based VLAN classifier rule, and map it to a specific VLAN. The no vlan classifier rule proto command destroys the rule.

Syntax `vlan classifier rule <1-256> proto <protocol>
encap {ethv2|nosnapllc|snapllc} vlan <vid>`

`no vlan classifier rule <1-256>`

Parameter	Description
<1-256>	VLAN Classifier identifier
proto	Protocol type
<protocol>	Specify a protocol either by its decimal number (0-65535) or by one of the following protocol names:
[arp 2054]	Address Resolution protocol
[atalkaarp 33011]	Appletalk AARP protocol
[atalkddp 32923]	Appletalk DDP protocol
[atmmulti 34892]	MultiProtocol Over ATM protocol
[atmtransport 34948]	Frame-based ATM Transport protocol
[dec 24576]	DEC Assigned protocol
[deccustom 24582]	DEC Customer use protocol
[decdiagnostics 24581]	DEC Systems Comms Arch protocol
[decdnadumpload 24577]	DEC DNA Dump/Load protocol
[decdnaremoteconsole 24578]	DEC DNA Remote Console protocol
[decdnarouting 24579]	DEC DNA Routing protocol
[declat 24580]	DEC LAT protocol
[decsyscomm 24583]	DEC Systems Comms Arch protocol
[g8bpqx25 2303]	G8BPQ AX.25 protocol
[ieeeaddrtrans 2561]	Xerox IEEE802.3 PUP Address
[ieeepup 2560]	Xerox IEEE802.3 PUP protocol
[ip 2048]	IP protocol
[ipx 33079]	IPX protocol

Parameter	Description
[netbeui 61680]	IBM NETBIOS/NETBEUI protocol
[netbeui 61681]	IBM NETBIOS/NETBEUI protocol
[pppdiscovery 34915]	PPPoE discovery protocol
[pppsession 34916]	PPPoE session protocol
[rarp 32821]	Reverse Address Resolution protocol
[x25 2056]	CCITT .25 protocol
[xeroxaddrtrans 513]	Xerox PUP Address Translation protocol
[xeroxpup 512]	Xerox PUP protocol
ethv2	Ethernet Version 2 encapsulation
nosnapllc	LLC without SNAP encapsulation
snapllc	LLC SNAP encapsulation
<vid>	VLAN ID to which an untagged packet is mapped (2-4094)

Mode Global Configuration

Usage If the protocol type matches the protocol specified in the VLAN classifier rule, the received packets are mapped to the specified VLAN. Ethernet Frame Numbers may be entered in place of the protocol names listed. For a full list please refer to the IANA list online: <http://www.iana.org/assignments/ethernet-numbers>.

Example

```
awplus# configure terminal
awplus(config)# vlan classifier rule 1 proto x25 encap ethv2
                vlan 2
awplus(config)# vlan classifier rule 2 proto 512 encap ethv2
                vlan 2
awplus(config)# vlan classifier rule 3 proto 2056 encap ethv2
                vlan 2
awplus(config)# vlan classifier rule 4 proto 2054 encap ethv2
                vlan 2
```

Validation Output

```
awplus# show vlan classifier rule
```

```
vlan classifier rule 16 proto rarp encap ethv2 vlan 2
vlan classifier rule 8 proto encap ethv2 vlan 2
vlan classifier rule 4 proto arp encap ethv2 vlan 2
vlan classifier rule 2 proto xeroxpup encap ethv2 vlan 2
```

Related Commands [show vlan classifier rule](#)
[vlan classifier activate](#)
[vlan classifier group](#)

vlan database

Use this command to enter the VLAN Configuration mode.

Syntax `vlan database`

Mode Global Configuration

Usage Use this command to enter the VLAN configuration mode. You can then add or delete a VLAN, or modify its values.

Examples In the following example, note the change to VLAN configuration mode from Configure mode:

```
awplus# configure terminal
awplus(config)# vlan database
awplus(config-vlan)#
```

Related Commands [vlan](#)

vlan statistics

This command creates a VLAN statistics instance, and enables you to add one or more ports to a defined instance. This command can only be applied to switch ports. You cannot apply it to aggregated links or eth ports.

The no variant of this command enables the deletion of VLAN statistics instances, or for removing one or more ports that are currently mapped to a counter instance. Note that the selected range of ports must all be switch ports.

*Note: In describing this command, the terms **frame** and **packet** are used interchangeably.*

Syntax `vlan <vid> statistics name <instance_name>`
`no vlan statistics name <instance_name>`

Parameter	Description
<code>vlan statistics</code>	The count of incoming frames or bytes, collected on a per VLAN basis.
<code><vid></code>	The VID of the VLAN that is associated with <code><instance-name></code> .
<code><instance-name></code>	The name of the instance for which incoming frames and their bytes are counted.

Mode Interface Configuration

Usage A maximum of 128 VLAN statistics instances can be created. When the first instance is configured, the switch will reserve sufficient resources to support 128 VLAN statistics instances. These resources are also shared with other features such as QoS and ACLs. Where the remaining resources are insufficient to support the VLAN Statistics feature the feature will not be enabled, and an error message will display.

Examples Create a VLAN statistics instance named vlan2-data, and apply this to count incoming vlan2 tagged frames on ports 1.0.4 and 1.0.5.

```
awplus# configure terminal
awplus(config)# interface port1.0.4,port1.0.5
awplus(config-if)# vlan 2 statistics name vlan2-data
```

From the previous example, add ports in the range 1.0.2 to 1.0.3 to the VLAN statistics instance. The vlan2-data instance will now count all incoming vlan2 tagged frames on ports within the range 1.0.1 to 1.0.5.

```
awplus(config)# interface port1.0.2-port1.0.3
awplus(config-if)# vlan 2 statistics name vlan2-data
```

To remove port1.0.5 from the VLAN statistics instance named vlan2-data.

```
awplus(config)# interface port1.0.5
awplus(config-if)# no vlan statistics name vlan2-data
```

To remove the remaining ports 1.0.2 to 1.0.4 from the VLAN statistics instance named vlan2-data. Note that because there are no ports associated with the vlan2-data, this instance will be removed.

```
awplus(config)# interface port1.0.2-port1.0.4
awplus(config-if)# no vlan statistics name vlan2-data
```

Related Commands [clear vlan statistics](#)
[show vlan statistics](#)

Chapter 18: Spanning Tree Introduction: STP, RSTP, and MSTP



Introduction.....	18.2
Overview of Spanning Trees.....	18.2
Spanning tree operation.....	18.2
Spanning tree modes.....	18.4
Spanning Tree Protocol (STP).....	18.5
Configuring STP.....	18.6
Rapid Spanning Tree Protocol (RSTP).....	18.7
Configuring RSTP.....	18.8
Multiple Spanning Tree Protocol (MSTP).....	18.10
Multiple Spanning Tree Instances (MSTI).....	18.11
MSTP Regions.....	18.12
Common and Internal Spanning Tree (CIST).....	18.14
MSTP Bridge Protocol Data Units (BPDUs).....	18.16
Configuring MSTP.....	18.18

Introduction

This chapter describes and provides configuration procedures for:

- Spanning Tree Protocol (STP)
- Rapid Spanning Tree Protocol (RSTP)
- Multiple Spanning Tree Protocol (MSTP)

For detailed information about the commands used to configure spanning trees, see [Chapter 19, Spanning Tree Commands](#).

Overview of Spanning Trees

The concept of the spanning tree protocol was devised to address broadcast storming. The spanning tree algorithm itself is defined by the IEEE standard 802.1D and its later revisions.

The IEEE Standard 802.1 uses the term “bridge” to define the spanning tree operation and uses terms such as Bridge Protocol Data Units, Root Bridge etc., when defining spanning tree protocol functions.

When a bridge receives a frame, it reads the source and destination address fields. The bridge then enters the frame's source address in its forwarding database. In doing this the bridge associates the frame's source address with the network attached to the port on which the frame was received. The bridge also reads the destination address and if it can find this address in its forwarding database, it forwards the frame to the appropriate port. If the bridge does not recognize the destination address, it forwards the frame out from all its ports except for the one on which the frame was received, and then waits for a reply. This process is known as “flooding.”

A significant problem arises where bridges connect via multiple paths. A frame that arrives with an unknown destination address is flooded over all available paths. The arrival of these frames at another network via different paths and bridges produces major problems. The bridges can become confused about the location of the send and receive devices and begin sending frames in the wrong directions. This process feeds on itself and produces a condition known as a broadcast storm, where the increase of circulating frames can eventually overload the network.

Spanning tree operation

Where a LAN's topology results in more than one path existing between bridges, frames transmitted onto the extended LAN circulate in increasing numbers around the loop, decreasing performance and potentially overloading the network. However, multiple paths through the extended LAN are often required in order to provide redundancy and backup in the event of a bridge or link failure.

The spanning tree is created through the exchange of Bridge Protocol Data Units (BPDUs) between the bridges in the LAN. The spanning tree algorithm operates by:

- Automatically computing a loop-free portion of the topology, called a *spanning tree*. The topology is dynamically pruned to the spanning tree by declaring certain ports on a switch to be redundant, and placing them into a 'Blocking' state.
- Automatically recovering from a switch failure that would partition the extended LAN by reconfiguring the spanning tree to use redundant paths, if available.

The logical tree computed by the spanning tree algorithm has the following properties:

- A single bridge is selected to become the spanning tree's unique *root bridge*. This is the device that advertises the lowest Bridge ID. Each bridge is uniquely identified by its Bridge ID, which comprises the bridge's *root priority* (a spanning tree parameter) followed by its MAC address.
- Each bridge or LAN in the tree, except the root bridge, has a unique parent, known as the *designated bridge*. Each LAN has a single bridge, called the *designated bridge*, that connects it to the next LAN on the path towards the root bridge.
- Each port connecting a bridge to a LAN has an associated *cost*, called the *root path cost*. This is the sum of the costs for each path between the particular bridge port and the root bridge. The designated bridge for a LAN is the one that advertises the lowest *root path cost*. If two bridges on the same LAN have the same lowest root path cost, then the switch with the lowest bridge ID becomes the designated bridge.

The spanning tree computation is a continuous, distributed process to establish and maintain a spanning tree (Table 18-1). The basic algorithm is similar for STP, RSTP and MSTP modes.

Table 18-1: Spanning tree process

The spanning tree algorithm ... By ...	
Selects a root bridge	It selects as the root bridge for the spanning tree the device with the (numerically) lowest bridge identifier (that is, the device with lowest root bridge priority value, or if they have the same priority, the bridge with the lowest MAC address).
Selects root ports	On each device, it selects the root port according to: ■ the port with the lowest path cost to the root bridge ■ the port connected to the bridge with the lowest root identifier ■ MSTP and RSTP only: the port with the lowest port priority value ■ the port with the lowest port number¹
Blocks alternate ports	In order to prevent loops, it blocks alternate ports (Discarding state) that provide higher cost paths to the root bridge.
Blocks backup ports	Where a second port connects one switch back to itself, it blocks the backup port that has the highest path cost or port number.
Selects designated ports	All other ports that are not disabled are selected as designated ports and are eventually made active (Forwarding state).
Maintains the spanning tree	If a switch or port fails, the spanning tree configures a new active topology, changing some port states, to reestablish connectivity and block loops. Depending on where the failure occurs, the changes may be widespread (e.g., if the root bridge fails), or local (e.g., if a designated port fails).

1. The whole three part port number (D.M.P) is used to find the lowest port number; where: D is the device number within a stack (1 for a non stacked device), M is the module number (XEM number) within the device - note that 0 is used for all base-board connected ports, and P is the number of the port within the XEM or base-board.

The logical spanning tree, sometimes called the *active topology*, includes the root bridge and all designated bridges, meaning all ports that are to be used for communication within the spanning tree. These ports are in the forwarding state. Ports removed from the logical spanning tree are not in the forwarding state. To implement the spanning tree algorithm, devices communicate with one another using the Spanning Tree Protocol.

Spanning tree modes

STP can run in one of three modes: STP, RSTP or MSTP. A device running RSTP is compatible with other devices running STP; a device running MSTP is compatible with other devices running RSTP or STP. By default, on a device in MSTP mode each port automatically detects the mode of the device connected to it (MSTP, RSTP or STP), and responds in the appropriate mode by sending messages (BPDUs) in the corresponding format. Ports on a device in RSTP mode can automatically detect and respond to connected devices in RSTP and STP mode. Particular ports can also be forced to only operate in a particular mode ([spanning-tree force-version command on page 19.28](#)).

STP The Spanning Tree Protocol (STP) is the original protocol defined by IEEE standard 802.1D-1988. It creates a single spanning tree over a network.

STP mode may be useful for supporting applications and protocols whose frames may arrive out of sequence or duplicated, for example NetBeui.

RSTP Rapid Spanning Tree Protocol (RSTP) also creates a single spanning tree over a network. Compared with STP, RSTP provides for more rapid convergence to an active spanning tree topology. RSTP is defined in IEEE standard 802.1D-2004.

By default, the device operates in RSTP mode.

MSTP The Multiple Spanning Tree Protocol (MSTP) addresses the limitations in the previous spanning tree protocols, STP and RSTP, within networks that use multiple VLANs with topologies that employ alternative physical links. It supports multiple spanning tree instances on any given link within a network, and supports large networks by grouping bridges into regions that appear as a single bridge to other devices.

MSTP is defined in IEEE standard 802.1Q-2005. The protocol builds on, and remains compatible with, the previous IEEE standards defining STP and RSTP.

Spanning Tree Protocol (STP)

STP uses the process described in [Table 18-1](#) to avoid loops.

STP port states

In STP mode, each switch port can be in one of five spanning tree states, and one of two switch states. The state of a switch port is taken into account by STP. The STP port states ([Table 18-2](#)) affect the behavior of ports whose switch state is enabled.

Table 18-2: STP port states

State	Meaning
DISABLED	STP operations are disabled on the port. The port does not participate in the operation of the Spanning Tree Algorithm and Protocol. The port can still switch if its switch state is enabled.
BLOCKING	The forwarding process discards received frames and does not submit forwarded frames for transmission. This is the “standby” mode. The port does not participate in frame relay.
LISTENING	The port is enabled for receiving frames only. The port is preparing to participate in frame relay. The forwarding process discards received frames and does not submit forwarded frames for transmission.
LEARNING	The port is enabled for receiving frames only, and the Learning Process can add new source address information to the Forwarding Database.
FORWARDING	The normal state for a switch port. The forwarding process and the Spanning Tree entity are enabled for transmit and receive operations on the port.

Configuring STP

By default, RSTP is enabled on all switch ports. This section provides a procedure for configuring STP (Table 18-3).

To configure other modes, see “Configuring RSTP” on page 18.8 or “Configuring MSTP” on page 18.18.

Table 18-3: Configuration procedure for STP

Configure STP	
RSTP is enabled by default with default settings on all switch ports to prevent layer 2 loops in your network.	
<code>awplus#</code>	Enter Global Configuration mode.
<code>configure terminal</code>	
<code>awplus(config)#</code>	By default, the device is in RSTP mode. Change to STP mode.
<code>spanning-tree mode stp</code>	
<code>awplus(config)#</code>	By default, spanning tree is enabled on all switch ports. If it has been disabled, enable it for STP.
<code>spanning-tree {mstp rstp stp} enable</code>	
<code>awplus(config)#</code>	By default, all devices have the same root bridge priority, 32768 (8000 in hexadecimal), so the device with the lowest MAC address becomes the root bridge. If you want the device to be the root bridge, set the root bridge priority to a value lower than 32768. (If you enter a number that is not a multiple of 4096, the switch rounds the number down.)
<code>spanning-tree priority <priority></code>	
Configure Root Guard	
The Root Guard feature makes sure that the port on which it is enabled is a designated port. If the Root Guard enabled port receives a superior BPDU, it goes to a Listening state (for STP) or discarding state (for RSTP and MSTP).	
<code>awplus(config)#</code>	Enter Interface Configuration mode for the switch ports you want to enable Root Guard for.
<code>interface <port-list></code>	
<code>awplus(config-if)#</code>	Enable the Guard Root feature for these ports.
<code>spanning-tree guard root</code>	
<code>awplus(config-if)#</code>	Return to Global Configuration mode.
<code>exit</code>	
<code>awplus(config)#</code>	Return to Privileged Exec mode.
<code>exit</code>	
Check STP configuration	
<code>awplus#</code>	Display the spanning tree configuration for the device, and confirm the new root bridge priority (Bridge Priority).
<code>show spanning-tree [interface <port-list>]</code>	Note that the Bridge ID is in a form like this: 80000000cd240331, and that other IDs follow the same pattern. This is made up of:
	■ 8000—the devices' root bridge priority in hexadecimal
	■ 0000cd240331—the devices' MAC address.

Advanced configuration:

For most networks the default settings for path costs will be suitable, however, you can configure them if required (`spanning-tree path-cost`).

Rapid Spanning Tree Protocol (RSTP)

RSTP uses the process described in [Table 18-1](#) to avoid loops.

A spanning tree running in STP mode can take up to one minute to rebuild after a topology or configuration change. The RSTP algorithm provides for a faster recovery of connectivity following the failure of a bridge, bridge port, or a LAN. RSTP provides rapid recovery by including port roles in the computation of port states, and by allowing neighboring bridges to explicitly acknowledge signals on a point-to-point link that indicate that a port wants to enter the forwarding mode.

In rapid mode, the rapid transition of a port to the forwarding state is possible when the port is considered to be part of a point-to-point link, or when the port is considered to be an *edge* port. An edge port is one that attaches to a LAN that has no other bridges attached.

Table 18-4: RSTP port states

State	Meaning
DISABLED	STP operations are disabled on the port.
DISCARDING	The port does not participate in frame relay. The forwarding process discards received frames and does not submit forwarded frames for transmission.
LEARNING	The port is enabled for receiving frames only, and the learning process can add new source address information to the forwarding database. The port does not forward any frames.
FORWARDING	The normal state for a switch port. The forwarding process and the Spanning Tree entity are enabled for transmit and receive operations on the port.

Configuring RSTP

RSTP is enabled by default with default settings on all switch ports to prevent layer 2 loops in your network. No further configuration is required if you want to use RSTP with these default settings. For further RSTP configuration, see [Table 18-5](#) below.

To configure other modes, see “Configuring MSTP” on page 18.18 or “Configuring STP” on page 18.6.

For detailed configuration examples, see the How To Note *How To Configure Basic Switching Functionality*, available from <http://www.alliedtelesis.com>.

Table 18-5: Configuration procedure for RSTP

	Command	Description
RSTP is enabled by default with default settings on all switch ports to prevent layer 2 loops in your network. No further configuration is required if you want to use RSTP with these default settings. If you need to restore the device to RSTP after it has been set to another mode, or modify the default RSTP settings, follow the procedure below.		
awplus#	<code>configure terminal</code>	Enter Configuration mode.
awplus(config)#	<code>spanning-tree mode rstp</code>	By default, the device is in RSTP mode. If it has been changed to STP or MSTP mode, change it back to RSTP.
awplus(config)#	<code>spanning-tree {mstp rstp stp} enable</code>	By default, RSTP is enabled on all switch ports. If it has been disabled, enable it.
awplus(config)#	<code>spanning-tree priority <priority></code>	By default, all devices have the same root bridge priority, 32768 (8000 in hexadecimal), so the device with the lowest MAC address becomes the root bridge. If you want the device to be the root bridge, set the root bridge priority to a value lower than 32768. (If you enter a number that is not a multiple of 4096, the switch rounds the number down.)
Configure edge ports		
If some switch ports are connected to devices that cannot generate BPDUs (such as workstations), you can set particular switch ports as edge ports, or set them to automatically detect whether they are edge ports.		
awplus(config)#	<code>interface (to configure) <port-list></code>	Enter Interface Configuration mode for these switch ports.
awplus(config-if)#	<code>spanning-tree edgeport</code>	Set these ports to be edge ports,
awplus(config-if)#	or	or
	<code>spanning-tree autoedge</code>	Set these ports to automatically detect whether they are edge ports.
Configure Root Guard		
awplus(config-if)#	<code>exit</code>	Return to Global Configuration mode.
awplus(config)#	<code>spanning-tree guard root</code>	The Root Guard feature makes sure that the port on which it is enabled is a designated port. If the Root Guard enabled port receives a superior BPDU, it goes to a Listening state (for STP) or discarding state (for RSTP and MSTP). Enable the Guard Root feature if required.

Table 18-5: Configuration procedure for RSTP(Continued)

	Command	Description
Configure BPDU Guard		
awplus(config)#	spanning-tree portfast bpdu-guard	If required, enable the BPDU Guard feature, and configure timeout parameters.
awplus(config)#	spanning-tree errdisable-timeout enable	
awplus(config)#	spanning-tree errdisable-timeout interval <10-1000000>	
Check RSTP configuration		
awplus(config)#	exit	Return to Privileged Exec mode.
awplus#	show spanning-tree [interface <port-list>]	Display the spanning tree configuration for the device, and confirm the new root bridge priority (Bridge Priority). Note that the Bridge ID is in a form like this: 80000000cd240331, and that other IDs follow the same pattern. This is made up of: ■ 8000—the devices' root bridge priority in hexadecimal ■ 0000cd240331—the devices' MAC address.

Advanced configuration: For most networks the default settings for path costs will be suitable, however, you can configure them if required ([spanning-tree path-cost](#)).

Multiple Spanning Tree Protocol (MSTP)

Conceptually, MSTP views the total bridged network as one that comprises a number of *Multiple Spanning Tree Regions* (MSTRs), where each region can contain up to 64 spanning trees, which operate locally, called *Multiple Spanning Tree Instances* (MSTIs). AlliedWare Plus supports up to 15 MSTIs. The regions are linked by the *Common Internal Spanning Tree* (CIST).

MSTP uses BPDUs to exchange information between spanning-tree compatible devices, to prevent loops in each MSTI and also in the CIST, by selecting active and blocked paths. This process is described in [Table 18-1](#).

If multiple ports are aggregated together into a dynamic (LACP) or static channel group, then the spanning-tree process is aware of the link aggregation and treats the aggregated ports as a single logical path.

Advantage of MSTP over RSTP

MSTP is similar to RSTP, in that it provides loop resolution and rapid convergence. However, RSTP can keep track of only one spanning-tree. MSTP can track many spanning-trees, referred to as *instances*. MSTP makes it possible to have different forwarding paths for different MST instances. This enables load balancing of network traffic across redundant links, so that all the links in a network can be used by at least one MSTI, and no link is left completely idle. That is to say that no link is unnecessarily shut down by spanning-tree.

Essentially, MSTP is VLAN aware and RSTP is not VLAN aware. MSTP BPDUs and RSTP BPDUs are compatible, so a network can have a mixture of MSTP and RSTP areas.


Multiple Spanning Tree Instances (MSTI)

MSTP enables the grouping and mapping of VLANs to different spanning tree instances. So, an MST Instance (MSTI) is a particular set of VLANs that are all using the same spanning tree.

In a network where all VLANs span all links of the network, judicious choice of bridge priorities for different MSTIs can result in different switches becoming root bridges for different MSTIs. That will result in the different MSTIs choosing different active topologies on the network. An example of how different MSTIs can choose different active topologies on the same physical set of links is illustrated in Figure 18-1.

MSTP is compatible with RSTP and STP—see “Common and Internal Spanning Tree (CIST)” on page 18.14.

Figure 18-1: Different spanning trees created by different MSTIs on the same physical layout




MSTP Regions

An MST region is a set of interconnected switches that all have the same values for the following MST configuration identification elements:

- MST configuration name - the name of the MST region
- Revision level - the revision number of configuration
- Configuration Digest - the mapping of which VLANs are mapped to which MST instances

Each of the MST instances created are identified by an MSTI number. This number is locally significant within the MST region. Therefore, an MSTI will not span across MST regions.

Figure 18-2: MSTIs in different regions



The task of assigning each bridge to a particular region is achieved by the member bridges each comparing their *MST Configuration Identifiers*. More information on configuration identifiers is provided in [Table 18-6](#), but for the moment an *MST Configuration Identifier* can simply be thought of as an identifier that represents the mapping of VLANs to MSTIs within each bridge. Therefore, bridges with identical *MST Configuration Identifiers*, must have identical MSTI mapping tables.

While each MSTI can have multiple VLANs, each VLAN can be associated with only one MSTI. Once these associations have been made, the bridges in each region can transmit their spanning tree BPDUs and advertise their MSTIs. This in turn establishes the active data paths between the bridges for each group of VLANs (that is, for each MSTI) and block any duplicate paths within each instance. A particular advantage of this enhancement applies where a large number of VLANs share a few internetwork paths. In this situation there need only be as many Multiple Spanning Tree Instances (MSTIs) as there are source and destination bridge pairs, remembering that a pair of bridges probably has multiple paths between them.

In order to ensure that each bridge within a region maintains the same configuration information (particularly their VID to MSTI mappings) and to ensure each bridge's membership of a particular region, the bridges exchange configuration information in the form of *MST Configuration Identifiers*. [Table 18-6](#) provides a breakdown of an *MST Configuration Identifier*. A detailed explanation of bridge configuration identifiers can be found in Section 13.7 of the IEEE 802.1Q-2003 standard.


Table 18-6: MST Configuration Identifier

Field Name	Description
Format Selector	A single octet field whose value of 0 indicates MSTP operation
Region Name	A name (up to 32 characters long) that identifies a particular MST region, defined using the region (MSTP) command on page 19.8
Revision Level	A number representing the region's revision level, defined using the revision (MSTP) command on page 19.9 .
Configuration Digest	A 16 octet (HMAC-MD5 based) signature created from the MST configuration table.

Common and Internal Spanning Tree (CIST)

The CIST is the default spanning tree instance of MSTP, i.e. all VLANs that are not members of particular MSTIs are members of the CIST. Also, an individual MST region can be regarded as a single virtual bridge by other MST regions. The spanning tree that runs between regions is the CIST. The CIST is also the spanning tree that runs between MST regions and Single Spanning Tree (SST) entities. So, in Figure 18-3, the STP that is running between the regions, and to the SST bridges, is the CIST.

Figure 18-3: The CIST operates on links between regions and to SST devices



Compatibility with Previous Spanning Tree Protocols

MSTP provides for compatibility with older spanning tree protocols in several ways. In addition to the MST region described in the previous section, the protocol provides for single spanning tree systems by employing a Common and Internal Spanning Tree (CIST). The CIST applies a common and internal spanning tree protocol to the whole of the bridged network and is a direct equivalent to the internal spanning tree (IST) protocol of earlier versions.

In common with legacy spanning tree systems, the CIST protocol first determines its root bridge from all the bridges on the network. This is the bridge that contains the lowest bridge identifier. The protocol then selects a regional root bridge for each MSTR. This is the bridge that provides the best path to the CIST root. After the MSTR root bridges have been chosen, they then act on the region's behalf in such a way that the region appears to the Common Spanning Tree (CST) as a virtual bridge. So in addition to having multiple MSTIs, each region operates as a bridge in a CST.

CIST In addition to the individual MSTIs within each MSTP region, the MSTP region is a member of a network-wide spanning tree called the Common and Internal Spanning Tree (CIST). Conceptually, each region represents a virtual bridge. Internal and external bridge connectivity are two independent functions.

Frames with VIDs allocated to the CIST are subject to the rules and path costs of the complete bridged LAN as determined by the CIST's vectors. Frames other than these are subject to the CIST when travelling outside their region, and subject to its particular MSTI inside the region.

The following operational rules apply:

- Each bridge can be a member of only one region.
- A data frame is associated with a single VID.
- Data frames with a given VID are associated with either the CIST or their particular MSTI, but not both.

The role of the Common Spanning Tree (CST) in a network, and the Common and Internal Spanning Tree (CIST) configured on each device, is to prevent loops within a wider network that may span more than one MSTP region and parts of the network running in legacy STP or RSTP mode.

CIST first allocates root and designated bridges by selecting the bridge with the lowest identifier as the root. MSTP then deals with any loops between the regions in the CST. It does this by considering the CIST "vectors" in the following order:

1. CIST External Root Path Cost
2. CIST Regional Root Identifier
3. CIST Internal Root Path Cost
4. CIST Designated Bridge Identifier
5. CIST Designated Port Identifier
6. CIST Receiving Port Identifier

MSTP Bridge Protocol Data Units (BPDUs)

The main function of bridge protocol data units is to enable MSTP to select its root bridges for the CIST (“[Common and Internal Spanning Tree \(CIST\)](#)” on page 18.14) and each MSTI. MSTP is compatible with earlier spanning tree versions; its Bridge Protocol Data Unit (BPDU) formats build on earlier versions (“[Compatibility with Previous Spanning Tree Protocols](#)” on page 18.14).

Table 18-7 shows the standardized format for MSTP BPDU messages. The general format of the BPDUs comprise a common generic portion—octets 1 to 36—that are based on those defined in IEEE Standard 802.1D, 1998, followed by components that are specific to CIST—octets 37 to 102. Components specific to each MSTI are added to this BPDU data block.

Table 18-7: MSTP Bridge Protocol Data Units (BPDUs)

Field Name	Octets	Description
Protocol Identifier	1–2	Protocol being used. The value 0000 0000 0000 0000 identifies the spanning tree algorithm and protocol.
Protocol Version Identifier	3	Identifies the protocol version used.
BPDU Type	4	Value 0000 0000 specifies a configuration BPDU.
CIST Flags	5	Bit 1 is the topology change flag. Bit 2 conveys the CIST proposal flag in RST and MST BPDUs - unused in STP. Bits 3 & 4 convey the CIST port role in RST, and MST BPDUs - unused in STP. Bit 5 conveys the CIST learning flag in RST and MST BPDUs - unused in STP. Bit 6 conveys the CIST forwarding flag in RST and MST BPDUs - unused in STP. Bit 7 conveys the CIST agreement flag in RST and MST BPDUs - unused in STP. Bit 8 conveys the topology change acknowledge flag in STP configuration BPDUs - unused in RSTP and MSTP BPDUs.
CIST Root Identifier	6–13	The Bridge identifier of the CIST Root
CIST External Path Cost	14–17	The path cost between MST regions from the transmitting bridge to the CIST root.
CIST Regional Root Identifier	18–25	ID of the current CIST regional root bridge.
CIST Port Identifier	26–27	CIST port identifier of the transmitting bridge port.
Message Age	28–29	Message age timer value.
Max Age	30–31	Timeout value to be used by all bridges in the bridged network. This value is set by the root. Some implementations of MSTP may choose not to use this value.
Hello Time	32–33	Time interval between the generation of configuration BPDUs by the root bridge.
Forward Delay	34–35	A timeout value used to ensure forward delay timer consistency when transferring a port to the forwarding state. It is also used for ageing filtering database dynamic entries following changes in the active topology.

Table 18-7: MSTP Bridge Protocol Data Units (BPDUs)(Continued)

Field Name	Octets	Description
Version 1 Length	36	Used to convey the Version 1 length. It is always transmitted as 0.
Version 3 Length	37–38	Used to convey the Version 3 length. It is the number of octets taken by the parameters that follow in the BPDU.
MST Configuration Identifier	39–89	An identifier comprising elements of the following: Format Selector Configuration Name Revision Level Configuration Digest.
CIST Internal Root Path Cost	90–93	Path cost to the CIST regional root.
CIST Bridge Identifier	94–101	CIST bridge identifier of the transmitting bridge.
CIST Remaining Hops	102	Remaining hops which limits the propagation and longevity of received spanning tree information for the CIST.
MSTI Configuration Messages (may be absent)	103–39 plus Version 3 Length	See Table 18-8 .

Table 18-8: MSTI configuration messages

Field Name	Octets	Description
MSTI Flags	1	Bits 1 through 8, convey the topology change flag, proposal flag, port role (two bits), Learning flag, forwarding flag, agreement flag, and master flag for this MSTI.
MSTI Regional Root Identifier	2–9	This includes the value of the MSTID for this configuration message encoded in bits 4 through 1 of octet 1, and bits 8 through 1 of octet 2.
MSTI Internal Root Path Cost	10-13	Internal Root Path Cost.
MSTI Bridge Priority	14	Bits 5 through 8 convey the value of the bridge identifier priority for this MSTI. Bits 1 through 4 of Octet 14 are transmitted as 0, and ignored on receipt.
MSTI Port Priority	15	Bits 5 through 8 are used to convey the value of the port identifier priority for this MSTI. Bits 1 through 4 are transmitted as 0, and ignored on receipt.
MSTI Remaining Hops	16	Value of remaining hops for this MSTI.

Configuring MSTP

By default, RSTP is enabled with default settings on all switch ports. To configure MSTP, see the configuration procedure in [Table 18-9](#).

To configure other modes, see “Configuring RSTP” on page 18.8 or “Configuring STP” on page 18.6.

For detailed configuration examples, see the How To Note *How To Configure Basic Switching Functionality*, available from website at <http://www.alliedtelesis.com>.

Configuration guidelines for MSTP

- Switches must have the same MST configuration identification elements (region name, revision level and VLAN to MSTI mapping) to be in the same MST region. When configuring multiple MST regions for MSTP, MSTIs are locally significant within an MST region. MSTIs will not span from one region to another region.
- Common and Internal Spanning Tree (CIST) is the default spanning tree instance for MSTP. This means that all VLANs that are not explicitly configured into another MSTI are members of the CIST.
- The software supports a single instance of the MSTP Algorithm consisting of the CIST and up to 15 MSTIs.
- A VLAN can only be mapped to one MSTI or to the CIST. One VLAN mapped to multiple spanning trees is not allowed. All the VLANs are mapped to the CIST by default. Once a VLAN is mapped to a specified MSTI, it is removed from the CIST.
- An MSTI is locally significant within an MST region. An MSTI cannot span across multiple MST regions. The CIST is the spanning tree instance for connecting different MST regions and single spanning tree entities, such as RSTP and STP switches.
- MSTP is compatible with RSTP and STP. An MST region appears as a virtual bridge connecting to single spanning tree entities.
- To avoid unnecessary STP processing, a port that attaches to a LAN that is known to have no other bridges/switches attached can be configured as an edge port.

Before configuring MSTP

Before configuring MSTP, configure VLANs and associate them with switch ports ([Chapter 16, VLAN Introduction](#) and [Chapter 17, VLAN Commands](#)), and determine for your network:

- which MSTP regions, revision level and instances are required
- which VLANs and switch ports will belong to which MSTIs,
- which devices you want to be root bridges for each MSTI

Table 18-9: Configuration procedure for MSTP

Enable MSTP		
awplus#	configure terminal	Enter Configuration mode.
awplus(config)#	spanning-tree mode mstp	By default, the device is in RSTP mode. Change to MSTP mode.
awplus(config)#	spanning-tree {mstp rstp stp} enable	By default, spanning tree is enabled on all switch ports. If it has been disabled, enable it for MSTP.
Configure MSTP region, revision, and instances		
All MSTP devices in this region of the network must have the same region name, revision number, and VLAN to MSTI mappings.		
awplus(config)#	spanning-tree mst configuration	Enter MST Configuration mode.
awplus(config-mst)#	region <region-name>	Specify the MSTP region. The region is an arbitrary string that specifies the name you want to assign to the MST region for identification.

Table 18-9: Configuration procedure for MSTP

<code>awplus(config-mst)# revision <revision-number></code>	Specify the MSTP revision number <0-255>. The revision parameter specifies the revision of the current MST configuration. The revision is an arbitrary number that you assign to an MST region. It can be used to keep track of the number of times that MST configuration has been updated for the network.
<code>awplus(config-mst)# instance <msti-id> vlan {<vid> <vid-list>}</code>	To allow MSTP to block traffic for different VLANs in different places in a loop, create multiple MSTP instances and associate VLANs with them. Each VLAN can only be in one instance.

Advanced configuration

The commands above are the minimum required to configure MSTP. The following commands allow more advanced configuration.

Assign root bridge priorities

MSTP lets you distribute traffic more efficiently across a network by blocking different links for different VLANs. You do this by making different devices into the root bridge for each MSTP instance, and for the CIST, so that each instance blocks a different link. By default, all devices have the same root bridge priority, 32768 (8000 in hexadecimal), so the device with the lowest MAC address becomes the root bridge. If you want the device to be the root bridge for an instance or for the CIST, set the priority to a lower value (a higher priority) than other devices for this instance. (If you enter a number that is not a multiple of 4096, the device rounds the number down.)

<code>awplus(config-if)# spanning-tree mst configuration</code>	Enter MST Configuration mode.
<code>awplus(config-mst)# instance <msti-id> priority <priority></code>	Set the priority for the device to become the root bridge for each instance.
<code>awplus(config-mst)# exit</code>	Return to Global Configuration mode.
<code>awplus(config)# spanning-tree priority <priority></code>	Set the priority for the device to become the root bridge for the CIST.

Configure edge ports

If some switch ports are connected to devices that cannot generate BPDUs (such as workstations), you can set particular switch ports as edge ports, or set them to automatically detect whether they are edge ports.

<code>awplus(config-if)# interface (to configure) <port-list></code>	Enter Interface Configuration mode for these switch ports.
<code>awplus(config-if)# spanning-tree edgeport</code>	Set these ports to be edge ports,
<code>awplus(config-if)# or</code>	or
<code>spanning-tree autoedge</code>	to automatically detect whether they are edge ports.

Configure Root Guard

<code>awplus(config-if)# spanning-tree guard root</code>	The Root Guard feature makes sure that the port on which it is enabled is a designated port. If the Root Guard enabled port receives a superior BPDU, it goes to a Listening state (for STP) or discarding state (for RSTP and MSTP). Enable the Guard Root feature if required.
<code>awplus(config-if)# exit</code>	Return to Global Configuration mode.

Table 18-9: Configuration procedure for MSTP

Configure BPDU Guard		
awplus(config)#	spanning-tree portfast bpdu-guard	If required, enable the BPDU Guard feature, and configure timeout parameters.
awplus(config)#	spanning-tree errdisable-timeout enable	
awplus(config)#	spanning-tree errdisable-timeout interval <10-1000000>	
Check MSTP configuration		
awplus(config)#	exit	Return to Privileged Exec mode.
awplus#	show spanning-tree mst config	Check that the digest is the same on this device as for all other devices in the same region.
awplus#	show spanning-tree mst	Check the MST to VLAN and port mapping.
awplus#	show spanning-tree mst instance <msti-id>	Check the detailed information for a particular instance, and all switch ports associated with that instance.
awplus#	show spanning-tree [interface <port-list>]	Check general information about MSTP, and the CIST settings.

Advanced configuration:

For most networks, the default settings of the following will be suitable. However, you can also configure them.

- path costs for ports in an MSTI (`spanning-tree mst instance path-cost`) or for the CIST (`spanning-tree path-cost`)
- port priority for ports in an MSTI (`spanning-tree mst instance priority`) or for the CIST (`spanning-tree priority (port priority)`)

Chapter 19: Spanning Tree Commands

Command List	19.2
clear spanning-tree detected protocols (RSTP and MSTP)	19.2
debug mstp (RSTP and STP)	19.3
instance priority (MSTP)	19.6
instance vlan (MSTP)	19.7
region (MSTP)	19.8
revision (MSTP)	19.9
show debugging mstp	19.10
show spanning-tree	19.11
show spanning-tree mst	19.14
show spanning-tree mst config	19.15
show spanning-tree mst detail	19.16
show spanning-tree mst detail interface	19.18
show spanning-tree mst instance	19.19
show spanning-tree mst instance interface	19.20
show spanning-tree mst interface	19.21
spanning-tree autoedge (RSTP and MSTP)	19.22
spanning-tree cisco-interoperability (MSTP)	19.23
spanning-tree edgeport (RSTP and MSTP)	19.24
spanning-tree enable	19.25
spanning-tree errdisable-timeout enable	19.26
spanning-tree errdisable-timeout interval	19.27
spanning-tree force-version	19.28
spanning-tree forward-time	19.29
spanning-tree guard root	19.30
spanning-tree hello-time	19.31
spanning-tree link-type	19.32
spanning-tree max-age	19.33
spanning-tree max-hops (MSTP)	19.34
spanning-tree mode	19.35
spanning-tree mst configuration	19.35
spanning-tree mst instance	19.36
spanning-tree mst instance path-cost	19.37
spanning-tree mst instance priority	19.38
spanning-tree path-cost	19.39
spanning-tree portfast (STP)	19.40
spanning-tree portfast bpdu-filter	19.41
spanning-tree portfast bpdu-guard	19.42
spanning-tree priority (bridge priority)	19.44
spanning-tree priority (port priority)	19.45
spanning-tree transmit-holdcount	19.46

Command List

This chapter provides an alphabetical reference for commands used to configure RSTP, STP or MSTP. For information about spanning trees, including configuration procedures, see [Chapter 18, Spanning Tree Introduction: STP, RSTP, and MSTP](#)

clear spanning-tree detected protocols (RSTP and MSTP)

Use this command to clear the detected protocols for a specific port, or all ports.

Use this command in RSTP or MSTP mode only.

Syntax `clear spanning-tree detected protocols [interface <port>]`

Parameter	Description
<port>	The port to clear detected protocols for. The port may be a switch port (e.g., port1.1.4), a static channel group (e.g., sa3), or an LACP channel group (e.g., po4).

Mode Privileged Exec mode

Example

```
awplus# clear spanning-tree detected protocols
```

debug mstp (RSTP and STP)

Use this command to enable debugging for the configured spanning tree mode, and echo data to the console, at various levels. Note that although this command uses the keyword mstp it displays debugging output for RSTP and STP protocols as well the MSTP protocol.

Use the no parameter with this command, to disable spanning tree debugging.

Syntax

```
debug mstp {all|cli|protocol [detail]|timer [detail]}
debug mstp {packet {rx|tx} [decode] [interface <interface>]}
debug mstp {topology-change [interface <interface>]}
no debug mstp {all|cli|protocol [detail]|timer [detail]}
no debug mstp {packet {rx|tx} [decode] [interface <interface>]}
no debug mstp {topology-change [interface <interface>]}
```

Parameter	Description
all	echoes all spanning tree debugging levels to the console.
cli	echoes spanning tree commands to the console.
packet	echoes spanning tree packets to the console.
rx	received packets.
tx	transmitted packets.
protocol	echoes protocol changes to the console.
timer	echoes timer information to the console.
detail	detailed output.
decode	interprets packet contents
topology-change	interprets topology change messages
interface	keyword before <interface> placeholder to specify an interface to debug
<interface>	placeholder used to specify the name of the interface to debug.

Mode Privileged Exec and Global Configuration mode

Usage 1 Use the debug mstp topology-change interface command to generate debugging messages when the switch receives an indication of a topology change in a BPDU from another device. The debugging can be activated on a per-port basis. Although this command uses the keyword mstp, it displays debugging output for RSTP and STP protocols as well as the MSTP protocol.

Due to the likely volume of output, these debug messages are best viewed using the [terminal monitor command on page 8.46](#) before issuing the relevant debug mstp command. The default terminal monitor filter will select and display these messages. Alternatively, the messages can be directed to any of the other log outputs by adding a filter for the MSTP application using [log buffered \(filter\) command on page 10.14](#)

```
awplus# configure terminal
awplus(config)# log buffered program mstp
```

Output 1 :

```
awplus#terminal monitor
awplus#debug mstp topology-change interface port1.0.19
10:09:09 awplus MSTP[1409]: Topology change rcvd on port1.0.19 (internal)
10:09:09 awplus MSTP[1409]: Topology change rcvd on MSTI 1 port1.0.19
awplus#debug mstp topology-change interface port1.0.21
10:09:29 awplus MSTP[1409]: Topology change rcvd on port1.0.21 (external)
10:09:29 awplus MSTP[1409]: Topology change rcvd on MSTI 1 port1.0.21
```

Usage 2 Use the debug mstp packet rx|tx decode interface command to generate debugging messages containing the entire contents of a BPDU displayed in readable text for transmitted and received xSTP BPDUs. The debugging can be activated on a per-port basis and transmit and receive debugging is controlled independently. Although this command uses the keyword mstp, it displays debugging output for RSTP and STP protocols as well as the MSTP protocol.

Due to the likely volume of output, these debug messages are best viewed using the [terminal monitor command on page 8.46](#) before issuing the relevant debug mstp command. The default terminal monitor filter will select and display these messages. Alternatively, the messages can be directed to any of the other log outputs by adding a filter for the MSTP application using the [log buffered \(filter\) command on page 10.14](#):

```
awplus(config)# log buffered program mstp
```

Output 2 In MSTP mode - an MSTP BPDU with 1 MSTI:

```
awplus#terminal monitor
awplus#debug mstp packet rx decode interface port1.0.19
17:23:42 awplus MSTP[1417]: port1.0.19 xSTP BPDU rx - start
17:23:42 awplus MSTP[1417]: Protocol version: MSTP, BPDU type: RST
17:23:42 awplus MSTP[1417]: CIST Flags: Agree Forward Learn role=Desig
17:23:42 awplus MSTP[1417]: CIST root id : 0000:0000cd1000fe
17:23:42 awplus MSTP[1417]: CIST ext pathcost : 0
17:23:42 awplus MSTP[1417]: CIST reg root id : 0000:0000cd1000fe
17:23:42 awplus MSTP[1417]: CIST port id : 8001 (128:1)
17:23:42 awplus MSTP[1417]: msg age: 0 max age: 20 hellotime: 2 fwd delay: 15
17:23:42 awplus MSTP[1417]: Version 3 length : 80
17:23:42 awplus MSTP[1417]: Format id : 0
17:23:42 awplus MSTP[1417]: Config name : test
17:23:42 awplus MSTP[1417]: Revision level : 0
17:23:42 awplus MSTP[1417]: Config digest : 3ab68794d602fdf43b21c0b37ac3bca8
17:23:42 awplus MSTP[1417]: CIST int pathcost : 0
17:23:42 awplus MSTP[1417]: CIST bridge id : 0000:0000cd1000fe
17:23:42 awplus MSTP[1417]: CIST hops remaining : 20
17:23:42 awplus MSTP[1417]: MSTI flags : Agree Forward Learn role=Desig
17:23:42 awplus MSTP[1417]: MSTI reg root id : 8001:0000cd1000fe
17:23:42 awplus MSTP[1417]: MSTI pathcost : 0
17:23:42 awplus MSTP[1417]: MSTI bridge priority : 32768 port priority : 128
17:23:42 awplus MSTP[1417]: MSTI hops remaining : 20
17:23:42 awplus MSTP[1417]: port1.0.19 xSTP BPDU rx - finish
```


In STP mode transmitting a TCN BPDU:

```
awplus#terminal monitor
awplus#debug mstp packet tx decode interface port1.0.19
17:28:09 awplus MSTP[1417]: port1.0.19 xSTP BPDU tx - start
17:28:09 awplus MSTP[1417]: Protocol version: STP, BPDU type: TCN
17:28:09 awplus MSTP[1417]: port1.0.19 xSTP BPDU tx - finish
```

In STP mode receiving an STP BPDU:

```
awplus#terminal monitor
awplus#debug mstp packet rx decode interface port1.0.19
17:31:36 awplus MSTP[1417]: port1.0.19 xSTP BPDU rx - start
17:31:36 awplus MSTP[1417]: Protocol version: STP, BPDU type: Config
17:31:36 awplus MSTP[1417]: Flags: role=none
17:31:36 awplus MSTP[1417]: Root id      : 8000:0000cd1000fe
17:31:36 awplus MSTP[1417]: Root pathcost : 0
17:31:36 awplus MSTP[1417]: Bridge id   : 8000:0000cd1000fe
17:31:36 awplus MSTP[1417]: Port id     : 8001 (128:1)
17:31:36 awplus MSTP[1417]: msg age: 0 max age: 20 hellotime: 2 fwd delay: 15
17:31:36 awplus MSTP[1417]: port1.0.19 xSTP BPDU rx - finish
```

In RSTP mode receiving an RSTP BPDU:

```
awplus#terminal monitor
awplus#debug mstp packet rx decode interface port1.0.19
awplus#17:30:17 awplus MSTP[1417]: port1.0.19 xSTP BPDU rx - start
17:30:17 awplus MSTP[1417]: Protocol version: RSTP, BPDU type: RST
17:30:17 awplus MSTP[1417]: CIST Flags: Forward Learn role=Design
17:30:17 awplus MSTP[1417]: CIST root id      : 8000:0000cd1000fe
17:30:17 awplus MSTP[1417]: CIST ext pathcost : 0
17:30:17 awplus MSTP[1417]: CIST reg root id   : 8000:0000cd1000fe
17:30:17 awplus MSTP[1417]: CIST port id      : 8001 (128:1)
17:30:17 awplus MSTP[1417]: msg age: 0 max age: 20 hellotime: 2 fwd delay: 15
17:30:17 awplus MSTP[1417]: port1.0.19 xSTP BPDU rx - finish
```

Examples

```
awplus# debug mstp all

awplus# debug mstp cli

awplus# debug mstp packet rx

awplus# debug mstp protocol detail

awplus# debug mstp timer

awplus# debug mstp packet rx decode interface port1.0.2

awplus# debug mstp packet tx decode interface port1.0.12
```

Related commands [log buffered \(filter\)](#)
[show debugging mstp](#)
[terminal monitor](#)

instance priority (MSTP)

Use this command to set the priority for this device to become the root bridge for the specified MSTI.

Use this command for MSTP only.

Use the no version of this command to restore the root bridge priority of the device for the instance to the default.

Syntax `instance <msti-id> priority <priority>`
`no instance <msti-id> priority <priority>`

Parameter	Description
<code><msti-id></code>	The MST instance ID (1-15).
<code><priority></code>	<0-61440> Specify the root bridge priority for the device for the MSTI. A lower priority number indicates a greater likelihood of the device becoming the root bridge. The priority values can be set only in increments of 4096. If you specify a number that is not a multiple of 4096, it will be rounded down. Default: 32768

Default The default priority value for all instances is 32768.

Mode MST Configuration Mode

Usage MSTP lets you distribute traffic more efficiently across a network by blocking different links for different VLANs. You do this by making different devices into the root bridge for each MSTP instance, so that each instance blocks a different link.

If all devices have the same root bridge priority for the instance, MSTP selects the device with the lowest MAC address to be the root bridge. Give the device a higher priority for becoming the root bridge for a particular instance by assigning it a lower priority number, or vice versa.

Example To set the root bridge priority for MSTP instance 2 to be the highest (0), so that it will be the root bridge for this instance when available, use the commands:

```
awplus# configure terminal
awplus(config)# spanning-tree mst configuration
awplus(config-mst)# instance 2 priority 0
```

To reset the root bridge priority for instance 2 to the default (32768), use the commands:

```
awplus# configure terminal
awplus(config)# spanning-tree mst configuration
awplus(config-mst)# no instance 2 priority
```

Related Commands

- region (MSTP)
- revision (MSTP)
- show spanning-tree mst config
- spanning-tree mst instance
- spanning-tree mst instance priority

instance vlan (MSTP)

Use this command to create an MST Instance (MSTI), and associate the specified VLANs with it. An MSTI is a spanning tree instance that exists within an MST region (MSTR). An MSTR can contain up to 15 MSTIs.

When a VLAN is associated with an MSTI the member ports of the VLAN are automatically configured to send and receive spanning-tree information for the associated MSTI. You can disable this automatic configuration of member ports of the VLAN to the associated MSTI by using a no spanning-tree mst instance command to remove the member port from the MSTI.

Use the instance vlan command for MSTP only.

Use the no instance vlan command to remove the specified VLANs from the MSTI.

Syntax

```
instance <msti-id> vlan {<vid>|<vid-list>}
no instance <msti-id> vlan {<vid>|<vid-list>}
```

Parameter	Description
<msti-id>	Specify the MST instance ID (1-15).
<vid>	<1-4094> Specify a VLAN ID to be associated with the MSTI.
<vid-list>	A hyphen-separated range or a comma-separated list of VLAN IDs

Mode MST Configuration Mode

Usage The VLANs must be created before being associated with an MST instance (MSTI). If the VLAN range is not specified, the MSTI will not be created.

This command removes the specified VLANs from the CIST and adds them to the specified MSTI. If you use the no command to remove the VLAN from the MSTI, it returns it to the CIST. To move a VLAN from one MSTI to another, you must first use the no version of this command to return it to the CIST.

Ports in these VLANs will remain in the control of the CIST until you associate the ports with the MSTI using the [spanning-tree mst instance](#) command.

Example

```
awplus# configure terminal
awplus(config)# spanning-tree mode mstp
awplus(config)# spanning-tree mst configuration
awplus(config-mst)# instance 2 vlan 30
```

Related Commands [region \(MSTP\)](#)
[revision \(MSTP\)](#)
[show spanning-tree mst config](#)
[spanning-tree mst instance](#)
[vlan](#)

region (MSTP)

Use this command to assign a name to the device's MST Region. MST Instances (MSTI) of a region form different spanning trees for different VLANs.

Use this command for MSTP only.

Use the no version of the command to remove this region name and reset it to the default.

Syntax `region <region-name>`
`no region`

Parameter	Description
<code><region-name></code>	Specify the name of the region, up to 32 characters. Valid characters are upper-case, lower-case, digits, underscore.

Mode MST Configuration mode

Default By default, the region name is My Name.

Usage The region name, the revision number, and the digest of the VLAN to MSTI configuration table must be the same on all devices that are intended to be in the same MST region.

Examples

```
awplus# configure terminal
awplus(config)# spanning-tree mst configuration
awplus(config-mst)# region ATL
```

Related Commands [revision \(MSTP\)](#)
[show spanning-tree mst config](#)

revision (MSTP)

Use this command to specify the MST revision number to be used in the configuration identifier.

Use this command for MSTP only.

Syntax `revision <revision-number>`

Parameter	Description
<code><revision-number></code>	<code><0-255></code> Revision number.

Mode MST Configuration Mode

Default The default value of revision number is 0.

Usage The region name, the revision number, and the digest of the VLAN to MSTI configuration table must be the same on all devices that are intended to be in the same MST region.

Examples

```
awplus# configure terminal
awplus(config)# spanning-tree mst configuration
awplus(config-mst)# revision 25
```

Related Commands `region (MSTP)`
`show spanning-tree mst config`
`instance vlan (MSTP)`

show debugging mstp

Use this command to display the MSTP debugging option set.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show debugging mstp`

Mode Privileged Exec mode

Example

```
awplus# show debugging mstp
```

Output This is a sample output from the `show debugging mstp` command.

```
awplus# debug mstp packet rx
```

```
awplus# show debugging mstp
```

```
MSTP debugging status:  
MSTP receiving packet debugging is on
```

Related Commands [debug mstp \(RSTP and STP\)](#)

show spanning-tree

Use this command to display detailed spanning tree information on the specified port or on all ports. Use this command for RSTP, MSTP or STP.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show spanning-tree [interface <port-list>]`

Parameter	Description
interface	Display information about the following port only.
<port-list>	The ports to display information about. A port-list can be: ■ a switch port (e.g. port1.2.12) a static channel group (e.g., sa3) or a dynamic (LACP) channel group (e.g., po3) ■ a continuous range of ports separated by a hyphen, e.g., port1.0.1-1.0.24 or port1.1.1-port1.1.24 or po1-po4 ■ a comma-separated list of ports and port ranges, e.g. port1.0.1, port1.1.1-1.2.24. Do not mix switch ports, static channel groups, and LACP channel groups in the same list.

Mode Exec mode, Privileged Exec mode, and Interface mode

Usage Note that any list of interfaces specified must not span any interfaces that are not installed.

A topology change counter has been included for RSTP and MSTP. You can see the topology change counter for RSTP by using the show spanning-tree command. You can see the topology change counter for MSTP by using the show spanning-tree mst instance command.

Examples To display spanning tree information, use the command:

```
awplus# show spanning-tree
```

Output See the following sample command output for the example command below to display the state of the spanning tree for port1.0.23:

```
awplus>show spanning-tree interface port1.0.23
% 1: Bridge up - Spanning Tree Enabled
% 1: Root Path Cost 0 - Root Port 0 - Bridge Priority 32768
% 1: Forward Delay 15 - Hello Time 2 - Max Age 20
% 1: Root Id 80000000cd20f093
% 1: Bridge Id 80000000cd20f093
% 1: last topology change Sun Nov 20 12:24:24 1977
% 1: portfast bpdu-filter disabled
% 1: portfast bpdu-guard disabled
% 1: portfast errdisable timeout disabled
% 1: portfast errdisable timeout interval 300 sec
%   port1.0.23: Port 5023 - Id 839f - Role Designated - State Forwarding
%   port1.0.23: Designated Path Cost 0
%   port1.0.23: Configured Path Cost 200000 - Add type Explicit ref count 1
%   port1.0.23: Designated Port Id 839f - Priority 128 -
%   port1.0.23: Root 80000000cd20f093
%   port1.0.23: Designated Bridge 80000000cd20f093
%   port1.0.23: Message Age 0 - Max Age 20
%   port1.0.23: Hello Time 2 - Forward Delay 15
%   port1.0.23: Forward Timer 0 - Msg Age Timer 0 - Hello Timer 1 - topo change
timer 0
%   port1.0.23: forward-transitions 32
%   port1.0.23: Version Rapid Spanning Tree Protocol - Received None - Send RSTP
%   port1.0.23: No portfast configured - Current portfast off
%   port1.0.23: portfast bpdu-guard default - Current portfast bpdu-guard off
%   port1.0.23: portfast bpdu-filter default - Current portfast bpdu-filter off
%   port1.0.23: no root guard configured - Current root guard off
%   port1.0.23: Configured Link Type point-to-point - Current point-to-point
```


The following is a sample output of the `show spanning-tree` command in RSTP mode.

Figure 19-1: Example output from the `show spanning-tree` command

```
awplus#show spanning-tree
% 1: Bridge up - Spanning Tree Enabled
% 1: Root Path Cost 0 - Root Port 0 - Bridge Priority 32768
% 1: Forward Delay 15 - Hello Time 2 - Max Age 20
% 1: Root Id 80000000cd24ff2d
% 1: Bridge Id 80000000cd24ff2d
% 1: last topology change Thu Jul 26 02:06:26 2007
% 1: portfast bpdu-filter disabled
% 1: portfast bpdu-guard disabled
% 1: portfast errdisable timeout disabled
% 1: portfast errdisable timeout interval 300 sec
%   port1.0.1: Port 5001 - Id 8389 - Role Disabled - State Discarding
%   port1.0.1: Designated Path Cost 0
%   port1.0.1: Configured Path Cost 20000000 - Add type Explicit ref count 1
%   port1.0.1: Designated Port Id 8389 - Priority 128 -
%   port1.0.1: Root 80000000cd24ff2d
%   port1.0.1: Designated Bridge 80000000cd24ff2d
%   port1.0.1: Message Age 0 - Max Age 20
%   port1.0.1: Hello Time 2 - Forward Delay 15
%   port1.0.1: Forward Timer 0 - Msg Age Timer 0 - Hello Timer 0 - topo change timer
0
%   port1.0.1: forward-transitions 0
%   port1.0.1: Version Rapid Spanning Tree Protocol - Received None - Send STP
%   port1.0.1: No portfast configured - Current portfast off
%   port1.0.1: portfast bpdu-guard default - Current portfast bpdu-guard off
%   port1.0.1: portfast bpdu-filter default - Current portfast bpdu-filter off
%   port1.0.1: no root guard configured - Current root guard off
%   port1.0.1: Configured Link Type point-to-point - Current shared
%
%   port1.0.2: Port 5002 - Id 838a - Role Disabled - State Discarding
%   port1.0.2: Designated Path Cost 0
%   port1.0.2: Configured Path Cost 20000000 - Add type Explicit ref count 1
%   port1.0.2: Designated Port Id 838a - Priority 128 -
%   port1.0.2: Root 80000000cd24ff2d
%   port1.0.2: Designated Bridge 80000000cd24ff2d
%   port1.0.2: Message Age 0 - Max Age 20
%   port1.0.2: Hello Time 2 - Forward Delay 15
%   port1.0.2: Forward Timer 0 - Msg Age Timer 0 - Hello Timer 0 - topo change timer
0
%   port1.0.2: forward-transitions 0
%   port1.0.2: Version Rapid Spanning Tree Protocol - Received None - Send STP
%   port1.0.2: No portfast configured - Current portfast off
%   port1.0.2: portfast bpdu-guard default - Current portfast bpdu-guard off
%   port1.0.2: portfast bpdu-filter default - Current portfast bpdu-filter off
%   port1.0.2: no root guard configured - Current root guard off
%   port1.0.2: Configured Link Type point-to-point - Current shared
%
```

show spanning-tree mst

This command displays bridge-level information about the CIST and VLAN to MSTI mappings.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show spanning-tree mst`

Mode Exec mode, Privileged Exec mode, and Interface mode

Example The following is an output of this command displaying the number of instances created, and the VLANs associated with it.

```
awplus#show spanning-tree mst
% 1: Bridge up - Spanning Tree Enabled
% 1: CIST Root Path Cost 0 - CIST Root Port 0 - CIST Bridge
Priority 32768
% 1: Forward Delay 15 - Hello Time 2 - Max Age 20 - Max-hops 20
% 1: CIST Root Id 8000000475e93ffe
% 1: CIST Reg Root Id 8000000475e93ffe
% 1: CST Bridge Id 8000000475e93ffe
% 1: portfast bpdu-filter disabled
% 1: portfast bpdu-guard disabled
% 1: portfast errdisable timeout disabled
% 1: portfast errdisable timeout interval 300 sec
%
%      Instance      VLAN
%  0:                1
%  2:                4
```

Related Commands [show spanning-tree mst interface](#)

show spanning-tree mst config

Use this command to display MSTP configuration identifier for the device.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax show spanning-tree mst config

Mode Exec mode, Privileged Exec mode, and Interface mode

Usage The region name, the revision number, and the digest of the VLAN to MSTI configuration table must be the same on all devices that are intended to be in the same MST region.

Example The following show output displays the MSTP configuration identifier.

```
awplus#show spanning-tree mst config
%
% MSTP Configuration Information:
%-----
% Format Id       : 0
% Name           : My Name
% Revision Level  : 0
% Digest         : 0x80DEE46DA92A98CF21C603291B22880A
%-----
```

Related Commands instance vlan (MSTP)
region (MSTP)
revision (MSTP)

show spanning-tree mst detail

This command prints the detailed information about each instance, and all interfaces associated with that particular instance.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax show spanning-tree mst detail

Mode Exec mode, Privileged Exec mode, and Interface mode

Usage The following is an output of this command displaying detailed information about each instance, and all interfaces associated with them.

Figure 19-2: Example output from the **show spanning-tree mst detail** command

```
awplus#sh spanning-tree mst detail
% 1: Bridge up - Spanning Tree Enabled
% 1: CIST Root Path Cost 0 - CIST Root Port 0 - CIST Bridge Priority 32768
% 1: Forward Delay 15 - Hello Time 2 - Max Age 20 - Max-hops 20
% 1: CIST Root Id 80000000cd24ff2d
% 1: CIST Reg Root Id 80000000cd24ff2d
% 1: CIST Bridge Id 80000000cd24ff2d
% 1: portfast bpdu-filter disabled
% 1: portfast bpdu-guard disabled
% 1: portfast errdisable timeout disabled
% 1: portfast errdisable timeout interval 300 sec
%   port1.0.1: Port 5001 - Id 8389 - Role Disabled - State Discarding
%   port1.0.1: Designated External Path Cost 0 -Internal Path Cost 0
%   port1.0.1: Configured Path Cost 20000000 - Add type Explicit ref count 1
%   port1.0.1: Designated Port Id 8389 - CIST Priority 128 -
%   port1.0.1: CIST Root 80000000cd24ff2d
%   port1.0.1: Regional Root 80000000cd24ff2d
%   port1.0.1: Designated Bridge 80000000cd24ff2d
%   port1.0.1: Message Age 0 - Max Age 20
%   port1.0.1: CIST Hello Time 2 - Forward Delay 15
%   port1.0.1: CIST Forward Timer 0 - Msg Age Timer 0 - Hello Timer 0 - topo change timer 0
%   port1.0.1: forward-transitions 0
%   port1.0.1: Version Multiple Spanning Tree Protocol - Received None - Send STP
%   port1.0.1: No portfast configured - Current portfast off
%   port1.0.1: portfast bpdu-guard default - Current portfast bpdu-guard off
%   port1.0.1: portfast bpdu-filter default - Current portfast bpdu-filter off
%   port1.0.1: no root guard configured - Current root guard off
%   port1.0.1: Configured Link Type point-to-point - Current shared
%
%   port1.0.2: Port 5002 - Id 838a - Role Disabled - State Discarding
%   port1.0.2: Designated External Path Cost 0 -Internal Path Cost 0
%   port1.0.2: Configured Path Cost 20000000 - Add type Explicit ref count 1
%   port1.0.2: Designated Port Id 838a - CIST Priority 128 -
%   port1.0.2: CIST Root 80000000cd24ff2d
%   port1.0.2: Regional Root 80000000cd24ff2d
%   port1.0.2: Designated Bridge 80000000cd24ff2d
%   port1.0.2: Message Age 0 - Max Age 20
%   port1.0.2: CIST Hello Time 2 - Forward Delay 15
%   port1.0.2: CIST Forward Timer 0 - Msg Age Timer 0 - Hello Timer 0 - topo change timer 0
%   port1.0.2: forward-transitions 0
%   port1.0.2: Version Multiple Spanning Tree Protocol - Received None - Send STP
%   port1.0.2: No portfast configured - Current portfast off
%   port1.0.2: portfast bpdu-guard default - Current portfast bpdu-guard off
%   port1.0.2: portfast bpdu-filter default - Current portfast bpdu-filter off
%   port1.0.2: no root guard configured - Current root guard off
%   port1.0.2: Configured Link Type point-to-point - Current shared
%
```

Figure 19-2: Example output from the **show spanning-tree mst detail** command (Continued)

```
% port1.0.3: Port 5003 - Id 838b - Role Disabled - State Discarding
% port1.0.3: Designated External Path Cost 0 -Internal Path Cost 0
% port1.0.3: Configured Path Cost 20000000 - Add type Explicit ref count 1
% port1.0.3: Designated Port Id 838b - CIST Priority 128 -
% port1.0.3: CIST Root 80000000cd24ff2d
% port1.0.3: Regional Root 80000000cd24ff2d
% port1.0.3: Designated Bridge 80000000cd24ff2d
% port1.0.3: Message Age 0 - Max Age 20
% port1.0.3: CIST Hello Time 2 - Forward Delay 15
% port1.0.3: CIST Forward Timer 0 - Msg Age Timer 0 - Hello Timer 0 - topo change timer 0
% port1.0.3: forward-transitions 0
% port1.0.3: Version Multiple Spanning Tree Protocol - Received None - Send STP
% port1.0.3: No portfast configured - Current portfast off
% port1.0.3: portfast bpdu-guard default - Current portfast bpdu-guard off
% port1.0.3: portfast bpdu-filter default - Current portfast bpdu-filter off
% port1.0.3: no root guard configured - Current root guard off
% port1.0.3: Configured Link Type point-to-point - Current shared
```

show spanning-tree mst detail interface

This command prints detailed information about the specified switch port, and the MST instances associated with it.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax show spanning-tree mst detail interface <port>

Parameter	Description
<port>	The port to display information about. The port may be a switch port (e.g., port1.1.4), a static channel group (e.g., sa3), or an LACP channel group (e.g., po4).

Mode Exec mode, Privileged Exec mode, and Interface mode

Example The following is an output of this command displaying detailed information about port1.1.3 and the instances associated with it.

Figure 19-3: Example output from the **show spanning-tree mst detail interface** command

```
awplus#sh spanning-tree mst detail int port1.0.2
% 1: Bridge up - Spanning Tree Enabled
% 1: CIST Root Path Cost 0 - CIST Root Port 0 - CIST Bridge Priority 32768
% 1: Forward Delay 15 - Hello Time 2 - Max Age 20 - Max-hops 20
% 1: CIST Root Id 80000000cd24ff2d
% 1: CIST Reg Root Id 80000000cd24ff2d
% 1: CIST Bridge Id 80000000cd24ff2d
% 1: portfast bpdu-filter disabled
% 1: portfast bpdu-guard disabled
% 1: portfast errdisable timeout disabled
% 1: portfast errdisable timeout interval 300 sec
% port1.0.2: Port 5002 - Id 838a - Role Disabled - State Discarding
% port1.0.2: Designated External Path Cost 0 - Internal Path Cost 0
% port1.0.2: Configured Path Cost 20000000 - Add type Explicit ref count 2
% port1.0.2: Designated Port Id 838a - CIST Priority 128 -
% port1.0.2: CIST Root 80000000cd24ff2d
% port1.0.2: Regional Root 80000000cd24ff2d
% port1.0.2: Designated Bridge 80000000cd24ff2d
% port1.0.2: Message Age 0 - Max Age 20
% port1.0.2: CIST Hello Time 2 - Forward Delay 15
% port1.0.2: CIST Forward Timer 0 - Msg Age Timer 0 - Hello Timer 0 - topo change timer 0
% port1.0.2: forward-transitions 0
% port1.0.2: Version Multiple Spanning Tree Protocol - Received None - Send STP
% port1.0.2: No portfast configured - Current portfast off
% port1.0.2: portfast bpdu-guard default - Current portfast bpdu-guard off
% port1.0.2: portfast bpdu-filter default - Current portfast bpdu-filter off
% port1.0.2: no root guard configured - Current root guard off
% port1.0.2: Configured Link Type point-to-point - Current shared
%
% Instance 2: Vlans: 2
% 1: MSTI Root Path Cost 0 -MSTI Root Port 0 - MSTI Bridge Priority 32768
% 1: MSTI Root Id 80020000cd24ff2d
% 1: MSTI Bridge Id 80020000cd24ff2d
% port1.0.2: Port 5002 - Id 838a - Role Disabled - State Discarding
% port1.0.2: Designated Internal Path Cost 0 - Designated Port Id 838a
% port1.0.2: Configured Internal Path Cost 20000000
% port1.0.2: Configured CST External Path cost 20000000
% port1.0.2: CST Priority 128 - MSTI Priority 128
% port1.0.2: Designated Root 80020000cd24ff2d
% port1.0.2: Designated Bridge 80020000cd24ff2d
% port1.0.2: Message Age 0 - Max Age 0
```

Figure 19-3: Example output from the **show spanning-tree mst detail interface** command (Continued)

```
% port1.0.2: Hello Time 2 - Forward Delay 15
% port1.0.2: Forward Timer 0 - Msg Age Timer 0 - Hello Timer 0
```

show spanning-tree mst instance

This command displays detailed information for the specified instance, and all switch ports associated with that instance.

A topology change counter has been included for RSTP and MSTP. You can see the topology change counter for RSTP by using the [show spanning-tree](#) command. You can see the topology change counter for MSTP by using the [show spanning-tree mst instance](#) command.

For information on output options, see [“Controlling “show” command output” on page 1.33](#).

Syntax `show spanning-tree mst instance <msti-id>`

Parameter	Description
<msti-id>	Specify the MST instance ID for which information needs to be displayed.

Mode Exec mode, Privileged Exec mode, and Interface mode

Usage The following is an output of this command displaying detailed information for instance 2.

```
awplus#sh spanning-tree mst instance 2
% 1: MSTI Root Path Cost 0 - MSTI Root Port 0 - MSTI Bridge Priority 32768
% 1: MSTI Root Id 80020000cd24ff2d
% 1: MSTI Bridge Id 80020000cd24ff2d
% port1.0.2: Port 5002 - Id 838a - Role Disabled - State Discarding
% port1.0.2: Designated Internal Path Cost 0 - Designated Port Id 838a
% port1.0.2: Configured Internal Path Cost 20000000
% port1.0.2: Configured CST External Path cost 20000000
% port1.0.2: CST Priority 128 - MSTI Priority 128
% port1.0.2: Designated Root 80020000cd24ff2d
% port1.0.2: Designated Bridge 80020000cd24ff2d
% port1.0.2: Message Age 0 - Max Age 0
% port1.0.2: Hello Time 2 - Forward Delay 15
% port1.0.2: Forward Timer 0 - Msg Age Timer 0 - Hello Timer 0
%
```

show spanning-tree mst instance interface

This command displays detailed information for the specified instance, and the specified switch port associated with that instance.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show spanning-tree mst instance <1-15> interface <port>`

Parameter	Description
<code><port></code>	The port to display information about. The port may be a switch port (e.g., port1.1.4), a static channel group (e.g., sa3), or an LACP channel group (e.g., po4).

Mode Exec mode, Privileged Exec mode, and Interface mode

Example

```
awplus#sh spanning-tree mst instance 2 interface port1.0.2
% 1: MSTI Root Path Cost 0 - MSTI Root Port 0 - MSTI Bridge Priority 32768
% 1: MSTI Root Id 80020000cd24ff2d
% 1: MSTI Bridge Id 80020000cd24ff2d
% port1.0.2: Port 5002 - Id 838a - Role Disabled - State Discarding
% port1.0.2: Designated Internal Path Cost 0 - Designated Port Id 838a
% port1.0.2: Configured Internal Path Cost 20000000
% port1.0.2: Configured CST External Path cost 20000000
% port1.0.2: CST Priority 128 - MSTI Priority 128
% port1.0.2: Designated Root 80020000cd24ff2d
% port1.0.2: Designated Bridge 80020000cd24ff2d
% port1.0.2: Message Age 0 - Max Age 0
% port1.0.2: Hello Time 2 - Forward Delay 15
% port1.0.2: Forward Timer 0 - Msg Age Timer 0 - Hello Timer 0
%
```


show spanning-tree mst interface

This command displays the number of instances created, and VLANs associated with it for the specified switch port.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show spanning-tree mst interface <port>`

Parameter	Description
<port>	The port to display information about. The port may be a switch port (e.g., port1.1.4), a static channel group (e.g., sa3), or an LACP channel group (e.g., po4).

Mode Exec mode, Privileged Exec mode, and Interface mode

Example The following is an output of this command displaying detailed information about each instance, and all interfaces associated with them for port1.1.4.

```
awplus#show spanning-tree mst interface port1.1.4
% 1: Bridge up - Spanning Tree Enabled
% 1: CIST Root Path Cost 0 - CIST Root Port 0 - CIST Bridge Priority 32768
% 1: Forward Delay 15 - Hello Time 2 - Max Age 20 - Max-hops 20
% 1: CIST Root Id 80000008c73a2b22
% 1: CIST Reg Root Id 80000008c73a2b22
% 1: CST Bridge Id 80000008c73a2b22
% 1: portfast bpdu-filter disabled
% 1: portfast bpdu-guard disabled
% 1: portfast errdisable timeout disabled
% 1: portfast errdisable timeout interval 1 sec
%
% Instance      VLAN
% 0:            1
% 1:            2-3
% 2:            4-5
```

spanning-tree autoedge (RSTP and MSTP)

Use this command to enable the autoedge feature on the port.

The autoedge feature allows the port to automatically detect that it is an edge port. If it does not receive any BPDUs in the first three seconds after linkup, enabling, or entering RSTP or MSTP mode, it sets itself to be an edgeport and enters the forwarding state.

Use this command for RSTP or MSTP.

Use the no parameter with this command to disable this feature.

Syntax spanning-tree autoedge
 no spanning-tree autoedge

Default Disabled.

Mode Interface mode

Example

```
awplus# configure terminal
awplus(config)# interface port1.1.3
awplus(config-if)# spanning-tree autoedge
```

Related commands [spanning-tree edgeport \(RSTP and MSTP\)](#)

spanning-tree cisco-interoperability (MSTP)

Use this command to enable/disable Cisco-interoperability for MSTP.

Use this command for MSTP only.

Syntax `spanning-tree cisco-interoperability {enable|disable}`

Parameter	Description
enable	Enable Cisco interoperability for MSTP.
disable	Disable Cisco interoperability for MSTP.

Default If this command is not used, Cisco interoperability is disabled.

Mode Global Configuration mode

Usage For compatibility with certain Cisco devices, all devices in the switched LAN running the AlliedWare Plus™ Operating System must have Cisco-interoperability enabled. When the AlliedWare Plus™ Operating System is interoperating with Cisco, the only criteria used to classify a region are the region name and revision level. VLAN to instance mapping is not used to classify regions when interoperating with Cisco.

Examples To enable Cisco interoperability on a Layer-2 switch:

```
awplus# configure terminal
awplus(config)# spanning-tree cisco-interoperability enable
```

To disable Cisco interoperability on a Layer-2 switch:

```
awplus# configure terminal
awplus(config)# spanning-tree cisco-interoperability disable
```

spanning-tree edgeport (RSTP and MSTP)

Use this command to set a port as an edge-port.

Use this command for RSTP or MSTP.

This command has the same effect as the [spanning-tree portfast \(STP\)](#) command, but the configuration displays differently in the output of some show commands.

Use the no parameter with this command to set a port to its default state (not an edge-port).

Syntax spanning-tree edgeport
 no spanning-tree edgeport

Default Not an edge port.

Mode Interface mode

Usage Use this command on a switch port connected to a LAN that has no other bridges attached. If a BPDU is received on the port that indicates that another bridge is connected to the LAN, then the port is no longer treated as an edge port.

Example

```
awplus# configure terminal
awplus(config)# interface port1.1.2
awplus(config-if)# spanning-tree edgeport
```

Related commands [spanning-tree autoedge \(RSTP and MSTP\)](#)

spanning-tree enable

Use this command to enable or disable the specified spanning tree protocol on the device. Note that this must be the spanning tree protocol that is configured on the device by the [spanning-tree mode](#) command.

Use the no version of this command to disable the configured spanning tree protocol. This places all ports in the forwarding state.

Syntax `spanning-tree {mstp|rstp|stp} enable`
`no spanning-tree {mstp|rstp|stp} enable`

Parameter	Description
mstp	Enables or disables MSTP
rstp	Enables or disables RSTP
stp	Enables or disables STP

Mode Global Configuration mode

Default The configured spanning tree mode is enabled by default.

Usage With no configuration, spanning tree is enabled, and the spanning tree mode is set to RSTP. To change the mode, see [spanning-tree mode command on page 19.35](#).

Examples

```
awplus# configure terminal
awplus(config)# spanning-tree mstp enable

awplus# configure terminal
awplus(config)# no spanning-tree mstp enable
```

Related commands [spanning-tree mode](#)

spanning-tree errdisable-timeout enable

Use this command to enable the errdisable-timeout facility, which sets a timeout for ports that are disabled due to the BPDU guard feature.

Use this command for RSTP or MSTP.

Syntax spanning-tree errdisable-timeout enable
 no spanning-tree errdisable-timeout enable

Mode Global Configuration mode

Default By default, the errdisable-timeout is disabled.

Usage The BPDU guard feature shuts down the port on receiving a BPDU on a BPDU-guard enabled port. This command associates a timer with the feature such that the port is re-enabled without manual intervention after a set interval. This interval can be configured by the user using the [spanning-tree errdisable-timeout interval](#) command.

Example

```
awplus# configure terminal
awplus(config)# spanning-tree errdisable-timeout enable
```

Related Commands [show spanning-tree](#)
 [spanning-tree errdisable-timeout interval](#)
 [spanning-tree portfast bpdu-guard](#)

spanning-tree errdisable-timeout interval

Use this command to specify the time interval after which a port is brought back up when it has been disabled by the BPDU guard feature.

Use this command for RSTP or MSTP.

Syntax `spanning-tree errdisable-timeout interval <10-1000000>`
`no spanning-tree errdisable-timeout interval`

Parameter	Description
<code><10-1000000></code>	Specify the errdisable-timeout interval in seconds.

Mode Global Configuration mode

Default By default, the port is re-enabled after 300 seconds.

Example

```
awplus# configure terminal
awplus(config)# spanning-tree errdisable-timeout interval 34
```

Related Commands `show spanning-tree`
 `spanning-tree errdisable-timeout enable`
 `spanning-tree portfast bpdu-guard`

spanning-tree force-version

Use this command to force the protocol version for the switch port. Use this command for RSTP or MSTP only.

Syntax `spanning-tree force-version <version>`
`no spanning-tree force-version`

Parameter	Description
<code><version></code>	<0-3> Version identifier. 0 - Forces the port to operate in STP mode 1- Not supported 2 - Forces the port to operate in RSTP mode. If it receives STP BPDUs, it can automatically revert to STP mode. 3 - Forces the port to operate in MSTP mode (this option is only available if MSTP mode is configured.) If it receives RSTP or STP BPDUs, it can automatically revert to RSTP or STP mode.

Mode Interface mode

Default By default, no version is forced for the port. The port is in the spanning tree mode configured for the device, or a lower version if it automatically detects one.

Examples Set the value to enforce the spanning tree protocol (STP):

```
awplus# configure terminal
awplus(config)# interface port1.1.2
awplus(config-if)# spanning-tree force-version 0
```

Set the default protocol version:

```
awplus# configure terminal
awplus(config)# interface port1.1.2
awplus(config-if)# no spanning-tree force-version
```

Related Commands `show spanning-tree`

spanning-tree forward-time

Use this command to set the forward delay.

The forward delay sets the time (in seconds) to control how fast a port changes its spanning tree state when moving towards the forwarding state. If the mode is set to STP, the value determines how long the port stays in each of the listening and learning states which precede the forwarding state. If the mode is set to RSTP or MSTP, this value determines the maximum time taken to transition from discarding to learning and from learning to forwarding.

This value is used only when the switch is acting as the root bridge. Switches not acting as the Root Bridge use a dynamic value for the forward delay set by the root bridge. The forward delay, max-age, and hello time parameters are interrelated.

Syntax `spanning-tree forward-time <forward-delay>`
`no spanning-tree forward-time`

Parameter	Description
<code><forward-delay></code>	<code><4-30></code> the forwarding time delay in seconds.

Mode Global Configuration mode

Default The default value is 15 seconds.

Usage The allowable range for forward-time is 4-30 seconds.

The forward delay, max-age, and hello time parameters should be set according to the following formulae, as specified in IEEE Standard 802.1d:

$$2 \times (\text{forward delay} - 1.0 \text{ seconds}) \geq \text{max-age}$$

$$\text{max-age} \geq 2 \times (\text{hello time} + 1.0 \text{ seconds})$$

Example

```
awplus# configure terminal
awplus(config)# spanning-tree forward-time 6
```

Related Commands `show spanning-tree`
`spanning-tree forward-time <forward-delay>`
`spanning-tree hello-time <hello-time>`
`spanning-tree mode`

spanning-tree guard root

Use this command to enable the Root Guard feature for the port. The root guard feature disables reception of superior BPDUs.

Use this command for RSTP, STP or MSTP.

Use the no parameter with this command to disable the root guard feature for the port.

Syntax spanning-tree guard root
 no spanning-tree guard root

Mode Interface mode

Usage The Root Guard feature makes sure that the port on which it is enabled is a designated port. If the Root Guard enabled port receives a superior BPDU, it goes to a Listening state (for STP) or discarding state (for RSTP and MSTP).

Example

```
awplus# configure terminal
awplus(config)# interface port1.1.2
awplus(config-if)# spanning-tree guard root
```

spanning-tree hello-time

Use this command to set the hello-time. This sets the time in seconds between the transmission of switch spanning tree configuration information when the switch is the Root Bridge of the spanning tree or is trying to become the Root Bridge.

Use this command for RSTP, STP or MSTP.

To restore the default value of the hello time, use the `no` parameter.

Syntax `spanning-tree hello-time <hello-time>`
`no spanning-tree hello-time`

Parameter	Description
<code><hello-time></code>	<code><1-10></code> The hello BPDU interval in seconds.

Mode Global Configuration mode

Default Default value is 2 seconds.

Usage The allowable range of values is 1-10 seconds.

The forward delay, max-age, and hello time parameters should be set according to the following formulae, as specified in IEEE Standard 802.1d:

$$2 \times (\text{forward delay} - 1.0 \text{ seconds}) \geq \text{max-age}$$

$$\text{max-age} \geq 2 \times (\text{hello time} + 1.0 \text{ seconds})$$

Example

```
awplus# configure terminal
awplus(config)# spanning-tree hello-time 3
```

Related Commands `spanning-tree forward-time <forward-delay>`
`spanning-tree max-age <max-age>`
`show spanning-tree`

spanning-tree link-type

Use this command to enable or disable point-to-point or shared link types on the switch port.

Use this command for RSTP or MSTP only.

Use the no parameter to return the port to the default link type.

Syntax `spanning-tree link-type {point-to-point|shared}`
`no spanning-tree link-type`

Parameter	Description
shared	Disable rapid transition.
point-to-point	Enable rapid transition.

Default The default link type is point-to-point.

Mode Interface mode

Usage You may want to set link type to shared if the port is connected to a hub with multiple switches connected to it.

Examples

```
awplus# configure terminal
awplus(config)# interface port1.1.3
awplus(config-if)# spanning-tree link-type point-to-point
```

spanning-tree max-age

Use this command to set the max-age. This sets the maximum age, in seconds, that dynamic spanning tree configuration information is stored in the switch before it is discarded.

Use this command for RSTP, STP or MSTP.

Use the no parameter with this command to restore the default value of max-age.

Syntax `spanning-tree max-age <max-age>`
`no spanning-tree max-age`

Parameter	Description
<max-age>	<6-40> The maximum time, in seconds.

Mode Global Configuration mode

Default The default value of spanning-tree max-age is 20 seconds.

Usage Max-age is the maximum time in seconds for which a message is considered valid.

Configure this value sufficiently high, so that a frame generated by the root bridge can be propagated to the leaf nodes without exceeding the max-age.

The forward delay, max-age, and hello time parameters should be set according to the following formulae, as specified in IEEE Standard 802.1d:

$$2 \times (\text{forward delay} - 1.0 \text{ seconds}) \geq \text{max-age}$$

$$\text{max-age} \geq 2 \times (\text{hello time} + 1.0 \text{ seconds})$$

Example

```
awplus# configure terminal
awplus(config)# spanning-tree max-age 12
```

Related Commands `show spanning-tree`
`spanning-tree forward-time <forward-delay>`
`spanning-tree hello-time <hello-time>`

spanning-tree max-hops (MSTP)

Use this command to specify the maximum allowed hops for a BPDU in an MST region. This parameter is used by all the instances of the MST region. To restore the default value, use the no parameter with this command.

Use this command for MSTP only.

Syntax `spanning-tree max-hops <hop-count>`
`no spanning-tree max-hops`

Parameter	Description
<code><hop-count></code>	Maximum hops the BPDU will be valid for.

Mode Global Configuration mode

Default The default max-hops in a MST region is 20.

Usage Specifying the max hops for a BPDU prevents the messages from looping indefinitely in the network. The hop count is decremented by each receiving port. When a switch receives an MST BPDU that has a hop count of zero, it discards the BPDU.

Examples

```
awplus# configure terminal
awplus(config)# spanning-tree max-hops 25
```

spanning-tree mode

Use this command to change the spanning tree protocol mode on the device. This can be either STP, RSTP, or MSTP.

Syntax `spanning-tree mode {stp|rstp|mstp}`

Default The default mode is RSTP.

Usage With no configuration, the device will have spanning tree enabled, and the spanning tree mode will be set to RSTP. Use this command to change the spanning tree protocol mode on the device. MSTP is VLAN aware, but RSTP and STP are not VLAN aware. To enable or disable spanning tree operation, see the [spanning-tree enable command on page 19.25](#).

Mode Global Configuration mode

Examples To change the spanning tree mode from the default of RSTP to MSTP, use the following commands:

```
awplus# configure terminal
awplus(config)# spanning-tree mode mstp
```

Related commands [spanning-tree enable](#)

spanning-tree mst configuration

Use this command to enter the MST Configuration mode to configure the Multiple Spanning-Tree Protocol.

Syntax `spanning-tree mst configuration`

Mode Global Configuration mode

Examples The following example uses this command to enter MST configuration mode. Note the change in the command prompt.

```
awplus# configure terminal
awplus(config)# spanning-tree mst configuration
awplus(config-mst)#
```

spanning-tree mst instance

Use this command to assign a Multiple Spanning Tree instance (MSTI) to a switch port or channel group.

Note that ports are automatically configured to send and receive spanning-tree information for the associated MSTI when VLANs are assigned to MSTIs using the [instance vlan \(MSTP\)](#) command.

You can disable automatic configuration of member ports of a VLAN to an associated MSTI by using a `no spanning-tree mst instance` command to remove the member port from the MSTI. Use the `spanning-tree mst instance` command to add a VLAN member port back to the MSTI.

Use the `no spanning-tree mst instance` command to remove the MSTI from this port.

Syntax `spanning-tree mst instance <instance-id>`
`no spanning-tree mst instance`

Parameter	Description
<code><instance-id></code>	<1-15> Specify the instance ID. The instance must have already been created using the instance vlan (MSTP) command.

Mode Interface mode

Default A port automatically becomes a member of MSTI(s) when it is assigned to VLAN(s).

Examples

```
awplus# configure terminal
awplus(config)# interface port1.1.2
awplus(config-if)# spanning-tree mst instance 3
```

Related Commands [instance vlan \(MSTP\)](#)

spanning-tree mst instance path-cost

Use this command to set the cost of a path associated with a port, for the specified MSTI.

This specifies the port's contribution to the cost of a path to the MSTI regional root via that port. This applies when the port is the root port for the MSTI.

Use the no parameter with this command to restore the default cost value of the path.

Syntax `spanning-tree mst instance <instance-id> path-cost <1-200000000>`
`no spanning-tree mst instance <instance-id> path-cost`

Parameter	Description
<instance-id>	Specify the instance identifier <1-15>
path-cost	<1-200000000> Specify the cost of path in the range of <1-200000000> (a lower path-cost indicates a greater likelihood of the specific interface becoming a root).

Mode Interface mode

Default The default path cost values and the range of recommended path cost values depend on the port speed, as shown in the following table from the IEEE 802.1q-2003 standard.

Port speed	Default path cost	Recommended path cost range
Less than 100 Kb/s	200,000,000	20,000,000-200,000,000
1Mbps	20,000,000	2,000,000-20,000,000
10Mbps	2,000,000	200,000-2,000,000
100 Mbps	200,000	20,000-200,000
1 Gbps	20,000	2,000-20,000
10 Gbps	2,000	200-2,000
100 Gbps	200	20-200
1Tbps	20	2-200
10 Tbps	2	2-20

Usage Before you can use this command to set a path-cost in a VLAN configuration, you must explicitly add an MST instance to a port using the `spanning-tree instance` command.

Example

```
awplus# configure terminal
awplus(config)# interface port1.1.2
awplus(config-if)# spanning-tree mst instance 3 path-cost 1000
```

Related Commands `instance vlan (MSTP)`
`spanning-tree mst instance`

spanning-tree mst instance priority

Use this command to set the port priority for an MST instance (MSTI).

This sets the value of the priority field contained in the port identifier. The MST algorithm uses the port priority when determining the root port for the switch in the MSTI. The port with the lowest value is considered to have the highest priority and will be chosen as root port over a port - equivalent in all other aspects - but with a higher priority value.

Use the no parameter with this command to restore the default priority value.

Syntax `spanning-tree mst instance <instance-id> priority <priority>`
`no spanning-tree mst instance priority <instance-id>`

Parameter	Description
<code><instance-id></code>	Specify the identifier.
<code><priority></code>	This must be a multiple of 16 and within the range 0 to 240. A lower priority indicates greater likelihood of the port becoming the root port.

Mode Interface mode

Default The default value is 128.

Examples

```
awplus# configure terminal
awplus(config)# interface port1.2.3
awplus(config-if)# spanning-tree mst instance 3 priority 121
```

Related Commands [spanning-tree priority \(port priority\)](#)

spanning-tree path-cost

Use this command to set the cost of a path for the specified port. This value then combines with others along the path to the root bridge in order to determine the total cost path value from the particular port, to the root bridge. The lower the numeric value, the higher the priority of the path. This applies when the port is the root port.

Use this command for RSTP, STP or MSTP. When MSTP mode is configured, this will apply to the port's path cost for the CIST.

Syntax `spanning-tree path-cost <pathcost>`

`no spanning-tree path-cost`

Parameter	Description
<code><pathcost></code>	<code><1-200000000></code> The cost to be assigned to the port.

Mode Interface mode

Default The default path cost values and the range of recommended path cost values depend on the port speed, as shown in the following table from the IEEE 802.1q-2003 and IEEE 802.1d-2004 standards.

Port speed	Default path cost	Recommended path cost range
Less than 100 Kb/s	200,000,000	20,000,000-200,000,000
1Mbps	20,000,000	2,000,000-20,000,000
10Mbps	2,000,000	200,000-2,000,000
100 Mbps	200,000	20,000-200,000
1 Gbps	20,000	2,000-20,000
10 Gbps	2,000	200-2,000
100 Gbps	200	20-200
1Tbps	20	2-200
10 Tbps	2	2-20

Example

```
awplus# configure terminal
awplus(config)# interface port1.1.2
awplus(config-if)# spanning-tree path-cost 123
```

spanning-tree portfast (STP)

Use this command to set a port as an edge-port. The portfast feature enables a port to rapidly move to the forwarding state, without having first to pass through the intermediate spanning tree states. This command has the same effect as the [spanning-tree edgeport \(RSTP and MSTP\)](#) command, but the configuration displays differently in the output of some show commands.

Note: You can run either of two additional parameters with this command. To simplify the syntax these are documented as separate commands. See the following additional portfast commands:
[spanning-tree portfast bpdu-filter](#) command on page 19.41 and,
[spanning-tree portfast bpdu-guard](#) command on page 19.42.

You can obtain the same effect by running the [spanning-tree edgeport \(RSTP and MSTP\)](#) command. However, the configuration output may display differently in some show commands.

Use the no parameter with this command to set a port to its default state (not an edge-port).

Syntax spanning-tree portfast
no spanning-tree portfast

Mode Interface Mode

Default Not an edge port.

Usage Portfast makes a port move from a blocking state to a forwarding state, bypassing both listening and learning states. The portfast feature is meant to be used for ports connected to end-user devices not switches. Enabling portfast on ports that are connected to a workstation or server allows devices to connect to the network without waiting for spanning-tree to converge. For example, you may need hosts to receive a DHCP address quickly and waiting for STP to converge would cause the DHCP request to time out. Ensure you do not use portfast on any ports connected to another switch to avoid creating a spanning-tree loop on the network.

Use this command on a switch port that connects to a LAN with no other bridges attached. An edge port should never receive BPDUs. Therefore if an edge port receives a BPDU, the portfast feature takes one of three actions.

- Cease to act as an edge port and pass BPDUs as a member of a spanning tree network ([spanning-tree portfast \(STP\)](#) command disabled).
- Filter out the BPDUs and pass only the data and continue to act as a edge port ([spanning-tree portfast bpdu-filter](#) command enabled)
- Block the port to all BPDUs and data ([spanning-tree portfast bpdu-guard](#) command enabled).

Example

```
awplus# configure terminal
awplus(config)# interface port1.1.2
awplus(config-if)# spanning-tree portfast
```

Related Commands spanning-tree edgeport (RSTP and MSTP)
show spanning-tree
spanning-tree portfast bpdu-filter

spanning-tree portfast bpdu-guard

spanning-tree portfast bpdu-filter

This command sets the portfast bpdu-filter feature and applies a filter to any BPDUs received. Enabling this feature ensures that portfast configured ports will not transmit any BPDUs and will ignore (filter out) any BPDUs received. BPDU Filter is not enabled on a port by default.

Using the `no spanning-tree portfast bpdu-filter` command to turn off the bpdu-filter, but retain the port's status as a portfast enabled port. If the port then receives a BPDU it will change its role from an edge-port to a non edge-port.

Syntax (Configuration Mode)

```
spanning-tree portfast bpdu-filter
no spanning-tree portfast bpdu-filter
```

Syntax (Interface Mode)

```
spanning-tree portfast bpdu-filter {default|disable|enable}
no spanning-tree portfast bpdu-filter
```

Parameter	Description
portfast	A port that behaves as an edge-port. Note that an edge port should never receive BPDUs. If a port does receive a BPDU then it will filter any received.
bpdu-filter	A portfast port that has bpdu-filter turned on will enter the STP blocking state if it receives a BPDU. This port type has one of the following parameters:
default	Takes the setting that has been configured for the whole switch, i.e. the setting made from the Global configuration mode.
disable	Turns off BPDU filter.
enable	Turns on BPDU filter.

Mode Global Configuration Mode and Interface mode

Default BPDU Filter is not enabled on any ports by default.

Usage This command filters the BPDUs and passes only data to continue to act as an edge port. Using this command in Global Configuration mode applies the portfast bpdu-filter feature to all ports on the switch. Using it in Interface mode applies the portfast feature to a specific port, or range of ports. The command will operate in both RSTP and MSTP networks.

A port with portfast enabled will receive BPDUs by default, so you can use this command to stop BPDUs coming to or going from the port. This command will take a port out of portfast if it receives a BPDU and forces the port to be part of the STP topology. Unlike the [spanning-tree portfast bpdu-guard](#) command, which places the port into the disabled state, this command keeps the port up, but without portfast running on the port.

Use the [show spanning-tree](#) command to display status of the bpdu-filter parameter for the switch ports.

Example

```
awplus# configure terminal
awplus(config)# spanning-tree portfast bpdu-filter

awplus# configure terminal
awplus(config)# interface port1.1.2
awplus(config-if)# spanning-tree portfast bpdu-filter enable
```

Related Commands

- spanning-tree edgeport (RSTP and MSTP)
- show spanning-tree
- spanning-tree portfast (STP)
- spanning-tree portfast bpdu-guard

spanning-tree portfast bpdu-guard

This command sets the portfast feature and applies a BPDU guard to the port. A port with the portfast bpdu-guard feature enabled will block all traffic (BPDUs and user data), if it starts receiving BPDUs.

Use this command in Global Configuration mode to set the portfast feature and apply BPDU guard to all ports on the switch. Use this command in Interface mode to for an individual interface or a range of interfaces specified. BPDU Guard is not enabled on a port by default.

Use the no spanning-tree portfast bpdu-guard command to disable the BPDU Guard feature on a switch in Global Configuration mode or to disable the BPDU Guard feature on a port in Interface mode.

**Syntax
(Configuration
Mode)**

```
spanning-tree portfast bpdu-guard
no spanning-tree portfast bpdu-guard
```

**Syntax
(Interface Mode)**

```
spanning-tree portfast bpdu-guard {default|disable|enable}
no spanning-tree portfast bpdu-guard
```

Parameter	Description
portfast	A port that behaves as an edge-port. Note that an edge port should never receive BPDUs. If a port does receive a BPDU then it will cease to act as an edge port.
bpdu-guard	A portfast port that has bpdu-guard turned on will enter the STP blocking state if it receives a BPDU. This port type has one of the following parameters:
default	Takes the setting that has been configured for the whole switch, i.e. the setting made from the Global configuration mode.
disable	Turns off BPDU guard.
enable	Turns on BPDU guard and will also set the port as an edge port.

Mode Global Configuration mode or Interface mode

Default BPDU Guard is not enabled on any ports by default.

Usage This command blocks the port(s) to all BPDUs and data when enabled. BPDU Guard is a port-security feature that changes how a portfast-enabled port behaves if it receives a BPDU. When bpdu-guard is set, then the port shuts down if it receives a BPDU. It does not process the BPDU as it is considered suspicious. When bpdu-guard is not set, then the port will negotiate spanning-tree with the device sending the BPDUs. By default, bpdu-guard is not enabled on a port. If a port with portfast enabled receives a BPDU, the port will be moved to the disabled state. This stops the port being connected to another port that is configured with portfast, so guards against spanning-tree loops forming on the network.

You can configure a port disabled by the bpdu-guard to re-enable itself after a specific time interval. This interval is set with the [spanning-tree errdisable-timeout interval command on page 19.27](#). If you do not use the errdisable-timeout feature, then you will need to manually re-enable the port by using the no shutdown command.

Use the [show spanning-tree command on page 19.11](#) to display the switch and port configurations for the BPDU Guard feature. It shows both the administratively configured and currently running values of bpdu-guard.

Example

```
awplus# configure terminal
awplus(config)# spanning-tree portfast bpdu-guard

awplus# configure terminal
awplus(config)# interface port1.1.2
awplus(config-if)# spanning-tree portfast bpdu-guard enable
```

Related Commands [spanning-tree edgeport \(RSTP and MSTP\)](#)
[show spanning-tree](#)
[spanning-tree portfast \(STP\)](#)
[spanning-tree portfast bpdu-guard](#)

spanning-tree priority (bridge priority)

Use this command to set the bridge priority for the switch. A lower priority value indicates a greater likelihood of the switch becoming the root bridge.

Use this command for RSTP, STP or MSTP. When MSTP mode is configured, this will apply to the CIST.

Use the no form of the command to reset it to the default value.

Syntax `spanning-tree priority <priority>`
`no spanning-tree priority`

Parameter	Description
<code><priority></code>	<code><0-61440></code> The bridge priority, which will be rounded to a multiple of 4096.

Mode Global Configuration mode

Default The default priority is 32768.

Usage To force a particular switch to become the root bridge use a lower value than other switches in the spanning tree.

Example

```
awplus# configure terminal
awplus(config)# spanning-tree priority 4096
```

Related Commands `spanning-tree mst instance priority`
`show spanning-tree`

spanning-tree priority (port priority)

Use this command to set the port priority for port. A lower priority value indicates a greater likelihood of the port becoming part of the active topology.

Use this command for RSTP, STP, or MSTP. When the device is in MSTP mode, this will apply to the CIST.

Use the no form of the command to reset it to the default value.

Syntax `spanning-tree priority <priority>`
`no spanning-tree priority`

Parameter	Description
<code><priority></code>	<0-240>, in increments of 16. The port priority, which will be rounded down to a multiple of 16.

Mode Interface mode

Default The default priority is 128.

Usage To force a port to be part of the active topology (for instance, become the root port or a designated port) use a lower value than other ports on the device. (This behavior is subject to network topology, and more significant factors, such as bridge ID.)

Example

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# spanning-tree priority 16
```

Related Commands `spanning-tree mst instance priority`
`spanning-tree priority (bridge priority)`
`show spanning-tree`

spanning-tree transmit-holdcount

Use this command to set the maximum number of BPDU transmissions that are held back.

Use the no parameter with this command to restore the default transmit hold-count value.

Syntax spanning-tree transmit-holdcount <1-10>
no spanning-tree transmit-holdcount <1-10>

Parameter	Description
<1-10>	Transmit hold-count value

Mode Global Configuration mode

Default Transmit hold-count default value is 3.

Example

```
awplus# configure terminal
awplus(config)# spanning-tree transmit-holdcount 5
```

Chapter 20: Link Aggregation Configuration



Introduction.....	20.2
Configuring LACP	20.2

Introduction

This chapter contains a complete sample Link Aggregation Control Protocol (LACP) configuration. To see details on the LACP commands used in this example, or to see the outputs of the validation commands, refer to [Chapter 21, Link Aggregation Commands](#)

LACP is based on the IEEE Standard 802.3ad. It allows bundling of several physical ports to form a single logical channel providing enhanced performance and redundancy. The aggregated channel is viewed as a single link to each switch. The spanning tree views the channel as one interface and not as multiple interfaces. When there is a failure in one physical port, the other ports stay up and there is no disruption.

This device supports the aggregation of a maximum of eight physical ports into a single channel group.

Configuring LACP

The following example shows how to configure three links between two Allied Telesis managed Layer 3 Switches. The three links are assigned the same administrative key (1), so that they aggregate to form a single channel 1. They are viewed by the STP as one interface.




Table 20-1: Switch 1 configuration

<code>awplus#</code>	
<code>configure terminal</code>	Enter the Configure mode.
<code>awplus(config)#</code>	
<code>lcp system-priority 20000</code>	Set the system priority of this switch. This priority is used for determining the system that is responsible for resolving conflicts in the choice of aggregation groups. A lower numerical value has a higher priority.
<code>awplus(config)#</code>	
<code>interface port1.0.1</code>	Enter the Interface mode and configure this interfaces properties.
<code>awplus(config-if)#</code>	
<code>channel-group 1 mode active</code>	Add this interface to a channel group 1 and enable link aggregation so that it may be selected for aggregation by the local system.
<code>awplus(config)#</code>	
<code>interface port1.0.2</code>	Enter the Interface mode and configure this interfaces properties.
<code>awplus(config-if)#</code>	
<code>channel-group 1 mode active</code>	Add this interface to a channel group 1 and enable link aggregation so that it may be selected for aggregation by the local system.
<code>awplus(config)#</code>	
<code>interface port1.0.3</code>	Enter the Interface mode and configure this interfaces properties.
<code>awplus(config-if)#</code>	
<code>channel-group 1 mode active</code>	Add this interface to a channel group 1 and enable link aggregation so that it may be selected for aggregation by the local system.

Table 20-2: Switch 2 configuration

awplus#	
<code>configure terminal</code>	Enter the Configure mode.
awplus(config)#	
<code>interface port1.0.2</code>	Enter the Interface mode and configure this interfaces properties.
awplus(config-if)#	
<code>channel-group 1 mode active</code>	Add this interface to a channel group 1 and enable link aggregation so that it may be selected for aggregation by the local system.
awplus(config)#	
<code>interface port1.0.3</code>	Enter the Interface mode and configure this interfaces properties.
awplus(config-if)#	
<code>channel-group 1 mode active</code>	Add this interface to a channel group 1 and enable link aggregation so that it may be selected for aggregation by the local system.
awplus(config)#	
<code>interface port1.0.4</code>	Enter the Interface mode and configure this interfaces properties.
awplus(config-if)#	
<code>channel-group 1 mode active</code>	Add this interface to a channel group 1 and enable link aggregation so that it may be selected for aggregation by the local system.

Commands Used `lACP system-priority`
`channel-group mode`

Validation Commands `show lACP sys-id`
`show port etherchannel`
`show etherchannel`
`show etherchannel detail.`

Chapter 21: Link Aggregation Commands



Command List	21.2
clear lacp counters	21.2
channel-group mode	21.3
debug lacp	21.5
lacp port-priority	21.6
lacp system-priority	21.7
lacp timeout	21.7
show debugging lacp	21.9
show etherchannel	21.10
show etherchannel detail	21.11
show etherchannel summary	21.12
show lacp-counter	21.13
show lacp sys-id	21.13
show port etherchannel	21.14
show static-channel-group	21.15
static-channel-group	21.16

Command List

This chapter provides an alphabetical reference of commands used to configure static link aggregation (static channel group) and dynamic link aggregation (LACP channel group). Link aggregation is also sometimes referred to as channelling.

For a description of static and dynamic link aggregation (LACP), see [“Channel Groups \(Link Aggregation\)” on page 14.11](#). For an LACP configuration example, see [Chapter 20, Link Aggregation Configuration](#).

clear lacp counters

Use this command to clear all counters of all present LACP aggregators (channel groups) or a given LACP aggregator.

Syntax `clear lacp [<1-65535>] counters`

Parameter	Description
<1-65535>	Channel-group number.

Mode Privileged Exec mode

Example `awplus# clear lacp 2 counters`

channel-group mode

Use this command to add the switch port to a dynamic (LACP) channel group specified by the channel group number, and set its mode. You can create up to 31 channel groups. This command enables LACP link aggregation on the switch port, so that it may be selected for aggregation by the local system. LACP channel groups are also known as LACP aggregators, dynamic channel groups, or ether channels.

Use the `no channel-group` command to turn off link aggregation on the switch port.

Syntax `channel-group <1-65535> mode {active|passive}`
`no channel-group`

Parameter	Description
<1-65535>	Specify a channel group number for an LACP link. Note that up to 31 channel groups can be created on the switch.
active	The port will transmit LACP dialogue messages whether or not it receives them from the partner system.
passive	The port will only transmit LACP dialogue messages if the partner systems is transmitting them, i.e. the partner is in the active mode.

Mode Interface mode

Usage All the switch ports in a channel-group must belong to the same VLANs, have the same tagging status, and can only be operated on as a group. All switch ports within a channel group must have the same port speed and be in full duplex mode.

Once the LACP channel group has been created, it is treated as a switch port, and can be referred to in most other commands that apply to switch ports.

To refer to an LACP channel group in other LACP commands, use the channel group number. To specify an LACP channel group (LACP aggregator) in other commands, prefix the channel group number with `po`. For example, 'po4' refers to the LACP channel group with channel group number 4.

For more on LACP, see [“LACP Channel Groups” on page 14.12](#) and [Chapter 20, Link Aggregation Configuration](#).

Example To add switch port 1.2.10 to a newly created LACP channel group 4 use the commands below:

```
awplus# configure terminal
awplus(config)# interface port1.2.10
awplus(config-if)# channel-group 4 mode active
```

To remove switch port 1.1.8 from any created LACP channel groups use the command below:

```
awplus# configure terminal
awplus(config)# interface port1.1.8
awplus(config-if)# no channel-group
```

To reference the pre-defined LACP channel group 2 as an interface apply commands as below:

```
awplus# configure terminal
awplus(config)# interface port1.1.8
awplus(config-if)# channel-group 2 mode active
awplus(config-if)# exit
awplus(config)# interface port.1.1.10
awplus(config-if)# channel-group 2 mode active
awplus(config-if)# exit
awplus(config)# interface po2
awplus(config-if)#
```

Related Commands

- show etherchannel
- show etherchannel detail
- show etherchannel summary
- show port etherchannel

debug lacp

Use this command to enable all LACP troubleshooting functions.

Use the no parameter with this command to disable this function.

Syntax `debug lacp {all|cli|event|ha|packet|sync|timer[detail]}`
`no debug lacp {all|cli|event|ha|packet|sync|timer[detail]}`

Parameter	Description
all	Turn on all debugging for LACP.
cli	Specifies debugging for CLI messages. Echoes commands to the console.
event	Specifies debugging for LACP events. Echoes events to the console.
ha	Specifies debugging for HA (High Availability) events. Echoes High Availability events to the console.
packet	Specifies debugging for LACP packets. Echoes packet contents to the console.
sync	Specified debugging for LACP synchronization. Echoes synchronization to the console.
timer	Specifies debugging for LACP timer. Echoes timer expiry to the console.
detail	Optional parameter for LACP timer-detail. Echoes timer start/stop details to the console.

Mode Privileged Exec mode and Global Configuration mode

Examples

```
awplus# debug lacp timer detail
awplus# debug lacp all
```

Output This command with the all parameter turns on complete LACP debug information.

```
awplus# debug lacp all
awplus# show debugging lacp
```

Figure 21-1: Example output after using the **debug lacp all** command

```
LACP debugging status:  
LACP timer debugging is on  
LACP timer-detail debugging is on  
LACP cli debugging is on  
LACP packet debugging is on  
LACP event debugging is on  
LACP sync debugging is on
```

Related Commands `show debugging lacp`

lacp port-priority

Sets the priority of a switch port. Ports are selected for aggregation based on their priority, with the higher priority (numerically lower) ports selected first.

Use the `no` parameter with this command to reset the priority of port to the default value (32768).

Syntax `lacp port-priority <1-65535>`
`no lacp port-priority`

Parameter	Description
<code><1-65535></code>	Specify the LACP port priority.

Mode Interface mode

Example

```
awplus# configure terminal  
awplus(config)# interface port1.2.5  
awplus(config-if)# lacp port-priority 34
```

lacp system-priority

Use this command to set the system priority of a local system. This is used in determining the system responsible for resolving conflicts in the choice of aggregation groups.

Use the no parameter with this command to reset the system priority of the local system to the default value (32768).

Syntax lacp system-priority <1-65535>

no lacp system-priority

Parameter	Description
<1-65535>	LACP system priority. The default system priority is 32768. Lower numerical values have higher priorities.

Mode Global Configuration mode

Example

```
awplus# configure terminal
awplus(config)# lacp system-priority 6700
```

lacp timeout

Use this command to set the short or long timeout on a port. Ports will time out of the aggregation if three consecutive updates are lost. The default is the long timeout of 30 seconds.

Syntax lacp timeout {short|long}

Parameter	Description
timeout	Number of seconds before invalidating a received LACP data unit (DU).
short	LACP short timeout. The short timeout value is 1 second.
long	LACP long timeout. The long timeout value is 30 seconds.

Mode Interface mode

Default The default is long timeout.

Usage This command enables the switch to indicate the rate at which it expects to receive LACPDUs from its neighbor.

If the timeout is set to long, then the switch expects to receive an update every 30 seconds, and this will time a port out of the aggregation if no updates are seen for 90 seconds (i.e. 3 consecutive updates are lost).

If the timeout is set to short, then the switch expects to receive an update every second, and this will time a port a port out of the aggregation if no updates are seen for 3 seconds (i.e. 3 consecutive updates are lost).

The switch indicates its preference by means of the 'Timeout' field in the 'Actor' section of its LACPDUs. If the 'Timeout' field is set to 1, then the switch has set the short timeout. If the 'Timeout' field is set to 0, then the switch has set the long timeout.

Setting the short timeout enables the switch to be more responsive to communication failure on a link, and does not add too much processing overhead to the switch (1 packet per second).

Note: It is not possible to configure the rate that the switch sends LACPDUs; the switch must send at the rate which the neighbor indicates it expects to receive LACPDUs.

Example The following commands set the LACP long timeout period for 30 seconds on port 1.0.2.

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# lacp timeout long
```

The following commands set the LACP short timeout for 1 second on port 1.0.2.

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# lacp timeout short
```

show debugging lacp

Use this command to display the LACP debugging option set.

To modify the lines displayed, use the | (output modifier token); to save the output to a file use the > output redirection token.

Syntax `show debugging lacp`

Mode Exec and Privileged Exec mode

Examples

```
awplus# show debugging lacp
```

Output Figure 21-2: Example output from the **show debugging lacp** command

```
LACP debugging status:
LACP timer debugging is on
LACP timer-detail debugging is on
LACP cli debugging is on
LACP packet debugging is on
LACP event debugging is on
LACP sync debugging is on
```

Related Commands `debug lacp`

show etherchannel

Use this command to display information about an LACP etherchannel specified by the channel-group number.

The command output also shows the thrash limiting status. If thrash limiting is detected and the thrash limiting parameter of the [thrash-limiting command on page 15.45](#) is set to vlan disable, the output will also show the VLANs on which thrashing is detected.

To modify the lines displayed, use the | (output modifier token); to save the output to a file, use the > output redirection token.

Syntax `show etherchannel [<1-65535>]`

Mode Exec and Privileged Exec mode

Example

```
awplus# show etherchannel 5
```

Output Figure 21-3: Example output from the **show etherchannel** command

```
% LACP Aggregator: po1
  Thrash-limiting
    Status Vlan Thrashing Detected, Action vlan-disable 60(s)
    Thrashing Vlan 1 2 3 4 5
% Member:
  port1.0.4
  port1.0.8
```

show etherchannel detail

Use this command to display detailed information about all LACP channels.

To modify the lines displayed, use the | (output modifier token); to save the output to a file, use the > output redirection token.

Syntax show etherchannel detail

Mode Privileged Exec mode

Example

```
awplus# show etherchannel detail
```

Output Figure 21-4: Example output from the **show etherchannel detail** command

```
% Aggregator po1 (4501)
% Mac address: 00:00:cd:24:fd:29
% Admin Key: 0001 - Oper Key 0001
% Receive link count: 1 - Transmit link count: 0
% Individual: 0 - Ready: 1
% Partner LAG: 0x8000,00-00-cd-24-da-a7
% Link: port1.0.1 (5001) disabled
% Link: port1.0.2 (5002) sync: 1
% Aggregator po2 (4502)
% Mac address: 00:00:cd:24:fd:29
% Admin Key: 0002 - Oper Key 0002
% Receive link count: 1 - Transmit link count: 0
% Individual: 0 - Ready: 1
% Partner LAG: 0x8000,00-00-cd-24-da-a7
% Link: port1.0.7 (5007) disabled
```

show etherchannel summary

Use this command to display a summary of all LACP channels.

To modify the lines displayed, use the | (output modifier token); to save the output to a file, use the > output redirection token.

Syntax `show etherchannel summary`

Mode Privileged Exec mode

Example

```
awplus# show etherchannel summary
```

Output Figure 21-5: Example output from the **show etherchannel summary** command

```
% Aggregator po1
% Admin Key: 0001 - Oper Key 0001
% Link: port1.0.1 (5001) disabled
% Link: port1.0.2 (5002) sync: 1
% Aggregator po2
% Admin Key: 0002 - Oper Key 0002
% Link: port1.0.7 (5007) disabled
```

show lacp-counter

Use this command to display the packet traffic on all ports of all present LACP aggregators, or a given LACP aggregator.

To modify the lines displayed, use the | (output modifier token); to save the output to a file, use the > output redirection token.

Syntax show lacp-counter [<1-65535>]

Parameter	Description
<1-65535>	Channel-group number.

Mode Exec mode and Privileged Exec mode

Example

```
awplus# show lacp-counter
```

Output Figure 21-6: Example output from the **show lacp-counter** command

```
% Traffic statistics
Port          LACPDUs      Marker      Pckt err
              Sent    Recv    Sent    Recv    Sent    Recv
% Aggregator po4 (4604)
port1.0.2     0      0      0      0      0      0
```

show lacp sys-id

Use this command to display the LACP system ID and priority.

To modify the lines displayed, use the | (output modifier token); to save the output to a file, use the > output redirection token.

Syntax show lacp sys-id

Mode Privileged Exec mode

Example

```
awplus# show lacp sys-id
```

```
% System Priority: 0x8000 (32768)
% MAC Address: 00-00-cd-24-fd-29
```

show port etherchannel

Use this command to show LACP details of the switch port specified.

To modify the lines displayed, use the | (output modifier token); to save the output to a file, use the > output redirection token.

Syntax `show port etherchannel <port>`

Parameter	Description
<port>	Name of the switch port to display LACP information about.

Mode Privileged Exec mode

Example

```
awplus# show port etherchannel port1.0.1
```

Output Figure 21-7: Example output from the **show port etherchannel** command

```
% Link: port1.0.1 (5001)
% Aggregator: po1 (4501)
% Receive machine state: Current
% Periodic Transmission machine state: Fast periodic
% Mux machine state: Collecting/Distributing
% Actor Information:
%   Selected ..... Selected
%   Physical Admin Key ..... 1
%   Port Key ..... 5
%   Port Priority ..... 32768
%   Port Number ..... 5001
%   Mode ..... Active
%   Timeout ..... Long
%   Individual ..... Yes
%   Synchronised ..... Yes
%   Collecting ..... Yes
%   Distributing ..... Yes
%   Defaulted ..... Yes
%   Expired ..... No
% Partner Information:
%   Partner Sys Priority ..... 0
%   Partner System .. 00-00-00-00-00-00
%   Port Key ..... 0
%   Port Priority ..... 0
%   Port Number ..... 0
%   Mode ..... Passive
%   Timeout ..... Short
%   Individual ..... Yes
%   Synchronised ..... Yes
%   Collecting ..... Yes
%   Distributing ..... Yes
%   Defaulted ..... Yes
%   Expired ..... No
```

show static-channel-group

Use this command to display all configured static channel groups and their corresponding member ports. Note that a static channel group is the same as a static aggregator.

The command output also shows the thrash limiting status. If thrash limiting is detected and the thrash limiting parameter of the [thrash-limiting command on page 15.45](#) is set to vlan disable, the output will also show the VLANs on which thrashing is detected.

Syntax `show static-channel-group`

Mode Exec and Privileged Exec mode

Examples

```
awplus# show static-channel-group
```

Output Figure 21-8: Example output from the **show static-channel-group** command

```
% Static Aggregator: sa1
  Thrash-limiting
    Status Vlan Thrashing Detected, Action vlan-disable, Timeout
60(s)
  Thrashing Vlans: 1 2 3 4 5
% Member:
  port1.1.2
  port1.1.3
% Static Aggregator: sa2
% Member:
  port1.1.4
```

Related Commands [static-channel-group](#)

static-channel-group

Use this command to create a static channel group (also known as a static aggregator), or add a member port to an already-existing static channel group. Use the no parameter with this command to remove the switch port from the static channel group.

Syntax `static-channel-group <1-31>`
`no static-channel-group`

Parameter	Description
<1-31>	Channel group number.

Mode Interface mode

Usage This command adds the switch port to the static channel group with the specified channel group number. If the channel group does not exist, it is created, and the port is added to it. The no prefix detaches the port from the static channel group. If the port is the last member to be removed, the static channel group is deleted.

All the ports in a channel group must have the same VLAN configuration: they must belong to the same VLANs and have the same tagging status, and can only be operated on as a group.

Once the static channel group has been created, it is treated as a switch port, and can be referred to in other commands that apply to switch ports.

To refer to a static channel group in other static channel group commands, use the channel group number. To specify a static channel group in other commands, prefix the channel group number with sa. For example, 'sa3' refers to the static channel group with channel group number 3.

For more on static channel groups, see [“Static Channel Groups” on page 14.11](#) and [Chapter 20, Link Aggregation Configuration](#).

Example To define a static channel group on a switch port apply the example commands shown below:

```
awplus# configure terminal
awplus(config)# interface port1.1.6
awplus(config-if)# static-channel-group 3
```

To reference the pre-defined static channel group 2 as an interface apply commands as below:

```
awplus# configure terminal
awplus(config)# interface port1.1.8
awplus(config-if)# static-channel-group 2
awplus(config-if)# exit
awplus(config)# interface port.1.1.10
awplus(config-if)# static-channel-group 2
awplus(config-if)# exit
awplus(config)# interface sa2
awplus(config-if)#
```

Related Commands [show static-channel-group](#)

Chapter 22: Power over Ethernet

Introduction



Introduction.....	22.2
Power over Ethernet (PoE)	22.2
The Advantages of PoE.....	22.3
PoE powered devices	22.3
PoE standard	22.4
How PoE works	22.4
Power Device (PD) discovery	22.4
Power classes.....	22.4
Power through the cable	22.5
AlliedWare Plus PoE Implementation.....	22.6
Power capacity.....	22.6
Power threshold	22.6
Power through the cable	22.7
PoE port management	22.7
Powered Device (PD) detection	22.7
Powered Device (PD) classification.....	22.7
Port prioritization	22.8
Software monitoring.....	22.9
AlliedWare Plus PoE Configuration	22.10
Configure a PD description for a PoE port.....	22.10
Configuring capacity and priority on a PoE port.....	22.11
Remotely monitoring power for all connected PDs.....	22.12

Introduction

This chapter provides an introduction to Power over Ethernet (PoE) technology, the PoE standard, PoE devices, and the AlliedWare Plus PoE implementation for your reference prior to configuring PoE in the CLI. This chapter applies to PoE capable switches only.

For information about the PoE commands available in the AlliedWare Plus Operating System, see [Chapter 23, Power over Ethernet Commands](#) for descriptions, examples, and output.

Power over Ethernet (PoE)

PoE is a mechanism for supplying power to network devices over the same cabling used to carry network traffic. PoE supplies power to network devices called Powered Devices (PDs).

Powered Devices (PDs)

PDs are devices such as IP phones, wireless LAN Access Points, and network cameras. PDs receive power, in addition to data, over existing network infrastructure and cabling. This feature can simplify network installation and maintenance by using the switch as a central power source for other network devices. The maximum power usage of Powered Devices (PD) is 12.95 watts according to the IEEE 802.3af Power Ethernet standard.

Power Sourcing Equipment (PSE)

A device that can source power, such as an Ethernet switch, is termed Power Sourcing Equipment (PSE). Power Sourcing Equipment can provide power, along with data, over existing LAN cabling to Powered Devices. The IEEE 802.3af Power Ethernet standard supplies up to 15.40 watts of DC power (minimum 44 VDC and 350 mA) to each Powered Device (PD). Up to 12.95 watts of power is available at the PD, because some power is dissipated in the cable.

The Advantages of PoE

Most network devices require both a data connection and a power supply. Just as standard phones are supplied power and also communicate over the same wiring, now the same provision can be made for Ethernet network devices. Benefits and applications of PoE switches include:

Cost saving

PDs only require a single Ethernet cable for the network and power connection. Devices that can be supplied power via PoE no longer require separate cabling for power and data. They can use the same Ethernet cabling for both power and data.

This feature reduces the power line installation cost for electrical wiring, conduits, and power outlets. PoE provides maximum flexibility for device installation. You can install PDs almost anywhere without the need for DC/AC power inputs.

Reliability

Using just one CAT-5 cable instead of separate cables for data and power improves overall network reliability and deployment flexibility.

Safety

You can set the power limitation for each port on the PoE switch. Power limit configuration can protect PoE switches from providing too much power to a single PD, even when requested by the PD.

Security

Using SNMP, the administrator can power on/off the device remotely for added protection. The network administrator can also disable the PSE when it is not in use or is accessed by unauthorized devices.

Further advantages of PoE include:

- It simplifies installation and saves space.
- Device placement is not limited to nearby power sources.
- PD's can be easily moved to wherever there is LAN cabling.
- Little configuration or management is required.

PoE powered devices

There are an increasing number of PoE powered devices becoming available. The more common uses for PoE are for communication devices such as VoIP phones and wireless LAN access points. There are however, quite a variety of devices now taking advantage of PoE technology such as:

- VoIP phones
- Wireless access points
- Webcams
- Security cameras
- Intercoms
- Building access systems

PoE standard

The IEEE 802.3af Power Ethernet standard was formally approved by the IEEE Standards Board in June 2003 and is an amendment to the existing IEEE 802.3 Ethernet standards.

How PoE works

PoE requires little configuration or management. The PSE automatically determines whether a device connected to a port is a powered device or not, and can determine the power class of the device. The PSE can supply up to 15.4 watts of power (at 48 Volts) to the device, while at the same time providing standard Ethernet network functionality.

Power Device (PD) discovery

The first step for PSE equipment (this switch, for example) is to ascertain whether a device plugged into a port is a valid Powered Device (PD). If it is, it will require power as well as network communication through the attached LAN cable.

The IEEE 802.3af-2003 standard for device detection involves applying a DC voltage between the transmit and receive wire pairs, and measuring the received current. A PSE will expect to see approximately 25K Ohm resistance and 150nF capacitance between the pairs for the device to be considered a valid PD. A range around these values is specified in the IEEE 802.3af Power Ethernet standard.

The PSE will check for the presence of PD's on connected ports at regular intervals, so power is removed when a PD is no longer connected. Legacy (pre-IEEE 802.3af Power Ethernet standard) PDs are also detected by the PSE by default. See [Powered Device \(PD\) detection](#).

Power classes

Once a PD is discovered, a PSE may optionally perform PD classification by applying a DC voltage to the port. If the PD supports optional power classification it will apply a load to the line to indicate to the PSE the classification the device requires.

Since PDs may require differing power ranges, the IEEE 802.3af Power Ethernet standard classifies PDs according to their power consumption. By providing the PSE with its power range, the PD allows the PSE to supply power with greater efficiency. The power classes as outlined by IEEE 802.3af are as follows showing the different PD classes and the PSE power output for each corresponding PD power range:

PD Class	Power Available at PD	Power Supplied from PSE
0	0.44W to 12.95W	15.4W
1	0.44W to 3.84W	4.0W
2	3.84W to 6.49W	7.0W
3	6.49W to 12.95W	15.4W

Once the PSE has detected the PDs IEEE 802.3af power class, the PSE can manage the power allocation by subtracting the PDs class maximum value from the overall power budget. This allows for control and management of power allocation when there is not enough power available from the PSE to supply maximum power to all ports. Any unclassified PD is considered to be a class 0 device.

The IEEE 802.3af standard supports delivery of up to 15.4 watts per port that may be used to deliver power to PoE devices. This allows a variety of possible devices to make use of the available power. The maximum power consumed by a PD, as specified by the standard, is 12.95 watts. The system provides the 'extra' power (up to 15.4 watts) to compensate for line loss. Some common PoE device power requirements are:

Device	Power Requirement
IP phone	3-6 watts
Wireless access point	4-11 watts
IP security camera	5-12 watts

Refer to the LLDP chapters [Chapter 77, LLDP Introduction](#) and [Chapter 78, LLDP Commands](#) for information about power monitoring at the PD. Note the difference in power supplied from the PSE to the power available at the PD due to line loss.

Power through the cable

An Ethernet cable has four twisted pairs, but only two of these are used for data transfer, (10/100/1000BASE-TX). The IEEE 802.3af standard allows two options for using these cables for power supply as follows. Note that the x600-24Ts-POE switch uses the data twisted pairs.

- The spare pairs are used. In this case the unused pairs are used to transfer the power. The twisted pair on pins 4 and 5 is connected to form the positive electric power supply, while the twisted pair on pins 7 and 8 is connected to form the negative power supply. Each pair can accommodate either polarity.
- The data pairs are used. The twisted pair on pins 3 and 6 and the pair on pins 1 and 2 can be of either polarity. Since Ethernet pairs are transformer coupled at each end, it is possible to apply DC power to the centre tap of the isolation transformer without upsetting the data transfer.

The IEEE 802.3af standard does not allow both sets of wires to be used, so a choice must be made. Different vendors PSE equipment may use one or other of the methods to supply power depending on PoE implementation. The Powered Device (PD) should be able to accept power from both options. The voltage supplied is nominally 48V, and a maximum of 12.95W of power is available at the Powered Device.

AlliedWare Plus PoE Implementation

This section is based around the PoE implementation in the Allied Telesis x600-24Ts-POE switch running the AlliedWare Plus Operating System. The x600-24Ts-POE model switch is a Layer 3 PoE Gigabit Ethernet switch with SFP support.

Power capacity

The PSU in the x600-24Ts-POE supplies enough power for the switch itself and enough power is available for PoE provision for all PoE capable switch ports.

The maximum possible power requirement (24 ports * 15.4W ~ 370 watts) falls below the maximum amount of power available (400 watts). This means that you can connect powered devices to all the ports on the switch (excluding optional expansion ports) without having to be concerned about exceeding the available power, even if all the PD's require the maximum 15.4 watts.

You can reduce the amount of power a port can source, from the maximum of 15.4 W, using the PoE command:

```
awplus(config-if)# power-inline max <4000-15400>
```

However, configuring the power limit on the switch will probably not be necessary. As already mentioned, the power supply in the switch can provide enough power to meet the needs of all 10/100/1000 base ports, even if they all require the maximum 15.4 watts for connected PD's.

For most sites, the default configuration (the PSE supplies the maximum power limit for the class of the PD connected to the port by default and the default priority for the port is low) provides plug-and-play installation of PDs to the PSE without further configuration of the PSE.

Power threshold

The switch can be configured to send a Simple Network Management Protocol (SNMP) trap to your management workstation and enters an event in the event log whenever the total power requirements of the powered devices exceed the specified percentage of the total maximum power available on the switch. At the default setting of 80% the switch sends an SNMP trap when the PoE devices require more than 80% of the maximum available power on the switch.

You can adjust the threshold using the PoE command:

```
awplus(config)# power-inline usage-threshold <1-99>
```

For your management workstations to receive traps from the switch, you must configure SNMP on the switch by specifying the IP address of the workstations. The switch will also enter an event in the event log whenever power consumption of the switch has returned below the power limit threshold.

You can set the SNMP traps (notifications) for PoE using the SNMP command:

```
awplus(config)# snmp-server enable trap power-inline
```

Power through the cable

As mentioned earlier, the IEEE 802.3af standard describes two methods for implementing PoE over twisted pair cabling. One method uses the same cables that carry the network traffic and the other the spare pairs. The PoE implementation on the x600-24Ts-POE switch transmits power over the same twisted pairs that carry the network traffic data (pairs 1 & 2 and 3 & 6). The connected Powered Device (PD) should accept power from the data twisted pairs.

PoE port management

PoE is enabled by default on all 10/100/1000 ports. PoE can be administratively enabled or disabled on each port using the `power-inline enable` PoE command in Interface Configuration:

```
awplus(config-if)# power-inline enable
```

When PoE is disabled on a port, the port will operate as a normal Ethernet port without delivering the power to the connected device.

The user can connect either a PD or a non-PD device to a PoE-enabled port without re-configuring the port, as PD detection is carried out before any power is supplied to the connected device.

Powered Device (PD) detection

The AlliedWare Plus implementation of PoE offers two methods of PD detection. The default is to use the IEEE 802.3af standard resistance and capacitance measurements as described earlier. The second option is to support legacy PD's that were designed before the IEEE standard was finalized. This involves measuring for a large capacitance value to confirm the presence of a legacy PD. The IEEE method will be tried first and failing the discovery of a valid PD the legacy capacitance measurement will be tried. Note that legacy mode is on by default.

The legacy PD detection method can be set with the PoE command:

```
awplus(config-if)# power-inline allow-legacy
```

PD detection is carried out in real-time by the PSE controller on each switch port to detect and monitor the presence of any powered devices. Power is not supplied to any specific port until a valid PD is detected. A switch port which has a PD unplugged, will cease to have power supplied.

Powered Device (PD) classification

The AlliedWare Plus PoE implementation also includes the optional PD power classification measurement. This is undertaken after PD detection has confirmed a valid PD is attached to a specific port.

Port prioritization

Port prioritization is the way the switch determines which ports are to receive power in the event that the needs of the PDs exceed the available power resources of the switch.

If the PD's connected to a switch require more power than the switch is capable of delivering, the switch will deny power to some ports based on a system called port prioritization. You can use port prioritization to ensure that PD's critical to the operations of your network are given preferential treatment by the switch in the distribution of power, should the demands of the devices exceed the available capacity.

There are three priority levels:

- Critical
- High
- Low

You can set the port priority using the PoE command:

```
awplus# power-inline priority
```

Critical is the highest priority level. Ports set to this level are guaranteed power before any ports assigned to the other two priority levels. Ports assigned to the other priority levels receive power only if all the Critical ports are receiving power. Your most critical powered devices should be assigned to this level. If there is not enough power to support all the ports set to the Critical priority level, power is provided to the ports based on port number, in ascending order.

High is the second highest level. Ports set to this level receive power only if all the ports set to the Critical level are already receiving power. If there is not enough power to support all of the ports set to the High priority level, power is provided to the ports based on port number, in ascending order.

Low is the lowest priority level. This is the default setting. Ports set to this level only receive power if all the ports assigned to the other two levels are already receiving power. As with the other levels, if there is not enough power to support all of the ports set to the Low priority level, power is provided to the ports based on port number, in ascending order.

Power allocation is dynamic. Ports supplying power to PD's may cease power transmission if the switch's power capacity has reached maximum usage and new PD's connected to ports with a higher priority, become active.

Software monitoring

There are four PoE show commands available which return information about the PoE settings on the switch.

```
awplus# show power-inline
```

The `show power-inline` command details power threshold set, a power usage percentage, and power consumed by each switch port, for all switch ports (with the format of show output displayed in a table similar to `show interface brief` command output).

```
awplus# show power-inline counters
```

The `show power-inline counters` command displays PoE event counters from the PoE MIB (RFC 3621) (with the format of show output displayed in a table similar to `show interface brief` command output).

```
awplus# show power-inline interface
```

The `show power-inline interface` command summarizes all PoE information, including power limit, power consumed, and power class (with the format of show output displayed in a table similar to `show interface brief` command output).

```
awplus# show power-inline interface detail
```

The `show power-inline interface detail` command details all PoE information, including power limit, power consumed, and power class (with the format of show output displayed in a list similar to `show interface` command output).

Note: All AlliedWare Plus PoE commands are fully detailed in Chapter 23, Power over Ethernet Commands following Chapter 22, Power over Ethernet Introduction.

AlliedWare Plus PoE Configuration

This section is based around PoE configuration tasks for the Allied Telesis x600-24Ts-POE switch running the AlliedWare Plus Operating System.

Configure a PD description for a PoE port

Adding a PD description allows the PoE switch to display the function, name, or type of PD connected to the PoE port. Knowing the type of PD is useful to confirm PD Class power usage. Check output from the Privileged Exec mode PoE show commands: [show power-inline](#), [show power-inline interface](#), and [show power-inline interface detail](#) to validate a PoE description.

Starting in Privileged Exec, follow the table below to add a description for the PoE port listed as port1.0.2 to display Wireless Access Point # 1 in the relevant show output.

Prompt	Command	Purpose
awplus#	configure terminal	Enter Global Configuration mode.
awplus(config-if)#	interface port1.0.2	Specify the PoE port to be configured and enter Interface mode.
awplus(config-if)#	power-inline description Wireless Access Point # 1	Specify Wireless Access Point # 1 will be displayed in all PoE show command output for port1.0.2.
awplus(config-if)#	exit	Return to Global Configuration mode.
awplus(config)#	exit	Return to Privileged Exec mode.
awplus#	show power-inline interface port1.0.2	Display the PoE status for port1.0.2 to confirm that your PoE configuration on the PSE has been successful. If a PD is connected to the configured PoE port then power consumption as well as power allocation values will display.
awplus#	copy running-config startup-config	Save your running-config to the startup-config to keep your PoE configuration after a switch restart or reboot.

Configuring capacity and priority on a PoE port

The following commands sets a higher priority and a lower maximum power for a PoE port. This will stop high powered PDs being connected to a PoE port reserved for low powered PDs. Starting in Privileged Exec mode, follow the configuration table to configure `port1.0.2`.

Prompt	Command	Purpose
<code>awplus#</code>	<code>configure terminal</code>	Enter Global Configuration mode.
<code>awplus(config-if)#</code>	<code>interface port1.0.2</code>	Specify the PoE port to be configured and enter Interface mode.
<code>awplus(config-if)#</code>	<code>power-inline priority high</code>	Specify a higher priority for the PoE port than the default low setting.
<code>awplus(config-if)#</code>	<code>power-inline max 4000</code>	Specify the lowest available power that the PSE can supply to the PD: 4000 mW (milliwatts).
<code>awplus(config-if)#</code>	<code>exit</code>	Return to Global Configuration mode.
<code>awplus(config)#</code>	<code>exit</code>	Return to Privileged Exec mode.
<code>awplus#</code>	<code>show power-inline interface port1.0.2</code>	Display the PoE status for <code>port1.0.2</code> to confirm that your PoE configuration on the PSE has been successful. If a PD is connected to the configured PoE port then power consumption as well as power allocation values will display.
<code>awplus#</code>	<code>copy running-config startup-config</code>	Save your running-config to the startup-config to keep your PoE configuration after a switch restart or reboot.

Remotely monitoring power for all connected PDs

By using the `power-inline usage-threshold` command and the `snmp-server enable trap` command, specifying the `power-inline` parameter, for PDs on the PSE you can remotely monitor PD power requests. Note that you will also need to configure SNMP beforehand.

For example, if the PD is a Class 0 (default class) or a Class 3 (15400 mW) PD then the PSE budgets 15400 mW for the PD regardless of the actual amount of power needed by the PD.

The following procedure allows you to remotely monitor power usage for all connected PDs.

Starting in Privileged Exec mode, follow the configuration table to configure the PSE:

Prompt	Command	Purpose
<code>awplus#</code>	<code>configure terminal</code>	Enter Global Configuration mode.
<code>awplus(config)#</code>	<code>service power-inline</code>	Enable PoE globally for the PSE. This will also enable PoE globally for all PoE ports on all connected stacked switches.
<code>awplus(config)#</code>	<code>snmp-server enable trap power-inline</code>	Configure SNMP notification so an SNMP trap is sent when the power usage threshold is exceeded to trigger an alarm.
<code>awplus(config)#</code>	<code>power-inline usage-threshold 75</code>	Specify SNMP notifications are generated when the power supplied exceeds 75% of the nominal PSE power available.
<code>awplus(config)#</code>	<code>exit</code>	Return to Privileged Exec mode.
<code>awplus#</code>	<code>show power-inline</code>	Display the PoE status for all PoE ports on the PSE. This will display the PoE status for all PoE ports on stacked switches. The PD Class, power consumption, and power allocated per PoE port displays for all PoE ports on the PSE.
<code>awplus#</code>	<code>copy running-config startup-config</code>	Save your running-config to the startup-config to keep your PoE configuration after a switch restart or reboot.

Chapter 23: Power over Ethernet Commands



Introduction.....	23.2
Command List.....	23.2
clear power-inline counters interface	23.2
debug power-inline.....	23.4
power-inline allow-legacy.....	23.5
power-inline description.....	23.6
power-inline enable.....	23.7
power-inline max.....	23.8
power-inline priority.....	23.10
power-inline usage-threshold.....	23.12
service power-inline	23.13
show debugging power-inline.....	23.14
show platform power-inline	23.15
show power-inline.....	23.16
show power-inline counters.....	23.18
show power-inline interface.....	23.20
show power-inline interface detail.....	23.23

Introduction

Power over Ethernet (PoE) is a technology allowing devices such as IP phones to receive power over existing LAN cabling.

PoE is configured using the commands in this chapter. Note the Power Sourcing Equipment (PSE) referred to throughout this chapter is an AlliedTelesis PoE switch running the AlliedWare Plus Operating System, supporting the IEEE 802.3af Power Ethernet standard. The Powered Device (PD) referred to throughout this chapter is a PoE powered device, such as an IP phone.

Note that PoE commands listed in this chapter are currently only available on the Allied Telesis Layer 3 switch model -24Ts-POE running the AlliedWare Plus Operating System™.

Command List

This chapter contains an alphabetical list of commands used to configure Power over Ethernet (PoE) showing examples of PoE commands together with relevant show command output. These commands are only supported on PoE capable ports. An error message will display on the console if you enter a PoE command on a port that does not support PoE.

For introductory information about PoE, see [Chapter 22, Power over Ethernet Introduction](#). See also [Chapter 76, SNMP MIBs](#) for information about which PoE MIB objects are supported.

clear power-inline counters interface

This command clears all Power over Ethernet (PoE) counters supported in the Power Ethernet MIB (RFC 3621) from a specified port, a range of ports, or all ports on the Power Sourcing Equipment (PSE). If no ports are entered then PoE counters for all ports are cleared.

Syntax `clear power-inline counters interface [<port-list>]`

Parameter	Description
<port-list>	The port or ports for which the counters are to be cleared.

Mode Privileged Exec

Usage The PoE counters are displayed with the [show power-inline counters](#) command.

Examples To clear the PoE counters for `port1.0.2` only, use the following command:

```
awplus# clear power-inline counters interface port1.0.2
```

To clear the PoE counters for `port1.0.1` through `port1.0.10`, use the following command:

```
awplus# clear power-inline counters interface port1.0.1-  
port1.0.10
```

To clear the PoE counters for all ports, use the following command:

```
awplus# clear power-inline counters interface
```

Validation `show power-inline counters`
Commands

debug power-inline

This command enables the specified Power over Ethernet (PoE) debugging messages.

Use the `no debug power-inline` command to disable the specified PoE debugging messages.

Syntax

```
debug power-inline [all|event|info|nsm|power]
no debug power-inline [all|event|info|nsm|power]
```

Parameter	Description
all	Displays all (event, info, nsm, power) debug messages.
event	Displays event debug information, showing any error conditions that may occur during PoE operation.
info	Displays informational level debug information, showing high-level essential debugging, such as information about message types.
nsm	Displays developer level debugging information, for test use only.
power	Displays power management debug information.

Default No debug messages are enabled by default.

Mode Privileged Exec

Usage Use the [terminal monitor](#) command to display PoE debug messages on the console.
Use the [show debugging power-inline](#) command to show the PoE debug configuration.

Examples To enable PoE debugging and start the display of PoE `event` and `info` debug messages on the console, use the following commands:

```
awplus# terminal monitor
awplus# debug power-inline event info
```

To enable PoE debugging and start the display of all PoE debugging messages on the console, use the following commands:

```
awplus# terminal monitor
awplus# debug power-inline all
```

To disable PoE debugging and stop the display of PoE `event` and `info` debug messages on the console, use the following command:

```
awplus# no debug power-inline event info
```

To disable all PoE debugging and stop the display of any PoE debugging messages on the console, use the following command:

```
awplus# no debug power-inline all
```


Validation Commands show debugging power-inline

Related Commands terminal monitor

power-inline allow-legacy

This command enables detection of pre-IEEE 802.3af Power Ethernet standard legacy Powered Devices (PDs). The no version of this command disables detection of PDs that do not conform to the IEEE 802.3af Power Ethernet standard.

Syntax power-inline allow-legacy
no power-inline allow-legacy

Default Detection of legacy PDs is enabled on all ports on the Power Sourcing Equipment (PSE).

Mode Interface Configuration

Usage In a stack of x600 series switches this command is supported on all PoE capable ports. Select a port, a list of ports, or a range of ports from the preceding interface command.

Note: Early model IP phones (such as the Cisco 7960G model IP phone) may not conform to the IEEE 802.3af Power Ethernet standard.

Examples To disable detection of legacy PDs on ports port1.0.1 to port1.0.20, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1-port1.0.20
awplus(config-if)# no power-inline allow-legacy
```

To enable detection of legacy PDs on ports port1.0.1 to port1.0.20, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1-port1.0.20
awplus(config-if)# power-inline allow-legacy
```

Validation Commands show power-inline interface
show running-config power-inline

power-inline description

This command adds a description for a Powered Device (PD) connected to a PoE port.

The no version of this command clears a previously entered description for a connected PD, resetting the PD description to the default (null).

Syntax `power-inline description <PD-description>`
`no power-inline description`

Parameter	Description
<code><PD-description></code>	Description of the PD connected to the PoE capable port (with a maximum 256 character string limit per PD description).

Default No description for a connected PD is set by default.

Mode Interface Configuration

Usage In a stack of x600 series switches this command is supported on all PoE capable ports.
Select a PoE port, a list of PoE ports, or a range of PoE ports from the preceding [interface \(to configure\)](#) command. If you specify a range or list of ports they must all be PoE capable ports.

Examples To add the description Desk Phone for a connected PD on port1.0.2, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# power-inline description Desk Phone
```

To clear the description as added above for the connected PD on port1.0.2, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# no power-inline description
```

Validation Commands `show power-inline interface`
`show running-config power-inline`

power-inline enable

This command enables Power over Ethernet (PoE) to detect a connected Powered Device (PD) and supply power from the Power Sourcing Equipment (PSE).

The no version of this command disables PoE functionality on the selected PoE port(s). No power is supplied to a connected PD after PoE is disabled on the selected PoE port(s).

Syntax `power-inline enable`
`no power-inline enable`

Default PoE is enabled by default on all ports on the PSE.

Mode Interface Configuration

Usage In a stack of x600 series switches this command is supported on all PoE capable ports.

Select a PoE port, a list of PoE ports, or a range of PoE ports from the preceding [interface \(to configure\)](#) command. If you specify a range or list of ports they must all be PoE capable ports.

No PoE log messages are generated for specified PoE port(s) after PoE is disabled. The disabled PoE port(s) still provide Ethernet connectivity after PoE is disabled.

Examples To disable PoE on ports `port1.0.1` to `port1.0.10`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1-port1.0.10
awplus(config-if)# no power-inline enable
```

To enable PoE on ports `port1.0.1` to `port1.0.10`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1-port1.0.10
awplus(config-if)# power-inline enable
```

**Validation
Commands** `show power-inline`
`show power-inline interface`
`show power-inline interface detail`
`show running-config power-inline`

power-inline max

This command sets the maximum power supplied to a Power over Ethernet (PoE) port.

The no version of this command sets the maximum power supplied to a PoE port to the default, which is set to the maximum power limit for the class of the connected Powered Device (PD).

Syntax `power-inline max <4000-15400>`
`no power-inline max`

Parameter	Description
<4000-15400>	The maximum power supplied to a PoE port in milliwatts (mW).

Default The Power Sourcing Equipment (PSE) supplies the maximum power limit for the class of the PD connected to the port by default. The power limits for all classes of PDs are listed in “Power classes” on page 22.4 and “Powered Device (PD) classification” on page 22.7.

Mode Interface Configuration

Usage In a stack of x600 series switches this command is supported on all PoE capable ports.

Select a PoE port, a list of PoE ports, or a range of PoE ports from the preceding [interface \(to configure\)](#) command. If you specify a range or list of ports they must all be PoE capable ports.

If you select a range of PoE ports in Interface Configuration mode before issuing this command, then each port in the range selected will have the same maximum power value configured. If the PoE port attempts to draw more than the maximum power this is logged and all power is removed. Note that the value entered is rounded up to the next hardware supported value. See the actual value used, as shown after command entry, in the sample console output below:

```
awplus#configure terminal
awplus(config)#interface port1.0.1
awplus(config-if)#power-line max 5300
% Maximum power for port1.0.1 set to 5450mW
```

Refer to [Chapter 77, LLDP Introduction](#) and [Chapter 78, LLDP Commands](#) for information about power monitoring at the PD. Note the difference in power supplied from the PSE to the power available at the PD due to line loss. The “Power classes” on page 22.4 shows the difference between the power supplied from the PSE and the power available at the PD by each PD class.

Examples To set the maximum power supplied to port1.0.2 to port1.0.12 to 6450 mW per port, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2-port1.0.12
awplus(config-if)# power-inline max 6450
```

To set the maximum power supplied to `port1.0.2`, to 6450 mW, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# power-inline max 6450
```

To clear the user-configured maximum power supplied to `port1.0.2`, and revert to using the default maximum power of 15400 mW, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# no power-inline max
```

Validation	<code>show power-inline interface</code>
Commands	<code>show running-config power-inline</code>

power-inline priority

This command sets the Power over Ethernet (PoE) priority level of a PoE port to one of three available priority levels (low, high, or critical).

The no version of this command restores the PoE port priority to the default (low).

Syntax `power-inline priority {low|high|critical}`
`no power-inline priority`

Parameter	Description
low	The lowest priority for a PoE enabled port (default). PoE ports set to low only receive power if all the PoE ports assigned to the other two levels are already receiving power
high	The second highest priority for a PoE enabled port. PoE ports set to high receive power only if all the ports set to the Critical level are already receiving power
critical	The highest priority for a PoE enabled port. PoE ports set to critical are guaranteed power before any ports assigned to the other two priority levels. Ports assigned to the other priority levels receive power only if all Critical ports are receiving power

Default The default priority is low for all PoE ports on the Power Sourcing Equipment (PSE).

Mode Interface Configuration

Usage In a stack of x600 series switches this command is supported on all PoE capable ports.

Select a PoE port, a list of PoE ports, or a range of PoE ports from the preceding [interface \(to configure\)](#) command. If you specify a range or list of ports they must all be PoE capable ports.

PoE ports with higher priorities are given power before PoE ports with lower priorities. If the priorities for two PoE ports are the same then the lower numbered PoE port is given power before the higher numbered PoE port.

See “[Port prioritization](#)” on [page 22.8](#) for further information about PoE priority.

Examples To set the priority level to high for port1.0.2, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# power-inline priority high
```

To reset the priority level to the default for port1.0.2, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# no power-inline priority
```

Validation show power-inline
Commands show power-inline interface
 show running-config power-inline

Related Commands power-inline usage-threshold

power-inline usage-threshold

This command sets the level at which the Power Sourcing Equipment (PSE) detects that the power supplied to all Powered Devices (PDs) has reached a critical level of the nominal power rating for the PSE.

The no version of this command resets the notification usage-threshold to the default (80% of the nominal power rating of the PSE).

Syntax `power-inline usage-threshold <1-99>`

`no power-inline usage-threshold`

Parameter	Description
<1-99>	The usage-threshold percentage configured with this command.

Default The default power usage threshold is 80% of the nominal power rating of the PSE.

Mode Global Configuration

Usage Use the [snmp-server enable trap command on page 75.15](#) to configure SNMP notification. An SNMP notification is sent when the usage-threshold, as configured in the example, is exceeded.

Examples To generate SNMP notifications when power supplied exceeds 70% of the nominal PSE power, use the following commands:

```
awplus# configure terminal
awplus(config)# snmp-server enable trap power-inline
awplus(config)# power-inline usage-threshold 70
```

To reset the notification threshold to the default (80% of the nominal PSE power rating), use the following commands:

```
awplus# configure terminal
awplus(config)# no power-inline usage-threshold
```

Validation Commands `show power-inline interface`
`show running-config power-inline`

Related Commands [snmp-server enable trap](#)

service power-inline

This command enables Power over Ethernet (PoE) globally on the Power Sourcing Equipment (PSE) for all PoE ports. In a stack, issuing this command enables PoE globally for all PoE ports.

The no version of this command disables PoE globally on the PSE for all PoE ports.

Syntax `service power-inline`
 `no service power-inline`

Default PoE functionality is enabled by default on the PSE.

Mode Global Configuration

Usage In a stack, only switches containing PoE hardware will have PoE enabled by default in software.

Examples To disable PoE on the PSE, use the following commands:

```
awplus# configure terminal
awplus(config)# no service power-inline
```

To re-enable PoE on the PSE, if PoE has been disabled, use the following commands:

```
awplus# configure terminal
awplus(config)# service power-inline
```

Validation `show power-inline`
Commands `show running-config power-inline`

show debugging power-inline

This command displays Power over Ethernet (PoE) debug settings.

For information on output options, see [“Controlling “show” command output”](#) on page 1.33.

Syntax show debugging power-inline

Mode User Exec and Privileged Exec

Examples To display PoE debug settings, use the following command:

```
awplus# show debugging power-inline
```

Output Figure 23-1: Example output from the **show debugging power-inline** command

```
awplus#show debugging power-inline
PoE Debugging status:
PoE Informational debugging is disabled
PoE Event debugging is disabled
PoE Power Management debugging is disabled
PoE NSM debugging is enabled
```

Related Commands debug power-inline
 terminal monitor

show platform power-inline

This command shows the current register values for the Power over Ethernet (PoE) Integrated Circuits (ICs) fitted to the Power Sourcing Equipment (PSE).

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show platform power-inline [<port>]`

Parameter	Description
<port>	Enter a port to display PoE IC register values for a port.

Mode Exec and Privileged Exec

Usage This command is only for Allied Telesis Field Support and Developer use when debugging PoE. Enter this command without specifying a PoE port to show the register values for all PoE ports.

Examples To display the PoE IC register values for `port1.0.2`, use the following command:

```
awplus# show platform power-inline port1.0.2
```

Output Figure 23-2: Example output from the **show platform power-inline** command

```
awplus# show platform power-inline port1.0.2
00: 03 fc dd dd 00 00 00 00
08: 00 00 00 00 34 06 64 64
10: 55 00 aa 0f df 00 00 e0
18: 00 00 00 64 00 00 00 00
20: 00 00 00 00 00 00 00 00
28: 02 11 00 00 ff 00 00 0f
30: 73 03 9e 20 00 00 00 00
38: a4 3f eb ff 00 00 00 00
40: 00 06 16 00 0f 00 02 d3
48: 80 00 00 02 14 80 00 42
50: 02 d3 80 00 00 02 d4 80
```

Related Commands [show power-inline counters](#)
[show power-inline interface](#)

show power-inline

This command displays the Power over Ethernet (PoE) status for all ports on the Power Sourcing Equipment (PSE).

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show power-inline`

Mode User Exec and Privileged Exec

Examples To display the PoE status for all ports on the PSE, use the following command:

```
awplus# show power-inline
```

Output Figure 23-3: Example output from the **show power-inline** command

```
awplus#show power-inline
PoE Status:

Stack Member 2
Nominal Power: 370W
Power Allocated: 246W
Actual Power Consumption: 151W
Operational Status: On
Power Usage Threshold: 80% (296W)

PoE Interface:
Interface  Admin   Pri   Oper   Power   Device   Class  Max (mW)
port2.0.1  Enabled Low   Powered 3840    n/a      1      4000 [C]
port2.0.2  Enabled High  Powered 6720    n/a      2      7000 [C]
port2.0.3  Enabled Low   Powered 14784   n/a      3      15400 [C]
port2.0.4  Enabled Crit  Powered 14784   n/a      3      15400 [C]
port2.0.5  Enabled Crit  Powered 3840    n/a      1      4000 [C]
port2.0.6  Enabled High  Powered 6720    n/a      2      7000 [C]
port2.0.7  Enabled Low   Powered 14784   n/a      3      15400 [C]
```

Table 23-1: Output description for the **show power-inline** command

Output	Meaning
Nominal Power:	Displays the nominal power available on device in watts (W).
Power Allocated:	Displays the current power allocated in watts (W) that is available to be drawn by any connected Powered Devices (PDs). This is updated every 5 seconds. If the maximum power for a port is dynamically configured then an asterisk (*) follows the amount.
Actual Power Consumption:	Displays the current power consumption in watts (W) drawn by any connected Powered Devices (PDs). This is updated every 5 seconds.
Operational Status	Displays the operational status of the PSU hardware on the PSE (Power Sourcing Equipment) when this command was issued: On if the PSU as installed inside the PSE is switched on. Off when the PSU in the PSE is switched off (an RPS may be connected to the PSE to power PoE instead of the PSU). Fault when there is an issue with the PSE PSU hardware.

Table 23-1: Output description for the **show power-inline** command (Continued)

Output (Continued)	Meaning (Continued)
Power Usage Threshold (%)	Displays the configured SNMP trap / log threshold for the PSE, as configured from a power-inline usage-threshold command.
Interface	Displays the PoE port(s) in the format <code>portx.y.z</code> , where <code>x</code> is the device number, <code>y</code> is the module number within the device, and <code>z</code> is the PoE port number within the module.
Admin	Displays the administrative state of PoE on a PoE port, either Enabled or Disabled.
Pri	Displays the current PoE priorities for PoE ports on the PSE, as configured from a power-inline priority command: Low displays when the <code>low</code> parameter is issued. The lowest priority for a PoE enabled port (default). High displays when the <code>high</code> parameter is issued. The second highest priority for a PoE enabled port. Crit displays when the <code>critical</code> parameter is issued. The highest priority for a PoE enabled port.
Oper	Displays the current PSE PoE port state when this command was issued: Powered displays when there is a PD connected and power is being supplied from the PSE. Disabled displays when supplying power would make the PSE go over the power budget. Off displays when PoE has been disabled for the PoE port. Fault displays when a PSE goes over its power allocation. Test displays when the PoE port is in test mode.
Power	Displays the power consumption in milliwatts (mW) for the PoE port when this command was entered.
Device	Displays the description of the connected PD device if a description has been configured with the power-inline description command. No description is shown for PDs not configured with the power-inline description command.
Class	Displays the class of the connected PD, if power is being supplied to the PD from the PSE. See the Power over Ethernet Introduction chapter for further information about PD classes and the power levels assigned per class.
Max (mW)	Displays the power in milliwatts (mW) allocated for the PoE port. Additionally, note the following as displayed per PoE port: [U] if the power limit for a port was user configured (with the power-inline max command). [L] if the power limit for a port was supplied by LLDP. [C] if the power limit for a port was supplied by the PD class.

Related Commands [show power-inline counters](#)
[show power-inline interface](#)

show power-inline counters

This command displays Power over Ethernet (PoE) event counters for ports on the Power Sourcing Equipment (PSE). The PoE event counters displayed can also be accessed by objects in the PoE MIB (RFC 3621). See [Chapter 76, SNMP MIBs](#) for information about which PoE MIB objects are supported.

To display all PoE event counters for all PoE ports on the PSE, do not enter the optional interface parameter.

For information on output options, see [“Controlling “show” command output” on page 1.33](#).

Syntax `show power-inline counters [<port-list>]`

Parameter	Description
<code><port-list></code>	Enter the PoE port(s) to display all PoE event counters for them.

Mode User Exec and Privileged Exec

Examples To display all PoE event counters for all PoE ports on the PSE, do not enter a `<port-list>`:

```
awplus# show power-inline counters
```

To display the PoE event counters for `port1.0.4` to `port1.0.12`, use the following command:

```
awplus# show power-inline counters interface port1.0.4-1.0.12
```

Output [Figure 23-4: Example output from the `show power-inline counters` command](#)

```
awplus#show power-inline counters interface port1.0.4-port1.0.12
PoE Counters:
Interface  MPSAbsent  Overload  Short  Invalid  Denied
port1.0.4   0           0         0      0         0
port1.0.5   0           0         0      0         0
port1.0.6   0           0         0      0         0
port1.0.7   0           0         0      0         0
port1.0.8   0           0         0      0         0
port1.0.9   0           0         0      0         0
port1.0.10  0           0         0      0         0
port1.0.11  0           0         0      0         0
port1.0.12  0           0         0      0         0
```

Table 23-2: Output description for the **show power-inline counters** command

Output Parameter	Meaning
Interface	Displays the PoE port(s) in the format <code>portx.y.z</code> , where <code>x</code> is the device number, <code>y</code> is the module number within the device, and <code>z</code> is the PoE port number within the module.
MPSAbsent	Displays the number of instances when the PoE MPS (Maintain Power Signature) signal has been lost. The PoE MPS signal is lost when a PD is disconnected from the PSE. Also increments <code>pethPsePortMPSAbsentCounter</code> in the PoE MIB.
Overload	Displays the number of instances when a PD exceeds its configured power limit (as configured by the power-inline max command). Also increments <code>pethPsePortOverLoadCounter</code> in the PoE MIB.
Short	Displays the number of short circuits that have happened with a PD. Also increments <code>pethPsePortShortCounter</code> in the PoE MIB.
Invalid	Displays the number of times a PD with an Invalid Signature (where the PD has an open or short circuit, or is a legacy PD) is detected. Also increments <code>pethPseInvalidSignatureCounter</code> in the PoE MIB.
Denied	Displays the number of times a PD has been refused power due to power budget limitations for the PSE. Also increments <code>pethPsePortPowerDeniedCounter</code> in the PoE MIB.

Related Commands

- `clear power-inline counters interface`
- `show power-inline`
- `show power-inline interface`

show power-inline interface

This command displays a summary of Power over Ethernet (PoE) information for specified ports. If no ports are specified then PoE information is displayed for all ports on the Power Sourcing Equipment (PSE).

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show power-inline interface [<port-list>]`

Parameter	Description
<code><port-list></code>	Enter the port(s) to display PoE specific information in the show output.

Mode User Exec and Privileged Exec

Examples To display the PoE port specific information for port1.0.1 to port1.0.4, use the following command:

```
awplus# show power-inline interface port1.0.1-port1.0.4
```

Output Figure 23-5: Example output from the **show power-inline interface** command

```
awplus#show power-inline interface port1.0.1-port1.0.4
Interface Admin Pri Oper Power Device Class Max(mW)
port1.0.1 Disabled Low Disabled 14784 n/a n/a 15400 [C]
port1.0.2 Enabled High Powered 3840 Desk Phone 1 5000 [U]
port1.0.3 Enabled Crit Powered 6720 AccessPoint 2 7000 [C]
port1.0.4 Disabled Low Disabled 14784 n/a n/a 15400 [C]
```


To display the PoE port specific information for all PoE ports on the switch, use the following command:

```
awplus# show power-inline interface
```

Output Figure 23-6: Example output from the **show power-inline interface** command

```
awplus#show power-inline interface
Interface Admin Pri Oper Power Device Class Max(mW)
port1.0.1 Disabled Low Disabled 14784 n/a n/a 15400 [C]
port1.0.2 Enabled High Powered 3840 Desk Phone 1 5000 [U]
port1.0.3 Enabled Crit Powered 6720 AccessPoint 2 7000 [C]
port1.0.4 Disabled Low Disabled 14784 n/a n/a 15400 [C]
port1.0.5 Disabled Low Disabled 14784 n/a n/a 15400 [C]
port1.0.6 Disabled Low Disabled 14784 n/a n/a 15400 [C]
port1.0.7 Disabled Low Disabled 14784 n/a n/a 15400 [C]
port1.0.8 Disabled Low Disabled 14784 n/a n/a 15400 [C]
port1.0.9 Disabled Low Disabled 14784 n/a n/a 15400 [C]
port1.0.10 Disabled Low Disabled 14784 n/a n/a 15400 [C]
port1.0.11 Disabled Low Disabled 14784 n/a n/a 15400 [C]
port1.0.12 Disabled Low Disabled 14784 n/a n/a 15400 [C]
port1.0.13 Disabled Low Disabled 14784 n/a n/a 15400 [C]
port1.0.14 Disabled Low Disabled 14784 n/a n/a 15400 [C]
port1.0.15 Disabled Low Disabled 14784 n/a n/a 15400 [C]
port1.0.16 Disabled Low Disabled 14784 n/a n/a 15400 [C]
port1.0.17 Disabled Low Disabled 14784 n/a n/a 15400 [C]
port1.0.18 Disabled Low Disabled 14784 n/a n/a 15400 [C]
port1.0.19 Disabled Low Disabled 14784 n/a n/a 15400 [C]
port1.0.20 Disabled Low Disabled 14784 n/a n/a 15400 [C]
```

Table 23-3: Output description for the **show power-inline interface** command

Output Parameter	Meaning
Interface	Displays the PoE port(s) in the format <code>portx.y.z</code> , where <code>x</code> is the device number, <code>y</code> is the module number within the device, and <code>z</code> is the PoE port number within the module.
Admin	Displays the administrative state of PoE on a PoE port, either Enabled or Disabled.
Pri	Displays the current PoE priorities for PoE ports on the PSE, as configured from a power-inline priority command: - Low displays when the <code>low</code> parameter is issued. The lowest priority for a PoE enabled port (default). - High displays when the <code>high</code> parameter is issued. The second highest priority for a PoE enabled port. - Crit displays when the <code>critical</code> parameter is issued. The highest priority for a PoE enabled port.
Oper	Displays the current PSE PoE port state when this command was issued: - Powered displays when there is a PD connected and power is being supplied from the PSE. - Disabled displays when supplying power would make the PSE go over the power budget. - Off displays when PoE has been disabled for the port. - Fault displays when a PSE goes over its power allocation. - Test displays when the PoE port is in test mode.

Table 23-3: Output description for the **show power-inline interface** command

Output Parameter	Meaning (Continued)
Power	Displays the power consumption in milliwatts (mW) for the PoE port when this command was entered.
Device	Displays the description of the connected PD device if a description has been configured with the power-inline description command. No description is shown for PDs not configured with the power-inline description command.
Class	Displays the class of the connected PD, if power is being supplied to the PD from the PSE. See “ Power classes ” on page 22.4 for further information about PD classes and the power assigned per class.
Max (mW)	Displays the power in milliwatts (mW) allocated for the PoE port. Additionally, note the following as displayed per PoE port: ■ [U] if the power limit for a port was user configured (with the power-inline max command). ■ [L] if the power limit for a port was supplied by LLDP. ■ [C] if the power limit for a port was supplied by the PD class.

Related Commands [show power-inline](#)
[show power-inline interface detail](#)

show power-inline interface detail

This command displays detailed information for specified Power over Ethernet (PoE) port(s) on the Power Sourcing Equipment (PSE).

To show detailed PoE information for all ports on the PSE, do not specify any ports.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show power-inline interface [<port-list>] detail`

Parameter	Description
<port-list>	Enter the PoE port(s) to display the PoE port specific information.

Mode User Exec and Privileged Exec

Usage The power allocated to each port is listed in the `Power allocated` row, and is limited by the maximum power per Powered Device (PD) class, or a user configured power limit.

Examples To display detailed PoE port specific information for `port2.0.1` to `port2.0.2`, use the following command:

```
awplus# show power-inline interface port2.0.1-port2.0.2 detail
```

Output Figure 23-7: Example output from the `show power-inline interface detail` command

```
awplus#show power-inline interface port2.0.1-2.0.2 detail
Interface port2.0.1
  Powered device type: Desk Phone #1
  PoE admin enabled
  Priority Low
  Detection status: Powered
  Current power consumption: 4800 mW
  Powered device class: 1
  Power allocated: 5000 mW (from configuration)
  Detection of legacy devices is disabled
  Powered pairs: Data
Interface port2.0.2
  Powered device type: Access Point #3
  PoE admin enabled
  Priority High
  Detection status: Powered
  Current power consumption: 6720 mW
  Powered device class: 2
  Power allocated: 7000 mW (from powered device class)
  Detection of legacy devices is enabled
  Powered pairs: Data
```

Table 23-4: Output description for the **show power-inline interface detail** command

Output Parameter	Meaning
Interface	Displays the PoE port(s) in the format <code>portx.y.z</code> , where <code>x</code> is the device number, <code>y</code> is the module number within the device, and <code>z</code> is the PoE port number within the module.
Powered device type:	Displays the name of the PD, if connected and if power is being supplied to the PD from the PSE, configured with the power-inline description command. n/a displays if a description has not been configured for the PD.
PoE admin	Displays the administrative state of PoE on a PoE capable port, either Enabled or Disabled as configured from the power-inline enable command or the <code>no power-inline enable</code> command respectively.
Priority	Displays the PoE priority of a port, which is either Low, or High, or Critical, as configured by the power-inline priority command.
Detection status:	Displays the current PSE PoE port state when this command was issued: ■ Powered displays when there is a PD connected and power is being supplied from the PSE. ■ Disabled displays when supplying power would make the PSE go over the power budget. ■ Off displays when PoE has been disabled for the PoE port. ■ Fault displays when a PSE goes over its power allocation. ■ Test displays when the PoE port is in test mode.
Current power consumption:	Displays the power consumption for the PoE port when this command was entered. Note that the power consumption may have changed since the command was entered and the power is displayed.
Powered device class:	Displays the class of the connected PD if connected, and if power is being supplied to the PD from the PSE. See Chapter 22, Power over Ethernet Introduction chapter for further information about PD classes and the power assigned per class.
Power allocated:	Displays the power in milliwatts (mW) allocated for the PoE port. Additionally, note the following as displayed per PoE port: ■ [U] if the power limit for a port was user configured (with the <code>power-inline max</code> command). ■ [L] if the power limit for a port was supplied by LLDP. ■ [C] if the power limit for a port was supplied by the PD class. If the maximum power for a port is dynamically configured then an asterisk (*) follows the amount.
Detection of legacy devices is	[Enabled Disabled] Displays the status of legacy PoE detection on the PoE port, as configured for the PoE port with the power-inline allow-legacy command.
Powered pairs:	[Data Spare] Either spare or data twisted pairs are used to transfer power to a PD. Displays the powered pairs status for each port. AlliedWare Plus PoE switches implement IEEE 802.3af Endpoint PSE Alternative A (Data). See “Power through the cable” on page 22.7 for further information about the data pairs in Ethernet cable used to transmit power.

Related Commands [show power-inline](#)
[show power-inline interface](#)

Part 3: Layer Three, Switching and Routing



- Chapter 24 Internet Protocol (IP) Addressing and Protocols
- Chapter 25 IP Addressing and Protocol Commands
- Chapter 26 IPv6 Introduction
- Chapter 27 IPv6 Commands
- Chapter 28 IPv6to4 Tunneling Configuration
- Chapter 29 IPv6to4 Tunneling Commands
- Chapter 30 Routing Protocol Overview
- Chapter 31 Route Selection
- Chapter 32 Routing Commands
- Chapter 33 RIP Configuration
- Chapter 34 RIP Commands
- Chapter 35 RIPng Configuration
- Chapter 36 RIPng Commands
- Chapter 37 OSPF Configuration
- Chapter 38 OSPF Commands
- Chapter 39 BGP Configuration
- Chapter 40 BGP Commands
- Chapter 41 Route Map Commands

Chapter 24: Internet Protocol (IP) Addressing and Protocols



Introduction.....	24.2
Address Resolution Protocol (ARP).....	24.3
Static ARP Entries.....	24.3
Timing Out ARP Entries.....	24.3
Deleting ARP Entries.....	24.4
Proxy ARP.....	24.4
Domain Name System (DNS).....	24.7
Internet Control Message Protocol (ICMP).....	24.9
ICMP Router Discovery Protocol (IRDP).....	24.10
Checking IP Connections.....	24.13
Ping.....	24.13
Traceroute.....	24.13
IP Helper.....	24.15
IP Directed Broadcast.....	24.15

Introduction

This chapter describes how to configure IPv4 addressing and the protocols used to help IP function on your network.

As well as the familiar Internet, with uppercase “I”, the term internet (with lowercase “i”) can refer to any network (usually a wide area network) that uses the Internet protocol. This chapter concentrates on this definition—a generalized network that uses IP as its transport protocol.

Assigning an IP Address

To configure your device to perform IP routing (for example, to access the Internet) you need to configure IP. You also need to configure IP if you want to manage your device from any IP-based management process (such as SSH, Telnet, or SNMP).

Add an IP address to each of the interfaces that you want to process IP traffic.

You can configure an interface on your device with a static IP address, or with a dynamic IP address assigned using your device's DHCP client.

Static IP addresses

To add a static IP address to an interface, enter interface mode for the interface that you want to configure, then use the command:

```
ip address <ip-addr/prefix-length> [secondary [label <label>]]
```

where <ip-address/m> the IP address followed by a slash then the prefix length. Note that you cannot specify the mask in dotted decimal notation in this command.

For example, to give the interface vlan1 an address of 192.168.10.10, with a class C subnet mask, use the command:

```
awplus(config-if)# ip address 192.168.10.10/24
```

The secondary parameter allows you to add multiple IP addresses to an interface using this command. Each interface must have a primary IP address before you can add a secondary address. Your device treats secondary addresses the same as primary addresses in most instances, such as responding for ARP requests for the IP address. However, the only packets generated that have a secondary address as source address are routing updates. You can define up to 32 secondary addresses on a single interface.

DHCP dynamic addresses

When you use the DHCP client, it obtains the IP address and subnet mask for the interface, and other IP configuration parameters, from a DHCP server. To configure an interface to gain its IP configuration using the DHCP client, use the command:

```
awplus(config-if)# ip address dhcp [client-id <interface>] [hostname <hostname>]
```

If an IP interface is configured to get its IP address and subnet mask from DHCP, the interface does not take part in IP routing until the IP address and subnet mask have been set by DHCP.

If you need to make a static entry in your DHCP server for the device, you need your device's MAC address, which you can display by using the command:

```
awplus# show interface
```

See [Chapter 72, Dynamic Host Configuration Protocol \(DHCP\) Introduction](#) for more information about DHCP.

Address Resolution Protocol (ARP)

Address Resolution Protocol (ARP) is used by your device to dynamically learn the layer 2 address of devices in its networks. Most hosts also have a MAC physical in addition to the assigned IP address. For Ethernet, this is a 6-byte, globally unique number. ARP enables your device to learn the physical address of the host that has a given IP address.

When your device needs to forward packets to a destination that it does not know the layer 2 address of, it broadcasts an ARP request to determine where to send the packet. The ARP request is a broadcast packet and includes the target IP address. All stations on the LAN receive this broadcast but only one host recognizes its own IP address. It replies, thereby giving your device its physical address.

Your device creates a dynamic ARP entry in its ARP cache, to record the IP address to physical address mapping (also called a binding). It uses that ARP entry to forward further packets to that address.

The ARP protocol is described in RFC 826, *An Ethernet Address Resolution Protocol—or—Converting Network Protocol Addresses to 48 bit Ethernet Address for Transmission on Ethernet Hardware*.

Static ARP Entries

If your LAN includes hosts that do not support ARP, you can add a static ARP entry to the cache. However, it is rarely necessary to add an ARP entry this way. To add a static ARP entry, use the command:

```
awplus(config)#arp <ip-addr> <mac-address> [<port-number>] [alias]
```

Timing Out ARP Entries

Your device times out dynamic ARP entries to ensure that the cache does not fill with entries for hosts that are no longer active. If your device stops receiving traffic for a device specified in a dynamic ARP entry, it deletes the ARP entry after a configurable timeout period. Static ARP entries are not aged or automatically deleted.

Increasing the ARP timeout reduces the amount of network traffic. Decreasing the timeout makes your device more responsive to changes in network topology.

To set a timeout period, enter the interface mode, then use the command:

```
awplus(config-if)#arp-aging-timeout <1-432000>
```

Deleting ARP Entries

To remove a static ARP entry, use the command:

```
awplus(config-if)#no arp <ip-addr>
```

To clear the ARP cache of dynamic entries, use the command:

```
awplus(config)#clear arp-cache
```

This removes the dynamic ARP entries for all interfaces.

To display the entries in the ARP cache, use the command:

```
awplus(config)#show arp
```

The ARP cache will be repopulated by the normal ARP learning mechanism. As long as the entries are relearned quickly enough, deleting dynamic ARP entries does not affect:

- routes
- OSPF neighbor status
- BGP peer status
- the TCP/UDP connection status
- VRRP status

Proxy ARP

Proxy ARP (defined in RFC 1027) allows hosts that do not support routing (i.e. they have no knowledge of the network structure) to determine the physical addresses of hosts on other networks. Your device intercepts ARP broadcast packets and substitutes its own physical address for that of the remote host. This occurs only if your device has the best route to the remote host. By responding to the ARP request, your device ensures that subsequent packets from the local host are directed to its physical address, and it can then forward these to the remote host. The process is symmetrical.

Proxy ARP is disabled by default. To enable proxy ARP on an interface, use the commands:

```
awplus(config)#interface <interface>  
awplus(config-if)#ip proxy-arp
```

To disable Proxy ARP on an interface, use the command:

```
awplus(config-if)#no ip proxy-arp
```

To check Proxy ARP is enabled on an interface, use the show running-config command. If Proxy ARP has been enabled an entry shows ip proxy-arp below the interface it is enabled on. No ip proxy-arp entry below an interface in the config indicates Proxy ARP is disabled on it.

See the sample configuration commands and validation command with resulting output showing proxy ARP enabled on VLAN 2 below:

```
awplus#configure terminal
awplus(config)#interface vlan2
awplus(config-if)#ip proxy-arp
awplus(config-if)#end
awplus(config)#exit
awplus#show running-config
!
interface vlan2
  ip proxy-arp
  ip address 192.168.2.2/24
!
```

See the sample configuration commands and validation command with resulting output showing proxy ARP disabled on VLAN 2 below:

```
awplus#configure terminal
awplus(config)#interface vlan2
awplus(config-if)#no ip proxy-arp
awplus(config-if)#end
awplus(config)#exit
awplus#show running-config
!
interface vlan2
  ip address 192.168.2.2/24
!
```

Local Proxy ARP

Local Proxy ARP lets you stop MAC address resolution between hosts within an interface's subnet. This ensures that devices within a subnet cannot send traffic that bypasses layer 3 routing on your device. This lets you monitor, filter, and control traffic between devices in the same subnet.

Local Proxy ARP extends proxy ARP by intercepting and responding to ARP requests between hosts within a subnet. Local proxy ARP responds to ARP requests with your device's own MAC address details instead of those from the destination host. This stops hosts from learning the MAC address of other hosts within its subnet.

When Local Proxy ARP is operating on an interface, your device does not generate or forward any ICMP-Redirect messages on that interface.

Local Proxy ARP is disabled by default. To enable local proxy ARP on an interface, use the commands:

```
awplus(config)#interface <interface>
awplus(config-if)#ip local-proxy-arp
```

To disable local proxy ARP on an interface, use the command:

```
awplus(config-if)#no ip local-proxy-arp
```

To check Local Proxy ARP is enabled on an interface, use the show running-config command. If Local Proxy ARP has been enabled an entry shows ip local-proxy-arp below the interface it is enabled on. No ip local-proxy-arp entry below an interface in the config indicates Local Proxy ARP is disabled on it.

See the sample configuration commands and validation command with resulting output showing local proxy ARP enabled on VLAN 1 below:

```
awplus#configure terminal
awplus(config)#interface vlan1
awplus(config-if)#ip local-proxy-arp
awplus(config-if)#end
awplus(config)#exit
awplus#show running-config
!
interface vlan1
  ip local-proxy-arp
  ip address 192.168.1.2/24
!
```

See the sample configuration commands and validation command with resulting output showing Local Proxy ARP disabled on VLAN 1 below:

```
awplus#configure terminal
awplus(config)#interface vlan1
awplus(config-if)#no ip local-proxy-arp
awplus(config-if)#end
awplus(config)#exit
awplus#show running-config
!
interface vlan1
  ip address 192.168.1.2/24
!
```

Domain Name System (DNS)

The Domain Name System allows you to access remote systems by entering human-readable device host names rather than IP addresses. DNS works by creating a mapping between a device name, such as “www.alliedtelesis.com”, and its IP address. These mappings are held on DNS servers. The benefits of DNS are that domain names:

- can map to a new IP address if the host's IP address changes
- are easier to remember than an IP address
- allow organizations to use a domain name hierarchy that is independent of any IP address assignment

Domain name parts

Domain names are made up of a hierarchy of two or more name segments. Each segment is separated by a period. The format of domain names is the same as the host portion of a URL (Uniform Resource Locator). The first segment from the left is unique to the host, with each following segment mapping the host in the domain name hierarchy. The segment on the far right is a top-level domain name shared by many hosts.

Server hierarchy

A network of domain name servers maintains the mappings between domain names and their IP addresses. This network operates in a hierarchy that is similar to the structure of the domain names. When a local DNS server cannot resolve your request it sends the request to a higher level DNS server.

For example, to access the site “alliedtelesis.com”, your PC sends a DNS enquiry to its local DNS server asking for the IP address matching alliedtelesis.com. If this address is already locally cached (following its recent use), the DNS server returns the IP address that matches alliedtelesis.com. If the DNS server does not have this address cached, it forwards the request upwards through the hierarchy of DNS servers until a DNS server can resolve the mapping. This means an often-used domain name is resolved quickly, while an uncommon or nonexistent domain may take longer to resolve or fail.

As well as the hierarchy of domain name servers accessible through the Internet, you can operate your own DNS server to map to private IP addresses within your network.

DNS client

Your AlliedWare Plus device has a DNS client that is enabled automatically when you add a DNS server to your device. This client allows you to use domain names instead of IP addresses when using commands on your device.

To add a DNS server to the list of servers that the device sends DNS queries to, use the command:

```
awplus(config)# ip name-server <ip-addr>
```

To check the list of servers that the device sends DNS queries to, use the command:

```
awplus# show ip name-server
```

To add a default domain name used to append to DNS requests, use the command:

```
awplus(config)# ip domain-name <domain_name>
```

For example, to use DNS to match hostnames to your internal network “example.net”, use the command:

```
awplus(config)# ip domain-name example.net
```

If you then use the command `ping host2`, your device sends a DNS request for `host2.example.net`. To check the domain name configured with this command, use the command:

```
awplus# show ip domain-name
```

Alternatively you can create a list of domain names that your device will try in turn by using the command:

```
awplus(config)# ip domain-list <domain_name>
```

For example, to use DNS to match incomplete hostnames to the top level domains “.com”, and “.net”, use the commands:

```
awplus(config)# ip domain-list .com
```

```
awplus(config)# ip domain-list .net
```

If you then use the command `ping alliedtelesis`, your device sends a DNS request for `alliedtelesis.com` and if no match was found your device would then try `alliedtelesis.net`. To check the entries in the domain list, use the command:

```
awplus# show ip domain-list
```

To disable the DNS client on your device, use the command:

```
awplus(config)# no ip domain-lookup
```

To check the status of the DNS client on your device, and the configured servers and domain names, use the command:

```
awplus# show hosts
```

DHCP options

When your device is using its DHCP client for an interface, it can receive the following DHCP options from the DHCP server:

- Option 6 - a list of DNS servers. This list appends to the DNS servers set on your device with the `ip name-server` command.
- Option 15 - a domain name used to resolve host names. This option replaces the domain name set with the `ip domain-name` command.

See [Chapter 72, Dynamic Host Configuration Protocol \(DHCP\) Introduction](#) for more information about DHCP and DHCP options.

Internet Control Message Protocol (ICMP)

The Internet Control Message Protocol (ICMP) allows networking devices to send information and control messages to other devices or hosts. Your device implements all non-obsolete ICMP functions.

The following table lists the ICMP messages implemented by your device.

ICMP Message Type	Device Response
Echo reply (0)	This is used to implement the ping command. Your device sends out an echo reply in response to an echo request.
Destination unreachable (3)	This message is sent when your device drops a packet because it did not have a route to the destination.
Source Quench (4)	Your device sends this message when it must drop a packet due to limited internal resources. This could be because the source was sending data too fast to be forwarded.
Redirect (5)	Your device issues this message to inform a local host that its target is located on the same LAN (no routing is required) or when it detects a host using a non-optimal route (usually because a link has failed or changed its status). For example, if your device receives a packet destined to its own MAC address, but with a destination IP address of another host in the local subnet, it returns an ICMP redirect to the originating host. ICMP redirects are disabled on interfaces on which local proxy ARP is enabled.
Echo request (8)	This is related to echo replies. If your device receives an echo request, it sends an echo reply. If you enter the ping command, your device generates echo requests.
Router Advertisements (10)	These are Router Discovery Protocol messages. If Router Discovery is enabled, your device sends these to announce the IP addresses of the sending interface.
Time to Live Exceeded (11)	If the TTL field in a packet falls to zero, your device sends this message. This occurs when there are too many hops in the path that a packet is traversing.

ICMP messages are enabled on all interfaces by default. You can control the flow of ICMP messages across different interfaces using the access-list commands. See [Chapter 51, Access Control List \(ACL\) Commands](#).

ICMP Router Discovery Protocol (IRDP)

Router discovery Your device supports the router specification sections of RFC 1256, *ICMP Router Discovery Messages*. If this feature is configured, your device sends router advertisements periodically and in response to router solicitations. It does not support the Host Specification section of this RFC.

Benefits Before an IP host can send an IP packet, the host has to know the IP address of a neighboring router that can forward the packet to its destination. ICMP Router Discovery messages let routers automatically advertise themselves to hosts. Other methods either require someone to manually keep these addresses current, or require DHCP to send router addresses.

Router discovery process The following table summarizes what happens when Router Discovery advertisements are enabled on an interface.

When...	Then...
Router Discovery advertising starts on an interface because: - your device starts up, or - you enable advertisements on your device or on an interface	your device multicasts a router advertisement and continues to multicast them periodically until router advertising is disabled.
a host starts up	the host may send a router solicitation message.
your device receives a router solicitation	your device multicasts an early router advertisement from the interface on which it received the router solicitation.
a host receives a router advertisement	the host stores the IP address and preference level for the advertisement lifetime.
the lifetimes of all existing router advertisements on a host expire	the host sends a router solicitation.
a host does not receive a router advertisement after sending a small number of router solicitations	the host waits for the next unsolicited router advertisement.
a host needs a default router address	the host uses the IP address of the router or L3 switch with the highest preference level.
Router Discovery advertising is deleted from the interface	your device multicasts a router advertisement with the IP address(es) that stopped advertising, and a lifetime of zero. It continues to periodically multicast router advertisements for other interfaces, if configured to.
the router receives a router advertisement from another router	the router does nothing but silently discards the message

Advertisement messages

A router advertisement is an ICMP (type 10) message that contains the following:

- in the destination address field of the IP header, the interface's configured advertisement address, either 224.0.0.1 or 255.255.255.255.
- in the lifetime field, the interface's configured advertisement lifetime.
- in the Router Address and Preference Level fields, the addresses and preference levels of all the logical interfaces that are set to advertise.

Your device does not send router advertisements by default.

Solicitation message

A router solicitation is an ICMP (type 10) message containing:

- source Address: an IP address belonging to the interface from which the message is sent
- destination Address: the configured Solicitation Address, and
- Time-to-Live: 1 if the Destination Address is an IP multicast address; at least 1 otherwise.

Advertisement interval

The router advertisement interval is the time between router advertisements. For the first few advertisements sent from an interface (up to 3), your device sends the router advertisements at intervals of at most 16 seconds. After these initial transmissions, it sends router advertisements at random intervals between the minimum and maximum intervals that the user configures, to reduce the probability of synchronization with the advertisements from other routers on the same link. By default, the minimum is 450 seconds (7.5 minutes), and the maximum is 600 seconds (10 minutes).

Preference level

The preference level is the preference of the advertised address as a default router address relative to other router addresses on the same subnet. By default, all routers and layer 3 switches have the same preference level, zero. While it is entered as a decimal from 0 to 2147483647, it is encoded in router advertisements as a twos-complement hex integer from 0x80000000 to 0x7fffffff. A higher preference level is preferred over a lower value.

Lifetime

The lifetime of a router advertisement is how long the information in the advertisement is valid. By default, the lifetime of all advertisements is 1800 seconds (30 minutes).

Address type

Your device can send its router advertisements using either a broadcast or multicast destination address. By default, your device sends router advertisements using the all-systems multicast address (224.0.0.1). However, on networks where the hosts do not support IP multicast you must use the broadcast address (255.255.255.255). To change the address type to broadcast on an interface, use the command:

```
awplus(config-if)# ip irdp broadcast
```

To change the address type back to multicast, use the no form of the above command, or use the command:

```
awplus(config-if)# ip irdp multicast
```

Configuration procedure

Do the following to configure your device to send router advertisements.

Step 1: Enter the interface to advertise.

Enter the configuration mode for the interface, using the command:

```
awplus(config)# interface <interface>
```

Step 2: Change the address type.

By default, your device sends router advertisements using a multicast destination address. If hosts on your network do not support this, change the address type to broadcast, using the command:

```
awplus(config-if)# ip irdp broadcast
```

Step 3: Configure the advertisement interval and lifetime.

By default, your device sends router advertisements every 7.5 to 10 minutes, with a lifetime of 30 minutes. These settings are likely to work well in most situations, and will not cause a large amount of extra traffic, even if there are several routers on the LAN. If you change these settings, keep the following proportions:

```
lifetime=3 x maxadvertisementinterval  
minadvertisementinterval=0.75 x maxadvertisementinterval
```

You cannot set the maximum advertisement interval below the minimum interval. If you are lowering the maximum interval to a value below the current minimum interval, you must change the minimum value first. This also applies to changing the minimum interval above the current maximum interval.

To change the maximum advertisement interval, use the command:

```
awplus(config-if)# ip irdp maxadvertinterval <4-1800>
```

To change the minimum advertisement interval, use the command:

```
awplus(config-if)# ip irdp minadvertinterval <3-1800>
```

To change the lifetime for your device's router advertisements, use the command:

```
awplus(config-if)# ip irdp lifetime <0-9000>
```

Step 4: Set preference levels.

By default, every interface has the same preference for becoming a default router. To give the interface a higher preference, increase the preference level. To give it a lower preference, decrease this value.

To set the preference level for all addresses on this interface, use the command:

```
awplus(config-if)# ip irdp preference <0-2147483647>
```

To set the preference for a specific address on the interface, use the command:

```
awplus(config-if)# ip irdp address <ip-address> preference  
                        <0-2147483647>
```

Step 5: Enable advertising on the interface.

To enable router advertisements on an interface, enter the interface mode and use the command:

```
awplus(config-if)# ip irdp
```

Step 6: Enable advertising on your device.

To globally enable router advertisements on your device, enter the configure mode and use the command:

```
awplus(config)# router ip irdp
```

Step 7: Check advertise settings.

To view the IRDP configuration on the interface, use the command:

```
awplus# show ip irdp interface [<interface-name>]
```

To view the global IRDP configuration for your device, use the command:

```
awplus# show ip irdp
```

Debugging IRDP

Information which may be useful for troubleshooting IRDP is available using the IRDP debugging function. To enable IRDP debugging, use the command:

```
awplus# debug ip irdp {event|nsm|receive|send|both|detail|all}
```

Checking IP Connections

To verify connections between networks and network devices, use the ping (Packet Internet Groper) and trace route functions on your device.

Ping

Ping tests the connectivity between two network devices to determine whether each network device can “see” the other device. Echo request packets are sent to the destination addresses and responses are displayed on the console.

If you can ping the end destination, then the physical, Layer 2 and Layer 3 links are functioning, and any difficulties are in the network or higher layers.

If pinging the end destination fails, use traceroute to discover the point of failure in the route to the destination.

To ping a device, use the command:

```
awplus# ping {<hostname> | <ipaddr>}
```

where WORD can be either the hostname or the IP address of the device you are trying to reach.

Traceroute

You can use traceroute to discover the route that packets pass between two systems running the IP protocol. Traceroute sends an initial UDP packets with the Time To Live (TTL) field in the IP header set starting at 1. The TTL field is increased by one for every subsequent packet sent until the destination is reached. Each hop along the path between two systems responds with a TTL exceeded packet (ICMP type 11) and from this the path is determined.

To use traceroute, use the command:

```
awplus# traceroute {<ip-addr>|<hostname>}
```

where WORD can be either the hostname or the IP address of the device you are trying to reach.

IP Helper

The IP Helper feature allows the switch to receive UDP broadcasts on one subnet, and forward them as broadcasts or unicasts into another subnet, so a client can use an application which uses UDP broadcast (such as Net-BIOS) when the client and server are located in different subnets. The IP Helper feature forwards UDP broadcast network traffic to specific hosts on another subnet and/or to the broadcast address of another subnet.

When the IP Helper feature is enabled on a VLAN interface, the UDP broadcast packets received on the interface are processed for forwarding out through another interface into another subnet. Depending on the nature of the `ip-helper` addresses configured, the UDP broadcasts will be unicast forwarded to a single host in the destination subnet, or unicast forwarded to multiple hosts in the destination subnet, or broadcast to the broadcast address of the destination subnet. Not all UDP broadcasts will be forwarded when IP Helper is configured. The set of broadcasts to be forwarded can be defined by specifying the destination UDP port(s) of the packets you wish to forward.

The command to enable the forwarding of UDP broadcasts received on a given interface is `ip helper-address` (entered in interface configuration mode). The `ip forward-protocol udp` command specifies types of broadcast packets to forward.

Multiple different destination addresses can be specified by using multiple instances of the `ip helper-address` command under the same interface. If a destination address is specified that is actually the broadcast address of one of the subnets directly connected to the switch, then the UDP packets will be forwarded as broadcasts onto that subnet.

Likewise, multiple different types of UDP packet can be specified for forwarding by specifying multiple different destination ports using the `ip forward-protocol udp` command.

Note: The types of UDP broadcast packets that the switch will forward are ONLY those specified by the `ip forward-protocol` command(s). There are not other UDP packet types that the IP helper process forwards by default.

IP Directed Broadcast

IP directed-broadcast is enabled and disabled per VLAN interface. When enabled a directed broadcast packet is forwarded to an enabled VLAN interface if received on another subnet.

An IP directed broadcast is an IP packet whose destination address is a broadcast address for some IP subnet, but originates from a node that is not itself part of that destination subnet. When a directed broadcast packet reaches a switch that is directly connected to its destination subnet, the packet is flooded as a broadcast on the destination subnet.

The `ip directed-broadcast` command controls the flooding of directed broadcasts when they reach target subnets. The command affects the final transmission of the directed broadcast on its destination subnet. It does not affect the transit unicast routing of IP directed broadcasts. If directed broadcast is enabled for an interface, incoming directed broadcast IP packets intended for the subnet assigned to interface will be flooded as broadcasts on that subnet.

If the `no ip directed-broadcast` command is configured for an interface, directed broadcasts destined for the subnet where the interface is attached will be dropped instead of broadcast.

Chapter 25: IP Addressing and Protocol Commands

Command List	25.2
arp-aging-timeout	25.2
arp (IP address MAC address)	25.3
clear arp-cache	25.4
debug ip packet interface	25.5
debug ip irdp	25.7
ip address	25.9
ip domain-list	25.10
ip domain-lookup	25.11
ip domain-name	25.12
ip directed-broadcast	25.13
ip forward-protocol udp	25.15
ip gratuitous-arp-link	25.16
ip helper-address	25.18
ip irdp	25.19
ip irdp address preference	25.20
ip irdp broadcast	25.21
ip irdp holdtime	25.22
ip irdp lifetime	25.23
ip irdp maxadvertinterval	25.24
ip irdp minadvertinterval	25.25
ip irdp multicast	25.26
ip irdp preference	25.27
ip local-proxy-arp	25.28
ip name-server	25.29
ip proxy-arp	25.30
optimistic-nd	25.31
ping	25.32
router ip irdp	25.33
show arp	25.34
show debugging ip packet	25.35
show hosts	25.36
show ip domain-list	25.36
show ip domain-name	25.37
show ip forwarding	25.37
show ip interface brief	25.38
show ip irdp	25.39
show ip irdp interface	25.40
show ip name-server	25.42
tcpdump	25.43
tracert	25.43

Command List

This chapter provides an alphabetical reference of commands used to configure the following protocols:

- Address Resolution Protocol (ARP)
- Domain Name Service (DNS)
- ICMP Router Discovery Advertisements (IRDP)

For more information see [Chapter 24, Internet Protocol \(IP\) Addressing and Protocols](#).

arp-aging-timeout

This command sets a timeout period on dynamic ARP entries associated with a specific interface. If your device stops receiving traffic for the host specified in a dynamic ARP entry, it deletes the ARP entry from the ARP cache after this timeout is reached.

Your device times out dynamic ARP entries to ensure that the cache does not fill with entries for hosts that are no longer active. Static ARP entries are not aged or automatically deleted.

By default the time limit for dynamic ARP entries is 300 seconds on all interfaces.

The no form sets the time limit to the default of 300 seconds.

Syntax `arp-aging-timeout <1-432000>`
`no arp-aging timeout`

Parameter	Description
<code><1-432000></code>	The timeout period in seconds.

Mode Interface Configuration for a VLAN interface.

Default 300 seconds (5 minutes)

Example To set the ARP entries on interface `vlan30` to time out after two minutes, use the commands:

```
awplus(config)# interface vlan30
awplus(config-if)# arp-aging-timeout 120
```

Related Commands `clear arp-cache`
 `show arp`

arp (IP address MAC address)

This command adds a static ARP entry to the ARP cache. This is typically used to add entries for hosts that do not support ARP or to speed up the address resolution function for a host. The ARP entry must not already exist. Use the `alias` parameter to allow your device to respond to ARP requests for this IP address.

The `no` form removes the static ARP entry. Use the `clear arp-cache` command to remove the dynamic ARP entries in the ARP cache.

Syntax `arp <ip-addr> <mac-address> [<port-number>] [alias]`
`no arp <ip-addr>`

Parameter	Description
<code><ip-addr></code>	IPv4 address of the device you are adding as a static ARP entry.
<code><mac-address></code>	MAC address of the device you are adding as a static ARP entry, in hexadecimal notation with the format HHHH.HHHH.HHHH.
<code><port-number></code>	The port number associated with the IP address. Specify this when the IP address is part of a VLAN.
<code>alias</code>	Allows your device to respond to ARP requests for the IP address. Proxy ARP must be enabled on the interface before using this parameter.

Mode Global Configuration

Example To add the IP address 10.10.10.9 with the MAC address 0010.2533.4655 into the ARP cache, and have your device respond to ARP requests for this address, use the commands:

```
awplus# configure terminal
awplus(config)# arp 10.10.10.9 0010.2355.4566 alias
```

Related Commands `clear arp-cache`
`ip proxy-arp`
`show arp`

clear arp-cache

This command deletes the dynamic ARP entries from the ARP cache.

To display the entries in the ARP cache, use the [show arp](#) command. To remove static ARP entries, use the [no arp <ip-addr>](#) command.

Syntax `clear arp-cache`

Mode Privileged Exec

Example To clear the dynamic ARP entries, use the command:

```
awplus# clear arp-cache
```

Related Commands [arp-aging-timeout](#)
[arp \(IP address MAC address\)](#)
[show arp](#)

debug ip packet interface

The debug ip packet interface command enables IP packet debug and is controlled by the terminal monitor command.

- If the optional icmp keyword is specified then ICMP packets are shown in the output.

The no debug ip interface command disables the debug ip interface command.

Syntax debug ip packet interface {<interface-name>|all}
[address <ip-address>|verbose|hex|arp|udp|tcp|icmp]
no debug ip packet interface [<interface-name>]

Parameter	Description
<interface-name>	Specify a single layer 3 interface name (not a range of interfaces) This keyword can be specified as either all or as a single layer 3 interface to show debugging for either all interfaces or a single interface.
all	Specify all layer 3 interfaces on the switch.
<ip-address>	Specify an IPv4 address. If this keyword is specified, then only packets with the specified IP address as specified in the ip-address placeholder are shown in the output.
verbose	Specify verbose to output more of the IP packet. If this keyword is specified then more of the packet is shown in the output.
hex	Specify hex to output the IP packet in hexadecimal. If this keyword is specified, then the output for the packet is shown in hex.
arp	Specify arp to output ARP protocol packets. If this keyword is specified, then ARP packets are shown in the output.
udp	Specify udp to output UDP protocol packets. If this keyword is specified then UDP packets are shown in the output.
tcp	Specify tcp to output TCP protocol packets. If this keyword is specified, then TCP packets are shown in the output.
icmp	Specify icmp to output ICMP protocol packets. If this keyword is specified, then ICMP packets are shown in the output.

Mode Privileged Exec and Global Configuration

Examples To turn on ARP packet debugging on `vlan1`, use the command:

```
awplus# debug ip packet interface vlan1 arp
```

To turn on all packet debugging on all interfaces on the switch, use the command:

```
awplus# debug ip packet interface all
```

To turn on TCP packet debugging on `vlan1` and IP address `192.168.2.4`, use the command:

```
awplus# debug ip packet interface vlan1 address 192.168.2.4 tcp
```

To turn off IP packet interface debugging on all interfaces, use the command:

```
awplus# no debug ip packet interface
```

To turn off IP packet interface debugging on interface `vlan2`, use the command:

```
awplus# no debug ip packet interface vlan2
```

Related Commands

- `no debug all`
- `show debugging ip packet`
- `tcpdump`
- `terminal monitor`

debug ip irdp

This command enables debugging of ICMP Router Discovery Protocol (IRDP) events and messages on your device. IRDP debugging is disabled by default.

- If event is specified, then IRDP events related debugging will be enabled.
- If nsm is specified, then IRDP processing of NSM messages debugging will be enabled.
- If receive is specified, then IRDP input packet processing debugging will be enabled.
- If send is specified, then IRDP output packet processing debugging will be enabled.
- If both is specified, then both IRDP input and output packet processing debugging will be enabled.
- If detail is specified, then both IRDP detailed input and output packet processing debugging will be enabled.
- If all is specified, then all IRDP debugging will be enabled.

The no form disables IRDP debugging.

- Note that setting detail also sets both, so if you set detail, the output will show "packet debugging mode is all". Negating any packet debug mode will switch detail off.

Syntax debug ip irdp {event|nsm|receive|send|both|detail|all}
no debug ip irdp {event|nsm|receive|send|both|detail|all}

Parameter	Description
event	Enables debugging of IRDP events.
nsm	Enables debugging of IRDP processing of NSM messages.
receive	Enables debugging of IRDP input packet processing.
send	Enables debugging of IRDP output packet processing.
both	Enables debugging of both IRDP input and output packet processing.
detail	Enables detailed debugging of both IRDP input and output packet processing.
all	Enables all IRDP debugging types.

Mode Privileged Exec and Global Configuration

Default IRDP protocol debugging is disabled by default

Examples To enable IRDP input packet process debugging, use the following command:

```
awplus# debug ip irdp receive
```

To disable all IRDP debugging, use the following command:

```
awplus# no debug ip irdp all
```

Related Commands [ip irdp](#)
 [router ip irdp](#)
 [show ip irdp](#)

ip address

This command sets a static IP address on an interface. To set the primary IP address on the interface, specify only ip address *<ip-address/m>*. This overwrites any configured primary IP address. To add additional IP addresses on this interface, use the secondary parameter. You must configure a primary address on the interface before configuring a secondary address.

Note: Use show running-config interface not show ip interface brief when you need to view a secondary address configured on an interface. show ip interface brief will only show the primary address not a secondary address for an interface

The no form removes the IP address from the interface. You cannot remove the primary address when a secondary address is present.

Syntax ip address *<ip-addr/prefix-length>* [secondary [label *<label>*]]
no ip address *<ip-addr/prefix-length>* [secondary]
no ip address

Parameter	Description
<i><ip-addr/prefix-length></i>	The IPv4 address and prefix length you are assigning to the interface.
label	Adds a user-defined description of the secondary IP address.
<i><label></i>	A user-defined description of the secondary IP address. Valid characters are any printable character and spaces.

Mode Interface Configuration for a VLAN interface.

Examples To add the primary IP address 10.10.10.50/24 to the interface vlan3, use the following commands:

```
awplus# configure terminal
awplus(config)# interface vlan3
awplus(config-if)# ip address 10.10.10.50/24
```

To add the secondary IP address 10.10.11.50/24 to the same interface, use the following commands:

```
awplus# configure terminal
awplus(config)# interface vlan3
awplus(config-if)# ip address 10.10.11.50/24 secondary
```

Related Commands show ip interface brief
show running-config interface

ip domain-list

This command adds a domain to the DNS list. Domain are appended to incomplete host names in DNS requests. Each domain in this list is tried in turn in DNS lookups. This list is ordered so that the first entry you create is checked first.

If there are no domains in the DNS list, then your device uses the domain specified with the [ip domain-name](#) command. If any domain exists in the DNS list, then the device does not use the domain set using the [ip domain-name](#) command.

The no parameter deletes a domain from the list.

Syntax `ip domain-list <domain_name>`
`no ip domain-list <domain_name>`

Parameter	Description
<code><domain_name></code>	Domain string, for example "company.com".

Mode Global Configuration

Example To add the domain `example.net` to the DNS list, use the following commands:

```
awplus# configure terminal
awplus(config)# ip domain-list example.net
```

Related Commands [ip domain-lookup](#)
 [ip domain-name](#)
 [show ip domain-list](#)

ip domain-lookup

This command enables the DNS client on your device. This allows you to use domain names instead of IP addresses in commands. The DNS client resolves the domain name into an IP address by sending a DNS enquiry to a DNS server, specified with the [ip name-server](#) command.

The client is enabled by default. However, it does not attempt DNS enquiries unless there is a DNS server configured.

The no parameter disables the DNS client. The client will not attempt to resolve domain names. You must use IP addresses to specify hosts in commands.

Syntax ip domain-lookup
 no ip domain-lookup

Mode Global Configuration

Examples To enable the DNS client on your device, use the following commands:

```
awplus# configure terminal
awplus(config)# ip domain-lookup
```

To disable the DNS client on your device, use the following commands:

```
awplus# configure terminal
awplus(config)# no ip domain-lookup
```

Related Commands [ip domain-list](#)
 [ip domain-name](#)
 [ip name-server](#)
 [show hosts](#)
 [show ip name-server](#)

ip domain-name

This command sets a default domain for the DNS. The DNS client appends this domain to incomplete host-names in DNS requests.

If there are no domains in the DNS list (created using the [ip domain-list](#) command) then your device uses the domain specified with this command. If any domain exists in the DNS list, then the device does not use the domain configured with this command.

When your device is using its DHCP client for an interface, it can receive Option 15 from the DHCP server. This option replaces the domain name set with this command. See [Chapter 72, Dynamic Host Configuration Protocol \(DHCP\) Introduction](#) for more information about DHCP and DHCP options.

The no parameter removes the domain-name previously set by this command.

Syntax

```
ip domain-name <domain_name>
no ip domain-name <domain_name>
```

Parameter	Description
<domain_name>	Domain string, for example "company.com".

Mode Global Configuration

Example To configure the domain name, enter the following commands:

```
awplus# configure terminal
awplus(config)# ip domain-name company.com
```

Related Commands

- [ip domain-list](#)
- [show ip domain-list](#)
- [show ip domain-name](#)

ip directed-broadcast

Use this command to enable flooding of directed broadcast packets into a directly connected subnet. If this command is configured on a VLAN interface, then directed broadcasts received on other VLAN interfaces, destined for the subnet on this VLAN, will be flooded to the subnet broadcast address of this VLAN.

Use the `no` parameter with this command to disable `ip directed-broadcast`. When this feature is disabled using `no ip directed-broadcast`, directed broadcasts are not forwarded.

Syntax `ip directed-broadcast`
 `no ip directed-broadcast`

Default The `ip directed-broadcast` command is disabled by default.

Usage `IP directed-broadcast` is enabled and disabled per VLAN interface. When enabled a directed broadcast packet is forwarded to an enabled VLAN interface if received on another subnet.

An IP directed broadcast is an IP packet whose destination address is a broadcast address for some IP subnet, but originates from a node that is not itself part of that destination subnet. When a directed broadcast packet reaches a switch that is directly connected to its destination subnet, that packet is flooded as a broadcast on the destination subnet.

The `ip directed-broadcast` command controls the flooding of directed broadcasts when they reach target subnets. The command affects the final transmission of the directed broadcast on its destination subnet. It does not affect the transit unicast routing of IP directed broadcasts. If directed broadcast is enabled for an interface, incoming directed broadcast IP packets intended for the subnet assigned to interface will be flooded as broadcasts on that subnet.

If the `no ip directed-broadcast` command is configured for an interface, directed broadcasts destined for the subnet where the interface is attached will be dropped instead of broadcast.

Mode Interface Configuration for a VLAN interface.

Examples To enable `ip directed-broadcast`, to flood broadcast packets out via the `vlan2` interface, enter the following commands:

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip directed-broadcast
```

To disable ip directed-broadcast, disabling the flooding of broadcast packets via `vlan2`, enter the following commands:

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# no ip directed-broadcast
```

**Validation
Commands** `show running-config`

Related Commands `ip forward-protocol udp`
 `ip helper-address`

ip forward-protocol udp

This command enables you to control which UDP broadcasts will be forwarded to the helper address(es). A UDP broadcast will only be forwarded if the destination UDP port number in the packet matches one of the port numbers specified using this command.

Refer to the IANA site (www.iana.org) for a list of assigned UDP port numbers for protocols to forward using ip forward-protocol udp.

Use the no parameter to remove a port number from the list of destination port numbers that are used as the criterion for deciding if a given UDP broadcast should be forwarded to the IP helper address(es).

Syntax ip forward-protocol udp <port>
no ip forward-protocol udp <port>

Parameter	Description
<port>	UDP Port Number

Default The ip forward-protocol udp command is not enabled by default.

Mode Global Configuration

Usage Combined with the [ip helper-address command on page 25.18](#) in interface mode, the ip forward-protocol udp command in global configuration mode allows control of which protocols (destination port numbers) are forwarded. The ip forward-protocol udp command configures protocols for forwarding, and the ip helper-address command configures the destination address(es).

*Note: The types of UDP broadcast packets that the switch will forward are ONLY those specified by the **ip forward-protocol** command(s). There are not other UDP packet types that the IP helper process forwards by default.*

Examples To configure forwarding of packets on UDP port 53 (DNS protocol), use the following commands:

```
awplus# configure terminal
awplus(config)# ip forward-protocol udp 53
```

To delete UDP port 53 (DNS protocol) from the UDP ports that the switch forwards, use the following commands:

```
awplus# configure terminal
awplus(config)# no ip forward-protocol udp 53
```

Validation Commands show running-config

Related Commands ip helper-address
ip directed-broadcast

ip gratuitous-arp-link

This command sets the Gratuitous ARP time limit for all switchports. The time limit restricts the sending of Gratuitous ARP packets to one Gratuitous ARP packet within the time in seconds. The range is <0-300> seconds, where 0 disables all sending, and the default is 5 seconds.

Note: Previously this command specified time between Gratuitous ARP packets to prevent excessive Gratuitous ARP packet transmission in the case of a link flapping up and down. Now this command specifies time between sequences of Gratuitous ARP packets, and time between individual Gratuitous ARP packets occurring in a sequence, to allow legacy support for older devices and interoperability between other devices that are not ready to receive and forward data until several seconds after linkup.

Additionally, jitter has been applied to the delay following linkup, so Gratuitous ARP packets applicable to a given port are spread over a period of 1 second so are not all sent at once. Remaining Gratuitous ARP packets in the sequence occur after a fixed delay from the first one.

Syntax `ip gratuitous-arp-link <0-300>`
`no ip gratuitous-arp-link`

Parameter	Description
<0-300>	Specify the minimum time between sequences of Gratuitous ARPs and the fixed time between Gratuitous ARPs occurring in a sequence, in seconds.

Mode Global Configuration

Default The default Gratuitous ARP time limit for all switchports is 5 seconds.

Usage Every switchport will send a sequence of 3 Gratuitous ARP packets to each VLAN that the switchport is a member of, whenever the switchport moves to the forwarding state. The first Gratuitous ARP packet is sent 1 second after the switchport becomes a forwarding switchport. The second and third Gratuitous ARP packets are each sent after the time period specified by the Gratuitous ARP time limit.

Additionally, the Gratuitous ARP time limit specifies the minimum time between the end of one Gratuitous ARP sequence and the start of another Gratuitous ARP sequence. When a link is flapping, the switchport's state is set to forwarding several times. The Gratuitous ARP time limit is imposed to prevent Gratuitous ARP packets from being sent undesirably often.

Specifying 0 for the Gratuitous ARP time limit disables the sending of Gratuitous ARP packets.

Examples To disable the sending of Gratuitous ARP packets, use the commands:

```
awplus# configure terminal
awplus(config)# ip gratuitous-arp-link 0
```

To restrict the sending of Gratuitous ARP packets to one every 20 seconds, use the commands:

```
awplus# configure terminal
```

```
awplus(config)# ip gratuitous-arp-link 20
```

Validation `show running-config`
Commands

ip helper-address

This command adds a forwarding destination address for IP Helper to enable forwarding of User Datagram Protocol (UDP) broadcasts on an interface.

Use the no form of this command to disable the forwarding of broadcast packets to specific addresses.

Syntax `ip helper-address <ip-addr>`
`no ip helper-address <ip-addr>`

Parameter	Description
<ip-addr>	Forwarding destination IP address for IP Helper

Default The destination address for the ip helper-address command is not configured by default.

Mode Interface Configuration for a VLAN interface.

Usage Combined with the [ip forward-protocol udp](#) command in global configuration mode, the ip helper-address command in interface mode allows control of which protocols (destination port numbers) are forwarded. The ip forward-protocol udp command configures protocols for forwarding, and the ip helper-address command configures the destination address(es).

The destination address can be a unicast address or a subnet broadcast address. The UDP destination port is configured separately with the ip forward-protocol udp command. If multiple destination addresses are registered then UDP packets are forwarded to each IP address added to an IP Helper. Up to 32 destination addresses may be added using IP Helper.

*Note: The types of UDP broadcast packets that the switch will forward are ONLY those specified by the **ip forward-protocol** command(s). There are not other UDP packet types that the IP helper process forwards by default.*

Examples The following example defines IPv4 address 192.168.1.100 as an IP Helper destination address to which to forward UDP broadcasts received on vlan2:

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip helper-address 192.168.1.100
```

The following example removes IPv4 address 192.168.1.100 as an IP Helper destination address to which to forward UDP broadcasts received on vlan2:

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# no ip helper-address 192.168.1.100
```

Validation Commands `show running-config`

Related Commands [ip forward-protocol udp](#)
[ip directed-broadcast](#)

ip irdp

This command enables ICMP Router Discovery advertising on an interface. However, the interface does not send or process Router Discovery messages until at least one IP address is configured on the interface with the [ip address](#) command.

The no form of this command disables ICMP Router Discovery advertisements on an IP interface. All transmitting and processing of Router Discovery messages ceases immediately on the interface.

Syntax `ip irdp`
 `no ip irdp`

Mode Interface Configuration for a VLAN interface.

Examples To enable Router Discovery advertisements on `vlan4`, use the commands:

```
awplus# configure terminal
awplus(config)# interface vlan4
awplus(config-if)# ip irdp
```

To disable Router Discovery advertisements on `vlan4`, use the commands:

```
awplus# configure terminal
awplus(config)# interface vlan4
awplus(config-if)# no ip irdp
```

Related Commands [show ip irdp](#)
 [show ip irdp interface](#)

ip irdp address preference

When multiple routers connected to a LAN are all sending Router Discovery advertisements, hosts need to be able to choose the best router to use. Therefore the IRDP defines a preference value to place in the Router Discovery advertisements. Hosts choose the router with the highest preference value.

This command sets the preference value to include in Router Discovery advertisements sent for the specified IP address.

The no form of this command sets the preference for a specific address to the default of 0.

Syntax `ip irdp address <ip-address> preference <0-2147483647>`
`no ip irdp address <ip-address> preference`

Parameter	Description
<ip-address>	The IP address to be advertised with the specified preference value.
<0-2147483647>	The preference value advertised. A higher number increases the preference level for this address. Default: 0

Mode Interface Configuration for a VLAN interface.

Examples To set the preference value to 3000 for the address 192.168.1.1 advertised on `vlan5`, use the commands:

```
awplus# configure terminal
awplus(config)# interface vlan5
awplus(config-if)# ip irdp address 192.168.1.1 preference 3000
```

To set the preference value to the default of 0 for the address 192.168.1.1 advertised on `vlan5`, use the commands:

```
awplus# configure terminal
awplus(config)# interface vlan5
awplus(config-if)# no ip irdp address 192.168.1.1 preference
```

Related Commands `ip irdp`
`ip irdp preference`
`show ip irdp interface`

ip irdp broadcast

This command configures broadcast Router Discovery advertisements on an interface. The interface sends IRDP advertisements with the broadcast address (255.255.255.255) as the IP destination address.

The no form of this command configures multicast Router Discovery advertisements on an interface. The interface sends IRDP advertisements with the all-system multicast address (224.0.0.1) as the IP destination address.

Syntax `ip irdp broadcast`
`no ip irdp broadcast`

Mode Interface Configuration for a VLAN interface.

Examples To enable broadcast Router Discovery advertisements on `vlan13`, use the commands:

```
awplus# configure terminal
awplus(config)# interface vlan13
awplus(config-if)# ip irdp broadcast
```

To enable multicast Router Discovery advertisements on `vlan13`, use the commands:

```
awplus# configure terminal
awplus(config)# interface vlan13
awplus(config-if)# no ip irdp broadcast
```

Related Commands `ip irdp`
 `ip irdp multicast`
 `show ip irdp interface`

ip irdp holdtime

This command sets the maximum length of time that the advertised addresses are to be considered as valid router addresses by hosts.

The no form of this command resets the holdtime back to the default of 1800 seconds.

Syntax `ip irdp holdtime <0-9000>`
`no ip irdp holdtime <0-9000>`

Parameter	Description
<0-9000>	The holdtime value in seconds of addresses advertised. Default: 1800

Mode Interface Configuration for a VLAN interface.

Default The IRDP holdtime is set to 1800 seconds (30 minutes) by default.

Examples To set the holdtime value of addresses advertised on `vlan2` to 4000 seconds, use the commands:

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip irdp holdtime 4000
```

To set the holdtime value of addresses advertised on `vlan2` back to the default, use the commands:

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# no ip irdp holdtime
```

Related Commands `show ip irdp interface`

ip irdp lifetime

This command sets the maximum length of time that hosts should consider the Router Discovery advertised addresses as valid router addresses. If you change the lifetime value, also change the `maxadvertisementinterval` and the `minadvertisementinterval` to maintain the following ratios:

```
lifetime=3 x maxadvertisementinterval
minadvertisementinterval=0.75 x maxadvertisementinterval
```

This command is synonymous with the `ip irdp hostname <0-9000>` command.

The `no` form of this command sets the lifetime back to the default of 1800 seconds.

Syntax

```
ip irdp lifetime <0-9000>
no ip irdp lifetime
```

Parameter	Description
<0-9000>	Lifetime value in seconds of the advertised addresses. Default: 1800

Mode Interface Configuration for a VLAN interface.

Examples To set the lifetime value to 4000 seconds for addresses advertised on `vlan6`, use the commands:

```
awplus# configure terminal
awplus(config)# interface vlan6
awplus(config-if)# ip irdp lifetime 4000
```

To set the lifetime value to the default of 1800 seconds for addresses advertised on `vlan6`, use the commands:

```
awplus# configure terminal
awplus(config)# interface vlan6
awplus(config-if)# no ip irdp lifetime
```

Related Commands

```
ip irdp
ip irdp maxadvertinterval
ip irdp minadvertinterval
show ip irdp interface
```

ip irdp maxadvertinterval

This command sets the maximum time allowed between sending router advertisements from the interface. If you change the maxadvertisementinterval value, also change the lifetime and the minadvertisementinterval to maintain the following ratios:

```
lifetime=3 x maxadvertisementinterval
```

```
minadvertisementinterval=0.75 x maxadvertisementinterval
```

You cannot set the maximum advertisement interval below the minimum interval. If you are lowering the maximum interval to a value below the current minimum interval, you must change the minimum value first.

The no form of this command sets the maxadvertinterval back to the default of 600 seconds.

Syntax `ip irdp maxadvertinterval <4-1800>`

`no ip irdp maxadvertinterval`

Parameter	Description
<4-1800>	The maximum time, in seconds, between Router Discovery advertisements. Default: 600 seconds

Mode Interface Configuration for a VLAN interface.

Default The IRDP maximum advertisement interval is set to 600 seconds (10 minutes) by default.

Examples To set the maximum interval between Router Discovery advertisements on `vlan7` to 950 seconds, use the commands:

```
awplus# configure terminal
awplus(config)# interface vlan7
awplus(config-if)# ip irdp maxadvertinterval 950
```

To set the maximum interval between advertisements on `vlan7` back to the default, use the commands:

```
awplus# configure terminal
awplus(config)# interface vlan7
awplus(config-if)# no ip irdp maxadvertinterval
```

Related Commands

- `ip irdp`
- `ip irdp lifetime`
- `ip irdp minadvertinterval`
- `show ip irdp interface`

ip irdp minadvertinterval

This command sets the minimum time allowed between sending router advertisements from the interface. If you change the minadvertisementinterval value, also change the lifetime and the maxadvertisementinterval to maintain the following ratios:

$$\text{lifetime} = 3 \times \text{maxadvertisementinterval}$$

$$\text{minadvertisementinterval} = 0.75 \times \text{maxadvertisementinterval}$$

You cannot set the minimum advertisement interval above the maximum interval. If you are raising the minimum interval to a value above the current maximum interval, you must change the maximum value first.

The no form of this command sets the minadvertinterval back to the default of 450 seconds.

Syntax `ip irdp minadvertinterval <3-1800>`

`no ip irdp minadvertinterval`

Parameter	Description
<3-1800>	The minimum time between advertisements in seconds. Default: 450

Mode Interface Configuration for a VLAN interface

Default The IRDP minimum advertisement interval is set to 450 seconds (7.5 minutes) by default.

Examples To set the minimum interval between advertisements on `vlan4` to 900 seconds, use the commands:

```
awplus# configure terminal
awplus(config)# interface vlan4
awplus(config-if)# ip irdp minadvertinterval 900
```

To set the minimum interval between advertisements on `vlan4` back to the default of 450 seconds, use the commands:

```
awplus# configure terminal
awplus(config)# interface vlan4
awplus(config-if)# no ip irdp minadvertinterval
```

Related Commands

- `ip irdp`
- `ip irdp lifetime`
- `ip irdp maxadvertinterval`
- `show ip irdp interface`

ip irdp multicast

This command configures multicast Router Discovery advertisements on an interface. The interface sends IRDP advertisements with the all-system multicast address (224.0.0.1) as the IP destination address.

The no form configures broadcast Router Discovery advertisements on an interface. The interface sends IRDP advertisements with the broadcast address (255.255.255.255) as the IP destination address.

The multicast address is the default IP destination address for Router Discovery advertisements.

Syntax ip irdp multicast
 no ip irdp multicast

Mode Interface Configuration for a VLAN interface.

Examples To enable multicast Router Discovery advertisements on vlan5, use the commands:

```
awplus# configure terminal
awplus(config)# interface vlan5
awplus(config-if)# ip irdp multicast
```

To enable broadcast Router Discovery advertisements on vlan5, use the commands:

```
awplus# configure terminal
awplus(config)# interface vlan5
awplus(config-if)# no ip irdp multicast
```

Related Commands ip irdp
 ip irdp broadcast
 show ip irdp interface

ip irdp preference

When multiple routers connected to a LAN are all sending Router Discovery advertisements, hosts need to be able to choose the best router to use. Therefore the IRDP defines a preference value to place in the Router Discovery advertisements. Hosts choose the router with the highest preference value.

This command sets the preference value to include in Router Discovery advertisements sent for the specified interface.

When this command is used, all IP addresses on the interface are assigned the same preference value, except the addresses that have specific preference value assignment using the command [ip irdp address preference](#).

The no form sets the preference value to the default of 0.

Syntax `ip irdp preference <0-2147483647>`
`no ip irdp preference`

Parameter	Description
<0-2147483647>	The preference value for the interface. A higher number increases the preference level for addresses on the specific interface. Default: 0

Mode Interface Configuration for a VLAN interface.

Examples To set the preference of addresses advertised on `vlan6` to 500, use the commands:

```
awplus# configure terminal
awplus(config)# interface vlan6
awplus(config-if)# ip irdp preference 500
```

To set the preference value for addresses on `vlan6` back to the default of 0, use the commands:

```
awplus# configure terminal
awplus(config)# interface vlan6
awplus(config-if)# no ip irdp preference
```

Related Commands [ip irdp](#)
[ip irdp address preference](#)
[show ip irdp interface](#)

ip local-proxy-arp

This command allows you to stop MAC address resolution between hosts within a private VLAN edge interface. Local Proxy ARP works by intercepting ARP requests between hosts within a subnet and responding with your device's own MAC address details instead of the destination host's details. This stops hosts from learning the MAC address of other hosts within its subnet through ARP requests.

Local Proxy ARP ensures that devices within a subnet cannot send traffic that bypasses layer 3 routing on your device. This lets you monitor and filter traffic between hosts in the same subnet, and enables you to have control over which hosts may communicate with one another.

When Local Proxy ARP is operating on an interface, your device does not generate or forward any ICMP-Redirect messages on that interface. This command does not enable proxy ARP on the interface; see the [ip proxy-arp](#) command for more information on enabling proxy ARP.

The `no` form disables Local Proxy ARP to stop your device from intercepting and responding to ARP requests between hosts within a subnet. This allows the hosts to use MAC address resolution to communicate directly with one another. Local Proxy ARP is disabled by default.

Syntax `ip local-proxy-arp`
 `no ip local-proxy-arp`

Mode Interface Configuration for a VLAN interface.

Default Local proxy ARP is disabled by default

Examples To enable your device to apply Local Proxy ARP on the interface `vlan7`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface vlan7
awplus(config-if)# ip local-proxy-arp
```

To disable your device to apply Local Proxy ARP on the interface `vlan7`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface vlan7
awplus(config-if)# no ip local-proxy-arp
```

Related Commands [ip proxy-arp](#)
 [show arp](#)
 [show running-config](#)

ip name-server

This command adds the IP address of a DNS server to the device's list of servers. The DNS client on your device sends DNS queries to devices on this list when trying to resolve a DNS hostname. Your device cannot resolve a hostname until you have added at least one server to this list. There is no limit on the number of servers you can add to the list.

When your device is using its DHCP client for an interface, it can receive Option 6 from the DHCP server. This option appends the name server list with more DNS servers. See [Chapter 72, Dynamic Host Configuration Protocol \(DHCP\) Introduction](#) for more information about DHCP and DHCP options.

The no form removes the DNS server from the list of servers.

Syntax `ip name-server <ip-addr>`
`no ip name-server <ip-addr>`

Parameter	Description
<code><ip-addr></code>	The IP address to be advertised with the specified preference value.

Mode Global Configuration

Example To allow your device to send DNS queries to a DNS server at 10.10.10.5, use the commands:

```
awplus# configure terminal
awplus(config)# ip name-server 10.10.10.5
```

Related Commands `ip domain-list`
`ip domain-lookup`
`ip domain-name`
`show ip name-server`

ip proxy-arp

This command enables Proxy ARP responses to ARP requests on an interface. When enabled, your device intercepts ARP broadcast packets and substitutes its own physical address for that of the remote host. By responding to the ARP request, your device ensures that subsequent packets from the local host are directed to its physical address, and it can then forward these to the remote host.

Your device responds only when it has a specific route to the address being requested, excluding the interface route that the ARP request arrived from. It ignores all other ARP requests. See the [ip local-proxy-arp](#) command about enabling your device to respond to other ARP messages.

The no form disables Proxy ARP responses on an interface. Proxy ARP is disabled by default.

Syntax `ip proxy-arp`
 `no ip proxy-arp`

Mode Interface mode for a VLAN interface.

Default Proxy ARP is disabled by default.

Examples To enable your device to Proxy ARP on the interface `vlan13`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface vlan13
awplus(config-if)# ip proxy-arp
```

To disable your device to Proxy ARP on the interface `vlan13`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface vlan13
awplus(config-if)# no ip proxy-arp
```

Related Commands [arp](#) (IP address MAC address)
 [ip local-proxy-arp](#)
 [show arp](#)
 [show running-config](#)

optimistic-nd

Use this command to enable the optimistic neighbor discovery feature for both IPv4 and IPv6.

Use the no form of this command to disable the optimistic neighbor discovery feature.

Syntax optimistic-nd
 no optimistic-nd

Mode Interface Configuration for a VLAN interface.

Default The optimistic neighbor discovery feature is enabled by default.

Usage The optimistic neighbor discovery feature allows the switch, after learning an IPv4 or IPv6 neighbor, to refresh the neighbor before the neighbor is deleted from the hardware L3 switching table. The neighbor is put into the 'stale' state in the software switching table if it is not refreshed, then the 'stale' neighbors are deleted from the hardware L3 switching table.

The optimistic neighbor discovery feature enables the switch to sustain L3 traffic switching to a neighbor without interruption. Without the optimistic neighbor discovery feature enabled L3 traffic is interrupted when a neighbor is 'stale' and is then deleted from the L3 switching table.

If a neighbor receiving optimistic neighbor solicitations does not answer optimistic neighbor solicitations with neighbor advertisements, then the neighbor will be put into the 'stale' state, and subsequently deleted from both the software and the hardware L3 switching tables.

Examples To enable the optimistic neighbor discovery feature on `vlan100`, use these commands:

```
awplus# configure terminal
awplus(config)# interface vlan100
awplus(config-if)# optimistic-nd
```

To disable the optimistic neighbor discovery feature on `vlan100`, use these commands:

```
awplus# configure terminal
awplus(config)# interface vlan100
awplus(config-if)# no optimistic-nd
```

**Validation
Commands** show running-config

ping

This command sends a query to another IPv4 host (send Echo Request messages).

Syntax `ping [ip] <host> [broadcast] [df-bit {yes|no}] [interval <0-128>]
[pattern <hex-data-pattern>] [repeat {<1-2147483647>|continuous}]
[size <36-18024>] [source <ip-addr>] [timeout <1-65535>] [tos <0-255>]`

Parameter	Description
<host>	The destination IP address or hostname.
broadcast	Allow pingging of a broadcast address.
df-bit	Enable or disable the do-not-fragment bit in the IP header.
interval <0-128>	Specify the time interval in seconds between sending ping packets. The default is 1.
pattern <hex-data-pattern>	Specify the hex data pattern.
repeat	Specify the number of ping packets to send.
<1-2147483647>	Specify repeat count. The default is 5.
continuous	Continuous ping
size <36-18024>	The number of data bytes to send, excluding the 8 byte ICMP header. The default is 56 (64 ICMP data bytes).
source <ip-addr>	The IP address of a configured IP interface to use as the source in the IP header of the ping packet.
timeout <1-65535>	The time in seconds to wait for echo replies if the ARP entry is present, before reporting that no reply was received. If no ARP entry is present, it does not wait.
tos <0-255>	The value of the type of service in the IP header.

Mode Exec and Privileged Exec

Example

```
awplus# ping 10.10.0.5
```

router ip irdp

This command globally enables ICMP Router Discovery (IRDP) advertisements on your device. However, your device does not send or process IRDP messages until at least one interface is configured to use IP and has had IRDP enabled on the interface with the [ip irdp](#) command.

The no form globally disables IRDP advertisements on the device. All interfaces immediately stop transmitting and processing Router Discovery messages.

Syntax `router ip irdp`
 `no router ip irdp`

Mode Global Configuration

Examples To enable Router Discovery advertisements on your device, use the command:

```
awplus# configure terminal
awplus(config)# router ip irdp
```

To disable Router Discovery advertisements on your device, use the command:

```
awplus# configure terminal
awplus(config)# no router ip irdp
```

Related Commands [ip irdp](#)
 [show ip irdp](#)

show arp

This command displays the dynamic and static ARP entries in the ARP cache. The ARP cache contains mappings of IP addresses to physical addresses for hosts. To have a dynamic entry in the ARP cache, a host must have used the ARP protocol to access another host.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show arp`

Mode Exec and Privileged Exec

Example To display the ARP entries in the ARP cache, use the command:

```
awplus# show arp
```

Output Figure 25-1: Example output from the `show arp` command

IP Address	MAC Address	Interface	Port	Type
192.168.2.4	0013.4078.3b98	vlan3	port1.0.7	dynamic
192.168.15.20	0030.940e.136b	vlan3	port1.0.7	dynamic
192.168.17.1	0017.9ab6.0369	vlan3	port1.0.7	dynamic
192.168.18.10	0003.376b.a6a5	vlan3	port1.0.7	dynamic
192.168.18.12	0000.cd23.55c4	vlan3	port1.0.7	dynamic
192.168.21.1	0003.476b.a8a9	vlan3	port1.0.7	dynamic
192.168.26.1	0030.846e.9bc5	vlan3	port1.0.7	dynamic
192.168.27.10	0000.f742.ad10	vlan3	port1.0.7	dynamic
192.168.27.100	0000.daaf.cd24	vlan3	port1.0.7	dynamic
192.168.1.100	00d0.6b04.2a42	vlan2	port1.0.8	static

Parameters in output of the `show arp` command

Parameter	Meaning
IP Address	IP address of the network device this entry maps to.
MAC Address	Hardware address of the network device.
Interface	Interface over which the network device is accessed.
Port	Physical port that the network device is attached to.
Type	Whether the entry is a static or dynamic entry. Static entries are added using the <code>arp (IP address MAC address)</code> command. Dynamic entries are learned from ARP request/reply message exchanges.

Related Commands `arp (IP address MAC address)`
`clear arp-cache`

show debugging ip packet

Use this command to show the IP interface debugging status. IP interface debugging is set using the debug ip packet interface command.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax show debugging ip packet

Parameter	Description
show	Show running system information
debugging	Debugging functions
ip	Internet Protocol (IP)
packet	Packet

Mode Privileged Exec

Example To display the IP interface debugging status when the terminal monitor off, use the command:

```
awplus# terminal no monitor
awplus# show debug ip packet
```

Output Figure 25-2: Example output from the **show debug ip packet** command with **terminal monitor off**

```
IP debugging status:
interface all tcp (stopped)
interface vlan1 arp verbose (stopped)
```

Example To display the IP interface debugging status when the terminal monitor is on, use the command:

```
awplus# terminal monitor
awplus# show debug ip packet
```

Output Figure 25-3: Example output from the **show debug ip packet** command with **terminal monitor on**

```
IP debugging status:
interface all tcp (running)
interface vlan1 arp verbose (running)
```

Related Commands debug ip packet interface
terminal monitor

show hosts

This command shows the default domain, domain list, and name servers configured on your device.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show hosts`

Mode Exec and Privileged Exec

Example To display the default domain, use the command:

```
awplus# show hosts
```

Output Figure 25-4: Example output from the **show hosts** command

```
Default domain is mycompany.com
Domain list: company.com
Name/address lookup uses domain service
Name servers are 10.10.0.2 10.10.0.88
```

Related Commands [ip domain-list](#)
[ip domain-lookup](#)
[ip domain-name](#)
[ip name-server](#)

show ip domain-list

This command shows the domains configured in the domain list. The DNS client uses the domains in this list to append incomplete hostnames when sending a DNS enquiry to a DNS server.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show ip domain-list`

Mode Exec and Privileged Exec

Example To display the list of domains in the domain list, use the command:

```
awplus# show ip domain-list
```

Output Figure 25-5: Example output from the **show ip domain-list** command

```
alliedtelesis.com
mycompany.com
```

Related Commands [ip domain-list](#)
[ip domain-lookup](#)

show ip domain-name

This command shows the default domain configured on your device. When there are no entries in the DNS list, the DNS client appends this domain to incomplete hostnames when sending a DNS enquiry to a DNS server.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip domain-name`

Mode Exec and Privileged Exec

Example To display the default domain configured on your device, use the command:

```
awplus# show ip domain-name
```

Output Figure 25-6: Example output from the **show ip domain-name** command

```
alliedtelesis.com
```

Related Commands [ip domain-name](#)
[ip domain-lookup](#)

show ip forwarding

Use this command to display the IP forwarding status.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip forwarding`

Mode Exec and Privileged Exec

Example

```
awplus# show ip forwarding
```

Output Figure 25-7: Example output from the **show ip forwarding** command

```
awplus#show ip forwarding
IP forwarding is on
```

show ip interface brief

Use this command to display brief information about interfaces and the IP addresses assigned to them. To display information about a specific interface, specify the interface name with the command.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show ip interface [<interface-list>] [brief]`

Parameter	Description
<code><interface-list></code>	The interfaces to display information about. An interface-list can be: ■ an interface, e.g. vlan2 ■ a continuous range of interfaces separated by a hyphen, e.g. vlan2-8 or vlan2-vlan5 ■ a comma-separated list of interfaces or interface ranges, e.g. vlan2,vlan5,vlan8-10 The specified interfaces must exist.

Mode Exec and Privileged Exec

Examples To show brief information for the assigned IP address for interface port1.0.2 use the command:

```
awplus# show ip interface port1.0.2 brief
```

To show the IP addresses assigned to vlan2 and vlan3, use the command:

```
awplus# show ip interface vlan2-3 brief
```

Interface	IP-Address	Status	Protocol
vlan2	unassigned	admin up	down
vlan3	192.168.6.6	admin up	down

Output Figure 25-8: Example output from the **show ip interface brief** command

Interface	IP-Address	Status	Protocol
port1.0.2	unassigned	admin up	down
vlan1	192.168.1.1	admin up	running
vlan2	192.168.2.1	admin up	running
vlan3	192.168.3.1	admin up	running
vlan8	unassigned	admin up	down.

show ip irdp

This command displays whether IRDP is globally enabled on your device, and the status of the debugging modes.

- If the `debug ip irdp` command has been set with the `detail` parameter then the `both` parameter is also set and the output will show "packet debugging mode is all".

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show ip irdp`

Mode Exec and Privileged Exec

Example To display global IRDP configuration, use the command:

```
awplus# show ip irdp
```

Output Figure 25-9: Example output from the `show ip irdp` command

```
IRDP is enabled
  event debugging is disabled
  nsm debugging is disabled
  packet debugging mode is disabled
```

Figure 25-10: Example output from the `show ip irdp` command with `debug ip irdp detail` set

```
IRDP is enabled
  event debugging is disabled
  nsm debugging is disabled
  packet debugging mode is all
```

Figure 25-11: Example output from the `show ip irdp` command with `debug ip irdp both` set

```
IRDP is enabled
  event debugging is disabled
  nsm debugging is disabled
  packet debugging mode is both
```

Related Commands `debug ip irdp`
`router ip irdp`

show ip irdp interface

This command displays the configuration of IRDP on all interfaces, or for a specified interface.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show ip irdp interface [<interface-name>]`

Parameter	Description
<interface-name>	Displays the interface status and configuration details of the specified interface.

Mode Exec and Privileged Exec

Example To display the IRDP configuration for `vlan4`, use the command:

```
awplus# show ip irdp interface vlan4
```

Output Figure 25-12: Example output from the **show ip irdp interface** command

```
vlan13 is up, line protocol is up
ICMP Router Discovery Protocol
  Sending mode          multicast
  Router Lifetime       1350 seconds
  Default Preference    0
  Min Adv Interval      450 seconds
  Max Adv Interval      600 seconds
  Next advertisement in 551 seconds
  Non default prefix preferences
    192.168.1.1         preference    25000

  In packets           0              Out packets           3
  In bad packets        0              Out bad packets        0
  In good packets       0              Out good packets       3
  In ignored packets    0
```

Parameters in output of the show ip irdp interface command

Parameter	Meaning
Sending mode	Whether this interface is sending broadcast or multicast router advertisements. This means the destination IP address of router advertisements will be either the multicast address 224.0.0.1, or the broadcast address 255.255.255.255.
Router Lifetime	The lifetime value set for router advertisements sent from this interface. This is the maximum time that other devices should treat the advertised address as valid.
Default Preference	The preference value for IP addresses as default router addresses, relative to other router addresses on the same subnet. This preference value is used for all IP addresses on this interface, except for those listed under the heading "non default prefix preferences".
Min Adv Interval	Minimum time allowed between sending router advertisements from this interface.
Max Adv Interval	Maximum time allowed between sending router advertisements from this interface.
Non default prefix preferences	List of the IP addresses on this interface that have been set with a specific router preference value. These addresses use the preference value listed beside them, rather than the interface's default preference value.
In packets	The total number of packets received by IRDP on this interface. IRDP processes all ICMP packets received on this interface.
Out packets	The number of packets sent by IRDP on this interface.
In bad packets	The number of packets received by IRDP that it has discarded because they do not conform or corrupted.
Out bad packets	The number of packets that IRDP generated but failed to send to the network layer.
In good packets	The number of packets received and processed by IRDP.
Out good packets	The number of packets generated and successfully sent by IRDP.
In ignored packets	The number of incoming packets ignored, like ICMP packets other than IRDP.

Related Commands [ip irdp](#)
[show ip irdp](#)

show ip name-server

This command displays the list of DNS servers your device sends DNS requests to. This is a static list configured using the [ip name-server](#) command.

For information on output options, see [“Controlling “show” command output” on page 1.33](#).

Syntax `show ip name-server`

Mode Exec and Privileged Exec

Example To display the list of DNS servers that your device sends DNS requests to, use the command:

```
awplus# show ip name-server
```

Output Figure 25-13: Example output from the **show ip name-server** command

```
Nameservers:
 10.10.0.123
 10.10.0.124
```

Related Commands [ip domain-lookup](#)
[ip name-server](#)

tcpdump

Use this command to start a tcpdump, which gives the same output as the Unix-like tcpdump command to display TCP/IP traffic. Press <ctrl> + c to stop a running tcpdump.

Syntax tcpdump <line>

Parameter	Description
<line>	Specify the dump options. For more information on the options for this placeholder see URL www.tcpdump.org/tcpdump_man.html

Mode Privileged Exec

Example To start a tcpdump running to capture IP packets, enter the command:

```
awplus# tcpdump ip
```

```
03:40:33.221337 IP 192.168.1.1 > 224.0.0.13: PIMv2, Hello, length: 34
1 packets captured
2 packets received by filter
0 packets dropped by kernel
```

Related Commands [debug ip packet interface](#)

traceroute

Use this command to trace the route to the specified IPv4 host.

Syntax traceroute {<ip-addr>|<hostname>}

Parameter	Description
<ip-addr>	The destination IPv4 address. The IPv4 address uses the format A.B.C.D.
<hostname>	The destination hostname.

Mode Exec and Privileged Exec

Example

```
awplus# traceroute 10.10.0.5
```


Chapter 26: IPv6 Introduction



Introduction.....	26.2
Overview	26.2
IPv6 Addresses and Prefixes.....	26.3
Address types.....	26.3
IPv6 Headers.....	26.4
The Internet Control Message Protocol (ICMPv6)	26.7
IPv6 Routing.....	26.9
Integration of IPv4 and IPv6	26.10
IPv6 on your Switch	26.10
Enabling IPv6	26.10
The 6bone Network	26.10

Introduction

This chapter describes the main features of IPv6, the switch's implementation of IPv6 and how to configure and operate IPv6 on the switch.

This chapter describes the following IPv6 features:

- linking together networks that run IPv6.
- allowing address autoconfiguration of hosts connected to the switch.

Overview

IPv6 is the next generation of the Internet Protocol (IP). It has primarily been developed to solve the problem of the eventual exhaustion of the IPv4 address space, but also offers other enhancements. IPv6 addresses are 16 bytes long, in contrast to IPv4's 4 byte addresses. Other features of IPv6 include:

- Address structure improvements:
 - « globally unique addresses with more levels of addressing hierarchy to reduce the size of routing tables
 - « autoconfiguration of addresses by hosts
 - « improved scalability of multicast routing by adding a "scope" field to multicast addresses
 - « a new type of address, the "anycast address", which sends packets to any one of a group of devices
- Removes the need for packet fragmentation en-route, by dynamic determination of the largest packet size that is supported by every link in the path. A link's MTU (Maximum Transmission Unit) must be at least 1280 bytes, compared with 576 bytes for IPv4.
- Includes a Traffic Class that allow packets to be labelled with an appropriate priority. If the network becomes congested, the lowest priority packets are dropped.
- Includes Flow labels that indicate to intermediate switches and routers that packets are part of a flow, and that a particular flow requires a particular type of service. This feature enables, for example, real-time processing of data streams. It also increases routing speed because the forwarding router need only check the flow label, not the rest of the header. The handling indicated by the flow label can be done by the IPv6 Hop-by-Hop header, or by a separate protocol such as RSVP.
- Mandatory authentication and data integrity protocols through IPsec. IPsec is optional in IPv4.

IPv6 Addresses and Prefixes

IPv6 addresses are hexadecimal, and are made up of eight pairs of octets separated by colons. An example of a valid address is fe80:0000:0000:0000:0260:0000:97ff:64aa. In the interests of brevity, addresses can be abbreviated in two ways:

- Leading zeros can be omitted, so this address can be written as fe80:0:0:0:260:0:97ff:64aa.
- Consecutive zeros can be replaced with a double colon, so this address can be written as fe80::260:0:97ff:64aa. Note that a double colon can replace any number of consecutive zeros, but an address can contain only one double colon.

Like IPv4 addresses, a proportion of the leftmost bits of the IPv6 address can be used to indicate the subnet, rather than a single node. This part of the address is called the *prefix*. Prefixes provide the equivalent functionality to a subnet mask in IPv4, allowing a subnet to be addressed, rather than a single node. If a prefix is specified, the IPv6 address is followed by a slash and the number of bits that represent the prefix. For example, 3ffe::/16 indicates that the first 16 bits (3ffe) of the address 3ffe:0:0:0:0:0:0:0 represent the prefix.

Like IPv4 addresses, IPv6 addresses are attached to interfaces.

Address types

IPv6 supports the following address types:

- Unicast
- Multicast
- Anycast

Unicast addresses

A unicast address is attached to a single interface and delivers packets only to that interface.

The following special addresses have been defined:

- IPv4-compatible and IPv4-mapped addresses. IPv4-compatible addresses are used to tunnel IPv6 packets across an IPv4 network. IPv4-mapped addresses are used by an IPv6 host to communicate with an IPv4 host. The IPv6 host addresses the packet to the mapped address.
- Link-local addresses, which can be used on the local network that the interface is attached to. The link-local prefix is fe80::/10. Different interfaces on a device may have the same link-local address.
- Site-local addresses, which are used in internal or private networks. These addresses are analogous to the IPv4 private addresses 10.x.x.x and 192.168.x.x.
- The Loopback address, consisting of ::1, which is the equivalent of the IPv4 loopback address, and allows a host to send packets to itself.
- The Unspecified address, consisting of ::, which is the equivalent of the IPv4 unspecified address, and is used as a source address by hosts during the autoconfiguration process.

Multicast addresses

IPv6 multicast addresses provide the equivalent functionality to broadcast addresses in IPv4. Broadcast addresses are not supported in IPv6. A multicast address identifies a group of interfaces, and packets are sent to all interfaces in that group.

Among the special addresses that have been defined are addresses that allow multicasting to:

- All interfaces on a particular host (FF01::1)
- All nodes on a local network (FF01::2)
- All routers on the local link (FF02::2)
- All routers on the local site (FF05::2).

Anycast addresses

An *anycast* address is a unicast address that is attached to more than one interface. If a packet is sent to an anycast address it is delivered to the nearest interface with that address, with the definition of “nearest” depending on the protocol used for routing. If the protocol is RIPv6, the nearest interface is the one that is the shortest number of hops away.

Anycast addresses can be assigned to routers only, and packets cannot originate from an anycast address. A router must be configured to know that it is using an anycast address because the address format cannot be distinguished from that of a unicast address.

Only one anycast address has been predefined: the subnet-router address. The subnet-router address sends messages to the nearest router on a subnet and consists of the subnet's prefix followed by zeros.

IPv6 Headers

The basic unit of data sent through an internet is called a *packet* in IPv6. A packet consists of a *header* followed by the *data*. The following figure shows the IPv6 packet.

Figure 26-1: IPv6 packet




Table 26-1: IPv6 packet - Field Description

Field	Function
Ver	Version of the IP protocol that created the packet. For IPv6, this field has a value of 6.
Differentiated Services	8-bit value that contains the 6-bit DSCP and is used to prioritize traffic as part of a Quality of Service system. For more information, see “Differentiated Services Architecture” on page 52.4 . Additional information can be found in RFC 2474, <i>Definition of the Differentiated Services Field (DS Field) in the IPv4 and IPv6 Headers</i> .
Flow Label	20-bit value that indicates the data flow to which this packet belongs. This flow may be handled in a particular way.
Payload Length	Length of the user data portion of the packet. If the data payload is larger than 64 kB, the length is given in the optional “Jumbo Payload” header and the Payload Length header is given a value of zero.
Next Header	Number that indicates the type of header that immediately follows the basic IP header. This header type may be an optional IPv6 extension header, a relevant IPv4 option header, or another protocol, such as TCP or ICMPv6. The IPv6 extension header values are: 0 (Hop-by-Hop Options Header) 43 (IPv6 Routing Header) 44 (IPv6 Fragment Header) 50 (Encapsulating Security Payload) 51 (IPv6 Authentication Header) 59 (No Next Header) 60 (Destination Options Header)
Hop Limit	Field that is the equivalent of the IPv4 Time To Live field, measured in hops.
Source IP address	128-bit IPv6 address of the sender.
Destination IP address	128-bit IPv6 address of the recipient.
Optional extension headers	Headers for less-frequently used information.
User data	Payload.

Basic IPv6 header structure

The headers contain information necessary to move the packet across the internet. They must be able to cope with missing and duplicated packets as well as possible fragmentation (and reassembly) of the original packet.

IPv6 headers are twice as long as IPv4 headers (40 bytes instead of 20 bytes) and contain four times the address space size (128 bits instead of 32 bits).

They no longer contains the header length, identification, flags, fragment offset, and header checksum fields. Some of these options are placed in extension headers. The Time To Live field is replaced with a hop limit, and the IPv4 Type of Service field is replaced with a Differentiated Services field. The Differentiated Services field contains the DSCP bits, used in a Quality of Service (QoS) regime. The following table explains IPv4 header fields that changed in IPv6.

Changed Field	Description
Type of Service	The type of service that a connection should receive is indicated in IPv6 by the Flow Label field in the IPv6 header.
Fragmentation information (the Identification field, the Flags field and the Fragment Offset field)	In most cases fragmentation does not occur in IPv6. If it does, packets are fragmented at their source and not en route. Therefore, the fragmentation information is contained in an extension header to reduce the size of the basic IPv6 header.
Header Checksum	This option has not been provided in IPv6. This is because transport protocols implement checksums and because of the availability of the IPsec authentication header (AH) in IPv6.
Options	Extension headers handle all the optional values associated with IPv6 packets. The biggest advantage of this scheme is that the size of the basic IP header is a constant.

Extension headers

IPv6 implements many of the less commonly used fields in the IPv4 header (or their equivalents) as extension headers, which are placed after the basic IPv6 header. The length of each header must be a multiple of 8 bytes.

The first extension header is identified by the Next Header field in the basic IPv6 header. Any subsequent extension headers are identified by an 8-bit "Next Header" value at the beginning of the preceding extension header.

IPv6 nodes that originate packets are required to place extension headers in a specific order:

1. The basic IPv6 header. This must come immediately before the extension headers.
2. The Hop-by-Hop header. This specifies options that must be examined by every node in the routing path.
3. A Destination Options header. This is used to specify options to be processed by the first destination or final destination. The destination options header is the only extension header that may be present more than once in the IPv6 packet.
4. The Routing header. This enables a static path to be specified for the packet, if the dynamically-determined path is undesirable.
5. The Fragment header. This indicates that the source node has fragmented the packet, and contains information about the fragmentation.
6. The Authentication header (AH). This verifies the integrity of the packet and its headers.

7. The Encapsulating Security Payload (ESP) header. This encrypts a packet and verifies the integrity of its contents.
8. The Upper Layer Protocol header. This indicates which protocol a higher layer (such as the transport layer) is to process the packet with (for example, TCP).

The Internet Control Message Protocol (ICMPv6)

The Internet Control Message Protocol, ICMPv6, provides a mechanism for error reporting and route discovery and diagnostics. It also conveys information about multicast group membership, a function that is carried out by the Internet Group Management Protocol (IGMP) in IPv4, and performs address resolution, which the Address Resolution Protocol (ARP) performs in IPv4.

Significant aspects of ICMPv6 include neighbor discovery, which enables one device in a network to find out about other nearby devices; and stateless address autoconfiguration, which allows a device to dynamically determine its own IPv6 address.

ICMPv6 is also used to support the Ping v6 (*Packet Internet Groper*) and Trace route v6 functions that are used to verify the connections between networks and network devices. Ping is used to test the connectivity between two network devices to determine whether each network device can “see” the other device. Trace route is used to discover the route used to pass packets between two systems running the IP protocol.

Both of these functions operate almost identically in IPv4 and IPv6. For more information, see [“Ping” on page 24.13](#).

Neighbor discovery

Neighbor discovery is an ICMPv6 function that enables a router or a host to identify other devices on its links. This information is then used in address autoconfiguration, to redirect a node to use a more appropriate router if necessary, and to maintain reachability information with its neighbors.

The IPv6 Neighbor Discovery protocol is similar to a combination of the IPv4 protocols ARP, ICMP Router Discovery and ICMP Redirect.

The following table describes packet types involved with neighbor discovery.

Packet Type	Description
router solicitation	Packet in which a host sends out a request for routers to generate advertisements.
router advertisement	Allows routers to advertise their presence and other network parameters. A router sends an advertisement packet in response to a solicitation packet from a host.
neighbor solicitation	Packet in which a node sends a packet to determine the link layer address of a neighbor or to verify that a neighbor is still active.
neighbor advertisement	A response to a neighbor solicitation packet. These packets are also used to notify neighbors of link layer address changes.
redirect	Informs hosts of a better first hop.

To comply with Section 6.2.1 of RFC 2461, *IPv6 Neighbor Discovery*, the router does not generate router advertisements by default. See [“Neighbor discovery” on page 26.7](#) for instructions about enabling advertisements.

The following table explains packet types and services.

Packet Type	Description
address resolution	A method for carrying out address autoconfiguration, and is achieved using the Neighbor Solicitation Message and the Neighbor Advertisement Message.
router and prefix discovery	On connection to a link, a node needs to know the address of a router that the node can use to reach the rest of the world. The node also needs to know the prefix (or prefixes) that define the range of IP addresses on its link that it can reach without going through a router. Routers use ICMP to convey this information to hosts, by means of router advertisements. The message may have an option attached (the <i>source link address</i> option), which enables the receiving node to respond directly to the router, without performing a neighbor solicitation.
immediate information	The configuration of a router includes a defined frequency at which unsolicited advertisements are sent. If a node wants to obtain information about the nearest router immediately, rather than waiting for the next unsolicited advertisement, the node can send a router solicitation message. Each router that receives the solicitation message sends a router advertisement specifically to the node that sent the solicitation.
redirection	If a node is aware of more than one router that it can use to connect to wider networks, the router to which it sends packets by default does not always represent the most desirable route. ICMPv6 uses the redirect packet to communicate a more effective path to the node.
Neighbor Unreachability Detection (NUD)	A node may issue solicitation requests to determine whether a path is still viable, or may listen in on acknowledgement packets of higher-layer protocols, such as TCP. If the node determines that a path is no longer viable, it attempts to establish a new link to the neighbor, or to re-establish the previous link. NUD can be used between any two devices in the network, independent of whether the devices are acting as hosts or routers.

Stateless address autoconfiguration

Stateless address autoconfiguration allows an IPv6-aware device to be plugged into a network without manual configuration with an IP address. This plug and play functionality results in networks that are easier to set up and modify, and simplifies the process of shifting to use a new Internet Service Provider (ISP).

Stateless address autoconfiguration is achieved in a series of steps. Routers and hosts perform the first three steps, which autoconfigure a link-local address. A global address is autoconfigured in the last three steps, which only hosts perform.

On the router or host

1. During system start-up, the node begins autoconfiguration by generating a link-local address for the interface. A link-local address is formed by adding the interface ID to the link-local prefix `fe80::10` (reference RFC 3513).
2. The node then transmits a neighbor solicitation message to this address. If the address is already in use, the node that the address belongs to replies with a neighbor advertisement message. The autoconfiguration process stops and manual configuration of the node is then required.

3. If no neighbor advertisement is received, the node concludes that the address is available and assigns it to the chosen interface.

On the host

1. The node then sends one or more router solicitations to detect if any routers are present. Any routers present responds with a router advertisement.

If no router advertisement is received, the node tries to use DHCP to obtain an address and other configuration information. If no DHCP server responds, the node continues using the link-level address

If no router advertisement is received, the node tries to use DHCP to obtain an address and other configuration information. If no DHCP server responds, the node continues using the link-level address.

If a router advertisement is received, this message informs the node how to proceed with the auto configuration process.

The prefix from the router advertisement, if received, is added to the link-level address to form the global unicast IP address.

2. This address is then assigned to the network interface.

If routers are present, the node continues to receive router advertisements. The node updates its configuration when there are changes in the router advertisements.

IPv6 Routing

Routing in IPv6 is almost identical to IPv4 routing under CIDR, except that the addresses are 128-bit IPv6 addresses instead of 32-bit IPv4 addresses.

Routing Information Protocol (RIPv6)

RIP is a simple distance vector protocol that defines networks based on how many hops they are from the router. When a network is more than 15 hops away (one hop is one link), it is not included in the routing table.

RIPv6, also referred to as RIPv6 (for “next generation”) is similar to RIPv2. Extensions to RIPv2 to support IPv6 are:

- the address field of a routing entry is expanded to 128 bits to allow IPv6 prefixes
- the 32-bit RIPv2 subnet mask field is replaced by an 8-bit prefix length field
- authentication is removed in RIPv6
- the size of a routing packet is no longer arbitrarily limited
- RIPv6 specifies the next hop instead of simply allowing the recipient of the update to set the next hop to the sender of the update.

In RIPv6, each router uses a routing table to keep track of every destination that is reachable throughout the system. Each entry in the routing table contains:

- the IPv6 prefix of the destination
- a metric, which represents the total cost of getting a packet from the router to that destination
- the IPv6 address of the next router along the path to the destination
- a flag to indicate that information about the route has changed recently
- various timers associated with the route.

Integration of IPv4 and IPv6

IPv6 has been designed in such a way that a smooth transition from IPv4 is possible. The most effective way to ensure this is to use a *dual IP stack*. A node configured as a dual stack system has both a 128-bit IPv6 address and a 32-bit IPv4 address, and so can communicate with nodes running IPv4 and those running IPv6.

Another aspect of the transition is to *tunnel* IPv6 packets through an IPv4 network. IPv6 packets are tunnelled simply by encapsulating the IPv6 packet within an IPv4 datagram, and identifying that this datagram is an encapsulated IPv6 packet by giving the datagram a protocol value of 41.

IPv6 on your Switch

This section describes the switch's support for IPv6, and how to configure IPv6 on the switch. Fundamental IPv6 features on the switch are:

Enabling IPv6

The switch's implementation of IPv6 is disabled by default. To enable IPv6 forwarding, use the [ipv6 forwarding command on page 27.4](#).

To display information about IPv6 settings, use the [show ipv6 interface brief command on page 27.16](#).

Because the switch implements IPv6 as a dual stack, implementing IPv6 does not affect IPv4 functionality.

The 6bone Network

The 6bone is an experimental virtual network of nodes that support IPv6 packets, tunnelled together through the existing IPv4 Internet. Most of the nodes are workstations or similar machines, with IPv6-capable operating systems. The theory of tunnelling IPv6 packets over an IPv4 network is outlined in "[Integration of IPv4 and IPv6](#)" on [page 26.10](#).

The 6bone is part of the transition to IPv6. Its purpose is to provide an environment in which IPv6 can be tested and procedures for IPv6 can be developed. When IPv6 is sufficiently developed and being used widely, the 6bone will probably disappear.

Chapter 27: IPv6 Commands



Command List	27.2
clear ipv6 neighbors	27.3
ipv6 address	27.3
ipv6 forwarding	27.4
ipv6 nd managed-config-flag	27.5
ipv6 nd other-config-flag	27.6
ipv6 nd prefix	27.7
ipv6 nd ra-interval	27.8
ipv6 nd ra-lifetime	27.9
ipv6 nd reachable-time	27.10
ipv6 nd suppress-ra	27.11
ipv6 neighbor	27.12
ipv6 route	27.13
ping ipv6	27.14
show ipv6 forwarding	27.15
show ipv6 interface brief	27.16
show ipv6 neighbors	27.17
show ipv6 route	27.17
show ipv6 route summary	27.18
traceroute ipv6	27.19

Command List

This chapter provides an alphabetical reference of commands used to configure IPv6. For more information, see [Chapter 26, IPv6 Introduction](#).

clear ipv6 neighbors

Use this command to clear all dynamic IPv6 neighbor entries.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax `clear ipv6 neighbors`

Mode Privileged Exec mode

Examples

```
awplus# clear ipv6 neighbors
```

ipv6 address

Use this command to set the IPv6 address of a VLAN interface.

Use the no form of this command to remove the address assignment.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax `ipv6 address <ipv6-addr/prefix-length>`
`no ipv6 address <ipv6-addr/prefix-length>`

Parameter	Description
<code>ipv6 address</code>	Specifies the IPv6 address using the format shown below.
<code><ipv6-addr/prefix-length></code>	Specifies the IPv6 address to be set. The IPv6 address uses the format X:X::X:X/Prefix-Length. The prefix-length is usually set between 0 and 64, or has the value 128.

Mode Interface mode for a VLAN interface.

Examples To assign the IPv6 address to the interface `vlan2`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ipv6 address 2001:0DB8::a2/64
```

Validation Commands `show running-config`
`show ipv6 interface brief`
`show ipv6 route`

ipv6 forwarding

Use this command to turn on IPv6 forwarding.

Syntax `ipv6 forwarding`

Mode Global Configuration mode

Usage Note that there is no accompanying “no ipv6 forwarding” command. The default mode is ipv6 forwarding - OFF. However, if ipv6 forwarding has been turned on, you can use the following procedure to turn it off:

- Run the `show boot` command to display the current config file.
- Delete the line that contains the text, “ipv6 forwarding.”
- Reboot the switch.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Examples

```
awplus# configure terminal
awplus(config)# ipv6 forwarding
```

ipv6 nd managed-config-flag

Use this command to set the managed address configuration flag, contained within the router advertisement field.

Setting this flag indicates the operation of a stateful autoconfiguration protocol such as DHCPv6 for address autoconfiguration, and that address information (i.e. the network prefix) and other (non-address) information can be requested from the switch.

An unset flag enables hosts receiving the advertisements to use a stateless autoconfiguration mechanism to establish their IPv6 addresses. The default is flag unset.

Use the `no` parameter to reset this command to its default of, *flag unset*.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax `ipv6 nd managed-config-flag`
 `no ipv6 nd managed-config-flag`

Default Unset

Mode Interface mode for a VLAN interface.

Usage Advertisement flags will not be transmitted unless you have applied the [no ipv6 nd suppress-ra command on page 27.11](#). This step is included in the example below.

Example To set the managed address configuration flag on `vlan2`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ipv6 nd managed-config-flag
awplus(config-if)# no ipv6 nd suppress-ra
```

Related Commands [ipv6 nd suppress-ra](#)
 [ipv6 nd prefix](#)
 [ipv6 nd other-config-flag](#)

ipv6 nd other-config-flag

Use this command to set the other stateful configuration flag (contained within the router advertisement field) to be used for IPv6 address auto-configuration. This flag is used to request the router to provide information in addition to providing addresses.

Note: Setting the `ipv6 nd managed-config-flag` command on page 27.5 implies that the `ipv6 nd other-config-flag` will also be set.

Use no parameter with this command to reset the value to default.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax `ipv6 nd other-config-flag`
 `no ipv6 nd other-config-flag`

Default Unset

Mode Interface mode for a VLAN interface.

Usage Advertisement flags will not be transmitted unless you have applied the `no ipv6 nd suppress-ra` command on page 27.11. This step is included in the example below.

Example To set the `ipv6 other-config-flag` on `vlan4`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface vlan4
awplus(config-if)# ipv6 nd other-config-flag
awplus(config-if)# no ipv6 nd suppress-ra
```

Related Commands `ipv6 nd suppress-ra`
 `ipv6 nd prefix`
 `ipv6 nd managed-config-flag`

ipv6 nd prefix

Use this command to specify the IPv6 prefix information that is advertised by the router advertisement for IPv6 address auto-configuration.

Use no parameter with this command to reset the IPv6 prefix.

Note: *This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.*

Syntax `ipv6 nd prefix <ipv6-prefix/length> <valid-lifetime>
<preferred-lifetime> [off-link] [no-autoconfig]`
`no ipv6 nd prefix <ipv6-addr/prefix-length> <valid-lifetime>
<preferred-lifetime> [off-link] [no-autoconfig]`

Parameter	Description
<code><ipv6-prefix/length></code>	The prefix to be advertised by the router. The IPv6 address prefix uses the format X:X::/prefix-length. The prefix-length is usually set between 0 and 64, or has the value 128. The default is X:X::/64.
<code><valid-lifetime></code>	The the period during which the specified IPv6 address prefix is valid. This can be set to a value between 0 and 4294967295 seconds. The default is 2592000 (30 days). Note that this period should be set to a value greater than that set for the prefix preferred-lifetime.
<code><preferred-lifetime></code>	Specifies the IPv6 prefix preferred lifetime. This is the period during which the IPv6 address prefix is considered a current (undeprecated) value. After this period, the command is still valid but should not be used in new communications. Set to a value between 0 and 4294967295 seconds. The default is 604800 seconds (7 days). Note that this period should be set to a value less than that set for the prefix valid-lifetime.
<code>off-link</code>	Specify the IPv6 prefix off-link flag. The default is <i>flag set</i> .
<code>no-autoconfig</code>	Specify the IPv6 prefix no autoconfiguration flag. Setting this flag indicates that the prefix is not to be used for autoconfiguration. The default is <i>flag set</i> .

Defaults Valid-lifetime default is 2592000 seconds (30 days). Preferred-lifetime default is 604800 seconds (7 days).

Mode Interface mode for a VLAN interface.

Usage This command specifies the IPv6 prefix flags that are advertised by the router advertisement message.

Example The following example configures the switch to issue router advertisements on `vlan4`, and advertises the address prefix of `2001:0DB8::/64`.

```
awplus# configure terminal
awplus(config)# interface vlan4
awplus(config-if)# ipv6 nd prefix 2001:0db8::/64
```

Related Commands [ipv6 nd suppress-ra](#)

ipv6 nd ra-interval

Use this command to specify the interval between IPv6 Router Advertisements (RA) transmissions.

Use no parameter with this command to reset the value to default.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax `ipv6 nd ra-interval <seconds>`
`no ipv6 nd ra-interval <seconds>`

Parameter	Description
<code><seconds></code>	Specifies the number of seconds between IPv6 router advertisements. Valid values are from 3 to 1800 seconds.

Default 600 seconds.

Mode Interface mode for a VLAN interface.

Usage Advertisement flags will not be transmitted unless you have applied the [no ipv6 nd suppress-ra command on page 27.11](#) as shown in the example below.

Example To set the advertisements interval on `vlan4` to be 60 seconds, use the following commands:

```
awplus# configure terminal
awplus(config)# interface vlan4
awplus(config-if)# ipv6 nd ra-interval 60
awplus(config-if)# no ipv6 nd suppress-ra
```

Related Commands [ipv6 nd suppress-ra](#)
[ipv6 nd prefix](#)

ipv6 nd ra-lifetime

Use this command to specify the time period that this router can usefully act as a default gateway for the network. Each router advertisement resets this time period.

Use no parameter with this command to reset the value to default.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax `ipv6 nd ra-lifetime <seconds>`
`no ipv6 nd ra-lifetime <seconds>`

Parameter	Description
<seconds>	Time period in seconds. Valid values are from 0 to 9000. Note that you should set this time period to a value greater than the value you have set using the ipv6 nd ra-interval command on page 27.8

Default 1800 seconds

Mode Interface mode for a VLAN interface.

Usage This command specifies the lifetime of the current router to be announced in IPv6 Router Advertisements.

Advertisement flags will not be transmitted unless you have applied the [no ipv6 nd suppress-ra command on page 27.11](#). This instruction is included in the example shown below.

Example To set the advertisement lifetime of 8000 seconds on `vlan4`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface vlan4
awplus(config-if)# ipv6 nd ra-lifetime 8000
awplus(config-if)# no ipv6 nd suppress-ra
```

Related Commands [ipv6 nd suppress-ra](#)
[ipv6 nd prefix](#)

ipv6 nd reachable-time

Use this command to specify the reachable time in the router advertisement to be used for detecting reachability of the IPv6 neighbor.

Use the no parameter with this command to reset the value to default.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax `ipv6 nd reachable-time <milliseconds>`
`no ipv6 nd reachable-time <milliseconds>`

Parameter	Description
<milliseconds>	Time period in milliseconds. Valid values are from 0 to 3600000. Setting the value of 0 indicates an unspecified reachable-time.

Default 0 milliseconds

Mode Interface mode for a VLAN interface.

Usage This command specifies the reachable time of the current router to be announced in IPv6 Router Advertisements.

Advertisement flags will not be transmitted unless you have applied the [no ipv6 nd suppress-ra command on page 27.11](#). This instruction is included in the example shown below.

Example To set the reachable-time in router advertisements on `vlan4` to be 1800000 milliseconds.

```
awplus# configure terminal
awplus(config)# interface vlan4
awplus(config-if)# ipv6 nd reachable-time 1800000
awplus(config-if)# no ipv6 nd suppress-ra
```

Related Commands [ipv6 nd suppress-ra](#)
[ipv6 nd prefix](#)

ipv6 nd suppress-ra

Use this command to inhibit IPv6 Router Advertisement (RA) transmission for the current interface. Router advertisements are used when applying IPv6 stateless auto-configuration.

Use no parameter with this command to enable Router Advertisement transmission.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax `ipv6 nd suppress-ra`
 `no ipv6 nd suppress-ra`

Default Router Advertisement (RA) transmission is suppressed by default.

Mode Interface mode for a VLAN interface.

Example To enable the transmission of router advertisements from interface `vlan4` on the switch, use the following commands:

```
awplus# configure terminal
awplus(config)# interface vlan4
awplus(config-if)# no ipv6 nd suppress-ra
```

Related Commands `ipv6 nd ra-interval`
 `ipv6 nd prefix`

ipv6 neighbor

Use this command to add a static IPv6 neighbor entry. Use the no form of this command to remove a specific IPv6 neighbor entry.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax `ipv6 neighbor <ipv6-address> <vlan-ID> <mac-address> <port-list>`
`no ipv6 neighbor <ipv6-address> <vlan-ID> <port-list>`

Parameter	Description
<code><ipv6-address></code>	Neighbor's IPv6 address in format x:X::X:X
<code><vlan-ID></code>	The neighbor VLAN name or VID
<code><mac-address></code>	MAC hardware address in hexadecimal notation with the format HHHH.HHHH.HHHH
<code><port-list></code>	The port number, or range.

Mode Global Configuration mode

Usage Use this command to clear a specific IPv6 neighbor entry. To clear all dynamic address entries, use the [clear ipv6 neighbors command on page 27.3](#).

Example To create a static neighbor entry for IPv6 address 2001:0DB8::a2, on vlan 4, MAC address 0000.cd28.0880, on port1.0.19, use the command:

```
awplus# configure terminal
awplus(config)# ipv6 neighbor 2001:0DB8::a2 vlan4
0000.cd28.0880 port1.0.19
```

Related Commands [clear ipv6 neighbors](#)

ipv6 route

Use this command to establish the distance for static routes of a network prefix. Use the no form of this command to disable the distance for static routes of the network prefix.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax

```
ipv6 route <dest-prefix> <dest-prefix/length>
    {<gateway-ip>|<gateway-name>} [<distvalue>]

no ipv6 route <dest-prefix> <dest-prefix/length>
    {<gateway-ip>|<gateway-name>} [<distvalue>]
```

Parameter	Description
<dest-prefix/length>	Specifies the IP destination prefix. The IPv6 address prefix uses the format X:X::/prefix-length. The prefix-length is usually set between 0 and 64, or has the value 128.
<gateway-ip>	Specifies the IP gateway (or next hop) address. The IPv6 address uses the format X:X::X:X/Prefix-Length. The prefix-length is usually set between 0 and 64, or has the value 128.
<distvalue>	Specifies the administrative distance for the route. Valid values are from 1 to 255.
<gateway-name>	Specifies the name of the gateway (or next hop) interface

Mode Global Configuration mode

Examples

```
awplus# configure terminal
awplus(config)# ipv6 route 3ffe3:506::1 128
awplus(config)# ipv6 route 3ffe:506::1/128 myintname 32
```

Validation Commands

```
show running-config
show ipv6 route
```

ping ipv6

This command sends a query to another IPv6 host (send Echo Request messages).

Syntax `ping ipv6 [<host>|<ipv6-address>] [repeat {<1-2147483647>|continuous}] [size <36-18024>] [source <ip-addr>] [timeout <1-65535>]`

Parameter	Description
<ipv6-addr>	The destination IPv6 address. The IPv6 address uses the format X:X::X:X.
<hostname>	The destination hostname.
repeat	Specify the number of ping packets to send.
<1-2147483647>	Specify repeat count. The default is 5.
size <36-18024>	The number of data bytes to send, excluding the 8 byte ICMP header. The default is 56 (64 ICMP data bytes).
source <ip-addr>	The IP address of a configured IP interface to use as the source in the IP header of the ping packet.
timeout <1-65535>	The time in seconds to wait for echo replies if the ARP entry is present, before reporting that no reply was received. If no ARP entry is present, it does not wait.
repeat	Specify the number of ping packets to send.
<1-2147483647>	Specify repeat count. The default is 5.
continuous	Continuous ping
size <36-18024>	The number of data bytes to send, excluding the 8 byte ICMP header. The default is 56 (64 ICMP data bytes).
timeout <1-65535>	The time in seconds to wait for echo replies if the ARP entry is present, before reporting that no reply was received. If no ARP entry is present, it does not wait.

Mode Exec and Privileged Exec

Example

```
awplus# ping 2001:0DB8::a2
```

show ipv6 forwarding

Use this command to display IPv6 forwarding status.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ipv6 forwarding`

Mode Exec mode and Privileged Exec mode

Examples

```
awplus# show ipv6 forwarding
```

Output The following is a sample output from this command, displaying the IPv6 forwarding status:

```
ipv6 forwarding is on
```

show ipv6 interface brief

Use this command to display brief information about interfaces and the IPv6 address assigned to them. To display information about a specific interface, specify the interface name with the command.

For information on output options, see “Controlling “show” command output” on page 1.33.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax `show ipv6 interface [<interface>] brief`

Parameter	Description
<interface>	The interface to display information about. For instance: ■ vlan2 The specified interface must exist.

Mode Exec mode and Privileged Exec mode

Examples

```
awplus# show ipv6 interface brief
```

```
awplus# show ipv6 interface vlan1 brief
```

Output Sample output from the show ipv6 interface brief command

Interface	IPv6-Address	Status	Protocol
lo	unassigned	admin up	running
vlan1	unassigned	admin up	running
vlan10	2001::a:0:0:c0a8:a0b/64 fe80::200:cdff:fe28:84a/64	admin up	running
vlan20	2001::14:0:0:c0a8:140b/64 fe80::200:cdff:fe28:84a/64	admin up	running
vlan30	2001::1e:0:0:c0a8:1e0b/64 fe80::200:cdff:fe28:84a/64	admin up	running
vlan40	2001::28:0:0:c0a8:280b/64 fe80::200:cdff:fe28:84a/64	admin up	running
vlan201	unassigned	admin up	running
vlan250	2001::fa:0:0:c0a8:fa0b/64 fe80::200:cdff:fe28:84a/64	admin up	running

Related Commands [show interface brief](#)

show ipv6 neighbors

Use this command to display all IPv6 neighbors.

For information on output options, see “Controlling “show” command output” on page 1.33.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax `show ipv6 neighbors`

Mode Exec mode and Privileged Exec mode

show ipv6 route

Use this command to display the IPv6 routing table for a protocol or from a particular table.

For information on output options, see “Controlling “show” command output” on page 1.33.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax `show ipv6 route [bgp|connected|database|ospf|rip|static|<ipv6-address>|<ipv6-addr/prefix-length>]`

Parameter	Description
bgp	Displays only the routes learned from Border Gateway Protocol (BGP).
connected	Displays only the routes learned from connected interfaces.
database	Displays only the routing information extracted from the database.
ospf	Displays only the routes learned from Open Shortest Path First (OSPF).
rip	Displays only the routes learned from Routing Information Protocol (RIP).
static	Displays only the static routes you have configured.
summary	Displays summary information from the routing table.
<ipv6-address>	Displays the routes for the specified address in the IP routing table. The IPv6 address uses the format X:X::X:X/Prefix-Length. The prefix-length is usually set between 0 and 64, or has the value 128.
<ipv6-prefix/length>	Displays only the routes for the specified IP prefix. The IPv6 address prefix uses the format X:X::X:X/prefix-length. The prefix-length is usually set between 0 and 64, or has the value 128.

Mode Exec mode and Privileged Exec mode

Example

```
awplus# show ipv6 route
```

Output The following is a sample output of this command displaying the IPv6 routing table.

```
IPv6 Routing Table
Codes: C - connected, S - static, R - RIP, O - OSPF, B - BGP
S   ::/0 [1/0] via 2001::a:0:0:c0a8:a6, vlan10
C   2001::a:0:0:0:0/64 via ::, vlan10
C   2001::14:0:0:0:0/64 via ::, vlan20
C   2001::1e:0:0:0:0/64 via ::, vlan30
C   2001::28:0:0:0:0/64 via ::, vlan40
C   2001::fa:0:0:0:0/64 via ::, vlan250
C   fe80::/64 via ::, vlan250
C   fe80::/64 via ::, vlan40
C   fe80::/64 via ::, vlan20
C   fe80::/64 via ::, vlan10
```

show ipv6 route summary

Use this command to display the summary of the current NSM RIB entries.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax show ipv6 route summary

Mode Exec mode and Privileged Exec mode

Examples

```
awplus# show ipv6 route summary
```

Output

```
IPv6 routing table name is Default-IPv6-Routing-Table(0)
IPv6 routing table maximum-paths is 4
RouteSource      Networks
connected        4
ospf              5
Total            9
FIB              5
```

Related Commands [show ip route](#)
[show ip route database](#)

traceroute ipv6

Use this command to trace the route to the specified IPv6 host.

Syntax `traceroute ipv6 {<ipv6-addr>|<hostname>}`

Parameter	Description
<code><ipv6-addr></code>	The destination IPv6 address. The IPv6 address uses the format X:X::X:X.
<code><hostname></code>	The destination hostname.

Mode Exec and Privileged Exec

Example

```
awplus# traceroute 2001:0DB8::a2
```


Chapter 28: IPv6to4 Tunneling Configuration



Introduction.....	28.2
6to4 Automatic Tunnel Configuration.....	28.2
Tunneling Operation	28.2
6to4 tunnels operation and configuration summary.....	28.3
Sample 6to4 configuration.....	28.4

Introduction

This chapter contains a basic IPv6to4 automatic tunneling configuration example for reference.

To see details on the Tunneling commands used in this sample configuration, or to see the outputs of the Validation commands, refer to [Chapter 29, IPv6to4 Tunneling Commands](#). Links to the Tunneling commands used in the examples are also provided below the examples.

6to4 Automatic Tunnel Configuration

IPv6 transition is required to migrate from IPv4 to IPv6. One method to connect to the global IPv6 network over the existing IPv4 network is called 6to4 automatic tunneling.

Although this method is called '6to4 tunneling', it does not involve discrete point-to-point tunnels. The 'tunneling' in '6to4 tunneling' refers to the fact that the IPv6 packets are encapsulated in IPv4 packets to be 'tunneled' across the IPv4 domain. Hence, '6to4 tunneling' is primarily a scheme for encapsulating IPv6 packets inside IPv4 headers.

Using 6to4 tunneling, you are not required to specify tunnel destination addresses. You only choose the interface that connects the switch to the IPv4 domain, and designate that interface to be the tunnel entry-point. As will be explained below, the IPv4 address that represents the point at which any given IPv6 packet will eventually exit the IPv4 domain is derived from the IPv6 packet itself. Note that the packet's destination IPv6 address itself contains the destination IPv4 address that is used for tunnel encapsulation.

The 6to4 tunneling implementation in AlliedWare Plus™ is used for routing only between IPv6 addresses that are of the form:

```
2002: <valid-IPv4-unicast-address> : XX:XX:XX:XX:XX
```

6to4 tunneling makes use of the fact that for every valid IPv4 unicast address $A.B.C.D$, there is always a corresponding valid IPv6 subnet $2002:<A.B.C.D>::/48$. So, for every global IPv4 address that has been allocated to an organization, there is immediately a global IPv6 subnet $2002:<ipv4-address>::/48$ available to that organization.

Tunneling Operation

When an IPv4 interface on the switch is designated as a tunnel entry point, using the [tunnel source command on page 29.5](#) command, an IPv6 tunnel interface is created. The interface is automatically allocated the IPv6 address: $2002:<ipv4-address>::1/128$.

Note: Other implementations of 6to4 tunneling might have a different scheme for deriving the IPv6 address of the tunnel interface, as there is no standardized scheme. This does not cause any interoperability problems, however, as the IPv6 address of the tunnel interface is not actually involved in the routing process.

This tunnel interface is the gateway used by the IPv6 packets to enter the IPv4 domain. As IPv6 packets enter the IPv4 domain, the switch must encapsulate them by pre-pending IPv6 packets with an IPv4 header. The source address of the encapsulating header is the IPv4 address that has been specified by the tunnel source command. The process for determining the destination IP address is explained in more detail below and on the following page.

The key to routing across the IPv4 domain is that there is a connection between the IPv4 address of a tunnel endpoint and the IPv6 subnets which can be reached via that endpoint. The connection is that the tunnel interface with IP address $<ipv4-address>$ is considered to be the gateway to **all** IPv6 subnets within the range $2002:<ipv4-address>::/48$.

When a switch is required to deliver packets, via a tunnel interface, to IPv6 addresses in the range `2002:<ipv4-address>::/48`, the switch knows that the IPv4 address to which the switch must deliver that packet is given by the 17th through 48th bits of the IPv6 destination address. So, the encapsulation process extracts those bits from the IPv6 destination address, and uses them as the IPv4 destination address in the encapsulating header.

For example, if `212.149.1.1` is the IPv4 address of a tunnel endpoint, then the IPv6 subnets in the range `2002:d495:101::/48` are automatically known to be reachable via that tunnel endpoint. If another tunnel endpoint has an IPv6 packet to deliver to `2002:d495:101:6::04:8d`, via the tunnel, then that switch will encapsulate the packet in an IPv4 header with a destination address of `212.149.1.1`.

The corollary to this is the requirement that, to be reachable from other 6to4 networks, the IPv6 VLAN interfaces on the IPv6 side a tunneling switch will need to be configured with IPv6 addresses that are subnetted from the `2002:<ipv4-address>::/48` address.

For example, `2002:<ipv4-address>:1::/64`, `2002:<ipv4-address>:2::/64`, `2002:<ipv4-address>:3::/64`, etc.

Note: `2002:<ipv4-address>::/64` cannot be used here, because it conflicts with the automatically configured tunnel address.

6to4 tunnels operation and configuration summary

1. When an IPv4 address is designated as the source address of a tunnel, that tunnel interface is automatically given the IPv6 address `2002:<ipv4-address>::1/128`.
2. The switch does not automatically create any IPv6 routes via that tunnel interface, so you do need to explicitly create a route to direct traffic over the tunnel interface. Typically, you will create a route to `2002::/16` via the tunnel interface. There might be occasions, though, when you want to just create some more restricted routes, within the `2002::/16` range, over the tunnel interface.
3. Once routes have been created that direct traffic over the tunnel interface, it is not necessary to specify nexthop addresses for the individual remote IPv6 subnets that are reachable via the tunnel. The switch will automatically know the IPv4 nexthop via which to reach any IPv6 subnet in the range `2002:<ipv4-address>::/48`.
4. The only IPv6 addresses that can be routed to via the 6to4 tunnels on switches running AlliedWare Plus™ are IPv6 addresses of the form:

`2002:<valid-IPv4-unicast-address>:xx:xx:xx:xx:xx`

Sample 6to4 configuration

The following example shows the minimum configuration required for 6to4 automatic tunnel configuration. Follow the commands and descriptions in the tables below the sample network:




Table 28-1: Example configuration for 6to4 automatic tunneling: Switch 1

awplus#	
<code>configure terminal</code>	Enter the Configure mode.
awplus(config)#	
<code>interface vlan2</code>	Specify the interface (vlan2) and enter the Interface mode.
awplusa(config-if)#	
<code>ip address 212.149.1.1/24</code>	Set the IPv4 address for the interface (vlan2).
awplus(config-if)#	
<code>exit</code>	Exit Interface mode and enter Configure mode.
awplus(config)#	
<code>interface vlan1</code>	Specify the interface (vlan1) and enter the Interface mode.
awplus(config-if)#	
<code>ipv6 address 2002:d495:101:1::10/64</code>	Set the IPv6 address for the interface (vlan1).
awplus(config-if)#	
<code>exit</code>	Exit Interface mode and enter Configure mode.
awplus(config)#	
<code>ipv6 forwarding</code>	Enable IPv6 routing.
awplus(config)#	
<code>interface tunnel 100</code>	Create a tunnel interface.
awplus(config-if)#	
<code>tunnel mode ipv6ip 6to4</code>	Set the tunnel mode.

Table 28-1: Example configuration for 6to4 automatic tunneling: Switch 1 (Continued)

<code>awplus(config-if)#</code> <code>tunnel source 212.149.1.1</code>	Define the IPv4 address to be used as the source address for the tunnel interface.
<code>awplus(config-if)##</code> <code>exit</code>	Exit Interface mode and enter Configure mode.
<code>awplus(config)##</code> <code>ipv6 route 2002::/16 tunnel 100</code>	Add a route to send traffic for other 6to4 subnets via the tunnel interface.
<code>awplus(config)##</code> <code>router ospf</code>	Create an OSPF routing instance.
<code>awplus(config-router)##</code> <code>router-id 10.70.0.57</code>	Specify a Router ID for the OSPF routing process.
<code>awplus(config-router)##</code> <code>network 212.149.1.0/24 area 0</code>	Enable OSPF routing with a specified Area ID on interfaces with IP addresses within the specified network address. The Area ID used in this case is 0, which specifies the backbone area.

Table 28-2: Example configuration for 6to4 automatic tunneling: Switch 2

<code>awplusawplus#</code> <code>configure terminal</code>	Enter the Configure mode.
<code>awplus(config)#</code> <code>interface vlan2</code>	Specify the interface (vlan2) and enter the Interface mode.
<code>awplus(config-if)#</code> <code>ip address 212.149.1.2/24</code>	Set the IPv4 address of the interface (vlan2).
<code>awplus(config-if)#</code> <code>exit</code>	Exit Interface mode and enter Configure mode.
<code>awplus(config)#</code> <code>interface vlan3</code>	Specify the interface (vlan3) and enter the Interface mode.
<code>awplus(config-if)#</code> <code>ip address 143.29.136.17/24</code>	Set the IPv4 address of the interface (vlan3).
<code>awplus(config-if)#</code> <code>exit</code>	Exit Interface mode and enter Configure mode.

Table 28-2: Example configuration for 6to4 automatic tunneling: Switch 2 (Continued)

<code>awplus(config)#</code>	
<code>router ospf</code>	Create an OSPF routing instance.
<code>awplus(config-router)#</code>	
<code>router-id 10.70.0.58</code>	Specify a Router ID for the OSPF routing process.
<code>awplus(config-router)#</code>	
<code>network 212.149.1.0/24 area 0</code>	Enable OSPF routing with a specified Area ID on interfaces with IP addresses with a specified network address. The Area ID used in this case is 0, which specifies the backbone area.
<code>awplus(config-router)#</code>	
<code>network 143.29.136.0/24 area 0</code>	Enable OSPF routing with a specified Area ID on interfaces with IP addresses within the specified network address. The Area ID used in this case is 0, which specifies the backbone area.

Table 28-3: Example configuration for 6to4 automatic tunneling: Switch 3

<code>awplus(config)#</code>	
<code>interface vlan3</code>	Specify interface (vlan3) and enter the Interface mode.
<code>awplus(config-if)#</code>	
<code>ip address 143.29.136.18/24</code>	Set the IPv4 address for the interface (vlan3).
<code>awplus(config-if)#</code>	
<code>exit</code>	Exit Interface mode and enter Configure mode.
<code>awplus(config)#</code>	
<code>interface vlan1</code>	Specify the interface (vlan1) and enter the Interface mode.
<code>awplus(config-if)#</code>	
<code>ipv6 address 2002:8f1d:8812:3::10/64</code>	Set the IPv6 address for the interface (vlan1).
<code>awplus(config-if)#</code>	
<code>exit</code>	Exit Interface mode and enter Configure mode.
<code>awplus(config)#</code>	
<code>ipv6 forwarding</code>	Enable IPv6 routing.
<code>awplus(config)#</code>	
<code>interface tunnel 100</code>	Create a tunnel interface.
<code>awplus(config-if)#</code>	
<code>tunnel mode ipv6ip 6to4</code>	Set the tunnel mode.

Table 28-3: Example configuration for 6to4 automatic tunneling: Switch 3 (Continued)

<code>awplus(config-if)#</code>	
<code>tunnel source 143.29.136.18</code>	Define the IPv4 address to be used as the source address for the tunnel interface.
<code>awplus(config-if)#</code>	
<code>exit</code>	Exit Interface mode and enter Configure mode.
<code>awplus(config)#</code>	
<code>ipv6 route 2002::/16 tunnel 100</code>	Add a route to send traffic for other 6to4 subnets via the tunnel interface.
<code>awplus(config)#</code>	
<code>router ospf</code>	Create an OSPF routing instance.
<code>awplus(config-router)#</code>	
<code>router-id 10.70.0.76</code>	Specify a Router ID for the OSPF routing process.
<code>awplus(config-router)#</code>	
<code>network 143.29.136.0/24 area 0</code>	Enable OSPF routing with a specified Area ID on interfaces with IP addresses within the specified network address. The Area ID used in this case is 0, which specifies the backbone area.

Names of Commands Used

interface tunnel
ip address
ipv6 address
network area
router-id
tunnel mode ipv6ip
tunnel source

Chapter 29: IPv6to4 Tunneling Commands



Command List	29.2
interface tunnel.....	29.2
tunnel dscp	29.3
tunnel mode ipv6ip.....	29.4
tunnel source.....	29.5
tunnel ttl.....	29.6

Command List

This chapter provides an alphabetical reference of commands used to configure automatic IPv6 tunneling over IPv4. For more information, see [Chapter 28, IPv6to4 Tunneling Configuration](#).

interface tunnel

Use this command to create a new tunnel interface, which is identified by an integer (1-145).

This command is also used to enter interface configuration mode for existing tunnel interfaces.

Use the no parameter to destroy a previously created tunnel interface.

Note: This command will function on your switch in the stand alone mode, but is not supported when the device forms part of a VCS Stack.

Syntax interface tunnel <1-145>
 no interface tunnel <1-145>

Default Disabled

Mode Global Configuration mode

Usage This command creates a new tunnel interface to configure in Interface mode.

Example

```
awplus# configure terminal
awplus(config)# interface tunnel 100
awplus(config-if)#

awplus# configure terminal
awplus(config)# no interface tunnel 100
awplus(config)#
```

Related Commands tunnel dscp
 tunnel mode ipv6ip
 tunnel source
 tunnel ttl

tunnel dscp

Use this command to configure the value (0-63) to use for the IPv4 DSCP (Differentiated Services Code Point) field in the IPv4 header that encapsulates the tunneled IPv6 packets. By default the IPv4 DSCP field value is 0.

Use the no parameter to reset the IPv4 DSCP field to the default value (0).

Note: This command will function on your switch in the stand alone mode, but is not supported when the device forms part of a VCS Stack.

Syntax tunnel dscp <0-63>

no tunnel dscp

Default The default IPv4 DSCP field value is 0.

Mode Interface mode

Usage This command controls the IPv4 DSCP field in the IPv4 headers that are prepended (or prefixed) to the tunneled IPv6 packets.

Example

```
awplus# configure terminal
awplus(config)# interface tunnel 100
awplus(config-if)# tunnel source 192.168.11.1
awplus(config-if)# tunnel dscp 10
```

```
awplus# configure terminal
awplus(config)# interface tunnel 100
awplus(config-if)# tunnel source 192.168.11.1
awplus(config-if)# no tunnel dscp
```

Related Commands interface tunnel
tunnel mode ipv6ip
tunnel source
tunnel ttl

tunnel mode ipv6ip

Use this command to specify the IPv6 transition tunnel mode. In AlliedWare Plus™ 6to4 automatic tunneling is the only tunnel mode supported.

Use the no parameter to return the mode of the IPv6 transition tunnel to an undefined state.

Note: This command will function on your switch in the stand alone mode, but is not supported when the device forms part of a VCS Stack.

Syntax tunnel mode ipv6ip 6to4
 no tunnel mode

Parameter	Description
6to4	6to4 automatic tunnel mode.

Mode Interface mode

Usage This command specifies a tunnel encapsulation mode for IPv6 in IPv4. Currently only 6to4 automatic tunneling is supported. Future releases may support alternative tunneling modes.

It is a requirement that the mode is set on a tunnel. The tunnel will not be operational until the tunnel mode has been set using the tunnel mode ipv6ip 6to4 command.

Example

```
awplus# configure terminal
awplus(config)# interface tunnel 100
awplus(config-if)# tunnel source 10.10.1.1
awplus(config-if)# tunnel mode ipv6ip

awplus# configure terminal
awplus(config)# interface tunnel 100
awplus(config-if)# tunnel source 10.10.1.1
awplus(config-if)# no tunnel mode
```

Related Commands interface tunnel
 tunnel dscp
 tunnel source
 tunnel ttl

tunnel source

Use this command to specify the IPv4 source address for packets being encapsulated in the tunnel. It should be the IPv4 address on the interface that attaches the switch for the IPv4 domain through which the IPv6 packets are to be tunneled.

Use the no parameter to remove a tunnel source address for a tunnel interface.

Note: This command will function on your switch in the stand alone mode, but is not supported when the device forms part of a VCS Stack.

Syntax tunnel source <ipv4-addr>

no tunnel source

Parameter	Description
<ipv4-addr>	IPv4 tunnel source address

Mode Interface mode

Usage This command specifies an IPv4 source address for the tunnel.

Note: There are constraints on the IPv4 source address specified for the tunnel. The IPv4 source address for the tunnel must be the IPv4 address of an interface on the switch, and it must be the interface for carrying the tunnel traffic.

Example

```
awplus# configure terminal
awplus(config)# interface tunnel 100
awplus(config-if)# tunnel source 10.11.2.1

awplus# configure terminal
awplus(config)# interface tunnel 100
awplus(config-if)# no tunnel source
```

Related Commands

- interface tunnel
- tunnel dscp
- tunnel mode ipv6ip
- tunnel ttl

tunnel ttl

Use this command to configure the value to use for the Time to Live (TTL) field in the IPv4 header that encapsulates the tunneled IPv6 packets.

Use the no tunnel ttl command to inherit the TTL value from the encapsulated packet.

Note: This command will function on your switch in the stand alone mode, but is not supported when the device forms part of a VCS Stack.

Syntax tunnel ttl <1-255>

no tunnel ttl

Default By default the TTL value is inherited from the encapsulated packet.

Mode Interface mode

Usage This command specifies a value of Time to Live (TTL) in the tunnel IPv4 encapsulation header.

Example

```
awplus# configure terminal
awplus(config)# interface tunnel 100
awplus(config-if)# tunnel source 192.168.0.1
awplus(config-if)# tunnel ttl 255
```

```
awplus# configure terminal
awplus(config)# interface tunnel 100
awplus(config-if)# tunnel source 192.168.0.1
awplus(config-if)# no tunnel ttl
```

Related Commands interface tunnel
tunnel dscp
tunnel mode ipv6ip
tunnel source

Chapter 30: Routing Protocol Overview



Introduction	30.2
RIP	30.2
OSPF	30.2
BGP	30.3
PIM-SM	30.4
VRRP	30.4

Introduction

This chapter introduces the basic routing protocols supported within the AlliedWare Plus™ Operating System.

RIP

A distance-vector protocol, Routing Information Protocol (RIP) is an Interior Gateway Protocol (IGP) that uses hop counts as its metrics. The AlliedWare Plus™ RIP module supports RFCs 1058 and 1723; the RIPv2 module supports more fields in the RIP packets, and supports security authentication features.

At regular intervals of the routing update timer (a default value of 30 seconds), and at the time of change in the topology, the RIP router sends update messages to other routers. The listening routers update their route table with the new route, and increase the metric value of the path by one (referred to as a hop count). The router recognizes the IP address advertising router as the next hop, then sends the routing updates to other routers. A maximum allowable hop count is 15. If a router reaches a metric value of 16 or more (referred to as infinity), the destination is identified as unreachable. This avoids the indefinite routing loops. The split-horizon and hold-down features are used to avoid propagation incorrect routing information. The route becomes not valid when the route time-out timer expires; it remains in the table until the route-flush timer expires.

OSPF

A link-state routing protocol, Open Shortest Path First (OSPF) is an interior gateway protocol (IGP) that uses the Shortest Path First (SPF) Dijkstra algorithm.

OSPF sends link-state advertisements (LSAs) to all other routers within the same hierarchical area. Data on attached interfaces, metrics used, and other variables, are included in OSPF LSAs. As OSPF routers accumulate link-state data, they use the SPF algorithm to calculate the shortest path to each node.

An Autonomous System (AS) or Domain is defined as a group of networks with common routing infrastructure. OSPF can work in one AS; or receive or send routes from or to different AS systems. Autonomous systems consist of areas. An area is a group of neighboring networks or attached hosts. A router attached to multiple areas with its interfaces is called an Area Border Router (ABR). It creates a distinct topological database: a group of LSAs received from all routers in the same area, for each area. All the routers in the same area have an identical topological database. OSPF routing traffic is restricted in the area because areas are unknown to each other. The routing information is distributed between areas, area border routers, networks, and connected routers by the OSPF backbone.

All backbone OSPF area routers use the same procedures and algorithms to maintain routing information within the backbone that any area router would. The backbone topology is invisible to all routers within an area. The individual area topologies are invisible to the backbone. Sometimes the backbone is not a contiguous area. Virtual links function as if they were direct links, and are configured between backbone routers that share a link to a non-backbone area.

AS border routers running OSPF learn about exterior routes through exterior gateway protocols (EGPs) such as the Border Gateway Protocol (BGP).

During boot-up, an OSPF router initializes its routing-protocol-specific data structures and tables. When the lower-layer protocols with which it interfaces are functional, it sends the OSPF Hello protocol packets to find neighboring routers. A router sends Hello packets as keep-alive packets, informing other routers about its continuing functionality. Two routers are adjacent when their link state databases are synchronized.

Multi-access networks have more than two routers. On multi-access networks, the hello protocol chooses a designated router and a designated backup-router. The designated router generates LSAs for the entire multi-access network, and reduces network traffic and the size of the topological database. The designated router also determines the adjacency of routers and the synchronization of their topological databases. The data on a router's adjacencies or state changes are provided by periodic transmission of an LSA. Failed routers are detected, and topology is changed quickly by comparison of adjacencies to link states. Each router calculates a shortest path tree, with itself as a root, from the topological database generated from these LSAs. This shortest path tree creates a routing table.

BGP

Border Gateway Protocol (BGP) is an exterior gateway protocol (EGP) that determines the best path in networks, performs optimal routing between multiple autonomous systems or domains, and exchanges routing information with other BGP systems. The RFCs 1771 (BGP4), 1654 (first BGP4 specification), and 1105, 1163, 1267 (older version of BGP) describe BGP and BGP4.

Multiple-peer BGP routers in different autonomous systems, or administrative domains on the same physical network, support consistent internetwork topology using inter-autonomous system routing. Multiple-peer BGP routers within the same AS support consistent system topology using inter-autonomous system routing. BGP determines the router to serve as the connection point for specific external autonomous system routing services. Multiple-peer BGP routers transport traffic across an autonomous system that does not run BGP using pass-through autonomous-systems routing. In this case, if the traffic does not originate, or is destined for an autonomous system under consideration, the AS is used only to transport (pass-through) the traffic using another intra-autonomous system routing protocol.

BGP exchanges information about the list of autonomous system paths with other BGP systems. A connectivity mapping between autonomous systems is created, routing loops are pruned, and other autonomous systems-level policy decisions are taken. Each BGP router maintains a routing table of all feasible and optimal paths to other networks and incrementally updates the routing information received from other peer BGP routers.

The BGP routing metric describes the preference of the path, and is assigned to each link by the network administrator. The network administrator assigns this value to a link depending on path criteria such as:

- the number of autonomous systems through which the path passes
- the history of stability
- the line speed
- any delays
- cost per packet

PIM-SM

The AlliedWare Plus™ Protocol Independent Multicast–Sparse Mode (PIM-SM) module is a multicast routing protocol module that uses the underlying unicast Routing Information Base (RIB) to determine the best next-hop neighbor to reach the root of the multicast data distribution tree, the Rendezvous Point (RP), or the source. It builds unidirectional-shared trees per group, and optionally creates shortest-path trees per source.

VRRP

Mission-critical applications running on fault-tolerant networking equipment, such as routers and switches, require redundancy and high availability. This section provides an architectural overview of Virtual Router Redundancy Protocol (VRRP) implementation in the AlliedWare Plus™ OS.

Typically, end hosts are connected to the enterprise network through a single router (first-hop router) that is in the same Local Area Network (LAN) segment. The most popular method of configuration is for the end hosts to statically configure this router as their default gateway. This minimizes configuration and processing overhead. The main problem with this configuration method is that it produces a single point of failure if the enterprise network's first-hop router fails.

VRRP attempts to solve this problem by introducing the concept of a virtual router, composed of two or more VRRP routers on the same subnet. The concept of a virtual IP address is also introduced, which is the address that end hosts configure as their default gateway. Only one of the routers (called the Master) forwards packets on behalf of this IP address. In the event that the Master fails, one of the other routers (Backups) assumes forwarding responsibility for it.

Chapter 31: Route Selection



Introduction.....	31.2
Types of Routes.....	31.2
Interface Routes	31.2
Static Routes	31.2
Dynamic Routes.....	31.2
RIB and FIB Routing Tables	31.4
Administrative Distance.....	31.4
Equal Cost Multipath Routing	31.7
How AlliedWare Plus Deletes Routes	31.7
How AlliedWare Plus Adds Routes.....	31.8

Introduction

This chapter describes the route selection process used by the AlliedWare Plus Operating System. Understanding the route selection process helps in analyzing and troubleshooting route-related problems.

The process of routing packets consists of selectively forwarding data packets from one network to another. Your device must determine which network to send each packet to, and over which interface to send the packet in order to reach the desired network. This information is contained in your device routes. For each packet, your device chooses the best route it has for that packet and uses that route to forward the packet. In addition, you can define filters to restrict the way packets are sent.

Types of Routes

Your device learns routes from static information entered as part of the configuration process and by listening to any configured routing protocols. The following types of routes are available on your device:

Interface Routes

Your device creates an interface route when you create the interface. This route tells your device to send packets over that interface when the packets are addressed to the interface's subnet.

Static Routes

You can manually enter routes, which are then called static routes. You can use static routes to:

- specify the default route (to 0.0.0.0). If your device does not have a route to the packet's destination, it sends it out the default route. The default route normally points to an external network such as the Internet.
- set up multiple networks or subnets. In this case you define multiple routes for a particular interface, usually a LAN port. This is a method of supporting multiple subnets on a single physical media.

To create a static route, use the command:

```
awplus(config)# ip route <subnet&mask> [<gateway-ip>|<interface>] [<1-255>]
```

Dynamic Routes

Your device learns dynamic routes from one or more routing protocols such as RIP, BGP, or OSPF. The routing protocol updates these routes as the network topology changes.

In all but the most simple networks, we recommend that you configure at least one dynamic routing protocol. Routing protocols enables your device to learn routes from other routers and switches on the network, and to respond automatically to changes in network topology.

Routing protocols use different metrics to calculate the best path for a destination. However, when two paths have an equal cost/metric and Equal Cost Multipath (ECMP) is enabled on a system, AlliedWare Plus™ may receive two paths from the same protocol.

■ [Routing Information Protocol \(RIP\)](#)

Routing Information Protocol (RIP) is a simple distance vector IPv4 routing protocol. It determines the number of hops between the destination and your device, where one hop is one link. Given a choice of routes, RIP uses the route that takes the lowest number of hops. If multiple routes have the same hop count, RIP chooses the first route it finds.

See [Chapter 33, RIP Configuration](#) for further information about RIP Configuration.

■ [Routing Information Protocol next generation \(RIPng\)](#)

Routing Information Protocol next generation (RIPng) is a simple distance vector IPv6 routing protocol. It determines the number of hops between the destination and your device, where one hop is one link. Given a choice of routes, RIPng uses the route that takes the lowest number of hops. If multiple routes have the same hop count, RIPng chooses the first route it finds.

RIPng (Routing Information Protocol next generation) is an extension of RIPv2 to support IPv6. RFC 2080 specifies RIPng. The differences between RIPv2 and RIPng are:

- « [RIPng does not support RIP updates authentication](#)
- « [RIPng does not allow the attachment of arbitrary tags to routes](#)
- « [RIPng requires the encoding of the next-hop for a set of routes](#)

See [Chapter 35, RIPng Configuration](#) for further information about RIPng Configuration.

■ [Open Shortest Path First \(OSPF\)](#)

The Open Shortest Path First (OSPF) protocol is documented in RFC 1247. It has a number of significant benefits over RIP, including:

- « [OSPF supports the concept of areas to allow networks to be administratively partitioned as they grow in size.](#)
- « [Load balancing, in which multiple routes exist to a destination, is also supported. OSPF distributes traffic over these links.](#)

See [Chapter 37, OSPF Configuration](#) for further information about OSPF Configuration.

■ [Border Gateway Protocol \(BGP\)](#)

The Border Gateway Protocol (BGP) allows routers in different routing domains to exchange routing information. This facilitates the forwarding of data across the borders of the routing domains. BGP-4 is based on distance vector (DV) protocol algorithms.

See [Chapter 39, BGP Configuration](#) for further information about BGP Configuration.

RIB and FIB Routing Tables

Your device maintains its routing information in routing tables that tell your device how to find a remote network or host. Each route is uniquely identified in a table by its IP address, network mask, next hop, interface, protocol, and policy. There are two routing tables populated by your device: the *Routing Information Base* (RIB) and the *Forwarding Information Base* (FIB).

Note: Routes in the FIB are used locally but are not advertised to neighbors if they are not also in the RIB.

Routing Information Base

The RIB records all the routes that your device has learnt. Your device uses the RIB to advertise routes to its neighbor devices and to populate the FIB. It adds routes to this table when:

- you add a static route using the `ip route` command
- one or more routing protocols, such as RIP or OSPF, exchanges routing information with other routers or hosts
- your device receives route information from a connected interface
- your device gathers route information from an ICMP redirect message or DHCP message

Forwarding Information Base

The RIB populates the *Forwarding Information Base* (FIB) with the best route to each destination. When your device receives an IP packet, and no filters are active that would exclude the packet, it uses the FIB to find the most specific route to the destination. If your device does not find a direct route to the destination, and no default route exists, it discards the packet and sends an ICMP message to that effect back to the source.

Adjusting table entries

To view the routes in the RIB, use the command:

```
awplus# show ip route database [bgp|connected|ospf|rip|static]
```

To view the routes in the FIB, use the command:

```
awplus# show ip route [bgp|connected|ospf|rip|static]<ip-addr>[<ip-addr/prefix-length>]
```

Administrative Distance

When multiple routes are available for the same prefix, the AlliedWare Plus Operating System adds the routes with the lowest *administrative distance* to the FIB. The administrative distance is a rank given to a route based on the protocol that the route was received from. The lower the administrative distance, the higher the route preference. For example, if the RIB has these routes

Route	Prefix	Protocol	Distance
1	192.168.0/16	eBGP	20
2	192.168.0/16	OSPF	110
3	192.168.1/24	OSPF	110

then the AlliedWare Plus Operating System adds routes 1 and 3 to the FIB. It does not add route 2, as this has a higher administrative distance than a route with the same prefix.

Note: Administrative distance indicates a level of trustworthiness of a route where the lower the administrative distance the higher the integrity of a route.

The following table lists the default administrative distances of protocols.

Protocols	Distance	Preference
Connected Routes directly connected to an interface.	-	1 (highest)
Static Routes added using the ip route command or learnt through DHCP options on interfaces using DHCP to obtain an IP address.	1	2
eBGP Routes learnt from BGP that are external to your network.	20	3
OSPF Routes learnt from OSPF.	110	4
RIP Routes learnt from RIP.	120	5
iBGP Routes learnt from BGP that are internal to your network.	200	6 (lowest)
Unknown No traffic will be passed to neighbors via this route.	255	(route is not advertised to neighbors)

You can change the administrative distances for static routes and protocol derived routes. Use the following commands:

- for static routes, specify the distance when adding the route. Use the command:
`awplus(config)# ip route <subnet&mask> {<gateway-ip>|<interface>} [<1-255>]`

- for eBGP and iBGP routes, enter the router mode, and use the command:
`awplus(config-router)# distance bgp <ebgp> <ibgp> <local>`

to enter a separate administrative distance value for each BGP route type. To set the administrative distance for a specific BGP route, use the command:

`awplus(config-router)# distance <1-255> <ip-address/m> [<listname>]`

- for OSPF routes, enter the router mode, and use the command:
`awplus(config-router)# distance ospf {external <1-255>|inter-area <1-255>|intra-area <1-255>}`

to enter a separate administrative distance value for each OSPF route type. To set the same value for all OSPF route types, use the command:

`awplus(config-router)# distance <1-255>`

- for RIP routes, enter the router mode, and use the command:
`awplus(config-router)# distance <1-255> {<ip-addr/prefix-length> [<access-list>]}`

This sets the administrative distance for all RIP routes.

You cannot set an administrative distance for connected routes.

Note: *AlliedWare Plus does not populate routes with an administrative distance of 255 in the FIB (Forwarding Information Base). But AlliedWare Plus does populate routes with an administrative distance of 255 in the RIB (Routing Information Base).*

See the below examples showing the behavior of a static route with an administrative distance of 255, which is only added to the RIB, as seen from the below show output:

Output Figure 31-1: Static route with an administrative distance of 255 that is added to the RIB:

```
awplus(config)#ip route 100.0.0.0/24 192.168.1.100 255
awplus(config)#end
awplus#show ip route database

Codes: C - connected, S - static, R - RIP, B - BGP
       O - OSPF, IA - OSPF inter area
       N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
       E1 - OSPF external type 1, E2 - OSPF external type 2
       > - selected route, * - FIB route, p - stale info

S      100.0.0.0/24 [255/0] via 192.168.1.100, vlan1
C      *> 192.168.1.0/24 is directly connected, vlan1
```

Output Figure 31-2: Static route with an administrative distance of 255 that is not added to the FIB:

```
awplus(config)#ip route 100.0.0.0/24 192.168.1.100 255
awplus(config)#end
awplus#show ip route

Codes: C - connected, S - static, R - RIP, B - BGP
       O - OSPF, IA - OSPF inter area
       N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
       E1 - OSPF external type 1, E2 - OSPF external type 2
       * - candidate default

C      192.168.1.0/24 is directly connected, vlan1
```


Equal Cost Multipath Routing

When multiple routes are available for the same prefix within the FIB, then your device uses Equal Cost Multipath Routing (ECMP) to determine how to forward packets.

ECMP allows the AlliedWare Plus Operating System to distribute traffic over multiple equal-cost routes to a destination. The software determines that two or more routes are equal cost if they have the same destination IP address and mask. When the software learns such multiple routes, it puts them in an ECMP route group. When it sends traffic to that destination, it distributes the traffic across all routes in the group.

The AlliedWare Plus Operating System distributes traffic over the routes one flow at a time, so all packets in a session take the same route. Each equal-cost route group can contain up to eight individual routes. ECMP is only used to select between routes already in the FIB.

By default, each equal-cost route group can contain four routes. You can change this setting by using the command:

```
awplus(config)#maximum-paths <1-8>
```

The maximum path setting determines how many routes with the same prefix value and the same administrative distance that the FIB can contain. Once an equal-cost route group has the maximum number of routes, then the RIB cannot add any further routes to the route group. The device only adds to the group if a route is deleted from the FIB.


To disable ECMP, set the maximum paths value to one.

How AlliedWare Plus Deletes Routes

When the AlliedWare Plus Operating System receives a route delete request from a routing protocol, it first deletes the specified route from its RIB. Then it checks if the specified route is in the FIB. If the route is in the FIB, it deletes it from the FIB and checks if another route is available in its database for the same prefix. If there is another route in the database, the software installs this route in the FIB. When multiple such routes exist, the software uses the route selection mechanism to choose the best route before adding it to the FIB.

How AlliedWare Plus Adds Routes

The following flow chart shows how the software adds a route to the FIB.



Chapter 32: Routing Commands



Command List	32.2
ip route	32.2
maximum-paths	32.3
show ip route	32.4
show ip route database	32.6
show ip route summary	32.7

Command List

This chapter provides an alphabetical reference of commands routing commands that are common across the routing IP protocols. For more information see [Chapter 30, Routing Protocol Overview](#) and [Chapter 31, Route Selection](#).

ip route

This command adds a static route to the Routing Information Base (RIB). If this route is the best route for the destination, then your device adds it to the Forwarding Information Base (FIB). Your device uses the FIB to advertise routes to neighbors and forward packets.

The no form removes the static route from the RIB and FIB.

Syntax `ip route <subnet&mask> {<gateway-ip>|<interface>} [<1-255>]`
`no ip route <subnet&mask> {<gateway-ip>|<interface>} [<1-255>]`

Parameter	Description
<code><subnet&mask></code>	The IPv4 address of the destination prefix with either a prefix length or a separate mask specified in one of the following formats: The IPv4 subnet address in dotted decimal notation followed by the subnet mask in dotted decimal notation. The IPv4 subnet address in dotted decimal notation followed by a forward slash, then the prefix length.
<code><gateway-ip></code>	The IPv4 address of the gateway device.
<code><interface></code>	The interface that connects your device to the network. Enter the name of the VLAN or its VID.
<code><1-255></code>	The administrative distance for this route. For more information about setting administrative distances, see “Administrative Distance” on page 31.4 .

Mode Global Configuration mode

Examples To add the destination 192.168.3.0 with the mask 255.255.255.0 as a static route available through the device at “10.10.0.2” with an administrative distance of 128, use the command:

```
awplus(config)# ip route 192.168.3.0 255.255.255.0 10.10.0.2
128
```

To add the destination 10.0.0.0 with a prefix length of 8 as a static route available through vlan4 with an administrative distance of 32, use the command:

```
awplus(config)# ip route 10.0.0.0/8 vlan4 32
```

Related Commands [show ip route](#)

maximum-paths

This command enables ECMP on your device, and sets the maximum number of paths that each route has in the Forwarding Information Base (FIB). ECMP is enabled by default.

The no form sets the maximum paths to the default of 4.

Syntax `maximum-paths <1-8>`

`no maximum-paths`

Parameter	Description
<code><1-8></code>	The maximum number of paths that a route can have in the FIB. Default: 4

Mode Global Configuration mode

Examples To set the maximum number of paths for each route in the FIB to 5, use the command:

```
awplus(config)# maximum-paths 5
```

To set the maximum paths for a route to the default of 4, use the command:

```
awplus(config)# no maximum-paths
```

show ip route

Use the `show ip route` command to display the current state of the routing table.

This command displays the routes in the FIB (Forwarding Information Base). The FIB contains the best routes to a destination, and your device uses these routes when forwarding traffic. You can use this command to view a subset of the FIB based on protocol or network.

To modify the lines displayed, use the `|` (output modifier token); to save the output to a file, use the `>` output redirection token.

Syntax `show ip route [bgp|connected|ospf|rip|static|<ip-addr>|<ip-addr/prefix-length>]`

Parameter	Description
<code>bgp</code>	Displays only the routes learned from BGP.
<code>connected</code>	Displays only the routes learned from connected interfaces.
<code>ospf</code>	Displays only the routes learned from OSPF.
<code>rip</code>	Displays only the routes learned from RIP.
<code>static</code>	Displays only the static routes you have configured.
<code><ip-addr></code>	Displays the routes for the specified address. Enter an IPv4 address.
<code><ip-addr/prefix-length></code>	Displays the routes for the specified network. Enter an IPv4 address and prefix length.

Mode Exec mode and Privileged Exec mode

Output Each entry in this table has a code preceding it, indicating the source of the routing entry. For example, O indicates OSPF as the origin of the route. The first few lines of the output list the possible codes that may be seen with the route entries.

Typically, route entries are composed of the following elements:

- code
- a second label indicating the sub-type of the route
- network or host ip address
- administrative distance and metric
- nexthop ip address
- outgoing interface name
- time since route entry was added

Figure 32-1: Example output from the **show ip route** command

```
Codes: C - connected, S - static, R - RIP, B - BGP
       O - OSPF, IA - OSPF inter area
       N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
       E1 - OSPF external type 1, E2 - OSPF external type 2
       * - candidate default

O      10.10.37.0/24 [110/11] via 10.10.31.16, vlan2, 00:20:54
C      3.3.3.0/24 is directly connected, vlan1
C      10.10.31.0/24 is directly connected, vlan2
C      10.70.0.0/24 is directly connected, vlan4
O E2   14.5.1.0/24 [110/20] via 10.10.31.16, vlan2, 00:18:56
C      33.33.33.33/32 is directly connected, lo
```

To avoid repetition, only selected route entries comprised of different elements are described here:

OSPF Route O 10.10.37.0/24 [110/11] via 10.10.31.16, vlan2, 00:20:54

This route entry denotes:

- This route in the network 10.10.37.0/24 was added by OSPF.
- This route has an administrative distance of 110 and metric/cost of 11.
- This route is reachable via nexthop 10.10.31.16.
- The outgoing local interface for this route is vlan2.
- This route was added 20 minutes and 54 seconds ago.

Connected Route C 10.10.31.0/24 is directly connected, vlan2

This route entry denotes:

- Route entries for network 10.10.31.0/24 are derived from the IP address of local interface vlan2.
- These routes are marked as Connected routes (C) and always preferred over routes for the same network learned from other routing protocols.

OSPF External Route O E2 14.5.1.0/24 [110/20] via 10.10.31.16, vlan2, 00:18:56

This route entry denotes:

- This route is the same as the other OSPF route explained above; the main difference is that it is a Type 2 External OSPF route.

Examples To display the OSPF routes in the FIB, use the command:

```
awplus# show ip route ospf
```

Related Commands maximum-paths
show ip route database

show ip route database

This command displays the routing entries in the RIB (Routing Information Base). When multiple entries are available for the same prefix, RIB uses the routes' administrative distances to choose the best route. All best routes are entered into the FIB (Forwarding Information Base). To view the routes in the FIB, use the [show ip route](#) command.

To modify the lines displayed, use the | (output modifier token); to save the output to a file, use the > output redirection token.

Syntax `show ip route database [bgp|connected|ospf|rip|static]`

Parameter	Description
bgp	Displays only the routes learned from BGP.
connected	Displays only the routes learned from connected interfaces.
ospf	Displays only the routes learned from OSPF.
rip	Displays only the routes learned from RIP.
static	Displays only the static routes you have configured.

Mode Exec mode and Privileged Exec mode

Output Figure 32-2: Example output from the [show ip route database](#) command

```
Codes: C - connected, S - static, R - RIP, B - BGP
       O - OSPF, IA - OSPF inter area
       N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
       E1 - OSPF external type 1, E2 - OSPF external type 2
       > - selected route, * - FIB route, p - stale info

O    *> 9.9.9.9/32 [110/31] via 10.10.31.16, vlan2, 00:19:21
O    10.10.31.0/24 [110/1] is directly connected, vlan2, 00:28:20
C    *> 10.10.31.0/24 is directly connected, vlan2
S    *> 10.10.34.0/24 [1/0] via 10.10.31.16, vlan2
O    10.10.34.0/24 [110/31] via 10.10.31.16, vlan2, 00:21:19
O    *> 10.10.37.0/24 [110/11] via 10.10.31.16, vlan2, 00:21:19
C    *> 10.30.0.0/24 is directly connected, vlan6
S    *> 11.22.11.0/24 [1/0] via 10.10.31.16, vlan2
O E2 *> 14.5.1.0/24 [110/20] via 10.10.31.16, vlan2, 00:19:21
O    16.16.16.16/32 [110/11] via 10.10.31.16, vlan2, 00:21:19
S    *> 16.16.16.16/32 [1/0] via 10.10.31.16, vlan2
O    *> 17.17.17.17/32 [110/31] via 10.10.31.16, vlan2, 00:21:19
C    *> 45.45.45.45/32 is directly connected, lo
O    *> 55.55.55.55/32 [110/21] via 10.10.31.16, vlan2, 00:21:19
C    *> 127.0.0.0/8 is directly connected, lo
```

The routes added to the FIB are marked with a *. When multiple routes are available for the same prefix, the best route is indicated with the > symbol. All unselected routes have neither the * nor the > symbol.

```
S    *> 10.10.34.0/24 [1/0] via 10.10.31.16, vlan2
O    10.10.34.0/24 [110/31] via 10.10.31.16, vlan2, 00:21:19
```


These route entries denote:

- The same prefix was learned from OSPF and from static route configuration.
- Since this static route has a lower administrative distance than the OSPF route (110), the static route (1) is selected and installed in the FIB.

If the static route becomes unavailable, then the device automatically selects the OSPF route and installs it in the FIB.

Examples To display the static routes in the RIB, use the command:

```
awplus# show ip route database static
```

Related Commands [maximum-paths](#)
[show ip route](#)

show ip route summary

This command displays a summary of the current RIB (Routing Information Base) entries.

To modify the lines displayed, use the | (output modifier token); to save the output to a file, use the > output redirection token.

Syntax `show ip route summary`

Mode Exec mode and Privileged Exec mode

Output Figure 32-3: Example output from the **show ip route summary** command

```
IP routing table name is Default-IP-Routing-Table(0)
IP routing table maximum-paths is 4
Route Source      Networks
connected         5
ospf               2
Total             8
FIB               2
```

Examples To display a summary of the current RIB entries, use the command:

```
awplus# show ip route summary
```

Related Commands [show ip route](#)
[show ip route database](#)

Chapter 33: RIP Configuration



Introduction.....	33.2
Enabling RIP.....	33.2
Specifying the RIP version.....	33.3
RIPv2 authentication (single key).....	33.5
RIPv2 text authentication (multiple keys).....	33.7
RIPv2 md5 authentication (multiple keys).....	33.11


Introduction

This chapter contains basic RIP configuration examples. To see details on the RIP commands used in these examples, or to see the outputs of the Validation commands, refer to the [Chapter 34, RIP Commands](#).

Enabling RIP

This example shows the minimum configuration required for enabling two devices to exchange routing information using RIP. The routing devices in this example are Allied Telesis managed Layer 3 Switches. Switch 1 and Switch 2 are two neighbors connecting to network 10.10.11.0/24. Switch 1 and Switch 2 are also connected to networks 10.10.10.0/24 and 10.10.12.0/24 respectively. This example assumes that the devices have already been configured with IP interfaces in those subnets.

To enable RIP, first define the RIP routing process and then associate a network with the routing process.



Switch 1

```
awplus#
configure terminal  Enter the Configure mode.

awplus(config)#
router rip          Define a RIP routing process and enter the Router mode.

awplus(config-router)#
network 10.10.10.0/24 Associate network 10.10.10.0/24 with the RIP process..

awplus#
network 10.10.11.0/24 Associate network 10.10.11.0/24 with the RIP process.
```

Switch 2

```
awplus#
configure terminal  Enter the Configure mode.

awplus(config)#
router rip          Define a RIP routing process and enter the Router mode.

awplus(config-router)#
network 10.10.11.0/24 Associate networks with the RIP process

awplus(config-router)#
network 10.10.12.0/24 Associate networks with the RIP process
```

Names of Commands Used


router rip, network (RIP)

Validation Commands

show ip rip, show running-config, show ip protocols rip, show ip rip interface, show ip route

Specifying the RIP version

Configure a router to receive and send specific versions of RIP packets on a VLAN interface. The routing devices in this example are Allied Telesis managed Layer 3 Switches. In this example, Switch 2 is configured to receive and send RIP version 1 and version 2 information on both `vlan2` and `vlan3` interfaces.



Switch 2

<code>awplus#</code>	
<code>configure terminal</code>	Enter the Configure mode.
<code>awplus(config)#</code>	
<code>router rip</code>	Enable the RIP routing process.
<code>awplus(config-router)#</code>	
<code>exit</code>	Return to the Configure mode
<code>awplus(config)#</code>	
<code>interface vlan2</code>	Specify vlan2 as an interface you want to configure.
<code>awplus(config-if)#</code>	
<code>ip rip send version 1 2</code>	Allow sending RIP version 1 and version 2 packets out of this interface.

Switch 2(Continued)


awplus(config-if)#	
<code>ip rip receive version 1 2</code>	Allow receiving of RIP version 1 and version 2 packets from the vlan2 interface.
awplus(config-if)#	
<code>exit</code>	Exit the Interface mode and return to Configure mode to configure the next interface.
awplus(config)#	
<code>interface vlan3</code>	Specify interface vlan3 as the interface you want to configure.
awplus(config-if)#	
<code>ip rip send version 1 2</code>	Allow sending RIP version 1 and version 2 packets out of this interface.
awplus(config-if)#	
<code>ip rip receive version 1 2</code>	Allow receiving of RIP version 1 and version 2 packets from the vlan3 interface.

Commands Used `ip rip send version`
 `ip rip receive version`

**Validation
Commands** `show ip rip`
 `show running-config`
 `show ip protocols rip`
 `show ip rip interface`
 `show ip route`

RIPv2 authentication (single key)

AlliedWare Plus™ RIP implementation provides the choice of configuring authentication for a single key or for multiple keys. This example illustrates authentication of the routing information exchange process for RIP using a single key. The routing devices in this example are Allied Telesis managed Layer 3 Switches. Switch 1 and Switch 2 are running RIP and exchange routing updates. To configure single key authentication on Switch 1, specify an interface and then define a key or password for that interface. Next, specify an authentication mode. Any receiving RIP packet on this specified interface should have the same string as password. For an exchange of updates between Switch 1 and Switch 2, define the same password and authentication mode on Switch 2.



Switch 1

<code>awplus#</code>	
<code>configure terminal</code>	Enter the Configure mode.
<code>awplus(config)#</code>	
<code>router rip</code>	Define a RIP routing process and enter the Router mode.
<code>awplus(config-router)#</code>	
<code>network 10.10.10.0/24</code>	Associate network 10.10.10.0/24 with the RIP process.
<code>awplus(config-router)#</code>	
<code>redistribute connected</code>	Enable redistributing from connected routes.
<code>awplus(config-router)#</code>	
<code>exit</code>	Exit the Router mode and return to the Configure mode.
<code>awplus(config)#</code>	
<code>interface vlan2</code>	Specify the VLAN interface (vlan2) for authentication.
<code>awplus(config-if)#</code>	
<code>ip rip authentication string Secret</code>	Specify the authentication string (Secret) for this interface.
<code>awplus(config-if)#</code>	
<code>ip rip authentication mode md5</code>	Specify the authentication mode to be MD5.

Switch 2

<code>awplus#</code>	
<code>configure terminal</code>	Enter the Configure mode.
<code>awplus(config)#</code>	
<code>router rip</code>	Define a RIP routing process and enter the Router mode.
<code>awplus(config-router)#</code>	
<code>network 10.10.10.0/24</code>	Associate network 10.10.10.0/24 with the RIP process.
<code>awplus(config-router)#</code>	
<code>redistribute connected</code>	Enable redistributing from connected routes.
<code>awplus(config-router)#</code>	
<code>exit</code>	Exit the Router mode and return to the Configure mode.
<code>awplus(config)#</code>	
<code>interface vlan2</code>	Specify the VLAN interface (vlan2) for authentication.
<code>awplus(config-if)#</code>	
<code>ip rip authentication string Secret</code>	Specify the authentication string (Secret) on this interface.
<code>awplus(config-if)#</code>	
<code>ip rip authentication mode md5</code>	Specify the authentication mode to be MD5.

Names of Commands Used

ip rip authentication string
 ip rip authentication mode
 redistribute (RIP)
 network (RIP)


Validation Commands

show ip rip
 show running-config
 show ip protocols rip
 show ip rip interface
 show ip route

RIPv2 text authentication (multiple keys)

This example illustrates text authentication of the routing information exchange process for RIP using multiple keys. The routing devices in this example are Allied Telesis managed Layer 3 Switches. Switch 1 and Switch 2 are running RIP and exchanging routing updates. To configure authentication on Switch 1, define a key chain, specify keys in the key chain and then define the authentication string or passwords to be used by the keys. Set the time period during which it is valid to receive or send the authentication key by specifying the accept and send lifetimes. After defining the key string, specify the key chain (or the set of keys) that will be used for authentication on each interface and also the authentication mode to be used.

Switch 1 accepts all packets that contain any key string that matches one of the key strings included in the specified key chain (within the accept lifetime) on that interface. The key ID is not considered for matching. For additional security, the accept lifetime and send lifetime are configured such that every fifth day the key ID and key string changes. To maintain continuity, the accept lifetimes should be configured to overlap. This will accommodate different time-setup on machines. However, the send lifetime does not need to overlap and we recommend not configuring overlapping send lifetimes.



Switch 1

<code>awplus#</code>	
<code>configure terminal</code>	Enter the Configure mode.
<code>awplus(config)#</code>	
<code>router rip</code>	Define a RIP routing process and enter the Router mode.
<code>awplus(config-router)#</code>	
<code>network 10.10.10.0/24</code>	Associate network 10.10.10.0/24 with the RIP process.
<code>awplus(config-router)#</code>	
<code>redistribute connected</code>	Enable redistributing of connected routes.
<code>awplus(config-router)#</code>	
<code>exit</code>	Exit the Router mode and return to the Configure mode.
<code>awplus(config)#</code>	
<code>key chain SUN</code>	Enter the key chain management mode to add keys to the key chain SUN.
<code>awplus(config-keychain)#</code>	
<code>key 10</code>	Add authentication key ID (10) to the key chain SUN.
<code>awplus(config-keychain-key)#</code>	
<code>key-string Secret</code>	Specify a password (Secret) to be used by the specified key.

Switch 1 (Continued)

awplus(config-keychain-key)#	
accept-lifetime 12:00:00 Mar 2 2007 14:00:00 Mar 7 2007	Specify the time period during which authentication key string <code>Secret</code> can be received. In this case, key string <code>Secret</code> can be received from noon of March 2 to 2 pm March 7, 2007.
awplus(config-keychain-key)#	
send-lifetime 12:00:00 Mar 2 2007 12:00:00 Mar 7 2007	Specify the time period during which authentication key string <code>Secret</code> can be send. In this case, key string <code>Secret</code> can be received from noon of March 2 to noon of March 7, 2007.
awplus(config-keychain-key)#	
exit	Exit the keychain-key mode and return to keychain mode.
awplus(config-keychain)#	
key 20	Add another authentication key (20) to the key chain <code>SUN</code> .
awplus(config-keychain-key)#	
key-string Earth	Specify a password (Earth) to be used by the specified key.
awplus(config-keychain-key)#	
accept-lifetime 12:00:00 Mar 7 2007 14:00:00 Mar 12 2007	Specify the time period during which authentication key string <code>Earth</code> can be received. In this case, key string <code>Earth</code> can be received from noon of March 7 to 2 pm March 12, 2007.
awplus(config-keychain-key)#	
send-lifetime 12:00:00 Mar 7 2007 12:00:00 Mar 12 2007	Specify the time period during which authentication key string <code>Earth</code> can be sent. In this case, key string <code>Secret</code> can be received from noon of March 7 to noon of March 12, 2007.
awplus(config-keychain-key)#	
end	Enter Privileged Exec mode.
awplus#	
configure terminal	Enter the Configure mode.
awplus(config)#	
interface vlan2	Specify VLAN interface (vlan2) as the interface you want to configure on Switch 1.
awplus(config-if)#	
ip rip authentication key-chain SUN	Enable RIPv2 authentication on the <code>vlan2</code> interface and specify the key chain <code>SUN</code> to be used for authentication.
awplus(config-if)#	
ip rip authentication mode text	Specify text authentication mode to be used for RIP packets. This step is optional, as text is the default mode.

Switch 2

<code>awplus#</code>	
<code>configure terminal</code>	Enter the Configure mode.
<code>awplus(config)#</code>	
<code>router rip</code>	Define a RIP routing process and enter the Router mode.
<code>awplus(config-router)#</code>	
<code>network 10.10.10.0/24</code>	Associate network 10.10.10.0/24 with the RIP process.
<code>awplus(config-router)#</code>	
<code>redistribute connected</code>	Enable redistributing from connected routes.
<code>awplus(config-router)#</code>	
<code>exit</code>	Exit the Router mode and return to the Configure mode.
<code>awplus(config)#</code>	
<code>key chain MOON</code>	Enter the key chain management mode to add keys to the key chain MOON.
<code>awplus(config-keychain)#</code>	
<code>key 30</code>	Add authentication key ID (30) to the key chain MOON.
<code>awplus(config-keychain-key)#</code>	
<code>key-string Secret</code>	Specify a password (Secret) to be used by the specified key.
<code>awplus(config-keychain-key)#</code>	
<code>accept-lifetime 12:00:00 Mar 2 2007</code> <code>14:00:00 Mar 7 2007</code>	Specify the time period during which authentication key string Secret can be received. In this case, key string Secret can be received from noon of March 2 to 2 pm March 7, 2007.
<code>awplus(config-keychain-key)#</code>	
<code>send-lifetime 12:00:00 Mar 2 2007</code> <code>12:00:00 Mar 7 2007</code>	Specify the time period during which authentication key string Secret can be send. In this case, key string Secret can be received from noon of March 2 to noon of March 7, 2007.
<code>awplus(config-keychain)#</code>	
<code>key 40</code>	Add another authentication key (40) to the key chain MOON.
<code>awplus(config-keychain-key)#</code>	
<code>key-string Earth</code>	Specify a password (Earth) to be used by the specified key.
<code>awplus(config-keychain-key)#</code>	
<code>accept-lifetime 12:00:00 Mar 7 2007</code> <code>14:00:00 Mar 12 2007</code>	Specify the time period during which authentication key string Earth can be received. In this case, key string Earth can be received from noon of March 7 to 2 pm March 12, 2007.

Switch 2 (Continued)


awplus(config-keychain-key)#	
<code>send-lifetime 12:00:00 Mar 7 2007</code>	Specify the time period during which authentication key string <code>Earth</code> can be sent. In this case, key string <code>Secret</code> can be received from noon of March 7 to noon of March 12, 2007.
<code>12:00:00 Mar 12 2007</code>	
awplus(config-keychain-key)#	
<code>end</code>	Enter Privileged Exec mode.
awplus#	
<code>configure terminal</code>	Enter the Configure mode.
awplus(config)#	
<code>interface vlan2</code>	Specify the VLAN interface that you want to configure on Switch 2.
awplus(config-if)#	
<code>ip rip authentication key-chain MOON</code>	Enable RIPv2 authentication on the <code>vlan2</code> interface, and specify the key chain <code>MOON</code> to be used for authentication.
awplus(config-if)#	
<code>ip rip authentication mode text</code>	Specify authentication mode to be used for RIP packets. This step is optional, as <code>text</code> is the default mode.

Names of Commands Used	key chain, key-string
	accept-lifetime
	send-lifetime
	ip rip authentication key-chain
	ip rip authentication mode
Validation Commands	show ip rip
	show running-config
	show ip protocols rip
	show ip rip interface, show ip route

RIPv2 md5 authentication (multiple keys)

This example illustrates the md5 authentication of the routing information exchange process for RIP using multiple keys. The routing devices in this example are Allied Telesis managed Layer 3 Switches. Switch 1 and Switch 2 are running RIP and exchange routing updates. To configure authentication on Switch 1, define a key chain, specify keys in the key chain and then define the authentication string or passwords to be used by the keys. Then set the time period during which it is valid to receive or send the authentication key by specifying the accept and send lifetimes. After defining the key string, specify the key chain (or the set of keys) that will be used for authentication on the interface and the authentication mode to be used. Configure Switch 2 and Switch 3 to have the same key ID and key string as Switch 1 for the time that updates need to be exchanged.

In md5 authentication, both the key ID and key string are matched for authentication. Switch 1 will receive only packets that match both the key ID and the key string in the specified key chain (within the accept lifetime) on that interface. In the following example, Switch 2 has the same key ID and key string as Switch 1. For additional security, the accept lifetime and send lifetime are configured such that every fifth day the key ID and key string changes. To maintain continuity, the accept lifetimes should be configured to overlap; however, the send lifetime should not be overlapping.



Switch 1

<code>awplus#</code>	
<code>configure terminal</code>	Enter the Configure mode.
<code>awplus(config)#</code>	
<code>router rip</code>	Define a RIP routing process and enter the Router mode.
<code>awplus(config-router)#</code>	
<code>network 10.10.10.0/24</code>	Associate network 10.10.10.0/24 with the RIP process.
<code>awplus(config-router)#</code>	
<code>redistribute connected</code>	Enable redistributing from connected routes.
<code>awplus(config-router)#</code>	
<code>exit</code>	Exit the Router mode and return to the Configure mode.
<code>awplus(config)#</code>	
<code>key chain SUN</code>	Enter the key chain management mode to add keys to the key chain SUN.
<code>awplus(config-keychain)#</code>	
<code>key 1</code>	Add authentication key ID (1) to the key chain SUN.
<code>awplus(config-keychain-key)#</code>	
<code>key-string Secret</code>	Specify a password (Secret) to be used by the specified key.

Switch 1 (Continued)

<code>awplus(config-keychain-key)#</code>	
<code>accept-lifetime 12:00:00 Mar 2 2007 14:00:00 Mar 7 2007</code>	Specify the time period during which authentication key string <code>Secret</code> can be received. In this case, key string <code>Secret</code> can be received from noon of March 2 to 2 pm March 7, 2007.
<code>awplus(config-keychain-key)#</code>	
<code>send-lifetime 12:00:00 Mar 2 2007 12:00:00 Mar 7 2007</code>	Specify the time period during which authentication key string <code>Secret</code> can be send. In this case, key string <code>Secret</code> can be received from noon of March 2 to noon of March 7, 2007.
<code>awplus(config-keychain-key)#</code>	
<code>exit</code>	Exit the <code>keychain-key</code> mode and return to <code>keychain</code> mode.
<code>awplus(config-keychain)#</code>	
<code>key 2</code>	Add another authentication key (2) to the key chain <code>SUN</code> .
<code>awplus(config-keychain-key)#</code>	
<code>key-string Earth</code>	Specify a password (<code>Earth</code>) to be used by the specified key.
<code>awplus(config-keychain-key)#</code>	
<code>accept-lifetime 12:00:00 Mar 7 2007 14:00:00 Mar 12 2007</code>	Specify the time period during which authentication key string <code>Earth</code> can be received. In this case, key string <code>Earth</code> can be received from noon of March 7 to 2 pm March 12, 2007.
<code>awplus(config-keychain-key)#</code>	
<code>send-lifetime 12:00:00 Mar 7 2007 12:00:00 Mar 12 2007</code>	Specify the time period during which authentication key string <code>Earth</code> can be send. In this case, key string <code>Secret</code> can be received from noon of March 7 to noon of March 12, 2007.
<code>awplus(config-keychain-key)#</code>	
<code>end</code>	Enter Privileged Exec mode.
<code>awplus#</code>	
<code>configure terminal</code>	Enter the Configure mode.
<code>awplus(config)#</code>	
<code>interface vlan2</code>	Specify interface <code>vlan2</code> as the VLAN interface you want to configure on Switch 1.
<code>awplus(config-if)#</code>	
<code>ip rip authentication key-chain SUN</code>	Enable RIPv2 authentication on the <code>vlan2</code> interface and specify the key chain <code>SUN</code> to be used for authentication.
<code>awplus(config-if)#</code>	
<code>ip rip authentication mode md5</code>	Specify the <code>md5</code> authentication mode to be used for RIP packets.

Switch 2

<code>awplus#</code>	
<code>configure terminal</code>	Enter the Configure mode.
<code>awplus(config)#</code>	
<code>router rip</code>	Define a RIP routing process and enter the Router mode.
<code>awplus(config-router)#</code>	
<code>network 10.10.10.0/24</code>	Associate network 10.10.10.0/24 with the RIP process.
<code>awplus(config-router)#</code>	
<code>redistribute connected</code>	Enable redistributing from connected routes.
<code>awplus(config-router)#</code>	
<code>exit</code>	Exit the Router mode and return to the Configure mode.
<code>awplus(config)#</code>	
<code>key chain MOON</code>	Enter the key chain management mode to add keys to the key chain MOON.
<code>awplus(config-keychain)#</code>	
<code>key 1</code>	Add authentication key ID (1) to the key chain MOON.
<code>awplus(config-keychain-key)#</code>	
<code>key-string Secret</code>	Specify a password (Secret) to be used by the specified key.
<code>awplus(config-keychain-key)#</code>	
<code>accept-lifetime 12:00:00 Mar 2 2007 14:00:00 Mar 7 2007</code>	Specify the time period during which authentication key string Secret can be received. In this case, key string Secret can be received from noon of March 2 to 2 pm March 7, 2007.
<code>awplus(config-keychain-key)#</code>	
<code>send-lifetime 12:00:00 Mar 2 2007 12:00:00 Mar 7 2007</code>	Specify the time period during which authentication key string Secret can be send. In this case, key string Secret can be received from noon of March 2 to noon of March 7, 2007.
<code>awplus(config-keychain)#</code>	
<code>key 2</code>	Add another authentication key (2) to the key chain MOON.
<code>awplus(config-keychain-key)#</code>	
<code>key-string Earth</code>	Specify a password (Earth) to be used by the specified key.
<code>awplus(config-keychain-key)#</code>	
<code>accept-lifetime 12:00:00 Mar 7 2007 14:00:00 Mar 12 2007</code>	Specify the time period during which authentication key string Earth can be received. In this case, key string Earth can be received from noon of March 7 to 2 pm March 12, 2007.
<code>awplus(config-keychain-key)#</code>	
<code>send-lifetime 12:00:00 Mar 7 2007 12:00:00 Mar 12 2007</code>	Specify the time period during which authentication key string Earth can be send. In this case, key string Secret can be received from noon of March 7 to noon of March 12, 2007.

Switch 2(Continued)

<code>awplus(config-keychain-key)#</code>	
<code>end</code>	Enter Privileged Exec mode.
<code>awplus#</code>	
<code>configure terminal</code>	Enter the Configure mode.
<code>awplus(config)#</code>	
<code>interface vlan2</code>	Specify vlan2 as the VLAN interface you want to configure on Switch 2.
<code>awplus(config-if)#</code>	
<code>ip rip authentication key-chain MOON</code>	Enable RIPv2 authentication on the <code>vlan2</code> interface and specify the key chain <code>MOON</code> to be used for authentication.
<code>awplus(config-if)#</code>	
<code>ip rip authentication mode md5</code>	Specify the md5 authentication mode to be used for RIP packets.

Commands Used

- key chain
- key-string
- accept-lifetime
- send-lifetime
- ip rip authentication key-chain
- ip rip authentication mode

Validation Commands

- show ip rip
- show running-config
- show ip protocols rip
- show ip rip interface

Chapter 34: RIP Commands

Command List	34.2
accept-lifetime	34.2
clear ip rip route	34.4
debug rip	34.5
default-information originate (RIP)	34.6
default-metric (RIP)	34.7
distance (RIP)	34.8
distribute-list (RIP)	34.9
ip rip authentication key-chain	34.10
ip rip authentication mode	34.13
ip rip authentication string	34.16
ip rip receive-packet	34.17
ip rip receive version	34.18
ip rip send-packet	34.19
ip rip send version	34.20
ip rip send version 1-compatible	34.21
ip rip split-horizon	34.22
key	34.23
key chain	34.24
key-string	34.25
maximum-prefix	34.26
neighbor (RIP)	34.27
network (RIP)	34.28
offset-list (RIP)	34.29
passive-interface (RIP)	34.30
recv-buffer-size (RIP)	34.30
redistribute (RIP)	34.31
restart rip graceful	34.32
rip restart grace-period	34.32
route (RIP)	34.33
router rip	34.34
send-lifetime	34.35
show debugging rip	34.36
show ip protocols rip	34.36
show ip rip	34.37
show ip rip database	34.37
show ip rip interface	34.38
timers (RIP)	34.39
undebug rip	34.40
version	34.41

Command List

This chapter provides an alphabetical reference of commands used to configure RIP. For more information, see [Chapter 33, RIP Configuration](#).

accept-lifetime

Use this command to specify the time period during which the authentication key on a key chain is received as valid.

Use the no accept-lifetime command to remove a specified time period for an authentication key on a key chain as set previously with the accept-lifetime command.

Syntax `accept-lifetime <start-date>{<end-date>|duration <seconds>|infinite}`
`no accept-lifetime`

Parameter	Description
<code><start-date></code>	Specifies the start period - time and date in the format DD MMM YYYY or MMM DD YYYY: <code><hh:mm:ss> {<day> <month> <year> <month> <day> <year>}</code>
<code><hh:mm:ss></code>	Time of the day when accept-lifetime starts, in hours, minutes and seconds
<code><day></code>	<code><1-31></code> Specifies the day of the month to start.
<code><month></code>	Specifies the month of the year to start (the first three letters of the month, for example, Jan).
<code><year></code>	<code><1993-2035></code> Specifies the year to start.
<code><end-date></code>	Specifies the end period - time and date in the format DD MMM YYYY or MMM DD YYYY: <code><hh:mm:ss> {<day> <month> <year> <month> <day> <year>}</code>
<code><hh:mm:ss></code>	Time of the day when lifetime expires, in hours, minutes and seconds.
<code><day></code>	<code><1-31></code> Specifies the day of the month to expire.
<code><month></code>	Specifies the month of the year to expire (the first three letters of the month, for example, Feb).
<code><year></code>	<code><1993-2035></code> Specifies the year to expire.
<code><seconds></code>	<code><1-2147483646></code> Duration of the key in seconds.
<code>infinite</code>	Never expires.

Mode Keychain-key mode

Examples The following examples show the setting of accept-lifetime for `key1` on the key chain named `mychain`.

```
awplus# configure terminal
awplus(config)# key chain mychain
awplus(config-keychain)# key 1
awplus(config-keychain-key)# accept-lifetime 03:03:01 Dec 3
                             2007 04:04:02 Oct 6 2008
```

or:

```
awplus# configure terminal
awplus(config)# key chain mychain
awplus(config-keychain)# key 1
awplus(config-keychain-key)# accept-lifetime 03:03:01 3 Dec
                             2007 04:04:02 6 Oct 2008
```

Related Commands [key](#)
[key-string](#)
[key chain](#)
[send-lifetime](#)

clear ip rip route

Use this command to clear specific data from the RIP routing table.

Syntax `clear ip rip route {<ip-dest-network/prefix-length>|static|connected|rip|ospf|bgp|all}`

Parameter	Description
<code><ip-dest-network/prefix-length></code>	Removes entries which exactly match this destination address from RIP routing table. Enter the IP address and prefix length of the destination network.
<code>static</code>	Removes static entries from the RIP routing table.
<code>connected</code>	Removes entries for connected routes from the RIP routing table.
<code>rip</code>	Removes only RIP routes from the RIP routing table.
<code>ospf</code>	Removes only OSPF routes from the RIP routing table.
<code>bgp</code>	Removes only BGP routes from the RIP routing table.
<code>all</code>	Clears the entire RIP routing table.

Mode Privileged Exec mode

Usage Using this command with the `all` parameter, clears the RIP table of all the routes.

Examples

```
awplus# clear ip rip route 10.0.0.0/8
```

```
awplus# clear ip rip route ospf
```

debug rip

Use this command to specify the options for the displayed debugging information for RIP events and RIP packets.

Use the no parameter with this command to disable the specified debug option.

Syntax `debug rip {events|nsm|<packet>|all}`
`no debug rip {events|nsm|<packet>|all}`

Parameter	Description
events	RIP events debug information is displayed.
nsm	RIP and NSM communication is displayed
<packet>	packet [recv send] [detail] Specifies RIP packets only
recv	Specifies that information for received packets be displayed.
send	Specifies that information for sent packets be displayed.
detail	Displays detailed information for the sent or received packet.
all	Displays all RIP debug information.

Default Disabled

Mode Privileged Exec mode and Global Configuration mode

Examples The following example displays information about the RIP packets that are received and sent out from the device.

```
awplus# debug rip packet
```

default-information originate (RIP)

Use this command to generate a default route into the Routing Information Protocol (RIP).

Use the no parameter with this command to disable this feature.

Syntax default-information originate
 no default-information originate

Default Disabled

Mode Router mode

Examples

```
awplus# configure terminal
awplus(config)# router rip
awplus(config-router)# default-information originate
```

default-metric (RIP)

Use this command to specify the metrics to be assigned to redistributed routes.

Use the no parameter with this command to reset the metric back to its default value (1).

Syntax

```
default-metric <metric>
no default-metric <metric>
no default-metric
```

Parameter	Diagnostic
<metric>	<1-16> Specifies the default metric.

Default By default, the metric value is set to 1.

Mode Router mode

Usage This command is used with the [redistribute \(RIP\)](#) command to make the routing protocol use the specified metric value for all redistributed routes. Default metric is useful in redistributing routes with incompatible metrics. Every protocol has different metrics and can not be compared directly. Default metric provides the standard to compare. All routes that are redistributed will use the default metric

Examples This example assigns the cost of 10 to the OSPF routes which are redistributed into RIP.

```
awplus# configure terminal
awplus(config)# router rip
awplus(config-router)# redistribute ospf
awplus(config-router)# default-metric 10
```

distance (RIP)

This command sets the administrative distance for RIP routes. Your device uses this value to select between two or more routes to the same destination from two different routing protocols. The route with the smallest administrative distance value is added to the Forwarding Information Base (FIB). See [“Administrative Distance” on page 31.4](#) for more information.

The no form sets the administrative distance for the RIP route to the default of 120.

Syntax `distance <1-255> {<ip-addr/prefix-length> [<access-list>]}`
`no distance <1-255> {<ip-addr/prefix-length> [<access-list>]}`

Parameter	Description
<code><1-255></code>	The administrative distance value you are setting for this RIP route.
<code><ip-addr/prefix-length></code>	The network prefix that you are changing the administrative distance for. Enter an IPv4 address and prefix length.
<code><access-list></code>	Specifies the access-list name. This access list specifies which routes within the network <code><ip-address/m></code> this command applies to.

Mode Router mode

Examples To set the administrative distance to 8 for the RIP routes within the 10.0.0.0/8 network that match the access-list `mylist`, use the commands:

```
awplus# configure terminal
awplus(config)# router rip
awplus(config-router)# distance 8 10.0.0.0/8 mylist
```

To set the administrative distance to the default of 120 for the RIP routes within the 10.0.0.0/8 network that match the access-list `mylist`, use the commands:

```
awplus# configure terminal
awplus (config)# router rip
awplus(config-router)# no distance 8 10.0.0.0/8 mylist
```


distribute-list (RIP)

Use this command to filter incoming or outgoing route updates using the access-list or the prefix-list.

Use the no parameter with this command to disable this feature.

Syntax `distribute-list {<access-list> | prefix <prefix-list>} {in|out} [<interface>]`

`no distribute-list {<access-list> | prefix <prefix-list>} {in|out} [<interface>]`

Parameter	Description
<code><access-list></code>	Specifies the IPv4 access-list number or name to use
<code>prefix</code>	Filter prefixes in routing updates
<code><prefix-list></code>	Specifies the name of the IPv4 prefix-list to use
<code>in</code>	Filter incoming routing updates
<code>out</code>	Filter outgoing routing updates
<code><interface></code>	The interface on which distribute-list applies. For instance: ■ <code>vlan2</code>

Default Disabled

Mode Router mode

Usage Filter out incoming or outgoing route updates using access-list or prefix-list. If you do not specify the name of the interface, the filter will be applied to all interfaces.

Example

```
awplus# configure terminal
awplus(config)# router rip
awplus(config-router)# distribute-list prefix myfilter in
vlan1
```

Related Commands [access-list \(IP\)](#)
[ip prefix-list](#)

ip rip authentication key-chain

Use this command to enable RIPv2 authentication on an interface and specify the name of the key chain to be used.

Use the `no` parameter with this command to disable this function.

Syntax `ip rip authentication key-chain <key-chain-name>`
`no ip rip authentication key-chain`

Parameter	Description
<code><key-chain-name></code>	Specify the name of the key chain. This is an alpha-numeric string, but it cannot include spaces

Mode Interface mode for VLAN interfaces only.

Usage This command can only be used on VLAN interfaces. Use this command to perform authentication on the interface. Not configuring the key chain results in no authentication at all.

The AlliedWare Plus™ implementation provides the choice of configuring authentication for single key or multiple keys at different times. Use the [ip rip authentication string](#) command for single key authentication. Use the [ip rip authentication key-chain](#) command for multiple keys authentication. See [Chapter 33, RIP Configuration](#) for illustrated RIP configuration examples.

For multiple keys authentication, use the following steps to configure a route to enable RIPv2 authentication using multiple keys at different times:

Step 1: Define a key chain:

In the Configure mode, identify a key chain with a key chain name using the following command:

```
awplus# configure terminal
awplus(config)# key chain <key-chain-name>
```

where `<key-chain-name>` is the name of the chain to manage, and should not include spaces.

Step 2: Define the key or keys:

In the Keychain mode, specify a key on this key chain using the following command:

```
awplus(config-keychain)# key <keyid>
```

where `<keyid>` (a decimal number in the range 1 to 2147483647) is the Key Identifier number.

Step 3: Define the authentication string or password:

In the Keychain-key mode, define the password used by a key, using the following command:

```
awplus(config-keychain-key)# key-string <key-password>
```

where *<key-password>* is a string of characters that can contain spaces, to be used as a password by the key.

Step 4: Set key management options:

This step can be performed at this stage or later when multiple keys are used. The options are configured in the keychain-key command mode.

Set the time period during which the authentication key on a key chain is received as valid, using the [accept-lifetime](#) command:

```
awplus(config-keychain-key)# accept-lifetime <START> <END>
```

where *<START>* and *<END>* are the beginning and end of the time period.

Set the time period during which the authentication key on a key chain can be sent, using the [send-lifetime](#) command:

```
awplus(config-keychain-key)# send-lifetime <START> <END>
```

where *<START>* and *<END>* are the beginning and end of the time period.

Step 5: Enable authentication on an interface:

In the Interface mode, enable authentication on `vlan3` and specify the key chain to be used, using the following command:

```
awplusawpluls# configure terminal
awplus(config)# interface vlan3
awplus(config-if)# ip rip authentication key-chain <key-chain-name>
```

where *<key-chain-name>* is a set of valid authentication keys.

Step 6: Specify the mode of authentication for the given interface:

In the Interface mode, specify whether the interface uses text or MD5 authentication using:

```
awplus(config-if)# ip rip authentication mode {md5|text}
```

Example In the following sample multiple keys authentication RIP configuration, a password *toyota* is set for key 1 in key chain *cars*. Authentication is enabled on *vlan1* and the authentication mode is set to MD5:

```
awplus# configure terminal
awplus(config)# key chain cars
awplus(config-keychain)# key 1
awplus(config-keychain-key)# key-string toyota
awplus(config-keychain-key)# accept-lifetime 10:00:00 Apr 08
                             2008 duration 43200
awplus(config-keychain-key)# send-lifetime 10:00:00 Apr 08
                             2008 duration 43200
awplus(config-keychain-key)# exit
awplus(config-keychain)# exit
awplus(config)# interface vlan1
awplus(config-if)# ip rip authentication key-chain
                    cars
awplus(config-if)# ip rip authentication mode md5
awplus(config-if)# exit
awplus(config)# exit
awplus#
```

Example In the following example, interface *vlan23* is configured to use key-chain authentication with the keychain *mykey*. See the [key](#) command for a description of how a key chain is created.

```
awplus# configure terminal
awplus(config)# interface vlan23
awplus(config-if)# ip rip authentication key-chain mykey
```

Related Commands

- [accept-lifetime](#)
- [send-lifetime](#)
- [ip rip authentication mode](#)
- [ip rip authentication string](#)
- [key](#)
- [key chain](#)

ip rip authentication mode

Use this command to specify the type of authentication mode used for RIP v2 packets.

Use the `no ip rip authentication mode` command to restore clear text authentication.

Syntax `ip rip authentication mode {md5|text}`
`no ip rip authentication mode {md5|text}`

Parameter	Description
md5	Uses the keyed MD5 authentication algorithm.
text	Specifies clear text or simple password authentication.

Default Text authentication is enabled

Mode Interface mode for VLAN interfaces only.

Usage This command can only be configured on VLAN interfaces. The AlliedWare Plus™ implementation provides the choice of configuring authentication for single key or multiple keys at different times. Use the [ip rip authentication string](#) command for single key authentication. Use the [ip rip authentication key-chain](#) command for multiple keys authentication. See [Chapter 33, RIP Configuration](#) for illustrated RIP configuration examples.

Use the following steps to configure a route to enable RIPv2 authentication using a single key or password:

Step 1: Define the authentication string or password

In the Interface mode, specify the authentication string or password used by the key, using the following command:

```
awplus(config-if)# ip rip authentication string <auth-string>
```

where `<auth-string>` is the authentication string or password and it can include spaces.

Step 2: Specify the mode of authentication for the given interface:

In the Interface mode, specify if the interface will use text or MD5 authentication, using the following command:

```
awplus(config-if)# ip rip authentication mode {md5|text}
```

See the sample below to specify *mykey* as the authentication string with MD5 authentication:

```
awplus# configure terminal
awplus(config)# interface vlan1
awplus(config-if)# ip rip authentication string mykey
awplus(config-if)# ip rip authentication mode md5
```

For multiple keys authentication, use the following steps to configure a route to enable RIPv2 authentication using multiple keys at different times:

Step 1: Define a key chain:

In the Configure mode, identify a key chain with a key chain name using the following command:

```
awplus(config)# key chain <key-chain-name>
```

where *<key-chain-name>* is the name of the chain to manage, a text string with no spaces.

Step 2: Define the key or keys:

In the Keychain mode, specify a key on this key chain using the following command:

```
awplus(config-keychain)# key <keyid>
```

where *<keyid>* (a decimal number in the range 1 to 2147483647) is the Key Identifier number.

Step 3: Define the authentication string or password:

In the Keychain-key mode, define the password used by a key, using the following command:

```
awplus(config-keychain-key)# key-string <key-password>
```

where *<key-password>* is a string of characters that can include spaces, to be used as a password by the key.

Step 4: Set key management options:

This step can be performed at this stage or later when multiple keys are used. The options are configured in the keychain-key command mode.

Set the time period during which the authentication key on a key chain is received as valid, using the [accept-lifetime](#) command:

```
awplus(config-keychain-key)# accept-lifetime START END
```

where *START* and *END* are the beginning and end of the time period.

Set the time period during which the authentication key on a key chain can be sent, using the [send-lifetime](#) command:

```
awplus(config-keychain-key)# send-lifetime START END
```

where *START* and *END* are the beginning and end of the time period.

Step 5: Enable authentication on an interface:

In the Interface mode, enable authentication on an interface and specify the key chain to be used, using the following command:

```
awplus(config-if)# ip rip authentication key-chain <key-chain-name>
```

where `<key-chain-name>` is a set of valid authentication keys, as defined in Step 1.

Step 6: Specify the mode of authentication for the given interface:

In the Interface mode, specify whether the interface uses text or MD5 authentication using:

```
awplus(config-if)# ip rip authentication mode {md5|text}
```

Example In the following sample multiple keys authentication RIP configuration, a password *toyota* is set for key 1 in key chain cars. Authentication is enabled on `vlan1` and the authentication mode is set to MD5:

```
awplus# configure terminal
awplus(config)# key chain cars
awplus(config-keychain)# key 1
awplus(config-keychain-key)# key-string toyota
awplus(config-keychain-key)# accept-lifetime 10:00:00 Apr 08
                             2008 duration 43200
awplus(config-keychain-key)# send-lifetime 10:00:00 Apr 08 2008
                             duration 43200
awplus(config-keychain-key)# exit
awplus(config-keychain)# exit
awplus(config)# interface vlan1
awplus(config-if)# ip rip authentication key-chain
                    cars
awplus(config-if)# ip rip authentication mode md5
awplus(config-if)# exit
awplus(config)# exit
awplus#
```

Example The following example shows md5 authentication configured on `vlan2`, ensuring authentication of rip packets received on this interface.

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip rip authentication mode md5
```

Related Commands [ip rip authentication string](#)
[ip rip authentication key-chain](#)

ip rip authentication string

Use this command to specify the authentication string or password used by a key.

Use the no parameter with this command to remove the authentication string.

Syntax `ip rip authentication string <auth-string>`
`no ip rip authentication string <auth-string>`

Parameter	Description
<code><auth-string></code>	The authentication string or password used by a key. It is an alpha-numeric string and can include spaces.

Mode Interface mode for VLAN interfaces only.

Usage This command can only be configured on VLAN interfaces. The AlliedWare Plus™ implementation provides the choice of configuring authentication for single key or multiple keys at different times. Use this command to specify the password for a single key on an interface. Use the [ip rip authentication key-chain](#) command for multiple keys authentication. See [Chapter 33, RIP Configuration](#) for further RIP configuration examples.

Use the following steps to configure a route to enable RIPv2 authentication using a single key or password:

Step 1: Define the authentication string or password:

In the Interface mode, specify the authentication string or password used by the key, using the following commands to configure the authentication string on `vlan3`:

```
awplus# configure terminal
awplus(config)# interface vlan3
awplus(config-if)# ip rip authentication string <auth-string>
```

where `<auth-string>` is the authentication string or password.

Step 2: Specify the mode of authentication for the given interface:

In the Interface mode, specify if the interface will use text or MD5 authentication, using the following command:

```
awplus(config-if)# ip rip authentication mode {md5|text}
```

Example See the sample below to specify `mykey` as the authentication string with MD5 authentication:

```
awplus# configure terminal
awplus(config)# interface vlan1
awplus(config-if)# ip rip authentication string mykey
awplus(config-if)# ip rip authentication mode md5
```


Example In the following example, the interface `vlan2` is configured to have an authentication string as `guest`. Any received RIP packet in that interface should have the same string as password.

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip rip authentication string guest
```

Related commands [ip rip authentication key-chain](#)
[ip rip authentication mode](#)

ip rip receive-packet

Use this command to configure the interface to enable the reception of RIP packets.

Use the `no` parameter with this command to disable this feature.

Syntax `ip rip receive-packet`
`no ip rip receive-packet`

Default Receive-packet is enabled

Mode Interface mode for VLAN interfaces only.

Usage This command can only be configured on VLAN interfaces.

Example This example shows packet receiving being turned on for interface `vlan3`.

```
awplus# configure terminal
awplus(config)# interface vlan3
awplus(config-if)# ip rip receive-packet
```

Related Commands [ip rip send-packet](#)

ip rip receive version

Use this command to specify the version of RIP packets accepted on an interface and override the setting of the version command.

Use the no form of this command to use the setting specified by the version command.

Syntax `ip rip receive version {[1][2]}`
`no ip rip receive version`

Parameter	Description
1	Specifies acceptance of RIP version 1 packets on the interface.
2	Specifies acceptance of RIP version 2 packets on the interface.

Default Version 2

Mode Interface mode for VLAN interfaces only.

Usage This command can only be configured on VLAN interfaces. This command applies to a specific VLAN interface and overrides any the version specified by the version command.

Example In the following example, interface `vlan3` is configured to receive both RIP version 1 and 2 packets.

```
awplus# configure terminal
awplus(config)# interface vlan3
awplus(config-if)# ip rip receive version 1 2
```

Related Commands [version](#)

ip rip send-packet

Use this command to enable sending RIP packets through the current interface.

Use the no parameter with this command to disable this feature.

Syntax `ip rip send-packet`
 `no ip rip send-packet`

Default Send packet is enabled

Mode Interface mode for VLAN interfaces only.

Usage This command can only be configured on VLAN interfaces.

Example This example shows packet sending being turned on for interface `vlan4`.

```
awplus# configure terminal
awplus(config)# interface vlan4
awplus(config-if)# ip rip send-packet
```

Related Commands [ip rip receive-packet](#)

ip rip send version

Use this command to specify the version of RIP packets sent on an interface and override the setting of the version command.

Use the no form of this command to use the setting specified by the version command.

Syntax `ip rip send version {[1][2]}`
`no ip rip send version`

Parameter	Description
1	Specifies sending of RIP version 1 packets out of an interface.
2	Specifies sending of RIP version 2 packets out of an interface.

Default Version 2

Mode Interface mode for VLAN interfaces only.

Usage This command can only be configured on VLAN interfaces. This command applies to a specific interface and overrides any the version specified by the version command.

Example In the following example, interface `vlan4` is configured to send both RIP version 1 and 2 packets.

```
awplus# configure terminal
awplus(config)# interface vlan4
awplus(config-if)# ip rip send version 1 2
```

ip rip send version 1-compatible

Use this command to send RIP version 1 compatible packets from a version 2 RIP interface. This mechanism causes version 2 RIP to broadcast the packets instead of multicasting them.

Use the no parameter with this command to use the global RIP version control rules.

Syntax `ip rip send version 1-compatible`

Default Disabled

Mode Interface mode for VLAN interfaces only.

Usage This command can only be configured on VLAN interfaces.

Example In the following example, interface `vlan2` is configured to send RIP version 1-compatible packets; so it broadcasts both RIP version 1 and 2 packets.

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip rip send version 1-compatible
```

ip rip split-horizon

Use this command to perform the split-horizon action on the interface. The default is split-horizon poisoned.

Use the no parameter with this command to disable this function.

Syntax `ip rip split-horizon [poisoned]`
`no ip rip split-horizon`

Parameter	Description
poisoned	Performs split-horizon with poisoned reverse.

Default Split horizon poisoned is the default.

Mode Interface mode for VLAN interfaces only.

Usage This command can only be configured on VLAN interfaces. Use this command to avoid including routes in updates sent to the same gateway from which they were learned. Using the split horizon command omits routes learned from one neighbor, in updates sent to that neighbor. Using the poisoned parameter with this command includes such routes in updates, but sets their metrics to infinity. Thus, advertising that these routes are not reachable.

Example

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip rip split-horizon poisoned
```

key

Use this command to manage, add and delete authentication keys in a key-chain.

Use the no key command to delete the authentication key.

Syntax `key <keyid>`
`no key <keyid>`

Parameter	Description
<keyid>	<0-2147483647> Key identifier number

Mode Keychain mode

Usage This command allows you to enter the keychain-key mode where a password can be set for the key.

Example The following example configures a key number 1 and shows the change into a keychain-key command mode prompt.

```
awplus# configure terminal
awplus(config)# key chain mychain
awplus(config-keychain)# key 1
awplus(config-keychain-key)#
```

Related Commands `key chain`
`key-string`
`accept-lifetime`
`send-lifetime`

key chain

Use this command to enter the key chain management mode and to configure a key chain with a key chain name. Use the no parameter on this command to remove the key chain and all configured keys.

Syntax `key chain <key-chain-name>`
`no key chain <key-chain-name>`

Parameter	Description
<code><key-chain-name></code>	Specify the name of the key chain to manage.

Mode Global Configuration mode

Usage This command allows you to enter the keychain mode from which you can specify keys on this key chain.

Example The following example shows the creation of a key chain named `mychain` and the change into keychain mode prompt.

```
awplus# configure terminal
awplus(config)# key chain mychain
awplus(config-keychain)#
```

Related Commands `key`
 `key-string`
 `accept-lifetime`
 `send-lifetime`

key-string

Use this command to define the password to be used by a key. Use the no parameter to remove a password.

Syntax `key-string <key-password>`
`no key-string <key-password>`

Parameter	Description
<code><key-password></code>	A string of characters to be used as a password by the key.

Mode Keychain-key mode

Usage Use this command to specify passwords for different keys.

Example In the following example, the password for `key1` in the key chain named `mychain` is set to password prime.

```
awplus# configure terminal
awplus(config)# key chain mychain
awplus(config-keychain)# key 1
awplus(config-keychain-key)# key-string prime
```

Related Commands `key`
`key chain`
`accept-lifetime`
`send-lifetime`

maximum-prefix

Use this command to configure the maximum number of RIP routes stored in the routing table.

Use the no parameter with this command to disable all limiting of the number of RIP routes stored in the routing table.

Syntax `maximum-prefix <maxprefix> [<threshold>]`
`no maximum-prefix`

Parameter	Description
<code><maxprefix></code>	<code><1-65535></code> The maximum number of RIP routes allowed.
<code><threshold></code>	<code><1-100></code> Percentage of maximum routes to generate a warning. The default threshold is 75%.

Mode Router mode

Examples

```
awplus# configure terminal
awplus(config)# router rip
awplus(config-router)# maximum-prefix 150
```

neighbor (RIP)

Use this command to specify a neighbor router. It is used for each router to which you wish to send unicast RIP updates.

Use the `no` parameter with this command to stop sending unicast updates to the specific router.

Syntax `neighbor <ip-address>`
`no neighbor <ip-address>`

Parameter	Description
<code><ip-address></code>	The IP address of a neighboring router with which the routing information will be exchanged.

Default Disabled

Mode Router mode

Usage Use this command to exchange nonbroadcast routing information. It can be used multiple times for additional neighbors.

The [passive-interface \(RIP\)](#) command disables sending routing updates on an interface. Use the `neighbor` command in conjunction with the [passive-interface \(RIP\)](#) to send routing updates to specific neighbors.

Example

```
awplus# configure terminal
awplus(config)# router rip
awplus(config-router)# passive-interface vlan1
awplus(config-router)# neighbor 1.1.1.1
```

Related Commands [passive-interface \(RIP\)](#)

network (RIP)

Use this command to specify a network or VLAN as one that runs Routing Information Protocol (RIP).

Use the no parameter with this command to remove the specified network or VLAN as one that runs RIP.

Syntax network {<network-address> [/<subnet-mask>] | <vlan-name>}
no network {<network-address> [/<subnet-mask>] | <vlan-name>}

Parameter	Description
<network-address> [/<subnet-mask>]	Specifies the network address to run RIP. Entering a subnet mask for the network address is optional. Note that a subnet mask for a network address is shown in the running-config if a subnet mask is not specified for a network address using this command.
<vlan-name>	Specify a VLAN name with up to 32 alphanumeric characters to run RIP.

Default Disabled

Mode Router mode and Address Family mode

Usage Use this command to specify networks, or VLANs, to which routing updates will be sent and received. The connected routes corresponding to the specified network, or VLANs, will be automatically advertised in RIP updates. RIP updates will be sent and received within the specified network or VLAN.

Example

```
awplus# configure terminal
awplus(config)# router rip
awplus(config-router)# network 10.0.0.0/8
awplus(config-router)# network vlan2
```

Related Commands show ip rip
show running-config
clear ip rip route

offset-list (RIP)

Use this command to add an offset to in and out metrics to routes learned through RIP.

Use the no parameter with this command to remove the offset list.

Syntax `offset-list <access_list> {in|out} <offset> [<interface>]`
`no offset-list <access_list> {in|out} <offset> [<interface>]`

Parameter	Description
<code><access_list></code>	Specifies the access-list number or names to apply.
<code>in</code>	Indicates the access list will be used for metrics of incoming advertised routes.
<code>out</code>	Indicates the access list will be used for metrics of outgoing advertised routes.
<code><offset></code>	<code><0-16></code> Specifies that the offset is used for metrics of networks matching the access list.
<code><interface></code>	An alphanumeric string that specifies the interface to match.

Default The default `offset` value is the metric value of the interface over which the updates are being exchanged.

Mode Router mode and Address Family mode

Usage Use this command to specify the offset value that is added to the routing metric. When the networks match the access list the offset is applied to the metrics. No change occurs if the offset value is zero.

Example In this example the router examines the RIP updates being sent out from interface `vlan2` and adds 5 hops to the routes matching the ip addresses specified in the access list 1.

```
awplus# configure terminal
awplus(config)# router rip
awplus(config-router)# offset-list 1 in 5 vlan2
```

Related Commands [access-list \(standard\)](#)
[access-list \(extended\)](#)

passive-interface (RIP)

Use this command to block RIP broadcasts on the VLAN interface.

Use the no parameter with this command to disable this function

Syntax `passive-interface <interface>`
`no passive-interface <interface>`

Parameter	Description
<code><interface></code>	Specifies the interface name.

Default Disabled

Mode Router mode

Usage This command can only be configured for VLAN interfaces.

Example

```
awplus# configure terminal
awplus(config)# router rip
awplus(config-router)# passive-interface vlan20
```

Related Commands [show ip rip](#)

recv-buffer-size (RIP)

Use this command to run-time configure the RIP UDP (User Datagram Protocol) receive-buffer size to improve UDP reliability by avoiding UDP receive buffer overrun.

Use the no parameter with this command to reset the configured RIP UDP receive-buffer size to the system default value (196608 bits).

Syntax `recv-buffer-size <8192-2147483647>`
`no recv-buffer-size`

Mode Router mode

Default 196608 bits system default value when reset using the no recv-buffer-size command.

Example

```
awplus# configure terminal
awplus(config)# router rip
awplus(config-router)# recv-buffer-size 23456789
```

redistribute (RIP)

Use this command to redistribute information from other routing protocols into RIP.

Using the no parameter with this command will disable the specified redistribution. The parameters metric and routemap may be used on this command, but have no effect.

Syntax `redistribute {connected|static|ospf|bgp} [metric <0-16>] [routemap <routemap>]`

`no redistribute {connected|static|ospf|bgp} [metric] [routemap]`

Parameter	Description
metric	Specifies the metric value to be applied to the redistributed routes
<0-16>	Metric value
routemap	route-map WORD Specifies route-map that controls how routes are redistributed
<routemap>	The name of the route map
connected	redistribute from connected routes
static	redistribute from static routes
ospf	redistribute from Open Shortest Path First (OSPF)
bgp	redistribute from Border Gateway Protocol (BGP)

Mode Router mode

Example

```
awplus# configure terminal
awplus(config)# router rip
awplus(config-router)# redistribute static metric 15 route-map
Chicago
```

restart rip graceful

Use this command to force the RIP process to restart.

Syntax `restart rip graceful [grace-period <1-65535>]`

Mode Privileged Exec mode

Usage After this command is executed, the RIP process immediately shuts down. It notifies the system that RIP has performed a graceful shutdown. Routes that have been installed into the route table by RIP are preserved until the specified grace-period expires.

- When a `restart rip graceful` command is issued, the RIP configuration is reloaded from the last saved configuration. Ensure you first issue the command `copy running-config startup-config`.

Example

```
awplus# copy running-config startup-config
awplus# restart rip graceful grace-period 100
```

rip restart grace-period

Use this command to change the grace period of RIP graceful restart.

Use the `no` parameter with this command to disable this function.

Syntax `rip restart grace-period <1-65535>`
`no rip restart grace-period <1-65535>`

Mode Global Configuration mode

Usage Use this command to enable the Graceful Restart feature on the RIP process. Entering this command configures a grace period for RIP.

Example

```
awplus# configure terminal
awplus(config)# rip restart grace-period 200
```


route (RIP)

Use this command to configure static RIP routes.

Use the no parameter with this command to disable this function.

Syntax `route <ip-addr/prefix-length>`
`no route <ip-addr/prefix-length>`

Parameter	Description
<code><ip-addr/prefix-length></code>	The IPv4 address and prefix length.

Default No static RIP route is added by default.

Mode Router mode

Usage Use this command to add a static RIP route. After adding the RIP route, the route can be checked in the RIP routing table.

Example

```
awplus# configure terminal
awplus(config)# router rip
awplus(config-router)# route 1.2.3.4/8
```

Related Commands `show ip rip`
`clear ip rip route`

router rip

Use this global command to enter Router Configuration mode to enable the RIP routing process.

Use the no parameter with this command to disable the RIP routing process.

Syntax router rip
 no router rip

Mode Global Configuration mode

Example This command is used to begin the RIP routing process:

```
awplus# configure terminal
awplus(config)# router rip
awplus(config-router)# version 1
awplus(config-router)# network 10.10.10.0/24
awplus(config-router)# network 10.10.11.0/24
awplus(config-router)# neighbor 10.10.10.10
```

Related Commands network (RIP)
 version

send-lifetime

Use this command to specify the time period during which the authentication key on a key chain can be sent.

Syntax `send-lifetime <start-date>{<end-date>|duration <seconds>|infinite}`
`no send-lifetime`

Parameter	Description
<code><start-date></code>	Specifies the start period - time and date in the format DD MMM YYYY or MMM DD YYYY: <code><hh:mm:ss> {<day> <month> <year> <month> <day> <year>}</code>
<code><hh:mm:ss></code>	Time of the day when send-lifetime starts, in hours, minutes and seconds
<code><day></code>	<code><1-31></code> Specifies the day of the month to start.
<code><month></code>	Specifies the month of the year to start (the first three letters of the month, for example, Jan).
<code><year></code>	<code><1993-2035></code> Specifies the year to start.
<code><end-date></code>	Specifies the end period - time and date in the format DD MMM YYYY or MMM DD YYYY: <code><hh:mm:ss> {<day> <month> <year> <month> <day> <year>}</code>
<code><hh:mm:ss></code>	Time of the day when lifetime expires, in hours, minutes and seconds.
<code><day></code>	<code><1-31></code> Specifies the day of the month to expire.
<code><month></code>	Specifies the month of the year to expire (the first three letters of the month, for example, Feb).
<code><year></code>	<code><1993-2035></code> Specifies the year to expire.
<code><seconds></code>	<code><1-2147483646></code> Duration of the key in seconds.
<code>infinite</code>	Never expires.

Mode Keychain-key mode

Example The following example shows the setting of send-lifetime for `key1` on the key chain named `mychain`.

```
awplus# configure terminal
awplus(config)# key chain mychain
awplus(config-keychain)# key 1
awplus(config-keychain-key)# send-lifetime 03:03:01 Jan 3 2004
                                04:04:02 Dec 6 2006
```

Related Commands [key](#)
[key-string](#)

key chain
accept-lifetime

show debugging rip

Use this command to display the RIP debugging status for these debugging options: nsm debugging, RIP event debugging, RIP packet debugging and RIP nsm debugging.

For information on output options, see [“Controlling “show” command output”](#) on page 1.33.

Syntax show debugging rip

Mode Privileged Exec mode

Usage Use this command to display the debug status of RIP.

Example

```
awplus# show debugging rip
```

show ip protocols rip

Use this command to display RIP process parameters and statistics.

For information on output options, see [“Controlling “show” command output”](#) on page 1.33.

Syntax show ip protocols rip

Mode Privileged Exec mode and Exec mode

Example

```
awplus# show ip protocols rip
```

Output This is an example of the output from the show ip protocols rip command:

```
awplus#show ip protocols rip
Routing Protocol is "rip"
Sending updates every 30 seconds with +/-50%, next due in 12
seconds
Timeout after 180 seconds, garbage collect after 120 seconds
Outgoing update filter list for all interface is not set
Incoming update filter list for all interface is not set
Default redistribution metric is 1
Redistributing: connected static
Default version control: send version 2, receive version 2
Interface          Send Recv  Key-chain
vlan25             2       2
Routing for Networks:
 10.10.0.0/24
Routing Information Sources:
 Gateway          BadPackets BadRoutes  Distance Last Update
Distance: (default is 120)
```

show ip rip

Use this command to show RIP routes.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip rip`

Mode Exec mode and Privileged Exec mode

Example

```
awplus# show ip rip
```

Output The following output displays the RIP routing table with the destination network, nexthop and metric to reach it.

```
awplus#show ip rip
Codes: R - RIP, Rc - RIP connected, Rs - RIP static
       C - Connected, S - Static, O - OSPF, B - BGP
Network      Next Hop Metric From If    Time
C 10.0.1.0/24          1      vlan20
S 10.10.10.0/24        1      vlan20
C 10.10.11.0/24        1      vlan20
S 192.168.101.0/24     1      vlan20
R 192.192.192.0/24     1      --
```

Related Commands [route \(RIP\)](#)
[network \(RIP\)](#)
[clear ip rip route](#)

Equivalent Command [show ip rip database](#)

show ip rip database

Use this command to display information about the RIP database.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip rip database`

Mode Exec mode and Privileged Exec mode

Example

```
awplus# show ip rip database
```

Related Commands [show ip rip](#)

show ip rip interface

Use this command to display information about the RIP interfaces. You can specify an interface name to display information about a specific interface.

For information on output options, see [“Controlling “show” command output” on page 1.33](#).

Syntax `show ip rip interface [<interface>]`

Parameter	Description
<interface>	The interface to display information about. For instance: ■ <code>vlan2</code>

Mode Exec mode and Privileged Exec mode

Example The following is the output from the `show ip rip interface` command. This output shows the RIP related configuration of each IP interface.

```
awplus# show ip rip interface
```

timers (RIP)

Use this command to adjust routing network timers.

Use the no parameter with this command to restore the defaults.

Syntax `timers basic <update> <timeout> <garbage>`
`no timers basic`

Parameter	Description
<code><update></code>	<code><5-2147483647></code> Specifies the period at which RIP route update packets are transmitted. The default is 30 seconds.
<code><timeout></code>	<code><5-2147483647></code> Specifies the routing information timeout timer in seconds. The default is 180 seconds. After this interval has elapsed and no updates for a route are received, the route is declared invalid.
<code><garbage></code>	<code><5-2147483647></code> Specifies the routing garbage collection timer in seconds. The default is 120 seconds.

Default Enabled

Mode Router mode

Usage This command adjusts the RIP timing parameters.

The update timer is the time between sending out updates, that contain the complete routing table, to every neighboring router.

If an update for a given route has not been seen for the time specified by the timeout parameter, that route is no longer valid. However, it is retained in the routing table for a short time, with metric 16, so that neighbors are notified that the route has been dropped.

When the time specified by the garbage parameter expires the metric 16 route is finally removed from the routing table. Until the garbage time expires, the route is included in all updates sent by the router.

All the routers in the network must have the same timers to ensure the smooth operation of RIP throughout the network.

Example

```
awplus# configure terminal
awplus(config)# router rip
awplus(config-router)# timers basic 30 180 120
```

undebg rip

Use this command to disable the options set for debugging information of RIP events, packets and communication between RIP and NSM.

This command has the same effect as the no debug rip command.

Syntax `undebg rip {all|events|nsm|<packet>}`

Parameter	Description
all	Disables all RIP debugging.
events	Disables the logging of RIP events.
nsm	Disables the logging of RIP and NSM communication.
<packet>	packet [recv send] [detail] Disables the debugging of RIP packets.
recv	Disables the logging of received packet information.
send	Disables the logging of sent packet information.
detail	Disables the logging of sent or received RIP packets.

Mode Privileged Exec mode

Example

```
awplus# undebg rip packet
```


version

Use this command to specify a RIP version used globally by the router.

Use the no parameter with this command to restore the default version.

Syntax `version {1|2}`
`no version`

Parameter	Description
1 2	Specifies the version of RIP processing. Default is RIP v2.

Default Version 2

Mode Router mode

Usage RIP can be run in version 1 or version 2 mode. Version 2 has more features than version 1; in particular RIP version 2 supports authentication. Once the rip version is set, RIP packets of that version will be received and sent on all the RIP-enabled interfaces.

The `ip rip receive version` command and the `ip rip send version` command override the value set by this command.

Example

```
awplus# configure terminal
awplus(config)# router rip
awplus(config-router)# version 1
```

Validation Commands `show running-config`

```
awplus# show running-config
```

```
!
router rip
 version 1
!
```

Related Commands `ip rip receive version`
`ip rip send version`

Chapter 35: RIPng Configuration



Introduction.....	35.2
Enabling RIPng.....	35.2
Troubleshooting RIPng Adjacency	35.4


Introduction

This chapter contains a basic RIPng configuration example. To see details on the RIPng commands used in these examples, or to see the outputs of the Validation commands, refer to [Chapter 36, RIPng Commands](#).

Enabling RIPng

This example shows the minimum configuration required for enabling RIPng on an interface. Switch 1 and Switch 2 are two switches connecting to network 3ffe:11::/64.

To enable RIPng, first define the RIPng routing process and then enable RIPng on each interface.



Switch 1

<code>awplus#</code>	
<code>configure terminal</code>	Enter the Configure mode.
<code>awplus(config)#</code>	
<code>interface vlan2</code>	Specify the interface (vlan2) and enter the Interface mode.
<code>awplus(config-if)#</code>	
<code>ipv6 router rip</code>	Enable RIPng routing on interface vlan2.
<code>awplus(config-if)#</code>	
<code>exit</code>	Exit Interface mode and enter Configure mode.
<code>awplus(config)#</code>	
<code>interface vlan3</code>	Specify the interface (vlan3) and enter the Interface mode.
<code>awplus(config-if)#</code>	
<code>ipv6 router rip</code>	Enable RIPng routing on interface vlan3.
<code>awplus(config-if)#</code>	
<code>exit</code>	Exit Interface mode and enter Configure mode.
<code>awplus(config)#</code>	
<code>ipv6 router rip</code>	Define a RIPng routing process and enter Router mode.
<code>awplus(config-router)#</code>	
<code>route 3ffe:11::/64</code>	Define a static RIPng route to connect Switch 1 to Switch 2 using IPv6 network address 3ffe:11::/64

Switch 2

<code>awplus#</code>	
<code>configure terminal</code>	Enter the Configure mode.
<code>awplus(config)#</code>	
<code>interface vlan5</code>	Specify the interface (vlan5) and enter the Interface mode.
<code>awplus(config-if)#</code>	
<code>ipv6 router rip</code>	Enable RIPng routing on interface vlan5
<code>awplus(config-if)#</code>	
<code>exit</code>	Exit Interface mode and enter Configure mode.
<code>awplus(config)#</code>	
<code>interface vlan4</code>	Specify the interface (vlan4) and enter the Interface mode.
<code>awplus(config-if)#</code>	
<code>ipv6 router rip</code>	Enable RIPng routing on interface vlan4.
<code>awplus(config-if)#</code>	
<code>exit</code>	Exit Interface mode and enter Configure mode.
<code>awplus(config)#</code>	
<code>ipv6 router rip</code>	Define a RIPng routing process and enter Router mode.
<code>awplus(config-router)#</code>	
<code>route 3ffe:11::/64</code>	Define a static RIPng route to connect Switch 2 to Switch 1 using IPv6 network address 3ffe:11::/64

Names of Commands Used router ipv6 rip
ipv6 router rip

Validation Commands show ipv6 rip

Troubleshooting RIPng Adjacency

Follow the steps below to troubleshoot RIPng adjacency:

Step 1. Confirm the Interface is not shutdown

<code>awplus#</code>	
<code>configure terminal</code>	Enter the Configure mode.
<code>awplus(config)#</code>	
<code>interface vlan2</code>	Specify the interface (vlan2) and enter the Interface mode.
<code>awplus(config-if)#</code>	
<code>no shutdown</code>	Ensure the interface is not administratively shutdown.
<code>awplus(config-if)#</code>	
<code>exit</code>	Exit Interface mode and enter Configure mode.
<code>awplus(config)#</code>	
<code>exit</code>	Exit Configure mode and return to Privileged Exec mode.
<code>awplus#</code>	
<code>show ipv6 interface brief</code>	Use the show interface command to make sure that the interface is not administratively shutdown.

Step 2. Confirm RIPng is enabled on the interface

<code>awplus#</code>	
<code>configure terminal</code>	Enter the Configure mode.
<code>awplus(config)#</code>	
<code>interface vlan2</code>	Specify the interface (vlan2) and enter the Interface mode.
<code>awplus(config-if)#</code>	
<code>ipv6 router rip</code>	Enable RIPng routing on interface port1.0.1.
<code>awplus(config-if)#</code>	
<code>exit</code>	Exit Interface mode and enter Configure mode.
<code>awplus(config)#</code>	
<code>exit</code>	Exit Configure mode and return to Privileged Exec mode.

Step 2. Confirm RIPng is enabled on the interface

```
awplus#
show ipv6 rip interface vlan2
```

Check the configuration. E.g.:

```
vlan2 is up, line protocol is up
Routing Protocol: RIPng
  Passive interface: Disabled
  Split horizon: Enabled with
  Poisoned Reversed
  IPv6 interface address:
    3ffe:1::10/64
    fe80::204:76ff:fec8:28cc/10
```

Step 3. Check the Interface is not a Passive Interface

```
awplus#
show running-config
```

Check that the interface is not configured as a passive interface.

If it is configured to be passive, this is displayed in the output from the show running config command, e.g.:

```
!
router ipv6 rip
  passive interface vlan2
!
```

```
awplus#
configure terminal
```

Enter the Configure mode.

```
awplus(config)#
router ipv6 rip
```

Enter RIPng Router mode.

```
awplus(config-router)#
no passive interface
port1.0.1
```

Remove the passive interface.

Step 4. Ensure RIPng Advertisements get exchanged

```
awplus#
configure terminal
```

Enter the Configure mode.

```
awplus(config)#
debug ipv6 rip event
```

Check on the interface to make sure that RIPng advertisements are being sent and received.

```
awplus(config)#
debug ipv6 rip packet detail
```

Check on the interface to make sure that RIPng advertisements are being sent and received.

```
awplus(config)#
exit
```

Exit Configure mode to enter Privileged Exec mode.

```
awplus#
terminal monitor
```

View log messages, or use a packet sniffer such as Ethereal or Wireshark, to verify RIPng advertisements.

Chapter 36: RIPng Commands



Introduction.....	36.2
Command List.....	36.2
aggregate-address (RIPng)	36.2
clear ipv6 rip route.....	36.3
debug ipv6 rip.....	36.4
default-information originate (RIPng)	36.5
default-metric (RIPng)	36.6
distribute-list (RIPng).....	36.7
ipv6 rip split-horizon	36.8
ipv6 router rip.....	36.9
neighbor (RIPng).....	36.10
offset-list (RIPng)	36.11
passive-interface (RIPng).....	36.12
recv-buffer-size (RIPng)	36.13
redistribute (RIPng).....	36.14
route (RIPng).....	36.15
router ipv6 rip.....	36.16
show debugging ipv6 rip.....	36.16
show ipv6 protocols rip	36.17
show ipv6 rip.....	36.18
show ipv6 rip database	36.19
show ipv6 rip interface	36.20
timers (RIPng)	36.21
undebug ipv6 rip.....	36.22

Introduction

This chapter contains AlliedWare Plus™ RIPng commands. RIPng (Routing Information Protocol next generation) is an extension of RIPv2 to support IPv6. RFC 2080 specifies RIPng. The differences between RIPv2 and RIPng are:

- RIPng does not support RIP updates authentication
- RIPng does not allow the attachment of arbitrary tags to routes
- RIPng requires the encoding of the next-hop for a set of routes

For more information, see [Chapter 35, RIPng Configuration](#).

Command List

This section provides an alphabetical reference of commands used to configure RIPng for IPv6.

aggregate-address (RIPng)

Use this command to aggregate RIPng routes.

Use the no parameter with this command to disable this feature.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax aggregate-address <ipv6-addr/prefix-length>
 no aggregate-address <ipv6-addr/prefix-length>

Parameter	Description
<ipv6-addr/prefix-length>	Specify the IPv6 Address in the format X:X::X:X/Prefix-Length. The prefix-length is a decimal integer between 1 and 128.

Mode Router mode

Example

```
awplus# configure terminal
awplus(config)# router ipv6 rip
awplus(config-router)# aggregate-address 3ffe:8088::/32
```

clear ipv6 rip route

Use this command to clear specific data from the RIPng routing table.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax `clear ipv6 rip route {<ipv6-addr/prefix-length>|all|connected|rip|static}`

Parameter	Description
<code><ipv6-addr/prefix-length></code>	Specify the IPv6 Address in format <code>X:X::X:X/Prefix-Length</code> . The prefix-length is a decimal integer between 1 and 128. Removes entries which exactly match this destination address from the RIPng routing table.
<code>connected</code>	Removes redistributed connected entries from RIPng routing table.
<code>static</code>	Removes redistributed static entries from the RIPng routing table.
<code>rip</code>	Removes RIPng routes from the RIPng routing table.
<code>all</code>	Clears the entire RIPng routing table.

Mode Privileged Exec mode

Example

```
awplus# clear ipv6 rip route all
awplus# clear ipv6 rip route 3ffe:ffff::/16
```

debug ipv6 rip

Use this command to enable RIPng debugging and specify debugging for RIPng events, RIPng packets, or RIPng communication with NSM processes.

Use the no parameter to disable RIPng debugging.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax `debug ipv6 rip [all|events|nsm|packet [detail]|recv [detail]|
send [detail]]`
`no debug ipv6 rip [all|events|nsm|packet [detail]|recv [detail]|
send [detail]]`

Parameter	Description
all	Displays all RIPng debugging showing RIPng events debug information, RIPng received packets information, and RIPng sent packets information.
events	Displays RIPng events debug information.
nsm	Displays RIPng and NSM communication.
packet	Displays RIPng packets only.
recv	Optional. Displays information for received packets.
send	Optional. Displays information for sent packets.
detail	Optional. Displays detailed information for the sent or received packet.

Default RIPng debugging is disabled by default.

Mode Privileged Exec mode and Global Configuration mode

Example

```
awplus# debug ipv6 rip events  
awplus# debug ipv6 rip packet send detail  
awplus# debug ipv6 rip nsm
```

default-information originate (RIPng)

Use this command to generate a default route into RIPng.

Use the no parameter with this command to disable this feature.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax default-information originate
no default-information originate

Default Disabled

Mode Router mode

Example

```
awplus# configure terminal
awplus(config)# router ipv6 rip
awplus(config-router)# default-information originate
```

default-metric (RIPng)

Use this command to specify the metrics to be assigned to redistributed routes.

Use the no parameter with this command to reset the metric back to its default value (1).

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax default-metric <1-16>
 no default-metric [<1-16>]

Parameter	Description
<1-16>	Metric value.

Default By default, the metric value is set to 1.

Mode Router mode

Usage This command is used with the [redistribute \(RIPng\)](#) command to make the routing protocol use the specified metric value for all redistributed routes. Default metric is useful in redistributing routes with incompatible metrics. Every protocol has different metrics and can not be compared directly. Default metric provides the standard to compare. All routes that are redistributed will use the default metric

Example

```
awplus# configure terminal
awplus(config)# router ipv6 rip
awplus(config-router)# default-metric 8
```

distribute-list (RIPng)

Use this command to filter incoming or outgoing route updates using the access-list or the prefix-list.

Use the no parameter with this command to disable this feature.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax distribute-list [<access-list>|prefix <prefix-list-name>] [in|out]
[<interface>]

no distribute-list [<access-list>|prefix <prefix-list-name>] [in|out]
[<interface>]

Parameter	Description
<access-list>	Optional. Specifies the IPv6 access-list number or name to use.
<prefix-list-name>	Optional. Filter prefixes in routing updates. Specify the name of the IPv6 prefix-list to use.
<interface>	The interface for which distribute-list applies. For instance: ■ vlan2
in	Optional. Filter incoming routing updates.
out	Optional. Filter outgoing routing updates.

Default Disabled

Mode Router mode

Usage Filter out incoming or outgoing route updates using the access-list or the prefix-list. If you do not specify the name of the interface, the filter is applied to all the interfaces.

Example

```
awplus# configure terminal
awplus(config)# router ipv6 rip
awplus(config-router)# distribute-list prefix myfilter in vlan2
```

Related Commands access-list (extended)
access-list (extended)
ipv6 nd prefix

ipv6 rip split-horizon

Use this command to perform the split-horizon action on the interface. The default is split-horizon with poisoned reverse.

Use the no parameter with this command to disable this function.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax `ipv6 rip split-horizon [poisoned]`
`no ipv6 rip split-horizon`

Parameter	Description
split-horizon	Required. Perform split-horizon without poisoned reverse
poisoned	Optional. Performs split-horizon with poisoned reverse.

Default Split-horizon with poisoned reverse is the default.

Mode Interface mode for VLAN interfaces only.

Usage This command can only be configured on VLAN interfaces. Use this command to avoid including routes in updates sent to the same gateway from which they were learned. Using the split horizon command omits routes learned from one neighbor, in updates sent to that neighbor. Using the poisoned parameter with this command includes such routes in updates, but sets their metrics to infinity. Thus, advertising that these routes are not reachable.

Example

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ipv6 rip split-horizon

awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ipv6 rip split-horizon poisoned

awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# no ipv6 rip split-horizon
```

Validation Commands `show running-config`

ipv6 router rip

Use this command to enable RIPng routing on the interface.

Use the no parameter with this command to disable RIPng routing.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax `ipv6 router rip`
 `no ipv6 router rip`

Default Disabled

Mode Interface mode for VLAN interfaces only.

Usage This command can only be configured on VLAN interfaces.

Example

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ipv6 router rip
```

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# no ipv6 router rip
```

neighbor (RIPng)

Use this command to specify a neighbor router.

Use the no parameter with this command to disable the specific router.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax neighbor <ipv6-link-local-addr> <interface>
no neighbor <ipv6-link-local-addr> <interface>

Parameter	Description
<ipv6-link-local-addr>	Specify the link-local IPv6 address (in the format X::X::X) of a neighboring router to exchange routing information with.
<interface>	The interface. For instance: ■ vlan2

Mode Router mode

Usage Use this command to exchange non broadcast routing information. It can be used multiple times for additional neighbors.

The [passive-interface \(RIPng\)](#) command disables sending routing updates on an interface. Use the neighbor command in conjunction with the [passive-interface \(RIPng\)](#) command to send routing updates to specific neighbors.

Example

```
awplus# configure terminal
awplus(config)# router ipv6 rip
awplus(config-router)# neighbor de80::1 vlan2

awplus# configure terminal
awplus(config)# router ipv6 rip
awplus(config-router)# no neighbor de80::1 vlan2
```

Related Commands [passive-interface \(RIPng\)](#)

offset-list (RIPng)

Use this command to add an offset to in and out metrics to routes learned through RIPng.

Use the no parameter with this command to remove an offset list.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax `offset-list {<access-list-number>|<access-list-name>} {in|out} <offset> [<interface>]`
`no offset-list {<access-list-number>|<access-list-name>} {in|out} <offset> [<interface>]`

Parameter	Description
<code><access-list-number></code>	Specify an access-list number to apply to an offset-list.
<code><access-list-name></code>	Specify and access-list name to apply to an offset-list.
<code>in</code>	Indicates the access-list will be used for metrics of incoming advertised routes
<code>out</code>	Indicates the access-list will be used for metrics of outgoing advertised routes
<code><offset></code>	<0-16> Specifies that the offset is used for metrics of networks matching the access-list
<code><interface></code>	The interface to match. For instance: ■ <code>vlan2</code>

Default The default offset value is the metric value of the interface over which the updates are being exchanged.

Mode Router mode

Usage Use this command to specify the offset value that is added to the routing metric. When the networks match the access list the offset is applied to the metrics. No change occurs if the offset value is zero.

Example In this example the router examines the RIPng updates being sent out from interface `vlan2` and adds 8 hops to the routes matching the ip addresses specified in the access list 2.

```
awplus# configure terminal
awplus(config)# router ipv6 rip
awplus(config-router)# offset-list mylist in 8 vlan2
```

passive-interface (RIPng)

Use this command to enable suppression of routing updates on an interface.

Use the no parameter with this command to disable this function.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax `passive-interface <interface>`
`no passive-interface <interface>`

Parameter	Description
<code><interface></code>	The interface. For example: <code>vlan2</code>

Default Disabled

Mode Router mode

Example

```
awplus# configure terminal
awplus(config)# router ipv6 rip
awplus(config-router)# passive-interface vlan2

awplus# configure terminal
awplus(config)# router ipv6 rip
awplus(config-router)# no passive-interface vlan2
```

recv-buffer-size (RIPng)

Use this command to configure the RIPng UDP (User Datagram Protocol) receive-buffer size. This should improve UDP reliability by avoiding UDP receive buffer overruns.

Use the no parameter with this command to unset the configured RIPng UDP receive-buffer size and set it back to the system default value of 196608 bits.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax `recv-buffer-size <8192-2147483647>`
`no recv-buffer-size`

Mode Router mode

Default The RIPng UDP receive-buffer-size is 196608 bits by default, and is reset to the default using the no recv-buffer-size command.

Example

```
awplus# configure terminal
awplus(config)# router ipv6 rip
awplus(config-router)# recv-buffer-size 23456789
```

redistribute (RIPng)

Use this command to redistribute information from other routing protocols into RIPng.

Use the no parameter with this command to disable the specified redistribution. The parameters metric and routemap may be used on this command, but have no effect.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax redistribute {connected|static} [metric <0-16>]
[route-map <route-map>]

no redistribute {connected|static} [metric <0-16>]
[route-map <route-map>]

Parameter	Description
<0-16>	Optional. Specifies the metric value to be used when redistributing information. If a value is not specified, and no value is specified using the default-metric (RIPng) command, the default value is zero.
<route-map>	Optional. Specifies route-map to be used to redistribute information.
connected	Redistribute from connected routes
static	Redistribute from static routes

Mode Router mode

Example

```
awplus# configure terminal
awplus(config)# router ipv6 rip
awplus(config-router)# redistribute static route-map mymap
awplus(config-router)# redistribute static metric 8
```

route (RIPng)

Use this command to configure static RIPng routes.

Use the no parameter with this command to disable this function.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax route <ipv6-addr/prefix-length>
no route <ipv6-addr/prefix-length>

Parameter	Description
<ipv6-addr/prefix-length>	Specify the IPv6 Address in format X:X::X:Prefix-Length. The prefix-length is a decimal integer between 1 and 128.

Mode Router mode

Usage Use this command to add a static RIPng route. After adding the RIPng route, the route can be checked in the RIPng routing table.

Example

```
awplus# configure terminal
awplus(config)# router ipv6 rip
awplus(config-router)# route 3ffe:1234:5678::1/64
```

Related Commands show ipv6 rip
clear ipv6 rip route

router ipv6 rip

Use this global command to enter Router Configuration mode to enable a RIPng routing process.

Use the no parameter with this command to disable the RIPng routing process.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax router ipv6 rip
 no router ipv6 rip

Mode Global Configuration mode

Example

```
awplus# configure terminal
awplus(config)# router ipv6 rip
awplus(config-router)#
```

show debugging ipv6 rip

Use this command to display the RIPng debugging status for the debugging options of: nsm debugging, RIPng event debugging, RIPng packet debugging and RIPng nsm debugging.

For information on output options, see [“Controlling “show” command output” on page 1.33](#).

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax show debugging ipv6 rip

Mode Privileged Exec mode

Usage Use this command to display the debug status of RIPng.

Example

```
awplus# show debugging ipv6 rip
```

show ipv6 protocols rip

Use this command to display RIPng process parameters and statistics.

For information on output options, see “Controlling “show” command output” on page 1.33.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax show ipv6 protocols rip

Mode Privileged Exec mode and Exec mode

Example

```
awplus# show ipv6 protocols rip
```

Output The following is a sample output from the show ipv6 protocols rip command.

```
Codes: R - RIP, K - Kernel, C - Connected, S - Static, O - OSPF,
I - IS-IS,
B - BGP, a - aggregate, s - suppressed
Network Next Hop If Met Tag Time
R 3ffe:1234:5678::/64 fe80::3 vlan3 3 0 02:28
C 3ffe:ffff:1::/64 :: vlan2 1 0
Ra 3ffe:ffff:2::/48 -- 1 0
Rs 3ffe:ffff:2::/48 fe80::3 vlan3 3 0 02:32
Cs 3ffe:ffff:2::/64 :: vlan3 1 0
R 3ffe:ffff:ffff:ffff::/64 fe80::3 vlan3 3 0 02:28
```

show ipv6 rip

Use this command to show RIPng routes.

For information on output options, see “Controlling “show” command output” on page 1.33.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax show ipv6 rip

Mode Privileged Exec mode and Exec mode

Example

```
awplus# show ipv6 rip
```

Output The following is a sample output from the show ipv6 rip command:

```
Routing Protocol is "RIPng"
  Sending updates every 30 seconds with +/-50%, next due in 10
seconds
  Timeout after 180 seconds, garbage collect after 120 seconds
  Outgoing update filter list for all interface is not set
  Incoming update filter list for all interface is not set
  Default redistribute metric is 1
  Redistributing: connected
  Routing for Networks:
    3ffe:1::/64

Codes: R - RIP, Rc - RIP connected, Rs - RIP static, Ra - RIP
aggregated, Rcx - RIP connect suppressed, Rsx - RIP static
suppressed, C - Connected, S - Static, O - OSPF, B - BGP

Network          Next Hop          If      Met Tag  Time
3ffe:1::/64
```

Related Commands show ipv6 rip database

show ipv6 rip database

Use this command to display information about the RIPng database.

For information on output options, see “Controlling “show” command output” on page 1.33.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax show ipv6 rip database

Mode Privileged Exec mode and Exec mode

Example

```
awplus# show ipv6 rip database
```

Usage The following is a sample output from the show ipv6 rip database command:

```
Codes: R - RIP, Rc - RIP connected, Rs - RIP static, Ra - RIP
aggregated, Rcx - RIP connect suppressed, Rsx - RIP static
suppressed, C - Connected, S - Static, O - OSPF, B - BGP

Network                Next Hop                If      Met Tag  Time
R 3ffe:1234:5678::/64  fe80::3  vlan3 3 0 02:28
C 3ffe:ffff:1::/64    ::  vlan2 0
Ra 3ffe:ffff:2::/48   --  1 0
Rs 3ffe:ffff:2::/48   fe80::3  vlan3 3 0 02:32
Cs 3ffe:ffff:2::/64    ::  vlan3 1 0
R 3ffe:ffff:ffff:ffff::/64 fe80::3  vlan3 3 0 02:28
```

Related Commands show ipv6 rip

show ipv6 rip interface

Use this command to display information about the RIPng interfaces. You can specify an interface name to display information about a specific interface.

For information on output options, see “Controlling “show” command output” on page 1.33.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax show ipv6 rip interface [<interface>]

Parameter	Description
<interface>	The interface to display information about. For instance: ■ vlan2

Mode Privileged Exec mode and Exec mode

Example

```
awplus# show ipv6 rip interface
```

Output The following is a sample output from the show ipv6 rip interface command.

```
lo is up, line protocol is up
RIPng is not enabled on this interface
vlan1 is up, line protocol is up
RIPng is not enabled on this interface
vlan2 is down, line protocol is down
RIPng is not enabled on this interface
vlan3 is up, line protocol is up
Routing Protocol: RIPng
Passive interface: Disabled
Split horizon: Enabled with Poisoned Reversed
IP interface address:
3ffe:ffff::1/64
3ffe:ffff::1/64
```

timers (RIPng)

Use this command to adjust the RIPng routing network timers.

Use the no parameter with this command to restore the defaults.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax `timers basic <update> <timeout> <garbage>`
`no timers basic`

Parameter	Description
<code><update></code>	<code><5-2147483647></code> Specifies the RIPng routing table update timer in seconds. The default is 30 seconds.
<code><timeout></code>	<code><5-2147483647></code> Specifies the RIPng routing information timeout timer in seconds. The default is 180 seconds. After this interval has elapsed and no updates for a route are received, the route is declared invalid.
<code><garbage></code>	<code><5-2147483647></code> Specifies the RIPng routing garbage collection timer in seconds. The default is 120 seconds.

Mode Router mode

Default The default RIPng routing table update timer default is 30 seconds, the default RIPng routing information timeout timer is 180 seconds, and the default RIPng routing garbage collection timer is 120 seconds. The no timers basic command restores the default RIPng routing timers.

Example

```
awplus# configure terminal
awplus(config)# router ipv6 rip
awplus(config-router)# timers basic 30 180 120
```

undebg ipv6 rip

Use this command to disable debugging options of RIPng events, RIPng packets, and communication between RIPng and NSM processes.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax `undebg ipv6 rip [all|events|nsm|packet [recv|send][detail]]`

Parameter	Description
all	Disables all RIPng debugging.
events	Disable the display of RIPng events information.
nsm	Disable the display of RIPng and NSM communication.
packet	Disable debugging of specified RIPng packets only.
recv	Disable the display of information for received packets.
send	Disable the display of information for sent packets.
detail	Disable the display of detailed information for sent or received packets.

Mode Privileged Exec mode and Global Configuration mode

Example

```
awplus# undebg ipv6 rip events
```

```
awplus# undebg ipv6 rip all
```

```
awplus# undebg ipv6 rip packet send
```

```
awplus# undebg ipv6 rip packet recv detail
```

Chapter 37: OSPF Configuration



Introduction.....	37.2
Terminology.....	37.2
Enabling OSPF on an Interface.....	37.3
Setting priority.....	37.5
Configuring an Area Border Router.....	37.7
Redistributing routes into OSPF.....	37.8
OSPF Cost.....	37.9
Configuring Virtual Links.....	37.12
OSPF Authentication.....	37.14

Introduction

This chapter contains basic OSPF configuration examples. To see details on the OSPF commands used in these examples, or to see the outputs of the validation commands, refer to [Chapter 38, OSPF Commands](#).

Terminology

The following is a brief description of terms and concepts used to describe the OSPF protocol:

OSPF Router

Any Layer 3 routing device that is running OSPF, such as an Allied Telesis managed layer 3 switch or Allied Telesis router.

Designated Router

Each OSPF network contains a designated router, that:

- originates the network link state advertisement for the network
- becomes adjacent to all other routers on the network

Since the topological database is spread over adjacencies, the designated router coordinates the synchronization of the topological database on all the routers attached to the network.

The designated router for a broadcast network is determined dynamically via hello packets. On non-broadcast multi-access networks, static configuration information is used to initiate the search for a designated router. To help in dynamic fallover, OSPF also determines a backup designated router for a network via hello packets. The backup designated router, like the designated router maintains an adjacency to all other routers on the network. If the designated router fails for any reason, the backup designated router takes over.

Autonomous System

A set of routers that exchange OSPF routing information with each other.

Router ID

A unique ID assigned to each OSPF router. This ID takes the same form as an IP address, i.e. A.B.C.D, where each of A,B,C,D is a number between 0 and 254. This number uniquely identifies the OSPF router within the AS.


Adjacency

A relationship created between neighboring OSPF routers, for the purpose of exchanging topological information. Not every router needs to become adjacent to every other router. Adjacencies are established and maintained with *hello* packets. These packets are sent periodically on all router interfaces. Bidirectional communication is determined by a router seeing itself listed in hello packets from its neighbors.

Enabling OSPF on an Interface

This example shows the minimum configuration required for enabling OSPF on an interface. In this example, the OSPF routers are Allied Telesis managed Layer 3 switches. Switch 1 and Switch 2 are two OSPF routers in Area 0 connecting to network 10.10.10.0/24.

Note: Configure one interface so that it belongs to only one area. However, you can configure different interfaces on an OSPF router to belong to different areas.



Switch 1

<code>awplus#</code>	
<code>configure terminal</code>	Enter the Configure mode.
<code>awplus(config)#</code>	
<code>router ospf 100</code>	Configure the Routing process and specify the Process ID (100). The Process ID should be a unique positive integer identifying the routing process.
<code>awplus(config-router)#</code>	
<code>network 10.10.10.0/24 area 0</code>	Define the interface (10.10.10.0/24) on which OSPF runs and associate the area ID (0) with the interface (area ID 0 specifies the backbone area).

Switch 2

<code>awplus#</code>	
<code>configure terminal</code>	Enter the Configure mode
<code>awplus(config)#</code>	
<code>router ospf 200</code>	Configure the Routing process and specify the Process ID (200). The Process ID should be a unique positive integer identifying the routing process. Note that the process ID used on this switch is different to that used on Switch 1. This is correct configuration as the process ID is a value that is only used within a single OSPF router. Therefore there is no requirement for the process IDs used on one OSPF router to have any relationship with the process IDs used on the other OSPF routers that it interacts with.
<code>awplus(config-router)#</code>	
<code>network 10.10.10.0/24 area 0</code>	Define the interface (10.10.10.0/24) on which OSPF runs and associate the area ID (0) with the interface.

Names of Commands Used


network area, router ospf

Validation Commands

show ip ospf, show ip ospf interface, show ip ospf neighbor, show ip ospf route

Setting priority

This example shows the configuration for setting the priority for an interface. You can set a high priority for an OSPF router to make it the Designated Router (DR). In this example, the OSPF routers are Allied Telesis managed Layer 3 switches. Switch 3 is configured to have a priority of 10, which is higher than the default priority (default priority is 1) of Switch 1 and Switch 2; making it the DR. In this example network the back-up DR would be Switch 2 as it has a higher router ID than Switch 1



Switch 3

<code>awplus(config)#</code>	
<code>interface vlan2</code>	Specify the interface (vlan2) to be configured.
<code>awplus(config-if)#</code>	
<code>ip ospf priority 10</code>	Specify the router priority to a higher priority (10) to make Switch 3 the Designated Router (DR).
<code>awplus(config-if)#</code>	
<code>exit</code>	Exit the Interface mode and return to the Configure mode.
<code>awplus(config)#</code>	
<code>router ospf 100</code>	Configure the Routing process and specify the Process ID (100). The Process ID should be a unique positive integer identifying the routing process.
<code>awplus(config-router)#</code>	
<code>network 10.10.10.0/24 area 0</code>	Define the interface (10.10.10.0/24) on which OSPF runs and associate the area ID (0) with the interface.

Switch 1

awplus#	
<code>configure terminal</code>	Enter the Configure mode.
awplus(config)#	
<code>router ospf 100</code>	Configure the Routing process and specify the Process ID (100). The Process ID should be a unique positive integer identifying the routing process.
awplus(config-router)#	
<code>network 10.10.10.0/24 area 0</code>	Define the interface (10.10.10.0/24) on which OSPF runs and associate the area ID (0) with the interface (area ID 0 specifies the backbone area).

Switch 2


awplus#	
<code>configure terminal</code>	Enter the Configure mode.
awplus(config)#	
<code>router ospf 200</code>	Configure the Routing process and specify the Process ID (200). The Process ID should be a unique positive integer identifying the routing process.
awplus(config-router)#	
<code>network 10.10.10.0/24 area 0</code>	Define the interface (10.10.10.0/24) on which OSPF runs and associate the area ID (0) with the interface.

**Names of
Commands Used** network area
 ip ospf priority

**Validation
Commands** show ip ospf neighbor
 show ip ospf interface

Configuring an Area Border Router

This example shows configuration for an Area Border Router (ABR). In this example, the OSPF routers are Allied Telesis managed Layer 3 switches. Switch 2 is an ABR, where interface vlan2 is in Area 0 and interface vlan3 is in Area 1.



Switch 2

awplus#	
configure terminal	Enter the Configure mode.
awplus(config)#	
router ospf 100	Configure the Routing process and specify the Process ID (100). The Process ID should be a unique positive integer identifying the routing process.
awplus(config-router)#	
network 10.10.10.0/24 area 0	Define one interface (10.10.10.0/24) on which OSPF runs and associate the area ID (0) with the interface.
awplus(config-router)#	
network 10.10.11.0/24 area 1	Define the other interface (10.10.11.0/24) on which OSPF runs and associate the area ID (1) with the interface.

Names of Commands Used


network area

Validation Commands

show ip ospf
show ip ospf interface

Redistributing routes into OSPF

In this example the configuration causes BGP routes to be imported into the OSPF routing table and advertised as Type 5 External LSAs into Area 0. In this example, the OSPF routers, labelled “Device 1-5” represent any Allied Telesis managed Layer 3 switches or Allied Telesis routers.



Device 1

awplus#	
configure terminal	Enter the Configure mode.
awplus(config)#	
router ospf 100	Configure the Routing process and specify the Process ID (100). The Process ID should be a unique positive integer identifying the routing process.
awplus(config-router)#	
network 10.10.10.0/24 area 0	Define one interface (10.10.10.0/24) on which OSPF runs and associate the area ID (0) with the interface (area ID 0 specifies the backbone area).
awplus(config-router)#	
redistribute bgp	Specify redistributing routes from other routing protocol (BGP) into OSPF.

Names of Commands Used

redistribute (OSPF), network area

Validation Commands

show ip ospf database external

OSPF Cost

You can make a route the preferred route by changing its cost. In this example, the OSPF routers are Allied Telesis managed Layer 3 switches. The cost has been configured to make Switch 2 the next hop for Switch 1.

The default cost on each interface is 10. Interface `vlan2` on Switch 2 has a cost of 100 and interface `vlan3` on Switch 3 has a cost of 150. The total cost for Switch 1 to reach 10.10.14.0/24 (Switch 4) Switch 2 or via Switch 3 is:

Switch 2: $10+100 = 110$

Switch 3: $10+150 = 160$

Therefore, Switch 1 chooses Switch 2 as its next hop for destination 10.10.14.0/24, as that path has the lower cost.

Switch 1

```
awplus#
configure terminal Enter the Configure mode.
awplus(config)#
router ospf 100 Configure the Routing process and specify the
                  Process ID (100). The Process ID should be a
                  unique positive integer identifying the routing
                  process.
awplus(config-router)#
network 10.10.9.0/24 area 0 Define interfaces on which OSPF runs and
awplus(config-router)#    associate the area ID (0) with the interface
network 10.10.10.0/24 area 0 (area ID 0 specifies the backbone area).
awplus(config-router)#
network 10.10.12.0/24 area 0
```

Switch 2

<code>awplus#</code>	
<code>configure terminal</code>	Enter the Configure mode.
<code>awplus(config)#</code>	
<code>interface vlan2</code>	Specify the interface (vlan2) to be configured.
<code>awplus(config-if)#</code>	
<code>ip ospf cost 100</code>	Set the OSPF cost of this link to 100.
<code>awplus(config-if)#</code>	
<code>exit</code>	Exit the Interface mode and return to Configure mode.
<code>awplus(config)#</code>	
<code>router ospf 100</code>	Configure the Routing process and specify the Process ID (100). The Process ID should be a unique positive integer identifying the routing process.
<code>awplus(config-router)#</code>	
<code>network 10.10.10.0/24 area 0</code>	Define interfaces on which OSPF runs and associate the area ID (0) with the interface.
<code>awplus(config-router)#</code>	
<code>network 10.10.11.0/24 area 0</code>	Define interfaces on which OSPF runs and associate the area ID (0) with the interface.

Switch 3

<code>awplus(config)#</code>	
<code>interface vlan3</code>	Specify the interface (vlan3) to be configured.
<code>awplus(config-if)#</code>	
<code>ip ospf cost 150</code>	Set the OSPF cost of this link to 100.
<code>awplus(config-if)#</code>	
<code>exit</code>	Exit the Interface mode and return to Configure mode.
<code>awplus(config)#</code>	
<code>router ospf 100</code>	Configure the Routing process and specify the Process ID (100). The Process ID should be a unique positive integer identifying the routing process.
<code>awplus(config-router)#</code>	
<code>network 10.10.12.0/24 area 0</code>	Define interfaces on which OSPF runs and associate the area ID (0) with the interface.
<code>awplus(config-router)#</code>	
<code>network 10.10.13.0/24 area 0</code>	

Switch 4

```

awplus(config)#
router ospf 100

```

Configure the Routing process and specify the Process ID (100). The Process ID should be a unique positive integer identifying the routing process.

```

awplus(config-router)#
network 10.10.11.0/24 area 0
awplus(config-router)#
network 10.10.13.0/24 area 0
awplus(config-router)#
network 10.10.14.0/24 area 0


```

Names of Commands Used	network area ip ospf cost
Validation Commands	show ip ospf route

Configuring Virtual Links

Virtual links are used to connect a disjointed non-backbone area to the backbone area, or to repair a non-contiguous backbone area. In this example, the OSPF routers shown represent any Allied Telesis managed Layer 3 switches or Allied Telesis routers.

In the network below, there is no area border router that connects Area2 to the backbone. So a virtual link needs to be created between ABR Device 1 and ABR Device 2 to connect Area 2 to Area 0. Area 1 is used as a transit area.



Device 1

awplus#	
<code>configure terminal</code>	Enter the Configure mode.
awplus(config)#	
<code>router ospf 100</code>	Configure the Routing process and specify the Process ID (100). The Process ID should be a unique positive integer identifying the routing process.
awplus(config-router)#	
<code>ospf router-id 10.10.21.1</code>	Configure OSPF Router ID (10.10.21.1) for this router.
awplus(config-router)#	
<code>network 10.10.21.0/24 area 0</code>	Define interfaces on which OSPF runs and associate the area IDs (0 and 1) with the interface.
awplus(config-router)#	
<code>network 10.10.22.0/24 area 1</code>	

```
awplus(config-router)#
area 1 virtual-link 10.10.23.2
```

Configure a virtual link between this router R1 and R2 (Router ID 10.10.23.2) through transit area 1.

Device 2

```
awplus(config)#
router ospf 100
```

Configure the Routing process and specify the Process ID (100). The Process ID should be a unique positive integer identifying the routing process.

```
awplus(config-router)#
ospf router-id 10.10.23.2
```

Configure OSPF Router ID (10.10.23.2) for this router.

```
awplus(config-router)#
network 10.10.23.0/24 area 1
awplus(config-router)#
network 10.10.24.0/24 area 2
```

Define interfaces on which OSPF runs and associate the area IDs (1 and 2) with the interface.

```
awplus(config-router)#
area 1 virtual-link 10.10.21.1
```

Configure a virtual link between this router R2 and R1(Router ID 10.10.21.1) through transit area 1.

Names of Commands Used

area virtual-link, network area

Validation Commands


show ip ospf virtual-links, show ip ospf neighbor, show ip ospf, show ip ospf route

OSPF Authentication

In the AlliedWare Plus™ implementation there are three types of OSPF authentications--Null authentication (Type 0), Simple Text (Type 1) authentication and MD5 (Type 2) authentication. With null authentication, routing exchanges over the network are not authenticated. In Simple Text authentication, the authentication type is the same for all OSPF routers that communicate using OSPF in a network. For MD5 authentication, you configure a key and a key-id on each OSPF router. The OSPF router generates a message digest on the basis of the key, key ID and the OSPF packet and adds it to the OSPF packet.

The Authentication type can be configured on a per-interface basis or a per-area basis. Additionally, Interface and Area authentication can be used together. Area authentication is used for an area and interface authentication is used for a specific interface in the area. If the Interface authentication type is different from Area authentication type, Interface authentication type overrides the Area authentication type. If the Authentication type is not specified for an interface, the Authentication type for the area is used. The authentication command descriptions contain details of each type of authentication. Refer to [Chapter 38, OSPF Commands](#) for OSPF authentication commands.

In this example, the OSPF routers are Allied Telesis managed Layer 3 switches. Switch 1 and Switch 2 are configured for both the interface and area authentications. The authentication type of interface vlan2 on Switch 1 and interface vlan2 on Switch 2 is md5 mode and is defined by the [area authentication command on page 38.3](#); however, the authentication type of interface vlan3 on Switch 1 and interface vlan4 on Switch 2 is plain text mode and is defined by the `ip ospf authentication` command. This interface command overrides the area authentication command.



Switch 1

```
awplus#
configure terminal  Enter the Configure mode.
```

Switch 1(Continued)

<code>awplus(config)#</code>	
<code>router ospf 100</code>	Configure the Routing process and specify the Process ID (100). The Process ID should be a unique positive integer identifying the routing process.
<code>awplus(config-router)#</code>	
<code>network 10.10.10.0/24 area 0</code>	Define interfaces on which OSPF runs and associate the area ID (0) with the interface (area ID 0 specifies the backbone area).
<code>awplus(config-router)#</code>	
<code>network 10.10.11.0/24 area 0</code>	
<code>awplus(config-router)#</code>	
<code>area 0 authentication message-digest</code>	Enable MD5 authentication on area 0.
<code>awplus(config-router)#</code>	
<code>exit</code>	Exit the Router mode and return to Configure mode.
<code>awplus(config)#</code>	
<code>interface vlan2</code>	Specify the interface (vlan2)you are configuring.
<code>awplus(config-if)#</code>	
<code>ip ospf message-digest-key 1 md5 test</code>	Register MD5 key test for OSPF authentication. The Key ID is 1.
<code>awplus(config-if)#</code>	
<code>exit</code>	Exit the Interface mode and return to Configure mode
<code>awplus(config)#</code>	
<code>interface vlan3</code>	Specify the interface (vlan3)you are configuring.
<code>awplus(config-if)#</code>	
<code>ip ospf authentication</code>	Enable OSPF packet to use text authentication on the current interface (vlan3).
<code>awplus(config-if)#</code>	
<code>ip ospf authentication-key test</code>	Specify an OSPF authentication password test for the neighboring OSPF routers.

Switch 2

<code>awplus#</code>	
<code>configure terminal</code>	Enter the Configure mode.
<code>awplus(config)#</code>	
<code>router ospf 100</code>	Configure the Routing process and specify the Process ID (100). The Process ID should be a unique positive integer identifying the routing process.
<code>awplus(config-router)#</code>	Define interfaces on which OSPF runs and associate the area ID (0) with the interface (area ID 0 specifies the backbone area).
<code>network 10.10.10.0/24 area 0</code>	
<code>awplus(config-router)#</code>	
<code>network 10.10.11.0/24 area 0</code>	
<code>awplus(config-router)#</code>	
<code>area 0 authentication message-digest</code>	Enable MD5 authentication on area 0.
<code>awplus(config-router)#</code>	
<code>exit</code>	Exit the Router mode and return to Configure mode.
<code>awplus(config)#</code>	
<code>interface vlan2</code>	Specify the interface (vlan2) you are configuring.
<code>awplus(config-if)#</code>	
<code>ip ospf message-digest-key 1 md5 test</code>	Register MD5 key test for OSPF authentication. The Key ID is 1.
<code>awplus(config-if)#</code>	
<code>exit</code>	Exit the Interface mode and return to Configure mode
<code>awplus(config)#</code>	
<code>interface vlan4</code>	Specify the interface (vlan4) you are configuring.
<code>awplus(config-if)#</code>	
<code>ip ospf authentication</code>	Enable OSPF packet to use text authentication on the current interface (vlan4).
<code>awplus(config-if)#</code>	
<code>ip ospf authentication-key test</code>	Specify an OSPF authentication password test for the neighboring OSPF routers.

Names of Commands Used

- `ip ospf authentication`
- `ip ospf authentication-key`
- `network area`
- `area authentication`

Validation Commands

- `show running-config`
- `show ip ospf neighbor`

Chapter 38: OSPF Commands

Command List	38.3
area authentication	38.3
area default-cost	38.4
area filter-list	38.5
area nssa	38.6
area range	38.8
area stub	38.9
area virtual-link	38.10
auto-cost reference bandwidth	38.12
bandwidth	38.13
capability opaque	38.13
capability restart	38.14
clear ip ospf process	38.14
compatible rfc1583	38.15
debug ospf events	38.16
debug ospf ifsm	38.17
debug ospf lsa	38.18
debug ospf nfsm	38.19
debug ospf nsm	38.20
debug ospf packet	38.21
debug ospf route	38.22
default-information originate (OSPF)	38.23
default-metric (OSPF)	38.24
distance (OSPF)	38.25
distribute-list (OSPF)	38.27
host area	38.28
ip ospf authentication	38.29
ip ospf authentication-key	38.30
ip ospf cost	38.31
ip ospf database-filter	38.32
ip ospf dead-interval	38.33
ip ospf disable all	38.34
ip ospf hello-interval	38.35
ip ospf message-digest-key	38.36
ip ospf mtu	38.37
ip ospf mtu-ignore	38.38
ip ospf network	38.39
ip ospf priority	38.40
ip ospf resync-timeout	38.41
ip ospf retransmit-interval	38.42
ip ospf transmit-delay	38.43
max-concurrent-dd	38.44
maximum-area	38.45
neighbor (OSPF)	38.46
network area	38.47
ospf abr-type	38.48
ospf restart grace-period	38.49

ospf restart helper.....	38.50
ospf router-id.....	38.51
overflow database.....	38.52
overflow database external.....	38.53
passive-interface (OSPF).....	38.54
redistribute (OSPF).....	38.55
restart ospf graceful.....	38.56
router ospf.....	38.57
router-id.....	38.58
show debugging ospf.....	38.58
show ip ospf.....	38.59
show ip ospf border-routers.....	38.61
show ip ospf database.....	38.62
show ip ospf database asbr-summary.....	38.63
show ip ospf database external.....	38.64
show ip ospf database network.....	38.65
show ip ospf database nssa-external.....	38.67
show ip ospf database opaque-area.....	38.69
show ip ospf database opaque-as.....	38.70
show ip ospf database opaque-link.....	38.71
show ip ospf database router.....	38.72
show ip ospf database summary.....	38.74
show ip ospf interface.....	38.76
show ip ospf neighbor.....	38.77
show ip ospf route.....	38.79
show ip ospf virtual-links.....	38.80
show ip protocols ospf.....	38.81
summary-address.....	38.82
timers spf.....	38.83

Command List

This chapter provides an alphabetical reference of commands used to configure OSPF. For more information, see [Chapter 37, OSPF Configuration](#).

area authentication

Use this command to enable authentication for an OSPF area. Specifying the area authentication sets the authentication to Type 1 authentication or the Simple Text password authentication (details in RFC 2328).

The no form removes the authentication specification for an area.

Syntax `area <area-id> authentication [message-digest]`
`no area <area-id> authentication`

Parameter	Description
<area-id>	The OSPF area that you are enabling authentication for. This can be entered in either dotted decimal format or normal decimal format.
	<ip-addr> OSPF Area ID expressed in IPv4 address, entered in the form A.B.C.D.
	<0-4294967295> OSPF Area ID expressed as a decimal number within the range shown.
	For example the values dotted decimal 0.0.1.2 and decimal 258 would both define the same area OSPF Area ID.
message-digest	Enables MD5 authentication in the OSPF area.

Mode Router Configuration

Default By default, no authentication occurs.

Usage All OSPF packets transmitted in this area must have the same password in their OSPF header. This ensures that only routers that have the correct password may join the routing domain.

Give all routers that are to communicate with each other through OSPF the same authentication password.

Use the [ip ospf authentication-key](#) command to specify a Simple Text password. Use the [ip ospf message-digest-key](#) command to specify MD5 password.

Examples

```
awplus# configure terminal
awplus(config)# router ospf 100
awplus(config-router)# area 1 authentication
```

Related Commands [ip ospf authentication](#)
[ip ospf message-digest-key](#)

area default-cost

This command specifies a cost for the default summary route sent into a stub or NSSA area.

The no form of this command removes the assigned default-route cost.

Syntax `area <area-id> default-cost <0-16777215>`
`no area <area-id> default-cost`

Parameter	Description
<area-id>	The OSPF area that you are specifying the default summary route cost for. Use one of the following formats: This can be entered in either dotted decimal format or normal decimal format.
	<ip-addr> OSPF Area ID expressed in IPv4 address format A.B.C.D.
	<0-4294967295> OSPF Area ID expressed as a decimal number within the range shown
	For example the values dotted decimal 0.0.1.2 and decimal 258 would both define the same area ID.
default-cost	Indicates the cost for the default summary route used for a stub or NSSA area. Default: 1

Mode Router Configuration

Usage The default-cost option provides the metric for the summary default route, generated by the area border router, into the NSSA or stub area. Use this option only on an area border router that is attached to the NSSA or stub area. Refer to the RFC 3101 for information on NSSA.

Examples To set the default cost to 10 in area 1 for the OSPF instance 100, use the commands:

```
awplus# configure terminal
awplus(config)# router ospf 100
awplus(config-router)# area 1 default-cost 10
```

Related Commands `area nssa`
`area stub`

area filter-list

This command configures filters to advertise summary routes on Area Border Routers (ABR).

This command is used to suppress particular intra-area routes from/to an area to/from the other areas. You can use this command in conjunction with either the access-list or prefix-list command.

The no form of this command removes the filter configuration.

Syntax `area <area-id> filter-list {access <access-list>|prefix <prefix-list>} {in|out}`

Parameter	Description
<area-id>	The OSPF area that you are configuring the filter for. Use one of the following formats: This can be entered in either dotted decimal format or normal decimal format.
<ip-addr>	OSPF Area ID expressed in IPv4 address format A.B.C.D.
<0-4294967295>	OSPF Area ID expressed as a decimal number within the range shown
	For example the values dotted decimal 0.0.1.2 and decimal 258 would both define the same area ID.
access	Use access-list to filter summary.
prefix	Use prefix-list to filter summary.
<access-list>	Name of an access-list.
<prefix-list>	Name of a prefix-list.
in	Filter routes from the other areas to this area.
out	Filter routes from this area to the other areas.

Mode Router Configuration

Examples

```
awplus# configure terminal
awplus(config)# access-list 1 deny 172.22.0.0
awplus(config)# router ospf 100
awplus(config-router)# area 1 filter-list access 1 in
```

area nssa

This command sets an area as a Not-So-Stubby-Area (NSSA). By default, no NSSA area is defined.

Use this command to simplify administration if you are connecting a central site using OSPF to a remote site that is using a different routing protocol. You can extend OSPF to cover the remote connection by defining the area between the central router and the remote router as an NSSA.

There are no external routes in an OSPF stub area, so you cannot redistribute from another protocol into a stub area. A NSSA allows external routes to be flooded within the area. These routes are then leaked into other areas. Although, the external routes from other areas still do not enter the NSSA. You can either configure an area to be a stub area or an NSSA, not both.

The no form removes this designation.

Syntax

```
area <area-id> nssa [default-information-originate <metric> |
no-redistribution | no-summary | translator-role <role> ]

no area <area-id> nssa [default-information-originate |
no-redistribution | no-summary | translator-role ]
```

Parameter	Description				
<area-id>	The OSPF area that you are configuring as an NSSA. Use one of the following formats: This can be entered in either dotted decimal format or normal decimal format. <table> <tr> <td><ip-addr></td><td>OSPF Area ID expressed in IPv4 address format A.B.C.D.</td></tr> <tr> <td><0-4294967295></td><td>OSPF Area ID expressed as a decimal number within the range shown</td></tr> </table> For example the values dotted decimal 0.0.1.2 and decimal 258 would both define the same area ID.	<ip-addr>	OSPF Area ID expressed in IPv4 address format A.B.C.D.	<0-4294967295>	OSPF Area ID expressed as a decimal number within the range shown
<ip-addr>	OSPF Area ID expressed in IPv4 address format A.B.C.D.				
<0-4294967295>	OSPF Area ID expressed as a decimal number within the range shown				
default-information-originate	Originate Type-7 default LSA into NSSA.				
<metric>	The external or internal metric. Specify the following: <table> <tr> <td>metric <0-16777214></td><td>The metric value.</td></tr> <tr> <td>metric-type <1-2></td><td>External metric type.</td></tr> </table>	metric <0-16777214>	The metric value.	metric-type <1-2>	External metric type.
metric <0-16777214>	The metric value.				
metric-type <1-2>	External metric type.				
no-redistribution	Do not redistribute external route into NSSA.				
no-summary	Do not inject inter-area route into NSSA.				
translator-role	Specify NSSA-ABR translator-role.				

Parameter	Description
<code><role></code>	The role type. Specify one of the following keywords:
<code>always</code>	Router always translate NSSA-LSA to Type-5 LSA.
<code>candidate</code>	Router may translate NSSA-LSA to Type-5 LSA if it is elected.
<code>never</code>	Router never translate NSSA-LSA.

Mode Router Configuration

Examples

```
awplus# configure terminal
awplus(config)# router ospf 100
awplus(config-router)# area 0.0.0.51 nssa
awplus(config-router)# area 3 nssa translator-role candidate
no-redistribution default-information-originate metric 34 metric-type 2
```

Related Commands [area default-cost](#)

area range

This command summarizes OSPF routes at an area boundary. By default, this feature is disabled.

The area range command is used to summarize intra-area routes for an area. The set of summary routes created by this command are then advertised to other areas by the Area Border Routers (ABRs). In this way, routing information is condensed at area boundaries so that routes are exchanged between areas in an efficient manner.

If the network numbers in an area are assigned in a way such that they fall into sets of contiguous routes, the ABRs can be configured to advertise a small set of summary routes that cover the individual networks within the area.

The no form disables this function.

Syntax `area <area-id> range <ip-addr/prefix-length> [advertise|not-advertise]`

`no area <area-id> range <ip-addr/prefix-length>`

Parameter	Description
<code><area-id></code>	The OSPF area that you summarizing the routes for. Use one of the following formats: This can be entered in either dotted decimal format or normal decimal format.
<code><ip-addr></code>	OSPF Area ID expressed in IPv4 address format A.B.C.D.
<code><0-4294967295></code>	OSPF Area ID expressed as a decimal number within the range shown
	For example the values dotted decimal 0.0.1.2 and decimal 258 would both define the same area ID.
<code><ip-addr/prefix-length></code>	The area range prefix and length.
<code>advertise</code>	Advertise this range as a summary route into other areas.
<code>not-advertise</code>	Does not advertise this range.

Mode Router Configuration

Usage Multiple ranges can be configured on a single area by multiple instances of this command.

Examples

```
awplus# configure terminal
awplus(config)# router ospf 100
awplus(config-router)# area 1 range 192.16.0.0/16
awplus(config-router)# area 1 range 203.18.0.0/16
```

area stub

This command defines an OSPF area as a stub area. By default, no stub area is defined.

Use this command when routers in the area do not require learning about summary LSAs from other areas. You can define the area as a totally stubby area by configuring the Area Border Router of that area using the `area stub no-summary` command.

There are two stub area router configuration commands: the `area stub` and `area default-cost` commands. In all routers attached to the stub area, configure the area by using the `area stub` command. For an area border router (ABR) attached to the stub area, also use the `area default-cost` command.

The `no` form removes this definition.

Syntax

```
area <area-id> stub [no-summary]
no area <area-id> stub [no-summary]
```

Parameter	Description
<area-id>	The OSPF area that you are configuring as a stub area. Use one of the following formats: This can be entered in either dotted decimal format or normal decimal format. For example the values dotted decimal 0.0.1.2 and decimal 258 would both define the same area ID.
<ip-addr>	OSPF Area ID expressed in IPv4 address in the format A.B.C.D.
<0-4294967295>	OSPF Area ID expressed as a decimal number within the range shown
	For example the values dotted decimal 0.0.1.2 and decimal 258 would both define the same area ID.
no-summary	Stops an ABR from sending summary link advertisements into the stub area.

Mode Router Configuration

Examples

```
awplus# configure terminal
awplus(config)# router ospf 100
awplus(config-router)# area 1 stub
```

Related Commands [area default-cost](#)

area virtual-link

This command configures a link between two backbone areas that are physically separated through other non-backbone areas.

In OSPF, all non-backbone areas must be connected to a backbone area. If the connection to the backbone is lost, the virtual link repairs the connection.

The no form removes the virtual link.

Syntax

```

area <area-id> virtual-link <ip-addr> [<auth-key>|<msg-key>]
no area <area-id> virtual-link <ip-addr> [<auth-key>|<msg-key>]

area <area-id> virtual-link <ip-addr> authentication
    [message-digest|null] [<auth-key>|<msg-key>]
no area <area-id> virtual-link <ip-addr> authentication
    [message-digest|null] [<auth-key>|<msg-key>]

area <area-id> virtual-link <ip-addr> [authentication]
    [dead-interval <1-65535>] [hello-interval <1-65535>]
    [retransmit-interval <1-3600>] [transmit-delay <1-3600>]
no area <area-id> virtual-link <ip-addr> [authentication]
    [dead-interval] [hello-interval] [retransmit-interval] [transmit-
    delay]
```

Parameter	Description
<area-id>	The area ID of the transit area that the virtual link passes through. Use one of the following formats: This can be entered in either dotted decimal format or normal decimal format.
	<ip-addr> OSPF Area ID expressed in IPv4 address format A.B.C.D.
	<0-4294967295> OSPF Area ID expressed as a decimal number within the range shown
	For example the values dotted decimal 0.0.1.2 and decimal 258 would both define the same area ID.
<ip-address>	The OSPF router ID of the virtual link neighbor.
<auth-key>	Specifies the password used for this virtual link. Use the following format: authentication-key <pswd-short>
	<pswd-short> An 8 character password.
<msg-key>	Specifies a message digest key using the MD5 encryption algorithm. Use the following format: message-digest-key <1-255> md5 <pswd-long>
	<1-255> The key ID.
	<pswd-long> Authentication password of 16 characters.
authentication	Enables authentication on this virtual link.
message-digest	Use message-digest authentication.

Parameter	Description
null	Use null authentication to override password or message digest.
dead-interval	If no packets are received from a particular neighbor for dead-interval seconds, the router considers that neighboring router as being off-line. Default: 40 seconds <1-65535> The number of seconds in the interval.
hello-interval	The interval the router waits before it sends a hello packet. Default: 10 seconds <1-65535> The number of seconds in the interval.
retransmit-interval	The interval the router waits before it retransmits a packet. Default: 5 seconds <1-3600> The number of seconds in the interval.
transmit-delay	The interval the router waits before it transmits a packet. Default: 1 seconds <1-3600> The number of seconds in the interval.

Mode Router Configuration

Usage You can configure virtual links between any two backbone routers that have an interface to a common non-backbone area. The protocol treats these two routers, joined by a virtual link, as if they were connected by an unnumbered point-to-point network. To configure a virtual link, you require:

- The transit area ID, i.e. the area ID of the non backbone area that the two backbone routers are both connected to.
- The corresponding virtual link neighbor's router ID. To see the router ID use the `show ip ospf` command.

Configure the hello-interval to be the same for all routers attached to a common network. A short hello-interval results in the router detecting topological changes faster but also an increase in the routing traffic.

The retransmit-interval is the expected round-trip delay between any two routers in a network. Set the value to be greater than the expected round-trip delay to avoid needless retransmissions.

The transmit-delay is the time taken to transmit a link state update packet on the interface. Before transmission, the link state advertisements in the update packet, are incremented by this

amount. Set the transmit-delay to be greater than zero. Also, take into account the transmission and propagation delays for the interface.

Examples

```
awplus# configure terminal
awplus(config)# router ospf 100
awplus(config-router)# area 1 virtual-link 10.10.11.50 hello 5
dead 10
```

Related Commands [area authentication](#)
[show ip ospf](#)
[show ip ospf virtual-links](#)

auto-cost reference bandwidth

This command controls how OSPF calculates default metrics for the interface.

By default, OSPF calculates the OSPF metric for an interface by dividing the reference bandwidth by the interface bandwidth. The default value for the reference bandwidth is 100 Mbps. As a result, if this default value is used, there is very little difference between the metrics applied to interfaces of increasing bandwidth beyond 100 Mbps. The auto-cost command is used to alter this reference bandwidth in order to give a real difference between the metrics of high bandwidth links of differing bandwidths. In a network that has multiple links with high bandwidths, specify a larger reference bandwidth value to differentiate the costs on those links.

The no form of this command assign cost based only on the interface bandwidth.

Syntax `auto-cost reference-bandwidth <1-4294967>`
`no auto-cost reference-bandwidth`

Parameter	Description
<code><1-4294967></code>	The reference bandwidth in terms of Mbits per second (Mbps). Default: 100

Mode Router Configuration

Examples

```
awplus# configure terminal
awplus(config)# router ospf 100
awplus(config-router)# auto-cost reference-bandwidth 1000
```

Related Commands [ip ospf cost](#)

bandwidth

Use this command to specify the maximum bandwidth to be used for each VLAN interface. The bandwidth value is in bits. OSPF uses this to calculate metrics for the VLAN interface.

The no form removes the maximum bandwidth.

Syntax `bandwidth <bandwidth-setting>`
`no bandwidth`

Parameter	Description
<code><bandwidth-setting></code>	Sets to bandwidth for the interface. Enter a value in the range 1 to 10000000000 bits.

Mode Interface Configuration for a VLAN interface.

Examples

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# bandwidth 1000000
```

Related Commands `show running-config`
`show running-config access-list`
`show interface`

capability opaque

This command enables opaque-LSAs. Opaque-LSAs are Type 9, 10 and 11 LSAs that deliver information used by external applications.

By default, opaque-LSAs are enabled.

The no form of this command to disables opaque-LSAs.

Syntax `capability opaque`
`no capability opaque`

Mode Router Configuration

Examples

```
awplus# configure terminal
awplus(config)# router ospf 100
awplus(config-router)# no capability opaque
```

capability restart

This command enables OSPF graceful restart or restart signaling features. By default, this is enabled.

The no form of this command to disables OSPF graceful restart and restart signalling features.

Syntax `capability restart [graceful|signaling]`
`no capability restart`

Parameter	Description
graceful	Specify enabling OSPF graceful restart feature. Default.
signaling	Specify enabling OSPF signaling restart feature.

Mode Router Configuration

Examples

```
awplus# configure terminal
awplus(config)# router ospf 100
awplus(config-router)# capability restart graceful
```

clear ip ospf process

This command clears and restarts the OSPF routing process. Specify the Process ID to clear one particular OSPF process. When no Process ID is specified, this command clears all running OSPF processes.

Syntax `clear ip ospf [<0-65535>] process`

Parameter	Description
<0-65535>	The Routing Process ID.

Mode Privileged Exec

Examples

```
awplus# clear ip ospf process
```

compatible rfc1583

This command changes the method used to calculate summary route to the that specified in RFC 1583. By default, OSPF uses the method specified in RFC 2328.

RFC 1583 specifies a method for calculating the metric for summary routes based on the minimum metric of the component paths available. RFC 2328 specifies a method for calculating metrics based on maximum cost.

It is possible that some ABRs in an area might conform to RFC 1583 and others support RFC 2328, which could lead to incompatibility in their interoperation. This command addresses this issue by allowing you to selectively disable compatibility with RFC 2328.

Use the no form of this command to disable RFC 1583 compatibility.

Syntax `compatible rfc1583`
 `no compatible rfc1583`

Mode Router Configuration

Examples

```
awplus# configure terminal
awplus(config)# router ospf 100
awplus(config-router)# compatible rfc1583
```

debug ospf events

This command enables OSPF debugging for OSPF event troubleshooting.

To enable all debugging options, specify `debug ospf event` with no additional parameters.

The `no` and `undebug` form disables OSPF debugging. Use this command without parameters to disable all the options.

Syntax

```
debug ospf events [abr] [asbr] [lsa] [nssa] [os] [router] [vlink]
no debug ospf events [abr] [asbr] [lsa] [nssa] [os] [router] [vlink]
undebug ospf events [abr] [asbr] [lsa] [nssa] [os] [router] [vlink]
```

Parameter	Description
abr	shows ABR events.
asbr	shows ASBR events.
lsa	shows LSA events.
nssa	shows NSSA events.
os	shows OS interaction events.
router	shows other router events.
vlink	shows virtual link events.

Mode Privileged Exec and Global Configuration

Examples

```
awplus# debug ospf events asbr lsa
```

Related Commands [terminal monitor](#)

debug ospf ifsm

This command specifies debugging options for OSPF Interface Finite State Machine (IFSM) troubleshooting.

To enable all debugging options, specify debug ospf ifsm with no additional parameters. The no and undebug form disables OSPF IFSM debugging. Use this command without parameters to disable all the options.

Syntax

```
debug ospf ifsm [status] [events] [timers]
no debug ospf ifsm [status] [events] [timers]
undebug ospf ifsm [status] [events] [timers]
```

Parameter	Description
events	Displays IFSM event information.
status	Displays IFSM status information.
timers	Displays IFSM timer information.

Mode Privileged Exec and Global Configuration

Examples

```
awplus# no debug ospf ifsm events status
awplus# debug ospf ifsm status
awplus# debug ospf ifsm timers
```

Related Commands [terminal monitor](#)

debug ospf lsa

This command enables debugging options for OSPF Link State Advertisements (LSA) troubleshooting. This displays information related to internal operations of LSAs.

To enable all debugging options, specify `debug ospf lsa` with no additional parameters.

The `no` and `undebug` form disables OSPF LSA debugging. Use this command without parameters to disable all the options.

Syntax `debug ospf lsa [flooding] [generate] [install] [maxage] [refresh]`
`no debug ospf lsa [flooding] [generate] [install] [maxage] [refresh]`
`undebug ospf lsa [flooding] [generate] [install] [maxage] [refresh]`

Parameter	Description
<code>flooding</code>	Displays LSA flooding.
<code>generate</code>	Displays LSA generation.
<code>install</code>	Show LSA installation.
<code>maxage</code>	Shows maximum age of the LSA in seconds.
<code>refresh</code>	Displays LSA refresh.

Mode Privileged Exec and Global Configuration

Output Figure 38-1: Example output from the `debug ospf lsa` command

```
2002/05/09 14:08:11 OSPF: LSA[10.10.10.10:10.10.10.70]: instance(0x8139cd0) created
with Link State Update
2002/05/09 14:08:11 OSPF: RECV[LS-Upd]: From 10.10.10.70 via vlan5:10.10.10.50
(10.10.10.10 -> 224.0.0.5)
2002/05/09 14:12:33 OSPF: SEND[LS-Upd]: Begin send queue
2002/05/09 14:12:33 OSPF: SEND[LS-Upd]: # of LSAs 1, destination 224.0.0.5
2002/05/09 14:12:33 OSPF: SEND[LS-Upd]: End send queue
2002/05/09 14:12:33 OSPF: SEND[LS-Upd]: To 224.0.0.5 via vlan5:10.10.10.50
```

Examples

```
awplus# undebug ospf lsa refresh
```

Related Commands `terminal monitor`

debug ospf nfsm

This command enables debugging options for OSPF Neighbor Finite State Machines (NFSMs).

To enable all debugging options, specify debug ospf nfsm with no additional parameters.

The no and undebug form disables OSPF NFSM debugging. Use this command without parameters to disable all the options.

Syntax

```
debug ospf nfsm [events] [status] [timers]
no debug ospf nfsm [events] [status] [timers]
undebug ospf nfsm [events] [status] [timers]
```

Parameter	Description
events	Displays NFSM event information.
status	Displays NFSM status information.
timers	Displays NFSM timer information.

Mode Privileged Exec and Global Configuration

Examples

```
awplus# debug ospf nfsm events
awplus# no debug ospf nfsm timers
awplus# undebug ospf nfsm events
```

Related Commands [terminal monitor](#)

debug ospf nsm

This command enables debugging options for the OSPF Network Service Module.

To enable both debugging options, specify debug ospf nsm with no additional parameters. The no and undebug form disables OSPF NSM debugging. Use this command without parameters to disable both options.

Syntax debug ospf nsm [interface] [redistribute]
 no debug ospf nsm [interface] [redistribute]
 undebug ospf nsm [interface] [redistribute]

Parameter	Description
interface	Specify NSM interface information.
redistribute	Specify NSM redistribute information.

Mode Privileged Exec and Global Configuration

Examples

```
awplus# debug ospf nsm interface
awplus# no debug ospf nsm redistribute
awplus# undebug ospf nsm interface
```

Related Commands [terminal monitor](#)

debug ospf packet

This command enables debugging options for OSPF packets.

To enable all debugging options, specify debug ospf packet with no additional parameters.

The no and undebug form disables OSPF packet debugging. Use this command without parameters to disable all options.

Syntax

```
debug ospf packet [dd] [detail] [hello] [ls-ack] [ls-request]
[ls-update] [recv] [send]

no debug ospf packet [dd] [detail] [hello] [ls-ack] [ls-request]
[ls-update] [recv] [send]

undebug ospf packet [dd] [detail] [hello] [ls-ack] [ls-request]
[ls-update] [recv] [send]
```

Parameter	Description
dd	Specifies debugging for OSPF database descriptions.
detail	Sets the debug option to detailed information.
hello	Specifies debugging for OSPF hello packets.
ls-ack	Specifies debugging for OSPF link state acknowledgments.
ls-request	Specifies debugging for OSPF link state requests.
ls-update	Specifies debugging for OSPF link state updates.
recv	Specifies the debug option set for received packets.
send	Specifies the debug option set for sent packets.

Mode Privileged Exec and Global Configuration

Examples

```
awplus# debug ospf packet detail
awplus# debug ospf packet dd send detail
awplus# no debug ospf packet ls-request recv detail
awplus# undebug ospf packet ls-request recv detail
```

Related Commands [terminal monitor](#)

debug ospf route

This command enables debugging of route calculation. Use this command without parameters to turn on all the options.

To enable all debugging options, specify debug ospf route with no additional parameters.

The no and undebug form disables OSPF route debugging. Use this command without parameters to disable all options.

Syntax

```
debug ospf route [ase] [ia] [install] [spf]
no debug ospf route [ase] [ia] [install] [spf]
undebug ospf route [ase] [ia] [install] [spf]
```

Parameter	Description
ia	Specifies the debugging of Inter-Area route calculation
ase	Specifies the debugging of external route calculation
install	Specifies the debugging of route installation
spf	Specifies the debugging of SPF calculation

Mode Privileged Exec and Global Configuration

Examples

```
awplus# debug ospf route
awplus# no debug ospf route ia
awplus# debug ospf route install
awplus# undebug ospf route install
```

Related Commands [terminal monitor](#)

default-information originate (OSPF)

This command creates a default external route into an OSPF routing domain.

When you use the default-information originate command to redistribute routes into an OSPF routing domain, then the system acts like an Autonomous System Boundary Router (ASBR). An ASBR does not by default, generate a default route into the OSPF routing domain.

When using this command, also specify the route-map WORD option to avoid a dependency on the default network in the routing table.

The metric-type is an external link type associated with the default route advertised into the OSPF routing domain. The value of the external route could be either Type 1 or 2. The default is Type 2.

The no form of this command disables this feature.

Syntax

```
default-information originate [always] [metric <metric>]
                             [metric-type <1-2>] [route-map <route-map>]

no default-information originate [always] [metric] [metric-type]
                             [route-map]
```

Parameter	Description
always	Used to advertise the default route regardless of whether there is a default route.
metric <metric>	The metric value used in creating the default route. Enter a value in the range 0-16777214. The default metric value is 10. The value used is specific to the protocol.
metric-type <1-2>	External metric type for default routes, either OSPF External Type 1 or Type 2 metrics. Enter the value 1 or 2.
route-map	Specifies to use a specific route-map.
<route-map>	The route-map name. It is a string comprised of any characters, numbers or symbols.

Mode Router Configuration

Examples

```
awplus# configure terminal
awplus(config)# router ospf 100
awplus(config-router)# default-information originate
always metric 23 metric-type 2
route-map myinfo
```

Related Commands route-map

default-metric (OSPF)

This command sets default metric values for the OSPF routing protocol.

The no form of this command returns OSPF to using built-in, automatic metric translations, as appropriate for each routing protocol.

Syntax `default-metric <0-16777214>`
`no default-metric [<0-16777214>]`

Parameter	Description
<1-16777214>	Default metric value appropriate for the specified routing protocol.

Mode Router Configuration

Usage A default metric facilitates redistributing routes even with incompatible metrics. If the metrics do not convert, the default metric provides an alternative and enables the redistribution to continue. The effect of this command is that OSPF will use the same metric value for all redistributed routes. Use this command in conjunction with the [redistribute \(OSPF\)](#) command.

Examples

```
awplus# configure terminal
awplus(config)# router ospf 100
awplus(config-router)# default-metric 100

awplus# configure terminal
awplus(config)# router ospf 100
awplus(config-router)# no default-metric
```

Related commands [redistribute \(OSPF\)](#)

distance (OSPF)

This command sets the administrative distance for OSPF routes based on the route type. Your switch uses this value to select between two or more routes to the same destination from two different routing protocols. The route with the smallest administrative distance value is added to the Forwarding Information Base (FIB). See [“Administrative Distance” on page 31.4](#) for more information.

Use the command `distance ospf` to set the distance for an entire category of OSPF routes, rather than the specific routes that pass an access list.

Use the command `distance <1-255>`, with no other parameter, to set the same distance for all OSPF route types.

The `no` form sets the administrative distance for all OSPF routes to the default of 110.

Syntax

```
distance <1-255>
distance ospf
    {external <1-255>|inter-area <1-255>|intra-area <1-255>}
no distance {ospf|<1-255>}
```

Parameter	Description
<1-255>	The OSPF routes Administrative Distance value.
external	Sets the distance for routes from other routing domains, learned by redistribution.
inter-area	Sets the distance for all routes from one area to another area.
intra-area	Sets the distance for all routes within an area.

Mode Router Configuration

Default The default OSPF administrative distance is 110. The default Administrative Distance for each type of route (intra, inter, or external) is 110.

Usage The administrative distance rates the trustworthiness of a routing information source. The distance could be any integer from 0 to 255. A higher distance value indicates a lower trust rating. For example, an administrative distance of 255 indicates that the routing information source cannot be trusted and should be ignored.

Use this command to set the distance for an entire group of routes, rather than a specific route that passes an access list.

Examples To set the following administrative distances for route types in OSPF 100:

- 20 for inter-area routes
- 10 for intra-area routes
- 40 for external routes

use the commands:

```
awplus(config)# router ospf 100
awplus(config-router)# distance ospf inter-area 20 intra-area 10
                        external 40
```

To set the administrative distance for all routes in OSPF 100 back to the default of 110, use the commands:

```
awplus(config)# router ospf 100
awplus(config-router)# no distance ospf
```


distribute-list (OSPF)

This command applies a filter to the choice of routes that will be redistributed from another routing protocol into OSPF.

The no form of this command removes the distribute command.

Syntax

```
distribute-list <list-name> in
distribute-list <list-name> out {bgp|connected|rip|static}
no distribute-list <list-name> in
no distribute-list <list-name> out {bgp|connected|rip|static}
```

Parameter	Description
<list-name>	Specifies the name of the access list.
in	Indicates that this applies to incoming advertised routes.
out	Indicates that this applies to outgoing advertised routes.
bgp	Specifies that this applies to the redistribution of BGP routes.
connected	Specifies that this applies to the redistribution of connected routes.
rip	Specifies that this applies to the redistribution of RIP routes.
static	Specifies that this applies to the redistribution of static routes.

Mode Router Configuration

Examples The following example shows the distribution of BGP routing updates based on access list 1 (network 172.10.0.0).

```
awplus# configure terminal
awplus(config)# access-list 1 permit 172.10.0.0
0.0.255.255
awplus(config)# router ospf 100
awplus(config-router)# distribute-list 1 out bgp
awplus(config-router)# redistribute bgp
```

Related Commands redistribute (OSPF)

host area

This command configures a stub host entry belonging to a particular area. You can use this command to advertise specific host routes in the router-LSA as stub link. Since stub host belongs to the specified router, specifying cost is optional.

The no form of this command removes the host area configuration.

Syntax `host <ip-address> area <area-id> [cost <0-65535>]`
`no host <ip-address> area <area-id> [cost <0-65535>]`

Parameter	Description
<code><ip-address></code>	The IPv4 address of the host, in dotted decimal notation.
<code><area-id></code>	The OSPF area ID of the transit area that configuring the stub host entry for. Use one of the following formats: ■ dotted decimal format, e.g., 0.0.1.2 ■ normal decimal format in the range <0-4294967295>, e.g., 258.
<code>cost <0-65535></code>	The cost for the stub host entry.

Mode Router Configuration

Default By default, no host entry is configured.

Examples

```
awplus# configure terminal
awplus(config)# router ospf 100
awplus(config-router)# host 172.16.10.100 area 1
awplus(config-router)# host 172.16.10.101 area 2 cost 10
```

ip ospf authentication

This command sets the authentication method used when sending and receiving OSPF packets on the current VLAN interface. The default is to use no authentication.

If no authentication method is specified in this command, then plain text authentication will be used.

The no form of this command disables the authentication.

Use the ip ospf authentication-key command to specify a Simple Text password. Use the ip ospf message-digest-key command to specify MD5 password.

Syntax `ip ospf [<ip-address>] authentication [message-digest|null]`
`no ip ospf [<ip-address>] authentication`

Parameter	Description
<ip-address>	The IP address of the interface.
message-digest	Use the message digest authentication.
null	Use no authentication. It overrides password or message-digest authentication of the interface.

Mode Interface Configuration for a VLAN interface.

Examples In this example, interface `vlan1` is configured to have no authentication. This will override any text or MD5 authentication configured on this interface.

```
awplus# configure terminal
awplus(config)# interface vlan1
awplus(config-if)# ip ospf authentication null
```

Related Commands `ip ospf authentication-key`
`area authentication`
`ip ospf message-digest-key`

ip ospf authentication-key

This command specifies an OSPF authentication password for the neighboring routers.

This command creates a password (key) that is inserted into the OSPF header when AlliedWare Plus™ software originates routing protocol packets. Assign a separate password to each network for different VLAN interfaces. All neighboring routers on the same network with the same password exchange OSPF routing data.

The key can be used only when authentication is enabled for an area. Use the area authentication command to enable authentication.

Simple password authentication allows a password to be configured for each area. Configure the routers in the same routing domain with the same password.

The no form of this command removes the OSPF authentication password.

Syntax `ip ospf [<ip-address>] authentication-key <pswd-long>`
`no ip ospf [<ip-address>] authentication-key`

Parameter	Description
<ip-address>	The IPv4 address of the interface, in dotted decimal notation.
<pswd-long>	Specifies the authentication password. The string by the end of line will be used.

Mode Interface Configuration for a VLAN interface.

Default By default, an authentication password is not specified.

Examples In the following example, an authentication key test is created on interface `vlan1` in area 0. Note that first authentication is enabled for area 0.

```
awplus# configure terminal
awplus(config)# router ospf 100
awplus(config-router)# network 10.10.10.0/24 area 0
awplus(config-router)# area 0 authentication
awplus(config-router)# exit
awplus(config)# interface vlan1
awplus(config-if)# ip ospf 3.3.3.3 authentication-key test
```

Related Commands [area authentication](#)
[ip ospf authentication](#)

ip ospf cost

This command explicitly specifies the cost of the link-state metric in a router-LSA.

The interface cost indicates the overhead required to send packets across a certain VLAN interface. This cost is stated in the Router-LSA's link. Typically, the cost is inversely proportional to the bandwidth of an interface. By default, the cost of a VLAN interface is calculated according to the following formula:

$$\text{reference bandwidth} / \text{interface bandwidth}$$

To set the VLAN interface cost manually, use this command.

The no form of this command resets the VLAN interface cost to the default value.

Syntax `ip ospf [<ip_address>] cost <1-65535>`
`no ip ospf [<ip_address>] cost`

Parameter	Description
<ip_address>	The IPv4 address of the interface, in dotted decimal notation.
<1-65535>	The link-state metric.

Mode Interface Configuration for a VLAN interface.

Default By default the reference bandwidth is 100 Mbps (10^8), but can be set to a different value by the command, [auto-cost reference bandwidth command on page 38.12](#).

Examples The following example shows setting ospf cost to 10 on interface `vlan25` for IP address 10.10.10.50

```
awplus# configure terminal
awplus(config)# interface vlan25
awplus(config-if)# ip ospf 10.10.10.50 cost 10
```

Related Commands [show ip ospf interface](#)
[auto-cost reference bandwidth](#)

ip ospf database-filter

This command turns on the LSA database-filter for a particular VLAN interface.

The no form of this command turns off the LSA database-filter.

Syntax `ip ospf [<ip_address>] database-filter all out`
`no ip ospf [<ip_address>] database-filter`

Parameter	Description
<ip_address>	The IPv4 address of the interface, in dotted decimal notation.

Mode Interface Configuration for a VLAN interface.

Default By default, all outgoing LSAs are flooded to the interface.

Usage OSPF floods new LSAs over all interfaces in an area, except the interface on which the LSA arrives. This redundancy ensures robust flooding. However, too much redundancy can waste bandwidth and might lead to excessive link and CPU usage in certain topologies, resulting in destabilizing the network. To avoid this, use the `ip ospf database-filter` command to block flooding of LSAs over specified interfaces.

Examples

```
awplus# configure terminal
awplus(config)# interface vlan1
awplus(config-if# ip ospf database-filter all out
```

ip ospf dead-interval

This command sets the interval during which no hello packets are received and after which a neighbor is declared dead.

The dead-interval is the amount of time that OSPF waits to receive an OSPF hello packet from the neighbor before declaring the neighbor is down. This value is advertised in the router's hello packets. It must be a multiple of the hello-interval and be the same for all routers on a specific network.

The no form of this command returns the interval to the default of 40 seconds. If you have configured this command specifying the IP address of the interface and want to remove the configuration, specify the IP address (no ip ospf <ip_address> dead-interval).

Syntax ip ospf [<ip_address>] dead-interval <1-65535>
no ip ospf [<ip_address>] dead-interval

Parameter	Description
<ip_address>	The IPv4 address of the interface, in dotted decimal notation.
<1-65545>	The interval in seconds. Default: 40

Mode Interface Configuration for a VLAN interface.

Examples The following example shows configuring the dead-interval to 10 seconds on interface vlan1.

```
awplus# configure terminal
awplus(config)# interface vlan1
awplus(config-if)# ip ospf dead-interval 10
```

Related Commands ip ospf hello-interval
show ip ospf interface

ip ospf disable all

This command completely disables OSPF packet processing on a VLAN interface. It overrides the [network area](#) command and disables the processing of packets on the specific interface.

Use the `no ip ospf disable all` command to restore OSPF packet processing on a selected interface.

Syntax `ip ospf disable all`
`no ip ospf disable all`

Mode Interface Configuration for a VLAN interface.

Example

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip ospf disable all
```


ip ospf hello-interval

This command specifies the interval between hello packets.

The hello-interval is advertised in the hello packets. Configure the same hello-interval for all routers on a specific network. A shorter hello interval ensures faster detection of topological changes, but results in more routing traffic.

The no form of this command returns the interval to the default of 10 seconds.

Syntax `ip ospf [<ip_address>] hello-interval <1-65535>`
`no ip ospf [<ip_address>] hello-interval`

Parameter	Description
<ip_address>	The IP address of the interface, in dotted decimal notation.
<1-65535>	The interval in seconds. Default: 10

Mode Interface Configuration for a VLAN interface.

Examples The following example shows setting the hello-interval to 3 seconds on interface VLAN 2.

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip ospf hello-interval 3
```

Related Commands `ip ospf dead-interval`
`show ip ospf interface`

ip ospf message-digest-key

This command registers an MD5 key for OSPF MD5 authentication.

Message Digest Authentication is a cryptographic authentication. A key (password) and key-id are configured on each router. The router uses an algorithm based on the OSPF packet, the key, and the key-id to generate a *message digest* that gets appended to the packet.

The no form of this command removes the MD5 key.

Syntax `ip ospf [<ip-address>] message-digest-key <key-id> md5 <pswd-long>`
`no ip ospf [<ip-address>] message-digest-key <key-id>`

Parameter	Description
<ip-address>	The IPv4 address of the interface, in dotted decimal notation.
<key-id>	A key ID number specified as an integer between 1 and 255.
md5	Use the MD5 algorithm.
<pswd-long>	The OSPF password. This is a string of 1 to 16 characters including spaces.

Mode Interface Configuration for a VLAN interface.

Default By default, there is no MD5 key registered.

Usage Use this command for uninterrupted transitions between passwords. It allows you to add a new key without having to delete the existing key. While multiple keys exist, all OSPF packets will be transmitted in duplicate; one copy of the packet will be transmitted for each of the current keys. This is helpful for administrators who want to change the OSPF password without disrupting communication. The system begins a rollover process until all the neighbors have adopted the new password. This allows neighboring routers to continue communication while the network administrator is updating them with a new password. The router will stop sending duplicate packets once it detects that all of its neighbors have adopted the new password.

Maintain only one password per interface, removing the old password whenever you add a new one. This will prevent the local system from continuing to communicate with the system that is using the old password. Removing the old password also reduces overhead during rollover. All neighboring routers on the same network must have the same password value to enable exchange of OSPF routing data.

Examples The following example shows OSPF authentication on the interface VLAN 5 when IP address has not been specified.

```
awplus# configure terminal
awplus(config)# interface vlan5
awplus(config-if)# ip ospf authentication message-digest
awplus(config-if)# ip ospf message-digest-key 1 md5 yourpass
```

The following example shows configuring OSPF authentication on the interface VLAN 2 for the IP address 1.1.1.1. (If the interface has two IP addresses assigned-- 1.1.1.1 & 2.2.2.2, OSPF authentication will be enabled only for the IP address 1.1.1.1)

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip ospf 1.1.1.1 authentication message-
digest
awplus(config-if)# ip ospf 1.1.1.1 message-digest-key 2 md5
yourpass
```

ip ospf mtu

This command sets the MTU size for OSPF. Whenever OSPF constructs packets, it uses VLAN interface MTU size as Maximum IP packet size. This command forces OSPF to use the specified value, overriding the actual VLAN interface MTU size.

The no form of this command to returns the MTU size to the default value.

Syntax `ip ospf mtu <576-65535>`

`no ip ospf mtu`

Mode Interface Configuration for a VLAN interface.

Default By default, OSPF uses interface MTU derived from the VLAN interface.

Usage This command allows an administrator to configure the MTU size recognized by the OSPF protocol. It does not configure the MTU settings on the VLAN interface. OSPF will not recognize MTU size configuration changes made to the kernel until the MTU size is updated through the CLI.

Examples

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip ospf mtu 1480
```

ip ospf mtu-ignore

Use this command to configure OSPF so that OSPF does not check the MTU size during DD (Database Description) exchange.

Use the `no` parameter with this command to make sure that OSPF checks the MTU size during DD exchange.

Syntax `ip ospf [<ip_address>] mtu-ignore`
`no ip ospf [<ip_address>] mtu-ignore`

Parameter	Description
<code><ip_address></code>	IPv4 address of the interface, in dotted decimal notation.

Mode Interface Configuration for a VLAN interface.

Usage By default, during the DD exchange process, OSPF checks the MTU size described in the DD packets received from the neighbor. If the MTU size does not match the interface MTU, the neighbor adjacency is not established. Using this command makes OSPF ignore this check and allows establishing of adjacency regardless of MTU size in the DD packet.

Examples

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-router)# ip ospf mtu-ignore
```

ip ospf network

This command configures the OSPF network type to a type different from the default for the particular VLAN interface.

The no form of this command returns the network type to the default for the particular VLAN interface.

Syntax `ip ospf network [broadcast | non-broadcast | point-to-point | point-to-multipoint]`
`no ip ospf network`

Parameter	Description
<code>broadcast</code>	Sets the network type to broadcast.
<code>non-broadcast</code>	Sets the network type to NBMA.
<code>point-to-multipoint</code>	Sets the network type to point-to-multipoint.
<code>point-to-point</code>	Sets the network type to point-to-point.

Mode Interface Configuration for a VLAN interface.

Mode The default is the `broadcast` OSPF network type for a VLAN interface.

Usage This command forces the interface network type to the specified type. Depending on the network type, OSPF changes the behavior of the packet transmission and the link description in LSAs.

Examples The following example shows setting the network type to point-to-point on the `vlan1` interface.

```
awplus# configure terminal
awplus(config)# interface vlan1
awplus(config-if)# ip ospf network point-to-point
```

ip ospf priority

This command sets the router priority, which is a parameter used in the election of the designated router for the network.

The no form of this command returns the router priority to the default of 1.

Syntax `ip ospf [<ip_address>] priority <priority>`
`no ip ospf [<ip_address>] priority`

Parameter	Description
<ip_address>	The IP address of the interface.
<priority>	<0-255>Specifies the Router Priority of the interface. Default value is 1.

Default The default priority is 1.

Mode Interface Configuration for a VLAN interface.

Usage Set the priority to help determine the OSPF Designated Router (DR) for a network. If two routers attempt to become the DR, the router with the higher router priority becomes the DR. If the router priority is the same for two routers, the router with the higher router ID takes precedence.

Only routers with nonzero router priority values are eligible to become the designated or backup designated router.

Configure router priority for multiaccess networks only and not for point-to-point networks.

Examples The following example shows setting the OSPF priority value to 3 on the `vlan2` interface.

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip ospf priority 3
```

Related Commands [ip ospf network](#)

ip ospf resync-timeout

Use this command to set the interval after which adjacency is reset if out-of-band resynchronization has not occurred. The interval period starts from the time a restart signal is received from a neighbor.

Use the `no` parameter with this command to return to the default value.

Syntax `ip ospf [<ip_address>] resync-timeout <1-65535>`
`no ip ospf [<ip_address>] resync-timeout`

Parameter	Description
<ip_address>	The IP address of the interface.
<1-65535>	Specifies the resynchronization timeout value of the interface in seconds.

Mode Interface Configuration for a VLAN interface.

Examples The following example shows setting the OSPF resynchronization timeout value to 65 seconds on the `vlan2` interface.

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip ospf resync-timeout 65
```

ip ospf retransmit-interval

Use this command to specify the time between link-state advertisement (LSA) retransmissions for adjacencies belonging to the interface.

Use the `no` parameter with this command to return to the default value of 5 seconds.

Syntax `ip ospf [<ip_address>] retransmit-interval <interval>`
`no ip ospf [<ip_address>] retransmit-interval`

Parameter	Description
<ip_address>	The IP address of the interface.
<interval>	<1-65535> Specifies the interval in seconds. The default interval is 5 seconds.

Mode Interface mode for a VLAN interface.

Usage After sending an LSA to a neighbor, the router keeps the LSA until it receives an acknowledgement. In case the router does not receive an acknowledgement during the set time (the retransmit interval value) it retransmits the LSA. Set the retransmission interval value conservatively to avoid needless retransmission. The interval should be greater than the expected round-trip delay between two routers.

Examples The following example shows setting the `ospf retransmit interval` to 6 seconds on the `vlan2` interface.

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip ospf retransmit-interval 6
```


ip ospf transmit-delay

Use this command to set the estimated time it takes to transmit a link-state-update packet on the VLAN interface.

Use the no parameter with this command to return to the default value of 1 second.

Syntax `ip ospf [<ip_address>] transmit-delay <delay>`
`no ip ospf [<ip_address>] transmit-delay`

Parameter	Description
<ip_address>	The IP address of the VLAN interface.
<delay>	<1-65535> Specifies the time, in seconds, to transmit a link-state update. The default interval is 1 second.

Mode Interface Configuration for a VLAN interface.

Default The default value is 1 second. The default is restored when the negated command is issued.

Usage The transmit delay value adds a specified time to the age field of an update. If the delay is not added, the time in which the LSA transmits over the link is not considered. This command is especially useful for low speed links. Add transmission and propagation delays when setting the transmit delay value.

Examples The following example shows setting the OSPF transmit delay time to 3 seconds on the vlan2 interface.

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip ospf transmit-delay 3
```

max-concurrent-dd

Use this command to set the limit for the number of Database Descriptors (DD) that can be processed concurrently.

Use the no max-concurrent-dd command to reset the limit for the number of Database Descriptors (DD) that can be processed concurrently.

Syntax max-concurrent-dd <1-65535>

no max-concurrent-dd

Parameter	Description
<1-65535>	Specify the number of DD processes.

Mode Router Configuration

Usage This command is useful when a router's performance is affected from simultaneously bringing up several OSPF adjacencies. This command limits the maximum number of DD exchanges that can occur concurrently per OSPF instance, thus allowing for all of the adjacencies to come up.

Examples The following example sets the max-concurrent-dd value to 4, so that only 4 DD exchanges will be processed at a time.

```
awplus# configure terminal
awplus(config)# router ospf 100
awplus(config-router# max-concurrent-dd 4
```

maximum-area

Use this command to set the maximum number of OSPF areas.

Use the no maximum-area command to set the maximum number of OSPF areas to the default value. The default value for the maximum number of OSPF areas is 4294967294.

Syntax maximum-area <1-4294967294>
 no maximum-area

Parameter	Description
<1-4294967294>	Specify the maximum number of OSPF areas.

Mode Router Configuration

Usage Use this command in router OSPF mode to specify the maximum number of OSPF areas.

Examples The following example sets the maximum number of OSPF areas to 2:

```
awplus# configure terminal
awplus(config)# router ospf 100
awplus(config-router)# maximum-area 2
```

The following example removes the maximum number of OSPF areas and resets to default:

```
awplus# configure terminal
awplus(config)# router ospf 100
awplus(config-router)# no maximum-area
```

neighbor (OSPF)

Use this command to inform the router of other neighboring routers that are connected to the same NBMA network.

Use the `no` parameter with this command to remove a configuration.

Syntax `neighbor <ip_address> [<cost>]{<priority>|<poll-interval>}`
`no neighbor <ip_address> [<cost>]{<priority>|<poll-interval>}`

Parameter	Description
<code><ip_address></code>	Specifies the interface IP address of the neighbor.
<code><priority></code>	<code>priority <0-255></code> specifies the router priority value of the non-broadcast neighbor associated with the specified IP address. The default value is 0. This keyword does not apply to point-to-multipoint interfaces.
<code><poll-interval></code>	<code>poll-interval <1-65535></code> Dead neighbor polling interval in seconds. It is recommended to set this value much higher than the hello interval. The default value is 120 seconds.
<code><cost></code>	<code>cost <1-65535></code> Specifies the link-state metric to this neighbor.

Mode Router Configuration

Usage To configure a neighbor on an NBMA network manually, use the `neighbor` command and include one neighbor entry for each known nonbroadcast network neighbor. The IP address used in this command is the neighbor's primary IP address on the interface where that neighbor connects to the NBMA network.

The poll interval is the reduced rate at which routers continue to send hello packets, when a neighboring router has become inactive. Set the poll interval to be much larger than hello interval.

Examples This example shows a neighbor configured with a priority value, poll interval time, and cost.

```
awplus# configure terminal
awplus(config)# router ospf 100
awplus(config-router)# neighbor 1.2.3.4 priority 1 poll-
interval 90
awplus(config-router)# neighbor 1.2.3.4 cost 15
```

network area

Use this command to enable OSPF routing with a specified Area ID on interfaces with IP addresses that match the specified network address.

Use the `no` parameter with this command to disable OSPF routing on the interfaces.

Syntax `network <network_address> area <area_id>`
`no network <network_address> area <area_id>`

Parameter	Description
<code><network_address></code>	<code>{<ip-network/m> <ip-addr> <reverse-mask>}</code>
<code><ip-network/m></code>	IP address of the network, entered in the form A.B.C.D/M: dotted decimal notation followed by a forward slash, and then the subnet mask length.
<code><ip-addr></code>	IPv4 network address, entered in the form A.B.C.D.
<code><reverse-mask></code>	Reverse mask in dotted decimal format. Note that the term reverse-mask is sometimes referred to as a Wildcard mask.
<code><area_id></code>	<code>{<ip-addr> <0-4294967295>}</code>
<code><ip-addr></code>	OSPF Area ID in IPv4 address format, in the form A.B.C.D.
<code><0-4294967295></code>	OSPF Area ID as 4 octets unsigned integer value.

Default No network area is configured by default.

Mode Router Configuration

Usage OSPF routing can be enabled per IPv4 subnet. The network address can be defined using either the prefix length or a wild card mask. A wild card mask is comprised of consecutive 0's as network bits and consecutive 1's as host bits.

Examples

```
awplus# configure terminal
awplus(config)# router ospf 100
awplus(config-router)# network 10.0.0.0/8 area 3
awplus(config-router)# network 10.0.0.0/8 area 1.1.1.1
```

ospf abr-type

Use this command to set an OSPF Area Border Router (ABR) type.

Use the no parameter with this command to revert the ABR type to the default setting (Cisco).

Syntax `ospf abr-type {cisco|ibm|standard}`
`no ospf abr-type {cisco|ibm|standard}`

Parameter	Description
cisco	Specifies an alternative ABR using Cisco implementation (RFC 3509). This is the default ABR type.
ibm	Specifies an alternative ABR using IBM implementation (RFC 3509).
standard	Specifies a standard behavior ABR (RFC 2328).

Default ABR type `Cisco`

Mode Router Configuration

Usage Specifying the ABR type allows better interoperability between different implementations. This command is specially useful in a multi-vendor environment. The different ABR types are:

- **Cisco ABR Type:** By this definition, a router is considered an ABR if it has more than one area actively attached and one of them is the backbone area.
- **Standard ABR Type:** By this definition, a router is considered an ABR if it has more than one area actively attached to it.
- **IBM ABR Type:** By this definition, a router is considered an ABR if it has more than one area actively attached and the backbone area is configured. In this case the configured backbone need not be actively connected.

Examples

```
awplus# configure terminal
awplus(config)# router ospf 100
awplus(config-router)# ospf abr-type ibm
```

ospf restart grace-period

Use this command to configure the grace-period for restarting OSPF routing.

Use the no parameter with this command to revert to the default grace-period.

Syntax ospf restart grace-period <1-1800>
no ospf restart grace-period

Parameter	Description
<1-1800>	Specifies the grace period in seconds.

Default In the AlliedWare Plus OSPF implementation, the default OSPF grace-period is 60 seconds.

Mode Global Configuration

Usage Use this command to enable the OSPF Graceful Restart feature and set the restart grace-period. Changes from the default restart grace-period are displayed in the running-config. The restart grace-period is not displayed in the running-config if it has been reset to the default using the no ospf restart grace-period command.

Examples To set the OSPF restart grace-period to 250 seconds, use the following commands:

```
awplus# configure terminal
awplus(config)# ospf restart grace-period 250
```

Validation Commands show running-config

Related Commands ospf restart helper
restart ospf graceful

ospf restart helper

Use this command to configure the helper behavior for the OSPF Graceful Restart feature.

Use the no parameter with this command to revert to the default.

Syntax `ospf restart helper`
 `{max-grace-period <1-1800>|never|only-reload|only-upgrade}`

`no ospf restart helper [max-grace-period]`

Parameter	Description
max-grace-period	Help only if received grace-period is less than specified value
<1-1800>	Maximum grace period to accept, in seconds.
never	Local Policy to never to act as Helper
only-reload	Help only on software reloads
only-upgrade	Help only on software upgrades
max-grace-period	Help only if received grace-period is less than this value

Mode Global Configuration

Default In the AlliedWare Plus OSPF implementation, the default OSPF grace-period is 60 seconds.

Usage The ospf restart helper command requires at least one parameter, but you may use more than one in the same command (excluding parameter never).

The no ospf restart helper command will turn off the OSPF restart helper, while the no ospf restart helper max-grace-period command will reset the max-grace-period rather than the helper policy itself.

Examples

```
awplus# configure terminal
awplus(config)# ospf restart helper only-reload
```

Related Commands [ospf restart grace-period](#)
[restart ospf graceful](#)

ospf router-id

```
awplus# configure terminal
```

```
awplus(config)# ospf restart helper only-reload
```

Use this command to specify a router ID for the OSPF process.

Use the no parameter with this command to disable this function.

Syntax `ospf router-id <ip_address>`
`no ospf router-id`

Parameter	Description
<code><ip_address></code>	Specifies the router ID in IPv4 address format.

Mode Router Configuration

Usage Configure each router with a unique router-id. In an OSPF router process that has active neighbors, a new router-id takes effect at the next reload or when you restart OSPF manually.

Examples The following example shows a specified router ID 2.3.4.5.

```
awplus# configure terminal
```

```
awplus(config)# router ospf 100
```

```
awplus(config-router)# ospf router-id 2.3.4.5
```

Related Commands `show ip ospf`

overflow database

Use this command to limit the maximum number of Link State Advertisements (LSAs) that can be supported by the current OSPF instance.

Use the no parameter with this command to have no limit on the maximum number of LSAs.

Syntax overflow database <0-4294967294> {hard|soft}
 no overflow database

Parameter	Description
<0-4294967294>	The maximum number of LSAs
hard	Shutdown occurs if the number of LSAs exceeds the specified value.
soft	Warning message appears if the number of LSAs exceeds the specified value.

Mode Router Configuration

Usage Use hard with this command if a shutdown is required if the number of LSAs exceeds the specified number. Use soft with this command if a shutdown is not required, but a warning message is required, if the number of LSAs exceeds the specified number.

Examples The following example shows setting the database overflow to 500, and a shutdown to occur, if the number of LSAs exceeds 500.

```
awplus# configure terminal
awplus(config)# router ospf 100
awplus(config-router)# overflow database 500 hard
```

overflow database external

Use this command to configure the size of the external database and the time the router waits before it tries to exit the overflow state.

Use the no parameter with this command to revert to default.

Syntax `overflow database external <max_lsas> <recover_time>`
`no overflow database external`

Parameter	Description
<code><max_lsas></code>	<code><0-2147483647></code> The maximum number of Link State Advertisements (LSAs). Note that this value should be the same on all routers in the AS.
<code><recover_time></code>	<code><0-65535></code> the number of seconds the router waits before trying to exit the database overflow state. If this parameter is 0, router exits the overflow state only after an explicit administrator command.

Mode Router Configuration

Usage Use this command to limit the number of AS-external-LSAs a router can receive, once it is in the wait state. It takes the number of seconds specified as the `<recover-time>` to recover from this state.

Examples The following example shows setting the maximum number of LSAs to 5 and the time to recover from overflow state to be 3:

```
awplus# configure terminal
awplus(config)# router ospf 100
awplus(config-router)# overflow database external 50 3
```

passive-interface (OSPF)

Use this command to suppress the sending of Hello packets on the specified interface.

Use the `no passive-interface` command to allow the sending of Hello packets on the specified interface.

Syntax `passive-interface {<interface>} [<ip_address>]`
`no passive-interface {<interface>} [<ip_address>]`

Parameter	Description
<code><interface></code>	The name of the interface.
<code><ip_address></code>	IP address of the interface.

Mode Router Configuration

Usage Configure an interface to be passive if you wish its connected route to be treated as an OSPF route (rather than an AS-external route), but do not wish to actually exchange any OSPF packets via this interface.

Examples

```
awplus(config)# router ospf 100
awplus(config-router)# passive-interface vlan2
```

redistribute (OSPF)

Use this command to redistribute routes from other routing protocols, static routes and connected routes into an ospf routing table.

Use the no parameter with this command to disable this function.

Syntax `redistribute {<protocol>} {METRIC|METRIC-TYPE|ROUTE-MAP|TAG}`
`no redistribute {<protocol>} {METRIC|METRIC-TYPE|ROUTE-MAP|TAG}`

Parameter	Description
<code><protocol></code>	{bgp rip connected static}
<code>bgp</code>	Specifies BGP routes.
<code>rip</code>	Specifies RIP routes.
<code>connected</code>	Specifies connected routes.
<code>static</code>	Specifies static routes.
<code>METRIC</code>	<code>metric <0-16777214></code> Specifies the external metric.
<code>METRIC-TYPE</code>	<code>metric-type {1 2}</code> Specifies the external metric-type.
<code>ROUTE-MAP</code>	<code>route-map WORD</code> Specifies name of the route-map.
<code>TAG</code>	<code>tag <0-4294967295></code> Specifies the external route tag.

Mode Router Configuration

Usage You use this command to inject routes, learnt from other routing protocols, into the OSPF domain to generate AS-external-LSAs. If a route-map is configured by this command, then that route-map is used to control which routes are redistributed and can set metric and tag values on particular routes.

The metric, metric-type, and tag values specified on this command are applied to any redistributed routes that are not explicitly given a different metric, metric-type, or tag value by the route map.

Examples The following example shows redistribution of bgp routes into ospf routing table, with metric 12.

```
awplus# configure terminal
awplus(config)# router ospf 100
awplus(config-router)# redistribute bgp metric 12
```

restart ospf graceful

Use this command to force the OSPF process to restart.

Syntax `restart ospf graceful [grace-period <1-1800>]`

Mode Privileged Exec

Default In the AlliedWare Plus OSPF implementation, the default OSPF grace-period is 60 seconds.

Usage After this command is executed, the OSPF process immediately shuts down. It notifies the system that OSPF has performed a graceful shutdown. Routes installed by OSPF are preserved until the grace-period expires.

- When a `restart ospf graceful` command is issued, the OSPF configuration is reloaded from the last saved configuration. Ensure you first issue the command `copy running-config startup-config`.

Examples

```
awplus# copy running-config startup-config
```

```
awplus# restart ospf graceful grace-period 200
```

Related Commands `ospf restart grace-period`
`ospf restart helper`

router ospf

Use this command to enter Router Configuration mode to configure an OSPF routing process. You must specify the process ID with this command for multiple OSPF routing processes on the switch.

Use the no parameter with this command to terminate an OSPF routing process. Use the no parameter with the process ID parameter, to terminate and delete a specific OSPF routing process. If no process ID is specified on the no command, then all OSPF routing processes are terminated, and all OSPF configuration is removed.

Syntax `router ospf <process-id>`
`no router ospf [<process-id>]`

Parameter	Description
<code><process-id></code>	<code><1-65535></code> Any positive integer identifying a routing process.

Default No routing process is defined by default.

Mode Global Configuration

Usage The process ID of OSPF is an optional parameter for the no router ospf command only. When removing all instances of OSPF, you do not need to specify each Process ID, but when removing particular instances of OSPF you must specify each Process ID to be removed.

Examples This example shows the use of this command to enter Router Configuration mode.

```
awplus# configure terminal
awplus(config)# router ospf 100
awplus(config-router)#
```

router-id

Use this command to specify a router ID for the OSPF process.

Use the `no` parameter with this command to force OSPF to use the previous OSPF router-id behavior.

Syntax `router-id <ip_address>`
`no router-id`

Parameter	Description
<code><ip_address></code>	Specifies the router ID in IPv4 address format.

Mode Router Configuration

Usage Configure each router with a unique router-id. In an OSPF router process that has active neighbors, a new router-id is used at the next reload or when you restart OSPF manually.

Examples The following example shows a fixed router ID 10.10.10.60

```
awplus# configure terminal
awplus(config)# router ospf 100
awplus(config-router)# router-id 10.10.10.60
```

Related Commands [show ip ospf](#)

show debugging ospf

Use this command to display which OSPF debugging options are currently enabled.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show debugging ospf`

Mode Privileged Exec

Examples To display which OSPF debugging options are currently enabled, use the command

```
awplus#show debugging ospf

OSPF debugging status:
  OSPF packet Link State Update debugging is on
  OSPF all events debugging is on
```


show ip ospf

Use this command to display general information about all OSPF routing processes. Include the process ID parameter with this command to display information about specified instances.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax show ip ospf
show ip ospf <process_id>

Parameter	Description
<process_id>	<0-65535> The ID of the router process for which information will be displayed. If this parameter is included, only the information for the specified routing process is displayed.

Mode Exec and Privileged Exec

Output Figure 38-2: Example output from the **show ip ospf** command

```
Routing Process "ospf 1" with ID 10.10.11.60
Process uptime is 46 minutes
Conforms to RFC2328, and RFC1583Compatibility flag is disabled
Supports only single TOS(TOS0) routes
Supports opaque LSA
This router is an ASBR (injecting external routing information)
SPF schedule delay 5 secs, Hold time between two SPFs 10 secs
Refresh timer 10 secs
Number of external LSA 1. Checksum Sum 0xBC1E
Number of non-default external LSA 1
External LSA database is unlimited.
Number of areas attached to this router: 1
  Area 0 (BACKBONE)
    Number of interfaces in this area is 1(1)
    Number of fully adjacent neighbors in this area is 1
    Area has no authentication
    SPF algorithm last executed 00:46:27.935 ago
    SPF algorithm executed 2 times
    Number of LSA 5. Checksum Sum 0x026a20
Routing Process "ospf 100" with ID 10.10.11.146
Process uptime is 0 minute
Conforms to RFC2328, and RFC1583Compatibility flag is disabled
Supports only single TOS(TOS0) routes
Supports opaque LSA
SPF schedule delay 5 secs, Hold time between two SPFs 10 secs
Refresh timer 10 secs
Number of external LSA 0. Checksum Sum 0x0
Number of non-default external LSA 0
External LSA database is unlimited.
Number of areas attached to this router: 1
  Area 1
    Number of interfaces in this area is 1(1)
    Number of fully adjacent neighbors in this area is 0
    Number of fully adjacent virtual neighbors through this
area is 0
    Area has no authentication
    SPF algorithm executed 0 times
    Number of LSA 1. Checksum Sum 0x00e3e2
```

Figure 38-3: Example output from the **show ip ospf <process_id>** command

```
Routing Process "ospf 100" with ID 10.10.11.146
Process uptime is 0 minute
Conforms to RFC2328, and RFC1583Compatibility flag is disabled
Supports only single TOS(TOS0) routes
Supports opaque LSA
SPF schedule delay 5 secs, Hold time between two SPFs 10 secs
Refresh timer 10 secs
Number of external LSA 0. Checksum Sum 0x0
Number of non-default external LSA 0
External LSA database is unlimited.
Number of areas attached to this router: 1
  Area 1
    Number of interfaces in this area is 1(1)
    Number of fully adjacent neighbors in this area is 0
    Number of fully adjacent virtual neighbors through this
area is 0
    Area has no authentication
    SPF algorithm executed 0 times
    Number of LSA 1. Checksum Sum 0x00e3e2
```

Examples To display general information about all OSPF routing processes, use the command:

```
awplus# show ip ospf
```

To display general information about OSPF routing process 100, use the command:

```
awplus# show ip ospf 100
```

Related Commands [router ospf](#)

show ip ospf border-routers

Use this command to display the ABRs and ASBRs for all OSPF instances. Include the process ID parameter with this command to view data about specified instances.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip ospf border-routers`
`show ip ospf <process-id> border-routers`

Parameter	Description
<process-id>	<0-65535> The ID of the router process for which information will be displayed.

Mode Exec and Privileged Exec

Output Figure 38-4: Example output from the **show ip ospf border-routers** command

```
OSPF process 1 internal Routing Table
Codes: i - Intra-area route, I - Inter-area route
i 10.15.0.1 [10] via 10.10.0.1, vlan2, ASBR, Area 0.0.0.0
i 172.16.10.1 [10] via 10.10.11.50, vlan3, ABR, ASBR, Area
0.0.0.0
```

Examples To display the ABRs and ASBRs for all OSPF instances, use the command:

```
awplus# show ip ospf border-routers
```

To display the ABRs and ASBRs for the specific OSPF instance 721, use the command:

```
awplus# show ip ospf 721 border-routers
```

show ip ospf database

Use this command to display a database summary for OSPF information. This command displays BGP tags for prefixes. Include the process ID parameter with this command to display information about specified instances.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show ip ospf database [self-originate|max-age]`
`show ip ospf <process_id> database [self-originate|max-age]`

Parameter	Description
<process_id>	<0-65535> The ID of the router process for which information will be displayed.
self-originate	Displays self-originated link states.
max-age	Displays LSAs in MaxAge list. It maintains the list of the all LSAs in the database which have reached the max-age which is 3600 seconds.

Mode Exec and Privileged Exec

Output Figure 38-5: Example output from the **show ip ospf database** command

```

      OSPF Router process 1 with ID (10.10.11.60)
      Router Link States (Area 0.0.0.1)
Link ID      ADV Router      Age  Seq#       CkSum  Link count
10.10.11.60  10.10.11.60      32  0x80000002  0x472b  1
      OSPF Router process 100 with ID (10.10.11.60)
      Router Link States (Area 0.0.0.0)
Link ID      ADV Router      Age  Seq#       CkSum  Link count
10.10.11.60  10.10.11.60      219 0x80000001  0x4f5d  0

```

Figure 38-6: Example output from the **show ip ospf database self-originate** command

```

      OSPF Router process 100 with ID (10.10.11.50)
      Router Link States (Area 0.0.0.1 [NSSA])
Link ID      ADV Router      Age  Seq#       CkSum  Link count
10.10.11.50  10.10.11.50      20  0x80000007  0x65c3  2
      Area-Local Opaque-LSA (Area 0.0.0.1 [NSSA])
Link ID      ADV Router      Age  Seq#       CkSum  Opaque ID
67.1.4.217   10.10.11.50      37  0x80000001  0x2129  66777
      AS-Global Opaque-LSA
Link ID      ADV Router      Age  Seq#       CkSum  Opaque ID
67.1.4.217   10.10.11.50      37  0x80000001  0x2daa  66777

```

Examples

```

awplus# show ip ospf database external 1.2.3.4 self-originate
awplus# show ip ospf database self-originate

```

show ip ospf database asbr-summary

Use this command to display information about the Autonomous System Boundary Router (ASBR) summary LSAs.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip ospf database asbr-summary [<ip-addr>]
[self-originate|<advrouter>]`

Parameter	Description
<advrouter>	adv-router <ip-address>
adv-router	Displays all the LSAs of the specified router.
<ip-addr>	A link state ID, as an IP address.
self-originate	Displays self-originated link states.

Mode Exec and Privileged Exec

Examples

```
awplus# show ip ospf database asbr-summary 1.2.3.4 self-originate
```

```
awplus# show ip ospf database asbr-summary self-originate
```

```
awplus# show ip ospf database asbr-summary 1.2.3.4 adv-router 2.3.4.5
```

show ip ospf database external

Use this command to display information about the external LSAs.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show ip ospf database external [<ip-addr>] [self-originate|<advrouter>]`

Parameter	Description
<advrouter>	adv-router <ip-address>
adv-router	Displays all the LSAs of the specified router.
<ip-addr>	A link state ID, as an IP address.
self-originate	Displays self-originated link states.

Mode Exec and Privileged Exec

Output Figure 38-7: Example output from the **show ip ospf database external self-originate** command

```

      OSPF Router process 100 with ID (10.10.11.50)
        AS External Link States
LS age: 298
Options: 0x2 (*|-|-|-|-|E|-)
LS Type: AS-external-LSA
Link State ID: 10.10.100.0 (External Network Number)
Advertising Router: 10.10.11.50
LS Seq Number: 80000001
Checksum: 0x7033
Length: 36
Network Mask: /24
    Metric Type: 2 (Larger than any link state path)
    TOS: 0
    Metric: 20
    Forward Address: 10.10.11.50
    External Route Tag: 0

```

Examples

```

awplus# show ip ospf database external 1.2.3.4 self-originate
awplus# show ip ospf database external self-originate
awplus# show ip ospf database external 1.2.3.4 adv-router
        2.3.4.5

```

show ip ospf database network

Use this command to display information about the network LSAs.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show ip ospf database network [<ip-addr>]
[self-originate|<advrouter>]`

Parameter	Description
<advrouter>	adv-router <ip-address>
adv-router	Displays all the LSAs of the specified router.
<ip-addr>	A link state ID, as an IP address.
self-originate	Displays self-originated link states.

Mode Exec and Privileged Exec

Output Figure 38-8: Example output from the **show ip ospf database network <ip-address>** command

```

      OSPF Router process 200 with ID (192.30.30.2)
      Net Link States (Area 0.0.0.0)
LS age: 1387
Options: 0x2 (*|---|E|)
LS Type: network-LSA
Link State ID: 192.10.10.9 (address of Designated Router)
Advertising Router: 192.30.30.3
LS Seq Number: 80000001
Checksum: 0xe1b0
Length: 32
Network Mask: /24
    Attached Router: 192.20.20.1
    Attached Router: 192.30.30.3
LS age: 1648
Options: 0x2 (*|---|E|)
LS Type: network-LSA
Link State ID: 192.30.30.3 (address of Designated Router)
Advertising Router: 192.30.30.3
LS Seq Number: 8000000f
Checksum: 0xe864
Length: 32
Network Mask: /24
    Attached Router: 192.30.30.2
    Attached Router: 192.30.30.3

```

Figure 38-9: Example output from the **show ip ospf database network** command

```

      OSPF Router process 200 with ID (192.30.30.2)
      Net Link States (Area 0.0.0.0)
LS age: 1175
Options: 0x2 (*|---|E|)
LS Type: network-LSA
Link State ID: 192.10.10.9 (address of Designated Router)
Advertising Router: 192.30.30.3
LS Seq Number: 80000002
Checksum: 0xdfb1
Length: 32
Network Mask: /24
    Attached Router: 192.20.20.1
    Attached Router: 192.30.30.3
LS age: 1327
Options: 0x2 (*|---|E|)
LS Type: network-LSA
Link State ID: 192.20.20.2 (address of Designated Router)
Advertising Router: 192.20.20.2
LS Seq Number: 8000000d
Checksum: 0xbce6
Length: 32
Network Mask: /24
    Attached Router: 192.20.20.1
    Attached Router: 192.20.20.2
LS age: 1278
Options: 0x2 (*|---|E|)
LS Type: network-LSA
Link State ID: 192.30.30.3 (address of Designated Router)
Advertising Router: 192.30.30.3
Advertising Router: 192.30.30.3
LS Seq Number: 80000001
Checksum: 0x0556
Length: 32
Network Mask: /24
    Attached Router: 192.30.30.2
    Attached Router: 192.30.30.3
LS age: 1436
Options: 0x2 (*|---|E|)
LS Type: network-LSA
Link State ID: 192.40.40.2 (address of Designated Router)
Advertising Router: 192.20.20.2
LS Seq Number: 8000000e
Checksum: 0xf173
Length: 32
Network Mask: /24
    Attached Router: 192.20.20.2
    Attached Router: 192.30.30.2

```

Examples

```

awplus# show ip ospf database network 1.2.3.4 self-originate

awplus# show ip ospf database network self-originate

awplus# show ip ospf database network 1.2.3.4 adv-router
2.3.4.5

```


show ip ospf database nssa-external

Use this command to display information about the NSSA external LSAs.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show ip ospf database nssa-external [<ip-address>]
[self-originate]<advrouter>]`

Parameter	Description
<advrouter>	adv-router <ip-address>
adv-router	Displays all the LSAs of the specified router.
<ip-address>	A link state ID, as an IP address.
self-originate	Displays self-originated link states.

Mode Exec and Privileged Exec

Output Figure 38-10: Example output from the **show ip ospf database nssa-external adv-router <ip-address>** command

```

      OSPF Router process 100 with ID (10.10.11.50)
          NSSA-external Link States (Area 0.0.0.0)
          NSSA-external Link States (Area 0.0.0.1 [NSSA])
LS age: 78
Options: 0x0 (*|---|---|---|)
LS Type: AS-NSSA-LSA
Link State ID: 0.0.0.0 (External Network Number For NSSA)
Advertising Router: 10.10.11.50
LS Seq Number: 80000001
Checksum: 0xc9b6
Length: 36
Network Mask: /0
    Metric Type: 2 (Larger than any link state path)
    TOS: 0
    Metric: 1
    NSSA: Forward Address: 0.0.0.0
--More--
      OSPF Router process 100 with ID (10.10.11.50)
          NSSA-external Link States (Area 0.0.0.0)
          NSSA-external Link States (Area 0.0.0.1 [NSSA])
LS age: 78
Options: 0x0 (*|---|---|---|)
LS Type: AS-NSSA-LSA
Link State ID: 0.0.0.0 (External Network Number For NSSA)
Advertising Router: 10.10.11.50
LS Seq Number: 80000001
Checksum: 0xc9b6
Length: 36
Network Mask: /0
    Metric Type: 2 (Larger than any link state path)
    TOS: 0
    Metric: 1
    NSSA: Forward Address: 0.0.0.0
    External Route Tag: 0
          NSSA-external Link States (Area 0.0.0.1 [NSSA])

```

Examples

```
awplus# show ip ospf database nssa-external 1.2.3.4 self-originate
```

```
awplus# show ip ospf database nssa-external self-originate
```

```
awplus# show ip ospf database nssa-external 1.2.3.4 adv-router 2.3.4.5
```

show ip ospf database opaque-area

Use this command to display information about the area-local (link state type 10) scope LSAs. Type-10 Opaque LSAs are not flooded beyond the borders of their associated area.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show ip ospf database opaque-area [<ip-address>]
[self-originate|<advrouter>]`

Parameter	Description
<advrouter>	adv-router <ip-address>
adv-router	Displays all the LSAs of the specified router.
<ip-address>	A link state ID, as an IP address.
self-originate	Displays self-originated link states.

Mode Exec and Privileged Exec

Output Figure 38-11: Example output from the **show ip ospf database opaque-area self-originate** command

```
OSPF Router process 100 with ID (10.10.11.50)
Area-Local Opaque-LSA (Area 0.0.0.0)
LS age: 262
Options: 0x2 (*|---|E|)
LS Type: Area-Local Opaque-LSA
Link State ID: 10.0.25.176 (Area-Local Opaque-Type/ID)
Opaque Type: 10
Opaque ID: 6576
Advertising Router: 10.10.11.50
LS Seq Number: 80000001
Checksum: 0xb413
Length: 26
```

Examples

```
awplus# show ip ospf database opaque-area 1.2.3.4 self-
originate

awplus# show ip ospf database opaque-area self-originate

awplus# show ip ospf database opaque-area 1.2.3.4 adv-router
2.3.4.5
```

show ip ospf database opaque-as

Use this command to display information about the link-state type 11 LSAs. This type of link-state denotes that the LSA is flooded throughout the Autonomous System (AS).

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip ospf database opaque-as [<ip-address>]
[self-originate|<advrouter>]`

Parameter	Description
<advrouter>	adv-router <ip-address>
adv-router	Displays all the LSAs of the specified router.
<ip-address>	A link state ID, as an IP address.
self-originate	Displays self-originated link states.

Mode Exec and Privileged Exec

Output Figure 38-12: Example output from the **show ip ospf database opaque-as self-originate** command

```

      OSPF Router process 100 with ID (10.10.11.50)
        AS-Global Opaque-LSA
LS age: 325
Options: 0x2 (*|---|E|)
LS Type: AS-external Opaque-LSA
Link State ID: 11.10.9.23 (AS-external Opaque-Type/ID)
Opaque Type: 11
Opaque ID: 657687
Advertising Router: 10.10.11.50
LS Seq Number: 80000001
Checksum: 0xb018
Length: 25

```

Examples

```

awplus# show ip ospf database opaque-as 1.2.3.4 self-originate

awplus# show ip ospf database opaque-as self-originate

awplus# show ip ospf database opaque-as 1.2.3.4 adv-router
2.3.4.5

```

show ip ospf database opaque-link

Use this command to display information about the link-state type 9 LSAs. This type denotes a link-local scope. The LSAs are not flooded beyond the local network.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show ip ospf database opaque-link [<ip-address>]
[self-originate|<advrouter>]`

Parameter	Description
<advrouter>	adv-router <ip-address>
adv-router	Displays all the LSAs of the specified router.
<ip-address>	A link state ID, as an IP address.
self-originate	Displays self-originated link states.

Mode Exec and Privileged Exec

Output Figure 38-13: Example output from the **show ip ospf database opaque-link <ip-address>** command

```
OSPF Router process 100 with ID (10.10.11.50)
  Link-Local Opaque-LSA (Link hme0:10.10.10.50)
LS age: 276
Options: 0x2 (*|---|E|)
LS Type: Link-Local Opaque-LSA
Link State ID: 10.0.220.247 (Link-Local Opaque-Type/ID)
Opaque Type: 10
Opaque ID: 56567
Advertising Router: 10.10.11.50
LS Seq Number: 80000001
Checksum: 0x744e
Length: 26
  Link-Local Opaque-LSA (Link hme1:10.10.11.50)
```

Examples

```
awplus# show ip ospf database opaque-link 1.2.3.4 self-
originate

awplus# show ip ospf database opaque-link self-originate

awplus# show ip ospf database opaque-link 1.2.3.4 adv-router
2.3.4.5
```

show ip ospf database router

Use this command to display information only about the router LSAs.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show ip ospf database router [<ip-address>]
[self-originate|<advrouter>]`

Parameter	Description
<advrouter>	adv-router <ip-address>
adv-router	Displays all the LSAs of the specified router.
<ip-address>	A link state ID, as an IP address.
self-originate	Displays self-originated link states.

Mode Exec and Privileged Exec

Output Figure 38-14: Example output from the **show ip ospf database router <ip-address>** command

```

      OSPF Router process 100 with ID (10.10.11.50)
        Router Link States (Area 0.0.0.0)
LS age: 878
Options: 0x2 (*|---|E|)
Flags: 0x3 : ABR ASBR
LS Type: router-LSA
Link State ID: 10.10.11.50
Advertising Router: 10.10.11.50
LS Seq Number: 80000004
Checksum: 0xe39e
Length: 36
  Number of Links: 1
    Link connected to: Stub Network
      (Link ID) Network/subnet number: 10.10.10.0
      (Link Data) Network Mask: 255.255.255.0
      Number of TOS metrics: 0
      TOS 0 Metric: 10
      Router Link States (Area 0.0.0.1)
LS age: 877
Options: 0x2 (*|---|E|)
Flags: 0x3 : ABR ASBR
LS Type: router-LSA
Link State ID: 10.10.11.50
Advertising Router: 10.10.11.50
LS Seq Number: 80000003
Checksum: 0xee93
Length: 36
  Number of Links: 1
    Link connected to: Stub Network
      (Link ID) Network/subnet number: 10.10.11.0
      (Link Data) Network Mask: 255.255.255.0
      Number of TOS metrics: 0
      TOS 0 Metric: 10

```

Examples

```
awplus# show ip ospf database router 1.2.3.4 self-originate
```

```
awplus# show ip ospf database router self-originate
```

```
awplus# show ip ospf database router 1.2.3.4 adv-router  
2.3.4.5
```

show ip ospf database summary

Use this command to display information about the summary LSAs.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show ip ospf database summary [<ip-address>]
[self-originate|<advrouter>]`

Parameter	Description
<advrouter>	adv-router <ip-address>
adv-router	Displays all the LSAs of the specified router.
<ip-address>	A link state ID, as an IP address.
self-originate	Displays self-originated link states.

Mode Exec and Privileged Exec

Output Figure 38-15: Example output from the `show ip ospf database summary <ip-address>` command

```
      OSPF Router process 100 with ID (10.10.11.50)
        Summary Link States (Area 0.0.0.0)
        Summary Link States (Area 0.0.0.1)
LS age: 1124
Options: 0x2 (*|---|E|)
LS Type: summary-LSA
Link State ID: 10.10.10.0 (summary Network Number)
Advertising Router: 10.10.11.50
LS Seq Number: 80000001
Checksum: 0x41a2
Length: 28
Network Mask: /24
      TOS: 0   Metric: 10
```


Figure 38-16: Example output from the **show ip ospf database summary self-originate** command

```

      OSPF Router process 100 with ID (10.10.11.50)
        Summary Link States (Area 0.0.0.0)
LS age: 1061
Options: 0x2 (*|---|E|)
LS Type: summary-LSA
Link State ID: 10.10.11.0 (summary Network Number)
Advertising Router: 10.10.11.50
LS Seq Number: 80000001
Checksum: 0x36ac
Length: 28
Network Mask: /24
      TOS: 0   Metric: 10
        Summary Link States (Area 0.0.0.1)
LS age: 1061
Options: 0x2 (*|---|E|)
LS Type: summary-LSA
Link State ID: 10.10.11.0 (summary Network Number)
Advertising Router: 10.10.11.50
LS Seq Number: 80000001
Checksum: 0x36ac
Length: 28
Network Mask: /24
      TOS: 0   Metric: 10
        Summary Link States (Area 0.0.0.1)
LS age: 1061
Options: 0x2 (*|---|E|)
LS Type: summary-LSA
Link State ID: 10.10.10.0 (summary Network Number)
Advertising Router: 10.10.11.50
LS Seq Number: 80000001
Checksum: 0x41a2
Length: 28
Network Mask: /24
      TOS: 0   Metric: 10

```

Figure 38-17: Example output from the **show ip ospf database summary adv-router <ip-address>** command

```

      OSPF Router process 100 with ID (10.10.11.50)
        Summary Link States (Area 0.0.0.0)
LS age: 989
Options: 0x2 (*|---|E|)
LS Type: summary-LSA
Link State ID: 10.10.11.0 (summary Network Number)
Advertising Router: 10.10.11.50
LS Seq Number: 80000001
Checksum: 0x36ac
Length: 28
Network Mask: /24
      TOS: 0   Metric: 10
        Summary Link States (Area 0.0.0.1)
LS age: 989
Options: 0x2 (*|---|E|)
LS Type: summary-LSA
Link State ID: 10.10.11.0 (summary Network Number)
Advertising Router: 10.10.11.50
LS Seq Number: 80000001
Checksum: 0x36ac
Length: 28
Network Mask: /24
      TOS: 0   Metric: 10

```

Examples

```
awplus# show ip ospf database summary 1.2.3.4 self-originate
awplus# show ip ospf database summary self-originate
awplus# show ip ospf database summary 1.2.3.4 adv-router
2.3.4.5
```

show ip ospf interface

Use this command to display interface information for OSPF.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip ospf interface <interface-name>`

Parameter	Description
<interface-name>	An alphanumeric string that is the interface name.

Mode Exec and Privileged Exec

Output Figure 38-18: Example output from the `show ip ospf interface <interface-name>` command

```
vlan2 is up, line protocol is up
  Internet Address 1.1.1.1/24, Area 0.0.0.0, MTU 1500
  Process ID 0, Router ID 33.33.33.33, Network Type BROADCAST,
Cost: 10
  Transmit Delay is 1 sec, State Waiting, Priority 1, TE Metric 0
  No designated router on this network
  No backup designated router on this network
  Timer intervals configured, Hello 10, Dead 40, Wait 40,
Retransmit 5
  Hello due in 00:00:02
  Neighbor Count is 0, Adjacent neighbor count is 0
  Crypt Sequence Number is 1106347721
  Hello received 0 sent 1, DD received 0 sent 0
  LS-Req received 0 sent 0, LS-Upd received 0 sent 0
  LS-Ack received 0 sent 0, Discarded 0
```

Examples

```
awplus# show ip ospf interface port1.0.2
```

show ip ospf neighbor

Use this command to display information on OSPF neighbors. Include the process ID parameter with this command to display information about specified instances.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax

```
show ip ospf [<ospf-id>] neighbor <ip-addr> [detail]
show ip ospf [<ospf-id>] neighbor detail [all]
show ip ospf [<ospf-id>] neighbor [all]
show ip ospf [<ospf-id>] neighbor interface <ip-addr>
```

Parameter	Description
<ospf-id>	<0-65535> The ID of the router process for which information will be displayed.
<ip-addr>	The Neighbor ID, entered as an IP address.
all	Include downstatus neighbor
detail	Detail of all neighbors
interface <ip-addr>	IP address of the interface.

Mode Exec and Privileged Exec

Examples

```
awplus# show ip ospf neighbor detail
awplus# show ip ospf neighbor 1.2.3.4
awplus# show ip ospf neighbor interface 10.10.10.50 detail all
```

Output Figure 38-19: Example output from the **show ip ospf neighbor** command

```
OSPF process 1:
Neighbor ID    Pri   State           Dead Time   Address      Interface
10.10.10.50    1     Full/DR         00:00:38   10.10.10.50  vlan1
OSPF process 100:
Neighbor ID    Pri   State           Dead Time   Address      Interface
10.10.11.50    1     Full/Backup     00:00:31   10.10.11.50  vlan2
awplus#show ip ospf 1 neighbor
OSPF process 1:
Neighbor ID    Pri   State           Dead Time   Address      Interface
10.10.10.50    1     Full/DR         00:00:38   10.10.10.50  vlan1
```

Figure 38-20: Example output from the **show ip ospf <ospf-id> neighbor** command

```
OSPF process 100:
Neighbor ID    Pri   State           Dead Time   Address      Interface
10.10.11.50    1     Full/Backup     00:00:31   10.10.11.50  vlan2
```

Figure 38-21: Example output from the **show ip ospf neighbor detail** command

```
Neighbor 10.10.10.50, interface address 10.10.10.50
  In the area 0.0.0.0 via interface vlan5
  Neighbor priority is 1, State is Full, 5 state changes
  DR is 10.10.10.50, BDR is 10.10.10.10
  Options is 0x42 (*|O|-|-|-|E|-)
  Dead timer due in 00:00:38
  Neighbor is up for 00:53:07
  Database Summary List 0
  Link State Request List 0
  Link State Retransmission List 0
  Crypt Sequence Number is 0
  Thread Inactivity Timer on
  Thread Database Description Retransmission off
  Thread Link State Request Retransmission off
  Thread Link State Update Retransmission on
Neighbor 10.10.11.50, interface address 10.10.11.50
  In the area 0.0.0.0 via interface vlan2
  Neighbor priority is 1, State is Full, 5 state changes
  DR is 10.10.11.10, BDR is 10.10.11.50
  Options is 0x42 (*|O|-|-|-|E|-)
  Dead timer due in 00:00:31
  Neighbor is up for 00:26:50
  Database Summary List 0
  Link State Request List 0
  Link State Retransmission List 0
  Crypt Sequence Number is 0
  Thread Inactivity Timer on
  Thread Database Description Retransmission off
  Thread Link State Request Retransmission off
  Thread Link State Update Retransmission on
```

show ip ospf route

Use this command to display the OSPF routing table. Include the `process ID` parameter with this command to display the OSPF routing table for specified instances.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show ip ospf [<ospf-id>] route`

Parameter	Description
<ospf-id>	<0-65535> The ID of the router process for which information will be displayed. If this parameter is included, only the information for this specified routing process is displayed.

Mode Exec and Privileged Exec

Examples To display the OSPF routing table, use the command:

```
awplus# show ip ospf route
```

Output Figure 38-22: Example output from the **show ip ospf route** command for a specific process

```
OSPF process 1:
Codes: C - connected, D - Discard, O - OSPF, IA - OSPF inter area
        N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
        E1 - OSPF external type 1, E2 - OSPF external type 2
O  10.10.0.0/24 [10] is directly connected, vlan1, Area 0.0.0.0
O  10.10.11.0/24 [10] is directly connected, vlan2, Area 0.0.0.0
O  10.10.11.100/32 [10] is directly connected, lo, Area 0.0.0.0
E2 10.15.0.0/24 [10/50] via 10.10.0.1, vlan1
IA 172.16.10.0/24 [30] via 10.10.11.50, vlan2, Area 0.0.0.0
E2 192.168.0.0/16 [10/20] via 10.10.11.50, vlan2
```

show ip ospf virtual-links

Use this command to display virtual link information.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show ip ospf virtual-links`

Mode Exec and Privileged Exec

Output Figure 38-23: Example output from the **show ip ospf virtual-links** command

```
Virtual Link VLINK0 to router 10.10.0.9 is up
  Transit area 0.0.0.1 via interface vlan5
  Transmit Delay is 1 sec, State Point-To-Point,
  Timer intervals configured, Hello 10, Dead 40, Wait 40,
  Retransmit 5
    Hello due in 00:00:02
    Adjacency state Full
Virtual Link VLINK1 to router 10.10.0.123 is down
  Transit area 0.0.0.1 via interface *
  Transmit Delay is 1 sec, State Down,
  Timer intervals configured, Hello 10, Dead 40, Wait 40,
  Retransmit 5
    Hello due in inactive
    Adjacency state Down
```

Examples To display virtual link information, use the command:

```
awplus# show ip ospf virtual-links
```

show ip protocols ospf

Use this command to display OSPF process parameters and statistics.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip protocols ospf`

Mode Exec and Privileged Exec

Output Figure 38-24: Example output from the **show ip protocols ospf** command

```
Routing Protocol is "ospf 200"
  Invalid after 0 seconds, hold down 0, flushed after 0
  Outgoing update filter list for all interfaces is
    Redistributed kernel filtered by filter1
  Incoming update filter list for all interfaces is
  Redistributing: kernel
  Routing for Networks:
    192.30.30.0/24
    192.40.40.0/24
  Routing Information Sources:
    Gateway          Distance          Last Update
  Distance: (default is 110)
    Address          Mask              Distance List
```

Examples To display OSPF process parameters and statistics, use the command:

```
awplus# show ip protocols ospf
```

summary-address

Use this command to suppress external routes that have the specified address range.

Use the `no summary-address` command to allow external routes that have the specified address range.

Syntax `summary-address <ip-addr/prefix-length> [not-advertise] [tag <0-4294967295>]`

`no summary-address <ip-addr/prefix-length> [not-advertise] [tag <0-4294967295>]`

Parameter	Description
<code><ip-addr/prefix-length></code>	The range of addresses given as IPv4 starting address and a prefix length.
<code>not-advertise</code>	Suppresses external routes.
<code>tag <0-4294967295></code>	The default tag value is 0.

Mode Router Configuration

Default The default tag value for a summary address is 0.

Usage An address range is a pairing of an address and a mask that is almost the same as IP network number. For example, if the specified address range is 192.168.0.0/255.255.240.0, it matches: 192.168.1.0/24, 192.168.4.0/22, 192.168.8.128/25 and so on.

Redistributing routes from other protocols into OSPF requires the router to advertise each route individually in an external LSA. Use the `summary address` command to advertise one summary route for all redistributed routes covered by a specified network address and mask. This helps decrease the size of the OSPF link state database.

Examples The following example uses the `summary-address` command to aggregate external LSAs that match the network 172.16.0.0/16 and assign a Tag value of 3.

```
awplus# configure terminal
awplus(config)# router ospf 100
awplus(config-router)# summary-address 172.16.0.0/16 tag 3
```


timers spf

Use this command to adjust route-calculation timers.

Use the no parameter with this command to return to the default timer values.

Syntax `timers spf <spf_delay> <spf_holdtime>`
`no timers spf`

Parameter	Description
<code><spf_delay></code>	<code><0-2147483647></code> Specifies the delay between receiving changed routing information and embarking on an SPF calculation.
<code><spf_holdtime></code>	<code><0-2147483647></code> Specifies the hold time between consecutive SPF calculations.

Mode Router Configuration

Default The default spf-delay value is 5 seconds. The default spf-holdtime value is 10 seconds.

Usage This command configures the delay time between the receipt of a topology change and the calculation of the Shortest Path First (SPF). This command also configures the hold time between two consecutive SPF calculations.

Examples

```
awplus# configure terminal
awplus(config)# router ospf 100
awplus(config-router)# timers spf 7 12
```


Chapter 39: BGP Configuration




Introduction.....	39.2
Enabling BGP Peers in the same AS	39.2
Enabling BGP between different Autonomous Systems.....	39.3
Route-Map.....	39.4
Route Reflector.....	39.7
Confederations.....	39.9

Introduction

This chapter contains basic BGP configuration examples. For details about the commands used in these examples, or the outputs from validation commands, see [Chapter 40, BGP Commands](#).

Enabling BGP Peers in the same AS

This example shows the minimum configuration required for enabling BGP on an interface. Peer 1 and Peer 2 are two BGP Peers belonging to the same Autonomous System, AS200, connecting to network 10.10.10.0/24. First, define the routing process and the AS number to which the peers belong. Then, define BGP neighbors to start exchanging routing updates.



Peer 1

```
awplus#
configure terminal  Enter the Configure mode.

awplus(config)#
router bgp 200      Define the routing process. The number 200 specifies the AS
                   number of Peer 1.

awplus(config-router)#
neighbor 10.10.10.11 remote-as 200  Define BGP neighbors. 10.10.10.11 is the IP address of the
                                   neighbor (Peer 2) and 200 is the neighbor's AS number.
```

Peer 2

```
awplusawplus#
configure terminal  Enter the Configure mode

awplus(config)#
router bgp 200      Define the routing process. The number 200 specifies the AS
                   number of Peer 2.

awplus(config-router)#
neighbor 10.10.10.10 remote-as 200  Define BGP neighbors. 10.10.10.10 is the IP address of the
                                   neighbor (Peer 1) and 200 is the neighbor's AS number.
```

Names of Commands Used


```
router bgp
neighbor remote-as
```

Validation Commands

```
show ip bgp summary
show ip bgp neighbors
```

Enabling BGP between different Autonomous Systems

This example shows the minimum configuration required for enabling BGP on an interface when the BGP peers belong to different Autonomous Systems. *Peer 1* and *Peer 2* are two BGP peers in different autonomous systems, AS200 and AS300 connecting to network 10.10.10.0/24.



Peer 1

```
awplus#
configure terminal  Enter the Configure mode.

awplus(config)#
router bgp 200      Define the routing process. The number 200 specifies the
                   AS number of Peer 1.

awplus(config-router)#
neighbor 10.10.10.11 remote-as 300  Define BGP neighbors. 10.10.10.11 is the IP address of the
                                     neighbor (Peer 2) and 300 is the neighbor's AS number.
```

Peer 2

<code>awplus#</code>	
<code>configure terminal</code>	Enter the Configure mode.
<code>awplus(config)#</code>	
<code>router bgp 300</code>	Define the routing process. The number 300 specifies the AS number of Peer 2.
<code>awplus(config-router)#</code>	
<code>neighbor 10.10.10.10 remote-as 200</code>	Define BGP neighbors. 10.10.10.10 is the IP address of the neighbor (Peer 1) and 200 is the neighbor's AS number.

Names of Commands Used


`router bgp`
`neighbor remote-as`

Validation Commands

`show ip bgp summary`
`show ip bgp neighbors`

Route-Map

Use route-maps to filter incoming updates from a BGP peer. In this example, a prefix-list `list1` on Peer 1 is configured to deny entry of any routes with the IP address `1.1.1.0/M` ($M = 26, 27, 28$). To test the filter, Peer 2 is configured to generate network addresses `1.1.1.0/27` and `1.1.2.0/24`. To verify, use the [show ip bgp command on page 40.110](#) on Peer 1; it displays Peer 1 receiving updates from only `1.1.2.0/24`.



Peer 1

awplus#	
<code>configure terminal</code>	Enter the Configure mode.
awplus(config)#	
<code>ip prefix-list prefixlist1 seq 5 deny 1.1.1.0/24 ge 26 le 28</code>	Create the prefix-list named prefixlist1 as shown opposite. prefixlist1 contains two entries. The first entry with a deny action is to not match any routes in the 1.1.1.0/24 range that have prefix lengths from 26 to 28 (inclusive). The second entry allows all other routes.
awplus(config)#	
<code>ip prefix-list prefixlist1 seq 10 permit any</code>	Also note the sequence number (seq 5 seq 10) in the prefix-list specifies the sequence for each entry.
awplus(config)#	
<code>route-map routemap1 permit 1</code>	Enter the route-map mode to set the match operation.
awplus(config-route-map)#	
<code>match ip address prefix-list prefixlist1</code>	Set the match criteria. This match criterion on this route-map entry is to match the incoming route updates against the prefix-list prefixlist1. If a route matches the permit criteria of the prefix-list prefixlist1, then packets are permitted by the route-map, since this route-map entry has a permit action. Because this is the only entry route-map, all routes that are not permitted by this entry route-map will be dropped.
awplus(config-route-map)#	
<code>exit</code>	Exit the Route-map mode and return to Configure mode.
awplus(config)#	
<code>router bgp 10</code>	Define the routing process. The number 10 specifies the AS number of R1.
awplus(config-router)#	
<code>neighbor 192.168.10.11 remote-as 11</code>	Define BGP neighbors. 192.168.10.11 is the IP address of the neighbor (Peer 2) and 11 is the neighbor's AS number.
awplus(config-router)#	
<code>neighbor 192.168.10.11 route-map routemap1 in</code>	The route-map is now applied as the filter for route updates that are received from the neighbor 192.168.10.11. Routes are accepted from the neighbor 192.168.10.11 if they match the permit criteria of route-map routemap1.

Peer 2

```
awplus(config)#
```

```
router bgp 11
```

 Define the routing process. The number 11 specifies the AS number of Peer 2.

```
awplus(config-router)#
```

```
neighbor 192.168.10.10 remote-as 10
```

 Define BGP neighbors. 192.168.10.10 is the IP address of the neighbor (Peer 1) and 10 is the neighbor's AS number.

```
awplus(config-router)#
```

```
network 1.1.1.0/27
```

 Specify a route to be advertised by the BGP routing process.

```
awplus(config-router)#
```

```
network 1.1.2.0/24
```

 Specify a route to be advertised by the BGP routing process.

Names of Commands Used


ip prefix-list
neighbor remote-as
route-map
match ip address
network (BGP)

Validation Commands

show ip bgp

Route Reflector

Use Route Reflector to reduce the iBGP mesh inside an AS. In this example, Peer 2, Peer 5 and Peer 4 would have to maintain a full mesh among themselves but by making Peer 5 the Route Reflector, Peer 2 (Client1) has an iBGP session with the Route Reflector only and not with Peer 4 (Client 2). The routes learned from Peer 2 are advertised to the other clients and to iBGP peers outside the cluster; the iBGP routes learned from iBGP peers outside the cluster are advertised to Peer 2. This reduces the iBGP peer connections in AS1.



Route Reflector (Peer 5)

<code>awplus#</code>	
<code>configure terminal</code>	Enter the Configure mode.
<code>awplus(config)#</code>	
<code>router bgp 1</code>	Define the routing process. The number 1 specifies the AS number of Peer 5.
<code>awplus(config-router)#</code>	
<code>neighbor 10.10.10.50 remote-as 1</code>	Define BGP neighbors. 10.10.10.50 is the IP address of one of the neighbors (Peer 2) and 1 is the neighbor's AS number.
<code>awplus(config-router)#</code>	
<code>neighbor 10.10.10.50 route-reflector client</code>	Configure Peer 5 as the Route-Reflector (RR) and neighbor Peer 2 as its client.
<code>awplus(config-router)#</code>	
<code>neighbor 10.10.11.50 remote-as 1</code>	Define BGP neighbor. 10.10.11.50 is the IP address of one of the neighbors (Peer 4) and 1 is the neighbor's AS number.
<code>awplus(config-router)#</code>	
<code>neighbor 10.10.11.50 route-reflector client</code>	Configure Peer 5 as the Route-Reflector (RR) and neighbor Peer 4 as its client.

Route Reflector Client 1 (Peer 2)

```
awplus(config)#
```

```
router bgp 1
```

Define the routing process. The number 1 specifies the AS number of Peer 2.

```
awplus(config-router)#
```

```
neighbor 10.10.10.10 remote-as 1
```

Define BGP neighbors. 10.10.10.10 is the IP address of the neighbor (Peer 5) and 1 is the neighbor's AS number.

Route Reflector Client 2 (Peer 4)

```
awplus(config)#
```

```
router bgp 1
```

Define the routing process. The number 1 specifies the AS number of Peer 4.

```
awplus(config-router)#
```

```
neighbor 10.10.11.10 remote-as 1
```


Define BGP neighbors. 10.10.11.10 is the IP address of the neighbor (Peer 5) and 1 is the neighbor's AS number.

Names of Commands Used neighbor remote-as
 neighbor route-reflector-client

Validation Commands show ip bgp
 show ip bgp neighbors

Confederations

In this example, AS1 contains three Confederation Autonomous Systems--AS 1000, AS 1001 and AS 1002. To any outside AS, the Confederation is a single Autonomous System AS1. Confederation eBGP is run between Peer 2 and Peer 5, and between Peer 5 and Peer 7. Peer 2 is configured so that its local AS is 1000. Its peer connection to Peer 5 is set up like any other eBGP session. The [bgp confederation identifier command on page 40.14](#) tells the peer that it is a member of a Confederation and the Confederation ID. The [bgp confederation peers command on page 40.15](#) lists the member autonomous system to which Peer 2 is connected. The command tells the BGP process that the eBGP connection is a Confederation eBGP rather than normal eBGP.



Peer 2

<code>awplus#</code>	
<code>configure terminal</code>	Enter the Configure mode.
<code>awplus(config)#</code>	
<code>router bgp 1000</code>	Define the routing process. The number 1000 specifies the AS number of Peer 2.
<code>awplus(config-router)#</code>	
<code>bgp confederation identifier 1</code>	Specify BGP Confederation Identifier. To routers outside the confederation, the whole confederation will appear as a single AS, and the identifier will appear as its AS number.
<code>awplus(config-router)#</code>	
<code>bgp confederation peers 1001 1002</code>	Specify AS 1001 and 1002 to become members of the Confederation.

Peer 2(Continued)

```

awplus(config-router)#
neighbor 10.10.10.5 remote-as 1001
awplus(config-router)#
neighbor 10.10.9.1 remote-as 1000
awplus(config-router)#
neighbor 10.10.7.3 remote-as 1000

```

Define BGP neighbors for Peer 2 by specifying the IP addresses and the AS numbers of neighbors.

Peer 5

```

awplus(config)#
router bgp 1001

```

Define the routing process. The number 1001 specifies the AS number of Peer 5.

```

awplus(config-router)#
bgp confederation identifier 1

```

Specify BGP Confederation Identifier. To routers outside the confederation, the whole confederation will appear as a single AS, and the identifier will appear as its AS number.

```

awplus(config-router)#
bgp confederation peers 1000 1002

```

Specify AS 1000 and 1002 to become members of the Confederation.

```

awplus(config-router)#
neighbor 10.10.10.2 remote-as 1000
awplus(config-router)#
neighbor 10.10.11.7 remote-as 1002
awplus(config-router)#
neighbor 10.10.13.6 remote-as 1001
awplus(config-router)#
neighbor 10.10.12.4 remote-as 1001

```

Define BGP neighbors for Peer 5 by specifying the IP addresses and the AS numbers of neighbors.

Peer 7

```

awplus(config)#
router bgp 1002

```

Define the routing process. The number 1001 specifies the AS number of Peer 5.

```

awplus(config-router)#
bgp confederation identifier 1

```

Specify BGP Confederation Identifier. To routers outside the confederation, the whole confederation will appear as a single AS, and the identifier will appear as its AS number.

```

awplus(config-router)#
bgp confederation peers 1000 1001

```

Specify AS 1000 and 1001 to become members of the Confederation.

```

awplus(config-router)#
neighbor 10.10.11.5 remote-as 1001
awplus(config-router)#
neighbor 10.10.15.8 remote-as 1002

```

Define BGP neighbors for Peer 7 by specifying the IP addresses and the AS numbers of neighbors.

Names of Commands Used

neighbor remote-as
bgp confederation peers
bgp confederation identifier

Validation Commands

show ip bgp
show ip bgp neighbors

Chapter 40: BGP Commands

Command List	40.4
address-family	40.4
aggregate-address (BGP)	40.5
auto-summary	40.6
bgp aggregate-nexthop-check	40.7
bgp always-compare-med	40.8
bgp bestpath as-path ignore	40.9
bgp bestpath compare-confed-aspath	40.9
bgp bestpath compare-routerid	40.10
bgp bestpath med	40.11
bgp client-to-client reflection	40.12
bgp cluster-id	40.13
bgp confederation identifier	40.14
bgp confederation peers	40.15
bgp config-type	40.16
bgp dampening	40.17
bgp default ipv4-unicast	40.18
bgp default local-preference	40.19
bgp deterministic-med	40.20
bgp enforce-first-as	40.21
bgp fast-external-failover	40.22
bgp graceful-restart	40.23
bgp log-neighbor-changes	40.24
bgp memory maxallocation	40.25
bgp multiple-instance	40.26
bgp rfc1771-path-select	40.26
bgp rfc1771-strict	40.27
bgp router-id	40.27
bgp scan-time	40.28
bgp update-delay	40.29
clear bgp *	40.30
clear bgp (ip address)	40.31
clear bgp (ASN)	40.32
clear bgp external	40.33
clear bgp peer-group	40.34
clear bgp view	40.35
clear ip bgp *	40.36
clear ip bgp (ip address)	40.37
clear ip bgp dampening	40.38
clear ip bgp flap-statistics	40.39
clear ip bgp (ASN)	40.40
clear ip bgp external	40.41
clear ip bgp peer-group	40.42
clear ip bgp view	40.44
debug bgp	40.45
distance (BGP)	40.46
exit-address-family	40.47

ip as-path access-list.....	40.48
ip community-list	40.49
ip community-list expanded.....	40.50
ip community-list standard	40.52
ip extcommunity-list expanded.....	40.54
ip extcommunity-list standard.....	40.56
neighbor activate	40.58
neighbor advertisement-interval.....	40.59
neighbor allowas-in.....	40.60
neighbor as-origination-interval.....	40.61
neighbor attribute-unchanged.....	40.62
neighbor capability dynamic	40.63
neighbor capability graceful-restart	40.64
neighbor capability orf prefix-list	40.65
neighbor capability route-refresh	40.66
neighbor collide-established	40.67
neighbor default-originate	40.68
neighbor description.....	40.69
neighbor distribute-list.....	40.70
neighbor dont-capability-negotiate	40.71
neighbor ebgp-multihop.....	40.72
neighbor enforce-multihop.....	40.73
neighbor filter-list.....	40.74
neighbor interface	40.75
neighbor maximum-prefix.....	40.76
neighbor next-hop-self	40.77
neighbor override-capability.....	40.78
neighbor passive.....	40.79
neighbor peer-group (adding a neighbor)	40.80
neighbor peer-group (creating a peer-group).....	40.81
neighbor port.....	40.82
neighbor prefix-list.....	40.83
neighbor remote-as.....	40.84
neighbor remove-private-AS.....	40.85
neighbor restart-time	40.86
neighbor route-map.....	40.87
neighbor route-reflector-client	40.88
neighbor route-server-client	40.90
neighbor send-community	40.91
neighbor shutdown	40.92
neighbor soft-reconfiguration inbound	40.93
neighbor strict-capability-match	40.94
neighbor timers	40.95
neighbor transparent-as.....	40.96
neighbor transparent-nexthop.....	40.97
neighbor unsuppress-map	40.98
neighbor update-source	40.99
neighbor version	40.100
neighbor weight.....	40.101
network (BGP)	40.102
network synchronization.....	40.103
redistribute route-map	40.104
restart bgp graceful.....	40.105
router bgp.....	40.106
router bgp view.....	40.107
show bgp memory maxallocation	40.108
show debugging bgp.....	40.109

show ip bgp	40.110
show ip bgp attribute-info.....	40.111
show ip bgp cidr-only	40.112
show ip bgp community.....	40.113
show ip bgp community-info.....	40.114
show ip bgp community-list	40.114
show ip bgp dampening	40.115
show ip bgp filter-list.....	40.116
show ip bgp inconsistent-as	40.117
show ip bgp longer-prefixes.....	40.118
show ip bgp neighbors	40.119
show ip bgp paths.....	40.121
show ip bgp prefix-list	40.121
show ip bgp quote-regexp	40.122
show ip bgp regexp	40.122
show ip bgp route-map	40.123
show ip bgp scan	40.123
show ip bgp summary	40.124
show ip bgp view	40.125
show ip bgp view neighbors	40.126
show ip bgp view summary.....	40.127
show ip community-list.....	40.128
show ip extcommunity-list.....	40.128
show ip protocols bgp.....	40.129
synchronization	40.130
timers (BGP)	40.131
undebg bgp	40.132

Command List

This chapter provides an alphabetical reference of commands used to configure the Border Gateway Protocol (BGP). For more information, see [Chapter 39, BGP Configuration](#).

address-family

This command enters the IPv4 address-family command mode. In this mode you can configure address-family specific parameters.

Use the [exit-address-family](#) command to leave the address family mode and return to Router mode.

Syntax `address-family ipv4 [multicast|unicast]`

Parameter	Description
<code>ipv4</code>	Configure parameters relating to the BGP exchange of IPv4 prefixes.
<code>multicast</code>	Configure parameters relating to the BGP exchange of routes to multicast sources.
<code>unicast</code>	Configure parameters relating to the BGP exchange of routes to unicast destinations.

Mode Router mode

Usage If you specify address-family IPv4 multicast, you configure BGP to exchange routing information about how to reach multicast sources, instead of unicast destinations. The PIM Reverse Path Forwarding (RPF) process always checks whether a stream is arriving on the interface that faces towards the best route to the source address of the multicast stream.

In general, a router will look into the unicast IPv4 routing table to find the best route to the source. However, the BGP multicast extensions, which are configured in multicast address-family mode, enable the router to carry a separate route table specifically for looking up RPF routes to multicast source addresses. This enables a network to forward multicast data along different paths those used for forwarding unicast data.

Example

```
awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# neighbor 192.168.0.1 interface
port1.0.2
awplus(config-router)# address-family ipv4
awplus(config-router-af)# neighbor 192.168.0.1 activate
awplus(config-router-af)# exit-address-family
awplus(config-router)#
```

Related Commands [exit-address-family](#)

aggregate-address (BGP)

This command adds an aggregate route that can be advertised to BGP neighbors. This command creates an aggregate entry in the BGP routing table if the switch learns, by any means, any routes that are within the range configured by the aggregate address/mask.

The `no aggregate-address` command removes the aggregate configured by the `aggregate-address` command.

Syntax

```
aggregate-address <ipaddr/m> {summary-only|as-set}
no aggregate-address <ipaddr/m> {summary-only|as-set}
```

Parameter	Description
<ipaddr/m>	Specifies the aggregate IPv4 address and mask.
summary-only	Filters more specific routes from updates. Only the aggregate address/mask will be advertised, and none of the component addresses that fall within the range of the aggregate address/mask.
as-set	Generates AS set path information. The AS-path advertised with the aggregate is an unordered list of all the AS-numbers that appear in any of the AS-paths of the component routes, with each AS-number appearing just once in the list.

Mode Router mode

Usage If the `summary-only` parameter is specified, then only the aggregate address/mask will be advertised, and none of the component addresses that fall within the range of the aggregate address/mask. For example, if you configure:

```
awplus#configure terminal
awplus(config)#router bgp 100
awplus(config-router)#aggregate-address 172.0.0.0/8 summary-only
```

then the switch will advertise the prefix 172.0.0.0/8, but no component routes like 172.10.0.0/16

The `as-set` parameter controls the AS-path attribute that is advertised with the aggregate route. If the switch has learnt multiple routes that are within the range of the aggregate address/mask, and the AS-paths associated with those routes contain different sets of AS-numbers, then it is not possible to create a single AS-path that accurately represents the AS-paths of all those component routes. In this case, the switch will, by default, advertise a NULL AS-path with the aggregate.

Example

```
awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# aggregate-address 192.0.0.0/8 as-set
summary-only
```

Related Commands [match as-path](#)

auto-summary

Use this command to enable sending summarized routes by a BGP speaker to its peers in the router configuration mode or in the address-family configuration mode. BGP uses auto-summary to advertise summarized routes. Use the no form to disable BGP auto-summary.

Syntax auto-summary
 no auto-summary

Default The auto-summary function is disabled by default.

Mode Router mode and Address Family IPv4 mode

Usage If certain routes have already been advertised, enabling auto-summary results in non-summarized routes being withdrawn and only summarized routes are advertised. Summarized routes are advertised before non-summarized routes are withdrawn from all connected peers.

If certain routes have already been advertised, disabling auto-summary results in summarized routes being withdrawn and only non-summarized routes are advertised. Non-summarized routes are advertised before summarized routes are withdrawn from all connected peers.

Examples The following example enables auto-summary in Router mode:

```
awplus# configure
awplus(config)# router bgp 100
awplus(config-router)# auto-summary
```

The following example disables auto-summary in Router mode:

```
awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# no auto-summary
```

The following example enables auto-summary in Address Family IPv4 mode:

```
awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# address-family ipv4
awplus(config-router-af)# auto-summary
```

The following example disables auto-summary in Address Family IPv4 mode:

```
awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# address-family ipv4
awplus(config-router-af)# no auto-summary
```

bgp aggregate-nexthop-check

This command enables the BGP option to perform aggregation only when next-hop matches the specified IP address. By default this is disabled.

The no form disable this function.

Syntax `bgp aggregate-nexthop-check`
 `no bgp aggregate-nexthop-check`

Mode Global Configuration mode

Example

```
awplus# configure terminal
awplus(config)# bgp aggregate-nexthop-check
```

bgp always-compare-med

This command enables BGP to compare the Multi Exit Discriminator (MED) for paths from neighbors in different autonomous systems. By default this feature is disabled.

Multi Exit Discriminator (MED) is used in best path selection by BGP. MED is compared after BGP attributes weight, local preference, AS-path and origin have been compared and are equal.

By default, MED comparison is done only among routes from the same autonomous system (AS). Use the `bgp always-compare-mode` command to allow comparison of MEDs from different ASs.

A path with a lower MED value is preferred. For example, if the `bgp` table contains the following entries, and the `bgp always-compare-med` command has been issued to enable this feature:

```
Route1: as-path 400, med 300
```

```
Route2: as-path 200, med 200
```

```
Route3: as-path 400, med 250
```

Route1 is compared to Route2. Route2 is best of the two (lower MED). Next, Route2 is compared to Route3 and Route2 is chosen best path again (lower MED). If `always-compare-med` was disabled, MED is not taken into account when Route1 and Route2 are compared, because of different ASs and MED is compared for only Route1 and Route3. In this case, Route3 would be the best path. The selected route is also affected by the `bgp deterministic-med` command. See the `bgp deterministic-med` command for details.

If this command is used to compare MEDs for all paths, it should be configured on every BGP router in the AS.

The `no` form disallows the comparison.

Syntax `bgp always-compare-med`
`no bgp always-compare-med`

Mode Router mode

Example

```
awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# bgp always-compare-med
```

Related Commands `bgp bestpath med`
`bgp bestpath as-path ignore`
`bgp bestpath compare-routerid`
`bgp deterministic-med`

bgp bestpath as-path ignore

This command prevents the router from considering as-path as a factor in the algorithm for choosing a route.

The no form allows the router to consider as-path in choosing a route.

Syntax `bgp bestpath as-path ignore`
 `no bgp bestpath as-path ignore`

Mode Router mode

Example

```
awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# bgp bestpath as-path ignore
```

Related Commands [bgp always-compare-med](#)
 [bgp bestpath med](#)
 [bgp bestpath compare-routerid](#)

bgp bestpath compare-confed-aspath

This command specifies that the AS confederation path length must be used, when available, in the BGP best path decision process. It is effective only when `bgp bestpath as-path ignore` command has not been specified.

By default, if BGP receives routes with identical eBGP paths from eBGP peers, BGP does not continue to consider any AS confederation path length attributes that may be associated with the routes.

The `no bgp bestpath compare-confed-aspath` command returns the switch to the default state, where the switch ignores AS confederation path length in the BGP best path selection process.

Syntax `bgp bestpath compare-confed-aspath`
 `no bgp bestpath compare-confed-aspath`

Mode Router mode

Example

```
awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# bgp bestpath compare-confed-aspath
```

Related Commands [bgp bestpath as-path ignore](#)

bgp bestpath compare-routerid

By default, when comparing similar routes from peers, BGP does not consider the router ID of neighbors advertising the routes - BGP simply selects the first received route. Use the `bgp bestpath compare-routerid` command to include router ID in the selection process; similar routes are compared and the route with the lowest router ID is selected.

The `no bgp bestpath compare-routerid` command disables this feature, and returns the switch to the default state, where the switch ignores the router ID in the BGP best path selection process.

Syntax `bgp bestpath compare-routerid`
`no bgp bestpath compare-routerid`

Mode Router mode

Example

```
awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# bgp bestpath compare-routerid
```

Related Commands `show ip bgp`
`show ip bgp neighbors`

bgp bestpath med

This command controls how the Multi Exit Discriminator (MED) attribute comparison is performed. The `bgp bestpath med` command features the `confed` and `missing-as-worst` parameters relating to MED comparison.

Use the `no bgp bestpath med` command to prevent BGP from considering the MED attribute when comparing paths.

Syntax `bgp bestpath med {[confed] [missing-as-worst]}`

Parameter	Description
<code>confed</code>	Compares MED among confederation paths
<code>missing-as-worst</code>	Treats missing MED as the least preferred one

Mode Router mode

Usage The `confed` parameter enables MED comparison among paths learned from confederation peers. The MED attributes are compared only if there is no external AS (Autonomous System), where an external AS is one that is not within the confederation. If there is an external AS in the path, then the MED comparison is not made.

For example, in the following paths the MED value is not compared with `Path3` since it is not in the confederation. MED is compared for `Path1` and `Path2` only.

`Path1 = 32000 32004, med=4`

`Path2 = 32001 32004, med=2`

`Path3 = 32003 1, med=1`

The effect of the `missing-as-worst` parameter is to treat a missing MED attribute in a path as having a value of infinity, making the path without a MED value the least desirable path. If the `missing-as-worst` parameter is not configured, the missing MED attribute is assigned the value of 0, making the path with the missing MED attribute the best path.

Example

```
awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# bgp bestpath med missing-as-worst

awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# bgp bestpath med confed

awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# bgp bestpath med confed missing-as-worst
```

Related Commands [bgp always-compare-med](#)
[bgp bestpath as-path ignore](#)
[bgp deterministic-med](#)

bgp client-to-client reflection

This command restores route reflection from a BGP route reflector to clients.

The `bgp client-to-client reflection` command is used to configure routers as route reflectors. Route reflectors are used when all Interior Border Gateway Protocol (iBGP) speakers are not fully meshed. If the clients are fully meshed the route reflector is not required, use the `no bgp client-to-client reflection` command to disable the client-to-client route reflection.

When a router is configured as a route reflector, client-to-client reflection is enabled by default.

The `no` form turns off client-to-client reflection.

Syntax `bgp client-to-client reflection`
`no bgp client-to-client reflection`

Mode Router mode

Example

```
awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# no bgp client-to-client reflection
```

Related Commands [bgp cluster-id](#)
[neighbor route-reflector-client](#)
[show ip bgp](#)

bgp cluster-id

This command configures the cluster ID if the BGP cluster has more than one route reflector. A cluster includes one or more route reflectors and their clients. Usually, each cluster is identified by the router ID of its single route reflector, but to increase redundancy, a cluster may sometimes have more than one route reflector. All route reflectors in such a cluster are then identified by a cluster ID.

The `bgp cluster-id` command is used to configure the 4 byte cluster ID for clusters with more than one route reflector.

The `no bgp cluster-id` command removes the cluster ID.

Syntax `bgp cluster-id {<ip-address>|<cluster-id>}`
`no bgp cluster-id [<ip-address>]`

Parameter	Description
<code><cluster-id></code>	<code><1-4294967295></code> Route Reflector cluster-id as a 32 bit quantity
<code><ip-address></code>	<code>A.B.C.D</code> Route Reflector Cluster-id in IP address format

Mode Router mode

Usage The following configuration creates `cluster-id 5` including two route-reflector-clients.

```
awplus(config)# router bgp 200
awplus(config-router)# neighbor 2.2.2.2 remote-as 200
awplus(config-router)# neighbor 3.3.3.3 remote-as 200
awplus(config-router)# neighbor 3.3.3.3 route-reflector-client
awplus(config-router)# neighbor 5.5.5.5 remote-as 200
awplus(config-router)# neighbor 5.5.5.5 route-reflector-client
awplus(config-router)# neighbor 6.6.6.6 remote-as 200
awplus(config-router)# bgp cluster-id 5
```

Example To add a `bgp cluster-id` apply the example commands as shown below:

```
awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# bgp cluster-id 10.10.1.1
```

To remove a `bgp cluster-id` apply the example commands as shown below:

```
awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# no bgp cluster-id 10.10.1.1
```

Related Commands [bgp client-to-client reflection](#)
[neighbor route-reflector-client](#)
[show ip bgp](#)

bgp confederation identifier

This command specifies a BGP confederation identifier.

The no form removes all BGP confederation identifiers.

Syntax `bgp confederation identifier <1-65535>`
`no bgp confederation identifier`

Parameter	Description
<1-65535>	Set routing domain confederation AS number.

Mode Router mode

Usage Note that the no form of this command removes all BGP confederation identifiers.

Example

```
awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# bgp confederation identifier 1

awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# no bgp confederation identifier
```

Related Commands [bgp confederation peers](#)

bgp confederation peers

This command configures the Autonomous Systems (AS) that belong to the same confederation as the current switch.

A confederation allows an AS to be divided into several sub-ASs. The overall AS is given a confederation identifier. External routers view only the whole confederation as one AS, whose AS number is the confederation identifier. Each sub-AS is fully meshed within itself and is visible internally to the confederation.

Use the `bgp confederation peer` command to define the list of AS numbers of the sub-ASs in the confederation containing the current switch.

The `no bgp confederation peers` command removes an autonomous system from the confederation.

Syntax

```
bgp confederation peers <1-65535>
no bgp confederation peers <1-65535>
```

Parameter	Description
<1-65535>	AS numbers of eBGP peers that are under same confederation but in a different sub-AS.

Mode Router mode

Usage In the following configuration of Router1 the neighbor 172.210.30.2 and 172.210.20.1 have iBGP connection within AS 100. The neighbor 173.213.30.1 has an BGP connection, but it is within AS 200, which is part of the same confederation. The neighbor 6.6.6.6 has an eBGP connection to external AS 500.

In the configuration of Router2, neighbor 5.5.5.4 has an eBGP connection to confederation 300. Router2 does not know about the ASs 100 and 200, it only knows about confederation 300.

Router1

```
awplus(config)# router bgp 100
awplus(config-router)# bgp confederation identifier 300
awplus(config-router)# bgp confederation peers 200
awplus(config-router)# neighbor 172.210.30.2 remote-as 100
awplus(config-router)# neighbor 172.210.20.1 remote-as 100
awplus(config-router)# neighbor 173.213.30.1 remote-as 200
awplus(config-router)# neighbor 6.6.6.6 remote-as 300
```

Router2

```
awplus(config)# router bgp 500
awplus(config-router)# neighbor 5.5.5.4 remote-as 300
```

Example

```
awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# bgp confederation peers 1234
```

Related Commands [bgp confederation identifier](#)

bgp config-type

This command sets the BGP configuration type.

By default, the BGP configuration type is extended.

Syntax `bgp config-type {standard|extended}`

Parameter	Description
standard	Specifies the Industry standard style configuration. After setting the configuration to standard, make sure to use the neighbor send-community command to send out BGP community attributes. The no synchronization command is always shown in the configuration.
extended	Specifies the extended style configuration. The extended configuration type requires no specific configuration for sending out BGP standard community and extended community attributes. The no synchronization command is enabled by default in Global Configuration mode and not shown in configuration output.

Mode Global Configuration mode**Example**

```
awplus# configure terminal
awplus(config)# bgp config-type standard
```

Related Commands [neighbor send-community](#)

bgp dampening

This command enables BGP dampening and sets BGP dampening parameters.

Route dampening minimizes the instability caused by route flapping. A penalty is added for every flap in a flapping route. As soon as the total penalty reaches the suppress limit the advertisement of the route is suppressed. This penalty is decayed according to the configured half time value. Once the penalty is lower than the reuse limit, the route advertisement is unsuppressed.

The dampening information is purged from the router once the penalty becomes less than half of the reuse limit.

The no form disables BGP dampening or unsets the BGP dampening parameters.

Syntax

```
bgp dampening
no bgp dampening
bgp dampening <reachtime>
no bgp dampening <reachtime>
bgp dampening <reachtime> <reuse> <suppress> <maxsuppress>
<unreachtime>
no bgp dampening <reachtime> <reuse> <suppress> <maxsuppress>
<unreachtime>
bgp dampening route-map <routermap-name>
no bgp dampening route-map <routermap-name>
```

Parameter	Description
<reachtime>	<1-45> Specifies the reachability half-life time in minutes. The time for the penalty to decrease to one-half of its current value. The default is 15 minutes.
<reuse>	<1-20000> Specifies the reuse limit value. When the penalty for a suppressed route decays below the reuse value, the routes become unsuppressed. The default reuse limit is 750
<suppress>	<1-20000> Specifies the suppress limit value. When the penalty for a route exceeds the suppress value, the route is suppressed. The default suppress limit is 2000.
<maxsuppress>	<1-255> Specifies the max-suppress-time. Maximum time that a dampened route is suppressed. The default max-suppress value is 4 times the half-life time (60 minutes).
<unreachtime>	<1-45> Specifies the un-reachability half-life time for penalty, in minutes.
route-map	Route-map to specify criteria for dampening.
<routermap_name>	Specify the name of the route-map.

Mode Router mode

Example

```
awplus# configure terminal
awplus(config)# router bgp 11
awplus(config-router)# bgp dampening 20 800 2500 80 25
```

bgp default ipv4-unicast

This command configures BGP defaults and activate ipv4-unicast for a peer by default. This affects the BGP global configuration.

The no form disables this function. The BGP routing process will no longer exchange IPv4 addressing information with BGP neighbor routers.

Syntax `bgp default ipv4-unicast`
`no bgp default ipv4-unicast`

Default This is enabled by default.

Mode Router mode

Example

```
awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# bgp default ipv4-unicast
```


bgp default local-preference

This command changes the default local preference value.

The local preference indicates the preferred path when there are multiple paths to the same destination. The path with the higher preference is preferred.

Use this command to define the default local preference value that the switch will advertise for the routes it sends. The preference is sent to all routers and access servers in the local autonomous system.

The no form reverts to the default local preference value of 100.

Syntax `bgp default local-preference <pref_value>`
`no bgp default local-preference [<pref_value>]`

Parameter	Description
<pref_value>	<0-4294967295> Configure default local preference value. The default local preference value is 100.

Mode Router mode

Default By default the local-preference value is 100.

Example

```
awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# bgp default local-preference 2345555

awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# no bgp default local-preference
```

bgp deterministic-med

Use this command to allow or disallow the switch to compare the Multi Exit Discriminator (MED) variable when choosing among routes advertised by different peers in the same autonomous system (AS).

Use the `bgp deterministic-med` command to enable this feature to allow the comparison of MED variables when choosing among routes advertised by different peers in the same AS.

Use the `no bgp deterministic-med` command to disable this feature to disallow the comparison of the MED variable when choosing among routes advertised by different peers in the same AS.

Syntax `bgp deterministic-med`
`no bgp deterministic-med`

Default Disabled by default

Mode Router mode

Usage When the `bgp deterministic-med` command is enabled, routes from the same AS are grouped together and ordered according to their MED values, and the best routes of each group are compared.

The main benefit of this is that the choice of best route then does not depend on the order in which the routes happened to be received, which is rather random and arbitrary.

To see how this works, consider the following set of `bgp` table entries, all for the same route:

```
1: AS PATH 234, MED 120, internal, IGP metric to NEXT_HOP 40
2: AS PATH 389, MED 190, internal, IGP metric to NEXT_HOP 35
3: AS PATH 234, MED 245, external
```

If `bgp deterministic-med` is not enabled, then entry 3 : will be chosen, because it is an external route.

But if BGP deterministic-MED is enabled, the entries will be grouped as follows:

```
Group 1: 1: AS PATH 234, MED 120, internal, IGP metric to NEXT_HOP 40
          3: AS PATH 234, MED 245, external
Group 2: 2: AS PATH 389, MED 190, internal, IGP metric to NEXT_HOP 35
```

Note: *Routes from the same AS are grouped together and ordered by MED*

Entry 1 : is chosen as the best route from Group 1, since this route has the lowest MED value. Entry 2 has to be the best route in Group 2, since this is the only route in that group. These two group winners are compared against each other, and Entry 2 : is chosen as the best route because Entry 2 : has the lower metric to next-hop.

All routers in an AS should have the same setting for BGP deterministic-MED. All routers in an AS should have BGP deterministic-MED enabled with `bgp deterministic-med`, or all routers in an AS should have BGP deterministic-MED disabled with `no bgp-deterministic-med`.

In the example above, the MED values were not considered when comparing the winners of the two groups (the best routes from the different ASs). To use MED in the comparison of routes from different ASs, use the [bgp always-compare-med command on page 40.8](#).

Example

```
awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# bgp deterministic-med

awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# no bgp deterministic-med
```

Related Commands [show ip bgp](#)
 [show ip bgp neighbors](#)

bgp enforce-first-as

Use this command to enforce the denying of eBGP updates in which the neighbor's AS number is not the first AS in the AS-path attribute.

Use the no parameter with this command to disable this feature.

Syntax `bgp enforce-first-as`
 `no bgp enforce-first-as`

Mode Router mode

Usage This command specifies that any updates received from an external neighbor that do not have the neighbor's configured Autonomous System (AS) at the beginning of the AS_PATH in the received update must be denied. Enabling this feature adds to the security of the BGP network by not allowing traffic from unauthorized systems.

Example

```
awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# bgp enforce-first-as
```

bgp fast-external-failover

Use this command to reset a BGP session immediately, if the interface used for BGP connection goes down.

Use the no parameter with this command to disable this feature.

Syntax `bgp fast-external-failover`
 `no bgp fast-external-failover`

Default Enabled

Mode Router mode

Example

```
awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# bgp fast-external-failover
```

bgp graceful-restart

Use this command to enable BGP graceful-restart capabilities for restart and stalepath times.

Use the no bgp graceful-restart command to restore restart timers to their default settings.

Syntax `bgp graceful-restart`
`[restart-time <delay-value>|stalepath-time <delay-value>]`
`no bgp graceful-restart [restart-time|stalepath-time]`

Parameter	Description
restart-time	The maximum time needed for neighbors to restart, in seconds. The default restart-time is 120 seconds.
stalepath-time	The maximum time to retain stale paths from restarting neighbors, in seconds. The default stalepath-time is 120 seconds.
<delay-value>	<1-3600> Maximum time in seconds. Default is 120 seconds.

Default The default BGP graceful restart time is 120 seconds without restart-time or stalepath-time parameters specified. The default restart-time and stalepath-times are also 120 seconds.

Mode Router mode

Usage This command is used to set the maximum time that a graceful-restart neighbor waits to come back up after a restart. This value is applied to all neighbors unless you explicitly override it by configuring the corresponding value on the neighbor.

The restart-time parameter is used for setting the maximum time that a graceful-restart neighbor waits to come back up after a restart. This restart-time value is applied to neighbors unless you explicitly override it by configuring the corresponding value on the neighbor.

The stalepath-time parameter is used to set the maximum time to preserve stale paths from a gracefully restarted neighbor. All stalepaths, unless reinstated by the neighbor after a re-establishment, will be deleted when time, as specified by the stalepath-time parameter, expires.

Example

```
awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# bgp graceful-restart 150

awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# no bgp graceful-restart

awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# bgp graceful-restart restart-time 150
```

```
awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# no bgp graceful-restart restart-time 150
```

bgp log-neighbor-changes

Use this command to enable logging of status change messages without turning on debug bgp commands.

Use the no parameter with this command to disable this feature.

Syntax bgp log-neighbor-changes
 no bgp log-neighbor-changes

Default Disabled

Mode Router mode

Usage AlliedWare Plus™ provides other kinds of logging services for neighbor status, for example, debug bgp fsm, debug bgp events, etc. However, these commands create a significant hit in the logging performance. If you need to log neighbor status changes only, we recommend turning off all the debug commands, then use this command.

To see bgp neighbor changes in the log you need to set the log level to informational using the [log buffered \(filter\)](#) command in [Chapter 10, Logging Commands](#).

A sample output of this log is:

```
%Protocol-Severity-Events: Message-text
```

A sample output of the log for an interface down event is:

```
%BGP-5-ADJCHANGE: neighbor 10.10.0.24 Down Interface flap
```

The bgp log-neighbor-changes command, logs the following events:

- BGP Notification Received
- Erroneous BGP Update Received
- User reset request
- Peer time-out
- Peer Closing down the session
- Interface flap
- Router ID changed
- Neighbor deleted
- Member added to peer group
- Administrative shutdown
- Remote AS changed
- RR client configuration modification
- Soft reconfiguration modification

Example To enable the logging of bgp status changes without using the debug bgp command:

```
awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# bgp log-neighbor-changes
```

bgp memory maxallocation

This command allocates a maximum percentage of the RAM (Random Access Memory) available on the switch for BGP processes.

When this percentage is exceeded, BGP peering terminates and an out of resources error displays. The default setting for bgp memory maxallocation is 100% memory allocation.

The no bgp memory maxallocation command resets memory allocation to the default value.

Syntax bgp memory maxallocation <1-100>
no bgp memory maxallocation

Parameter	Description
<1-100>	Percentage of switch memory allocated to BGP processes. Note this is RAM (Random Access Memory), not switch flash memory.

Mode Global Configuration mode

Default BGP processes are allocated the maximum percentage of 100% of the switch's available RAM memory by default. Note only non-default BGP memory allocation values are shown in the running or startup configuration files:

```
awplus#show running-config
!
bgp memory maxallocation 50
!
```

Example To limit the maximum amount of memory used by BGP processes to 65% of the total RAM memory available on the switch, use the commands:

```
awplus# configure terminal
awplus(config)# bgp memory maxallocation 65
```

To return to the default 100% maximum RAM memory allocation available on the switch for BGP processes, use the commands:

```
awplus# configure terminal
awplus(config)# no bgp memory maxallocation
```

bgp multiple-instance

Use this command to enable or disable the bgp multiple instance support.

Use the **no** parameter with this command to disable this function.

Syntax `bgp multiple-instance`
 `no bgp multiple-instance`

Default No multiple-instance support

Mode Global Configuration mode

Example

```
awplus# configure terminal
awplus(config)# bgp multiple-instance
```

bgp rfc1771-path-select

Use this command to set RFC1771 compatible path selection mechanism.

Use the **no** parameter with this command to revert this setting.

Syntax `bgp rfc1771-path-select`
 `no bgp rfc1771-path-select`

Default Industry standard compatible path selection mechanism.

Mode Global Configuration mode

Example

```
awplus# configure terminal
awplus(config)# bgp rfc1771-path-select
```


bgp rfc1771-strict

Use this command to set the Strict RFC1771 setting.

Use the no parameter with this command to revert this setting.

Syntax `bgp rfc1771-strict`
`no bgp rfc1771-strict`

Default Disabled

Mode Global Configuration mode

Example

```
awplus# configure terminal
awplus(config)# bgp rfc1771-strict
```

bgp router-id

Use this command to configure the router identifier.

Use the no parameter with this command to disable this function.

Syntax `bgp router-id <routerid>`
`no bgp router-id [<routerid>]`

Parameter	Description
<code><routerid></code>	A.B.C.D Specifies the IP address without mask for a manually configured router ID.

Default In case the loopback interface is configured the router-id is set to the IP address of a loopback interface. If not, the highest IP address is the router-id.

Mode Router mode

Usage Use bgp router-id command to manually configure a fixed router ID as a BGP router identifier.

Example To configure a router ID with an IP address for a BGP router identifier, issue the commands listed below:

```
awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# bgp router-id 1.1.2.3
```

To disable the router ID for a BGP router identifier issue the commands listed below:

```
awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# no bgp router-id
```

bgp scan-time

Use this command to set the interval for BGP route next-hop scanning.

Use the no parameter with this command to disable this function.

Syntax `bgp scan-time <time>`
`no bgp scan-time [<time>]`

Parameter	Description
<time>	<0-60> Scanning interval in seconds. The default scanning interval is 60 seconds.

Mode Router mode

Usage Use this command to configure scanning intervals of BGP routers. This interval is the period after which router checks the validity of the routes in its database.

To disable BGP scanning, set the scan time interval to 0 seconds.

Example

```
awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# bgp scan-time 10
```

bgp update-delay

Use this command to specify the update-delay value for a graceful-restart capable router.

Use the no parameter with this command to revert to the default update-delay value.

Syntax `bgp update-delay <1-3600>`
 `no bgp update-delay [<1-3600>]`

Mode Router mode

Default The default update-delay value is 120 seconds.

Usage The update-delay value is the maximum time a graceful-restart capable router, which is restarting, will defer route-selection and advertisements to all its graceful-restart capable neighbors. This maximum time starts from the instance the first neighbor attains established state after restart. The restarting router prematurely terminates this timer when end-of-rib markers are received from all its graceful-restart capable neighbors.

Example

```
awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# bgp update-delay 345
```

clear bgp *

Use this command to reset the BGP connection for all peers.

Syntax

```
clear bgp *
clear bgp * in [prefix-filter]
clear bgp * out
clear bgp * soft [in|out]
```

Parameter	Description
*	Clears all bgp peers
in	Indicates that incoming advertised routes will be cleared.
prefix-filter	Specifies that a prefix-list will be sent, by the ORF mechanism, to those neighbors with which the ORF capability has been negotiated. The neighbors will be triggered to resend updates, which match the prefix-list filter, to the local router. The local router will then perform a soft reconfiguration.
out	Indicates that outgoing advertised routes will be cleared.
soft in	Soft inbound reset causes the neighbors to resend all their updates to the local switch, without resetting the connection or clearing the entries in the local switch. So, the local switch stores new updates, and uses them to systematically replace existing table entries. This process can use a considerable amount of memory.
soft out	Soft outbound reset causes the switch to simply resend all its updates to the specified neighbor(s), without resetting the connection, or clearing table entries.

Mode Privileged Exec mode

Example

```
awplus# clear bgp * soft in
awplus# clear bgp ipv6 * in prefix-filter
```

clear bgp (ip address)

Use this command to reset the BGP connection for specified peers.

Syntax

```
clear bgp <ip-address>
clear bgp <ip-address> in [prefix-filter]
clear bgp <ip-address> out
clear bgp <ip-address> soft [in|out]
```

Parameter	Description
<ip-address>	Specifies the IPv4 address of the neighbor whose connection is to be reset, entered in the form A.B.C.D.
in	Indicates that incoming advertised routes will be cleared.
prefix-filter	Specifies that a prefix-list will be sent, by the ORF mechanism, to those neighbors with which the ORF capability has been negotiated. The neighbors will be triggered to resend updates, which match the prefix-list filter, to the local router. The local router will then perform a soft reconfiguration.
out	Indicates that outgoing advertised routes will be cleared.
soft in	Soft inbound reset causes the neighbors to resend all their updates to the local switch, without resetting the connection or clearing the entries in the local switch. So, the local switch stores new updates, and uses them to systematically replace existing table entries. This process can use a considerable amount of memory.
soft out	Soft outbound reset causes the switch to simply resend all its updates to the specified neighbor(s), without resetting the connection, or clearing table entries.

Mode Privileged Exec mode

Example

```
awplus# clear bgp 3.3.3.3 soft in prefix-filter
awplus# clear bgp ipv6 2.2.2.2 out
```

clear bgp (ASN)

Use this command to reset the BGP connection for peers in the specified Autonomous System Number (ASN).

Syntax

```
clear bgp <asn>
clear bgp <asn> in [prefix-filter]
clear bgp <asn> out
clear bgp <asn> soft [in|out]
```

Parameter	Description
<asn>	<1-65535> The AS Number for which all routes will be cleared
in	Indicates that incoming advertised routes will be cleared.
prefix-filter	Specifies that a prefix-list will be sent, by the ORF mechanism, to those neighbors with which the ORF capability has been negotiated. The neighbors will be triggered to resend updates, which match the prefix-list filter, to the local router. The local router will then perform a soft reconfiguration.
out	Indicates that outgoing advertised routes will be cleared.
soft in	Soft inbound reset causes the neighbors to resend all their updates to the local switch, without resetting the connection or clearing the entries in the local switch. So, the local switch stores new updates, and uses them to systematically replace existing table entries. This process can use a considerable amount of memory.
soft out	Soft outbound reset causes the switch to simply resend all its updates to the specified neighbor(s), without resetting the connection, or clearing table entries.

Mode Privileged Exec mode

Example

```
awplus# clear bgp 300 soft in prefix-filter
awplus# clear bgp ipv6 500 soft out
awplus# clear bgp 300 soft in
awplus# clear bgp 1 in prefix-filter
```

clear bgp external

Use this command to reset the BGP connection for all external peers.

Syntax

```
clear bgp external
clear bgp external in [prefix-filter]
clear bgp external out
clear bgp external soft [in|out]
```

Parameter	Description
external	clears all external peers
in	Indicates that incoming advertised routes will be cleared.
prefix-filter	Specifies that a prefix-list will be sent, by the ORF mechanism, to those neighbors with which the ORF capability has been negotiated. The neighbors will be triggered to resend updates, which match the prefix-list filter, to the local router. The local router will then perform a soft reconfiguration.
out	Indicates that outgoing advertised routes will be cleared.
soft in	Soft inbound reset causes the neighbors to resend all their updates to the local switch, without resetting the connection or clearing the entries in the local switch. So, the local switch stores new updates, and uses them to systematically replace existing table entries. This process can use a considerable amount of memory.
soft out	Soft outbound reset causes the switch to simply resend all its updates to the specified neighbor(s), without resetting the connection, or clearing table entries.

Mode Privileged Exec mode

Example

```
awplus# clear bgp external soft in
awplus# clear bgp external in prefix-filter
```

clear bgp peer-group

Use this command to reset the BGP connection for all members of a peer group.

Syntax

```
clear bgp peer-group <peer-group>
clear bgp peer-group <peer-group> in [prefix-filter]
clear bgp peer-group <peer-group> out
clear bgp peer-group <peer-group> soft [in|out]
```

Parameter	Description
peer-group	clears all members of a peer group
<peer-group>	Name of the BGP peer group
in	Indicates that incoming advertised routes will be cleared.
prefix-filter	Specifies that a prefix-list will be sent, by the ORF mechanism, to those neighbors with which the ORF capability has been negotiated. The neighbors will be triggered to resend updates, which match the prefix-list filter, to the local router. The local router will then perform a soft reconfiguration.
out	Indicates that outgoing advertised routes will be cleared.
soft in	Soft inbound reset causes the neighbors to resend all their updates to the local switch, without resetting the connection or clearing the entries in the local switch. So, the local switch stores new updates, and uses them to systematically replace existing table entries. This process can use a considerable amount of memory.
soft out	Soft outbound reset causes the switch to simply resend all its updates to the specified neighbor(s), without resetting the connection, or clearing table entries.

Mode Privileged Exec mode

Example

```
awplus# clear bgp peer-group P1 soft in
awplus# clear bgp ipv6 peer-group P2 in
```


clear bgp view

Use this command to reset all BGP connections.

Syntax `clear bgp view <bgp-view> *`
`clear bgp view <bgp-view> * soft [in|out]`

Parameter	Description
*	Clears all bgp peers
<bgp-view>	Name of the BGP view
soft in	Soft inbound reset causes the neighbors to resend all their updates to the local switch, without resetting the connection or clearing the entries in the local switch. So, the local switch stores new updates, and uses them to systematically replace existing table entries. This process can use a considerable amount of memory.
soft out	Soft outbound reset causes the switch to simply resend all its updates to the specified neighbor(s), without resetting the connection, or clearing table entries.

Mode Privileged Exec mode

Example

```
awplus# clear bgp view instance1 * soft in
```

clear ip bgp *

Use this command to reset all BGP connections—either by fully resetting sessions, or by performing soft resets.

Syntax

```
clear ip bgp *
clear ip bgp * in [prefix-filter]
clear ip bgp * out
clear ip bgp * soft [in|out]
```

Parameter	Description
*	Clears all bgp peers
in	Indicates that incoming advertised routes will be cleared.
prefix-filter	Specifies that a prefix-list will be sent, by the ORF mechanism, to those neighbors with which the ORF capability has been negotiated. The neighbors will be triggered to resend updates, which match the prefix-list filter, to the local router. The local router will then perform a soft reconfiguration.
out	Indicates that outgoing advertised routes will be cleared.
soft in	Soft inbound reset causes the neighbors to resend all their updates to the local switch, without resetting the connection or clearing the entries in the local switch. So, the local switch stores new updates, and uses them to systematically replace existing table entries. This process can use a considerable amount of memory.
soft out	Soft outbound reset causes the switch to simply resend all its updates to the specified neighbor(s), without resetting the connection, or clearing table entries.

Mode Privileged Exec mode

Example

```
awplus# clear ip bgp *
awplus# clear ip bgp * ipv4 unicast in prefix-filter
```

clear ip bgp (ip address)

Use this command to reset the IPv4 BGP connection to the peer specified by the IP address.

Syntax

```
clear ip bgp <ip-address>
clear ip bgp <ip-address> in [prefix-filter]
clear ip bgp <ip-address> out
clear ip bgp <ip-address> soft [in|out]
clear ip bgp <ip-address> ipv4 {unicast|multicast}
clear ip bgp <ip-address> ipv4 {unicast|multicast} in [prefix-filter]
clear ip bgp <ip-address> ipv4 {unicast|multicast} out
clear ip bgp <ip-address> ipv4 {unicast|multicast} soft [in|out]
```

Parameter	Description
<ip-address>	Specifies the IPv4 address of the neighbor whose connection is to be reset, entered in the form A.B.C.D.
ipv4	Clears all IPv4 address family peers. Configure parameters relating to the BGP exchange of IPv4 prefixes.
in	Indicates that incoming advertised routes will be cleared.
prefix-filter	Specifies that a prefix-list will be sent, by the ORF mechanism, to those neighbors with which the ORF capability has been negotiated. The neighbors will be triggered to resend updates, which match the prefix-list filter, to the local router. The local router will then perform a soft reconfiguration.
out	Indicates that outgoing advertised routes will be cleared.
soft in	Soft inbound reset causes the neighbors to resend all their updates to the local switch, without resetting the connection or clearing the entries in the local switch. So, the local switch stores new updates, and uses them to systematically replace existing table entries. This process can use a considerable amount of memory.
soft out	Soft outbound reset causes the switch to simply resend all its updates to the specified neighbor(s), without resetting the connection, or clearing table entries.
unicast	unicast address family modifier. Configure parameters relating to the BGP exchange of routes to unicast destinations.
multicast	multicast address family modifier. Configure parameters relating to the BGP exchange of routes to multicast sources.

Mode Privileged Exec mode

Example

```
awplus# clear ip bgp 192.0.2.12 soft
awplus# clear ip bgp 192.0.2.5 ipv4 unicast out
awplus# clear ip bgp 192.0.2.11
```

clear ip bgp dampening

Use this command to clear route dampening information and unsuppress routes that have been suppressed routes.

Syntax `clear ip bgp dampening [<ip-address>|<ip-address/m>]`
`clear ip bgp ipv4 {unicast|multicast} dampening [<ip-address>|<ip-address/m>]`

Parameter	Description
<ip-address>	Specifies the IPv4 address for which BGP dampening is to be cleared, in dotted decimal format.
<ip-address/m>	Specifies the IPv4 address with mask for which BGP dampening is to be cleared, entered in the form A.B.C.D/M. Where M is the subnet mask
ipv4	Clears all IPv4 address family peers. Configure parameters relating to the BGP exchange of IPv4 prefixes.
unicast	unicast address family modifier. Configure parameters relating to the BGP exchange of routes to unicast destinations.
multicast	multicast address family modifier. Configure parameters relating to the BGP exchange of routes to multicast sources.

Mode Privileged Exec mode

Example

```
awplus# clear ip bgp dampening 10.10.0.121
awplus# clear ip bgp ipv4 unicast dampening
```

clear ip bgp flap-statistics

Use this command to clear the flap count and history duration for the specified prefixes.

Syntax `clear ip bgp flap-statistics [<ip-address>|<ip-address/m>]`
`clear ip bgp ipv4 {unicast|multicast} flap-statistics [<ip-address>|<ip-address/m>]`

Parameter	Description
<ip-address>	Specifies the IPv4 address for which BGP flap count and history duration are to be cleared.
<ip-address/m>	Specifies the IPv4 address with mask for which BGP flap count and history duration are to be cleared.
ipv4	Clears all IPv4 address family peers. Configure parameters relating to the BGP exchange of IPv4 prefixes.
unicast	unicast address family modifier. Configure parameters relating to the BGP exchange of routes to unicast destinations.
multicast	multicast address family modifier. Configure parameters relating to the BGP exchange of routes to multicast sources.

Mode Privileged Exec mode

Example

```
awplus# clear ip bgp flap-statistics 10.10.0.121
awplus# clear ip bgp ipv4 unicast flap-statistics
```

clear ip bgp (ASN)

Use this command to reset the BGP connections to all peers in a specified Autonomous System Number (ASN).

Syntax

```
clear ip bgp <asn>
clear ip bgp <asn> in [prefix-filter]
clear ip bgp <asn> out
clear ip bgp <asn> soft [in|out]
clear ip bgp <asn> ipv4 {unicast|multicast}
clear ip bgp <asn> ipv4 {unicast|multicast} in [prefix-filter]
clear ip bgp <asn> ipv4 {unicast|multicast} out
clear ip bgp <asn> ipv4 {unicast|multicast} soft [in|out]
```

Parameter	Description
<asn>	<1-65535> Specifies the AS Number for which all routes will be cleared
ipv4	Clears all IPv4 address family peers. Configure parameters relating to the BGP exchange of IPv4 prefixes.
in	Indicates that incoming advertised routes will be cleared.
prefix-filter	Specifies that a prefix-list will be sent, by the ORF mechanism, to those neighbors with which the ORF capability has been negotiated. The neighbors will be triggered to resend updates, which match the prefix-list filter, to the local router. The local router will then perform a soft reconfiguration.
out	Indicates that outgoing advertised routes will be cleared.
soft in	Soft inbound reset causes the neighbors to resend all their updates to the local switch, without resetting the connection or clearing the entries in the local switch. So, the local switch stores new updates, and uses them to systematically replace existing table entries. This process can use a considerable amount of memory.
soft out	Soft outbound reset causes the switch to simply resend all its updates to the specified neighbor(s), without resetting the connection, or clearing table entries.
unicast	unicast address family modifier. Configure parameters relating to the BGP exchange of routes to unicast destinations.
multicast	multicast address family modifier. Configure parameters relating to the BGP exchange of routes to multicast sources.

Mode Privileged Exec mode

Example

```
awplus# clear ip bgp 100
awplus# clear ip bgp 200 ipv4 unicast in prefix-filter
```

clear ip bgp external

Use this command to reset the BGP connections to all external peers.

Syntax

```
clear ip bgp external
clear ip bgp external in [prefix-filter]
clear ip bgp external out
clear ip bgp external soft [in|out]
clear ip bgp external ipv4 {unicast|multicast}
clear ip bgp external ipv4 {unicast|multicast} in [prefix-filter]
clear ip bgp external ipv4 {unicast|multicast} out
clear ip bgp external ipv4 {unicast|multicast} soft [in|out]
```

Parameter	Description
external	Clears all external peers
ipv4	Clears all IPv4 address family peers. Configure parameters relating to the BGP exchange of IPv4 prefixes.
in	Indicates that incoming advertised routes will be cleared.
prefix-filter	Specifies that a prefix-list will be sent, by the ORF mechanism, to those neighbors with which the ORF capability has been negotiated. The neighbors will be triggered to resend updates, which match the prefix-list filter, to the local router. The local router will then perform a soft reconfiguration.
out	Indicates that outgoing advertised routes will be cleared.
soft in	Soft inbound reset causes the neighbors to resend all their updates to the local switch, without resetting the connection or clearing the entries in the local switch. So, the local switch stores new updates, and uses them to systematically replace existing table entries. This process can use a considerable amount of memory.
soft out	Soft outbound reset causes the switch to simply resend all its updates to the specified neighbor(s), without resetting the connection, or clearing table entries.
unicast	unicast address family modifier. Configure parameters relating to the BGP exchange of routes to unicast destinations.
multicast	multicast address family modifier. Configure parameters relating to the BGP exchange of routes to multicast sources.

Mode Privileged Exec mode

Example

```
awplus# clear ip bgp external out
awplus# clear ip bgp external ipv4 unicast in prefix-filter
```

clear ip bgp peer-group

Use this command to reset the BGP connections to all members of a peer group.

Syntax

```
clear ip bgp peer-group <peer-name>
clear ip bgp peer-group <peer-name> in [prefix-filter]
clear ip bgp peer-group <peer-name> out
clear ip bgp peer-group <peer-name> soft [in|out]
clear ip bgp peer-group <peer-name> ipv4 {unicast|multicast}
clear ip bgp peer-group <peer-name> ipv4 {unicast|multicast} in
[prefix-filter]
clear ip bgp peer-group <peer-name> ipv4 {unicast|multicast} out
clear ip bgp peer-group <peer-name> ipv4 {unicast|multicast} soft
[in|out]
```

Parameter	Description
peer-group	Clears all members of a peer group
<peer-name>	Specifies the name of the peer group for which all members will be cleared.
ipv4	Clears all IPv4 address family peers. Configure parameters relating to the BGP exchange of IPv4 prefixes.
in	Indicates that incoming advertised routes will be cleared.
prefix-filter	Specifies that a prefix-list will be sent, by the ORF mechanism, to those neighbors with which the ORF capability has been negotiated. The neighbors will be triggered to resend updates, which match the prefix-list filter, to the local router. The local router will then perform a soft reconfiguration.
out	Indicates that outgoing advertised routes will be cleared.
soft in	Soft inbound reset causes the neighbors to resend all their updates to the local switch, without resetting the connection or clearing the entries in the local switch. So, the local switch stores new updates, and uses them to systematically replace existing table entries. This process can use a considerable amount of memory.
soft out	Soft outbound reset causes the switch to simply resend all its updates to the specified neighbor(s), without resetting the connection, or clearing table entries.
unicast	unicast address family modifier. Configure parameters relating to the BGP exchange of routes to unicast destinations.
multicast	multicast address family modifier. Configure parameters relating to the BGP exchange of routes to multicast sources.

Mode Privileged Exec mode

Example

```
awplus# clear ip bgp peer-group Peer1 out  
awplus# clear ip bgp peer-group mypeer ipv4 unicast in  
prefix-filter
```

clear ip bgp view

Use this command to reset connections with all the neighbors within the specified view.

The specified bgp view for this command is created using the [router bgp view](#) command.

Syntax

```
clear ip bgp view <bgp-view> *
clear ip bgp view <bgp-view> * in [prefix-filter]
clear ip bgp view <bgp-view> * out
clear ip bgp view <bgp-view> * soft [in|out]
clear ip bgp view <bgp-view> * ipv4 {unicast|multicast}
clear ip bgp view <bgp-view> * ipv4 {unicast|multicast} in [prefix-filter]
clear ip bgp view <bgp-view> * ipv4 {unicast|multicast} out
clear ip bgp view <bgp-view> * ipv4 {unicast|multicast} soft [in|out]
```

Parameter	Description
view	Specifies BGP view
<bgp-view>	Specifies the name of the view for which all routes will be cleared
*	Clears all peers
ipv4	Clears all IPv4 address family peers. Configure parameters relating to the BGP exchange of IPv4 prefixes.
in	Indicates that incoming advertised routes will be cleared.
prefix-filter	Specifies that a prefix-list will be sent, by the ORF mechanism, to those neighbors with which the ORF capability has been negotiated. The neighbors will be triggered to resend updates, which match the prefix-list filter, to the local router. The local router will then perform a soft reconfiguration.
out	Indicates that outgoing advertised routes will be cleared.
soft in	Soft inbound reset causes the neighbors to resend all their updates to the local switch, without resetting the connection or clearing the entries in the local switch. So, the local switch stores new updates, and uses them to systematically replace existing table entries. This process can use a considerable amount of memory.
soft out	Soft outbound reset causes the switch to simply resend all its updates to the specified neighbor(s), without resetting the connection, or clearing table entries.
unicast	unicast address family modifier. Configure parameters relating to the BGP exchange of routes to unicast destinations.
multicast	multicast address family modifier. Configure parameters relating to the BGP exchange of routes to multicast sources.

Mode Privileged Exec mode

Example

```
awplus# clear ip bgp view I4 * in prefix-filter
awplus# clear ip bgp view I2 ipv4 unicast soft in
```

Related Commands [router bgp view](#)

debug bgp

Use this command to turn on one or more BGP debug options.

Use the no parameter with this command to disable one or more BGP debug options.

Syntax debug bgp [all|dampening|events|filters|fsm|keepalives|nsm|<updates>]
no debug all bgp
no debug bgp [all|dampening|events|filters|fsm|keepalives|nsm|<updates>]

Parameter	Description
all	Used with the no form exclusively; turns off all debugging for BGP
dampening	Specifies debugging for BGP dampening.
events	Specifies debugging for BGP events.
filters	Specifies debugging for BGP filters.
fsm	Specifies debugging for BGP Finite State Machine (FSM).
keepalives	Specifies debugging for BGP keepalives.
nsm	Specifies debugging for NSM messages.
<updates>	updates [in out] Specifies debugging for BGP updates.
in	Inbound updates
out	Outbound updates

Mode Privileged Exec mode

Usage If the command is entered with no parameters, then all debug options are enabled.

Example

```
awplus# debug bgp
awplus# debug bgp events
```

Related Commands [show debugging bgp](#)

distance (BGP)

This command sets the administrative distance for BGP routes. The switch uses this value to select between two or more routes to the same destination from two different routing protocols. The route with the smallest administrative distance value is added to the Forwarding Information Base (FIB). See [Administrative Distance](#) in the [Route Selection](#) Chapter for more information.

You can use this command to set the administrative distance:

- for each BGP route types by specifying:
distance (BGP) <ebgp> <ibgp> <local>
- for a specific route by specifying:
distance (BGP) <1-255> <ip-address/m> [<listname>]

The no form sets the administrative distance for the route to the default for the route type.

Syntax

```
distance <1-255> <ip-address/m> [<listname>]
distance bgp <ebgp> <ibgp> <local>
no distance <1-255> <ip-address/m> [<listname>]
no distance bgp <ebgp> <ibgp> <local>
```

Parameter	Description
<1-255>	The administrative distance value you are setting for the route.
<ip-address/m>	The IP source prefix that you are changing the administrative distance for, entered in the form A.B.C.D/M. This is an IPv4 address in dotted decimal notation followed by a forward slash, and then the prefix length.
<listname>	The name of the access list to be applied to the administrative distance to selected routes.
<ebgp>	Specifies the administrative distance of external BGP (eBGP) routes. These are routes learnt from a neighbor out of the AS. Specify the distance as a number between 1 and 255. Default: 20
<ibgp>	Specifies the administrative distance of internal BGP (iBGP) routes. These are routes learnt from a neighbor within the same AS. Specify the distance as a number between 1 and 255. Default: 200
<local>	Specifies the administrative distance of local BGP routes. These are routes redistributed from another protocol within your device. Specify the distance as a number between 1 and 255. Default: 200

Mode Router mode

If the administrative distance is changed, it could create inconsistency in the routing table and obstruct routing.

Example To set the administrative distance to 34 for the route 10.10.0.0/24 in BGP 100, and use the access list "mylist" to filter the routes, use the commands:

```
awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# distance 34 10.10.0.0/24 mylist
```

To set BGP 100's administrative distances for eBGP routes to 34, iBGP routes to 23, and local BGP routes to 15, use the commands:

```
awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# distance bgp 34 23 15
```

exit-address-family

Use this command to exit the Address Family mode.

Syntax `exit-address-family`

Mode Address Family [ipv4 unicast | ipv4 multicast] mode

Example The following example shows the use of `exit-address-family` command and the change in the prompt after using this command.

```
awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# address-family ipv4 multicast
awplus(config-router-af)# exit-address-family
```

Related Commands [address-family](#)

ip as-path access-list

This command defines a BGP Autonomous System (AS) path access list.

The named AS path list is a filter based on regular expressions. If the regular expression matches the AS path in a BGP update message, then the permit or deny condition applies to that update. Use this command to define the BGP access list globally, then use neighbor configuration commands to apply the list to a particular neighbor.

The no form disables the use of the access list

Syntax `ip as-path access-list <listname> {deny|permit} <reg-exp>`
`no ip as-path access-list <listname> {deny|permit} <reg-exp>`

Parameter	Description
<listname>	Specifies the name of the access list.
deny	Denies access to matching conditions.
permit	Permits access to matching conditions.
<reg-exp>	Specifies a regular expression to match the BGP AS paths.

Regular expressions listed below can be used with the ip as-path-access-list command:

Symbol	Character	Meaning
^	Caret	Used to match the beginning of the input string. When used at the beginning of a string of characters, it negates a pattern match.
\$	Dollar sign	Used to match the end of the input string.
.	Period	Used to match a single character (white spaces included).
*	Asterix	Used to match none or more sequences of a pattern.
+	Plus sign	Used to match one or more sequences of a pattern.
?	Question mark	Used to match none or one occurrence of a pattern.
_	Underscore	Used to match spaces, commas, braces, parenthesis, or the beginning and end of an input string.
[]	Brackets	Specifies a range of single-characters.
-	Hyphen	Separates the end points of a range.

Mode Global Configuration mode

Example

```
awplus# configure terminal
awplus(config)# ip as-path access-list mylist deny ^65535$
```

ip community-list

Use this command to add an entry to a standard BGP community-list filter.

Use the no parameter with this command to delete the community list entry.

Syntax `ip community-list <listname> {deny|permit} .<community>`
`no ip community-list <listname> {deny|permit} .<community>`

Parameter	Description
<listname>	Specifies the community listname.
deny	Specifies the community to reject.
permit	Specifies the community to accept.
.<community>	{<AS:VAL> local-AS no-advertise no-export}
<AS:VAL>	Specifies the valid value for the community number. This format represents the 32 bit communities value, where AS is the high order 16 bits and VAL is the low order 16 bits in digit format.
local-AS	Specifies routes not to be advertised to external BGP peers.
no-advertise	Specifies routes not to be advertised to other BGP peers.
no-export	Specifies routes not to be advertised outside of Autonomous System boundary.

Mode Global Configuration mode

Usage A community-list can be used as a filter to BGP updates. Use this command to define the community access list globally, then use neighbor configuration commands to apply the list to a particular neighbor.

There are two kinds of community-lists: expanded and standard. A standard community-list defines the community attributes explicitly and not via a regular expression. An expanded community-list defines the communities attributes with regular expressions.

The standard community-list is compiled into binary format and is directly compared with the BGP communities attribute in the BGP updates. The comparison is faster than the expanded community-list. Any community value that does not match the standard community value is automatically treated as expanded.

Example

```
awplus# configure terminal
awplus(config)# ip community-list mylist permit 7675:80 7675:90
```

Related Commands [ip community-list standard](#)
[ip community-list expanded](#)

ip community-list expanded

Use this command to add an entry to an expanded BGP community-list filter.

Use the `no` parameter with this command to delete the community list entry.

Syntax

```
ip community-list <100-199> {deny|permit} .<line>
no ip community-list <100-199> {deny|permit} .<line>
ip community-list <expanded> {deny|permit} .<line>
no ip community-list <expanded> {deny|permit} .<line>
```

Parameter	Description
<100-199>	Expanded community list number.
<expanded>	expanded <expanded_listname>
expanded	Specifies an expanded community list.
<expanded_listname>	Expanded community list number
deny	Specifies community to reject.
permit	Specifies community to accept.
.<line>	Specifies community attributes with regular expressions.

Regular expressions listed below can be used with the `ip community-list expanded` command:

Symbol	Character	Meaning
^	Caret	Used to match the beginning of the input string. When used at the beginning of a string of characters, it negates a pattern match.
\$	Dollar sign	Used to match the end of the input string.
.	Period	Used to match a single character (white spaces included).
*	Asterix	Used to match none or more sequences of a pattern.
+	Plus sign	Used to match one or more sequences of a pattern.
?	Question mark	Used to match none or one occurrence of a pattern.
_	Underscore	Used to match spaces, commas, braces, parenthesis, or the beginning and end of an input string.
[]	Brackets	Specifies a range of single-characters.
-	Hyphen	Separates the end points of a range.

Mode Global Configuration mode

Usage A `community-list` can be used as a filter to BGP updates. Use this command to define the community access list globally, then use `neighbor` configuration commands to apply the list to a particular neighbor.

There are two kinds of community-lists: expanded and standard. A standard community-list defines the community attributes explicitly and not via a regular expression. An expanded community-list defines the communities attributes with regular expressions.

The standard community-list is compiled into binary format and is directly compared with the BGP communities attribute in the BGP updates. The comparison is faster than the expanded community-list. Any community value that does not match the standard community value is automatically treated as expanded.

Example

```
awplus# configure terminal
awplus(config)# ip community-list 125 permit 6789906
awplus(config)# ip community-list expanded CLIST permit .*
```

Related Commands [ip community-list](#)
[ip community-list standard](#)

ip community-list standard

Use this command to add an entry to a standard BGP community-list filter.

Use the **no** parameter with this command to delete the standard community-list entry.

Syntax

```
ip community-list <1-99> {deny|permit} [.<community>]
no ip community-list <1-99> {deny|permit} [.<community>]
ip community-list <standard> {deny|permit} [.<community>]
no ip community-list <standard> {deny|permit} [.<community>]
```

Parameter	Description
<1-99>	Standard community list number.
<standard>	standard <standard_listname> Specifies the community listname.
standard	Specifies a standard community list.
<standard_listname>	Standard community list number.
deny	Specifies community to reject.
permit	Specifies community to accept.
<community>	{ <AS:VAL> local-AS no-advertise no-export }
<AS:VAL>	Specifies the valid value for the community number. This format represents the 32 bit communities value, where AS is the high order 16 bits and VAL is the low order 16 bits in digit format.
local-AS	Specifies routes not to be advertised to external BGP peers.
no-advertise	Specifies routes not to be advertised to other BGP peers.
no-export	Specifies routes not to be advertised outside of the Autonomous System boundary.

Mode Global Configuration mode

Usage A community-list can be used as a filter to BGP updates. Use this command to define the community access list globally, then use neighbor configuration commands to apply the list to a particular neighbor.

There are two kinds of community-lists: expanded and standard. The standard community-list defines the community attributes as explicit values, without regular expressions. The expanded community-list defines the communities attributes with regular expressions.

The standard community-list is compiled into binary format and is directly compared with the BGP communities attribute in the BGP updates. The comparison is faster than the expanded community-list. Any community value that does not match the standard community value is automatically treated as expanded.

Example

```
awplus# configure terminal

awplus(config)# ip community-list standard CLIST permit 7675:80
7675:90 no-export

awplus(config)# ip community-list 34 permit 5675:50 no-
advertise
```

Related Commands [ip community-list](#)
[ip community-list expanded](#)

ip extcommunity-list expanded

Use this command to create or delete an expanded extended community list. Use the no parameter with this command to delete the expanded extended community-list entry.

Syntax

```
ip extcommunity-list <100-199> {deny|permit}
{.<line>|.<AS:NN>|.<ip-address>}

no ip extcommunity-list <100-199> {deny|permit}
{.<line>|.<AS:NN>|.<ip-address>}

ip extcommunity-list expanded <expanded-listname> {deny|permit}
{.<line>|.<AS:NN>|.<ip-address>}

no ip extcommunity-list expanded <expanded-listname> {deny|permit}
{.<line>|.<AS:NN>|.<ip-address>}

no ip extcommunity-list <100-199>

no ip extcommunity-list expanded <expanded-listname>
```

Parameter	Description
<100-199>	Expanded extcommunity list number
<expanded>	expanded <expanded_listname>
expanded	Specifies an expanded extcommunity list
<expanded_listname>	Expanded extcommunity list name
deny	Specifies the extcommunity to reject
permit	Specifies the extcommunity to accept
.<line>	Specifies extcommunity attributes with regular expression.
<AS:NN>	Specifies the valid value for an extcommunity number. This format represents the 32 bit extcommunities value, where AA is the high order 16 bits and NN is the low order 16 bits in digit format.
<ip-address>	Specifies the IP address to deny or permit.

Regular expressions listed below are used with the ip extcommunity-list expanded command:

Symbol	Character	Meaning
^	Caret	Used to match the beginning of the input string. When used at the beginning of a string of characters, it negates a pattern match.
\$	Dollar sign	Used to match the end of the input string.
.	Period	Used to match a single character (white spaces included).
*	Asterix	Used to match none or more sequences of a pattern.
+	Plus sign	Used to match one or more sequences of a pattern.
?	Question mark	Used to match none or one occurrence of a pattern.
_	Underscore	Used to match spaces, commas, braces, parenthesis, or the beginning and end of an input string.

Symbol	Character	Meaning
[]	Brackets	Specifies a range of single-characters.
-	Hyphen	Separates the end points of a range.

Mode Global Configuration mode

Example

```
awplus# configure terminal
awplus(config)# ip extcommunity-list 125 permit 4567335
awplus(config)# ip extcommunity-list expanded CLIST permit .*
```

Related Commands [ip extcommunity-list standard](#)

ip extcommunity-list standard

Use this command to create and delete a standard extended community list.

Use the no parameter with this command to delete a standard extended community-list entry.

Syntax

```
ip extcommunity-list <standard> {deny|permit} {rt|soo}
    <community-number>

no ip extcommunity-list <standard> {deny|permit} {rt|soo}
    <community-number>

no ip extcommunity-list <1-99>

no ip extcommunity-list standard <standard-listname>
```

Parameter	Description
<1-99>	Standard extcommunity list number
<standard>	standard <standard-listname>
standard	Specifies a standard extended community list
<standard-listname>	Standard extended community list name
deny	Specifies the extended community to reject
permit	Specifies the extended community to accept
rt	Specifies the route target of the extended community
soo	Specifies the site of origin of the extended community
<community-number>	Specifies the valid value for an extended community number. This can be one of two formats: ■ <ASN:NN> where ASN is an AS (Autonomous System) number and NN is a value chosen by the ASN administrator ■ <A.B.C.D:NN> where A.B.C.D is an IPv4 address, and NN is a value chosen by the ASN administrator. Note that ASN and NN are both integers from 1 to 65535. AS numbers are assigned to the regional registries by IANA (www.iana.org) and must be obtained in your region.
<ip-address>	Specifies the IPv4 address to deny or permit.

Mode Global Configuration mode

Example

```
awplus# configure terminal

awplus(config)# ip extcommunity-list 36 permit rt 5675:50

awplus(config)# ip extcommunity-list standard CLIST permit soo
7645:70
```

```
awplus# configure terminal
awplus(config)# ip extcommunity-list 36 deny rt 192.168.1.1:70
awplus(config)# ip extcommunity-list standard CLIST deny soo
                  10.10.1.1:50
```

Related Commands [ip extcommunity-list expanded](#)
[show ip extcommunity-list](#)

neighbor activate

Use this command to enable the exchange of routes with a neighboring router, possibly within a specific address-family.

Use the no parameter with this command to disable exchange of information with a neighbor.

Syntax `neighbor <neighborid> activate`
`no neighbor <neighborid> activate`

Parameter	Description
<neighborid>	{<ip-address> <tag>}
<ip-address>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<tag>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.

Mode Router mode and Address Family [ipv4 unicast | ipv4 multicast] mode

Usage This command triggers the switch to start a BGP peering relationship with the specified neighbor and start exchanging routes with that neighbor. To enable the exchange of multicast NLRI (Network Layer Reachability Information), neighbors are activated using the neighbor activate command in multicast address family mode.

Example To enable an exchange of routes with a neighboring router enter the commands shown below:

```
awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# neighbor 1.2.3.4 activate
```

To enable an exchange of multicast NLRI (Network Layer Reachability Information) with a neighboring router enter the commands shown below:

```
awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# address-family ipv4 multicast
awplus(config-router-af)# neighbor 10.10.10.0 activate
```

Related Commands [neighbor remote-as](#)

neighbor advertisement-interval

Use this command to set the minimum interval between sending the BGP routing updates.

Use the no parameter with this command to set the interval time to the default (30 seconds).

Syntax `neighbor <neighborid> advertisement-interval <time>`
`no neighbor <neighborid> advertisement-interval [<time>]`

Parameter	Description
<code><neighborid></code>	<code>{<ip-address> <tag>}</code>
<code><ip-address></code>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<code><tag></code>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.
<code><time></code>	<code><1-600></code> Advertise -interval value in seconds

Mode Router mode

Default The default minimum interval between sending the BGP routing updates is 30 seconds.

Usage Use this command to set the minimum interval between the sending of BGP routing updates. To reduce the flapping of routes to internet, a minimum advertisement interval is set, so that the BGP routing updates are sent only per interval seconds. BGP dampening can also be used to control the effects of flapping routes.

Example

```
awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# neighbor 10.10.0.3 advertisement-
interval 45
```

neighbor allowas-in

Use this command to accept an AS-path with the specified Autonomous System (AS) number from inbound updates.

Use the no parameter with this command to revert to default.

Syntax `neighbor <neighborid> allowas-in <occurrences>`
`no neighbor <neighborid> allowas-in`

Parameter	Description
<code><neighborid></code>	<code>{<ip-address> <tag>}</code>
<code><ip-address></code>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<code><tag></code>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.
<code><occurrences></code>	<code><1-10></code> Specifies the number of occurrences of the AS number.

Default Disabled

Usage Use this command to configure PE routers to allow re-advertisement of all prefixes containing duplicate Autonomous System Numbers (ASNs). In a hub and spoke configuration, a PE router re-advertises all prefixes containing duplicate ASNs. Specify the remote-as or peer-group first using the related commands.

Mode Router mode and Address Family [ipv4 unicast | ipv4 multicast] mode

Example

```
awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# neighbor 10.10.0.1 allowas-in 3

awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# address-family ipv4
awplus(config-router-af)# neighbor 10.10.0.1 allowas-in 3
```

Related Commands [neighbor remote-as](#)
[neighbor peer-group \(creating a peer-group\)](#)
[neighbor peer-group \(adding a neighbor\)](#)

neighbor as-origination-interval

Use this command to enable the sending of AS (Autonomous System) origination routing updates to the specified neighbor. This command can also be used to adjust the rate at which the updates are sent.

Use the no negation parameter with this command to disable this feature.

Syntax `neighbor <neighbor_address> as-origination-interval <time>`
`neighbor <neighbor_address> as-origination-interval`
`no neighbor <neighbor_address> as-origination-interval`

Parameter	Description
<code><neighbor_address></code>	neighbor IP address. Use A.B.C.D form.
<code><time></code>	<code><1 - 600></code> time in seconds

Default Disabled

Mode Router mode and Address Family [ipv4 unicast | ipv4 multicast] mode

Usage This command is used to change the minimum interval between sending AS-origination routing updates. The interval can be from 1 to 600 seconds.

Example

```
awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-router)# address-family ipv4
awplus(config-router-af)# neighbor 10.10.0.1 as-origination-
interval 10
```

Related Commands [address-family](#)

neighbor attribute-unchanged

Use this command to advertise unchanged BGP attributes to the specified neighbor.

Use the no parameter with this command to disable this function.

Syntax `neighbor <neighborid> attribute-unchanged {as-path|next-hop|med}`
`no neighbor <neighborid> attribute-unchanged {as-path|next-hop|med}`

Parameter	Description
<neighborid>	{<ip-address> <tag>}
<ip-address>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<tag>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.
as-path	AS path attribute
next-hop	Next hop attribute
med	Multi Exit Discriminator

Mode Router mode and Address Family [ipv4 unicast | ipv4 multicast] mode

Example

```
awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# neighbor 10.10.0.75 attribute-unchanged
as-path med
```

neighbor capability dynamic

Use this command to enable the dynamic capability for a specific peer.

Use the no parameter with this command to disable the dynamic capability.

Syntax `neighbor <neighborid> capability dynamic`
`no neighbor <neighborid> capability dynamic`

Parameter	Description
<neighborid>	{<ip-address> <tag>}
<ip-address>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<tag>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.

Default Disabled

Mode Router mode

Usage This command allows a BGP speaker to advertise or withdraw an address family capability to a peer in a non-disruptive manner.

Example

```
awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# neighbor 10.10.10.1 capability dynamic
```

neighbor capability graceful-restart

Use this command to configure the router to advertise the Graceful Restart Capability to the neighbors.

Use the `no` parameter with this command to configure router so it does not advertise the Graceful Restart Capability to its neighbor.

Syntax `neighbor <neighborid> capability graceful-restart`
`no neighbor <neighborid> capability graceful-restart`

Parameter	Description
<code><neighborid></code>	<code>{<ip-address> <tag>}</code>
<code><ip-address></code>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<code><tag></code>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.

Default Disabled

Mode Router mode and Address Family [ipv4 unicast | ipv4 multicast] mode

Usage This configuration only indicates BGP speaker has the ability to preserve its forwarding state for some address family when BGP restarts.

Use the `neighbor capability graceful-restart` command to advertise to the neighbor routers the capability of graceful restart. First specify neighbors `remote-as` identification number assigned by the neighbor router.

- The graceful restart capability is advertised only when the graceful restart capability has been enabled using the [bgp graceful-restart command on page 40.23](#).

Example

```
awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# neighbor 10.10.10.50 capability
graceful-restart
```

Related Commands [bgp graceful-restart](#)

neighbor capability orf prefix-list

Use this command to advertise ORF capability to neighbors.

Use the no parameter with this command to disable this function.

Syntax `neighbor <neighborid> capability orf prefix-list {both|receive|send}`
`no neighbor <neighborid> capability orf prefix-list {both|receive|send}`

Parameter	Description
<neighborid>	{<ip-address> <tag>}
	<ip-address> The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
	<tag> Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.
orf	Advertises ORF capability to its neighbors
both	Indicates that the local router can send ORF entries to its peer as well as receive ORF entries from its peer.
receive	Indicates that the local router is willing to receive ORF entries from its peer
send	Indicates that the local router is willing to send ORF entries to its peer

Mode Router mode and Address Family [ipv4 unicast | ipv4 multicast] mode

Usage Outbound Route Filters (ORFs) send and receive capabilities to lessen the number of updates exchanged between neighbors. By filtering updates, this option minimizes generating and processing of updates. The local router advertises the ORF capability in `send` mode and the remote router receives the ORF capability in `receive` mode applying the filter as outbound policy. The two routers exchange updates to maintain the ORF for each router. Only an individual router or a peer-group can be configured to be in `receive` or `send` mode. A peer-group member cannot be configured to be in `receive` or `send` mode

Example

```
awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# neighbor 10.10.0.5 capability orf
prefix-list both
```

neighbor capability route-refresh

Use this command to advertise route-refresh capability to the specified neighbors.

Use the no parameter with this command to disable this function

Syntax `neighbor <neighborid> capability route-refresh`
`no neighbor <neighborid> capability route-refresh`

Parameter	Description
<neighborid>	{<ip-address> <tag>}
<ip-address>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<tag>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.

Mode Router mode

Usage Use this command to advertise to peer about route refresh capability support. If route refresh capability is supported, then router can dynamically request that the peer readvertises its Adj-RIB-Out.

Example

```
awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# neighbor 10.10.10.1 capability route-
refresh
```


neighbor collide-established

Use this command to specify including a neighbor, already in an 'established' state, for conflict resolution when a TCP connection collision is detected.

Use the `no neighbor collide-established` command to remove a neighbor, already in an 'established' state, for conflict resolution when a TCP connection collision is detected.

Syntax `neighbor <neighborid> collide-established`
`no neighbor <neighborid> collide-established`

Parameter	Description
<code><neighborid></code>	<code>{<ip-address> <tag>}</code>
<code><ip-address></code>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<code><tag></code>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.

Mode Router mode

Usage This command must be used only when specially required. It is not required in most network deployments.

- The associated functionality of including an 'established' neighbor into TCP connection collision conflict resolution is automatically enabled when neighbor is configured for BGP graceful-restart.

Example

```
awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# neighbor 3.3.3.3 collide-established
```

neighbor default-originate

Use this command to allow a BGP local router to send the default route 0.0.0.0 to a neighbor.

Use the no parameter with this command to send no route as a default.

Syntax `neighbor {<neighborid>} default-originate [<route-map>]`
`no neighbor {<neighborid>} default-originate [<route-map>]`

Parameter	Description
<neighborid>	{<ip-address> <tag>}
	<ip-address> The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
	<tag> Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.
<route-map>	route-map <routername>
route-map	If a route-map is specified, then the route table must contain at least one route that matches the permit criteria of the route map before the default route will be advertised to the specified neighbor.
<routername>	Route-map name

Mode Router mode and Address Family [ipv4 unicast | ipv4 multicast] mode

Example

```
awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# neighbor 10.10.10.1 default-originate
route-map myroute
```

neighbor description

Use this command to associate a description with a neighbor.

Use the no parameter with this command to remove the description.

Syntax `neighbor <neighborid> description <description>`
`no neighbor <neighborid> description [<description>]`

Parameter	Description
<code><neighborid></code>	{ <code><ip-address></code> <code><tag></code> }
<code><ip-address></code>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<code><tag></code>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.
<code><description></code>	Up to 80 characters of text describing the neighbor.

Mode Router mode

Example

```
awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# neighbor 1.2.3.4 description Backup
router for sales.
```

neighbor distribute-list

This command filters route update from a particular BGP neighbor using an access control list.

You can add one incoming and one outgoing distribute-list for each BGP neighbor.

The no neighbor distribute-list command removes a previously configured distribute-list.

Syntax `neighbor <neighborid> distribute-list <access-list> {in|out}`
`no neighbor <neighborid> distribute-list <access-list> {in|out}`

Parameter	Description
<neighborid>	Identification method for the BGP peer. Use one of the following formats:
<ip-address>	The address of an IPv4 BGP neighbor, in dotted decimal notation <i>A.B.C.D</i> .
<tag>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) and neighbor remote-as commands. When this parameter is used with a command, the command applies on all peers in the specified group.
<access-list>	The specific access-list used to filter routes. Specify one of the following types of access-lists:
<WORD>	The name of IP access-list.
<1-199>	The ID number of a standard IP access-list.
<1300-2699>	The ID number of an extended IP access-list.
in	Indicates that incoming advertised routes will be filtered.
out	Indicates that outgoing advertised routes will be filtered.

Mode Router mode and Address Family [ipv4 unicast | ipv4 multicast] mode

Example

```
awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# neighbor 1.2.3.4 distribute-list
mylist out
```

neighbor dont-capability-negotiate

Use this command to disable capability negotiation.

The capability negotiation is performed by default. This command is used to allow compatibility with older BGP versions that have no capability parameters used in open messages between peers.

Use the no parameter with this command to enable capability negotiation.

Syntax `neighbor <neighborid> dont-capability-negotiate`
`no neighbor <neighborid> dont-capability-negotiate`

Parameter	Description
<code><neighborid></code>	<code>{<ip-address> <tag>}</code>
<code><ip-address></code>	Specifies the address of the BGP neighbor in IPv4 format <i>A.B.C.D</i> .
<code><tag></code>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.

Mode Router mode

Example

```
awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# neighbor 10.10.0.34 dont-capability-
negotiate
```

neighbor ebgp-multihop

Use this command to accept and attempt BGP connections to external peers on indirectly connected networks.

The switch will not establish a connection to a multihop neighbor, if the only route to the multihop peer is a default route.

Use the no parameter with this command to return to the default.

Syntax `neighbor <neighborid> ebgp-multihop [<count>]`
`no neighbor <neighborid> ebgp-multihop [<count>]`

Parameter	Description
<code><neighborid></code>	<code>{<ip-address> <tag>}</code>
<code><ip-address></code>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<code><tag></code>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.
<code><count></code>	<code><1-255></code> Maximum hop count that appears TTL field of the BGP packets. If the maximum hop count is not set the hop count is 255.

Mode Router mode

Example

```
awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# neighbor 10.10.10.34 remote-as 20
awplus(config-router)# neighbor 10.10.10.34 ebgp-multihop 5
```

neighbor enforce-multihop

Use this command to enforce the requirement that BGP neighbors form multihop connections.

Use the no parameter with this command to turn off this feature.

Syntax `neighbor <neighborid> enforce-multihop`
`no neighbor <neighborid> enforce-multihop`

Parameter	Description
<neighborid>	{<ip-address> <tag>}
<ip-address>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<tag>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.

Mode Router mode

Example

```
awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# neighbor 10.10.0.34 remote-as 20
awplus(config-router)# neighbor 10.10.0.34 enforce-multihop
```

neighbor filter-list

This command creates a BGP filter using an AS (Autonomous System) path list. This command specifies an AS path list, which it then applies to filter updates to and from a BGP neighbor.

The no form of this command removes the previously specified filter using access control lists.

Syntax

```
neighbor <neighborid> filter-list <listname> {in|out}
no neighbor <neighborid> filter-list <listname> {in|out}
```

Parameter	Description
<neighborid>	Identification method for the BGP peer. Use one of the following formats:
<ip-address>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<tag>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.
<listname>	The name of an AS (Autonomous System) path list.
in	Indicates that incoming advertised routes will be filtered.
out	Indicates that outgoing advertised routes will be filtered.

Mode Router mode and Address Family [ipv4 unicast | ipv4 multicast] mode

Usage This command specifies a filter for updates based on a BGP AS (Autonomous System) path list.

Example

```
awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# neighbor 10.10.0.34 filter-list list1
out
```

neighbor interface

Use this command to configure the interface name of a BGP-speaking neighbor.

Use the no parameter with this command to disable this function

Syntax neighbor <ipaddr> interface <interface>
 no neighbor <ipaddr> interface <interface>

Parameter	Description
<ipaddr>	Specifies the IPv4 address of the BGP neighbor - entered in dotted decimal notation.
<interface>	Specifies the interface name of BGP neighbor, e.g., vlan2.

Mode Router mode

Example

```
awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# neighbor 10.10.0.72 interface vlan2

awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# no neighbor 10.10.0.72 interface vlan2
```

neighbor maximum-prefix

Use this command to control the number of prefixes that can be received from a neighbor.

Use the `no` parameter with this command to disable this function. Do not specify threshold to apply the default threshold of 75% for the maximum number of prefixes before this is applied.

Syntax `neighbor <neighborid> maximum-prefix <maximum>`
`no neighbor <neighborid> maximum-prefix [<maximum>]`

Parameter	Description
<code><neighborid></code>	<code>{<ip-address> <tag>}</code>
<code><ip-address></code>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<code><tag></code>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.
<code><maximum></code>	<code><maxprefix> [<threshold>] [warning-only]</code>
<code><maxprefix></code>	<code><1-4294967295></code> Specifies the maximum number of prefixes permitted.
<code><threshold></code>	<code><1-100></code> Specifies the threshold value, 1 to 100 percent. 75% by default.
<code>warning-only</code>	Only gives a warning message when the limit is exceeded.

Mode Router mode and Address Family [ipv4 unicast | ipv4 multicast] mode

Default The default threshold value is 75%. If the threshold value is not specified this default is applied.

Usage The `neighbor maximum-prefix` command allows the configuration of a specified number of prefixes that a BGP router is allowed to receive from a neighbor. When the `warning-only` option is not used, if any extra prefixes are received, the router ends the peering. A terminated peer, stays down until the `clear ip bgp` command is used.

Example

```
awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# neighbor 10.10.0.72 maximum-prefix 1244
warning-only
```

neighbor next-hop-self

Use this command to configure the router as the next hop for a BGP-speaking neighbor or peer group.

Use the no parameter with this command to disable this feature.

Syntax `neighbor <neighborid> next-hop-self`
`no neighbor <neighborid> next-hop-self`

Parameter	Description
<neighborid>	{<ip-address> <tag>}
<ip-address>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<tag>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.

Mode Router mode and Address Family [ipv4 unicast | ipv4 multicast] mode

Usage This command allows a BGP router to change the nexthop information that is sent to the iBGP peer. The nexthop information is set to the IP address of the interface used to communicate with the neighbor.

Example

```
awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# neighbor 10.10.0.72 remote-as 100
awplus(config-router)# neighbor 10.10.0.72 next-hop-self
```

neighbor override-capability

Use this command to override a capability negotiation result.

Use the no parameter with this command to disable this function

Syntax `neighbor <neighborid> override-capability`
`no neighbor <neighborid> override-capability`

Parameter	Description
<code><neighborid></code>	<code>{<ip-address> <tag>}</code>
<code><ip-address></code>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<code><tag></code>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.

Mode Router mode

Example

```
awplus# configure terminal
awplus(config)# router bgp 12
awplus(config-router)# neighbor 10.10.10.10 override-capability
```

neighbor passive

Use this command to configure the local router to be passive with regard to the specified neighbor. This has the effect that the router will not attempt to initiate connections to this neighbor, but will accept incoming connection attempts from the neighbor.

Use the no parameter with this command to disable this function

Syntax `neighbor <neighborid> passive`
`no neighbor <neighborid> passive`

Parameter	Description
<neighborid>	{<ip-address> <tag>}
<ip-address>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<tag>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.

Mode Router mode

Example

```
awplus# configure terminal
awplus(config)# router bgp 12
awplus(config-router)# neighbor 10.10.10.10 passive

awplus# configure terminal
awplus(config)# router bgp 12
awplus(config-router)# no neighbor 10.10.10.10 passive
```

neighbor peer-group (adding a neighbor)

Use this command to add a neighbor to an existing peer-group.

Use the no parameter with this command to disable this function.

Syntax `neighbor <ip-address> peer-group <tag>`
`no neighbor <ip-address> peer-group <tag>`

Parameter	Description
<code><ip-address></code>	Specifies the IPv4 address of the BGP neighbor, entered in the format A.B.C.D.
<code><tag></code>	Name of the peer-group

Mode Router mode and Address Family [ipv4 unicast | ipv4 multicast] mode

Usage Use this command to add Neighbors with the same update policies to a peer group. This facilitates the updates of various policies, such as, distribute and filter lists. The peer-group is then configured easily with any of the neighbor commands. Any changes made to the peer group affect all members.

To create a peer-group use the neighbor peer-group create command and then use this command to add neighbors to the group.

Example This example shows a new peer-group group1 and the adding of a neighbor 10.10.0.63 to the group.

```
awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# neighbor group1 peer-group
awplus(config-router)# neighbor 10.10.0.63 peer-group group1
```

neighbor peer-group (creating a peer-group)

Use this command to create a peer-group.

Use the no parameter with this command to disable this function

Syntax neighbor <tag> peer-group
no neighbor <tag> peer-group

Parameter	Description
<tag>	Name of the peer-group

Mode Router mode and Address Family [ipv4 unicast | ipv4 multicast] mode

Usage Neighbors with the same update policies are grouped into peer groups. This facilitates the updates of various policies, such as, distribute and filter lists. The peer-group is then configured easily with any of the neighbor commands. Any changes made to the peer group affect all members. Use this command to create a peer-group.

Example

```
awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# neighbor group1 peer-group
```

neighbor port

Use this command to specify the TCP port to which packets are sent to on a neighbor.

Syntax `neighbor <neighborid> port <portnum>`
`no neighbor <neighborid> port [<portnum>]`

Parameter	Description
<code><neighborid></code>	{ <code><ip-address></code> <code><tag></code> }
<code><ip-address></code>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<code><tag></code>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.
<code><portnum></code>	<code><0-65535></code> Specifies the TCP port number.

Mode Router mode

Example

```
awplus# configure terminal
awplus(config)# router bgp 12
awplus(config-router)# neighbor 10.10.10.10 port 643
```


neighbor prefix-list

Use this command to distribute BGP neighbor information as specified in a prefix list.

Use the no parameter with this command to remove an entry.

Syntax `neighbor <neighborid> prefix-list <listname> {in|out}`
`no neighbor <neighborid> prefix-list <listname> {in|out}`

Parameter	Description
<code><neighborid></code>	<code>{<ip-address> <tag>}</code>
<code><ip-address></code>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<code><tag></code>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.
<code><listname></code>	The name of an IP prefix list.
<code>in</code>	Specifies that the IP prefix list applies to incoming advertisements.
<code>out</code>	Specifies that the IP prefix list applies to outgoing advertisements.

Mode Router mode and Address Family [ipv4 unicast | ipv4 multicast] mode

Usage Use this command to specify a prefix list for filtering BGP advertisements. Filtering by prefix list matches the prefixes of routes with those listed in the prefix list. If there is a match, the route is used. An empty prefix list permits all prefixes. If a given prefix does not match any entries of a prefix list, the route is denied access.

The router begins the search at the top of the prefix list, with the sequence number 1. Once a match or deny occurs, the router does not need to go through the rest of the prefix list. For efficiency the most common matches or denies are listed at the top.

The neighbor distribute-list command is an alternative to the neighbor prefix-list command and only one of them can be used for filtering to the same neighbor in any direction.

Example

```
awplus# configure terminal
awplus(config)# ip prefix-list list1 deny 30.0.0.0/24
awplus(config)# router bgp 12
awplus(config-router)# neighbor 10.10.10.10 prefix-list list1
in
```

Related Commands [ip prefix-list](#)

neighbor remote-as

Use this command to configure an internal or external BGP (iBGP or eBGP) peering relationship with another router.

Use the **no** parameter with this command to remove a previously configured BGP peering relationship.

Syntax `neighbor <neighborid> remote-as <as-number>`
`no neighbor <neighborid> remote-as <as-number>`

Parameter	Description
<code><neighborid></code>	<code>{<ip-address> <tag>}</code>
<code><ip-address></code>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<code><tag></code>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.
<code><as-number></code>	<code><1-65535></code> Neighbor's Autonomous System (AS) number.

Mode Router mode

Usage This command is used to configure iBGP and eBGP peering relationships with other neighbors. A peer-group support of this command is configured only after creating a specific peer-group. Use the **no** parameter with this command to remove a previously configured BGP peering relationship.

Example To configure a BGP peering relationship with another router:

```
awplus# configure terminal
awplus(config)# router bgp 11
awplus(config-router)# neighbor 10.10.0.73 remote-as 345
```

To remove a configured BGP peering relationship from another router:

```
awplus# configure terminal
awplus(config)# router bgp 11
awplus(config-router)# no neighbor 10.10.0.73 remote-as 345
```

neighbor remove-private-AS

Use this command to remove the private Autonomous System (AS) number from outbound updates.

Use the no parameter with this command to revert to default.

Syntax `neighbor <neighborid> remove-private-AS`
`no neighbor <neighborid> remove-private-AS`

Parameter	Description
<neighborid>	{<ip-address> <tag>}
<ip-address>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<tag>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.

Default Disabled

Mode Router mode and Address Family [ipv4 unicast | ipv4 multicast] mode

Usage The private AS numbers range from <64512-65535>. Private AS numbers are not advertised to the Internet. This command is used with external BGP peers only. The router removes the AS numbers only if the update includes private AS numbers. If the update includes both private and public AS numbers, the system treats it as an error.

Example

```
awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# neighbor 10.10.0.63 remove-private-AS

awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# no neighbor 10.10.0.63 remove-private-AS
```

neighbor restart-time

Use this command to set a different restart-time other than the global restart-time configured using the `bgp graceful-restart` command.

Use the `no` parameter with this command to restore the router to its default state.

Syntax `neighbor <neighborid> restart-time <1-3600>`
`no neighbor <neighborid> restart-time <1-3600>`

Parameter	Description
<code><neighborid></code>	<code>{<ip-address> <tag>}</code>
<code><ip-address></code>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<code><tag></code>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.

Mode Router mode

Usage This command takes precedence over the restart-time value specified using the `bgp graceful-restart` command.

The restart-time value is the maximum time that a graceful-restart neighbor waits to come back up after a restart. The default value is 120 seconds.

Make sure that the restart time specified using this command does not exceed the stalepath-time specified in the Router mode.

Example

```
awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# neighbor 3.3.3.3 restart-time 45

awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# no neighbor 3.3.3.3 restart-time 45
```

Related Commands [bgp graceful-restart](#)

neighbor route-map

Use this command to apply a route map to incoming or outgoing routes.

Use the no parameter with this command to a route map.

Syntax `neighbor <neighborid> route-map <mapname> {in|out}`
`no neighbor <neighborid> route-map <mapname> {in|out}`

Parameter	Description
<code><neighborid></code>	<code>{<ip-address> <tag>}</code>
<code><ip-address></code>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<code><tag></code>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.
<code><mapname></code>	Specifies name of the route-map.
<code>in</code>	Specifies that the access list applies to incoming advertisements
<code>out</code>	Specifies that the access list applies to outgoing advertisements.

Mode Router mode and Address Family [ipv4 unicast | ipv4 multicast] mode

Usage Use neighbor route-map command to filter updates and modify attributes. A route map is applied to inbound or outbound updates. Only the routes that pass the route map are sent or accepted in updates.

Example The following example shows the configuration of the route-map name rmap2 and then the use of this map name in the neighbor route-map command.

```
awplus# configure terminal
awplus(config)# route-map rmap2 permit 6
awplus(config-route-map)# match origin incomplete
awplus(config-route-map)# set metric 100
awplus(config-route-map)# exit
awplus(config)# router bgp 12
awplus(config-router)# neighbor 10.10.10.10 route-map rmap2
in
```

Related Commands [route-map](#)

neighbor route-reflector-client

Use this command to configure the router as a BGP route reflector and configure the specified neighbor as its client.

Use the `no` parameter with this command to indicate that the neighbor is not a client.

Syntax `neighbor <neighborid> route-reflector-client`
`no neighbor <neighborid> route-reflector-client`

Parameter	Description
<code><neighborid></code>	<code>{<ip-address> <tag>}</code>
<code><ip-address></code>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<code><tag></code>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.

Mode Router mode and Address Family [ipv4 unicast | ipv4 multicast] mode

Usage Route reflectors are a solution for the explosion of iBGP peering within an autonomous system. By route reflection the number of iBGP peers within an AS is reduced. Use the `neighbor route-reflector-client` command to configure the local router as the route reflector and specify neighbors as its client.

An AS can have more than one route reflector. One route reflector treats the other route reflector as another iBGP speaker.

In the following configuration, Router1 is the route reflector for clients 3.3.3.3 and 2.2.2.2; it also has a non-client peer 6.6.6.6.

```
Router1#
router bgp 200
neighbor 3.3.3.3 remote-as 200
neighbor 3.3.3.3 route-reflector-client
neighbor 2.2.2.2 remote-as 200
neighbor 2.2.2.2 route-reflector-client
neighbor 6.6.6.6 remote-as 200
```

Example

```
awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# neighbor 10.10.0.72 route-reflector-client
```

```
awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# no neighbor 10.10.0.72 route-reflector-
client
```

neighbor route-server-client

Use this command to specify the peer as route server client.

Use the no parameter with this command to disable this function

Syntax `neighbor <neighborid> route-server-client`
`no neighbor <neighborid> route-server-client`

Parameter	Description
<neighborid>	{<ip-address> <tag>}
<ip-address>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<tag>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.

Mode Router mode and Address Family [ipv4 unicast | ipv4 multicast] mode

Example

```
awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# neighbor 10.10.0.72 route-server-client

awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# no neighbor 10.10.0.72 route-server-client
```


neighbor send-community

Use this command to specify that a community attribute should be sent to a BGP neighbor.

Use the `no` parameter with this command to remove the entry. Use the `extended` and `no` parameters to remove extended communities. Specifying no other parameter with `no` removes standard communities only.

Syntax `neighbor <neighborid> send-community {both|extended|standard}`
`no neighbor <neighborid> send-community {both|extended|standard}`

Parameter	Description
<code><neighborid></code>	<code>{<ip-address> <tag>}</code>
<code><ip-address></code>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<code><tag></code>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.
<code>both</code>	Sends Standard and Extended Community attributes
<code>extended</code>	Sends Extended Community attributes
<code>standard</code>	Sends Standard Community attributes

Default Both standard and extended community attributes are sent to a neighbor.

Mode Router mode and Address Family [ipv4 unicast | ipv4 multicast] mode

Usage This command is used to specify a community attribute to be sent to a neighbor. The community attribute groups destinations in a certain community and applies routing decisions according to those communities. On receiving community attributes the router reannounces them to the neighbor. Only when the `no` parameter is used with this command the community attributes are not reannounced to the neighbor.

By default, both standard and extended community attributes are sent to a neighbor. To explicitly send only the `standard` or `extended` community attribute, run the [bgp config-type command on page 40.16](#) with the `standard` parameter, before running this command.

Example

```
awplus# configure terminal
awplus(config)# bgp config-type standard
awplus(config)# router bgp 10
awplus(config-router)# neighbor 10.10.0.72 send-community
extended
```

Related Commands [bgp config-type](#)

neighbor shutdown

Use this command to disable a peering relationship with a neighbor.

Use the `no` parameter with this command to re-enable the neighbor.

Syntax `neighbor <neighborid> shutdown`
 `no neighbor <neighborid> shutdown`

Parameter	Description
<neighborid>	{<ip-address> <tag>}
<ip-address>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<tag>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.

Mode Router mode

Usage This command shuts down any active session for the specified neighbor and clears all related routing data.

Example

```
awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# neighbor 10.10.0.72 shutdown

awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# no neighbor 10.10.0.72 shutdown
```

neighbor soft-reconfiguration inbound

Use this command to configure the switch to start storing all updates from the neighbor, without any consideration of any inward route filtering policy that might be applied to the connection with this neighbor. This is so that the full set of the neighbor's updates are available locally to be used in a soft-reconfiguration event.

Use the `no` parameter with this command to disable this function.

Syntax `neighbor <neighborid> soft-reconfiguration inbound`
`no neighbor <neighborid> soft-reconfiguration inbound`

Parameter	Description
<code><neighborid></code>	<code>{<ip-address> <tag>}</code>
<code><ip-address></code>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<code><tag></code>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.

Mode Router mode and Address Family [ipv4 unicast | ipv4 multicast] mode

Usage Use this command to store updates for inbound soft reconfiguration. Soft-reconfiguration may be used in lieu of BGP route refresh capability. Using this command enables local storage of all the received routes and their attributes. This requires additional memory. When a soft reset (inbound) is done on this neighbor, the locally stored routes are re-processed according to the inbound policy. The BGP neighbor connection is not affected.

Example

```
awplus# configure terminal
awplus(config)# router bgp 12
awplus(config-router)# neighbor 10.10.10.10 soft-reconfiguration
inbound

awplus# configure terminal
awplus(config)# router bgp 12
awplus(config-router)# no neighbor 10.10.10.10 soft-
reconfiguration inbound
```

neighbor strict-capability-match

Use this command to close the BGP connection if the capabilities being advertised by the switch do not exactly match the capabilities being advertised by the neighbor.

Use the no parameter with this command to disable this function

Syntax neighbor <neighborid> strict-capability-match
 no neighbor <neighborid> strict-capability-match

Parameter	Description
<neighborid>	{<ip-address> <tag>}
<ip-address>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<tag>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.

Mode Router mode

Example

```
awplus# configure terminal
awplus(config)# router bgp 12
awplus(config-router)# neighbor 10.10.10.10 strict-
                        capability-match
```

neighbor timers

Use this command to set the timers for a specific BGP neighbor.

Use the no parameter with this command to clear the timers for a specific BGP neighbor

Syntax `neighbor <neighborid> timers {<keepalive>|<connect>}`
`no neighbor <neighborid> timers [<connect>]`

Parameter	Description
<code><neighborid></code>	<code>{<ip-address> <tag>}</code>
	<code><ip-address></code> The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
	<code><tag></code> Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.
<code><keepalive></code>	<code><0-65535></code> holdtime Frequency (in seconds) at which a router sends keepalive messages to its neighbor. The default is 60 seconds
<code>holdtime</code>	<code><0-65535></code> Interval (in seconds) after which, on not receiving a keepalive message, the router declares a neighbor dead. The default is 180 seconds.
<code><connect></code>	<code><1-65535></code> Specifies the connect timer in seconds.

Mode Router mode

Usage Keepalive messages are sent by a router to inform another router that the BGP connection between the two is still active. The keepalive interval is the period of time between each keepalive message sent by the router. The holdtime interval is the time the router waits to receive a keepalive message and if it does not receive a message for this period it declares the neighbor dead.

Example

```
awplus# configure terminal
awplus(config)# router bgp 12
awplus(config-router)# neighbor 10.10.10.10 timers 60 120
awplus(config-router)# neighbor 10.10.10.10 timers connect 10
```

neighbor transparent-as

Use this command to specify not to append your AS path number even if the peer is an eBGP peer.

Syntax `neighbor <neighborid> transparent-as`

Parameter	Description
<code><neighborid></code>	<code>{<ip-address> <tag>}</code>
<code><ip-address></code>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<code><tag></code>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.

Mode Router mode

Example

```
awplus# configure terminal
awplus(config)# router bgp 12
awplus(config-router)# neighbor 10.10.10.10 transparent-as
```

neighbor transparent-nexthop

Use this command to keep the nexthop value of the route even if the peer is an eBGP peer.

Syntax `neighbor <neighborid> transparent-nexthop`

Parameter	Description
<code><neighborid></code>	<code>{<ip-address> <tag>}</code>
<code><ip-address></code>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<code><tag></code>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.

Mode Router mode

Example

```
awplus# configure terminal
awplus(config)# router bgp 12
awplus(config-router)# neighbor 10.10.10.10 transparent-nexthop
```

neighbor unsuppress-map

Use this command to selectively leak more-specific routes to a particular neighbor.

Use the `no neighbor unsuppress-map` command to remove selectively leaked specific routes to a particular neighbor as specified previously with the `neighbor unsuppress-map` command.

Syntax `neighbor <neighborid> unsuppress-map <route-map-name>`
`no neighbor <neighborid> unsuppress-map <route-map-name>`

Parameter	Description
<code><neighborid></code>	<code>{<ip-address> <tag>}</code>
<code><ip-address></code>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<code><tag></code>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.
<code><route-map-name></code>	The name of the route-map used to select routes to be unsuppressed.

Mode Router mode and Address Family [`ipv4 unicast` | `ipv4 multicast`] mode

Usage When the `aggregate-address` command is used with the `summary-only` option, the more-specific routes of the aggregate are suppressed to all neighbors. Use the `unsuppress-map` command to selectively leak more-specific routes to a particular neighbor.

Example

```
awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# neighbor 10.10.0.73 unsuppress-map
mymap

awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# address-family ipv4 unicast
awplus(config-router-af)# neighbor 10.10.0.70 unsuppress-map
mymap
```


neighbor update-source

Use this command to specify that the source IP address of BGP packets sent to the neighbor to be the IP address that is configured on the specified interface.

Use the `no neighbor update-source` command to remove the IP address from the interface as the source IP address of BGP packets sent to the neighbor.

Syntax `neighbor <neighborid> update-source <interface>`
`no neighbor <neighborid> update-source`

Parameter	Description
<code><neighborid></code>	<code>{<ip-address> <tag>}</code>
<code><ip-address></code>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<code><tag></code>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.
<code><interface></code>	Specifies the loopback interface.

Mode Router mode

Usage Use this command in conjunction with any specified interface on the router. The loopback interface is the interface that is most commonly used with this command. The use of loopback interface eliminates a dependency and BGP does not have to rely on the availability of a particular interface for making BGP peer relationships..

Example

```
awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# neighbor 10.10.0.72 update-source myif
```

neighbor version

Use this command to configure the switch to accept only a particular BGP version.

Use the no parameter with this command to use the default BGP version (version 4).

Syntax `neighbor <neighborid> version <version>`
`no neighbor <neighborid> version`

Parameter	Description
<code><neighborid></code>	<code>{<ip-address> <tag>}</code>
<code><ip-address></code>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<code><tag></code>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.
<code><version></code>	<code>{4}</code> Specifies the BGP version number.
4	Border Gateway Protocol 4

Mode Router mode

Usage By default, the system uses BGP version 4 and on request dynamically negotiates down to version 2. Using this command disables the router's version-negotiation capability and forces the router to use only a specified version with the neighbor.

Example

```
awplus# configure terminal
awplus(config)# router bgp 12
awplus(config-router)# neighbor 10.10.10.10 version 4
```

neighbor weight

Use this command to set default weights for routes from this neighbor.

Use the no parameter with this command to remove a weight assignment.

Syntax `neighbor <neighborid> weight <weight>`
`no neighbor <neighborid> weight [<weight>]`

Parameter	Description
<code><neighborid></code>	<code>{<ip-address> <tag>}</code>
<code><ip-address></code>	The address of an IPv4 BGP neighbor, in dotted decimal notation A.B.C.D.
<code><tag></code>	Name of an existing peer-group. For information on how to create peer groups, refer to the neighbor peer-group (adding a neighbor) command on page 40.80 , and neighbor remote-as command on page 40.84 . When this parameter is used with a command, the command applies on all peers in the specified group.
<code><weight></code>	<code><0-65535></code> Specifies the weight this command assigns to the route.

Mode Router mode

Usage Use this command to specify a weight value to all routes learned from a neighbor. The route with the highest weight gets preference when there are other routes on the network.

Unlike the local-preference attribute, the weight attribute is relevant only to the local router.

The weights assigned using the set weight command overrides the weights assigned using this command.

Example

```
awplus# configure terminal
awplus(config)# router bgp 12
awplus(config-router)# neighbor 10.10.10.10 weight 60
```

network (BGP)

Use this command to specify particular routes to be redistributed into the BGP routing process. A unicast network address without a mask is accepted if it falls into the natural boundary of its class. A class-boundary mask is derived if the address matches its natural class-boundary.

Use the no form of this command to remove a network route entry.

Syntax `network <ip-network-prefix> [route-map <route-map-name>]`
`no network <ip-network-prefix> [route-map <route-map-name>]`

Parameter	Description
<code><ip-network-prefix></code>	IP network prefix entered in the format A.B.C.D, e.g. 35.0.0.0
<code><route-map-name></code>	Name of the route map

Mode Router mode and Address Family [`ipv4 unicast`|`ipv4 multicast`] mode

Usage The route configured by this command will not be advertised by BGP unless it appears in the IP routing table. It does not matter how it arrange in the IP routing table. The route can arrive in the IP routing table by a static route, or the route can be learnt from OSPF or RIP routing.

If you configure a route-map, then that route-map will be used in filtering the network, or the route-map will be used to modify the attributes that are advertised with the route.

Example The following example illustrates a Class-A address configured as a network route. The natural Class-A network prefix mask length of 8 will be internally derived, that is, 2.0.0.0/8.

```
awplus(config)# router bgp 1
awplus(config-router)# network 2.0.0.0
awplus(config-router)# exit
awplus(config)# exit
awplus# show run
```

```
router bgp 1
no synchronization
network 1.0.0.0
```

The following example illustrates a network address which does not fall into its natural class boundary, and hence, is perceived as a host route, that is, 1.2.3.0/32.

```
awplus(config)# router bgp 1
awplus(config-router)# network 1.2.3.0
awplus(config-router)# exit
awplus(config)# exit
awplus# show run
```

```
router bgp 1
no synchronization
network 1.2.3.0 mask 255.255.255.255
```

network synchronization

Use this command to ensure the exact same static network prefix, specified through any of the network <prefix> commands, is local or has IGP reachability (in the NSM RIB) before being introduced into the BGP RIB.

Use the no parameter with this command to disable this function.

Syntax network synchronization
no network synchronization

Default Network synchronization is disabled by default.

Mode Router mode and Address Family [ipv4 unicast] mode

Example The following example enables IGP synchronization of BGP static network routes in the router configuration mode.

```
awplus# configure terminal
awplus(config)# router bgp 11
awplus(config-router)# network synchronization
```

The following example enables IGP synchronization of BGP static network routes in the IPv4-Unicast address family.

```
awplus# configure terminal
awplus(config)# router bgp 11
awplus(config-router)# address-family ipv4 unicast
awplus(config-router-af)# network synchronization
```

redistribute route-map

Use this command to inject routes from one routing process into another.

Use the no parameter with this command to disable this function.

Syntax `redistribute {ospf|rip|connected|static} [route-map <route-map-entry-pointer>]`

`no redistribute {ospf|rip|connected|static} [route-map <route-map-entry-pointer>]`

Parameter	Description
connected	Specifies the redistribution of connected routes.
ospf	Specifies the redistribution of OSPF information.
rip	Specifies the redistribution of RIP.
static	Specifies the redistribution of Static routes.
route-map	Route map reference
<route-map-entry-pointer>	Pointer to route-map entries.

Mode Router mode

Usage Redistribution is used by routing protocols to advertise routes that are learned by some other means, such as by another routing protocol or by static routes. Since all internal routes are dumped into BGP, careful filtering is applied to make sure that only routes to be advertised reach the internet, not everything. This command allows redistribution by injecting prefixes from one routing protocol into another routing protocol.

Example The following example shows the configuration of the route-map name rmap1 and then the use of this map name in the redistribute route-map command.

```
awplus# configure terminal
awplus(config)# route-map rmap1 permit 1
awplus(config-route-map)# match origin incomplete
awplus(config-route-map)# set metric 100
awplus(config-route-map)# exit
awplus(config)# router bgp 12
awplus(config-router)# redistribute ospf route-map rmap1
```

restart bgp graceful

Use this command to force the switch to perform a graceful BGP restart.

Syntax `restart bgp graceful`

Mode Privileged Exec mode

Usage This command stops the whole BGP process and makes AlliedWare Plus™ retain the BGP routes and mark them as stale. Receiving BGP speakers, retain and mark as stale all BGP routes received from the restarting speaker for all the address families received in the Graceful Restart Capability exchange.

- When a `restart bgp graceful` command is issued, the BGP configuration is reloaded from the last saved configuration. Ensure you first issue a `copy running-config startup-config`.

Example

```
awplus# restart bgp graceful
```

Related Commands `neighbor capability graceful-restart`

router bgp

Use this command to configure a BGP routing process.

Use the no parameter with this command to disable a routing process.

Syntax router bgp <asn>
 no router bgp <asn>

Parameter	Description
<asn>	<1-65525> Specifies the Autonomous System (AS) number.

Mode Global Configuration mode

Usage The router bgp command enables a BGP routing process so you can set up a route server.

```
router bgp 1
  neighbor 10.0.0.1 remote-as 2
  neighbor 10.0.0.2 remote-as 3
  !
router bgp 2
  neighbor 10.0.0.3 remote-as 4
  neighbor 10.0.0.4 remote-as 5
```

Example

```
awplus# configure terminal
awplus(config)# router bgp 12
awplus(config-router)#
```

Related Commands router bgp view

router bgp view

Use this command to create a named BGP view. BGP views can have the same or different Autonomous System (AS) number. BGP view is only for exchanging BGP routing information.

Use the no parameter with this command to disable a named BGP view.

Syntax `router bgp <asn> view <view_name>`
`no router bgp <asn> view <view_name>`

Parameter	Description
<asn>	<1-65525> Specifies the Autonomous System (AS) number.
<view_name>	Specifies BGP view name.

Mode Global Configuration mode

Usage Specify bgp multiple-instance before applying router bgp view so you can setup a route server:

```
router bgp 1 view 1
neighbor 10.0.0.1 remote-as 2
neighbor 10.0.0.2 remote-as 3
!
router bgp 2 view 2
neighbor 10.0.0.3 remote-as 4
neighbor 10.0.0.4 remote-as 5
```

If you have enabled bgp with the router bgp command you must disable bgp with the no router bgp command before you can specify bgp multiple-instance.

Example

```
awplus# configure terminal
awplus(config)# bgp multiple-instance
awplus(config)# router bgp 12 view bgp12
awplus(config-router)#
```

Related Commands

- bgp multiple-instance
- clear bgp view
- clear ip bgp view
- router bgp
- show ip bgp view
- show ip bgp view summary
- show ip bgp view neighbors

show bgp memory maxallocation

This command displays the maximum percentage of total memory that is allocated to BGP processes.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show bgp memory maxallocation`

Parameter	Description
show	Show running system information
bgp	Border Gateway Protocol (BGP)
memory	Memory information
maxallocation	Maximum percentage of RAM allocated to BGP processes

Mode Privileged Exec Mode

Example To display the maximum amount of memory allocated for BGP processes, use the command:

```
awplus# show bgp memory maxallocation
```

BGP maximum RAM allocation is 100%

show debugging bgp

Use this command to display the BGP debugging option set.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show debugging bgp`

Mode Privileged Exec mode

Example

```
awplus# show debugging bgp
```

Output This is a sample output from the command:

Figure 40-1: Example output from the **show debugging bgp** command

```
BGP debugging status:
  BGP debugging is on
  BGP events debugging is on
  BGP updates debugging is on
  BGP fsm debugging is on
```

Related Commands [debug bgp](#)

show ip bgp

Use this command to display BGP network information.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show ip bgp [<ipaddr>|<ipaddr/m>]`
`show ip bgp {<prefix> [<ipaddr>]}`

Parameter	Description
<ipaddr> <ipaddr/m>	Specifies the IPv4 address and optional prefix mask length.
<prefix>	{multicast unicast}
unicast	Specifies a IPv4 unicast address family. This is the default option. Configures parameters relating to the BGP exchange of routes to unicast destinations.
multicast	Specifies a IPv4 multicast address family. Configures parameters relating to the BGP exchange of routes to source addresses of multicast streams.

Mode Privileged Exec mode and Exec mode

Default Unicast is the default IPv4 address family.

Example

```
awplus# show ip bgp 10.10.1.34/24
```

Output This is a sample output from the `show ip bgp` command displaying BGP network information.

```
awplus# show ip bgp
```

Figure 40-2: Example output from the `show ip bgp` command

```
BGP table version is 7, local router ID is 80.80.80.80
Status codes: s suppressed, d damped, h history, * valid, >
best, i - internal, S Stale
Origin codes: i - IGP, e - EGP, ? - incomplete

   Network          Next Hop           Metric LocPrf Weight Path
S>i10.70.0.0/24      192.10.23.67         0      100      0 ?
S>i30.30.30.30/32    192.10.23.67         0      100      0 ?
S>i63.63.63.1/32     192.10.23.67         0      100      0 ?
S>i67.67.67.67/32    192.10.23.67         0      100      0 ?
S>i172.22.10.0/24    192.10.23.67         0      100      0 ?
S>i192.10.21.0       192.10.23.67         0      100      0 ?
S>i192.10.23.0       192.10.23.67         0      100      0 ?

Total number of prefixes 7
```

show ip bgp attribute-info

Use this command to show internal attribute hash information.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip bgp attribute-info`

Mode Privileged Exec mode and Exec mode

Example

```
awplus# show ip bgp attribute-info
```

Usage This is a sample output from the `show ip bgp attribute-info` command displaying internal attribute information

Figure 40-3: Example output from the **show ip bgp attribute-info** command

```
attr[1] nexthop 0.0.0.0
attr[1] nexthop 10.10.10.10
attr[1] nexthop 10.10.10.50
```

show ip bgp cidr-only

Use this command to display routes with non-natural network masks.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show ip bgp cidr-only`
`show ip bgp {multicast|unicast} cidr-only`

Parameter	Description
unicast	Specifies a IPv4 unicast address family. This is the default option. Configures parameters relating to the BGP exchange of routes to unicast destinations.
multicast	Specifies a IPv4 multicast address family. Configures parameters relating to the BGP exchange of routes to source addresses of multicast streams.

Mode Privileged Exec mode and Exec mode

Example

```
awplus# show ip bgp cidr-only
```

Output This is a sample output from the `show ip bgp cidr-only` command

Figure 40-4: Example output from the `show ip bgp cidr-only` command

```
BGP table version is 0, local router ID is 10.10.10.50
Status codes: s suppressed, d damped, h history, p stale, *
valid, > best, i - internal
Origin codes: i - IGP, e - EGP, ? - incomplete
   Network        Next Hop           Metric LocPrf Weight Path
*> 3.3.3.0/24      10.10.10.10                0 11 i
*> 6.6.6.0/24      0.0.0.0                    32768 i
Total number of prefixes 2
```

show ip bgp community

Use this command to display routes matching the communities.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

You may use any combination and repetition of parameters listed in the `<type>` placeholder.

Syntax `show ip bgp community [<type>] [exact-match]`

Parameter	Description
<code><type></code>	{ [AA:NN] [local-AS] [no-advertise] [no-export] }
<code>AA:NN</code>	Specifies the Autonomous System (AS) community number, in AA:NN format.
<code>local-AS</code>	Do not send outside local Autonomous Systems (well-known community).
<code>no-advertise</code>	Do not advertise to any peer (well-known community).
<code>no-export</code>	Do not export to next AS (well-known community).
<code>exact-match</code>	Specifies that the exact match of the communities is displayed. This optional parameter cannot be repeated.

Mode Privileged Exec mode and Exec mode

Examples

```
awplus# show ip bgp community 64497:64499 exact-match
awplus# show ip bgp community 64497:64499 64500:64501 exact-match
awplus# show ip bgp community 64497:64499 64500:64501 no-advertise 64510:64511
awplus# show ip bgp community no-advertise no-advertise no-advertise exact-match
awplus# show ip bgp community no-export 64510:64511 no-advertise local-AS no-export
awplus# show ip bgp community no-export 64510:64511 no-advertise 64497:64499 64500:64501 no-export
awplus# show ip bgp community no-export 64497:64499 no-advertise local-AS no-export
```

Note that the AS numbers shown are for exemplification only.

Related Commands [set community](#)

show ip bgp community-info

Use this command to list all BGP community information.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show ip bgp community-info`

Mode Privileged Exec mode and Exec mode

Example

```
awplus# show ip bgp community-info
```

show ip bgp community-list

Use this command to display routes that match the community-list.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show ip bgp community-list <listname> [exact-match]`

Parameter	Description
<listname>	Specifies the community list name.
exact-match	Displays only routes that have exactly the same specified communities.

Mode Privileged Exec mode and Exec mode

Example

```
awplus# show ip bgp community-list mylist exact-match
```


show ip bgp dampening

Use this command to display detailed information about dampening.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip bgp dampening {dampened-paths|flap-statistics|parameters}`
`show ip bgp {multicast|unicast} dampening {dampened-paths|flap-statistics|parameters}`

Parameter	Description
dampened-paths	Display paths suppressed due to dampening.
flap-statistics	Display flap statistics of routes.
parameters	Display details of configured dampening parameters.
unicast	Specifies a IPv4 unicast address family. This is the default option. Configures parameters relating to the BGP exchange of routes to unicast destinations.
multicast	Specifies a IPv4 multicast address family. Configures parameters relating to the BGP exchange of routes to source addresses of multicast streams.

Mode Exec mode and Privileged Exec mode

Example

```
awplus# show ip bgp dampening dampened-paths
```

Usage Enable BGP dampening to maintain dampened-path information in memory.

Output The following is sample output displaying all the dampening parameters:

Figure 40-5: Example output from the **show ip bgp dampening parameters** command

```
awplus#show ip bgp dampening parameters
dampening 15 750 2000 60 15
  Reachability Half-Life time      : 15 min
  Reuse penalty                    : 750
  Suppress penalty                 : 2000
  Max suppress time                : 60 min
  Un-reachability Half-Life time   : 15 min
  Max penalty (ceil)               : 11999
  Min penalty (floor)              : 375
```

The following sample output is showing that the internal route (i), has flapped 3 times and is now categorized as history (h).

Figure 40-6: Example output from the **show ip bgp dampening flap-statistics** command

```
awplus# show ip bgp dampening flap-statistics
BGP table version is 1, local router ID is 30.30.30.77
Status codes: s suppressed, d damped, h history, * valid, > best, i - internal, S
Stale
Origin codes: i - IGP, e - EGP, ? - incomplete
   Network          From            Flaps  Duration  Reuse    Path
   hi1.1.1.0/24      10.100.0.62          3    00:01:20      i
```

The following sample output is showing a dampened route in the 1.1.1.0/24 network.

Figure 40-7: Example output from the **show ip bgp dampening dampened-path** command

```
awplus# show ip bgp dampening dampened-paths
BGP table version is 1, local router ID is 30.30.30.77
Status codes: s suppressed, d damped, h history, * valid, > best, i - internal, S
Stale
Origin codes: i - IGP, e - EGP, ? - incomplete
   Network          From            Reuse    Path
   di 1.1.1.0/24      10.100.0.62      00:35:10  i
Total number of prefixes 1
```

show ip bgp filter-list

Use this command to display routes conforming to the filter-list.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show ip bgp filter-list <listname>`

`show ip bgp {multicast|unicast} filter-list <listname>`

Parameter	Description
<listname>	Specifies the regular-expression access list name.
unicast	Specifies a IPv4 unicast address family. This is the default option. Configures parameters relating to the BGP exchange of routes to unicast destinations.
multicast	Specifies a IPv4 multicast address family. Configures parameters relating to the BGP exchange of routes to source addresses of multicast streams.

Mode Privileged Exec mode and Exec mode

Example

```
awplus# show ip bgp filter-list mylist
awplus# show ip bgp unicast filter-list atl
```

show ip bgp inconsistent-as

Use this command to display routes with inconsistent AS Paths.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip bgp inconsistent-as`
`show ip bgp {multicast|unicast} inconsistent-as`

Parameter	Description
unicast	Specifies a IPv4 unicast address family. This is the default option. Configures parameters relating to the BGP exchange of routes to unicast destinations.
multicast	Specifies a IPv4 multicast address family. Configures parameters relating to the BGP exchange of routes to source addresses of multicast streams.

Mode Privileged Exec mode and Exec mode

Example

```
awplus# show ip bgp inconsistent-as
awplus# show ip bgp ipv4 unicast inconsistent-as
```

show ip bgp longer-prefixes

Use this command to display the route of the local BGP routing table for a specific prefix with a specific mask or for any prefix having a longer mask than the one specified.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip bgp <ip-address/m> longer-prefixes`
`show ip bgp {multicast|unicast} <ip-address/m> longer-prefixes`

Parameter	Description
unicast	Specifies a IPv4 unicast address family. This is the default option. Configures parameters relating to the BGP exchange of routes to unicast destinations.
multicast	Specifies a IPv4 multicast address family. Configures parameters relating to the BGP exchange of routes to source addresses of multicast streams.
<ip-address/m>	Neighbor's IP address and subnet mask, entered in the form A.B.C.D/M. Where M is the subnet mask length.

Mode Privileged Exec mode and Exec mode

Example

```
awplus# show ip bgp 10.10.0.10/24 longer-prefixes
awplus# show ip bgp multicast 3.3.3.3/16 longer-prefixes
```

show ip bgp neighbors

Use this command to display detailed information on peering connections to all BGP neighbors.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip bgp neighbors [<ipaddr> [advertised-routes|<received>|received-routes|routes]]`

`show ip bgp {multicast|unicast} neighbors [<ipaddr> [advertised-routes|<received>|received-routes|routes]]`

Parameter	Description
<ipaddr>	Specifies the IPv4 address.
advertised-routes	Displays the routes advertised to a BGP neighbor.
<received>	received prefix-filter Displays all received routes, both accepted and rejected.
prefix-filter	Displays the prefix-list filter.
received-routes	Displays the received routes from neighbor. To display all the received routes from the neighbor, configure the BGP soft reconfigure first.
routes	Displays all accepted routes learned from neighbors.
unicast	Specifies a IPv4 unicast address family. This is the default option. Configures parameters relating to the BGP exchange of routes to unicast destinations.
multicast	Specifies a IPv4 multicast address family. Configures parameters relating to the BGP exchange of routes to source addresses of multicast streams.

Mode Privileged Exec mode and Exec mode

Example

```
awplus# show ip bgp neighbors 1.2.3.4 received-routes

awplus# show ip bgp ipv4 unicast neighbors 7.67.7.0 received
prefix-filter
```

Output This is a sample output from the `show ip bgp neighbors` command displaying information about the specified neighbor.

Figure 40-8: Example output from the `show ip bgp neighbors` command

```
awplus#show ip bgp neighbors
BGP neighbor is 192.10.23.67, remote AS 1, local AS 1, internal
link
  BGP version 4, remote router ID 172.22.10.10
  BGP state = Established, up for 00:00:22
  Last read 00:00:22, hold time is 240, keepalive interval is 60
seconds
  Neighbor capabilities:
    Route refresh: advertised and received (old and new)
    Address family IPv4 Unicast: advertised and received
  Received 3 messages, 0 notifications, 0 in queue
  Sent 3 messages, 0 notifications, 0 in queue
  Route refresh request: received 0, sent 0
  Minimum time between advertisement runs is 5 seconds

For address family: IPv4 Unicast
  BGP table version 1, neighbor version 1
  Index 1, Offset 0, Mask 0x2
  AF-dependant capabilities:
    Graceful restart: advertised, received

  Community attribute sent to this neighbor (both)
    0 accepted prefixes
    0 announced prefixes

Connections established 1; dropped 0
Graceful-restart Status:
  Remote restart-time is 120 sec

Local host: 192.10.23.80, Local port: 33837
Foreign host: 192.10.23.67, Foreign port: 179
Nexthop: 192.10.23.80
Nexthop global: 1111::80
Nexthop local: fe80::203:47ff:fe97:bb79
BGP connection: non shared network
```

show ip bgp paths

Use this command to display BGP path information.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip bgp paths`
`show ip bgp {multicast|unicast} paths`

Parameter	Description
unicast	Specifies a IPv4 unicast address family. This is the default option. Configures parameters relating to the BGP exchange of routes to unicast destinations.
multicast	Specifies a IPv4 multicast address family. Configures parameters relating to the BGP exchange of routes to source addresses of multicast streams.

Mode Privileged Exec mode and Exec mode

Example
`awplus# show ip bgp paths`

show ip bgp prefix-list

Use this command to display routes matching the prefix-list.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip bgp prefix-list <list>`
`show ip bgp {multicast|unicast} prefix-list <list>`

Parameter	Description
<list>	Specifies the name of the IP prefix list.
unicast	Specifies a IPv4 unicast address family. This is the default option. Configures parameters relating to the BGP exchange of routes to unicast destinations.
multicast	Specifies a IPv4 multicast address family. Configures parameters relating to the BGP exchange of routes to source addresses of multicast streams.

Mode Privileged Exec mode and Exec mode

Example
`awplus# show ip bgp prefix-list mylist`

show ip bgp quote-regexp

Use this command to display routes matching the AS path regular expression in quotes.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip bgp quote-regexp <expression>`

Parameter	Description
<expression>	Specifies a regular-expression to match the BGP AS paths

Mode Privileged Exec mode and Exec mode

Example

```
awplus# show ip bgp quote-regexp "myexpression"
```

show ip bgp regexp

Use this command to display routes matching the AS path regular expression.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip bgp regexp <expression>`
`show ip bgp {multicast|unicast} regexp <expression>`

Parameter	Description
regexp	Displays routes matching the AS path regular expression.
<expression>	Specifies a regular-expression to match the BGP AS paths.
unicast	Specifies a IPv4 unicast address family. This is the default option. Configures parameters relating to the BGP exchange of routes to unicast destinations.
multicast	Specifies a IPv4 multicast address family. Configures parameters relating to the BGP exchange of routes to source addresses of multicast streams.

Mode Privileged Exec mode and Exec mode

Example

```
awplus# show ip bgp regexp myexpression
```


show ip bgp route-map

Use this command to display routes that match the specified route-map.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip bgp route-map <route-map>`
`show ip bgp {multicast|unicast} route-map <route-map>`

Parameter	Description
<route-map>	Specifies a route-map that is matched.
unicast	Specifies a IPv4 unicast address family. This is the default option. Configures parameters relating to the BGP exchange of routes to unicast destinations.
multicast	Specifies a IPv4 multicast address family. Configures parameters relating to the BGP exchange of routes to source addresses of multicast streams.

Mode Privileged Exec mode and Exec mode

show ip bgp scan

Use this command to display BGP scan status.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip bgp scan`

Mode Privileged Exec mode and Exec mode

Example

```
awplus# show ip bgp scan
```

Output Figure 40-9: Example output from the show ip bgp scan command

```
BGP scan is running
BGP scan interval is 60
BGP instance : AS is 11,DEFAULT
Current BGP nexthop cache:
BGP connected route:
 10.10.10.0/24
 10.10.11.0/24
```

show ip bgp summary

Use this command to display a summary of BGP neighbor status.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show ip bgp summary`
`show ip bgp {multicast|unicast} summary`

Parameter	Description
unicast	Specifies a IPv4 unicast address family. This is the default option. Configures parameters relating to the BGP exchange of routes to unicast destinations.
multicast	Specifies a IPv4 multicast address family. Configures parameters relating to the BGP exchange of routes to source addresses of multicast streams.

Mode Privileged Exec mode and Exec mode

Example

```
awplus# show ip bgp summary
```

Output This is a sample output, displaying a summary of BGP neighbor status

Figure 40-10: Example output from the **show ip bgp summary** command

```
awplus# show ip bgp summary
BGP router identifier 10.10.15.50, local AS number 65000
1 BGP AS-PATH entries
0 BGP community entries
Neighbor V AS MsgRcvd MsgSent TblVer InQ OutQ Up/Down State
PfxRcd
10.10.9.50      4 65000      460      595 0    0    0 00:17:48    3
10.10.14.51     4 100         93     1200 0    0    0 00:42:16
Total number of neighbors 2
```

show ip bgp view

Use this command to view the neighbors of the given instance.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip bgp view <instance> [<ip-address>[/M]]`

Parameter	Description
<instance>	The name of the instance to display data for.
<ip-address>	IPv4 address, entered in the form A.B.C.D.
/M	The subnet mask length

Mode Privileged Exec mode and Exec mode

Example

```
awplus# show ip bgp 128 view instance1 10.10.10.0/24
```

Output Figure 40-11: Example output from the **show ip bgp view** command

```
awplus#show ip bgp view I2

BGP table version is 0, local router ID is 10.10.10.50
Status codes: s suppressed, d damped, h history, p stale, *
valid, > best, i - internal
Origin codes: i - IGP, e - EGP, ? - incomplete
   Network        Next Hop           Metric LocPrf Weight Path
*>i100.156.70.0/24 10.10.10.52             0         0 i
*>i100.156.71.0/24 10.10.10.52             0         0 i
*>i100.156.72.0/24 10.10.10.52             0         0 i
*>i100.156.73.0/24 10.10.10.52             0         0 i
*>i100.156.74.0/24 10.10.10.52             0         0 i
Total number of prefixes 5
```

Related Commands [show ip bgp neighbors](#)

show ip bgp view neighbors

Use this command to view the neighbors of the given instance.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show ip bgp view <instance> neighbors`
`show ip bgp view <instance> neighbors [<ip-address>]`

Parameter	Description
<instance>	The name of the instance to display data for.
<ip-address>	The IPv4 address of the neighbor, entered in the form A.B.C.D.

Mode Privileged Exec mode and Exec mode

Example

```
awplus# show ip bgp 128 view instance1 neighbors 10.10.10.5
```

Output Figure 40-12: Example output from the `show ip bgp view neighbors` command

```
awplus#show ip bgp view I2 neighbors

BGP neighbor is 10.10.10.52, remote AS 10, local AS 10, internal
link
  BGP version 4, remote router ID 10.10.10.52
  BGP state = Established, up for 00:03:22
  Last read 00:00:13, hold time is 90, keepalive interval 30
seconds
  Neighbor capabilities:
    Route refresh: advertised
    Address family IPv4 Unicast: advertised
  Received 8 messages, 0 notifications, 0 in queue
  Sent 8 messages, 0 notifications, 0 in queue
  Route refresh request: received 0, sent 0
  Minimum time between advertisement runs is 5 seconds
For address family: IPv4 Unicast
  Community attribute sent to this neighbor (both)
  5 accepted prefixes
  0 announced prefixes
  Connections established 1; dropped 0
  Local host: 10.10.10.50, Local port: 179
  Foreign host: 10.10.10.52, Foreign port: 36950
  Nexthop: 10.10.10.50
  Nexthop global: fe80::280:c8ff:feb9:d268
  Nexthop local: ::
  BGP connection: non shared network
  Read thread: on  Write thread: off
```

Related Commands `show ip bgp neighbors`

show ip bgp view summary

Use this command to view the summary data of neighbors of the given instance.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show ip bgp view <instance> summary`
`show ip bgp view <instance> [{multicast|unicast}] summary`

Parameter	Description
<instance>	the name of the instance to display data for.
unicast	Specifies a IPv4 unicast address family. This is the default option. Configures parameters relating to the BGP exchange of routes to unicast destinations.
multicast	Specifies a IPv4 multicast address family. Configures parameters relating to the BGP exchange of routes to source addresses of multicast streams.

Mode Privileged Exec mode and Exec mode

Example

```
awplus# show ip bgp 128 view instance1 neighbor 10.10.10.5
```

Output The following example shows the summary data of instance named I2.

Figure 40-13: Example output from the **show ip bgp view summary** command

```
awplus#show ip bgp view I2 summary

BGP router identifier 10.10.10.50, local AS number 10
1 BGP AS-PATH entries
0 BGP community entries

Neighbor V  AS MsgRcvd MsgSent TblVer  InQ OutQ Up/Down  State/PfxRcd
10.10.10.52 4  10      1      2      0   0   0 00:00:07      5
Total number of neighbors 1
```

Related Commands `show ip bgp neighbors`

show ip community-list

Use this command to display routes that match a specified community-list name or number.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip community-list [<listnumber>|<listname>]`

Parameter	Description
<code><listnumber></code>	Specifies the community list number in the range <1-199> as specified by a previously issued ip community-list command.
<code><listname></code>	Specifies the community list name as specified by a previously issued ip community-list command..

Mode Privileged Exec mode and Exec mode

Example

```
awplus# show ip community-list mylist
awplus# show ip community-list 99
```

show ip extcommunity-list

Use this command to display a configured extcommunity-list.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip extcommunity-list [<1-199>|<extcommunity-listname>]`

Parameter	Description
<code><1-199></code>	Extcommunity-list number
<code><extcommunity-listname></code>	Extcommunity-list name

Mode Exec mode and Privileged Exec mode

Example

```
awplus# show ip extcommunity-list 33
```

show ip protocols bgp

Use this command to display BGP process parameters and statistics.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip protocols bgp`

Mode Exec mode and Privileged Exec mode

Example To display BGP process parameters and statistics, use the command:

```
awplus# show ip protocols bgp
```

Output Figure 40-14: Example output from the show ip protocols bgp command

```
Routing Protocol is "bgp 100"
  IGP synchronization is disabled
  Automatic route summarization is disabled
  Default local-preference applied to incoming route is 100
  Redistributing:
  Neighbor(s):
  Address AddressFamily FiltIn FiltOut DistIn DistOut RouteMapIn RouteMapOut Weight
10.10.10.1          unicast
```

synchronization

Use this command to enable IGP synchronization of Internal BGP (iBGP) learned routes with the Internal Gateway Protocol (IGP) system in the router configuration mode or in the address-family configuration mode.

Use the `no` parameter with this command to disable this function.

Syntax `synchronization`
 `no synchronization`

Default IGP synchronization is disabled.

Mode Router mode and Address Family [`ipv4 unicast`|`ipv4 multicast`] mode

Usage Synchronization is used when a BGP router should not advertise routes learned from iBGP neighbors, unless those routes are also present in an IGP (for example, OSPF). Synchronization may be enabled when all the routers in an autonomous system do not speak BGP, and the autonomous system is a transit for other autonomous systems. The `no synchronization` command is used when BGP router can advertise routes learned from its iBGP neighbors without waiting for the IGP reachability to be present.

Example The following example enables IGP synchronization of iBGP routes in Router mode.

```
awplus# configure terminal
awplus(config)# router bgp 11
awplus(config-router)# synchronization
```

The following example enables IGP synchronization of iBGP routes in the IPv4-Unicast address family.

```
awplus# configure terminal
awplus(config)# router bgp 11
awplus(config)# address-family ipv4 unicast
awplus(config-af)# synchronization
```

timers (BGP)

Use this command sets the BGP keepalive timer and holdtime timer values.

Use the no parameter with this command to reset timers to default value.

Syntax `timers bgp <keep_alive> <hold_time>`
`no timers bgp`

Parameter	Description
<code><keep_alive></code>	<code><0-65535></code> The frequency with which the keepalive messages are sent to the neighbors. The default value is 60 seconds.
<code><hold_time></code>	<code><0-65535></code> The interval after which the neighbor is considered dead if keepalive messages are not received. The default holdtime value is 180 seconds.

Mode Router mode

Usage This command is used globally to set or unset the keepalive and holdtime values for all the neighbors.

Example

```
awplus# configure terminal
awplus(config)# router bgp 10
awplus(config-router)# timers bgp 40 120
```

undebg bgp

Use this command to disable BGP debugging functions.

Syntax undebg bgp [all|dampening|events|filters|fsm|keepalives|nsm|updates]
undebg all bgp

Parameter	Description
all	Disable all debugging for BGP
dampening	Disable debugging for BGP dampening.
events	Disable debugging for BGP events.
filters	Disable debugging for BGP filters.
fsm	Disable debugging for BGP Finite State Machine (FSM).
keepalives	Disable debugging for BGP keepalives.
nsm	Disable debugging for NSM messages.
updates	Disable debugging for BGP updates.

Mode Privileged Exec mode

Example
`awplus# undebg bgp events`

Chapter 41: Route Map Commands



Command List	41.2
match as-path	41.2
match community	41.3
match interface	41.4
match ip address	41.5
match ip next-hop	41.7
match ipv6 address	41.9
match ipv6 next-hop	41.10
match metric	41.11
match origin	41.12
match route-type	41.13
match tag	41.14
route-map	41.15
set aggregator	41.17
set as-path	41.18
set atomic-aggregate	41.19
set comm-list delete	41.20
set community	41.21
set dampening	41.23
set extcommunity	41.25
set ip next-hop (route map)	41.26
set ipv6 next-hop	41.27
set local-preference	41.28
set metric	41.29
set metric-type	41.30
set origin	41.31
set originator-id	41.32
set tag	41.33
set weight	41.34
show route-map	41.35

Command List

This chapter provides an alphabetical reference for route map commands. These commands can be divided into the following categories:

- **route-map** command, used to create a route map and/or route map entry, and to put you into route map mode
- **match** commands, used to determine which routes or BGP update messages the route map applies to
- **set** commands, used to modify matching routes or BGP update messages.

match as-path

Use this command to add an autonomous system (AS) path match clause to a route map entry. Specify the AS path attribute value or values to match by specifying the name of an AS path access list. To create the AS path access list, enter Global Configuration mode and use the `ip as-path access-list` command.

A BGP update message matches the route map if its attributes include AS path values that match the AS path access list.

Each entry of a route map can only match against one AS path access list in one AS path match clause. If the route map entry already has an AS path match clause, entering this command replaces that match clause with the new clause.

Note that AS path access lists and route map entries both specify an action of deny or permit. The action in the AS path access list determines whether the route map checks update messages for a given AS path value. The route map action and its set clauses determine what the route map does with update messages that contain that AS path value.

Use the `no` parameter to remove the AS path match clause from a route map entry.

Syntax `match as-path <AS-path-listname>`
`no match as-path [<AS-path-listname>]`

Parameter	Description
<code><AS-path-listname></code>	Specifies an AS path access list name.

Mode Route-map mode

Usage This command is valid for BGP update messages only.

Examples To add entry 34 to the route map called `myroute`, which will discard update messages if they contain the AS path values that are included in `myaccesslist`, use the commands:

```
awplus# configure terminal
awplus(config)# route-map myroute deny 34
awplus(config-route-map)# match as-path myaccesslist
```

Related Commands

- [ip as-path access-list](#)
- [route-map](#)
- [set as-path](#)
- [show route-map](#)

match community

Use this command to add a community match clause to a route map entry. Specify the community value or values to match by specifying a community list. To create the community list, enter Global Configuration mode and use the [ip community-list](#) command.

A BGP update message matches the route map if its attributes include community values that match the community list.

Each entry of a route map can only match against one community list in one community match clause. If the route map entry already has a community match clause, entering this command replaces that match clause with the new clause.

Note that community lists and route map entries both specify an action of deny or permit. The action in the community list determines whether the route map checks update messages for a given community value. The route map action and its set clauses determine what the route map does with update messages that contain that community value.

Use the `no` parameter to remove the community match clause from a route map.

Syntax

```
match community {<community-listname> | <1-99> | <100-199>} [exact-match]
no match community [<community-listname> | <1-99> | <100-199>] [exact-match]
```

Parameter	Description
<code><community-listname></code>	The community list name or number.
<code><1-99></code>	Community list number (standard range)
<code><100-199></code>	Community list number (expanded range)
<code>exact-match</code>	Exact matching of communities

Mode Route-map mode

Usage This command is valid for BGP update messages only.

Communities are used to group and filter routes. They are designed to provide the ability to apply policies to large numbers of routes by using match and set commands. Community lists are used to identify and filter routes by their common attributes.

Examples To add entry 3 to the route map called `myroute`, which will process update messages if they contain the community values that are included in `mylist`, use the commands:

```
awplus# configure terminal
awplus(config)# route-map myroute permit 3
awplus(config-route-map)# match community mylist
```

Related Commands [ip community-list](#)
[route-map](#)
[set comm-list delete](#)
[set community](#)
[show route-map](#)

match interface

Use this command to add an interface match clause to a route map entry. Specify the interface name to match.

A route matches the route map if its interface matches the interface name.

Each entry of a route map can only match against one interface in one interface match clause. If the route map entry already has an interface match clause, entering this command replaces that match clause with the new clause.

Use the no parameter to remove the interface match clause from the route map entry.

Syntax `match interface <interface>`
`no match interface`

Parameter	Description
<code><interface></code>	The VLAN to match, e.g. vlan2.

Mode Route-map mode

Usage This command is valid for RIP and OSPF routes only.

Example To add entry 10 to the route map called mymap1, which will process routes if they use the interface vlan1, use the commands:

```
awplus# configure terminal
awplus(config)# route-map mymap1 permit 10
awplus(config-route-map)# match interface vlan1
```

Related Commands [match ip address](#)
[match ip next-hop](#)
[match route-type](#)
[match tag](#)
[route-map](#)
[show route-map](#)

match ip address

Use this command to add an IP address prefix match clause to a route map entry. You can specify the prefix or prefixes to match by either:

- specifying the name of an access list. To create the access list, enter Global Configuration mode and use the `access-list` command.
- specifying the name of a prefix list. To create the prefix list, enter Global Configuration mode and use the `ip prefix-list` command.

A route matches the route map entry if the route's prefix matches the access list or prefix list.

Each entry of a route map can have at most one access list-based IP address match clause and one prefix list-based IP address match clause. If the route map entry already has one of these match clauses, entering this command replaces that match clause with the new clause.

Note that access lists, prefix lists and route map entries all specify an action of deny or permit. The action in the access list or prefix list determines whether the route map checks update messages and routes for a given prefix. The route map action and its set clauses determine what the route map does with routes that contain that prefix.

Use the `no` parameter to remove the IP address match clause from a route map entry. To remove a prefix list-based match clause you must also specify the `prefix-list` parameter.

Syntax

```
match ip address {<accesslistID>|prefix-list <prefix_listname>}
no match ip address [<accesslistID>]
no match ip address prefix-list <prefix_listname>
```

Parameter	Description
<accesslistID>	{<access-list-name> <1-199> <1300-2699>} The IP access list name or number
<access-list-name>	The IP access list name
<1-199>	The IP access list number
<1300-2699>	The IP access list number (expanded range)
prefix-list	Use an IP prefix list to specify which prefixes to match
<prefix_listname>	The prefix list name

Mode Route-map mode

Usage The `match ip address` command specifies the IP address to be matched. If there is a match for the specified IP address, and `permit` is specified, the route is redistributed or controlled, as specified by the set action. If the match criteria are met, and `deny` is specified then the route is not redistributed or controlled. If the match criteria are not met, the route is neither accepted nor forwarded, irrespective of `permit` or `deny` specifications.

This command is valid for routes in BGP update messages, and for OSPF and RIP routes.

Examples To add entry 3 to the route map called `myroute`, which will process routes that match the ACL called `List1`, use the commands:

```
awplus# configure terminal
awplus(config)# route-map myroute permit 3
awplus(config-route-map)# match ip address List1
```

To add entry 3 to the route map called `rmap1`, which will process routes that match the prefix list called `mylist`, use the commands:

```
awplus# configure terminal
awplus(config)# route-map rmap1 permit 3
awplus(config-route-map)# match ip address prefix-list mylist
```

Related Commands

- [access-list \(extended\)](#)
- [access-list \(standard\)](#)
- [ip prefix-list](#)
- [route-map](#)
- [show ip access-list](#)
- [show route-map](#)

match ip next-hop

Use this command to add a next-hop match clause to a route map entry. You can specify the next hop to match by either:

- specifying the name of an access list. To create the access list, enter Global Configuration mode and use the `access-list` command.
- specifying the name of a prefix list. To create the prefix list, enter Global Configuration mode and use the `ip prefix-list` command.

A route matches the route map if the route's next hop matches the access list or prefix list.

Each entry of a route map can have at most one access list-based next-hop match clause and one prefix list-based next-hop match clause. If the route map entry already has one of these match clauses, entering this command replaces that match clause with the new clause.

Note that access lists, prefix lists and route map entries all specify an action of deny or permit. The action in the access list or prefix list determines whether the route map checks update messages and routes for a given next-hop value. The route map action and its set clauses determine what the route map does with update messages and routes that contain that next hop.

Use the `no` parameter to remove the next-hop match clause from a route map entry. To remove a prefix list-based match clause you must also specify the `prefix-list` parameter.

Syntax

```
match ip next-hop {<accesslistID>|prefix-list <prefix-listname>}
no match ip next-hop [<accesslistID>]
no match ip next-hop prefix-list [<prefix-listname>]
```

Parameter	Description
<accesslistID>	{<access-list-name> <1-199> <1300-2699>} The IP access list name or number
<access-list-name>	The IP access list name
<1-199>	The IP access list number
<1300-2699>	The IP access list number (expanded range)
prefix-list	Use an IP prefix list to specify which next hop to match
<prefix-listname>	The prefix list name.

Mode Route-map mode

Usage This command is valid for BGP update messages and OSPF and RIP routes.

Examples To add entry 3 to the route map called `rmap1`, which will process routes whose next hop matches the ACL called `mylist`, use the commands:

```
awplus# configure terminal
awplus(config)# route-map rmap1 permit 3
awplus(config-route-map)# match ip next-hop mylist
```

To add entry 3 to the route map called `mymap`, which will process routes whose next hop matches the prefix list called `list1`, use the commands:

```
awplus# configure terminal
awplus(config)# route-map mymap permit 3
awplus(config-route-map)# match ip next-hop prefix-list list1
```

Related Commands

- [access-list \(extended\)](#)
- [access-list \(standard\)](#)
- [ip prefix-list](#)
- [route-map](#)
- [show ip access-list](#)
- [show ip prefix-list](#)
- [show route-map](#)

match ipv6 address

Use this command to specify the match address of route.

Use the `no` parameter with this command to remove the `match ipv6 address` entry.

Syntax `match ipv6 address {<access-list-name>|prefix-list <prefix-listname>}`
`no match ipv6 address [<access-list-name>|prefix-list <prefix-listname>]`

Parameter	Description
<code><access-list-name></code>	The name of the IPv6 access list that specifies criteria for the addresses to match. Valid only with BGP and RIPv6.
<code><prefix-listname></code>	The name of the IPv6 prefix list that specifies criteria for the addresses to be matched. Valid only with BGP and RIPv6.

Mode Route-map mode

Usage The `match ipv6 address <access-list>` command specifies the IPv6 address to be matched. If there is a match for the specified IPv6 address, and `permit` is specified, the route is redistributed or controlled as specified by the set action. If the match criteria are met, and `deny` is specified, the route is not redistributed or controlled. If the match criteria are not met, the route is neither accepted nor forwarded, irrespective of `permit` or `deny` specifications.

The `match ipv6 address prefix-list` command specifies the entries of prefix-lists to be matched. If there is a match for the specified prefix-list entries, and `permit` is specified, the route is redistributed or controlled as specified by the set action. If the match criteria are met, and `deny` is specified, the route is not redistributed or controlled. If the match criteria are not met, the route is neither accepted nor forwarded, irrespective of `permit` or `deny` specifications.

Examples

```
awplus# configure terminal
awplus(config)# route-map rmap1 deny 1
awplus(config-route-map)# match ipv6 address rmap1

awplus# configure terminal
awplus(config)# route-map rmap1 permit 3
awplus(config-route-map)# match ipv6 address prefix-list mylist
```

match ipv6 next-hop

Use this command to specify a next-hop address to be matched by the route-map.

Use the `no` parameter with this command to disable this function

Syntax `match ipv6 next-hop {<access-list-name>|<ipv6-addr>|prefix-list
<prefix-listname>}`

`no match ipv6 next-hop [<access-list-name>|<ipv6-addr>|prefix-list
[<prefix-listname>]]`

Parameter	Description
<code><access-list-name></code>	The name of the IPv6 access list that specifies criteria for the addresses to match.
<code><ipv6-addr></code>	The IPv6 address of the next hop. The IPv6 address uses the format X:X::X:X.
<code><prefix-listname></code>	The name of the IPv6 prefix list that specifies criteria for the addresses to be matched.

Mode Route-map mode

Usage The `match ipv6 next-hop` command specifies the next-hop address to be matched. If there is a match for the specified next-hop address, and `permit` is specified, the route is redistributed or controlled as specified by the set action. If the match criteria are met, and `deny` is specified, the route is not redistributed or controlled. If the match criteria are not met, the route is neither accepted nor forwarded, irrespective of `permit` or `deny` specifications.

Note: This command is valid only for BGP.

Examples

```
awplus# configure terminal
awplus(config)# route-map rmap1 permit 3
awplus(config-route-map)# match ipv6 next-hop 3ffe::1
```

match metric

Use this command to add a metric match clause to a route map entry. Specify the metric value to match.

A route matches the route map if its metric matches the route map's metric. A BGP update message matches the route map if its MED attribute value matches the route map's metric.

Each entry of a route map can only match against one metric value in one metric match clause. If the route map entry already has a metric match clause, entering this command replaces that match clause with the new clause.

Use the no parameter to remove the metric match clause from the route map entry.

Syntax `match metric <metric>`
`no match metric [<metric>]`

Parameter	Description
<metric>	<0-4294967295> Specifies the metric value.

Mode Route-map mode

Usage This command is valid for BGP update messages and OSPF and RIP routes.

Examples To stop entry 3 of the route map called `myroute` from processing routes with a metric of 888999, use the commands:

```
awplus# configure terminal
awplus(config)# route-map myroute permit 3
awplus(config-route-map)# no match metric 888999
```

Related Commands `route-map`
`set metric`
`show route-map`

match origin

Use this command to add an origin match clause to a route map entry. Specify the origin attribute value to match.

A BGP update message matches the route map if its origin attribute value matches the route map's origin value.

Each entry of a route map can only match against one origin in one origin match clause. If the route map entry already has an origin match clause, entering this command replaces that match clause with the new clause.

Use the `no` parameter to remove the origin match clause from the route map entry.

Syntax

```
match origin {egp|igp|incomplete}
no match origin [egp|igp|incomplete]
```

Parameter	Description
egp	Learned from an exterior gateway protocol
igp	Learned from a local interior gateway protocol
incomplete	Of unknown heritage, for example a static route

Mode Route-map mode

Usage The origin attribute defines the origin of the path information. The `egp` parameter is indicated as an `e` in the routing table, and it indicates that the origin of the information is learned via Exterior Gateway Protocol. The `igp` parameter is indicated as an `i` in the routing table, and it indicates the origin of the path information is interior to the originating AS. The `incomplete` parameter is indicated as a `?` in the routing table, and indicates that the origin of the path information is unknown or learned through other means. If a static route is redistributed into BGP, the origin of the route is incomplete.

The `match origin` command specifies the origin to be matched. If there is a match for the specified origin, and `permit` is specified, the route is redistributed or controlled as specified by the `set` action. If the match criteria are met, and `deny` is specified, the route is not redistributed or controlled. If the match criteria are not met, the route is neither accepted nor forwarded, irrespective of `permit` or `deny` specifications.

This command is valid for BGP update messages only.

Example To add entry 34 to the route map called "rmap1", which will drop externally-originated routes, use the commands:

```
awplus# configure terminal
awplus(config)# route-map myroute deny 34
awplus(config-route-map)# match origin egp
```

Related Commands

- [route-map](#)
- [set origin](#)
- [show route-map](#)

match route-type

Use this command to add an external route-type match clause to a route map entry. Specify whether to match OSPF type-1 external routes or OSPF type-2 external routes.

An OSPF route matches the route map if its route type matches the route map's route type.

Each entry of a route map can only match against one route type in one match clause. If the route map entry already has a route type match clause, entering this command replaces that match clause with the new clause.

Use the no parameter to remove the route type match clause from the route map entry.

Syntax `match route-type external {type-1|type-2}`
`no match route-type external [type-1|type-2]`

Parameter	Description
type-1	OSPF type-1 external routes
type-2	OSPF type-2 external routes

Mode Route-map mode

Usage Use the `match route-type external` command to match specific external route types. AS-external LSA is either Type-1 or Type-2. `external type-1` matches only Type 1 external routes, and `external type-2` matches only Type 2 external routes.

This command is valid for OSPF routes only.

Examples To add entry 10 to the route map called `mymap1`, which will process type-1 external routes, use the commands:

```
awplus# configure terminal
awplus(config)# route-map mymap1 permit 10
awplus(config-route-map)# match route-type external type-1
```

Related Commands `match interface`
`match ip address`
`match ip next-hop`
`match tag`
`route-map`
`set metric-type`
`show route-map`

match tag

Use this command to add a tag match clause to a route map entry. Specify the route tag value to match.

An OSPF route matches the route map if it has been tagged with the route map's tag value. Routes can be tagged through OSPF commands or through another route map's set clause.

Each entry of a route map can only match against one tag in one match clause. If the route map entry already has a tag match clause, entering this command replaces that match clause with the new clause.

Use the no parameter to remove the tag match clause from the route map entry.

Syntax `match tag <0-4294967295>`
`no match tag [<0-4294967295>]`

Mode Route-map mode

Usage This command is valid for OSPF routes only.

Examples To add entry 10 to the route map called `mymap1`, which will process routes that are tagged 100, use the following commands:

```
awplusc# onfigure terminal
awplus(config)# route-map mymap1 permit 10
awplus(config-route-map)# match tag 100
```

Related Commands `match interface`
 `match ip address`
 `match ip next-hop`
 `match route-type`
 `route-map`
 `set tag`
 `show route-map`

route-map

Use this command to configure a route map entry, and to specify whether the device will process or discard matching routes and BGP update messages.

The switch uses a name to identify the route map, and a sequence number to identify each entry in the route map.

The route-map command puts you into route-map configuration mode. In this mode, you can use the following:

- one or more of the match commands to create match clauses. These specify what routes or update messages match the entry.
- one or more of the set commands to create set clauses. These change the attributes of matching routes or update messages.

Use the no parameter to delete a route map or to delete an entry from a route map.

Syntax

```
route-map <mapname> {deny|permit} <seq>
no route-map <mapname>
no route-map <mapname> {deny|permit} <seq>
```

Parameter	Description
<mapname>	A name to identify the route map
deny	The route map causes a routing process to discard matching routes or BGP update messages
permit	The route map causes a routing process to use matching routes or BGP update messages
<seq>	<1-65535> The sequence number of the entry. You can use this parameter to control the order of entries in this route map.

Mode Global Configuration mode

Usage Route maps allow you to control and modify routing information by filtering routes and setting route attributes. You can apply route maps when the device:

- processes BGP update messages that it has received from a peer
- prepares BGP update messages to send to peers
- redistributes routes from one routing protocol into another
- redistributes static routes into routing protocols
- uses BGP route flap dampening

When a routing protocol passes a route or update message through a route map, it checks the entries in order of their sequence numbers, starting with the lowest numbered entry.

If it finds a match on a route map with an action of permit, then it applies any set clauses and accepts the route. Having found a match, the route is not compared against any further entries of the route map.

If it finds a match on a route map with an action of deny, it will discard the matching route.

If it does not find a match, it discards the route or update message. This means that route maps end with an implicit deny entry. To permit all non-matching routes or update messages, end your route map with an entry that has an action of permit and no match clause.

Examples To enter route-map mode for entry 1 of the route map called `route1`, and then add a match and set clause to it, use the commands:

```
awplus# configure terminal
awplus(config)# route-map route1 permit 1
awplus(config-route-map)# match as-path 60
awplus(config-route-map)# set weight 70
```

Note how the prompt changes when you go into route map configuration mode.

To make the device process non-matching update messages instead of discarding them, add a command like the following one:

```
awplus(config)# route-map route1 permit 100
```

Related Commands `show route-map`

For BGP:

`bgp dampening`
`neighbor default-originate`
`neighbor route-map`
`neighbor unsuppress-map`
`network (BGP)`
`redistribute route-map`
`show ip bgp route-map`

For OSPF:

`default-information originate (OSPF)`
`redistribute (OSPF)`

For RIP:

`redistribute (RIP)`

set aggregator

Use this command to add an aggregator set clause to a route map entry.

When a BGP update message matches the route map entry, the device sets the update's aggregator attribute. The aggregator attribute specifies the AS and IP address of the device that performed the aggregation.

Use the no parameter to remove the set clause.

Syntax `set aggregator as <asnum> <ip-address>`
`no set aggregator as [<asnum> <ip-address>]`

Parameter	Description
<asnum>	The AS number of the aggregator.
<ip-address>	The IP address of the aggregator.

Mode Route-map mode

Usage An Autonomous System (AS) is a collection of networks under a common administration sharing a common routing strategy. It is subdivided by areas, and is assigned a unique 16-bit number. Use the set aggregator command to assign an AS number for the aggregator.

This command is valid for BGP update messages only.

Examples To use entry 3 of the route map called `myroute` to set the aggregator attribute to 43 10.10.0.3 in matching update messages, use the commands:

```
awplus# configure terminal
awplus(config)# route-map myroute permit 3
awplus(config-route-map)# set aggregator as 43 10.10.0.3
```

Related Commands `route-map`
`show route-map`

set as-path

Use this command to add an AS path set clause to a route map entry.

When a BGP update message matches the route map entry, the device prepends the specified Autonomous System Number (ASN) or ASNs to the update's AS path attribute.

The AS path attribute is a list of the autonomous systems through which the announcement for the prefix has passed. As prefixes pass between autonomous systems, each autonomous system adds its ASN to the beginning of the list. This means that the AS path attribute can be used to make routing decisions.

Use the `no` parameter to remove the set clause.

Syntax `set as-path prepend <1-65535> [<1-65535>]...`
`no set as-path prepend [<1-65535> [<1-65535>]...]`

Parameter	Description
<code>prepend</code>	Prepends the autonomous system path.
<code><1-65535></code>	The number to prepend to the AS path. If you specify multiple ASNs, separate them with spaces.

Mode Route-map mode

Usage Use the `set as-path` command to specify an autonomous system path. By specifying the length of the AS-Path, the device influences the best path selection by a neighbor. Use the `prepend` parameter with this command to prepend an AS path string to routes increasing the AS path length.

This command is valid for BGP update messages only.

Examples To use entry 3 of the route map called `myroute` to prepend ASN 8 and 24 to the AS path of matching update messages, use the commands:

```
awplus# configure terminal
awplus(config)# route-map myroute permit 3
awplus(config-route-map)# set as-path prepend 8 24
```

Related Commands `match as-path`
`route-map`
`show route-map`

set atomic-aggregate

Use this command to add an atomic aggregate set clause to a route map entry.

When a BGP update message matches the route map entry, the device adds the atomic aggregate attribute to the update.

Use the no parameter to remove the set clause.

Syntax `set atomic-aggregate`
 `no set atomic-aggregate`

Mode Route-map mode

Usage This command is valid for BGP update messages only.

Examples To use entry 3 of the route map called `rmap1` to add the atomic aggregator attribute to matching update messages, use the commands:

```
awplus# configure terminal
awplus(config)# route-map rmap1 permit 3
awplus(config-route-map)# set atomic-aggregate
```

Related Commands `route-map`
 `show route-map`

set comm-list delete

Use this command to delete one or more communities from the community attribute of a BGP update message. Specify the communities to delete by specifying a community list. To create the community list, enter Global Configuration mode and use the [ip community-list](#) command.

When a BGP update message matches the route map entry, the device deletes the specified communities from the update's comm.unify attribute.

Use the no parameter to stop deleting the communities.

Syntax `set comm-list {<1-199>|<100-199>|<word>} delete`
`no set comm-list {<1-199>|<100-199>|<word>} delete`

Parameter	Description
<1-99>	Standard community-list number.
<100-199>	Expanded community-list number.
<word>	Name of the Community-list.

Mode Route-map mode

Usage This command is valid for BGP update messages only.

Examples To use entry 3 of the route map called `myroute` to delete the communities in community list 34 from matching update messages, use the commands:

```
awplus# configure terminal
awplus(config)# route-map myroute permit 3
awplus(config-route-map)# set comm-list 34 delete
```

Related Commands [ip community-list](#)
[match community](#)
[route-map](#)
[set community](#)
[show route-map](#)

set community

Use this command to add a community set clause to a route map entry.

When a BGP update message matches the route map entry, the device takes one of the following actions:

- changes the update's community attribute to the specified value or values, or
- adds the specified community value or values to the update's community attribute, if you specify the additive parameter after specifying another parameter. or
- removes the community attribute from the update, if you specify the none parameter

Use the no parameter to remove the set clause.

Syntax

```
set community {[<1-65535>][AA:NN] [internet] [local-AS]
[no-advertise] [no-export] [additive]}

no set community {[AA:NN] [internet] [local-AS] [no-advertise]
[no-export] [additive]}

set community none

no set community none
```

Parameter	Description
<1-65535>	The AS number of the community as an integer not in AA:NN format.
AA:NN	The Autonomous System (AS) number of the community, in AA:NN format. AS numbers are assigned to the regional registries by the IANA (www.iana.org) and can be obtained from the registry in your region. AA and NN are both integers from 1 to 65535. AA is the AS number; NN is a value chosen by the ASN administrator.
local-AS	The community of routes that must not be advertised to external BGP peers (this includes peers in other members' Autonomous Systems inside a BGP confederation).
internet	The community of routes that can be advertised to all BGP peers.
no-advertise	The community of routes that must not be advertised to other BGP peers.
no-export	The community of routes that must not be advertised outside a BGP confederation boundary (a standalone Autonomous System that is not part of a confederation should be considered a confederation itself).
none	The device removes the community attribute from matching update messages.
additive	The device adds the specified community value to the update message's community attribute, instead of replacing the existing attribute. By default this parameter is not included, so the device replaces the existing attribute.

Mode Route-map mode

Usage This command is valid for BGP update messages only.

Examples To use entry 3 of the route map called `rmap1` to put matching routes into the no-advertise community, use the commands:

```
awplus# configure terminal
awplus(config)# route-map rmap1 permit 3
awplus(config-route-map)# set community no-advertise
```

To use entry 3 of the route map called `rmap1` to put matching routes into several communities, use the commands:

```
awplus# configure terminal
awplus(config)# route-map rmap1 permit 3
awplus(config-route-map)# set community 10:01 23:34 12:14 no-export
```

To use entry 3 of the route map called `rmap1` to put matching routes into a single AS community numbered 16384, use the commands:

```
awplus# configure terminal
awplus(config)# route-map rmap1 permit 3
awplus(config-route-map)# set community 16384 no-export
```

Related Commands

- `match community`
- `route-map`
- `set aggregator`
- `set comm-list delete`
- `set extcommunity`
- `show route-map`

set dampening

Use this command to add a route flap dampening set clause to a route map entry.

Also use the route map by specifying it in the command `bgp dampening routemap` command.

When a route matches the route map entry, the device enables route flap dampening for that route. If the set clause includes dampening parameter values, the device uses those values when dampening the matching route.

Use the `no` parameter to remove the set clause. This disables dampening on matching routes.

Syntax

```
set dampening

set dampening [<reachtime>]

set dampening <reachtime> [<reuse> <suppress> <maxsuppress>]
[<unreachtime>]

no set dampening

no set dampening [<reachtime>]

no set dampening <reachtime> [<reuse> <suppress> <maxsuppress>]
[<unreachtime>]
```

Parameter	Description
<reachtime>	<1-45> The time it takes, in minutes, for the route's instability penalty to halve if the route remains stable. The instability penalty is called the Figure of Merit (FoM). For example, if reachtime is 15, the FoM of a stable route halves over a 15 minute period, quarters over a 30 minute period, and so on. The default is 15 minutes.
<reuse>	<1-20000> The value that the instability penalty (FoM) must reach for the device to use a suppressed route again. Once a route is suppressed, it remains suppressed until its FoM falls below this threshold. Reuse must not exceed suppress. The default is 750.
<suppress>	<1-20000> The instability penalty (FoM) at which the route is suppressed. Suppress must be greater than or equal to reuse. If suppress is less than 1000, a route is suppressed when it becomes unreachable for the first time. The default is 2000.
<maxsuppress>	<1-255> A number that is multiplied by reachtime to give the maximum time in minutes for which a suppressed route must remain stable in order to become unsuppressed. The lowest maxsuppress value of 1 gives a maximum suppression time of 1 x reachtime, and the highest maxsuppress value of 255 gives a maximum suppression time of 255 x reachtime. For example, if reachtime is 15 and maxsuppress is 4, the route is unsuppressed after 60 minutes of stability even if its FoM still exceeds reuse. The default is 4.

Parameter(Continu	Description(Continued)
<unreachtime>	<1-45> The time it takes, in minutes, for the route's instability penalty to halve if the route remains unstable. The default value is 15 minutes.

Mode Route-map mode

Usage The suppress value must be greater than or equal to the reuse value.
Set the unreachability half-life time to be equal to, or greater than, reachability half-life time. The suppress-limit value must be greater than or equal to the reuse limit value.
This command is valid for BGP routes only.

Example To use entry 24 of the route map called R1 to enable dampening of matching routes and set the dampening parameters, use the commands:

```
awplus# configure terminal
awplus(config)# route-map R1 permit 24
awplus(config-route-map)# set dampening 20 333 534 30
```

Related Commands [bgp dampening](#)
[route-map](#)
[show route-map](#)

set extcommunity

Use this command to add an extended community set clause to a route map entry. A route map entry can have a route target extended community set clause, a site-of-origin extended community set clause, or both.

When a BGP update message matches the route map entry, the device sets the update's extended community attribute to the specified value or values.

Use the no parameter to remove the set clause.

Syntax `set extcommunity {rt|soo} <extcomm-number>`
`no set extcommunity {rt|soo} [<extcomm-number>]`

Parameter	Description
rt	Configure a route target extended community. This consists of routers that will receive matching routes.
soo	Configure a site-of-origin extended community. This consists of routers that will inject matching routes into BGP.
<extcomm-number>	The extended community number, in the format AA:NN or IPADD:N

Mode Route-map mode

Usage This command is valid for BGP update messages only.

Examples To use entry 3 of the route map called rmap1 to set the route target extended community attribute to 06:01, use the commands:

```
awplus# configure terminal
awplus(config)# route-map rmap1 permit 3
awplus(config-route-map)# set extcommunity rt 06:01
```

To instead specify the extended community number in dotted decimal notation, use the command:

```
awplus# configure terminal
awplus(config)# route-map rmap1 permit 3
awplus(config-route-map)# set extcommunity rt 0.0.0.6:01
```

To use entry 3 of the route map called rmap1 to set the site-of-origin extended community attribute to 06:01, use the commands:

```
awplus# configure terminal
awplus(config)# route-map rmap1 permit 3
awplus(config-route-map)# set extcommunity soo 06:01
```

To instead specify the extended community number in dotted decimal notation, use the command:

```
awplus# configure terminal
awplus(config)# route-map rmap1 permit 3
awplus(config-route-map)# set extcommunity soo 0.0.0.6:01
```

Related Commands

- match community
- route-map
- set comm-list delete
- set community
- show route-map

set ip next-hop (route map)

Use this command to add a next-hop set clause to a route map entry.

When a route or BGP update message matches the route map entry, the device sets the route's next hop to the specified IP address.

Use the no parameter to remove the set clause.

Syntax

```
set ip next-hop <ip-address>
no set ip next-hop [<ip-address>]
```

Parameter	Description
<ip-address>	The IP address of the next hop, entered in the form A.B.C.D.

Mode Route-map mode

Usage Use this command to set the next-hop IP address to the routes.

This command is valid for BGP update messages, and OSPF and RIP routes.

Examples To use entry 3 of the route map called mymap to give matching routes a next hop of 10.10.0.67, use the commands:

```
awplus# configure terminal
awplus(config)# route-map mymap permit 3
awplus(config-route-map)# set ip next-hop 10.10.0.67
```

Related Commands

- match ip next-hop
- route-map
- show route-map

set ipv6 next-hop

Use this command to set a next hop-address.

Use the no parameter with this command to delete an entry.

Syntax `set ipv6 next-hop {<ipv6-addr-global>|local <ipv6-addr>}`
`no set ipv6 next-hop [<ipv6-addr-global>|local [<ipv6-addr>]]`

Parameter	Description
<code><ipv6-addr-global></code>	The IPv6 global address of next hop. The IPv6 address uses the format X:X::X:X.
<code>local</code>	Specifies that the address is local.
<code><ipv6-addr></code>	The IPv6 local address of next hop. The IPv6 address uses the format X:X::X:X.

Mode Route-map mode

Usage Use this command to set the next-hop IPv6 address to the routes.
This command is valid only for BGP.

Examples

```
awplus# configure terminal
awplus(config)# route-map rmap1 permit 3
awplus(config-route-map)# set ipv6 next-hop local
                        fe80::203:47ff:fe97:66dc
awplus(config-route-map)# no set ipv6 next-hop
```

set local-preference

This command changes the default local preference value.

The local preference indicates the BGP local preference path attribute when there are multiple paths to the same destination. The path with the higher preference is chosen. Use this command to define the preference of a particular path. The preference is sent to all routers and access servers in the local autonomous system.

The no form reverts to the default setting.

Syntax `set local-preference <pref-value>`
`no set local-preference [<pref-value>]`

Parameter	Description
<pref-value>	<0-4294967295> Configure local preference value. The default local preference value is 100.

Mode Router mode

Examples

```
awplus# configure terminal
awplus(config)# route-map rmap1 permit 3
awplus(config-route-map)# set local-preference 2345555
```

```
awplus# configure terminal
awplus(config)# router bgp 100
awplus(config-route-map)# no set local-preference
```

Related Commands For related Route Map commands:

[route-map](#)
[show route-map](#)

For related BGP commands:

[bgp default local-preference](#)
[neighbor route-map](#)

set metric

Use this command to add a metric set clause to a route map entry.

When a route or BGP update message matches the route map entry, the device takes one of the following actions:

- changes the metric (or for BGP, the MED attribute value) to the specified value, or
- adds or subtracts the specified value from the metric or MED attribute, if you specify **+** or **-** before the value (for example, to increase the metric by 2, enter **+2**)

Use the **no** parameter to remove the set clause.

Syntax `set metric {+<metric-value>|-<metric-value>|<metric-value>}`
`no set metric [+<metric-value>|-<metric-value> |<metric-value>]`

Parameter	Description
+	Increase the metric or MED attribute by the specified amount.
-	Decrease the metric or MED attribute by the specified amount.
<metric-value>	<0-4294967295> The new metric or MED attribute value, or the amount by which to increase or decrease the existing value.

Mode Route-map mode

Usage For BGP, if you want the device to compare MED values in update messages from peers in different ASes, also enter the command `bgp always-compare-med`. The device always compares MED values in update messages from peers in the same AS.

This command is valid for BGP update messages, and OSPF and RIP routes.

Examples To use entry 3 of the route map called `rmap1` to give matching routes a metric of 600, use the commands:

```
awplus# configure terminal
awplus(config)# route-map rmap1 permit 3
awplus(config-route-map)# set metric 600
```

To use entry 3 of the route map called `rmap1` to increase the metric of matching routes by 2, use the commands:

```
awplus# configure terminal
awplus(config)# route-map rmap1 permit 3
awplus(config-route-map)# set metric +2
```

Related Commands `match metric`
`route-map`
`show route-maps`

set metric-type

Use this command to add a metric-type set clause to a route map entry.

When a route matches the route map entry, the device sets its route type to the specified value.

Use the no parameter to remove the set clause.

Syntax `set metric-type {type-1|type-2}`
`no set metric-type [type-1|type-2]`

Parameter	Description
type-1	Redistribute matching routes into OSPF as type-1 external routes.
type-2	Redistribute matching routes into OSPF as type-2 external routes.

Mode Route-map mode

Usage This command is valid for OSPF routes only.

Examples To use entry 3 of the route map called `rmap1` to redistribute matching routes into OSPF as type-1 external routes, use the commands:

```
awplus# configure terminal
awplus(config)# route-map rmap1 permit 3
awplus(config-route-map)# set metric-type 1
```

Related Commands [default-information originate \(OSPF\)](#)
[redistribute \(OSPF\)](#)
[match route-type](#)
[route-map](#)
[show route-map](#)

set origin

Use this command to add an origin set clause to a route map entry.

When a BGP update message matches the route map entry, the device sets its origin attribute to the specified value.

Use the no parameter to remove the set clause.

Syntax `set origin {egp|igp|incomplete}`
`no set origin [egp|igp|incomplete]`

Parameter	Description
egp	Learned from an exterior gateway protocol
igp	Learned from a local interior gateway protocol
incomplete	Of unknown heritage, for example a static route

Mode Route-map mode

Usage This command is valid for BGP update messages only.

Examples To use entry 3 of the route map called `rmap1` to give matching update messages an origin of `egp`, use the commands:

```
awplus# configure terminal
awplus(config)# route-map rmap1 permit 3
awplus(config-route-map)# set origin egp
```

Related Commands `match origin`
`route-map`
`show route-map`

set originator-id

Use this command to add an originator ID set clause to a route map entry.

The originator ID is the router ID of the IBGP peer that first learned this route, either via an EBGP peer or by some other means such as importing it.

When a BGP update message matches the route map entry, the device sets its originator ID attribute to the specified value.

Use the no parameter to remove the set clause.

Syntax `set originator-id <ip-address>`
`no set originator-id [<ip-address>]`

Parameter	Description
<code><ip-address></code>	The IP address of the originator, entered in the form A.B.C.D.

Mode Route-map mode

Usage This command is valid for BGP update messages only.

Examples To use entry 3 of the route map called `rmap1` to give matching update messages an originator ID of 1.1.1.1, use the commands:

```
awplus# configure terminal
awplus(config)# route-map rmap1 permit 3
awplus(config-route-map)# set originator-id 1.1.1.1
```

Related Commands `route-map`
 `show route-map`

set tag

Use this command to add a tag set clause to a route map entry.

When a route matches the route map entry, the device sets its tag to the specified value when it redistributes the route into OSPF.

Use the no parameter to remove the set clause.

Syntax `set tag <tag-value>`
`no set tag [<tag-value>]`

Parameter	Description
<code><tag-value></code>	<code><0-4294967295></code> Value to tag matching routes with.

Mode Route-map mode

Usage This command is valid only when redistributing routes into OSPF.

Examples To use entry 3 of the route map called `rmap1` to tag matching routes with the number 6, use the commands:

```
awplus# configure terminal
awplus(config)# route-map rmap1 permit 3
awplus(config-route-map)# set tag 6
```

Related Commands `default-information originate (OSPF)`
`redistribute (OSPF)`
`match tag`
`route-map`
`show route-map`

set weight

Use this command to add a weight set clause to a route map entry.

The weight value assists in best path selection of BGP routes. It is stored with the route in the BGP routing table, but is not advertised to peers. When there are multiple routes with a common destination, the device uses the route with the highest weight value.

When a route matches the route map entry, the device sets its weight to the specified value.

Use the no parameter to remove the set clause.

Syntax `set weight <weight>`
`no set weight [<weight>]`

Parameter	Description
<weight>	<0-4294967295> The weight value.

Mode Route-map mode

Usage This command is valid for BGP routes only.

Examples To use entry 3 of the route map called `rmap1` to give matching routes a weight of 60, use the commands:

```
awplus# configure terminal
awplus(config)# route-map rmap1 permit 3
awplus(config-route-map)# set weight 60
```

Related Commands `route-map`
 `show route-map`

show route-map

Use this command to display information about one or all route maps.

Syntax `show route-map <map-name>`

Parameter	Description
<code><map-name></code>	A name to identify the route map

Mode Privileged Exec mode

Examples To display information about the route-map named `example-map`, use the command:

```
awplus# show route-map example-map
```

Output Figure 41-1: Example output from the show route-map command

```
route-map example-map, permit, sequence 1
  Match clauses:
    ip address prefix-list example-pref
  Set clauses:
    metric 100
route-map example-map, permit, sequence 200
  Match clauses:
  Set clauses:
```

Related Commands `route-map`

Part 4: Multicast Applications



- Chapter 42 IGMP Snooping Introduction and Configuration
- Chapter 43 IGMP Multicast Commands
- Chapter 44 Common Multicast Commands
- Chapter 45 PIM-SM Configuration
- Chapter 46 PIM-SM Commands
- Chapter 47 PIM-DM Configuration
- Chapter 48 PIM-DM Commands
- Chapter 49 MLD Snooping Commands

Chapter 42: IGMP Snooping Introduction and Configuration



Introduction.....	42.2
Configuring IGMP snooping.....	42.3
Introduction to Query Solicitation.....	42.4
How Query Solicitation Works.....	42.4
Query Solicitation Operation.....	42.5
Speeding up IGMP convergence in a non-looped topology	42.6
Enabling Query Solicitation on multiple switches in a looped topology	42.7

Introduction


This chapter provides steps to configure Internet Group Management Protocol (IGMP) snooping and an introduction to the Query Solicitation feature when used with IGMP snooping. To see details on the commands used in this example, or to see the outputs of the validation commands, refer to [Chapter 43, IGMP Multicast Commands](#).

Without IGMP snooping, Layer-2 switches handle IP multicast traffic in the same manner as broadcast traffic, and forward multicast frames received on one port to all other ports in the same VLAN. IGMP Snooping allows switches to monitor network traffic, and determine hosts to receive multicast traffic, by looking into IGMP packets to learn which attached hosts need to receive which multicast groups.

This example describes the configuration on an Allied Telesis managed Layer 3 Switch (switch 1). The interface, port1.0.12, is configured as a multicast router port. Host A and Host B are both members of the same multicast group.

To enable IGMP Snooping on an interface:

- Enable IGMP Snooping globally, if necessary.
- Statically configure ports that are connected to routers if necessary.
- By default, IGMP report suppression is enabled on the switch.



As a result of this configuration:

- Membership reports are generated by hosts. The IGMP Snooping switch will forward the membership reports to its router port. Queries received by the IGMP Snooping switch from the IGMP Querier on port1.0.12 are forwarded by the IGMP Snooping switch.
- Because Host A and Host B are members of the same multicast group, the switch does not notify the IP IGMP routing device (IGMP Querier) when Host A leaves the group, because the group still has another member Host B remaining. When Host B also leaves the group, the switch forwards the leave message to the IP IGMP Querier.
- The addition of a static mrouter port is only required when there is no upstream IGMP querier or an upstream router does not send topology discovery or maintenance messages (like IGMP General Queries or OSPF Hello packets).
- In this example, the configuration of a static mrouter port on port1.0.12 is provided to illustrate the `ip igmp snooping mrouter` command. However, this command would probably not be necessary, since the switch should dynamically set port1.0.12 to be an mrouter port as it receives IGMP Queries arriving from the IGMP Querier attached to port1.0.12.

- In this example, it is not necessary to explicitly configure the switch to work with IGMPv2 or IGMPv3. When the IGMP version is not configured then the switch will work with both versions of IGMP.

Configuring IGMP snooping

In this example when configuring Switch 1, the ports are all part of the same VLAN and IGMP snooping is enabled. This example does not describe how to add the switch ports to a VLAN.

Step 1: Enter the configure mode.

Use the command:

```
awplus# configure terminal
```

Step 2: Enable IGMP snooping.

IGMP snooping is enabled by default. Use the following command only if you have previously disabled it:

```
awplus(config)# ip igmp snooping
```

Step 3: Specify the interface you are configuring.

Specify the interface (vlan1) you are configuring, and enter the Interface mode. Use the command:

```
awplus(config)# interface vlan1
```

Step 4: Configure the multicast router port.

Configure port1.0.12 as a multicast router port to the IGMP Querier. Use the command:

```
awplus(config-if)# ip igmp snooping mrouter interface  
port1.0.12
```

Step 5: Validate the configuration.

Use the following commands to validate the configuration:

```
awplus# show ip igmp interface vlan1
```

```
awplus# show ip igmp groups
```

```
awplus# show ip igmp snooping mrouter vlan1
```

Commands Used

Use the following links to access command descriptions:

- [ip igmp snooping](#)
- [ip igmp snooping mrouter](#)
- [show ip igmp groups](#)
- [show ip igmp interface](#)
- [show ip igmp snooping mrouter](#)

Introduction to Query Solicitation

Query Solicitation minimizes the loss of multicast data after a topology change on networks that use EPSR or spanning tree (STP, RSTP, or MSTP) for loop protection. Without Query Solicitation, when the underlying link layer topology changes, multicast data flow can stop for up to several minutes, depending on which port goes down and how much of the IGMP query interval remained at the time of the topology change. Query Solicitation greatly reduces this disruption.

Query Solicitation operates without configuration in AlliedWare Plus switches running STP, RSTP, MSTP or EPSR. However, you may find it useful to manually enable Query Solicitation in loop-free networks running IGMP (see [Speeding up IGMP convergence in a non-looped topology](#)) and networks where not all switches support Query Solicitation (see [Enabling Query Solicitation on multiple switches in a looped topology](#)).

How Query Solicitation Works

Query Solicitation monitors STP, RSTP, MSTP and EPSR messages for topology changes. When it detects a change, it generates a special IGMP Leave message called a Query Solicit. The switch floods the Query Solicit message to all ports in every VLAN that Query Solicitation is enabled on. When the Querier receives the Query Solicit message, it sends out a General Query and waits for clients to respond with Membership Reports. These Reports update the snooping information throughout the network.

Query Solicit messages have a group address of 0.0.0.0.

Query Solicitation works by default (without you enabling it) on all VLANs on the root bridge in an STP instance and on all data VLANs on the master node in an EPSR instance. By default, the root bridge or master node always sends a Query Solicit message when any of the following events occur:

- an STP BPDU packet with the Topology Change (TC) flag arrives at the root bridge
- an STP port on a switch goes from a Discarding to Forwarding state
- the FDB gets flushed by EPSR

If necessary, you can make clients respond more quickly to the General Query by tuning the IGMP timers, especially the maximum response time advertised in IGMP queries using the [ip igmp query-max-response-time](#) command.

Query Solicitation Operation

When IGMP snooping is enabled and EPSR or Spanning Tree changes the underlying link layer topology, this can interrupt multicast data flow for a significant length of time. This is because there is no way for switches in a network with interested clients to know where the traffic is available, due to the change in network topology. This change in network topology may take up to two IGMP Query intervals from the IGMP Querier, until the switches will know where to forward membership reports received by client hosts. During this time, those hosts will not receive multicast traffic.

Query solicitation prevents this by monitoring for any topology changes. When it detects a change, it generates a special IGMP Leave message known as a Query Solicit, and floods the Query Solicit message to all ports in every VLAN that query solicitation is enabled on. When the IGMP Querier receives the message, it responds by sending a General Query, which all IGMP listeners respond to. This refreshes snooped group membership information in the network.

Query solicitation reduces downtime to a negligible amount by triggering on topology changes. The generation of query solicitation messages in the network causes the IGMP Querier to send an IGMP Query immediately following a topology change resulting in the switches knowing where to look for the traffic and thus sending reports to the correct switch upstream, and thus allow the multicast data traffic to be recovered instantly.

Query solicitation functions by default (without you enabling it) on all VLANs on the root bridge in an STP instance and on all data VLANs on the master node in an EPSR instance. By default, the root bridge or master node always sends a Query Solicit message when the topology changes.

If you have multiple STP or EPSR instances, query solicitation only sends Query Solicit messages on VLANs in the instance that experienced a topology change.

In switches other than the STP root bridge or EPSR master node, query solicitation is disabled by default, but you can enable it by using the `ip igmp snooping tcn query solicit` command

If you enable query solicitation on a switch other than the STP root bridge or EPSR master node, both that switch and the root or master send a Query Solicit message.

Once the Querier receives the Query Solicit message, it sends out a General Query and waits for responses, which update the snooping information throughout the network.


The `ip igmp query-holdtime` command can be configured on the IGMP Querier. This command introduces a brief delay between when the IGMP Querier receives the query solicit, and when it sends out the general query. Although this slightly reduces the speed with which the network recovers from the topology change, it does guard against a DoS (Denial of Service) attack. Without this delay, a malign host sending a stream of query solicits could cause the IGMP Querier to flood the network with IGMP Queries.

To get the network to converge faster, use the `ip igmp query-max-response-time` command and set a low response time value, such as one or two seconds, so that the clients will respond immediately with a report as a response to the IGMP Queries

On switches other than the STP root bridge or the EPSR master node, you can disable query solicitation by using the no version of the `ip igmp snooping tcn query solicit` command.

To see whether query solicitation is on or off, check the Query Solicitation field in output of the `show ip igmp interface` command. You can view running and startup configurations with `show running-config` and `show startup-config` commands to see if Query Solicitation is enabled.

The following figure shows how Query Solicitation works when a port goes down:



Speeding up IGMP convergence in a non-looped topology

For loop-free networks running IGMP, where it may take up to two minutes for multicasting to recover in a non-looped topology after a port comes back up, you can speed up convergence by enabling RSTP using the [spanning-tree mode](#) and [spanning-tree enable](#) commands.

RSTP enables the network to use Query Solicitation by default, and means that multicasting should resume within seconds, not minutes, of the link coming up.


Enabling Query Solicitation on multiple switches in a looped topology

On networks that use spanning tree or EPSR, Query Solicitation is not normally required on switches other than the STP root bridge or EPSR master node. Therefore, it is only enabled by default on the root bridge and the master node.

However, in some networks you may need to turn on Query Solicitation on all switches—for example, if the network includes other switches that do not support Query Solicitation and therefore the STP root bridge may be a switch that does not send Query Solicit messages. To enable Query Solicitation, use the `ip igmp snooping tcn query solicit` command.

Every switch that has Query Solicitation enabled sends a Query Solicit message when it detects a topology change. Enabling it on multiple switches means you get multiple messages, but has no other disadvantage.

The following figure shows a the packet flow for a four-switch network with Query Solicitation enabled on all the switches.



Chapter 43: IGMP Multicast Commands

Introduction.....	43.2
Command List.....	43.2
clear ip igmp.....	43.2
clear ip igmp group.....	43.3
clear ip igmp interface.....	43.4
debug igmp.....	43.5
ip igmp.....	43.6
ip igmp access-group.....	43.7
ip igmp immediate-leave.....	43.8
ip igmp last-member-query-count.....	43.9
ip igmp last-member-query-interval.....	43.10
ip igmp limit.....	43.11
ip igmp mroute-proxy.....	43.13
ip igmp proxy-service.....	43.14
ip igmp querier-timeout.....	43.15
ip igmp query-holdtime.....	43.16
ip igmp query-interval.....	43.18
ip igmp query-max-response-time.....	43.19
ip igmp ra-option (Router Alert).....	43.20
ip igmp robustness-variable.....	43.20
ip igmp snooping.....	43.21
ip igmp snooping fast-leave.....	43.22
ip igmp snooping mrouter.....	43.23
ip igmp snooping querier.....	43.24
ip igmp snooping report-suppression.....	43.25
ip igmp snooping routermode.....	43.26
ip igmp snooping tcn query solicit.....	43.28
ip igmp source-address-check.....	43.29
ip igmp ssm-map enable.....	43.30
ip igmp ssm-map static.....	43.31
ip igmp static-group.....	43.32
ip igmp version.....	43.33
show debugging igmp.....	43.34
show ip igmp groups.....	43.35
show ip igmp interface.....	43.36
show ip igmp snooping mrouter.....	43.38
show ip igmp snooping routermode.....	43.38
show ip igmp snooping statistics.....	43.39

Introduction

The Internet Group Management Protocol (IGMP) module includes the IGMP Proxy service and IGMP Snooping functionality. Some of the following commands may have commonalities and restrictions: these are described under the Usage section for each command.

Command List

This chapter provides an alphabetical reference of configure, clear, and show commands related to Internet Group Management Protocol (IGMP).

clear ip igmp

Use this command to clear all IGMP group membership records on all VLAN interfaces.

Syntax `clear ip igmp`

Mode Privileged Exec

Usage This command applies to VLAN interfaces configured for IGMP, IGMP Snooping, or IGMP Proxy.

Example

```
awplus# clear ip igmp
```

**Validation
Commands** `show ip igmp interface`
`show running-config`

Related Commands `clear ip igmp group`
`clear ip igmp interface`

clear ip igmp group

Use this command to clear IGMP group membership records for a specific group, on all VLAN interfaces, or for a single VLAN interface, or for a range of VLAN interfaces.

Syntax `clear ip igmp *`
`clear ip igmp group <ip-address> <interface>`

Parameter	Description
<code>*</code>	Clears all groups on all VLAN interfaces. This is an alias to the <code>clear ip igmp</code> command.
<code><ip-address></code>	Specifies the group whose membership records will be cleared from all VLAN interfaces, entered in the form A.B.C.D.
<code><interface></code>	Specifies the name of the VLAN interface; all groups learned on this VLAN interface are deleted.

Mode Privileged Exec

Usage This command applies to groups learned by IGMP, IGMP Snooping, or IGMP Proxy. In addition to the group, a VLAN interface can be specified. Specifying this will mean that only entries with the group learnt on the interface will be deleted.

Example

```
awplus# clear ip igmp group *
awplus# clear ip igmp group 224.1.1.1
```

Validation Commands `show ip igmp interface`
`show running-config`

Related Commands `clear ip igmp`
`clear ip igmp interface`

clear ip igmp interface

Use this command to clear IGMP group membership records on a particular VLAN interface.

Syntax `clear ip igmp interface <interface>`

Parameter	Description
<interface>	Specifies the name of the VLAN interface; all groups learned on this VLAN interface are deleted.

Mode Privileged Exec

Usage This command applies to interfaces configured for IGMP, IGMP Snooping, or IGMP Proxy.

Example

```
awplus# clear ip igmp interface vlan1
```

**Validation
Commands** `show ip igmp interface`
`show running-config`

Related Commands `clear ip igmp`
`clear ip igmp group`

debug igmp

Use this command to enable debugging of all IGMP, or a specific component of IGMP.

Use the no parameter with this command to disable all IGMP debugging, or debugging of a specific component of IGMP.

Syntax `debug igmp {all|decode|encode|events|fsm|tib}`
`no debug igmp {all|decode|encode|events|fsm|tib}`

Parameter	Description
all	enable or disable all debug options for IGMP
decode	debug of IGMP packets that have been received
encode	debug of IGMP packets that have been sent
events	debug IGMP events
fsm	debug IGMP Finite State Machine (FSM)
tib	debug IGMP Tree Information Base (TIB)

Modes Privileged Exec and Global Configuration

Usage This command applies to interfaces configured for IGMP, IGMP Snooping, or IGMP Proxy.

Example

```
awplus# configure terminal
awplus(config)# debug igmp all
```

Related Commands [show debugging igmp](#)

ip igmp

Use this command to enable IGMP on an interface. The command configures the device as an IGMP querier.

Use the no parameter with this command to return all IGMP related configuration to the default on this interface.

Syntax ip igmp
 no ip igmp

Mode Interface Configuration for a VLAN interface.

Default Disabled

Usage This command can only be configured on VLAN interfaces, and will have no effect on IGMP Proxy or IGMP Snooping configuration.

Example

```
awplus# configure terminal
awplus(config)# interface vlan1
awplus(config-if)# ip igmp
```

Validation show ip igmp interface
Commands show running-config

ip igmp access-group

This command adds an access control list to a VLAN interface configured for IGMP, IGMP Snooping, or IGMP Proxy. The access control list is used to control and filter the multicast groups learnt on the VLAN interface configured for IGMP, IGMP Snooping, or IGMP Proxy.

The no form disables the access control filtering on the interface.

Syntax `ip igmp access-group {<1-99>|<access-list>}`
`no ip igmp access-group`

Parameter	Description
<1-99>	Standard IP access-list number.
<access-list>	Standard IP access-list name.

Mode Interface Configuration for a VLAN interface.

Default By default there are no access lists configured on any interface.

Usage This command applies to VLAN interfaces configured for IGMP, IGMP Snooping, or IGMP Proxy.

Example In the following example, hosts serviced by VLAN 1 can only join the group 225.2.2.2:

```
awplus# configure terminal
awplus(config)# access-list 1 permit 225.2.2.2 0.0.0.0
awplus(config)# interface vlan1
awplus(config-if)# ip igmp access-group 1
```

ip igmp immediate-leave

In IGMP version 2, use this command to minimize the leave latency of IGMP memberships for specified multicast groups.

To disable this feature, use the `no` parameter with this command.

Syntax `ip igmp immediate-leave group-list <accesslist>`
`no ip igmp immediate-leave`

Parameter	Description
<accesslist>	<1-99> <1300-1999> <word> Standard access-list name or number that defines multicast groups in which the immediate leave feature is enabled.
<1-99>	Access-list number.
<1300-1999>	Access-list number (expanded range).
<word>	Standard IP access-list name.

Mode Interface Configuration for a VLAN interface.

Default Disabled by default. The `no ip igmp immediate-leave` command is used to reset to the default.

Usage This command applies to interfaces configured for IGMP, IGMP Snooping, or IGMP Proxy.

Example The following example shows how to enable the immediate-leave feature on an interface for a specific range of multicast groups

```
awplus# configure terminal
awplus(config)# interface vlan1
awplus(config-if)# ip igmp immediate-leave group-list 34
awplus(config-if)# exit
awplus(config)# access-list 34 permit 225.192.20.0 0.0.0.255
```

Related Commands [ip igmp last-member-query-interval](#)

ip igmp last-member-query-count

Use this command to set the last-member query-count value for an interface.

To return to the default value on an interface, use the no parameter with this command.

Syntax `ip igmp last-member-query-count <2-7>`
`no ip igmp last-member-query-count`

Parameter	Description
<2-7>	last member query count value

Mode Interface Configuration for a VLAN interface.

Default The default last member query count value is 2.

Usage This command applies to interfaces configured for IGMP, IGMP Snooping, or IGMP Proxy.

Example

```
awplus# configure terminal
awplus(config)# interface vlan1
awplus(config-if)# ip igmp last-member-query-count 3
```

Validation `show ip igmp interface`
Commands `show running-config`

ip igmp last-member-query-interval

Use this command to configure the frequency at which the router sends IGMP group-specific host query messages.

To set this frequency to the default value, use the no parameter with this command.

Syntax `ip igmp last-member-query-interval <interval>`
`no ip igmp last-member-query-interval`

Parameter	Description
<interval>	<1000-25500> Frequency (in milliseconds) at which IGMP group-specific host query messages are sent.

Mode Interface Configuration for a VLAN interface.

Default 1000 milliseconds

Usage This command applies to interfaces configured for IGMP, IGMP Snooping, or IGMP Proxy.

Example The following example changes the IGMP group-specific host query message interval to 2 seconds (2000 milliseconds):

```
awplus# configure terminal
awplus(config)# interface vlan1
awplus(config-if)# ip igmp last-member-query-interval 2000
```

**Validation
Commands** `show ip igmp interface`
`show running-config`

Related Commands `ip igmp immediate-leave`

ip igmp limit

Use this command to configure the limit on the maximum number of group membership entries for the device as a whole or for the specified interface (if in interface mode). Once the specified number of group memberships is reached, all further membership reports will be ignored. Optionally, you can configure an access-list to stop certain address(es) from being subject to the limit.

The limit is dependent on the MTU (Maximum Transmission Unit) of the interface, which is the size in bytes of the largest packet that a network protocol can transmit. Typically for an ethernet channel with an MTU of 1500 the igmp group membership limit will be 183 groups, because each igmp group membership is 8 bytes.

Use the no parameter with this command to reset the limit and any specified exception access-list.

Syntax `ip igmp limit <limitvalue> [except <accesslist>]`
`no ip igmp limit`

Parameter	Description
<limitvalue>	<2-512> Maximum number of group membership entries.
<accesslist>	<1-99> <1300-1999> <word> Number or name of the access list that defines multicast groups that are not subject to the configured limit.
<1-99>	Access-list number
<1300-1999>	Access-list number (expanded range)
<word>	Standard IP access-list name

Mode Global Configuration and Interface Configuration for a VLAN interface.

Default The default limit, which is reset by the no ip igmp limit command, is the same as maximum number of group membership entries that can be learned with the ip igmp limit command.
The default limit of group membership entries that can be learned is 512 entries.

Usage This command applies to interfaces configured for IGMP, IGMP Snooping, or IGMP Proxy.

Example The following example configures an IGMP limit of 100 group membership entries across all interfaces on which IGMP is enabled, and excludes group 224.1.1.1 from this limitation:

```
awplus# configure terminal
awplus(config)# access-list 1 permit 224.1.1.1 0.0.0.0
awplus(config)# ip igmp limit 100 except 1
```

The following example configures an IGMP limit of 100 group membership entries on vlan1:

```
awplus# configure terminal
awplus(config)# interface vlan1
awplus(config-if)# ip igmp limit 100
```

ip igmp mroute-proxy

Use this command to enable IGMP mroute proxy on this downstream interface and associate it with the upstream proxy service interface.

Use the no parameter with this command to remove the association with the proxy-service interface.

Syntax `ip igmp mroute-proxy <interface>`
`no ip igmp mroute-proxy`

Mode Interface Configuration for a VLAN interface.

Usage You must also enable the IGMP proxy service on the upstream interface, using the [ip igmp proxy-service](#) command. You can associate one or more downstream mroute proxy interfaces on the device with a single upstream proxy service interface. This downstream mroute proxy interface listens for IGMP reports, and forwards them to the upstream IGMP proxy service interface.

IGMP Proxy does not work with other multicast routing protocols, such as PIM-SM or PIM-DM. This command applies to interfaces configured for IGMP Proxy.

Example The following example configures the `vlan1` interface as the upstream proxy-service interface for the downstream interface, `vlan2`.

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip igmp mroute-proxy vlan1
```

Related Commands [ip igmp proxy-service](#)

ip igmp proxy-service

Use this command to enable the VLAN interface to be the upstream IGMP proxy-service interface for the device. All associated downstream IGMP mroute proxy interfaces on this device will have their memberships consolidated on this proxy service interface, according to IGMP host-side functionality.

Use the `no` parameter with this command to remove the designation of the VLAN interface as an upstream proxy-service interface.

Syntax `ip igmp proxy-service`
`no ip igmp proxy-service`

Mode Interface Configuration for a VLAN interface.

Usage This command is used with the `ip igmp mroute-proxy` command to enable forwarding of IGMP reports to a proxy service interface for all forwarding entries for this interface. You must also enable the downstream IGMP mroute proxy interfaces on this device using the command `ip igmp mroute-proxy`.

IGMP Proxy does not work with other multicast routing protocols, such as PIM-SM or PIM-DM.

Example The following example designates the `vlan1` interface as the upstream proxy-service interface.

```
awplus# configure terminal
awplus(config)# interface vlan1
awplus(config-if)# ip igmp proxy-service
```

Related Commands `ip igmp mroute-proxy`

ip igmp querier-timeout

Use this command to configure the timeout period before the device takes over as the querier for the VLAN interface after the previous querier has stopped querying.

To restore the default value, use the no parameter with this command.

Syntax `ip igmp querier-timeout <timeout>`
`no ip igmp querier-timeout`

Parameter	Description
<timeout>	IGMP previous querier timeout interval value in the range <1-65535>. Number of seconds that the device waits after the previous querier has stopped querying before it takes over as the querier.

Mode Interface Configuration for a VLAN interface.

Default 255 seconds

Usage This command applies to VLAN interfaces configured for IGMP. The timeout value should not be less than the current active querier's general query interval.

Example The following example configures the device to wait 130 seconds from the time it received the last query before it takes over as the querier for the interface:

```
awplus# configure terminal
awplus(config)# interface vlan20
awplus(config-if)# ip igmp querier-timeout 130
```

Validation Commands `show ip igmp interface`
`show running-config`

Related Commands `ip igmp query-interval`

ip igmp query-holdtime

This command sets the time that an IGMP Querier waits after receiving a query solicitation before it sends an IGMP Query. IGMP General Query messages will not be sent during the hold time interval.

To return to the default query hold time period, use the no parameter with this command.

Syntax `ip igmp query-holdtime <interval>`
`no ip igmp query-holdtime`

Parameter	Description
<interval>	Query interval value (in milliseconds) in the range <100-5000>. Period (in milliseconds) of the delay between receipt of the query solicitation and the sending of the IGMP Query by the IGMP Querier.

Mode Interface Configuration for a VLAN interface.

Default By default the delay before sending IGMP General Query messages is 500 milliseconds.

Usage Use this command to configure a value for the IGMP query hold time in the current network. IGMP Queries can be generated after receiving Query Solicitation (QS) packets and there is a possibility of a DoS (Denial of Service) attack if a stream of Query Solicitation (QS) packets are sent to the IGMP Querier, eliciting a rapid stream of IGMP Queries. This command applies to interfaces on which the switch is acting as an IGMP Querier.

Use the `ip igmp query-interval` command when a delay for IGMP general query messages is required and IGMP general query messages are required. The `ip igmp query-holdtime` command stops IGMP query messages during the configured holdtime interval, so the rate of IGMP Queries that can be sent out of an interface can be restricted.

See [“Introduction to Query Solicitation” on page 42.4](#) for introductory information about the Query Solicitation feature.

Note: This command will function on your switch in the stand alone mode. but is not supported when the device forms part of a VCS Stack.

Example To set the IGMP query holdtime to 900 ms for `vlan20`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface vlan20
awplus(config-if)# ip igmp query-holdtime 900
```

To reset the IGMP query holdtime to the default (500 ms) for `vlan10`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface vlan10
awplus(config-if)# no ip igmp query-holdtime
```


Validation show ip igmp interface
Commands show running-config

Related Commands ip igmp query-interval
ip igmp snooping tcn query solicit

ip igmp query-interval

Use this command to configure the period for sending IGMP General Query messages. The IGMP query interval specifies the time between IGMP General Query messages being sent.

Note: IGMP query interval must be greater than IGMP query maximum response time.

To return to the default query interval period, use the no parameter with this command.

Syntax ip igmp query-interval <interval>
no ip igmp query-interval

Parameter	Description
<interval>	Query interval value in the range <2-18000>. Period (in seconds) at which IGMP host query messages are sent.

Mode Interface Configuration for a VLAN interface.

Default The default IGMP query interval is 125 seconds.

Usage This command applies to interfaces configured for IGMP. Note that the IGMP query interval is automatically set to a greater value than the IGMP query max response time.

For example, if you set the IGMP query max response time to 2 seconds using the [ip igmp query-max-response-time](#) command, and the IGMP query interval is currently less than 3 seconds, then the IGMP query interval period will be automatically reconfigured to be 3 seconds, so it is greater than the IGMP query maximum response time.

Use the ip igmp query-interval command when a non-default interval for IGMP General Query messages is required.

The [ip igmp query-holdtime](#) command can occasionally delay the sending of IGMP Queries.

Example The following example changes the period between IGMP host-query messages to 3 minutes (180 seconds):

```
awplus# configure terminal
awplus(config)# interface vlan20
awplus(config-if)# ip igmp query-interval 180
```

The following example resets the period between sending IGMP host-query messages to the default (125 seconds):

```
awplus# configure terminal
awplus(config)# interface vlan20
awplus(config-if)# no ip igmp query-interval
```

**Validation
Commands** show ip igmp interface
show running-config

Related Commands [ip igmp query-holdtime](#)
[ip igmp query-max-response-time](#)

ip igmp query-max-response-time

Use this command to configure the maximum response time advertised in IGMP Queries.

Note: The IGMP query maximum response time must be less than the IGMP query interval.

To restore the default value, use the no parameter with this command.

Syntax `ip igmp query-max-response-time <responsetime>`
`no ip igmp query-max-response-time`

Parameter	Description
<responsetime>	Response time value in the range <1-3180> Maximum response time (in seconds) advertised in IGMP queries.

Mode Interface Configuration for a VLAN interface.

Default The default IGMP query maximum response time is 10 seconds.

Usage This command applies to interfaces configured for IGMP. Note that the IGMP query interval is automatically set to a greater value than the IGMP query maximum response time.

For example, if you set the IGMP query interval to 3 seconds using the [ip igmp query-interval](#) command, and the current IGMP query interval is less than 3 seconds, then the IGMP query maximum response time will be automatically reconfigured to be 2 seconds, so it is less than the IGMP query interval time.

To get the network to converge faster, use the `ip igmp query-max-response-time` command and set a low response time value, such as one or two seconds, so that the clients will respond immediately with a report as a response to the IGMP Queries

Example The following example configures a maximum response time of 8 seconds:

```
awplus# configure terminal
awplus(config)# interface vlan1
awplus(config-if)# ip igmp query-max-response-time 8
```

The following example restores the default maximum response time of 10 seconds:

```
awplus# configure terminal
awplus(config)# interface vlan1
awplus(config-if)# no ip igmp query-max-response-time
```

Validation Commands [show ip igmp interface](#)
[show running-config](#)

Related Commands [ip igmp query-interval](#)

ip igmp ra-option (Router Alert)

Use this command to enable strict Router Alert (RA) option validation. With strict Router Alert (RA) option enabled, IGMP packets without RA options are ignored.

Use the `no ip igmp ra-option` command to disable strict Router Alert (RA) option validation.

Syntax `ip igmp ra-option`
`no ip igmp ra-option`

Mode Interface Configuration for a VLAN interface.

Default The default state of Router Alert (RA) validation is unset.

Usage This command applies to interfaces configured for IGMP, and IGMP Snooping.

Example

```
awplus# configure terminal
awplus(config)# interface vlan20
awplus(config-if)# ip igmp ra-option
```

ip igmp robustness-variable

Use this command to change the robustness variable value on a VLAN interface.

To return to the default value on an interface, use the `no` parameter with this command.

Syntax `ip igmp robustness-variable <2-7>`
`no ip igmp robustness-variable`

Mode Interface Configuration for a VLAN interface.

Default The default robustness variable value is 2.

Usage This command applies to interfaces configured for IGMP, and IGMP Snooping.

Example

```
awplus# configure terminal
awplus(config)# interface vlan20
awplus(config-if)# ip igmp robustness-variable 3
```

**Validation
Commands** `show ip igmp interface`
`show running-config`

ip igmp snooping

Use this command to enable IGMP Snooping. When this command is used in the Global Configuration mode, IGMP Snooping is enabled at the switch level. When this command is used in Interface Configuration mode, IGMP Snooping is enabled for the specified VLANs.

Use the no parameter with this command to globally disable IGMP Snooping, or for the specified interface.

Syntax ip igmp snooping
 no ip igmp snooping

Mode Global Configuration and Interface Configuration for a VLAN interface.

Default By default, IGMP Snooping is enabled both globally and on all VLANs.

Usage For IGMP snooping to operate on particular VLAN interfaces, it must be enabled both globally by using this command in Global Configuration mode, and on individual VLAN interfaces by using this command in Interface Configuration mode. (Both are enabled by default.)

Both IGMP snooping and MLD snooping must be enabled globally on the switch for IGMP snooping to operate. MLD snooping is also enabled by default. To enable it if it has been disabled, use the [ipv6 mld snooping command on page 49.9](#) in Global Configuration mode.

Examples

```
awplus# configure terminal
awplus(config)# ip igmp snooping
awplus(config)# interface vlan1
awplus(config-if)# ip igmp snooping
```

Related Commands [ipv6 mld snooping](#)
 [show ip igmp interface](#)
 [show running-config](#)

ip igmp snooping fast-leave

Use this command to enable IGMP Snooping fast-leave processing. Fast-leave processing is analogous to immediate-leave processing; the IGMP group-membership entry is removed as soon as an IGMP leave group message is received, without sending out a group-specific query.

Use the no parameter with this command to disable fast-leave processing.

Syntax `ip igmp snooping fast-leave`
 `no ip igmp snooping fast-leave`

Mode Interface Configuration for a VLAN interface.

Default IGMP Snooping fast-leave processing is disabled.

Usage This IGMP Snooping command can only be configured on VLAN interfaces.

Example This example shows how to enable fast-leave processing on a VLAN.

```
awplus# configure terminal
awplus(config)# interface vlan1
awplus(config-if)# ip igmp snooping fast-leave
```

**Validation
Commands** `show ip igmp interface`
 `show running-config`

ip igmp snooping mrouter

Use this command to statically configure the specified port in the VLAN as a multicast router port for IGMP Snooping in that VLAN. This command applies to interfaces configured for IGMP Snooping.

Use the `no` parameter with this command to remove the static configuration of the port as a multicast router port.

Syntax `ip igmp snooping mrouter interface <port>`
`no ip igmp snooping mrouter interface <port>`

Parameter	Description
<port>	The port to display information about. The port may be a switch port (e.g., port1.1.4), a static channel group (e.g., sa3), or an LACP channel group (e.g., po4).

Mode Interface Configuration for a VLAN interface.

Usage This IGMP Snooping command can only be configured on VLAN interfaces.

Example This example shows port1.1.2 statically configured to be a multicast router interface.

```
awplus# configure terminal
awplus(config)# interface vlan1
awplus(config-if)# ip igmp snooping mrouter interface port1.1.2
```

ip igmp snooping querier

Use this command to enable IGMP querier operation on a VLAN when no multicast routing protocol is configured in the VLAN. When enabled, the IGMP Snooping querier sends out periodic IGMP queries for all interfaces on that VLAN. This command applies to interfaces configured for IGMP Snooping.

Use the no parameter with this command to disable IGMP querier configuration.

Syntax `ip igmp snooping querier`
 `no ip igmp snooping querier`

Mode Interface Configuration for a VLAN interface.

Usage This command can only be configured on VLAN interfaces.

The IGMP Snooping querier uses the 0.0.0.0 Source IP address because it only masquerades as a proxy IGMP querier for faster network convergence.

It does not start, or automatically cease, the IGMP Querier operation if it detects query message(s) from a multicast router.

If an IP address is assigned to a VLAN, which has IGMP querier enabled on it, then the IGMP Snooping querier uses the VLAN's IP address as the Source IP Address in IGMP queries.

The IGMP Snooping Querier will not stop sending IGMP Queries if there is another IGMP Snooping Querier in the network with a lower Source IP Address.

Note: Do not enable the IGMP Snooping Querier feature on a L2 switch when there is an operational IGMP Querier in the network.

Example

```
awplus# configure terminal
awplus(config)# interface vlan1
awplus(config-if)# ip igmp snooping querier
```

Validation `show ip igmp interface`
Commands `show running-config`

ip igmp snooping report-suppression

Use this command to enable report suppression for IGMP versions 1 and 2. This command applies to interfaces configured for IGMP Snooping.

Report suppression stops reports being sent to an upstream multicast router port when there are already downstream ports for this group on this interface.

Use the no parameter with this command to disable report suppression.

Syntax ip igmp snooping report-suppression
 no ip igmp snooping report-suppression

Mode Interface Configuration for a VLAN interface.

Default Report suppression does not apply to IGMPv3, and is turned on by default for IGMPv1 and IGMPv2 reports.

Usage This command can only be configured on VLAN interfaces.

Example This example shows how to enable report suppression for IGMPv2 reports.

```
awplus# configure terminal
awplus(config)# interface vlan1
awplus(config-if)# ip igmp version 2
awplus(config-if)# ip igmp snooping report-suppression
```

Validation show ip igmp interface
Commands show running-config

ip igmp snooping routermode

Use this command to set source IP addresses as router multicast addresses, according to the routermode (all multicast addresses, default multicast addresses, specified multicast addresses).

Use the no parameter with this command to reset ip igmp snooping routermode to the default. You can also remove a specified IP address from a custom list of multicast addresses.

Syntax `ip igmp snooping routermode {all|default|ip|multicastrouter|address <ip-address>}`

`no ip igmp snooping routermode [address <ip-address>]`

Parameter	Description
no	Negates ip igmp snooping routermode command and resets to its default
all	All reserved multicast addresses (224.0.0.x). Packets from all possible addresses in range 224.0.0.x are set as routers.
default	Default set of reserved multicast addresses. Packets from 224.0.0.1, 224.0.0.2, 224.0.0.4, 224.0.0.5, 224.0.0.6, 224.0.0.9, 224.0.0.13, 224.0.0.15 and 224.0.0.24 are set as routers.
ip	Custom reserved multicast addresses. Custom IP address in the 224.0.0.x range are set as router multicast addresses using the ip igmp snooping routermode address command.
multicastrouter	DVMRP (224.0.0.4) and PIM (224.0.0.13) multicast addresses are set as routers.
address	Specify the multicast address in the 224.0.0.x range for use after issuing an ip igmp snooping routermode ip command
<ip-address>	IPv4 multicast address (224.0.0.x)

Mode Global Configuration

Default The default routermode is default not all and shows the below reserved multicast addresses:

```
Router mode.....Def
Reserved multicast address
    224.0.0.1
    224.0.0.2
    224.0.0.4
    224.0.0.5
    224.0.0.6
    224.0.0.9
    224.0.0.13
    224.0.0.15
    224.0.0.24
```

Example To set ip igmp snooping routermode for all default reserved addresses enter:.

```
awplus(config)# ip igmp snooping routermode default
```

To remove the multicast address 224.0.0.5 from the custom list of multicast addresses enter:.

```
awplus(config)# no ip igmp snooping routermode address  
224.0.0.5
```

Related commands [show ip igmp snooping routermode](#)

ip igmp snooping tcn query solicit

Use this command to enable IGMP (Internet Group Management Protocol) Snooping TCN (Topology Change Notification) Query Solicitation feature globally on all IGMP interfaces.

Use the no parameter with this command to disable IGMP Snooping TCN Query Solicitation.

Syntax ip igmp snooping tcn query solicit
 no ip igmp snooping tcn query solicit

Mode Global Configuration

Default IGMP Snooping TCN Query Solicitation is disabled by default on the switch, unless the switch is the Master Node in an EPSR ring, or is the Root Bridge in a Spanning Tree.

When the switch is the Master Node in an EPSR ring, or the switch is the Root Bridge in a Spanning Tree, then IGMP Snooping TCN Query Solicitation is enabled by default and cannot be disabled.

Usage Once enabled, if the switch is not an IGMP Querier, on detecting a topology change, the switch generates IGMP Query Solicit messages that are sent to all the ports of the vlan configured for IGMP Snooping on the switch.

On a switch that is not the Master Node in an EPSR ring or the Root Bridge in a Spanning Tree, Query Solicitation can be disabled using the no ip igmp snooping tcn query solicit command after being enabled.

If the switch that detects a topology change is an IGMP Querier then the switch will generate an IGMP Query message.

Note that the no ip igmp snooping tcn query solicit command has no effect on a switch that is the Master Node in an EPSR ring, or a switch that is a Root Bridge in a Spanning Tree, since Query Solicitation cannot be disabled on the Master Node in an EPSR ring or the Root Bridge in a Spanning Tree.

See [“Introduction to Query Solicitation” on page 42.4](#) for introductory information about the Query Solicitation feature.

Note: This command will function on your switch in the stand alone mode, but is not supported when the device forms part of a VCS Stack.

Example This example shows how to enable IGMP Snooping TCN Query Solicitation on a switch:

```
awplus# configure terminal
awplus(config)# ip igmp snooping tcn query solicit
```

This example shows how to disable IGMP Snooping TCN Query Solicitation on a switch:

```
awplus# configure terminal
awplus(config)# no ip igmp snooping tcn query solicit
```

**Validation
Commands** show ip igmp interface
 show running-config

Related Commands ip igmp query-holdtime

ip igmp source-address-check

This command enables the checking of the Source Address for an IGMP Report, which is the default behavior, rejecting any IGMP Reports originating on devices outside of the local subnet.

Use the no form of this command to disable the checking of the Source Address for an IGMP Report, which allows IGMP Reports from devices outside of the local subnet.

Syntax `ip igmp source-address-check`
`no ip igmp source-address-check`

Parameter	Description
no	Negate a command or set its defaults
ip	Internet Protocol (IP)
igmp	Internet Group Management Protocol (IGMP)
source-address-check	Enable or disable report source address checking for IGMP Reports

Mode Interface Configuration for a VLAN interface.

Default Source address checking for IGMP Reports is enabled by default.

Usage This is a security feature, and should be enabled unless IGMP Reports from outside the local subnet are expected, for example, if Multicast VLAN Registration is active in the network.

The no igmp source-address-check command is required to disable the IGMP Report source address checking feature in networks that use Multicast VLAN Registration to allow IGMP Reports from devices outside of the local subnet.

Examples To deny IGMP Reports from outside the current subnet, use the following commands:

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip igmp source-address-check
```

To allow IGMP Reports from outside the current subnet, use the following commands:

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# no ip igmp source-address-check
```

Validation Commands `show ip igmp interface`
`show running-config`

ip igmp ssm-map enable

Use this command to enable Source Specific Mapping (SSM) on the device.

Use the no parameter with this command to disable SSM mapping.

Syntax ip igmp ssm-map enable
 no ip igmp ssm-map enable

Mode Global Configuration

Usage This command applies to VLAN interfaces configured for IGMP.

Example This example shows how to configure SSM mapping on the router.

```
awplus# configure terminal
awplus(config)# ip igmp ssm-map enable
```

Related Commands ip igmp ssm-map static

ip igmp ssm-map static

Use this command to specify the static mode of defining SSM mapping. SSM mapping statically assigns sources to IGMPv1 and IGMPv2 groups to translate such (*,G) groups' memberships to (S,G) memberships for use with PIM-SSM.

Use the no parameter with this command to remove the SSM map association.

Syntax `ip igmp ssm-map static <access-list> <ip-address>`
`no ip igmp ssm-map static <access-list> <ip-address>`

Parameter	Description
<access-list>	<1-99> Access-list number
<1300-1999	Access-list number (expanded range).
<ip-address>	Standard IP access-list name, entered in the form A.B.C.D.

Mode Global Configuration

Usage This command applies to VLAN interfaces configured for IGMP.

Example This example shows how to configure an SSM static mapping for group-address 224.1.1.1.

```
awplus# configure terminal
awplus(config)# ip igmp ssm-map static 1 1.2.3.4
awplus(config)# access-list 1 permit 224.1.1.1 0.0.0.0
```

Related Commands [ip igmp ssm-map enable](#)

ip igmp static-group

Use this command to statically configure group membership entries on an interface. To statically add only a group membership, do not specify any parameters.

Use the no parameter with this command to delete static group membership entries.

Syntax `ip igmp static-group <ip-address> [source {<ip-source-addr>|ssm-map}] [interface <port>]`

`no ip igmp static-group <ip-address> [source {<ip-source-addr>|ssm-map}] [interface <port>]`

Parameter	Description
<code><ip-address></code>	Standard IP Multicast group address, entered in the form A.B.C.D, to be configured as a static group member.
<code>source</code>	Optional.
<code><ip-source-addr></code>	Standard IP source address, entered in the form A.B.C.D, to be configured as a static source from where multicast packets originate.
<code>ssm-map</code>	Mode of defining SSM mapping. SSM mapping statically assigns sources to IGMPv1 and IGMPv2 groups to translate these (*, G) groups' memberships to (S, G) memberships for use with PIM-SSM.
<code>interface</code>	Optional. Use this parameter on VLAN interfaces when static configuration is required for IGMP snooping. If used, static configuration is applied to the port specified in <port>. If not used, static configuration is applied on all ports in the VLAN.
<code><port></code>	The port to display information about. The port may be a switch port (e.g., port1.1.4), a static channel group (e.g., sa3), or an LACP channel group (e.g., po4).

Mode Interface Configuration for a VLAN interface.

Usage This command applies to IGMP operation on a specific interface to statically add group and/or source records; or to IGMP Snooping on a VLAN interface to statically add group and/or source records.

Example The following example show how to statically add group and source records for IGMP:

```
awplus# configure terminal
awplus(config)# interface vlan3
awplus(config-if)# ip igmp static-group 226.1.2.4 source
10.2.3.4
```

ip igmp version

Use this command to set the current IGMP version (IGMP version 1, 2 or 3) on an interface.

To return to the default version, use the no parameter with this command.

Syntax `ip igmp version <1-3>`

`no ip igmp version`

Parameter	Description
<1-3>	IGMP protocol version number

Mode Interface Configuration for a VLAN interface.

Usage This command applies to VLAN interfaces configured for IGMP.

Default The default IGMP protocol version number is 3.

Example

```
awplus# configure terminal
awplus(config)# interface vlan5
awplus(config-if)# ip igmp version 2
```

**Validation
Commands** `show ip igmp interface`

show debugging igmp

Use this command to display the IGMP debugging option set.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show debugging igmp`

Mode Privileged Exec

Usage This is a sample output from the `show debugging igmp` command.

```
awplus#debug igmp all
awplus#show debugging igmp
IGMP Debugging status:
  IGMP Decoder debugging is on
  IGMP Encoder debugging is on
  IGMP Events debugging is on
  IGMP FSM debugging is on
  IGMP Tree-Info-Base (TIB) debugging is on
```

Example

```
awplus# show debugging igmp
```

Related Commands [debug igmp](#)

show ip igmp groups

Use this command to display the multicast groups with receivers directly connected to the router, and learned through IGMP.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip igmp groups [<ip-address>|<interface> detail]`

Parameter	Description
<ip-address>	Address of the multicast group, entered in the form A.B.C.D.
<interface>	Interface name for which to display local information.

Mode Exec and Privileged Exec

Example The following command displays local-membership information for all ports in all interfaces:

```
awplus#show ip igmp groups
IGMP Connected Group Membership
Group Address      Interface      Uptime      Expires      Last Reporter
224.0.1.1          port1.1.1     00:00:09    00:04:17    10.10.0.82
224.0.1.24         port1.1.2     00:00:06    00:04:14    10.10.0.84
224.0.1.40         port1.1.3     00:00:09    00:04:15    10.10.0.91
224.0.1.60         port1.1.3     00:00:05    00:04:15    10.10.0.7
224.100.100.100    port1.1.1     00:00:11    00:04:13    10.10.0.91
228.5.16.8         port1.1.3     00:00:11    00:04:16    10.10.0.91
228.81.16.8        port1.1.7     00:00:05    00:04:15    10.10.0.91
228.249.13.8       port1.1.3     00:00:08    00:04:17    10.10.0.91
235.80.68.83       port1.1.11    00:00:12    00:04:15    10.10.0.40
239.255.255.250    port1.1.3     00:00:12    00:04:15    10.10.0.228
239.255.255.254    port1.1.12    00:00:08    00:04:13    10.10.0.84
```

The following describes significant fields shown in the display above:

Field	Description
Group Address	Address of the multicast group.
Interface	Port through which the group is reachable.
Uptime	The time in weeks, days, hours, minutes, and seconds that this multicast group has been known to the device.
Expires	Time (in hours, minutes, and seconds) until the entry expires.
Last Reporter	Last host to report being a member of the multicast group.

show ip igmp interface

Use this command to display the state of IGMP, IGMP Proxy service, and IGMP Snooping for a specified VLAN, or all VLANs. IGMP is shown as Active or Disabled in the show output.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip igmp interface [<interface>]`

Parameter	Description
<interface>	The name of the VLAN interface.

Mode Exec and Privileged Exec

Example The following command displays the IGMP interface status on all VLANs enabled for IGMP:

```
awplus#show ip igmp interface
Interface vlan1 (Index 4294967295)
IGMP Active, Non-Querier, Version 3 (default)
IGMP querying router is 0.0.0.0
IGMP query interval is 125 seconds
IGMP querier timeout is 255 seconds
IGMP max query response time is 10 seconds
Last member query response interval is 1000 milliseconds
Group Membership interval is 260 seconds
IGMP Snooping is globally enabled
IGMP Snooping is enabled on this interface
IGMP Snooping fast-leave is not enabled
IGMP Snooping querier is not enabled
IGMP Snooping report suppression is enabled
```

The following command displays the IGMP interface status for vlan2:

```
awplus>show ip igmp interface vlan2
Interface vlan2 (Index 5024)
IGMP Disabled, Inactive, Version 3 (default)
IGMP interface has 0 group-record states
IGMP activity: 0 joins, 0 leaves
IGMP robustness variable is 2
IGMP last member query count is 2
IGMP query interval is 125 seconds
IGMP querier timeout is 255 seconds
IGMP max query response time is 10 seconds
Last member query response interval is 1000 milliseconds
Group Membership interval is 260 seconds
Strict IGMPv3 ToS checking is disabled on this interface
IGMP Snooping is globally enabled
IGMP Snooping fast-leave is not enabled
IGMP Snooping querier is not enabled
IGMP Snooping report suppression is enabled
```

The following command displays the IGMP interface status and Query Solicitation for vlan3:

```
awplus#show ip igmp interface vlan3
Interface vlan3 (Index 203)
  IGMP Enabled, Active, Querier, Version 3 (default)
  Internet address is 192.168.9.1
  IGMP interface has 256 group-record states
  IGMP activity: 51840 joins, 0 leaves
  IGMP robustness variable is 2
  IGMP last member query count is 2
  IGMP query interval is 125 seconds
  IGMP query holdtime is 500 milliseconds
  IGMP querier timeout is 250 seconds
  IGMP max query response time is 1 seconds
  Last member query response interval is 1000 milliseconds
  Group Membership interval is 251 seconds
  Strict IGMPv3 ToS checking is disabled on this interface
  IGMP Snooping is globally enabled
  IGMP Snooping query solicitation is globally enabled
    Num. query-solicit packets: 1 sent, 10 recvd
  IGMP Snooping is enabled on this interface
  IGMP Snooping fast-leave is not enabled
  IGMP Snooping querier is not enabled
  IGMP Snooping report suppression is enabled
awplus#
```

*Note: Query Solicitation status information is highlighted in **bold** in the above output.*

*Use the **show ip igmp interface** command to validate Query Solicitation is enabled and to show the number of query-solicit message packets sent and received on a vlan.*

Related Commands

- clear ip igmp
- clear ip igmp group
- clear ip igmp interface
- ip igmp
- ip igmp last-member-query-count
- ip igmp last-member-query-interval
- ip igmp querier-timeout
- ip igmp query-holdtime
- ip igmp query-interval
- ip igmp query-max-response-time
- ip igmp robustness-variable
- ip igmp snooping
- ip igmp snooping fast-leave
- ip igmp snooping querier
- ip igmp snooping report-suppression
- ip igmp snooping tcn query solicit
- ip igmp version

show ip igmp snooping mrouter

Use this command to display the multicast router ports, both static and dynamic, in a VLAN.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip igmp snooping mrouter interface <interface>`

Parameter	Description
<interface>	The name of the VLAN interface.

Mode Exec and Privileged Exec

Example The following command displays the multicast router interfaces in `vlan1`.

```
awplus#show ip igmp snooping mrouter vlan1
VLAN      Interface
1         port1.1.2
1         port1.1.5
```

show ip igmp snooping routermode

Use this command display the current routermode and the list of IP addresses set as router multicast addresses from the `ip igmp snooping routermode` command.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip igmp snooping routermode`

Mode Exec and Privileged Exec

Example To show the routermode and the list of router multicast addresses, use the command:

```
awplus#show ip igmp snooping routermode
Router mode.....Def
Reserved multicast address
    224.0.0.1
    224.0.0.2
    224.0.0.4
    224.0.0.5
    224.0.0.6
    224.0.0.9
    224.0.0.13
    224.0.0.15
    224.0.0.24
```

Related Commands [ip igmp snooping routermode](#)

show ip igmp snooping statistics

Use this command to display IGMP Snooping statistics data.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip igmp snooping statistics interface <interface-range>`

Parameter	Description
<code><interface-range></code>	The name of the VLAN interface or interface range.

Mode Exec and Privileged Exec

Example The following displays IGMP statistical information for `vlan1` and `vlan2`

```
awplus#show ip igmp snooping statistics interface vlan1-vlan2
IGMP Snooping statistics for vlan1
Interface:      port1.1.3
Group:         224.1.1.1
Uptime:        00:00:09
Group mode:    Exclude (Expires: 00:04:10)
Last reporter: 10.4.4.5
Source list is empty
IGMP Snooping statistics for vlan2
Interface:      port1.1.4
Group:         224.1.1.2
Uptime:        00:00:19
Group mode:    Exclude (Expires: 00:05:10)
Last reporter: 10.4.4.6
Source list is empty
```


Chapter 44: Common Multicast Commands



Command List	44.2
clear ip mroute	44.2
clear ip mroute statistics	44.3
debug nsm mcast	44.3
ip mroute	44.4
ip multicast route-limit	44.5
ip multicast-routing	44.6
multicast	44.7
show ip mroute	44.8
show ip mvif	44.10
show ip rpf	44.11

Command List

This chapter provides an alphabetical reference of multicast commands common to PIM Sparse Mode and PIM Dense Mode. See also [Chapter 43, IGMP Multicast Commands](#), [Chapter 46, PIM-SM Commands](#), [Chapter 48, PIM-DM Commands](#), and [Chapter 49, MLD Snooping Commands](#).

clear ip mroute

Use this command to delete entries from the IP multicast routing table.

Syntax `clear ip mroute [*|<group-addr> [<source-addr>]] [pim sparse-mode]`

Parameter	Description
*	Deletes all multicast routes
<group-addr>	A.B.C.D Group IP address.
<source-addr>	A.B.C.D Source IP address.
pim sparse-mode	Clear specified multicast route(s) for PIM Sparse Mode only.

Mode Privileged Exec mode

Usage When this command is used, the Multicast Routing Information Base (MRIB) clears the multicast route entries in its multicast route table, and removes the entries from the multicast forwarder. The MRIB sends a “clear” message to the multicast protocols. Each multicast protocol has its own “clear” multicast route command. The protocol-specific “clear” command clears multicast routes from PIM Sparse Mode, and also clears the routes from the MRIB.

Example

```
awplus# clear ip mroute 225.1.1.1 192.168.3.3
```

clear ip mroute statistics

Use this command to delete multicast route statistics entries from the IP multicast routing table.

Syntax `clear ip mroute statistics [*|<group-addr> [<source-addr>]]`

Parameter	Description
*	All multicast route entries.
<group-addr>	A.B.C.D Group IP address.
<source-addr>	A.B.C.D Source IP address.

Mode Privileged Exec mode

Example

```
awplus# clear ip mroute statistics 225.1.1.2 192.168.4.4
```

debug nsm mcast

Use this command to debug events in the Multicast Routing Information Base (MRIB).

Syntax `debug nsm mcast
{all|fib-msg|mrt|mtrace|mtrace-detail|register|stats|vif}`

Parameter	Description
all	All IPv4 multicast debugging.
fib-msg	Forwarding Information Base (FIB) messages.
mrt	Multicast routes.
mtrace	Multicast traceroute.
mtrace-detail	Multicast traceroute detailed debugging.
register	Multicast PIM register messages.
stats	Multicast statistics.
vif	Multicast interface.

Mode Privileged Exec and Global Configuration mode

Example

```
awplus# configure terminal
awplus(config)# debug nsm mcast register
```

ip mroute

Use this command to create a multicast static route. Use the `no` form of this command to delete the route.

Multicast static routes are unicast routes which allow multicast and unicast topologies to be independent. These routes are used by multicast routing protocols to perform reverse-path forwarding (RPF) checks.

Syntax `ip mroute <source-addr/mask-length> [bgp|ospf|rip|static] <rpf-addr> [<distance>]`

`no ip mroute <source-addr/mask-length> [bgp|ospf|rip|static]`

Parameter	Description
<code><source-addr/mask-length></code>	A.B.C.D/0-32 Specifies multicast source IP address and mask length.
<code>bgp</code>	BGP unicast routing protocol
<code>ospf</code>	OSPF unicast routing protocol
<code>rip</code>	RIP unicast routing protocol
<code>static</code>	specifies a static route
<code><rpf-addr></code>	A.B.C.D RPF address for the multicast route. The host IP address can be a directly connected system or a remote system. When it is a remote system, a lookup is done from the unicast routing table to find a directly connected system.
<code><distance></code>	The administrative distance. Use this to determine whether the RPF lookup selects the unicast or multicast route. Lower distances have preference. If the multicast static route has the same distance as the other RPF sources, the multicast static route takes precedence. Default is 0. Range is 0-255.

Mode Global Configuration mode

Examples The following example configures the 10.10.3.0 network address with a static multicast route to 192.168.2.2 with an administrative distance of 2:

```
awplus# configure terminal
```

```
awplus(config)# ip mroute 10.10.3.0/24 static 2 192.168.2.2
```

The following example configures all specific sources within a network number to be accessible through 10.10.10.50:

```
awplus# configure terminal
```

```
awplus(config)# ip mroute 192.168.3.0/24 10.10.10.50
```

Validation Commands `show ip rpf`

ip multicast route-limit

Use this command to limit the number of multicast routes that can be added to a multicast routing table.

Use the no parameter with this command to return the limit to the default.

Syntax `ip multicast route-limit <limit> [<threshold>]`
`no ip multicast route-limit`

Parameter	Description
<code><limit></code>	<code><1-2147483647></code> Number of routes.
<code><threshold></code>	<code><1-2147483647></code> Threshold above which to generate a warning message. The mroute warning threshold must not exceed the mroute limit.

Mode Global Configuration mode

Default The default limit and threshold value is 2147483647.

Usage This command limits the number of multicast routes (mroutes) that can be added to a router, and generates an error message when the limit is exceeded. If the threshold parameter is set, a threshold warning message is generated when this threshold is exceeded, and the message continues to occur until the number of mroutes reaches the limit set by the limit argument.

Example

```
awplus# configure terminal
awplus(config)# ip multicast route-limit 34 24
```

ip multicast-routing

Use this command to turn on/off multicast routing on the router; when turned off the device does not perform multicast functions.

Use the `no` parameter with this command to disable multicast routing after enabling it. Note the default stated below.

Syntax `ip multicast-routing`
 `no ip multicast-routing`

Mode Global Configuration mode

Default By default, multicast routing is off.

Usage When the `no` parameter is used with this command, the Multicast Routing Information Base (MRIB) cleans up Multicast Routing Tables (MRT), stops IGMP operation, and stops relaying multicast forwarder events to multicast protocols.

When multicast routing is enabled, the MRIB starts processing any MRT addition/deletion requests, and any multicast forwarding events.

You must enable multicast routing before issuing other multicast commands.

Example

```
awplus# configure terminal
awplus(config)# ip multicast-routing
```

**Validation
Commands** `show running-config`

multicast

Use this command to enable a switch port to route multicast packets that ingress the port.

Use the no form of this command to stop the switch port from routing multicast packets that ingress the port. Note that this does not affect layer 2 forwarding of multicast packets. If you enter no multicast on a port, multicast packets received on that port will not be forwarded to other VLANs, but ports in the same VLANs as the receiving port will still receive the multicast packets.

Syntax multicast
 no multicast

Mode Interface mode

Default By default, all switch ports route multicast packets.

Examples

```
awplus# configure terminal
awplus(config)# interface port1.0.1
awplus(config-if)# multicast
```

```
awplus# configure terminal
awplus(config)# interface port1.0.1
awplus(config-if)# no multicast
```

**Validation
Commands** show running-config

show ip mroute

Use this command to display the contents of the IP multicast routing (mroute) table.

Syntax `show ip mroute [<group-addr>] [<source-addr>] [{dense|sparse}] [{count|summary}]`

Parameter	Description
<code><group-addr></code>	Group IP address.
<code><source-addr></code>	Source IP address.
<code>dense</code>	Display dense multicast routes.
<code>sparse</code>	Display sparse multicast routes.
<code>count</code>	Display the route and packet count from the IP multicast routing (mroute) table.
<code>summary</code>	Display the contents of the IP multicast routing (mroute) table in an abbreviated form.

Mode Exec and Privileged Exec mode

Example

```
awplus# show ip mroute 10.10.3.34 224.1.4.3
```

```
awplus# show ip mroute 10.10.5.24 225.2.2.2 count
```

```
awplus# show ip mroute 10.10.1.34 summary
```

The following is a sample output of this command displaying the IP multicast routing table, with and without specifying the group and source IP address:

```
awplus# show ip mroute
IP Multicast Routing Table
Flags: I - Immediate Stat, T - Timed Stat, F - Forwarder
installed
Timers: Uptime/Stat Expiry
Interface State: Interface (TTL)

(10.10.1.52, 224.0.1.3), uptime 00:00:31, stat expires 00:02:59
Owner PIM-SM, Flags: TF
  Incoming interface: vlan2
  Outgoing interface list:
    vlan3 (1)
```



```
awplus# show ip mroute 10.10.1.52 224.0.1.3

IP Multicast Routing Table
Flags: I - Immediate Stat, T - Timed Stat, F - Forwarder installed
Timers: Uptime/Stat Expiry
Interface State: Interface (TTL)

(10.10.1.52, 224.0.1.3), uptime 00:03:24, stat expires 00:01:28
Owner PIM-SM, Flags: TF
  Incoming interface: vlan2
  Outgoing interface list:
    vlan3 (1)
```

The following is a sample output of this command displaying the packet count from the IP multicast routing table:

```
awplus# show ip mroute count

IP Multicast Statistics
Total 1 routes using 132 bytes memory
Route limit/Route threshold: 2147483647/2147483647
Total NOCACHE/WRONGVIF/WHOLEPKT rcv from fwd: 1/0/0
Total NOCACHE/WRONGVIF/WHOLEPKT sent to clients: 1/0/0
Immediate/Timed stat updates sent to clients: 0/0
Reg ACK rcv/Reg NACK rcv/Reg pkt sent: 0/0/0
Next stats poll: 00:01:10

Forwarding Counts: Pkt count/Byte count, Other Counts: Wrong If
pkts
Fwd msg counts: WRONGVIF/WHOLEPKT rcv
Client msg counts: WRONGVIF/WHOLEPKT/Imm Stat/Timed Stat sent
Reg pkt counts: Reg ACK rcv/Reg NACK rcv/Reg pkt sent

(10.10.1.52, 224.0.1.3), Forwarding: 2/19456, Other: 0
  Fwd msg: 0/0, Client msg: 0/0/0/0, Reg: 0/0/0
```

The following is a sample output for this command displaying the IP multicast routing table in an abbreviated form:

```
awplus# show ip mroute summary

IP Multicast Routing Table
Flags: I - Immediate Stat, T - Timed Stat, F - Forwarder installed
Timers: Uptime/Stat Expiry
Interface State: Interface (TTL)

(10.10.1.52, 224.0.1.3), 00:01:32/00:03:20, PIM-SM, Flags: TF
```

show ip mvif

Use this command to display the contents of the Multicast Routing Information Base (MRIB) VIF table.

Syntax `show ip mvif [<interface>]`

Parameter	Description
<interface>	The interface to display information about.

Mode Exec and Privileged Exec mode

Usage The following are sample outputs of this command displaying the contents for the MRIB VIF table, both with and without the interface parameter specified:

```
awplus#show ip mvif
Interface  Vif  Owner  TTL  Local  Remote  Uptime
          Idx  Module                Address  Address
vlan2      0    PIM-SM    1    192.168.1.53    0.0.0.0    00:04:26
Register   1                1    192.168.1.53    0.0.0.0    00:04:26
vlan3      2    PIM-SM    1    192.168.10.53   0.0.0.0    00:04:25
```

```
awplus# show ip mvif vlan2
Interface  Vif  Owner  TTL  Local  Remote  Uptime
          Idx  Module                Address  Address
vlan2      0    PIM-SM    1    192.168.1.53    0.0.0.0    00:05:17
```

Example

```
awplus# show ip mvif vlan2
```

show ip rpf

Use this command to display Reverse Path Forwarding (RPF) information for the specified source address.

Syntax `show ip rpf <source-addr>`

Parameter	Description
<code><source-addr></code>	A.B.C.D Specifies source IP address

Mode Exec mode and Privileged Exec mode

Examples

```
awplus# show ip rpf 10.10.10.50
```


Chapter 45: PIM-SM Configuration



Introduction.....	45.2
Roles in PIM Sparse Mode.....	45.3
Operation of PIM Sparse Mode.....	45.4

Introduction

PIM Sparse Mode (PIM-SM) provides efficient communication between members of sparsely distributed groups - the type of groups that are most common in wide-area internetworks. It is designed on the principle that several hosts wishing to participate in a multicast conference does not justify flooding the entire internetwork with periodic multicast traffic. PIM-SM is designed to limit multicast traffic so that only those routers interested in receiving traffic for a particular group receive the traffic.

Routers with directly attached or downstream members are required to join a Sparse Mode distribution tree by transmitting explicit join messages. If a router does not become part of the predefined distribution tree, it does not receive multicast traffic addressed to the group. In contrast, dense mode multicast routing protocols assume downstream group membership and continue to forward multicast traffic on downstream links until explicit prune messages are received. The default forwarding action of a sparse mode multicast routing protocol is to block traffic unless it is explicitly requested, while the default action of the dense mode multicast routing protocols is to forward traffic.

PIM-SM employs the concept of a rendezvous point (RP) where receivers “meet” sources. The initiator of each multicast group selects a primary RP and a small ordered set of alternative RPs, known as the RP-list. For each multicast group, there is only a single active RP. Each receiver wishing to join a multicast group contacts its directly attached router, which in turn joins the multicast distribution tree by sending an explicit join message to the group's primary RP. A source uses the RP to announce its presence and to find a path to members that have joined the group. This model requires Sparse Mode routers to maintain some state information (the RP-list) prior to the arrival of data packets. In contrast, Dense Mode multicast routing protocols are data driven, since they do not define any state for a multicast group until the first data packet arrives.

Roles in PIM Sparse Mode

A multicast sender does not need to know the addresses of the members of the group in order to send to them, and the members of the group need not know the address of the sender. Group membership can change at any time. When PIM is enabled on the switch, and before the switch can route multicast traffic, it must establish which of the PIM routers in the network are performing some key roles: *designated router* (DR), *rendezvous point* (RP), and *bootstrap router* (BSR).

Designated router

There must be one PIM designated router (DR) in the subnetwork to which the IP hosts are connected. Any PIM-SM interfaces on the subnetwork elect the designated router with the highest DR priority. If there is more than one router with the same priority, or no priority, they choose the interface with the highest IP address number. The DR performs all the PIM functionality for the subnetwork. If the current DR becomes unavailable, the remaining routers elect a new DR on the interface by DR priority or IP address.

Rendezvous point

Each multicast group must have a rendezvous point (RP). The RP forms the root of the group's distribution tree. The designated router for a multicast sender sends multicast packets towards the RP. Designated routers with group members connected to them send join messages towards the group's RP. The RP candidate with the lowest priority is elected from all the RP candidates for a group. If the RP becomes unavailable, the remaining RP candidates elect a new RP.

Bootstrap router

Each PIM-SM network must have at least one bootstrap router (BSR) candidate, unless all routers in the domain are configured statically with information about all RPs in the domain. Every router that is a BSR candidate periodically sends a Bootstrap Candidate Advertisement message to advertise that it is available as a bootstrap router candidate. The BSR candidates in the network elect the router with the highest preference value to be the bootstrap router. The elected bootstrap router listens to PIM Candidate RP Advertisement messages specifying RP candidates for multicast groups. It maintains a list of RP candidates, and sends a bootstrap message every BSM interval, specifying all the multicast groups in the PIM network, and their rendezvous point candidates. Each router uses this information and a standardized hash mechanism to determine the RP for each group.

In summary:

- Each *multicast group* must have at least one rendezvous point candidate
- Each *PIM-SM domain* must have at least one Bootstrap Router candidate, unless all routers in the domain are configured statically with information about all RPs in the domain
- Each *subnetwork* must have at least one Designated Router candidate.

PIM hello messages

When PIM is enabled on a switch, it sends out a PIM *Hello* message on all its PIM enabled interfaces, and listens for Hello messages from its PIM neighbors. When a switch receives a Hello message, it records the interface, IP address, priority for becoming a designated router, and the timeout for the neighbor's information. The switch sends Hello messages regularly at the Hello Time interval.

Operation of PIM Sparse Mode

Once roles are established, multicast routing follows specific phases:

1. Rendezvous point tree
2. Register stop
3. Shortest path tree

While multicast routing always begins with phase 1, the designated router for a receiver determines whether and when to move on to phases 2 and 3, depending on the amount of traffic from the source.

Rendezvous point tree

Phase 1 establishes and uses a shared tree rooted at the rendezvous point (RP) to forward all multicast data to group members.

When an IP host sends an IGMP join message to the local PIM designated router, which is not the RP for the group, the designated router sends a *PIM join* message towards the RP for the group ("upstream"). The designated router determines which router is the RP for the group from the most recent bootstrap message. Every router the join message passes through records that there is a group member on the incoming interface. Eventually, the join message reaches either the RP, or another router that already knows that it has a group member downstream. If the group has many members, the join messages converge on the RP to form a rendezvous point tree (RPT). This is called a shared tree because multicast data that is sent to the group by any sender shares the tree. The multicast receiver's designated router sends join messages periodically according to the upstream join timer as long as the IP host is a member of the group. When the last receiver on a subnetwork leaves the group, the join messages stop, and their entries timeout on routers that are closer to the RP.

The sender's designated router encapsulates the multicast data in a unicast packet in a process called *registering*, and sends these register packets to the group's RP. When the RP receives the data, it decapsulates them, and forwards them onto the shared tree.

Register stop

Phase 2 improves efficiency and performance by using register stop. In this phase the RP joins the shortest path tree between the source and receiver. This allows the original (unencapsulated) packets to be forwarded from the sender, instead of encapsulated packets. It also allows shorter paths to receivers that are close to the sender, making it more efficient in some circumstances.

When the RP for a group receives the first encapsulated data packet from a source, it joins the shortest path tree towards the sender. Once data is able to flow along the shortest path from the sender to the RP, packets do not need to be registered. The RP sends a *register stop* message in reply to the next encapsulated message. When the sender's DR receives the register stop message, it stops registering. The DR sends a *null register* message to the RP to find whether the RP still does not need to receive registered packets. If it receives another register stop message, the DR continues to forward only the native data packets. If the DR does not receive another register stop message within the register probe time, it resumes registering the data packets and sending them to the RP.

When the RP starts receiving native data packets from the source, it starts to discard the encapsulated packets, and starts forwarding native packets on the shared tree to all the group members. If the path from the source to the RP intersects the shared RP tree for the group, then the packets also take a short-cut onto the shared tree for delivery to the group members down its branches.

Shortest path tree This phase further optimizes routing by using shortest path trees (SPT). In phase 3 the receiver joins the shortest path tree between the source and receiver. This allows a multicast group member to receive multicast data by the shortest path from the sender, instead of from the shared RP tree. When the receiver's DR receives multicast data from a particular sender, it sends a *join* message towards the sender. When this message reaches the sender's DR, the DR starts forwarding the multicast data directly towards the receiver. As several receivers all initiate shortest paths to the sender, these paths converge, creating a shortest path tree.

When the multicast packets start arriving from the SPT at the receiver's DR or an upstream router common to the SPT and the RPT, it starts discarding the packets from the RPT, and sends a *prune* message towards the RP. The prune message travels up the RPT until it reaches the RP or a router that still needs to forward multicast packets from this sender to other receivers. Every time a router receives a prune message, it waits a short time so that other routers on the LAN have the opportunity to override the prune message.

Multi-Access LANs If the PIM-SM network includes multi-access LAN links for transit, as well as point-to-point links, then a mechanism is needed to prevent multiple trees forwarding the same data to the same group member. Two or more routers on a LAN may have different information about how to reach the RP or the multicast sender. They could each send a join message to two different routers closer to the RP for an RPT or the sender for an SPT. This could potentially cause two copies of all the multicast traffic towards the receiver.

When PIM routers notice duplicate data packets on the LAN, they elect a single router to forward the data packets, by each sending PIM *Assert* messages. If one of the upstream routers is on an SPT and the other is on an RPT, the router on the SPT has the shortest path to the sender, and wins the Assert election. If both routers are on RPTs the router with the shortest path to the RP (the lowest sum of metrics to the RP) wins the Assert. If both routers are on an SPT, then the router with the shortest path to the sender (the lowest sum of metrics to the sender's DR) wins the Assert.

The router that won the Assert election forwards these data packets, and acts as the local designated router for any IGMP members on the LAN. The downstream routers on the LAN also receive the Assert messages, and send all their join messages to the Assert winner. The result of an Assert election will timeout after the Assert Time. As long as the situation causing the duplication remains unchanged, the Assert winner sends an Assert message at a the Assert time interval, before the previous Assert messages time out. When the last downstream router leaves the SPT, the Assert winner sends an Assert Cancel message saying that it is about to stop forwarding data on the SPT. Any RPT downstream routers then switch back to the RP tree.

Chapter 46: PIM-SM Commands

Command List	46.2
clear ip pim sparse-mode bsr rp-set *	46.2
debug pim sparse-mode	46.3
debug pim sparse-mode timer	46.4
ip pim accept-register list	46.6
ip pim anycast-rp	46.7
ip pim bsr-border	46.8
ip pim bsr-candidate	46.9
ip pim cisco-register-checksum	46.9
ip pim cisco-register-checksum group-list	46.10
ip pim crp-cisco-prefix	46.11
ip pim dr-priority	46.12
ip pim exclude-genid	46.13
ip pim hello-holdtime (PIM-SM)	46.14
ip pim hello-interval (PIM-SM)	46.15
ip pim ignore-rp-set-priority	46.16
ip pim jp-timer	46.16
ip pim neighbor-filter (PIM-SM)	46.17
ip pim register-rate-limit	46.18
ip pim register-rp-reachability	46.18
ip pim register-source	46.19
ip pim register-suppression	46.20
ip pim rp-address	46.21
ip pim rp-candidate	46.23
ip pim rp-register-kat	46.24
ip pim sparse-mode	46.25
ip pim sparse-mode passive	46.26
ip pim spt-threshold	46.27
ip pim spt-threshold group-list	46.28
ip pim ssm	46.29
show debugging pim sparse-mode	46.30
show ip pim sparse-mode bsr-router	46.30
show ip pim sparse-mode interface	46.31
show ip pim sparse-mode interface detail	46.32
show ip pim sparse-mode mroute	46.33
show ip pim sparse-mode mroute detail	46.34
show ip pim sparse-mode neighbor	46.36
show ip pim sparse-mode nexthop	46.37
show ip pim sparse-mode rp-hash	46.38
show ip pim sparse-mode rp mapping	46.38
undebg all pim sparse-mode	46.39

Command List

This chapter provides an alphabetical reference of PIM-SM commands. For commands common to PIM-SM and PIM-DM, see [Chapter 44, Common Multicast Commands](#).

clear ip pim sparse-mode bsr rp-set *

Use this command to clear all Rendezvous Point (RP) sets learned through the PIMv2 Bootstrap Router (BSR).

Syntax `clear ip pim sparse-mode bsr rp-set *`

Parameter	Description
*	Clears all RP sets.

Mode Privileged Exec

Usage For multicast clients, note that one router will be automatically or statically designated as the RP, and all routers must explicitly join through the RP. A Designated Router (DR) sends periodic Join/Prune messages toward a group-specific RP for each group that it has active members.

For multicast sources, note that the Designated Router (DR) unicasts Register messages to the RP encapsulated with data packets from the multicast source. The RP forwards decapsulated data packets from the source toward group members.

Example

```
awplus# clear ip pim sparse-mode bsr rp-set *
```

debug pim sparse-mode

Use this command to activate/de-activate all PIM-SM debugging.

Syntax

```
debug pim sparse-mode [all] [events] [mfc] [mib] [nexthop] [nsm]
                        [packet] [state] [mtrace]

no debug pim sparse-mode [all] [events] [mfc] [mib] [nexthop] [nsm]
                        [packet] [state] [mtrace]
```

Parameter	Description
all	activates/deactivates all PIM-SM debugging
events	activates debug printing of events
mfc	activates debug printing of MFC (Multicast Forwarding Cache in kernel) add/delete/updates
mib	activates debug printing of PIM-SM MIBs
nexthop	activates debug printing of PIM-SM nexthop communications
nsm	activates debugging of PIM-SM Network Services Module communications
packet	activates debug printing of incoming and/or outgoing packets
state	activates debug printing of state transition on all PIM-SM FSMs
mtrace	activates debug printing of multicast traceroute

Mode Global Configuration and Privileged Exec

Example

```
awplus# configure terminal
awplus(config)# debug pim sparse-mode all
```

Related Commands [show debugging pim sparse-mode](#)

debug pim sparse-mode timer

Use this command to enable debugging for the specified PIM-SM timers.

Use the no versions of this command to disable debugging for the specified PIM-SM timers.

Syntax

```

debug pim sparse-mode timer assert [at]
no debug pim sparse-mode timer assert [at]
debug pim sparse-mode timer bsr [bst|crp]
no debug pim sparse-mode timer bsr [bst|crp]
debug pim sparse-mode timer hello [ht|nlt|tht]
no debug pim sparse-mode timer hello [ht|nlt|tht]
debug pim sparse-mode timer joinprune [jt|et|ppt|kat|ot]
no debug pim sparse-mode timer joinprune [jt|et|ppt|kat|ot]
debug pim sparse-mode timer register [rst]
no debug pim sparse-mode timer register [rst]

```

Parameter	Description
assert	Enable or disable debugging for the Assert timers.
at	Enable or disable debugging for the Assert Timer.
bsr	Enable or disable debugging for the specified Bootstrap router timer, or all Bootstrap router timers.
bst	Enable or disable debugging for the Bootstrap Router: Bootstrap Timer.
crp	Enable or disable debugging for the Bootstrap Router: Candidate-RP Timer.
hello	Enable or disable debugging for the specified Hello timer, or all Hello timers.
ht	Enable or disable debugging for the Hello timer: Hello Timer.
nlt	Enable or disable debugging for the Hello timer: Neighbor Liveness Timer.
tht	Enable or disable debugging for the Hello timer: Triggered Hello Timer.
joinprune	Enable or disable debugging for the specified JoinPrune timer, or all JoinPrune timers.
jt	Enable or disable debugging for the JoinPrune timer: upstream Join Timer.
et	Enable or disable debugging for the JoinPrune timer: Expiry Timer.
ppt	Enable or disable debugging for the JoinPrune timer: PrunePending Timer.
kat	Enable or disable debugging for the JoinPrune timer: KeepAlive Timer.
ot	Enable or disable debugging for the JoinPrune timer: Upstream Override Timer.
register	Enable or disable debugging for the Register timers.
rst	Enable or disable debugging for the Register timer: Register Stop Timer.

Mode Global Configuration and Privileged Exec

Default By default, all debugging is disabled.

Mode Global Configuration and Privileged Exec

Example To enable debugging for the PIM-SM Bootstrap router bootstrap timer, use the commands:

```
awplus(config)# debug pim sparse-mode timer bsr bst
```

To enable debugging for the PIM-SM Hello: neighbor liveness timer, use the command:

```
awplus(config)# debug pim sparse-mode timer hello ht
```

To enable debugging for the PIM-SM Joinprune expiry timer, use the command:

```
awplus# debug pim sparse-mode timer joinprune et
```

To disable debugging for the PIM-SM Register timer, use the command:

```
awplus# no debug pim sparse-mode timer register
```

Related Commands [show debugging pim sparse-mode](#)

ip pim accept-register list

Use this command to configure the ability to filter out multicast sources specified by the given access-list at the Rendezvous Point (RP), so that the RP will accept/refuse to perform the register mechanism for the packets sent by the specified sources. By default, the RP accepts register packets from all multicast sources.

Use the no parameter with this command to revert to default.

Syntax `ip pim accept-register list{<simplerange>|<exprange>|<access-list>}`
`no ip pim accept-register`

Parameter	Description
<simplerange>	<100 -199> IP extended access-list.
<exprange>	<2000 -2699> IP extended access list (expanded range).
<access-list>	IP Named Standard Access list.

Mode Global Configuration

Example

```
awplus# configure terminal
awplus(config)# ip pim accept-register list 121
awplus(config)# access-list 121 permit ip 100.1.1.1 0.0.0.0 any
```


ip pim anycast-rp

Use this command to configure Anycast RP (Rendezvous Point) in a RP set.

Use the no version of this command to remove the configuration.

Syntax `ip pim anycast-rp <anycast_rp_address> <member_rp_address>`
`no ip pim anycast-rp <anycast_rp_address> [<member_rp_address>]`

Parameter	Description
<anycast_rp_address>	<100-199> IP extended access-list.
<member_rp_address>	<2000-2699> IP extended access list (expanded range).

Mode Global Configuration

Usage Anycast is a network addressing and routing scheme where data is routed to the nearest or best destination as viewed by the routing topology. Compared to unicast with a one-to-one association between network address and network endpoint, and multicast with a one-to-many association between network address and network endpoint; anycast has a one-to-many association between network address and network endpoint. For anycast, each destination address identifies a set of receiver endpoints, from which only one receiver endpoint is chosen.

Anycast is often implemented using BGP to simultaneously advertise the same destination IP address range from many sources, resulting in packets address to destination addresses in this range being routed to the nearest source announcing the given destination IP address.

Use this command to specify the Anycast RP configuration in the Anycast RP set. Use the no parameter with this command to remove the Anycast RP configuration. Note that the member RP address is optional when using the no parameter to remove the Anycast RP configuration. removing the anycast RP address also removes the member RP address.

Examples The following example shows how to configure the Anycast RP address with ip pim anycast-rp:

```
awplus# configure terminal
awplus(config)# ip pim anycast-rp 1.1.1.1 10.10.10.10
```

The following example shows how to remove the Anycast RP in the RP set specifying only the anycast RP address with no ip pim anycast-rp, but not specifying the member RP address:

```
awplus# configure terminal
awplus(config)# no ip pim anycast-rp 1.1.1.1
```

ip pim bsr-border

Use the `ip pim bsr-border` command to prevent bootstrap router (BSR) messages from being sent or received through a VLAN interface. The BSR border is the border of the PIM domain.

Use the `no ip pim bsr-border` command to disable the configuration set with `ip pim bsr-border`.

Syntax `ip pim bsr-border`
 `no ip pim bsr-border`

Mode Interface for a VLAN interface.

Usage When this command is configured on a VLAN interface, no PIM version 2 BSR messages will be sent or received through the interface. Configure an interface bordering another PIM domain with this command to avoid BSR messages from being exchanged between the two PIM domains.

BSR messages should not be exchanged between different domains, because devices in one domain may elect Rendezvous Points (RPs) in the other domain, resulting in loss of isolation between the two PIM domains that would stop the PIM protocol from working as intended.

Examples The following example configures the interface specified to be the PIM domain border:

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip pim bsr-border
```

The following example removes the interface specified from the PIM domain border:

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# no ip pim bsr-border
```

ip pim bsr-candidate

Use this command to give the device the candidate BSR (bootstrap router) status using the specified IP address mask of the interface.

Use the no version of this command to disable this function to remove the BSR candidate.

Syntax `ip pim bsr-candidate <interface> [<hash>] [<priority>]`
`no ip pim bsr-candidate [<interface>]`

Parameter	Description
<interface>	The interface. For instance, vlan2.
<hash>	<0-32> configure hash mask length for RP selection.
<priority>	<0-255> configure priority for a BSR candidate. Note that you must also specify the HASH (mask length) when specifying the PRIORITY.

Mode Global Configuration

Examples To set the BSR candidate to a specified interface issue the command shown below:

```
awplus# configure terminal
awplus(config)# ip pim bsr-candidate vlan2 20 30
```

To disable this function and remove the BSR candidate from a specified interface enter:

```
awplus# configure terminal
awplus(config)# no ip pim bsr-candidate vlan2
```

ip pim cisco-register-checksum

Use this command to configure the option to calculate the Register checksum over the whole packet. This command is used to inter-operate with older Cisco IOS versions.

Use the no parameter with this command to disable this option.

Syntax `ip pim cisco-register-checksum`
`no ip pim cisco-register-checksum`

Default This command is disabled by default. By default, Register Checksum is calculated only over the header.

Mode Global Configuration

Example

```
awplus# configure terminal
awplus(config)# ip pim cisco-register-checksum
```

ip pim cisco-register-checksum group-list

Use this command to configure the option to calculate the Register checksum over the whole packet on multicast groups specified by the access-list. This command is used to inter-operate with older Cisco IOS versions.

Use the no parameter with this command to revert to default settings.

Syntax

```
ip pim cisco-register-checksum group-list  
    [<simplerange>|<exprange>|<access-list>]  
  
no ip pim cisco-register-checksum group-list  
    [<simplerange>|<exprange>|<access-list>]
```

Parameter	Description
<simplerange>	<1-99> Simple access-list.
<exprange>	<1300-1999> Simple access-list (expanded range).
<access-list>	IP Named Standard Access list.

Mode Global Configuration

Example

```
awplus# configure terminal  
awplus(config)# ip pim cisco-register-checksum group-list 34  
awplus(config)# access-list 34 permit 224.0.1.3
```

ip pim crp-cisco-prefix

Use this command to interoperate with Cisco devices that conform to an earlier draft standard. Some Cisco devices might not accept candidate RPs with a group prefix number of zero. Note that the latest BSR specification prohibits sending RP advertisements with prefix 0. RP advertisements for the default IPv4 multicast group range 224/4 are sent with a prefix of 1.

Use the no parameter with this command to revert to the default settings.

Syntax `ip pim crp-cisco-prefix`
`no ip pim crp-cisco-prefix`

Mode Global Configuration

Usage Cisco's BSR code does not conform to the latest BSR draft, it does not accept candidate RPs with a group prefix number of zero. To make the candidate RP work with a Cisco BSR, use the `ip pim crp-cisco-prefix` command when interoperating with older versions of Cisco IOS.

Example

```
awplus# configure terminal
awplus(config)# ip pim crp-cisco-prefix
```

Related Commands [ip pim rp-candidate](#)

ip pim dr-priority

Use this command to set the designated router priority value.

Use the no parameter with this command to disable this function.

Syntax `ip pim dr-priority <priority>`
`no ip pim dr-priority`

Parameter	Description
<code><priority></code>	<code><0 - 4294967294></code> The priority value. A higher value has a higher preference.

Mode Interface for a VLAN interface.

Default The default value is 1. The negated form of this command restores the value to the default.

Examples To set the designated router priority value apply the example commands shown below:

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip pim dr-priority 11234
```

To disable designated router priority value apply the example commands shown below:

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# no ip pim dr-priority
```

Related Commands [ip pim ignore-rp-set-priority](#)

ip pim exclude-genid

Use this command to exclude the GenID option from Hello packets sent out by the PIM module on a particular interface. This command is used to inter-operate with older Cisco IOS versions.

Use the no parameter with this command to revert to default settings.

Syntax `ip pim exclude-genid`
 `no ip pim exclude-genid`

Mode Interface for a VLAN interface.

Default By default, this command is disabled; the GenID option is included.

Example

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip pim exclude-genid
```

ip pim hello-holdtime (PIM-SM)

This command configures a hello-holdtime value. You cannot configure a hello-holdtime value that is less than the current hello-interval.

Use the no variant of this command to return it to its default value of 3.5 * the current hello-interval.

Syntax `ip pim hello-holdtime <holdtime>`
`no ip pim hello-holdtime`

Parameter	Description
<holdtime>	<1-65535> The holdtime value in seconds (no fractional seconds are accepted).

Mode Interface for a VLAN interface.

Default The default hello-holdtime value is 3.5 * the current hello-interval. The default hello-holdtime is restored using the negated form of this command.

Usage Each time the hello interval is updated, the hello holdtime is also updated, according to the following rules:

If the hello holdtime is not configured; or if the hello holdtime is configured and less than the current hello-interval value, it is modified to the (3.5 * hello interval). Otherwise, it retains the configured value.

Example

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip pim hello-holdtime 123
```

ip pim hello-interval (PIM-SM)

This command configures a hello-interval value.

Use the no parameter with this command to reset the hello-interval to the default value.

Syntax `ip pim hello-interval <interval>`
`no ip pim hello-interval`

Parameter	Description
<interval>	<1-65535> the value in seconds (no fractional seconds accepted).

Mode Interface for a VLAN interface.

Default The default hello-interval value is 30 seconds. The default is restored using the negated form of this command.

Usage When the hello interval is configured, and the hello holdtime is not configured, or when the configured hello-holdtime value is less than the new hello-interval value; the holdtime value is modified to the (3.5 * hello interval). Otherwise, the hello-holdtime value is the configured value.

Example

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip pim hello-interval 123
```

ip pim ignore-rp-set-priority

Use this command to ignore the RP-SET priority value, and use only the hashing mechanism for RP selection.

This command is used to inter-operate with older Cisco IOS versions.

Use the no command to disable this setting.

Syntax ip pim ignore-rp-set-priority
 no ip pim ignore-rp-set-priority

Mode Global Configuration

Example

```
awplus# configure terminal
awplus(config)# ip pim ignore-rp-set-priority
```

ip pim jp-timer

Use this command to set the join/prune timer.

Syntax ip pim jp-timer <1-65535>

Parameter	Description
<1-65535>	Specifies the Join/Prune timer value.

Mode Global Configuration

Example

```
awplus# configure terminal
awplus(config)# ip pim jp-timer 234
```

ip pim neighbor-filter (PIM-SM)

This command enables filtering of neighbors on the VLAN interface. When configuring a neighbor filter, PIM-SM will either not establish adjacency with the neighbor, or terminate adjacency with the existing neighbors if denied by the filtering access list.

Use the `no` parameter with this command to disable this function.

Syntax `ip pim neighbor-filter {<number>|<accesslist>}`
`no ip pim neighbor-filter {<number>|<accesslist>}`

Parameter	Description
<code><number></code>	<1-99> Standard IP access-list number.
<code><accesslist></code>	IP access list name.

Mode Interface for a VLAN interface.

Default By default, there is no filtering.

Example

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip pim neighbor-filter 14
```

ip pim register-rate-limit

Use this command to configure the rate of register packets sent by this DR, in units of packets per second.

Use the no parameter to remove the limit.

Syntax ip pim register-rate-limit <1-65535>
 no ip pim register-rate-limit

Parameter	Description
<1-65535>	Specifies the maximum number of packets that can be sent per second.

Mode Global Configuration

Example

```
awplus# configure terminal
awplus(config)# ip pim register-rate-limit 3444
```

ip pim register-rp-reachability

Use this command to enable the RP reachability check for PIM Register processing at the DR. The default setting is no checking for RP-reachability.

Use the no parameter to disable this processing.

Syntax ip pim register-rp-reachability
 no ip pim register-rp-reachability

Mode Global Configuration

Default This command is disabled; by default, there is no checking for RP-reachability.

Example

```
awplus# configure terminal
awplus(config)# ip pim register-rp-reachability
```

ip pim register-source

Use this command to configure the source address of register packets sent by this DR, overriding the default source address, which is the address of the RPF interface toward the source host.

Use the `no` parameter to un-configure the source address of Register packets sent by this DR, reverting back to use the default source address that is the address of the RPF interface toward the source host.

The configured address must be a reachable address to be used by the RP to send corresponding Register-Stop messages in response. It is normally the loopback interface address, but can also be other physical addresses. This address must be advertised by unicast routing protocols on the DR. The configured interface does not have to be PIM enabled.

Syntax `ip pim register-source [<sourceaddress>|<interface>]`
`no ip pim register-source`

Parameter	Description
<code><sourceaddress></code>	The IP address, entered in the form A.B.C.D, to be used as the source of the register packets.
<code><interface></code>	The name of the interface to be used as the source of the register packets.

Mode Global Configuration

Example

```
awplus# configure terminal
awplus(config)# ip pim register-source 10.10.1.3
```

ip pim register-suppression

Use this command to configure the register-suppression time, in seconds, overriding the default value of 60 seconds. Configuring this value modifies register-suppression time at the DR. Configuring this value at the RP modifies the RP-keepalive-period value if the [ip pim rp-register-kat command on page 46.24](#) is not used. Use the no parameter to reset the value to its default of 60 seconds.

Syntax `ip pim register-suppression <1-65535>`
`no ip pim register-suppression`

Parameter	Description
<1-65535>	Register suppression on time in seconds.

Mode Global Configuration

Example

```
awplus# configure terminal
awplus(config)# ip pim register-suppression 192
```

ip pim rp-address

Use this command to statically configure RP (Rendezvous-Point) address for multicast groups.

Use the no ip pim rp-address command to remove a statically configured RP (Rendezvous-Point) address for multicast groups.

Syntax

```
ip pim rp-address <ip-address>
    [<simplerange>|<expandedrange>|<accesslist>] [<override>]

no ip pim rp-address <ip-address>
    [<simplerange>|<expandedrange>|<accesslist>] [<override>]
```

Parameter	Description
<ip-address>	IP address of Rendezvous-point, entered in the form A.B.C.D.
<simplerange>	<1-99> IP Standard Access-list.
<expandedrange>	<1300-1999> IP Standard Access-list (expanded range).
<accesslist>	IP extended Access-list name.
<override>	Enables statically defined RPs to override dynamically learned RPs.

Mode Global Configuration

Usage The AlliedWare Plus™ PIM-SM implementation supports multiple static RPs. It also supports usage of static-RP and BSR mechanism simultaneously. The ip pim rp-address command is used to statically configure the RP address for multicast groups.

You need to understand the following information before using this command.

If the RP-address that is configured by the BSR, and the RP-address that is configured statically, are both available for a group range, then the RP-address configured through BSR is chosen over the statically configured RP-address.

A single static-RP can be configured for multiple group ranges using Access Lists. However, configuring multiple static RPs (using ip pim rp-address command) with the same RP address is not allowed. The static-RP can either be configured for the whole multicast group range 224.0.0.0/4 (without ACL) or for specific group ranges (using ACL).

For example, configuring ip pim rp-address 192.168.3.4 will configure static-RP 192.168.3.4 for the default group range 224.0.0.0/4. Configuring ip pim rp-address 192.168.7.8 grp-list will configure static-RP 192.168.7.8 for all the group ranges represented by permit filters in grp-list ACL.

If multiple static-RPs are available for a group range, then one with the highest IP address is chosen.

Only Permit filters in ACL are considered as valid group ranges. The default Permit filter 0.0.0.0/0 is converted to the default multicast filter 224.0.0.0/4.

After configuration, the RP-address is inserted into a static-RP group tree based on the configured group ranges. For each group range, multiple static-RPs are maintained in a linked list. This list is sorted in a descending order of IP addresses. When selecting static-RPs for a group range, the first element (which is the static-RP with highest IP address) is chosen.

RP-address deletion is handled by removing the static-RP from all the existing group ranges and recalculating the RPs for existing TIB states if required.

Group mode and RP address mappings learned through BSR take precedence over mappings statistically defined by the `ip pim rp-address` command with the `override` keyword. Commands with the `override` keyword take precedence over dynamically learned mappings.

Example

```
awplus# configure terminal
awplus(config)# ip pim rp-address 192.168.3.4 4
```

Related Commands `ip pim rp-candidate`
 `ip pim rp-register-kat`

ip pim rp-candidate

Use this command to give the router the candidate RP (Rendezvous-Point) status using the IP address of the specified interface.

Use the no parameter to remove the RP status set using the ip pim rp-candidate command.

Syntax `ip pim rp-candidate <interface>
[priority <priority>|interval <interval>| grouplist <grouplist>]
no ip pim rp-candidate [<interface>]`

Parameter	Description
<interface>	Interface name
<priority>	<0-255> configure priority for an RP candidate.
<interval>	advertisement interval specified in the range <1-16383> (in seconds).
<grouplist>	IP access list specifier for standard, expanded or named access lists in their respective ranges: [<1-99> WORD]

Mode Global Configuration

Default The priority value for a candidate RP is 0 by default until specified using the priority parameter.

Usage Note that issuing the command ip pim rp-candidate <interface> without optional priority, interval, or grouplist parameters will configure the candidate RP with a priority value of 0.

Example

```
awplus# configure terminal
awplus(config)# ip pim rp-candidate vlan2 priority 3

awplus# configure terminal
awplus(config)# ip pim rp-candidate vlan2 priority 3
group-list 3

awplus# configure terminal
awplus(config)# no ip pim rp-candidate vlan2
```

Related Commands `ip pim rp-address`
`ip pim rp-register-kat`

ip pim rp-register-kat

Use this command to configure the Keep Alive Time (KAT) for (S,G) states at the RP (Rendezvous-Point) to monitor PIM Register packets.

Use the no parameter to remove a previously configured KAT time with ip pim rp-register-kat.

Syntax ip pim rp-register-kat <1-65535>
 no ip pim rp-register-kat

Parameter	Description
<1-65536>	KAT time in seconds.

Mode Global Configuration

Examples

```
awplus# configure terminal
awplus(config)# ip pim rp-register-kat 3454

awplus# configure terminal
awplus(config)# no ip pim rp-register-kat
```

Related Commands ip pim rp-address
 ip pim rp-candidate

ip pim sparse-mode

Use this command to enable PIM-SM on the VLAN interface.

Use the no form of this command to disable PIM-SM on the VLAN interface.

Syntax ip pim sparse-mode
 no ip pim sparse-mode

Mode Interface for a VLAN interface.

Example

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip pim sparse-mode
```

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# no ip pim sparse-mode
```

ip pim sparse-mode passive

Use this command to enable and disable passive mode operation for local members on the VLAN interface.

Use the no form of this command to disable passive mode operation for local members on the VLAN interface.

Syntax `ip pim sparse-mode passive`
`no ip pim sparse-mode passive`

Mode Interface mode for a VLAN interface.

Usage Passive mode essentially stops PIM transactions on the interface, allowing only IGMP mechanism to be active. To turn off passive mode, use the `no ip pim sparse-mode passive` or the `ip pim sparse-mode` command. To turn off PIM activities on the VLAN interface, use the `no ip pim sparse-mode` command.

Example

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip pim sparse-mode passive
```

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# no ip pim sparse-mode passive
```

ip pim spt-threshold

This command turns on the ability for the last-hop PIM router to switch to SPT.

The no form of this command turns off the ability for the last-hop PIM router to switch to SPT.

Note: The switching to SPT happens either at the receiving of the first data packet, or not at all; it is not rate-based.

Syntax ip pim spt-threshold
 no ip pim spt-threshold

Mode Global Configuration

Example

```
awplus# configure terminal
awplus(config)# ip pim spt-threshold

awplus# configure terminal
awplus(config)# no ip pim spt-threshold
```

ip pim spt-threshold group-list

Use this command to turn on/off the ability for the last-hop PIM router to switch to SPT for multicast group addresses specified by the given access-list.

The switching to SPT happens either at the receiving of the first data packet, or not at all; it is not rate-based.

Use the no variant of this command to turn off switching to the SPT.

Syntax

```
ip pim spt-threshold group-list {<simplerange>|<expandedrange>|
<named-accesslist>}
no ip pim spt-threshold group-list [<simplerange>|<expandedrange>|
<named-accesslist>]
```

Parameter	Description
<simplerange>	<1-99> IP Standard Access-list.
<expandedrange>	<1300-1999> IP Standard Access-list (expanded range).
<named-accesslist>	WORD IP Access-list name.

Mode Global Configuration

Usage Turn on/off the ability for the last-hop PIM router to switch to SPT for multicast group addresses specified by the given access-list.

Example

```
awplus# configure terminal
awplus(config)# ip pim spt-threshold group-list 1
awplus(config)# access-list 1 permit 224.0.1.3
```

ip pim ssm

Use this command to define the Source Specific Multicast (SSM) range of IP multicast addresses. The default keyword defines the SSM range as 232/8. To define the SSM range to be other than the default, use the access-list parameter option.

Use the no variant of this command to disable the SSM range.

Syntax

```
ip pim ssm default
ip pim ssm range {<accesslist>|<named-accesslist>}
no ip pim ssm
```

Parameter	Description
<accesslist>	<1-99> Simple access-list.
<named-accesslist>	Named Standard Access List.

Mode Global Configuration

Default By default, the command is disabled.

Usage When an SSM range of IP multicast addresses is defined by the ip pim ssm command, the no (*,G) or (S,G,rpt) state will be initiated for groups in the SSM range.

The messages corresponding to these states will not be accepted or originated in the SSM range.

Example The following commands show how to configure SSM service for the IP address range defined by access list 10:

```
awplus# configure terminal
awplus(config)# access-list 10 permit 225.1.1.1
awplus(config)# ip pim ssm range 4
```

The following commands show how to disable PIM-SSM :

```
awplus# configure terminal
awplus(config)# no ip pim ssm
```

show debugging pim sparse-mode

This command displays the status of the debugging of the system.

For information on output options, see [“Controlling “show” command output”](#) on page 1.33.

Syntax `show debugging pim sparse-mode`

Mode Privileged Exec

Example To display PIM-SM debugging settings, use the command:

```
awplus# show debugging pim sparse-mode
```

Figure 46-1: output from the show debugging pim sparse-mode command

```
Debugging status:
PIM event debugging is on
PIM Hello THT timer debugging is on
PIM event debugging is on
PIM MFC debugging is on
PIM state debugging is on
PIM packet debugging is on
PIM incoming packet debugging is on
PIM outgoing packet debugging is on
```

Related Commands [debug pim sparse-mode](#)

show ip pim sparse-mode bsr-router

Use this command to show the bootstrap router (BSR) (v2) address.

For information on output options, see [“Controlling “show” command output”](#) on page 1.33.

Syntax `show ip pim sparse-mode bsr-router`

Mode Privileged Exec and Exec

Output Figure 46-2: output from the show ip pim sparse-mode bsr-router command

```
PIMv2 Bootstrap information
BSR address: 10.10.11.35 (?)
Uptime:      00:00:38, BSR Priority: 0, Hash mask length: 10
Expires:     00:01:32
Role: Non-candidate BSR
State: Accept Preferred
```

Related Commands [show ip pim sparse-mode rp mapping](#)
[show ip pim sparse-mode neighbor](#)

show ip pim sparse-mode interface

Use this command to show PIM-SM interface information.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax show ip pim sparse-mode interface

Mode Privileged Exec and Exec

Example To display information about PIM-SM interfaces, use the command:

```
awplus# show ip pim sparse-mode interface
```

Figure 46-3: Example output from the show ip pim sparse-mode interface command

```
awplus#sh ip pim sparse-mode interface
Total configured interfaces: 16   Maximum allowed: 31
Total active interfaces:      12

Address          Interface VIFindex Ver/  Nbr   DR      DR
                  Mode    Count  Prior
192.168.1.53     vlan2    0      v2/S  2      2      192.168.1.53
192.168.10.53    vlan3    2      v2/S  0      2      192.168.10.53
.
.
```

Table 46-1: Fields in the output from the show ip pim sparse-mode interface command

Field	Description
Total configured interfaces	The number of configured PIM Sparse Mode interfaces.
Maximum allowed	The maximum number of PIM Sparse Mode interfaces that can be configured.
Total active interfaces	The number of active PIM Sparse Mode interfaces.
Address	Primary PIM-SM address.
Interface	Name of the PIM-SM interface.
VIF Index	The Virtual Interface index of the VLAN.
Ver/Mode	PIM version/Sparse mode.
Nbr Count	Neighbor count of the PIM-SM interface.
DR Priority	Designated router priority.
DR	The IP address of the designated router.

Related Commands

- ip pim sparse-mode
- show ip pim sparse-mode rp mapping
- show ip pim sparse-mode neighbor

show ip pim sparse-mode interface detail

Use this command to show detailed information on a PIM-SM interface.

For information on output options, see [“Controlling “show” command output”](#) on page 1.33.

Syntax show ip pim sparse-mode interface detail

Mode Privileged Exec and Exec

Output Figure 46-4: output from the show ip pim sparse-mode interface detail command

```
vlan3 (vif 3):
  Address 192.168.1.149, DR 192.168.1.149
  Hello period 30 seconds, Next Hello in 15 seconds
  Triggered Hello period 5 seconds
  Neighbors:
    192.168.1.22

vlan2 (vif 0):
  Address 10.10.11.149, DR 10.10.11.149
  Hello period 30 seconds, Next Hello in 18 seconds
  Triggered Hello period 5 seconds
  Neighbors:
    10.10.11.4
```

show ip pim sparse-mode mroute

This command displays the IP multicast routing table, or the IP multicast routing table based on the specified address or addresses.

Two group addresses cannot be used simultaneously; two source addresses cannot be used simultaneously.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip pim sparse-mode mroute [<group-address>] [<source-address>]`
`show ip pim sparse-mode mroute [<source-address> <group-address>]`

Parameter	Description
<code><group-address></code>	Group IP address, entered in the form A.B.C.D. Based on the group and source address, the output is the selected route if present in the multicast route tree.
<code><source-address></code>	Source IP address, entered in the form A.B.C.D. Based on the source and group address, the output is the selected route if present in the multicast route tree.

Mode Privileged Exec and Exec

Example

```
awplus# show ip pim sparse-mode mroute
awplus# show ip pim sparse-mode mroute 40.40.40.11
awplus# show ip pim sparse-mode mroute 235.0.0.1
awplus# show ip pim sparse-mode mroute 235.0.0.1 40.40.40.11
```

Figure 46-5: output from the show ip pim sparse-mode mroute command

```
IP Multicast Routing Table

(*,*,RP) Entries: 0
(*,G) Entries: 1
(S,G) Entries: 0
(S,G,rpt) Entries: 0
FCR Entries: 1

(*, 224.0.0.1)
RP: 10.10.5.153
RPF nbr: 192.168.1.152
RPF idx: vlan2
Upstream State: JOINED
Local      .....
Joined     ..j.....
Asserted   .....
FCR:
Source: 10.10.1.52
Outgoing   ..O.....
KAT timer running, 144 seconds remaining
Packet count 1
```

show ip pim sparse-mode mroute detail

This command displays detailed entries of the IP multicast routing table, or detailed entries of the IP multicast routing table based on the specified address or addresses.

Two group addresses cannot be used simultaneously; two source addresses cannot be used simultaneously.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax

```
show ip pim sparse-mode mroute [<group-address> | <source-address>]
detail

show ip pim sparse-mode mroute [<group-address> <source-address>]
detail

show ip pim sparse-mode mroute [<source-address> <group-address>]
detail
```

Parameter	Description
<group-address>	Group IP address, entered in the form A.B.C.D. Output is all multicast entries belonging to that group
<source-address>	Source IP address, entered in the form A.B.C.D. Output is all multicast entries belonging to that source.
detail	Show detailed information

Usage Based on the group and source address, the output is the selected route if present in the multicast route tree.

Mode Privileged Exec and Exec

Examples

```
awplus# show ip pim sparse-mode mroute detail

awplus# show ip pim sparse-mode mroute 40.40.40.11 detail

awplus# show ip pim sparse-mode mroute 224.1.1.1 detail

awplus# show ip pim sparse-mode mroute 224.1.1.1 40.40.40.11
detail
```

Figure 46-6: output from the show ip pim sparse-mode mroute detail command

```
IP Multicast Routing Table

(*,*,RP) Entries: 0
(*,G) Entries: 4
(S,G) Entries: 0
(S,G,rpt) Entries: 0
FCR Entries: 0

(*, 224.0.1.24) Uptime: 00:06:42
  RP: 0.0.0.0, RPF nbr: None, RPF idx: None
  Upstream:
    State: JOINED, SPT Switch: Disabled, JT: off
    Macro state: Join Desired,
  Downstream:
    vlan2:
      State: NO INFO, ET: off, PPT: off
      Assert State: NO INFO, AT: off
      Winner: 0.0.0.0, Metric: 42949672951, Pref: 42949672951, RPT
  bit: on
    Macro state: Could Assert, Assert Track
  Local Olist:
    vlan2
```

show ip pim sparse-mode neighbor

Use this command to show the PIM-SM neighbor information.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show ip pim sparse-mode neighbor [<interface>] [<ip-address>]
[detail]`

Parameter	Description
<interface>	Optional. Interface name (e.g. vlan2). Show neighbors on an interface.
<ip-address>	Optional. Show neighbors with a particular address on an interface. The IP address entered in the form A.B.C.D.
detail	Optional. Show detailed information.

Mode Privileged Exec and Exec

Examples

```
awplus# show ip pim sparse-mode neighbor
```

```
awplus# show ip pim sparse-mode neighbor vlan5 detail
```

Figure 46-7: Example output from the show ip pim sparse-mode neighbor command

Neighbor Address	Interface	Uptime/Expires	Ver	DR Priority/Mode
10.10.0.9	vlan2	00:55:33/00:01:44	v2	1 /
10.10.0.136	vlan2	00:55:20/00:01:25	v2	1 /
10.10.0.172	vlan2	00:55:33/00:01:32	v2	1 / DR
192.168.0.100	vlan3	00:55:30/00:01:20	v2	N / DR

Figure 46-8: Example output from the show ip pim sparse-mode neighbor interface detail command

<pre>Nbr 10.10.3.180 (vlan5), DR Expires in 55 seconds, uptime 00:00:15 Holdtime: 70 secs, T-bit: off, Lan delay: 1, Override interval: 3 DR priority: 100, Gen ID: 625159467, Secondary addresses: 192.168.30.1</pre>

show ip pim sparse-mode nexthop

Use this command to see the nexthop information as used by PIM-SM.

For information on output options, see [“Controlling “show” command output”](#) on page 1.33.

Syntax show ip pim sparse-mode nexthop

Mode Exec and Privileged Exec

Example

```
awplus# show ip pim sparse-mode nexthop
```

Figure 46-9: Example output from the show ip pim sparse-mode nexthop command

```
Flags: N = New, R = RP, S = Source, U = Unreachable
Destination Type Nexthop Nexthop Nexthop Nexthop Metric Pref Refcnt
              Num      Addr      Ifindex      Name
-----
10.10.0.9    .RS.  1      0.0.0.0  4          0          0          1
```

Table 46-2: Parameters in output of the show ip pim sparse-mode nexthop command

Parameter	Meaning
Destination	The destination address for which PIM-SM requires nexthop information.
Type	The type of destination, as indicated by the Flags description. N = New, R= RP, S = Source, U = Unreachable.
Nexthop Num	The number of nexthops to the destination. PIM-SM always uses only 1 nexthop.
Nexthop Addr	The address of the primary nexthop gateway.
Nexthop Ifindex	The interface on which the nexthop gateway can be reached.
Nexthop Name	The name of nexthop interface.
Metric	The metric of the route towards the destination.
Preference	The preference of the route towards destination.
Refcnt	Only used for debugging.

show ip pim sparse-mode rp-hash

Use this command to display the rendezvous point (RP) to be chosen based on the group selected.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip pim sparse-mode rp-hash <group-addr>`

Parameter	Description
<code><group-addr></code>	The group address for which to find the RP, entered in the form A.B.C.D.

Mode Privileged Exec and Exec

Example

```
awplus# show ip pim sparse-mode rp-hash 224.0.1.3
```

Figure 46-10: output from the show ip pim sparse-mode rp-hash command

```
RP: 10.10.11.35
Info source: 10.10.11.35, via bootstrap
```

Related Commands [show ip pim sparse-mode rp mapping](#)

show ip pim sparse-mode rp mapping

Use this command to show group-to-RP (rendezvous point) mappings, and the RP set.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip pim sparse-mode rp mapping`

Mode Privileged Exec and Exec

Example

```
awplus# show ip pim sparse-mode rp mapping
```

Figure 46-11: output from the show ip pim sparse-mode rp mapping command

```
PIM Group-to-RP Mappings
Group(s): 224.0.0.0/4
RP: 10.10.0.9
Info source: 10.10.0.9, via bootstrap, priority 0
Uptime: 16:52:39, expires: 00:02:50
```

Related Commands [show ip pim sparse-mode rp-hash](#)

undebg all pim sparse-mode

Use this command to disable all PIM-SM debugging.

Syntax undebg all pim sparse-mode

Mode Privileged Exec

Example

```
awplus# undebg all pim sparse-mode
```

Related Commands debug pim sparse-mode

Chapter 47: PIM-DM Configuration



Introduction.....	47.2
Characteristics of PIM-DM	47.2
PIM-DM Terminology.....	47.2
PIM-DM Configuration	47.4
Configuration Example	47.4
Verifying Configuration	47.8

Introduction

Protocol Independent Multicast - Dense Mode (PIM-DM) is a data-driven multicast routing protocol, which builds source-based multicast distribution trees that operate on the Flood-and-Prune principle. It requires unicast-reachability information, but does not depend on a specific unicast routing protocol.

For details of the commands used to configure PIM-DM, see [Chapter 48, PIM-DM Commands](#).

Characteristics of PIM-DM

PIM Dense Mode (PIM-DM) is a significantly less complex protocol than PIM Sparse Mode (PIM-SM). PIM-DM works on the principle that it is probable that any given multicast stream will have at least one downstream listener. PIM-DM is ideal where many hosts subscribe to receive multicast packets, so most of the PIM Routers receive and forward all multicast packets.

Where PIM-SM only forwards a multicast stream when requested, PIM-DM always floods any new multicast stream that arrives at the PIM Router and only stops flooding the multicast stream on a given link if it is explicitly told to, by receiving a Prune message from the downstream PIM Router.

PIM-DM does not include the concepts of Rendezvous Points, which are used in PIM-SM. PIM-SM explicitly builds unidirectional shared trees rooted at a Rendezvous Point (RP) per group. PIM-DM implicitly builds shortest-path trees by flooding multicast traffic domain wide, then Prunes back branches of the tree where no receivers are available. As with PIM-SM, so does PIM-DM also use Reverse Path Forwarding (RPF) to stop loops for packet forwarding for PIM Routers receiving multicast packets.

PIM-DM Terminology

See the below descriptions of the terms and concepts used to describe the PIM-DM protocol:

PIM Router

Any Layer 3 routing device that is running PIM, such as an Allied Telesis managed Layer 3 switch or Allied Telesis router.

Reverse Path Forwarding

Reverse Path Forwarding (RPF) is the mechanism that PIM uses to make sure it does not forward multicast streams around in loops. If a set of PIM Routers are connected in a loop, and each PIM Router is forwarding a given multicast stream, then eventually the multicast stream would be forwarded right around the loop.

To prevent this from happening, PIM makes use of the fact that the unicast routing tables in a set of PIM Routers should converge into a loop-free tree of paths to any given destination.

When a PIM Router receives a multicast stream from source address *SourceA* through an interface *IF1*, it checks whether *IF1* is the interface the PIM Router would use to reach *SourceA*. The PIM Router will only forward the multicast stream if *IF1* is the interface the PIM Router would use to reach *SourceA*.

RPF determines whether the interface is correct by consulting unicast routing tables. This ensure that the multicast stream is forwarded in a loop-free manner back up the tree of unicast paths that lead to the source.

**Forwarding
Multicast Packets**

PIM Routers forward a given multicast stream onto all PIM enabled IP interfaces that have not received a Prune for the given multicast stream. As with unicast routing, the PIM Router decrements the TTL (Time To Live) in each packet that the PIM Router forwards. The packet is discarded if the TTL is decremented to 0.

However, unlike unicast routing, the destination MAC addresses of the packets are not altered as they are forwarded by the PIM Router. The destination MAC addresses remain set to the multicast MAC addresses that correspond to the destination group address of the multicast stream.

Upstream

Towards the Source.

Downstream


Anything other than the upstream interface for that group.

PIM-DM Configuration

The main requirement is to enable PIM-DM on the desired interfaces. This section provides a PIM-DM configuration example for a relevant scenario. The configuration uses Allied Telesis managed Layer 3 Switches as the PIM Routers. Three PIM Routers are connected in a chain, and a multicast client is attached to the third PIM Router.

Configuration Example

In this example, the address of the multicast source is 10.10.1.52. The following figure displays the network topology used in this example:



The steps involved in the forwarding of the multicast streams for this sample configuration are:

- Switch A**
1. When the PIM Routers start, they use the exchange of PIM Hello packets to for PIM neighbor relationships with each other. Then each PIM Router becomes aware of the location of its PIM neighbors.
 2. As a multicast stream arrives from the source to Switch A, it performs an RPF check on the source IP address of the multicast stream. Switch A determines the best route to the source IP address (10.10.1.52) is the receiving interface, so it forwards the multicast stream to its only PIM neighbor.
 3. Switch A creates an (S, G) (Source, Group) entry in its PIM-DM forwarding table. Any further packets from the same source, which are destined to be forwarded to the same group, will be automatically forwarded without an RFP (Reverse Path Forwarding) check.
- Switch B**
4. When the multicast stream arrives at Switch B, it performs the same steps (2 and 3) as Switch A. This results in Switch B also having an (S, G) entry for the multicast stream in its PIM forwarding table, and the multicast stream is forwarded to Switch C.
- Switch C**
5. When the multicast stream arrives at Switch C, it will perform an RPF check on the multicast stream as it arrives, and accept it.

This PIM Router does not have any downstream PIM Routers, but if Switch C has received an IGMP report from the client to request this multicast stream, Switch C will forward the multicast stream out port1.0.1, but no other ports.

If the client leaves the group, and Switch C has no other attached clients requesting the group, then Switch C will send a Prune message upstream, resulting in Switch A and Switch B stopping forwarding the multicast stream to Switch C.

Switch A Configuration Output

See the following configuration output for Switch A:

```
hostname Switch A
vlan database
vlan 2 state enable
vlan 3 state enable
interface vlan2
ip address 10.10.1.9/24
ip igmp
ip pim dense-mode
!
interface vlan3
ip address 10.10.3.9/24
ip igmp
ip pim dense-mode
!
interface port1.0.1
switchport access vlan 3
!
interface port1.0.2
switchport access vlan 2
!
ip multicast-routing
```

**Switch B
Configuration
Output**

!
See the following configuration output for Switch B:

```
hostname Switch B
vlan database
vlan 2 state enable
vlan 3 state enable
interface vlan2
ip address 10.10.3.20/24
ip igmp
ip pim dense-mode
!
interface vlan3
ip address 172.16.1.2/24
ip igmp
ip pim dense-mode
!
interface port1.0.1
switchport access vlan 3
!
interface port1.0.2
switchport access vlan 2
!
ip multicast-routing
!
```

**Switch C
Configuration
Output**

See the following configuration output for Switch C:

```
hostname Switch C
vlan database
vlan 2 state enable
vlan 3 state enable
interface vlan2
ip address 172.16.1.10/24
ip igmp
ip pim dense-mode
!
interface vlan3
ip address 192.168.1.10/24
ip igmp
ip pim dense-mode
!
interface port1.0.1
switchport access vlan 3
!
interface port1.0.2
```



```
switchport access vlan 2
!  
ip multicast-routing
!
```

Verifying Configuration

Use the following commands to verify the interface details and multicast routing table.

Interface Details

The `show ip pim dense-mode interface` command displays the interface details for Switch C.

Switch C#**show ip pim dense-mode interface**

Address	Interface	VIFindex	Ver/	Nbr
			Mode	Count
192.168.1.10	port1.0.1	0	v2/D	0
172.16.1.10	port1.0.2	2	v2/D	1

IP Multicast Routing Table

The `show ip mroute` command displays the IP multicast routing table.

Switch C#**show ip mroute**

IP Multicast Routing Table

Flags: I - Immediate Stat, T - Timed Stat, F - Forwarder installed

Timers: Uptime/Stat Expiry

Interface State: Interface (TTL)

(10.10.1.52, 224.0.1.3), uptime 00:00:15

Owner PIM-DM, Flags: F

Incoming interface: port1.0.2

Outgoing interface list:

port1.0.1 (1)

IP PIM-DM Multicast Routing Table

The `show ip pim dense-mode mroute` displays the IP PIM-DM multicast routing table.

Switch C#**show ip pim dense-mode mroute**

PIM-DM Multicast Routing Table

(10.10.1.52, 224.0.1.3)

RPF Neighbor: 172.16.1.2, Nexthop: 172.16.1.2, port1.0.2

Upstream IF: port1.0.2

Upstream State: Forwarding

Assert State: NoInfo

Downstream IF List:

port1.0.1, in 'olist':

Downstream State: NoInfo

Assert State: NoInfo

Chapter 48: PIM-DM Commands



Command List	48.2
debug pim dense-mode all	48.2
debug pim dense-mode context	48.3
debug pim dense-mode decode	48.3
debug pim dense-mode encode	48.4
debug pim dense-mode fsm	48.4
debug pim dense-mode mrt	48.5
debug pim dense-mode nexthop	48.5
debug pim dense-mode nsm	48.6
debug pim dense-mode vif	48.6
ip pim dense-mode	48.7
ip pim dense-mode passive	48.7
ip pim hello-holdtime (PIM-DM)	48.8
ip pim hello-interval (PIM-DM)	48.9
ip pim max-graft-retries	48.10
ip pim neighbor-filter (PIM-DM)	48.11
ip pim propagation-delay	48.12
ip pim state-refresh origination-interval	48.13
show debugging pim dense-mode	48.14
show ip pim dense-mode interface	48.15
show ip pim dense-mode interface detail	48.16
show ip pim dense-mode mroute	48.17
show ip pim dense-mode neighbor	48.18
show ip pim dense-mode neighbor detail	48.18
show ip pim dense-mode nexthop	48.19
undebg all pim dense-mode	48.20

Command List

This chapter provides an alphabetical reference of PIM-DM commands. For commands common to PIM-SM and PIM-DM, see [Chapter 44, Common Multicast Commands](#).

debug pim dense-mode all

This command enables or disables PIM-DM debugging.

Syntax debug pim dense-mode all
 no debug pim dense-mode all

Mode Global Configuration mode and Privileged Exec mode

Example

```
awplus# configure terminal
awplus(config)# debug pim dense-mode all
```

Output Figure 48-1: Example output from the **debug pim dense-mode all** command

```
PIM event debugging is on
PIM MFC debugging is on
PIM state debugging is on
PIM packet debugging is on
PIM incoming packet debugging is on
PIM outgoing packet debugging is on
```

Validation Commands show debugging pim dense-mode

Related Commands debug pim dense-mode context
 debug pim dense-mode decode
 debug pim dense-mode encode
 debug pim dense-mode fsm
 debug pim dense-mode mrt
 debug pim dense-mode nexthop
 debug pim dense-mode nsm
 debug pim dense-mode vif

debug pim dense-mode context

Enables or disables debugging of general configuration and Virtual Routing (VR), and Virtual Routing and Forwarding (VRF) context.

Syntax `debug pim dense-mode context`
`no debug pim dense-mode context`

Mode Global Configuration mode and Privileged Exec mode

Example

```
awplus# configure terminal
awplus(config)# debug pim dense-mode context
```

Related Commands `debug pim dense-mode all`
`debug pim dense-mode decode`
`debug pim dense-mode encode`
`debug pim dense-mode fsm`
`debug pim dense-mode mrt`
`debug pim dense-mode nexthop`
`debug pim dense-mode nsm`
`debug pim dense-mode vif`

debug pim dense-mode decode

Enables or disables debugging of the PIM-DM message decoder.

Syntax `debug pim dense-mode decode`
`no debug pim dense-mode decode`

Mode Global Configuration mode and Privileged Exec mode

Example

```
awplus# configure terminal
awplus(config)# debug pim dense-mode decoder
```

Related Commands `debug pim dense-mode all`
`debug pim dense-mode context`
`debug pim dense-mode encode`
`debug pim dense-mode fsm`
`debug pim dense-mode mrt`
`debug pim dense-mode nexthop`
`debug pim dense-mode nsm`
`debug pim dense-mode vif`

debug pim dense-mode encode

Enables or disables debugging of the PIM-DM message encoder.

Syntax `debug pim dense-mode encode`
 `no debug pim dense-mode encode`

Mode Global Configuration mode and Privileged Exec mode

Example

```
awplus# configure terminal
awplus(config)# debug pim dense-mode encoder
```

Related Commands `debug pim dense-mode all`
 `debug pim dense-mode context`
 `debug pim dense-mode decode`
 `debug pim dense-mode fsm`
 `debug pim dense-mode mrt`
 `debug pim dense-mode nexthop`
 `debug pim dense-mode nsm`
 `debug pim dense-mode vif`

debug pim dense-mode fsm

Enables or disables debugging of Finite-State Machine (FSM) specific information of all Multicast Routing Table (MRT) and MRT Virtual Multicast Interface (MRT-VIF) entries.

Syntax `debug pim dense-mode fsm`
 `no debug pim dense-mode fsm`

Mode Global Configuration mode and Privileged Exec mode

Example

```
awplus# configure terminal
awplus(config)# debug pim dense-mode fsm
```

Related Commands `debug pim dense-mode all`
 `debug pim dense-mode context`
 `debug pim dense-mode decode`
 `debug pim dense-mode encode`
 `debug pim dense-mode mrt`
 `debug pim dense-mode nexthop`
 `debug pim dense-mode nsm`
 `debug pim dense-mode vif`

debug pim dense-mode mrt

Enables or disables debugging of MRT and MRT-VIF entry handling (for example, creation and deletion of).

Syntax `debug pim dense-mode mrt`
`no debug pim dense-mode mrt`

Mode Global Configuration mode and Privileged Exec mode

Example

```
awplus# configure terminal
awplus(config)# debug pim dense-mode mrt
```

Related Commands `debug pim dense-mode all`
`debug pim dense-mode context`
`debug pim dense-mode decode`
`debug pim dense-mode encode`
`debug pim dense-mode fsm`
`debug pim dense-mode nexthop`
`debug pim dense-mode nsm`
`debug pim dense-mode vif`

debug pim dense-mode nexthop

Enables or disables debugging of Reverse Path Forwarding (RPF) neighbor nexthop cache handling.

Syntax `debug pim dense-mode nexthop`
`no debug pim dense-mode nexthop`

Mode Global Configuration mode and Privileged Exec mode

Example

```
awplus# configure terminal
awplus(config)# debug pim dense-mode nexthop
```

Related Commands `debug pim dense-mode all`
`debug pim dense-mode context`
`debug pim dense-mode decode`
`debug pim dense-mode encode`
`debug pim dense-mode fsm`
`debug pim dense-mode mrt`
`debug pim dense-mode nsm`
`debug pim dense-mode vif`

debug pim dense-mode nsm

Enables or disables debugging of PIM-DM interface with NSM.

Syntax `debug pim dense-mode nsm`
`no debug pim dense-mode nsm`

Mode Global Configuration mode and Privileged Exec mode

Example

```
awplus# configure terminal
awplus(config)# debug pim dense-mode nsm
```

Related Commands `debug pim dense-mode all`
`debug pim dense-mode context`
`debug pim dense-mode decode`
`debug pim dense-mode encode`
`debug pim dense-mode fsm`
`debug pim dense-mode mrt`
`debug pim dense-mode nexthop`
`debug pim dense-mode vif`

debug pim dense-mode vif

Enables or disables debugging of VIF handling.

Syntax `debug pim dense-mode vif`
`no debug pim dense-mode vif`

Mode Global Configuration mode and Privileged Exec mode

Example

```
awplus# configure terminal
awplus(config)# debug pim dense-mode vif
```

Related Commands `debug pim dense-mode all`
`debug pim dense-mode context`
`debug pim dense-mode decode`
`debug pim dense-mode encode`
`debug pim dense-mode fsm`
`debug pim dense-mode mrt`
`debug pim dense-mode nexthop`
`debug pim dense-mode nsm`

ip pim dense-mode

This command enables or disables PIM-DM operation from Interface mode on the current VLAN interface. This command also disables passive mode on the VLAN interface if passive mode has been enabled using an `ip pim dense-mode passive` command.

To disable all PIM-DM activities on the interface, use the `no ip pim dense-mode` command.

Syntax `ip pim dense-mode`
`no ip pim dense-mode`

Mode Interface mode for a VLAN interface.

Example

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip pim dense-mode
```

ip pim dense-mode passive

This command enables or disables PIM-DM passive mode operation from Interface mode on the current VLAN interface.

To disable passive mode, use the `no ip pim dense-mode passive` or the `ip pim dense-mode` command.

Syntax `ip pim dense-mode passive`
`no ip pim dense-mode passive`

Mode Interface mode for a VLAN interface.

Usage Configuring a VLAN interface as a passive PIM-DM interface indicates that the VLAN interface is connected to a stub network (i.e. a network that does not contain any PIM Routers). So, multicast streams that arrive on other PIM-DM interfaces can be routed to hosts on the passive PIM-DM interface, but no PIM neighbor relationships will be formed on the passive PIM-DM interface.

Example

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip pim dense-mode passive
```

ip pim hello-holdtime (PIM-DM)

This command configures a hello-holdtime. The PIM hello-holdtime on a VLAN interface is the period which the router will wait to receive a hello from neighbors on that interface. If the router does not receive a hello from a given neighbor within that period, then it will decide that the neighbor is no longer an active PIM Router, and will terminate the neighbor relationship.

You cannot configure a hello-holdtime value that is less than the current hello-interval. Each time the hello-interval is updated, the hello-holdtime is also updated, according to the following rules:

- If the hello-holdtime is not configured; or if the hello holdtime is configured and less than the current hello-interval value, it is modified to 3.5 times the hello-interval value.
- Otherwise, it retains the configured value.

Use the no variant of this command to return the hello-holdtime value to its default value of 3.5 times the current hello-interval value.

Syntax `ip pim hello-holdtime <holdtime>`

`no ip pim hello-holdtime`

Parameter	Description
<code><holdtime></code>	<code><1-65535></code> The holdtime value in seconds (no fractional seconds are accepted).

Mode Interface mode for a VLAN interface.

Example

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip pim hello-holdtime 123
```

ip pim hello-interval (PIM-DM)

This command configures a PIM hello-interval value. The PIM hello-interval on a VLAN interface is the period at which the router will transmit PIM hello messages on that interface.

When the hello-interval is configured, and the hello-holdtime is not configured, or when the configured hello-holdtime value is less than the new hello-interval value; the hello-holdtime value is modified to 3.5 times the hello-interval value. Otherwise, the hello-holdtime value is the configured value. The default is 30 seconds.

Use the no parameter with this command to reset the hello-interval to the default value.

Syntax `ip pim hello-interval <interval>`
`no ip pim hello-interval`

Parameter	Description
<interval>	<1-65535> the value in seconds (no fractional seconds accepted).

Mode Interface mode for a VLAN interface.

Example

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip pim hello-interval 123
```

ip pim max-graft-retries

This command configures PIM-DM to send a limited number of Graft message retries, after which time the device will remove all information regarding the particular (Source, Group), or until the device receives an acknowledgment, whichever occurs first.

The no form of this command configures PIM-DM to send Graft message retries until the device receives an acknowledgment, which is the default behavior.

Syntax `ip pim max-graft-retries <1-65535>`
`no pim max-graft-retries`

Parameter	Description
no	Negate a command or set its defaults
ip	Internet Protocol (IP)
pim	PIM Interface commands
max-graft-retries	PIM Graft message retries
<1-65535>	Graft message retries before ceasing Graft message retries.

Default By default, Graft retries are sent by PIM-DM until the device receives an acknowledgement.

Mode Interface mode for a VLAN interface.

Usage Graft messages are used to reduce the join latency when a previously pruned branch of the source tree must be grafted back, when a member joins the group after the PIM-DM device has sent a Prune message to prune unwanted traffic. Graft messages are the only PIM-DM messages that receive an acknowledgement.

If Graft messages were not used, then the member waiting for pruned off traffic would have to wait up to 3 minutes for the periodic re-flooding to occur to begin receiving multicast traffic again. By using Grafts, the Prune can be reversed much faster than waiting for periodic re-flooding to begin receiving multicast traffic again.

Examples To configure PIM-DM to send a maximum of 10 Graft message retries, use the following commands:

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip pim max-graft-retries 10
```

To configure PIM-DM to send Graft message retries forever, which is the default behavior, use the following commands:

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# no ip pim max-graft-retries
```

Validation show ip mroute
Commands show ip pim dense-mode mroute
show running-config

ip pim neighbor-filter (PIM-DM)

Enables filtering of neighbors on the VLAN interface. When configuring a neighbor filter, PIM-DM will either not establish adjacency with the neighbor, or terminate adjacency with the existing neighbors if denied by the filtering access list.

Use the no parameter with this command to disable this function.

Syntax ip pim neighbor-filter [*<number>* | *<accesslist>*]
no ip pim neighbor-filter [*<number>* | *<accesslist>*]

Parameter	Description
<i><number></i>	<1-99> Standard IP access list number.
<i><accesslist></i>	IP access list name.

Mode Interface mode for a VLAN interface.

Default By default, there is no filtering.

Example

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip pim neighbor-filter 14
```

ip pim propagation-delay

This command configures the PIM propagation-delay value. The PIM propagation-delay is the expected delay in the transfer of PIM messages across the VLAN interface that it is attached to.

Use the no parameter with this command to return the propagation-delay to the default value (1000 milliseconds).

Syntax `ip pim propagation-delay <delay>`
`no ip pim propagation-delay`

Parameter	Description
<delay>	<1000-5000> the value in milliseconds. The default value is 1000 milliseconds.

Mode Interface mode for a VLAN interface.

Default The propagation-delay is set to 1000 milliseconds by default.

Example

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip pim propagation-delay 2000

awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# no ip pim propagation-delay
```

ip pim state-refresh origination-interval

This command configures a PIM state-refresh origination-interval value. The origination interval is the number of seconds between PIM state refresh control messages. The default is 60 seconds.

Use the no parameter with this command to return the origination interval to the default value.

Syntax `ip pim state-refresh origination-interval <interval>`
`no ip pim state-refresh origination-interval`

Parameter	Description
<interval>	<1-100> the integer value in seconds (no fractional seconds accepted). The default state-refresh origination-interval value is 60.

Mode Interface mode for a VLAN interface.

Default The state-refresh origination-interval is set to 60 seconds by default, and is reset using negation.

Example

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip pim state-refresh origination-interval 65
```

show debugging pim dense-mode

This command displays the status of the debugging of the system.

For information on output options, see [“Controlling “show” command output”](#) on page 1.33.

Syntax show debugging pim dense-mode

Mode Privileged Exec mode and Exec mode

Output Figure 48-2: Example output from the **show debugging pim dense-mode** command

```
awplus#show debugging pim dense-mode
PIM-DM Debugging status:
  PIM-DM VR-VRF Context debugging is off
  PIM-DM Decoder debugging is off
  PIM-DM Encoder debugging is off
  PIM-DM FSM debugging is off
  PIM-DM MRT debugging is off
  PIM-DM NHOP debugging is off
  PIM-DM NSM debugging is off
  PIM-DM VIF debugging is off
```

Related Commands [debug pim dense-mode all](#)

show ip pim dense-mode interface

This command displays the PIM-DM interface information.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax show ip pim dense-mode interface

Mode Privileged Exec mode and Exec mode

Example To display information about the PIM-DM interfaces, use the command:

```
awplus# show ip pim dense-mode interface
```

Figure 48-3: Example output from the **show ip pim dense-mode interface** command

```
awplus#show ip pim dense-mode interface
Total configured interfaces: 24   Maximum allowed: 32
Total active interfaces:      22

Address          Interface VIFIndex Ver/   Nbr
                  Mode      Count
192.168.1.53/24  vlan2     0      v2/D   2
192.168.2.1     vlan3     2      v2/D   0
.
.
```

Figure 48-4: Example output from the **show ip pim dense-mode interface** command

Field	Description
Total configured interfaces	The number of configured PIM Dense Mode interfaces.
Maximum allowed	The maximum number of PIM Dense Mode interfaces that can be configured.
Total active interfaces	The number of active PIM Dense Mode interfaces.
Address	Primary PIM-DM address.
Interface	Name of the PIM-DM interface.
VIF Index	The Virtual Interface index of the VLAN.
Ver/Mode	PIM version/Dense mode.
Nbr Count	Neighbor count of the PIM-DM interface.

Related Commands ip pim dense-mode
show ip pim dense-mode neighbor

show ip pim dense-mode interface detail

This command displays detailed information on a PIM-DM interface.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax show ip pim dense-mode interface detail

Mode Privileged Exec mode and Exec mode

Example

```
awplus# show ip pim dense-mode interface detail
```

Figure 48-5: Example output from the **show ip pim dense-mode interface detail** command

```
vlan2 (vif-id: 0):  
  Address 192.168.1.53/24  
  Hello period 30 seconds, Next Hello in 30 seconds  
  Neighbors:  
    192.168.1.152/32  
    192.168.1.149/32  
vlan3 (vif-id: 2):  
  Address 192.168.10.53/24  
  Hello period 30 seconds, Next Hello in 8 seconds  
  Neighbors: none
```

show ip pim dense-mode mroute

This command displays the IP PIM-DM multicast routing table.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip pim dense-mode mroute`

Mode Privileged Exec mode and Exec mode

Example

```
awplus# show ip pim dense-mode mroute
```

Figure 48-6: Example output from the **show ip pim dense-mode mroute** command

```
PIM-DM Multicast Routing Table
(192.168.10.52, 224.1.1.1)
  Source directly connected on vlan3
  State-Refresh Originator State: Originator
  Upstream IF: vlan3, State: Forwarding
  Downstream IF List:
    vlan2, in 'olist':
      Downstream State: NoInfo
      Assert State: NoInfo
```

show ip pim dense-mode neighbor

This command displays PIM-DM neighbor information.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax show ip pim dense-mode neighbor

Mode Privileged Exec mode and Exec mode

Usage The total number of PIM-DM neighbors is restricted to 500 PIM-DM neighbors.

When the 500 PIM-DM neighbor limit is reached, as a result of receiving hello packets from new PIM-DM neighbors, a log entry will be issued to the log file in the below format:

```
<date> <time> <facility>.<severity> <program[<pid>]>: <message>
```

```
-----
2008 Dec 10 00:58:39 user.err x900 PIM-DM[1150]: [VIF] Nbr Create:
Cannot create more than 500 neighbours - ignoring neighbour
100.0.1.247/32 on vlan100
```

Example

```
awplus# show ip pim dense-mode neighbor
```

Figure 48-7: Example output from the **show ip pim dense-mode neighbor** command

```
Total number of neighbors: 500
Neighbor-Address  Interface      Uptime/Expires  Ver
192.168.1.152     vlan2          17:15:42/00:01:28 v2
192.168.1.149     vlan2          17:15:34/00:01:34 v2
```

show ip pim dense-mode neighbor detail

This command displays detailed PIM-DM neighbor information.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax show ip pim dense-mode neighbor detail

Mode Privileged Exec mode and Exec mode

Example

```
awplus# show ip pim dense-mode neighbor detail
```

Figure 48-8: Example output from the **show ip pim dense-mode neighbor detail** command

```
Neighbor 192.168.1.152 (vlan2)
Up since 17:16:20, Expires in 00:01:20
Neighbor 192.168.1.149 (vlan2)
Up since 17:16:12, Expires in 00:01:26
```

show ip pim dense-mode nexthop

This command displays the nexthop information as used by PIM-DM. In the context of PIM-DM, the term 'nexthop' refers to the nexthop router on the path back to the source address of a multicast stream.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax show ip pim dense-mode nexthop

Mode Exec mode and Privileged Exec mode

Example

```
awplus# show ip pim dense-mode nexthop
```

Figure 48-9: Example output from the **show ip pim dense-mode neighbor nexthop** command

Destination Pref	Nexthop Num	Nexthop Addr	Nexthop Interface	Metric	
192.168.10.52	1	0.0.0.0	vlan2	3	1

Field	Description
Destination	Destination address for which PIM-DM requires nexthop information
Nexthop Num	Number of nexthops to the destination. PIM can only use one nexthop
Nexthop Addr	Address of the current nexthop gateway
Nexthop Interface	Name of the nexthop interface
Metric	Metric of the route towards the destination
Preference	Preference of the route towards the destination

undebug all pim dense-mode

Use this command from the Global Configuration mode to disable all PIM-DM debugging.

Syntax `undebug all pim dense-mode`

Mode Global Configuration mode

Example

```
awplus# configure terminal
awplus(config)# undebug all pim dense-mode
```

Related Commands

- `debug pim dense-mode all`
- `debug pim dense-mode context`
- `debug pim dense-mode decode`
- `debug pim dense-mode encode`
- `debug pim dense-mode fsm`
- `debug pim dense-mode mrt`
- `debug pim dense-mode nexthop`
- `debug pim dense-mode nsm`
- `debug pim dense-mode vif`

Chapter 49: MLD Snooping Commands



Introduction.....	49.2
Command List.....	49.2
clear ipv6 mld.....	49.2
clear ipv6 mld group.....	49.3
clear ipv6 mld interface.....	49.4
debug mld.....	49.5
ipv6 mld access-group.....	49.6
ipv6 mld limit.....	49.7
ipv6 mld snooping.....	49.9
ipv6 mld snooping fast-leave.....	49.10
ipv6 mld snooping mrouter.....	49.11
ipv6 mld snooping report-suppression.....	49.12
ipv6 mld ssm-map enable.....	49.13
ipv6 mld ssm-map static.....	49.14
ipv6 mld static-group.....	49.15
show ipv6 mld groups.....	49.17
show ipv6 mld interface.....	49.18
show ipv6 mld snooping mrouter.....	49.19
show ipv6 mld snooping statistics.....	49.20

Introduction

Multicast Listener Discovery (MLD) is used to exchange membership status information between IPv6 routers that support multicasting and members of multicast groups on a network segment. Host membership in a multicast group is reported by individual member hosts, and membership status is periodically polled by multicast routers. MLD is defined in RFC 2710, "Multicast Listener Discovery (MLD) for IPv6."

MLD Snooping is a feature whereby a layer 2 switch listens to or "snoops" the MLD messages passing through the switch or from member hosts and multicast routers.

The purpose of MLD Snooping is to provide efficient layer 2 multicast forwarding, by sending only to hosts that have expressed an interest in receiving the multicast data.

Hosts express an interest in receiving multicast data for a given multicast group by sending an MLD join message. Without MLD Snooping, if one host expresses an interest in getting multicast data for a given group, by sending an MLD join for the multicast group, then all hosts connected to the same vlan will also receive the multicast data. This wastes bandwidth on the switch ports connected to the host that are not interested in receiving the multicast data. Snooping takes note of exactly which ports have received joins for a given group, and send that group only to those ports.

MLD Snooping is enabled by default globally for the switch. It can be enabled and disabled on a per-vlan basis.

MLD Snooping makes a distinction between Member ports, which are ports connected to members hosts, and Router ports, which are ports connected to, or directed towards, a layer 3 router or a layer 3 switch.

Command List

This chapter provides an alphabetical reference of configuration, clear, and show commands related to MLD Snooping.

clear ipv6 mld

Use this command to clear all MLD local memberships on all interfaces.

Syntax `clear ipv6 mld`

Mode Privileged Exec

Usage This command applies to groups learned by MLD Snooping.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Example

```
awplus# clear ipv6 mld
```

Related Commands `clear ipv6 mld group`
`clear ipv6 mld interface`

clear ipv6 mld group

Use this command to clear MLD specific local-membership(s) on all interfaces, for a particular group.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax `clear ipv6 mld group {*|<ipv6-address>}`

Parameter	Description
*	Clears all groups on all interfaces. This is an alias to the clear ipv6 mld command.
<ipv6-address>	Specify the group address for which MLD local-memberships are to be cleared from all interfaces. Specify the IPv6 multicast group address in the format in the format X:X::X:X

Mode Privileged Exec

Usage This command applies to groups learned by MLD Snooping.

Example

```
awplus# clear ipv6 mld group *
```

Related Commands [clear ipv6 mld](#)
[clear ipv6 mld interface](#)

clear ipv6 mld interface

Use this command to clear MLD interface entries.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax `clear ipv6 mld interface <interface>`

Parameter	Description
<interface>	Specifies name of the interface; all groups learned from this interface are deleted.

Mode Privileged Exec

Usage This command applies to interfaces configured for MLD Snooping.

Example

```
awplus# clear ipv6 mld interface vlan2
```

Related Commands `clear ipv6 mld`
`clear ipv6 mld group`

debug mld

Use this command to enable all MLD debugging modes, or a specific MLD debugging mode.

Use the no parameter with this command to disable all MLD debugging modes, or a specific MLD debugging mode.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax debug mld {all|decode|encode|events|fsm|tib}
no debug mld {all|decode|encode|events|fsm|tib}

Parameter	Description
all	debug all MLD
decode	debug MLD decoding
encode	debug MLD encoding
events	debug MLD events
fsm	debug MLD Finite State Machine (FSM)
tib	debug MLD Tree Information Base (TIB)

Mode Privileged Exec and Global Configuration

Example

```
awplus# configure terminal
awplus(config)# debug mld all

awplus# configure terminal
awplus(config)# debug mld decode

awplus# configure terminal
awplus(config)# debug mld encode

awplus# configure terminal
awplus(config)# debug mld events
```

ipv6 mld access-group

Use this command to control the multicast local-membership groups learned on an interface.

Use the no parameter with this command to disable this access control.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax `ipv6 mld access-group <access-list-name>`
`no ipv6 mld access-group`

Parameter	Description
<code><access-list-name></code>	Standard IPv6 access-list name.

Mode Interface Configuration for a specified VLAN interface.

Default No access list is configured by default.

Usage This command applies to groups learned by MLD Snooping.

Example In the following example, `vlan2` will only accept MLD joins for groups in the range `ff1e:0db8:0001::/64`:

```
awplus# configure terminal
awplus(config)# ipv6 access-list standard group1 permit
                ff1e:0db8:0001::/64
awplus(config)# interface vlan2
awplus(config-if)# ipv6 mld access-group group1
```

ipv6 mld limit

Use this command to configure a limit on the maximum number of group memberships that may be learned. The limit may be set for the switch as a whole, or for a specific interface.

Once the specified group membership limit is reached, all further local-memberships will be ignored.

Optionally, an exception access-list can be configured to specify the group-address(es) that are exempted from being subject to the limit.

Use the no parameter with this command to reset the limit and any specified exception access-list.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax `ipv6 mld limit <limitvalue> [except <access-list-name>]`
`no ipv6 mld limit`

Parameter	Description
<limitvalue>	<2 - 2097152> Maximum number of group membership states.
<access-list-name>	Optional. Standard IPv6 access-list name that defines multicast groups which are exempted from being subject to the configured limit.

Mode Global Configuration and Interface Configuration for a specified VLAN interface.

Default The default limit, which is reset by the no ipv6 mld limit command, is the same as maximum number of group membership entries that can be learned with the ipv6 mld limit command.
The default limit of group membership entries that can be learned is 2097152 entries.

Usage This command applies to interfaces learned by MLD Snooping.
If this command is issued on multiple VLAN interfaces, the limits apply individually to each of those interfaces.

Example The following example configures an MLD limit of 100 group-memberships across all VLAN interfaces on which MLD is enabled, and excludes groups in the range ff1e:0db8:0001::/64 from this limitation:

```
awplus# configure terminal
awplus(config)# ipv6 access-list standard v6grp permit
ff1e:0db8:0001::/64
awplus(config)# ipv6 mld limit 100 except v6grp
```

The following example configures an MLD limit of 100 group-membership states on `vlan2`:

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ipv6 mld limit 100
```

ipv6 mld snooping

Use this command to enable MLD Snooping. When this command is issued in the Global Configuration mode, MLD Snooping is enabled globally for the switch. When this command is issued in Interface mode for a VLAN then MLD Snooping is enabled for the specified VLAN. Note that MLD Snooping is enabled on the VLAN only if it is enabled globally and on the VLAN.

Use the `no` parameter with this command to globally disable MLD Snooping in Global Configuration mode, or for the specified VLAN interface in Interface mode.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCStack configurations.

Syntax `ipv6 mld snooping`
`no ipv6 mld snooping`

Default By default, MLD Snooping is enabled both globally and on all VLANs.

Mode Global Configuration and Interface Configuration for a specified VLAN interface.

Usage For MLD snooping to operate on particular VLAN interfaces, it must be enabled both globally by using this command in Global Configuration mode, and on individual VLAN interfaces by using this command in Interface Configuration mode. (Both are enabled by default.)

Both IGMP snooping and MLD snooping must be enabled globally on the switch for MLD snooping to operate. IGMP snooping is also enabled by default. To enable it if it has been disabled, use the [ip igmp snooping command on page 43.21](#) in Global Configuration mode.

Examples To configure MLD Snooping on `vlan2`, enter the following commands:

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ipv6 mld snooping
```

To disable MLD Snooping for `vlan2`, enter the following commands:

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config)# no ipv6 mld snooping
```

To configure MLD Snooping globally for the switch, enter the following commands:

```
awplus# configure terminal
awplus(config)# ipv6 mld snooping
```

To disable MLD Snooping globally for the switch, enter the following commands:

```
awplus# configure terminal
awplus(config)# no ipv6 mld snooping
```

Related Commands [ip igmp snooping](#)

ipv6 mld snooping fast-leave

Use this command to enable MLD Snooping fast-leave processing. Fast-leave processing is analogous to immediate-leave processing; the MLD group-membership is removed as soon as an MLD leave group message is received, without sending out a group-specific query.

Use the `no` parameter with this command to disable fast-leave processing

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax `ipv6 mld snooping fast-leave`
`no ipv6 mld snooping fast-leave`

Mode Interface Configuration for a specified VLAN interface.

Default MLD Snooping fast-leave processing is disabled.

Usage This MLD Snooping command can only be configured on VLAN interfaces.

Example This example shows how to enable fast-leave processing on `vlan2`.

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ipv6 mld snooping fast-leave
```


ipv6 mld snooping mrouter

Use this command to statically configure the specified port as a Multicast Router interface for MLD Snooping within the specified VLAN.

Use the no parameter with this command to remove the static configuration of the interface as a Multicast Router interface.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax `ipv6 mld snooping mrouter interface <port>`
`no ipv6 mld snooping mrouter interface <port>`

Parameter	Description
<port>	Specify the name of the port

Mode Interface Configuration for a specified VLAN interface.

Usage This MLD Snooping command statically configures a switch port as a Multicast Router interface.

Example This example shows how to specify the next-hop interface to the multicast router.

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ipv6 mld snooping mrouter interface
port1.0.5
```

ipv6 mld snooping report-suppression

Use this command to enable report suppression from hosts for Multicast Listener Discovery version 1 (MLDv1) on a VLAN in interface configuration mode.

Use the no parameter to disable report suppression on a VLAN in interface configuration mode.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax `ipv6 mld snooping report-suppression`

`no ipv6 mld snooping report-suppression`

Mode Interface Configuration for a specified VLAN interface.

Default Report suppression does not apply to MLDv2, and is turned on by default for MLDv1 reports.

Usage This MLD Snooping command can only be configured on VLAN interfaces.

MLDv1 snooping maybe configured to suppress reports from hosts. When a querier sends a query, only the first report for particular set of group(s) from a host will be forwarded to the querier by the MLD Snooping switch. Similar reports (to the same set of groups) from other hosts, which would not change group memberships in the querier, will be suppressed by the MLD Snooping switch to prevent 'flooding' of query responses.

Example This example shows how to enable report suppression for MLDv1 reports on `vlan2`.

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ipv6 mld snooping report-suppression
```

This example shows how to disable report suppression for MLDv1 reports on `vlan2`:

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# no ipv6 mld snooping report-suppression
```

ipv6 mld ssm-map enable

Use this command to enable the Source Specific Multicast (SSM) mapping feature on the switch.

Use the no parameter with this command to disable the SSM mapping feature on the switch.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax `ipv6 mld ssm-map enable`
 `no ipv6 mld ssm-map enable`

Mode Global Configuration

Usage This command applies to interfaces configured for MLD Snooping.

This command enables the SSM mapping feature for group members in the defined SSM range. Configure the group member and the SSM range using the [ipv6 mld ssm-map static](#) command.

Example This example shows how to enable the MLD SSM mapping feature on the switch.

```
awplus# configure terminal
awplus(config)# ipv6 mld ssm-map enable
```

Related Commands [ipv6 mld ssm-map static](#)

ipv6 mld ssm-map static

Use this command to statically define a Source Specific Multicast (SSM) mapping. The SSM mapping statically assigns sources to MLDv1 groups to translate such (*,G) groups' memberships to (S,G) memberships for use with PIM-SSM.

Use the no parameter with this command to remove the SSM map association.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax `ipv6 mld ssm-map static <access-list-name> X:X::X:X`
`no ipv6 mld ssm-map static <access-list-name> X:X::X:X`

Parameter	Description
<code><access-list-name></code>	IPv6 named standard access-list.
<code>X:X::X:X</code>	IPv6 source address that is associated with the above access-list. The IPv6 address uses the format X:X::X:X.

Mode Global Configuration

Usage This command applies to interfaces configured for MLD Snooping.

Use this command to configure SSM mappings after enabling SSM mapping with the [ipv6 mld ssm-map enable](#) command.

Example This example shows how to configure an SSM static mapping for the group-address `ff0e::1/128`.

```
awplus# configure terminal
awplus(config)# ipv6 mld ssm-map enable
awplus(config)# ipv6 access-list standard v6grp permit
                ff0e::1/128
awplus(config)# ipv6 mld ssm-map static v6grp 2006::3
```

Related Commands [ipv6 mld ssm-map enable](#)

ipv6 mld static-group

Use this command to statically configure IPv6 group membership entries on an interface. To statically add only a group membership, do not specify any parameters.

Use the no parameter with this command to delete static group membership entries.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax `ipv6 mld static-group <ipv6-group-address>
[source <ipv6-source-address>|ssm-map] [interface <port>]`
`no ipv6 mld static-group <ipv6-group-address>
[source <ipv6-source-address>|ssm-map] [interface <port>]`

Parameter	Description
<ipv6-group-address>	Specify a standard IPv6 Multicast group address to be configured as a static group member. The IPv6 address uses the format X:X::X:X.
<ipv6-source-address>	Optional. Specify a standard IPv6 source address to be configured as a static source from where multicast packets originate. The IPv6 address uses the format X:X::X:X.
ssm-map	Mode of defining SSM mapping. SSM mapping statically assigns sources to MLDv1 groups to translate these (*,G) groups' memberships to (S,G) memberships for use with PIM-SSM.
<port>	Optional. Physical interface. This parameter specifies a physical port. If this parameter is used, the static configuration is applied to just to that physical interface. If this parameter is not used, the static configuration is applied on all ports in the VLAN.

Mode Interface Configuration for a specified VLAN interface.

Usage This command applies to MLD Snooping on a VLAN interface to statically add groups and/or source records.

Example The following examples show how to statically add group and/or source records for MLD Snooping on vlan2:

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ipv6 mld static-group ff1e::10
```

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ipv6 mld static-group ff1e::10 source
fe80::2fd:6cff:fe1c:b
```

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ipv6 mld static-group ff1e::10 source ssm-
map
```

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ipv6 mld static-group ff1e::10 interface
port1.0.8
```

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ipv6 mld static-group ff1e::10 source
fe80::2fd:6cff:fe1c:b interface port1.0.8
```

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ipv6 mld static-group ff1e::10 source ssm-
map interface port1.0.8
```

show ipv6 mld groups

Use this command to display the multicast groups with receivers directly connected to the router, and learned through MLD.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax `show ipv6 mld groups [<ipv6-address> |<interface> detail]`

Parameter	Description
<code><ipv6-address></code>	Optional. Specify Address of the multicast group in format X:X::X:X
<code><interface></code>	Optional. Specify the Interface name for which to display local information.

Mode Exec and Privileged Exec

Example The following command displays local-membership information for all interfaces:

```
awplus# show ipv6 mld groups
```

Output

```
MLD Connected Group Membership
Group Address      Interface      Uptime        Expires       Last
Reporter
ff1e::10           ge10          00:03:16      00:01:09
fe80::202:b3ff:fe0:79d8
```

show ipv6 mld interface

Use this command to display the state of MLD Snooping for a specified interface, or all interfaces.

For information on output options, see “Controlling “show” command output” on page 1.33.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax show ipv6 mld interface [<interface>]

Parameter	Description
<interface>	Interface name

Mode Exec and Privileged Exec

Example The following displays MLD interface status on all interfaces enabled for MLD.

```
awplus# show ipv6 mld interface
```

Output

```
Interface eth1 (Index 2)
  MLD Enabled, Active, Querier, Version 2 (default)
  Internet address is fe80::2fd:6cff:fe1c:b
  MLD interface has 0 group-record states
  MLD activity: 0 joins, 0 leaves
  MLD query interval is 125 seconds
  MLD querier timeout is 255 seconds
  MLD max query response time is 10 seconds
  Last member query response interval is 1000 milliseconds
  Group Membership interval is 260 seconds
```


show ipv6 mld snooping mrouter

Use this command to display the multicast router interfaces, both configured and learned, in a VLAN.

For information on output options, see “Controlling “show” command output” on page 1.33.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax `show ipv6 mld snooping mrouter <interface>`

Parameter	Description
<interface>	The name of the VLAN interface

Mode Exec and Privileged Exec

Example The following displays the multicast router interfaces in vlan2

```
awplus# show ipv6 mld snooping mrouter vlan2
```

Output

VLAN	Interface	Static/Dynamic
2	port1.0.2	
2	port1.0.3	

show ipv6 mld snooping statistics

Use this command to display MLD Snooping statistics data.

For information on output options, see “Controlling “show” command output” on page 1.33.

Note: This command is only supported in the stand alone mode. IPv6 is not supported on x600 series switches in VCS configurations.

Syntax show ipv6 mld snooping statistics interface <interface>

Parameter	Description
<interface>	The name of the VLAN interface

Mode Exec and Privileged Exec

Example The following displays MLDv2 statistical information for vlan2.

```
awplus# show ipv6 mld snooping statistics interface vlan2
```

Output

```
Interface:      vlan2
Group:          ff1e::10
Uptime:         00:00:13
Group mode:     Include
Last reporter:  fe80::202:b3ff:fe0:79d8
Group source list: (R - Remote, M - SSM Mapping)
  Source Address      Uptime    v2 Exp    Fwd  Flags
  7ffe::4             00:00:13  00:04:06  Yes  R
```

Part 5: Access and Security



- Chapter 50 Access Control Lists Introduction
- Chapter 51 Access Control List (ACL) Commands
- Chapter 52 Quality of Service (QoS)
- Chapter 53 QoS Commands
- Chapter 54 802.1X Configuration
- Chapter 55 802.1X Commands
- Chapter 56 Authentication Configuration
- Chapter 57 Authentication Commands
- Chapter 58 AAA Introduction and Configuration
- Chapter 59 AAA Commands
- Chapter 60 RADIUS Commands
- Chapter 61 Local RADIUS Server Introduction and Configuration
- Chapter 62 Local RADIUS Server Commands
- Chapter 63 Secure Shell (SSH) Introduction
- Chapter 64 Secure Shell (SSH) Configuration
- Chapter 65 Secure Shell (SSH) Commands

Chapter 50: Access Control Lists

Introduction



Introduction.....	50.2
Classifying Your Traffic.....	50.3
Security Access Control Lists	50.3
QoS Access Control Lists	50.3
ACL Types.....	50.4
Hardware MAC Access Control Lists.....	50.4
Hardware IP Access Control Lists.....	50.5
Actions for Hardware Access Control Lists	50.6
Applying Access Control Lists	50.7
Attaching Access Control Lists to a Port.....	50.8
Filtering with the QoS Match Commands.....	50.10
TCP Flags.....	50.10

Introduction

An Access List (or ACL) is one, or a sequence of, filters that are applied to an interface to either block, pass or (when using QoS) apply priority to, packets that match the filter definitions.

Because filters in an ACL are applied sequentially and their action stops at the first match, it is very important that you apply the filters in the correct order. For example you might want to pass all traffic from VLAN 4 except for that arriving from two selected addresses A and B. Setting up a filter that first passes all traffic from VLAN 4 then denies traffic from addresses A and B will not filter out traffic from A and B if they are members VLAN 4. To ensure that the traffic from A and B is always blocked you should first apply the filter to block traffic from A and B, then apply the filter to allow all traffic from VLAN 4.

Each ACL is assigned an Access List Number within the range 1 to 4699. ACL numbers are grouped into ranges, where each range denotes a specific functionality. The following table shows the number ranges and functionality that your switch supports.

Table 50-1: ACL Numeric Ranges and Functionality

ACL Number Range	Function
1 to 99	IP standard ACL range ¹
100 to 199	IP extended ACL range ¹
1300 to 1999	IP standard expanded ACL range ¹
2000 to 2699	IP extended expanded ACL range ¹
3000 to 3699	Hardware IP ACL range
4000 to 4699	Hardware MAC ACL range

1. Software ACLs that use either the ranges 1-99, 100-199, 1300-1999, 2000-2699, or are named ACLs (that use the standard or extended keyword followed by a text string), are used in features such as SNMP, IGMP, BGP and OSPF.

Note: The filtering principles applied to software ACLs (those in the range 1 to 2699) are different to those applied to hardware ACLs (those in the range 3000 to 4699)

*Software ACLs will **deny** access unless **explicitly permitted** by an ACL action.
Hardware ACLs will **permit** access unless **explicitly denied** by an ACL action.*

Classifying Your Traffic

Classification is the process of, *Filtering* and *Marking*. Filtering involves sorting your data into appropriate traffic types. Marking involves tagging the data so that downstream ports and routers can apply appropriate service policy rules.

There are two reasons to classify data:

1. To provide network security (Security ACLs)
2. To apply service quality criteria QoS.

Security Access Control Lists

The main application of security ACLs is to block undesired traffic. Other applications include:

- copy-to-cpu
- copy-to-mirror
- send-to-cpu

For more information on these applications see [“Actions for Hardware Access Control Lists” on page 50.6](#)

QoS Access Control Lists

When using ACLs though QoS, the same classification and action abilities are available, but QoS has some additional fields that it can match on (see Match Commands) and also provides the ability to perform metering, marking and remarking on packets that match the filter definitions.

For more information on applying QoS filtering, see [“Classifying your Data” on page 52.7](#).

ACL Types

ACLs used in AlliedWarePlus are separated into two different types, *Software ACLs* and *Hardware ACLs*.

Note: The filtering principles applied to software ACLs (those in the range 1 to 2699) are different to those applied to hardware ACLs (those in the range 3000 to 4699)

*Software ACLs will **deny** access unless **explicitly permitted** by an ACL action. Hardware ACLs will **permit** access unless **explicitly denied** by an ACL action.*

Hardware ACLs

These ACL types are applied directly to an interface, or are used for QoS classifications. They use the following ranges:

- 3000-3699 for Hardware IP ACLs and
- 4000-4699 for Hardware MAC ACLs.

Software ACLs

These ACLs types can be either named ACLs - using the standard or extended keyword followed by a text string - or they can use the following numeric ranges:

- 1-99, 100-199, 1300-1999, 2000-2699

Software ACLs are used in features such as SNMP, IGMP, BGP and OSPF.

Note: Generally - with the exception is SNMP - the software ACLs are not matching on packets. For example, with OSPF and BGP, they are used to discard routes from route maps that have been received from a neighbor.

Hardware MAC Access Control Lists

These are used to filter traffic based on specific source or destination MAC addresses contained within the data frames. They can be applied to ports in the form of access groups. A MAC access list requires the following components:

- an ACL number in the range 4000-4699
- an action, permit, deny etc. See “Actions for Hardware Access Control Lists” on page 50.6
- a source MAC address. You can use the format, HHHH.HHHH.HHHH to filter on a specific MAC address (where H is a hexadecimal number), or you can filter on any source MAC address by entering the word “any”.
- a source MAC mask. This mask determines which portion of the source MAC address header will be compared with that found in the incoming packets. The mask is configured in the format <HHHH.HHHH.HHHH> where each H is a hexadecimal number. In practice each hex number will normally be either 0 (to represent a match) or F (to represent a don't care condition). A mask is not required if the source address is specified as “any”.
- a destination MAC address. You can use the format, HHHH.HHHH.HHHH to filter on a specific MAC address (where H is a hexadecimal number), or you can filter on any destination MAC address by entering the word “any”.
- a destination MAC mask. This mask determines which portion of the destination MAC address header will be compared with that found in the incoming packets. The mask is configured in the format <HHHH.HHHH.HHHH> where each H is a hexadecimal

number. In practice each hex number will normally be either 0 (to represent a match) or F (to represent a don't care condition). A mask is not required if the source address is specified as "any".

Example To permit packets coming from a specific MAC address of 0030.841A.1234 and with any destination address:

```
awplus# configure terminal
awplus(config)# access-list 4000 permit 0030.841A.1234
0000.0000.0000 any
```

Hardware IP Access Control Lists

These are used to filter traffic based on specific source or destination IP addresses contained within the data frames. They can be applied to ports in the form of access groups. An IP access list requires the following components.

- an ACL number in the range 3000-3699
- an action see [“Actions for Hardware Access Control Lists” on page 50.6](#)
- a packet type:
 - « IP; This matches any type of IP packet. A source and destination address must also be specified, although they can be "any".
 - « ICMP; This matches ICMP packets. A source and destination address must also be specified, although they can be "any". An ICMP type can optionally be specified after the destination address.
 - « TCP; This matches TCP packets. A source and destination address must also be specified, although they can be "any". After the source address, a source port can optionally be specified and after the destination address a destination port can optionally be specified. The port matching can be done using eq (equal to), gt (greater than), lt (less than), ne (not equal to), or range (for a range of ports, which requires a start port and an end port).
 - « UDP; This matches UDP packets and has the same options as TCP.
 - « proto; This allows any IP protocol type to be specified (e.g., 89 for OSPF). A source and destination address must be also specified, although they can be "any".

For example, to match (and permit) any type of IP packet containing a destination address of 192.168.1.1

```
awplus(config)# access-list 3000 permit ip any 192.168.1.1/32
```

To match (and permit) an ICMP packet with a source address of 192.168.x.x and an ICMP code of 4

```
awplus(config)# access-list 3001 permit icmp 192.168.0.0/16
any icmp-type 4
```

To match a TCP packet with a source address of 192.168.x.x, source port of 80 and a destination port from 100 to 150:

```
awplus(config)# access-list 3002 permit tcp 192.168.0.0/16 eq
80 any range 100 150
```

To match a UDP packet with a source address of 192.168.x.x, a destination address of 192.168.1.x, and a destination port greater than 80:

```
awplus(config)# access-list 3003 permit udp 192.168.0.0/16
192.168.1.0/24 gt 80
```

To match to any OSPF packet:

```
awplus(config)# access-list 3004 permit proto 89 any any
```

Note that an IP address mask can be specified using either of the following notations:

- "A.B.C.D/M": This is the most common; e.g., 192.168.1.0/24
- "A.B.C.D A.B.C.D": 192.168.1.1 0.0.0.0 is the same as 192.168.1.1/32 and 192.168.1.1 255.255.255.255 is the same as "any"
- "host A.B.C.D": This is the same as A.B.C.D/32

Actions for Hardware Access Control Lists

The following actions are available for Hardware ACLs:

- deny: Discard the packet.
- permit: Allow the packet.
- copy-to-cpu: Send a copy of the packet to the CPU and forward it as well. This is the same as copy,forward in AW hardware filters.
- send-to-cpu: Send the packet to the CPU and doesn't forward it. This is the same as copy,discard in AW hardware filters.
- copy-to-mirror: Send a copy of the packet to the mirror port and forward it as well.

The Action used by a QoS class-map is determined by the ACL that is attached to it. If no ACL is attached, it uses the permit action. If an ACL is not required by the class-map (for example, only matching on the VLAN) and a deny action is required, a MAC ACL should be added with any for source address and any for destination address.

The following example creates a class-map with will deny all traffic on vlan 2:

```
awplus(config)# access-list 4000 deny any any

awplus(config)# class-map cmap1

awplus(config-cmap)# match access-group 4000

awplus(config-cmap)# match vlan 2
```

The default class-map matches to all traffic and so cannot have any match or ACL commands applied to it. The action for this class-map is set via the default-action command and is permit by default. It can be changed to "deny" by using the following commands:

```
awplus(config)# policy-map pmap1

awplus(config-pmap)# default-action deny
```

Applying Access Control Lists

Interface ACLs and QoS policies can both be attached to the same port. Where this is done, packets received on the port will be matched against the ACLs first.

The interface ACLs and QoS classifications are implemented by taking the first matching entry and applying the action defined for that entry. All subsequent matches in the table are then ignored. Thus, because ACLs are also matched first, if the matching ACL has a permit action, the packet is forwarded due to that rule's action and any subsequent QoS rules are bypassed.

You can also apply permit rules are using QoS.

For example, you might want to permit a source IP address of 192.168.1.x, but block everything else on 192.168.x.x.

In this case you could create both the permit and deny rules using QoS).

Attaching Access Control Lists to a Port

An ACL is attached directly to a port (as an "Interface ACL") by using the `ip access-group` command for Hardware IP access lists, and the command for Hardware MAC access lists.

For example, to permit traffic from 192.168.1.x, but discard from 192.168.x.x:

```
awplus(config)# access-list 3000 permit ip 192.168.1.0/24
any
awplus(config)# access-list 3001 deny ip 192.168.0.0/24 any
awplus (config)# interface port1.0.1
awplus(config-if)# ip access-group 3000
awplus(config-if)# ip access-group 3001
```

The same functionality can be achieved using QoS, by attaching the ACL to a class-map, attaching the class-map to a policy-map and attaching the policy-map to a port:

Step 1: Enable QoS on the switch

```
awplus(config)# mls qos enable
```

Step 2: Create access lists

Create access-list 3000 to permit all packets from the 192.168.1 subnet.

```
awplus(config)# access-list 3000 permit ip 192.168.1.0/24 any
```

Create access-list 3001 to deny all packets from the 192.168.0 subnet.

```
awplus(config)# access-list 3001 deny ip 192.168.0.0/24 any
```

Step 3: Attach access-groups to class-maps

Attach access-group 3000 to the class-map cmap1

```
awplus(config)class-map cmap1
awplus(config)# class-map cmap1
awplus(config-cmap)# match access-group 3000
awplus(config-cmap)# exit
```

Attach access-group 3001 to the same class-map (cmap2)

```
awplus(config-cmap)# match access-group 3001
awplus(config-cmap)# exit
```

Step 4: Attach class-maps to policy-maps

Attach the class-map cmap1 to policy-map pmap1

```
awplus(config)# policy-map pmap1
awplus(config-pmap)# class cmap1
awplus(config-pmap-c)# exit
```

Add the class-map cmap2 to the policy-map pmap1

```
awplus(config-pmap)# class cmap2
awplus(config-pmap-c)# exit
```

Return to config mode

```
awplus(config-pmap)# exit
```

Step 5: Add policy-maps to ports

Add policy-map pmap1 to port1.0.1

```
awplus(config)# interface port1.0.1
awplus(config-if)# service-policy input pmap1
```

Note that multiple interface ACLs can be attached to the same port, or either type and can be interleaved. The order of matching is based on the order in which the ACLs were attached to the port. Only one ACL can be attached to a class-map, but multiple class-maps can be attached to a policy-map. Interface ACLs can be attached to the same port as a QoS policy, with the interface ACLs being matched first as described at the beginning of the Classification section.

Filtering with the QoS Match Commands

Another reason for using QoS rather than interface ACLs is that QoS provides a lot more fields on which to match. These are accessed through the match commands in config-cmap mode.

Configure Class-map mode describes the fields that can be matched on. Only one of each type can be matched, with the exception of tcp-flags (see below for classification). If multiple matches are specified, they are ANDed together.

The following example shows how you can match a packet on vlan 2, that has a source IP address of 192.168.x.x and a DSCP of 12:

Create access-list 3000 to permit all packets from the 192.168 subnet.

```
awplus(config)# access-list 3000 permit ip 192.168.0.0/16  
any
```

Apply access-list 3000 to the class-map cmap1 and add the matching criteria of vlan 2 and DSCP 12

```
awplus(config)# class-map cmap1  
awplus(config-cmap)# match access-group 3000  
awplus(config-cmap)# match vlan 2  
awplus(config-cmap)# match ip-dscp 12
```

TCP Flags

Usually, if multiple matches of the same type are specified, the matching process will apply to the last match that you specified. For TCP flags however, the arguments are ANDed together. For example, the following series of commands will match on a packet that has ack, syn and fin set:

```
awplus(config)# class-map cmap1  
awplus(config-cmap)# match tcp-flags ack  
awplus(config-cmap)# match tcp-flags syn  
awplus(config-cmap)# match tcp-flags fin
```

The following commands will achieve the same result

```
awplus(config)# class-map cmap1  
awplus(config-cmap)# match tcp-flags ack syn fin
```

Note that the matching is looking to see whether “any” of the specified flags are set. There is no checking for whether any of these flags are unset. Therefore the following command will match on a packet in any of the following combinations of syn and ack status flags as shown in the following table

```
awplus(config)# class-map cmap1
awplus(config-cmap)# match tcp-flags syn
```

Syn	Ack	Match on Packet
Set	Set	Yes
Set	Unset	Yes
Unset	Set	No
Unset	Unset	No

If you want to drop packets with syn only, but not with ack and syn, the following two class-maps can be used (note that access-list 4000 is used to apply a drop action as described in [“Actions for Hardware Access Control Lists” on page 50.6](#)):

Step 1: Create access lists

Create access-list 4000 to deny all packets with any source or destination address.

```
awplus(config)# access-list 4000 deny any any
```

Step 2: Create class-maps

Create the class-map cmap1 and configure it to match on the TCP flags, ack and syn

```
awplus(config)# class-map cmap1
awplus(config-cmap)# match tcp-flags ack syn
awplus(config-cmap)# exit
```

Create the class-map cmap2 and configure it to match on the TCP flag, syn

```
awplus(config)# class-map cmap2
awplus(config-cmap)# match tcp-flags syn
```

Step 3: Apply access-groups to class-maps

Apply access-group 4000 to this class-map (i.e. to cmap2)

```
awplus(config-cmap)# match access-group 4000
awplus(config-cmap)# exit
```

Step 4: Create policy-maps

Create the policy-map pmap1 and associate it with cmap1

```
awplus(config)# policy-map pmap1
awplus(config-pmap)# class cmap1
awplus(config-pmap-c)# exit
```

Step 5: Associate class-maps with policy-maps

Associate cmap2 with this policy-map (pmap1)

```
awplus(config-pmap)# class cmap2
```


Chapter 51: Access Control List (ACL) Commands

Command List	51.2
access-list (extended)	51.2
access-list (standard)	51.3
access-list (IP)	51.4
access-list (MAC)	51.12
access-list extended (named)	51.14
access-list standard (named)	51.20
clear ip prefix-list	51.20
dos	51.21
ip access-group	51.23
ip prefix-list	51.25
ipv6 access-list extended (Named)	51.27
ipv6 access-list standard (Named)	51.31
mac access-group	51.32
maximum-access-list	51.33
show interface access-group	51.34
show access-list	51.35
show ip access-list	51.37
show ip prefix-list	51.38
show ipv6 access-list	51.39

Command List

This chapter provides an alphabetical reference for the Access Control List (ACL) commands.

To apply ACLs to an LACP channel group, apply it to all the individual switch ports in the channel group. To apply ACLs to a static channel group, apply it to the static channel group itself. For more information on link aggregation see, “[Channel Groups \(Link Aggregation\)](#)” on [page 14.11](#), [Chapter 20, Link Aggregation Configuration](#), and [Chapter 21, Link Aggregation Commands](#).

access-list (extended)

This command configures an access list for filtering IP software packets. Packets must match both the source and the destination details. The no form removes a specified access list.

Syntax

```
access-list {<100-199>|<2000-2699>} {deny|permit} ip <source>
<destination>

no access-list {<100-199>|<2000-2699>}{deny|permit} ip <source>
<destination>
```

Parameter	Description						
<100-199>	IP extended access list.						
<2000-2699>	IP extended access list (expanded range).						
deny	Access-list rejects packets that match the source and destination filtering specified with this command.						
permit	Access-list permits packets that match the source and destination filtering specified with this command.						
<source>	The source address contained within the packets. You can specify either a subnet, a host, or all sources. You can use any of the following formats to specify the source: <table> <tr> <td>any</td><td>Filters packets with any source address.</td></tr> <tr> <td>host <ip-addr></td><td>Filters packets matching a specific source IP address.</td></tr> <tr> <td><ip-addr> <reverse-mask></td><td>An IPv4 address, followed by space then a reverse mask in dotted decimal format. Example: To filter on the address component A.B.C of the address A.B.C.D, you would enter A.B.C.D 0.0.0.255.</td></tr> </table>	any	Filters packets with any source address.	host <ip-addr>	Filters packets matching a specific source IP address.	<ip-addr> <reverse-mask>	An IPv4 address, followed by space then a reverse mask in dotted decimal format. Example: To filter on the address component A.B.C of the address A.B.C.D, you would enter A.B.C.D 0.0.0.255.
any	Filters packets with any source address.						
host <ip-addr>	Filters packets matching a specific source IP address.						
<ip-addr> <reverse-mask>	An IPv4 address, followed by space then a reverse mask in dotted decimal format. Example: To filter on the address component A.B.C of the address A.B.C.D, you would enter A.B.C.D 0.0.0.255.						
<destination>	The destination address contained within the packets. You can specify either a subnet, a host, or all destinations. The following are the valid formats to specify the destination: <table> <tr> <td>any</td><td>Filters packets with any destination address.</td></tr> <tr> <td>host <ip-addr></td><td>Filters packets matching a specific destination address.</td></tr> <tr> <td><ip-addr> <reverse-mask></td><td>An IPv4 address, followed by space then a reverse mask in dotted decimal format. For example, to filter on the address component A.B.C of the address A.B.C.D you would enter A.B.C.D 0.0.0.255.</td></tr> </table>	any	Filters packets with any destination address.	host <ip-addr>	Filters packets matching a specific destination address.	<ip-addr> <reverse-mask>	An IPv4 address, followed by space then a reverse mask in dotted decimal format. For example, to filter on the address component A.B.C of the address A.B.C.D you would enter A.B.C.D 0.0.0.255.
any	Filters packets with any destination address.						
host <ip-addr>	Filters packets matching a specific destination address.						
<ip-addr> <reverse-mask>	An IPv4 address, followed by space then a reverse mask in dotted decimal format. For example, to filter on the address component A.B.C of the address A.B.C.D you would enter A.B.C.D 0.0.0.255.						

Mode Global Configuration

Related Commands [show running-config](#)
[show ip access-list](#)

access-list (standard)

This command configures a standard IP access list for filtering within specific applications.

The no form removes the specified access-list..

Syntax `access-list {<1-99>|<1300-1999>} {deny|permit} <source>`
`no access-list {<1-99>|<1300-1999>} {deny|permit} <source>`

Parameter	Description
<1-99>	IP standard access list.
<1300-1999>	IP standard access list (expanded range).
deny	Access-list rejects packets from the specified source.
permit	Access-list accepts packets from the specified source.
<source>	The source address of the packets. You can specify either a subnet, a host, or all sources. The following are the valid formats to specify the source:
any	Filters packets with any source address.
host <ip-addr>	Filters packets matching a specific source address.
<ip-addr> <reverse-mask>	An IPv4 address, followed by space then a reverse mask in dotted decimal format. Example: To filter on the address component A.B.C of the address A.B.C.D, you would enter A.B.C.D 0.0.0.255.

Mode Global Configuration

Example

```
awplus# configure terminal
awplus(config)# access-list 67 deny 172.16.10.0 0.0.0.255
awplus(config-if)# access-list 1332 permit any
```

Related Commands [show running-config](#)
[show ip access-list](#)

access-list (IP)

This command configures an IP access list for filtering IP hardware packets, ICMP packets, TCP packets, UDP packets, or IANA defined IP protocols.

The no form removes the previously specified IP hardware access list.

Syntax
[icmp|ip] access-list <3000-3699>
 {copy-to-cpu | copy-to-mirror | send-to-mirror | deny | permit | send-to-cpu}
 {icmp | ip}
 {<source> | any | host} {<destination> | any | host}
 [icmp-type <type-number>]
 [vlan <1-4094>]
 no access-list <3000-3699>

Parameter	Description				
<3000-3699>	Hardware IP access list				
copy-to-cpu	Specify packets to copy to the CPU.				
copy-to-mirror	Specify packets to copy to the mirror port.				
send-to-mirror	Specify packets to send to the mirror port				
deny	Access-list rejects packets that match the source and destination filtering specified with this command.				
permit	Access-list permits packets that match the source and destination filtering specified with this command.				
send-to-cpu	Specify packets to send to the CPU.				
icmp	ICMP packet.				
ip	IP packet.				
<source>	The source address of the packets. You can specify either a host address or a subnet. The following are the valid formats to specify the source: <table border="0"> <tr> <td><ip-addr>/<prefix></td><td>An IPv4 address, followed by a forward slash, then the prefix length. This matches any source IP address within the specified subnet.</td></tr> <tr> <td><ip-addr><reverse-mask></td><td>Alternatively, you can enter a reverse mask in dotted decimal format. For example entering A.B.C.D 0.0.0.255 is the same as entering A.B.C.D/24.</td></tr> </table>	<ip-addr>/<prefix>	An IPv4 address, followed by a forward slash, then the prefix length. This matches any source IP address within the specified subnet.	<ip-addr><reverse-mask>	Alternatively, you can enter a reverse mask in dotted decimal format. For example entering A.B.C.D 0.0.0.255 is the same as entering A.B.C.D/24.
<ip-addr>/<prefix>	An IPv4 address, followed by a forward slash, then the prefix length. This matches any source IP address within the specified subnet.				
<ip-addr><reverse-mask>	Alternatively, you can enter a reverse mask in dotted decimal format. For example entering A.B.C.D 0.0.0.255 is the same as entering A.B.C.D/24.				
any	Any source host.				
host	A single source host.				

Parameter(Continue	Description(Continued)																										
<destination>	The destination address of the packets. You can specify either a host address or a subnet. The following are the valid formats to specify the source: <table> <tr> <td><ip-addr>/ <prefix></td><td>An IPv4 address, followed by a forward slash, then the prefix length. This matches any destination IP address within the specified subnet.</td></tr> <tr> <td><ip-addr> <reverse-mask></td><td>Alternatively, you can enter a reverse mask in dotted decimal format. For example entering A.B.C.D 0.0.0.255 is the same as entering A.B.C.D/24.</td></tr> </table>	<ip-addr>/ <prefix>	An IPv4 address, followed by a forward slash, then the prefix length. This matches any destination IP address within the specified subnet.	<ip-addr> <reverse-mask>	Alternatively, you can enter a reverse mask in dotted decimal format. For example entering A.B.C.D 0.0.0.255 is the same as entering A.B.C.D/24.																						
<ip-addr>/ <prefix>	An IPv4 address, followed by a forward slash, then the prefix length. This matches any destination IP address within the specified subnet.																										
<ip-addr> <reverse-mask>	Alternatively, you can enter a reverse mask in dotted decimal format. For example entering A.B.C.D 0.0.0.255 is the same as entering A.B.C.D/24.																										
icmp-type	Matches only a specified type of ICMP messages. This is valid only when the filtering is set to match ICMP packets.																										
<type-number>	The ICMP type, as defined in RFC792 and RFC950. Specify one of the following integers to create a filter for the ICMP message type: <table> <tr><td>0</td><td>Echo replies.</td></tr> <tr><td>3</td><td>Destination unreachable messages.</td></tr> <tr><td>4</td><td>Source quench messages.</td></tr> <tr><td>5</td><td>Redirect (change route) messages.</td></tr> <tr><td>8</td><td>Echo requests.</td></tr> <tr><td>11</td><td>Time exceeded messages.</td></tr> <tr><td>12</td><td>Parameter problem messages.</td></tr> <tr><td>13</td><td>Timestamp requests.</td></tr> <tr><td>14</td><td>Timestamp replies.</td></tr> <tr><td>15</td><td>Information requests.</td></tr> <tr><td>16</td><td>Information replies.</td></tr> <tr><td>17</td><td>Address mask requests.</td></tr> <tr><td>18</td><td>Address mask replies.</td></tr> </table>	0	Echo replies.	3	Destination unreachable messages.	4	Source quench messages.	5	Redirect (change route) messages.	8	Echo requests.	11	Time exceeded messages.	12	Parameter problem messages.	13	Timestamp requests.	14	Timestamp replies.	15	Information requests.	16	Information replies.	17	Address mask requests.	18	Address mask replies.
0	Echo replies.																										
3	Destination unreachable messages.																										
4	Source quench messages.																										
5	Redirect (change route) messages.																										
8	Echo requests.																										
11	Time exceeded messages.																										
12	Parameter problem messages.																										
13	Timestamp requests.																										
14	Timestamp replies.																										
15	Information requests.																										
16	Information replies.																										
17	Address mask requests.																										
18	Address mask replies.																										
any	Any destination host.																										
host	A single destination host.																										
vlan	This optional parameter can be used in either single or double-tagged VLAN networks. It is the conventional VLAN tag (VID). In a double-tagged network it is sometimes referred to as the STAG.																										
<1-4094>	VLAN ID																										

Syntax **[tcp|udp]** access-list <3000-3699>
 {copy-to-cpu|copy-to-mirror|send-to-mirror|deny|permit|send-to-cpu}
 {tcp|udp} <source>
 {eq|lt|gt|ne} <sourceport> <destination> {eq|lt|gt|ne}
 <destport>
 [range <0-65535> <0-65535>]
 no access-list <3000-3699>

Parameter	Description								
<3000-3699>	Hardware IP access list								
copy-to-cpu	Specify packets to copy to the CPU.								
copy-to-mirror	Specify packets to copy to the mirror port.								
send-to-mirror	Specify packets to send to the mirror port								
deny	The access-list rejects packets that match the type, source, and destination filtering specified with this command.								
permit	The access-list permits packets that match the type, source, and destination filtering specified with this command.								
send-to-cpu	Specify packets to send to the CPU.								
tcp	The access-list matches only TCP packets.								
udp	The access-list matches only UDP packet.								
<source>	The source address of the packets. You can specify either a subnet or all sources. The following are the valid formats for specifying the source: <table> <tr> <td><ip-addr>/<prefix></td><td>An IPv4 address, followed by a forward slash, then the prefix length. This matches any source IP address within the specified subnet.</td></tr> <tr> <td><ip-addr> <reverse-mask></td><td>Alternatively, you can enter a reverse mask in dotted decimal format. For example entering A.B.C.D 0.0.0.255 is the same as entering A.B.C.D/24.</td></tr> <tr> <td>any</td><td>Matches any source IP address.</td></tr> <tr> <td>host</td><td>Matches any source IP host.</td></tr> </table>	<ip-addr>/<prefix>	An IPv4 address, followed by a forward slash, then the prefix length. This matches any source IP address within the specified subnet.	<ip-addr> <reverse-mask>	Alternatively, you can enter a reverse mask in dotted decimal format. For example entering A.B.C.D 0.0.0.255 is the same as entering A.B.C.D/24.	any	Matches any source IP address.	host	Matches any source IP host.
<ip-addr>/<prefix>	An IPv4 address, followed by a forward slash, then the prefix length. This matches any source IP address within the specified subnet.								
<ip-addr> <reverse-mask>	Alternatively, you can enter a reverse mask in dotted decimal format. For example entering A.B.C.D 0.0.0.255 is the same as entering A.B.C.D/24.								
any	Matches any source IP address.								
host	Matches any source IP host.								
<sourceport>	The source (TCP or UDP) port number, specified as an integer between 0 and 65535.								
<destination>	The destination address of the packets. You can specify either a subnet or all destinations. The following are the valid formats for specifying the destination: <table> <tr> <td><ip-addr>/<prefix></td><td>An IPv4 address, followed by a forward slash, then the prefix length. This matches any source IP address within the specified subnet.</td></tr> <tr> <td><ip-addr> <reverse-mask></td><td>Alternatively, you can enter a reverse mask in dotted decimal format. For example entering A.B.C.D 0.0.0.255 is the same as entering A.B.C.D/24.</td></tr> <tr> <td>any</td><td>Matches any destination IP address.</td></tr> </table>	<ip-addr>/<prefix>	An IPv4 address, followed by a forward slash, then the prefix length. This matches any source IP address within the specified subnet.	<ip-addr> <reverse-mask>	Alternatively, you can enter a reverse mask in dotted decimal format. For example entering A.B.C.D 0.0.0.255 is the same as entering A.B.C.D/24.	any	Matches any destination IP address.		
<ip-addr>/<prefix>	An IPv4 address, followed by a forward slash, then the prefix length. This matches any source IP address within the specified subnet.								
<ip-addr> <reverse-mask>	Alternatively, you can enter a reverse mask in dotted decimal format. For example entering A.B.C.D 0.0.0.255 is the same as entering A.B.C.D/24.								
any	Matches any destination IP address.								

Parameter(Continu	Description(Continued)
<destport>	The destination (TCP or UDP) port number, specified as an integer between 0 and 65535.
eq	Matches port numbers that are equal to the port number specified immediately after this parameter.
lt	Matches port numbers that are less than the port number specified immediately after this parameter.
gt	Matches port numbers that are greater than the port number specified immediately after this parameter.
ne	Matches port numbers that are not equal to the port number specified immediately after this parameter.
range	Range of port numbers (optional)
<0-65535>	Port number at start of range
<0-65535>	Port number at end of range

Syntax `access-list <3000-3699>`
[proto] `{copy-to-cpu|copy-to-mirror|send-to-mirror|deny|permit|send-to-cpu}`
`{proto <ip-protocol>}`
`{<source>|any|host}{<destination>|any|host}`
`no access-list <3000-3699>`

Parameter	Description
<3000-3699>	Hardware IP access list
copy-to-cpu	Specify packets to copy to the CPU.
copy-to-mirror	Specify packets to copy to the mirror port.
send-to-mirror	Specify packets to send to the mirror port
deny	Access-list rejects packets that match the source and destination filtering specified with this command.
permit	Access-list permits packets that match the source and destination filtering specified with this command.
send-to-cpu	Specify packets to send to the CPU.
<source>	The source address of the packets. You can specify either a subnet, a host, or all sources. The following are the valid formats to specify the source:
any	Filters packets with any source address.
host <ip-addr>	Filters packets matching a specific source address.
<ip-addr>/<prefix>	An IPv4 address, followed by a forward slash, then the prefix length. This matches any source IP address within the specified subnet.
<ip-addr> <reverse-mask>	Alternatively, you can enter a reverse mask in dotted decimal format. For example entering A.B.C.D 0.0.0.255 is the same as entering A.B.C.D/24.
any	Any source host.
host	A single source host.
<destination>	The destination of the packets. You can specify either a subnet, a host, or all destinations. The following are valid formats to specify the destination:
any	Filters packets with any destination address.
host <ip-addr>	Filters packets matching a specific destination address.
<ip-addr>/<prefix>	An IPv4 address, followed by a forward slash, then the prefix length. This matches any source IP address within the specified subnet.
<ip-addr> <reverse-mask>	Alternatively, you can enter a reverse mask in dotted decimal format. For example entering A.B.C.D 0.0.0.255 is the same as entering A.B.C.D/24.
proto	Matches only a specified type of IP Protocol.

Parameter(Continued)	Description(Continued)
<code><ip-protocol></code>	The IP protocol number, as defined by IANA (Internet Assigned Numbers Authority www.iana.org ref: http://www.iana.org/assignments/protocol-numbers)
Protocol Number	Protocol Description [RFC Reference]
1	Internet Control Message [RFC792]
2	Internet Group Management [RFC1112]
3	Gateway-to-Gateway [RFC823]
4	IP in IP [RFC2003]
5	Stream [RFC1190] [RFC1819]
6	TCP (Transmission Control Protocol) [RFC793]
8	EGP (Exterior Gateway Protocol) [RFC888]
9	IGP (Interior Gateway Protocol) [IANA]
11	Network Voice Protocol [RFC741]
17	UDP (User Datagram Protocol) [RFC768]
20	Host monitoring [RFC869]
27	RDP (Reliable Data Protocol) [RFC908]
28	IRTP (Internet Reliable Transaction Protocol) [RFC938]
29	ISO-TP4 (ISO Transport Protocol Class 4) [RFC905]
30	Bulk Data Transfer Protocol [RFC969]
33	DCCP (Datagram Congestion Control Protocol) [RFC4340]
48	DSR (Dynamic Source Routing Protocol) [RFC4728]
50	ESP (Encap Security Payload) [RFC2406]
51	AH (Authentication Header) [RFC2402]
54	NARP (NBMA Address Resolution Protocol) [RFC1735]
58	ICMP for IPv6 [RFC1883]
59	No Next Header for IPv6 [RFC1883]
60	Destination Options for IPv6 [RFC1883]
88	EIGRP (Enhanced Interior Gateway Routing Protocol)
89	OSPFv2 [RFC1583]
97	Ethernet-within-IP Encapsulation / RFC3378

Parameter(Continued)	Description(Continued)
<ip-protocol> (cont.)	98 Encapsulation Header / RFC1241
	108 IP Payload Compression Protocol / RFC2393
	112 Virtual Router Redundancy Protocol / RFC3768
	134 RSVP-E2E-IGNORE / RFC3175
	135 Mobility Header / RFC3775
	136 UDPLite / RFC3828
	137 MPLS-in-IP / RFC4023
	138 MANET Protocols / RFC-ietf-manet-iana-07.txt
	139-252 Unassigned / IANA
	253 Use for experimentation and testing / RFC3692
	254 Use for experimentation and testing / RFC3692
	255 Reserved / IANA
any	Any destination host.
host	A single destination host.

Mode Global Configuration

Usage This command creates an access list for use with hardware classification, such as when applying QoS. This command can be used to match ICMP packets, IP protocols, or TCP/UDP packets.

For ICMP packets, the <3000-3699> range IP hardware access-list will match any ICMP packet that has the specified source and destination IP addresses and ICMP type.

You may apply the any parameter if the source or destination IP address is not important. The ICMP type is an optional parameter.

Examples Follow the below example commands to configure access-lists for ICMP, IP protocol and TCP.

ICMP To create an access list that will permit ICMP packets with a source address of 192.168.1.0/24 with any destination address and an ICMP type of 5 issue the below example commands:

```
awplus# configure terminal
```

```
awplus(config)# access-list 3000 permit icmp 192.168.1.0/24
any icmp-type 5
```

To destroy the access list with an access list identity of 3000 issue the below example commands:

```
awplus# configure terminal
```

```
awplus(config)# no access-list 3000
```

IP protocol To create an access list that will permit any type of IP packet with a source address of 192.168.1.1 and any destination address, issue the example commands:

```
awplus# configure terminal
awplus(config)# access-list 3000 permit ip 192.168.1.1/32 any
```

To create an access list that will deny all IGMP packets (IP protocol 2) from the 192.168.0.0 network, issue the example commands:

```
awplus# configure terminal
awplus(config)# access-list 3000 deny proto 2 192.168.0.0/16
any
```

TCP To create an access list that will permit TCP packets with a destination address of 192.168.1.1, a destination port of 80 and any source address and source port, issue the example commands:

```
awplus# configure terminal
awplus(config)# access-list 3000 permit tcp any 192.168.1.1/32
eq 80
```

Related Commands [show running-config](#)
[show ip access-list](#)

access-list (MAC)

This command configures an IP access list for filtering on hardware MAC addresses.

The no form removes the specified MAC hardware filter access list.

Syntax

```
access-list <4000-4699>
    {copy-to-cpu|copy-to-mirror|deny|permit|send-to-cpu}
    {<source-mac-address> <source-mac-mask>|any}
    {<destination-mac-address> <destination-mac-mask>|any}
    [vlan <1-4094> [inner-vlan <1-4094>]]

no access-list <4000-4699>
```

Parameter	Description
<4000-4699>	Hardware MAC access list
copy-to-cpu	Specify packets to copy to the CPU.
copy-to-mirror	Specify packets to copy to the mirror port.
deny	Access-list rejects packets that match the source and destination filtering.
permit	Access-list permits packets that match the source and destination filtering.
send-to-cpu	Specify packets to send to the CPU.
<source-mac-address>	The source MAC address of the packets. Enter this in the format <HHHH.HHHH.HHHH> Where each H is a hexadecimal number that represents a 4 bit binary number.
<source-mac-mask>	The mask that will be applied to the source MAC addresses. Enter this in the format <HHHH.HHHH.HHHH> Where each H is a hexadecimal number that represents a 4 bit binary number. For a mask, each value will be either 0 or F
any	Any source MAC host
<destination-mac-address>	The destination MAC address of the packets. Enter this in the format <HHHH.HHHH.HHHH> Where each H is a hexadecimal number that represents a 4 bit binary number.
<destination-mac-mask>	The mask that will be applied to the destination MAC addresses. Enter this in the format <HHHH.HHHH.HHHH> Where each H is a hexadecimal number that represents a 4 bit binary number. For a mask, each value will be either 0 or F
any	Any destination MAC host
vlan	This optional parameter can be used in either single or double-tagged VLAN networks. It is the conventional VLAN tag (VID). In a double-tagged network it is sometimes referred to as the STAG.
inner-vlan	This optional parameter is used within double-tagged VLANs. It is the inner VLAN tag (VID); sometimes referred to as the CTAG.
<1-4094>	VLAN ID

Mode Global Configuration

Usage This command creates an access list for use with hardware classification, such as when applying QoS. The <4000-4699> range MAC hardware access list will match on packets that have the specified source and destination MAC addresses. You may apply the **any** parameter if the source or destination MAC host address is not important.

Example To create an access list that will permit packets with a MAC address of 0000.00ab.1234 and any destination address issue the below example commands:

```
awplus# configure terminal
```

```
awplus(config)# access-list 4000 permit 0000.00ab.1234  
0000.0000.0000 any
```

To create an access list that will permit packets with an initial MAC address component of 0000.00ab and any destination address, issue the below example commands:

```
awplus# configure terminal
```

```
awplus(config)# access-list 4001 permit 0000.00ab.1234  
0000.0000.FFFF any
```

To destroy the access list with an access list identity of 4000 issue the below example commands:

```
awplus# configure terminal
```

```
awplus(config)# no access-list 4000
```

Related Commands [show running-config](#)
[show ip access-list](#)

access-list extended (named)

This command configures an access list for filtering frames that permit or deny IP, ICMP, TCP, UDP packets or ICMP packets with a specific value based on the source or destination.

Use access lists to control the transmission of packets on an interface, and restrict the content of routing updates. The switch stops checking the access list when a match is encountered.

The no form removes a specified access-list.

Syntax
[any|icmp|ip] access-list extended <list-name> {deny|permit} {any|icmp|ip} <source>
 <destination> [icmp-type <type-number>] [log]
 no access-list extended <list-name> {deny|permit} {any|icmp|ip}
 <source> <destination> [icmp-type <type-number>] [log]

Parameter	Description						
<list-name>	A user-defined name for the access-list.						
deny	The access-list rejects packets that match the type, source, and destination filtering specified with this command.						
permit	The access-list permits packets that match the type, source, and destination filtering specified with this command.						
any	The access-list matches any type of packet.						
ip	The access-list matches only IP packets.						
icmp	The access-list matches only ICMP packets.						
<source>	The source address of the packets. You can specify either a subnet or all sources. The following are the valid formats for specifying the source: <table> <tr> <td><ip-addr>/ <prefix></td><td>An IPv4 address, followed by a forward slash, then the prefix length. This matches any source IP address within the specified subnet.</td></tr> <tr> <td><ip-addr> <reverse-mask></td><td>Alternatively, you can also a reverse mask in dotted decimal format. Entering A.B.C.D 0.0.0.255 is the same as entering A.B.C.D/24.</td></tr> <tr> <td>any</td><td>Matches any source IP address.</td></tr> </table>	<ip-addr>/ <prefix>	An IPv4 address, followed by a forward slash, then the prefix length. This matches any source IP address within the specified subnet.	<ip-addr> <reverse-mask>	Alternatively, you can also a reverse mask in dotted decimal format. Entering A.B.C.D 0.0.0.255 is the same as entering A.B.C.D/24.	any	Matches any source IP address.
<ip-addr>/ <prefix>	An IPv4 address, followed by a forward slash, then the prefix length. This matches any source IP address within the specified subnet.						
<ip-addr> <reverse-mask>	Alternatively, you can also a reverse mask in dotted decimal format. Entering A.B.C.D 0.0.0.255 is the same as entering A.B.C.D/24.						
any	Matches any source IP address.						
<destination>	The destination address of the packets. You can specify either a subnet or all destinations. The following are the valid formats for specifying the destination: <table> <tr> <td><ip-addr>/ <prefix> or <ip-addr> <reverse-mask></td><td>An IPv4 address, followed by a forward slash, then the prefix length. This matches any destination IP address within the specified subnet. Alternatively, you can also a reverse mask in dotted decimal format. Therefore, entering A.B.C.D/24 is the same as entering A.B.C.D 0.0.0.255.</td></tr> <tr> <td>any</td><td>Matches any destination IP address.</td></tr> </table>	<ip-addr>/ <prefix> or <ip-addr> <reverse-mask>	An IPv4 address, followed by a forward slash, then the prefix length. This matches any destination IP address within the specified subnet. Alternatively, you can also a reverse mask in dotted decimal format. Therefore, entering A.B.C.D/24 is the same as entering A.B.C.D 0.0.0.255.	any	Matches any destination IP address.		
<ip-addr>/ <prefix> or <ip-addr> <reverse-mask>	An IPv4 address, followed by a forward slash, then the prefix length. This matches any destination IP address within the specified subnet. Alternatively, you can also a reverse mask in dotted decimal format. Therefore, entering A.B.C.D/24 is the same as entering A.B.C.D 0.0.0.255.						
any	Matches any destination IP address.						
icmp-type	Matches only a specified type of ICMP messages. This is valid only when the filtering is set to match ICMP packets.						

Parameter(Continu	Description(Continued)
<code><type-number></code>	The ICMP type, as defined in RFC792 and RFC950. Specify one of the following integers to create a filter for the ICMP message type:
0	Echo replies.
3	Destination unreachable messages.
4	Source quench messages.
5	Redirect (change route) messages.
8	Echo requests.
11	Time exceeded messages.
12	Parameter problem messages.
13	Timestamp requests.
14	Timestamp replies.
15	Information requests.
16	Information replies.
17	Address mask requests.
18	Address mask replies.
log	Logs the results.

Syntax
[tcp|udp]

```
access-list extended <list-name> {deny|permit} {tcp|udp} <source>
    {eq|lt|gt|ne} <source> <destination> {eq|lt|gt|ne} <destport>
    [log]

no access-list extended <list-name> {deny|permit} {tcp|udp} <source>
    {eq|lt|gt|ne} <sourceport> <destination> {eq|lt|gt|ne} <destport>
    [log]
```

Parameter	Description				
<list-name>	A user-defined name for the access-list.				
deny	The access-list rejects packets that match the type, source, and destination filtering specified with this command.				
permit	The access-list permits packets that match the type, source, and destination filtering specified with this command.				
tcp	The access-list matches only TCP packets.				
udp	The access-list matches only UDP packet.				
<source>	The source address of the packets. You can specify either a subnet or all sources. The following are the valid formats for specifying the source: <table> <tr> <td><ip-addr>/<reverse-mask></td><td>An IPv4 address, followed by a forward slash, then the prefix length. This matches any source IP address within the specified subnet. Note that the term reverse-mask is sometimes referred to as a wildcard mask.</td></tr> <tr> <td>any</td><td>Matches any source IP address.</td></tr> </table>	<ip-addr>/<reverse-mask>	An IPv4 address, followed by a forward slash, then the prefix length. This matches any source IP address within the specified subnet. Note that the term reverse-mask is sometimes referred to as a wildcard mask.	any	Matches any source IP address.
<ip-addr>/<reverse-mask>	An IPv4 address, followed by a forward slash, then the prefix length. This matches any source IP address within the specified subnet. Note that the term reverse-mask is sometimes referred to as a wildcard mask.				
any	Matches any source IP address.				
<sourceport>	The source port number, specified as an integer between 0 and 65535.				
<destination>	The destination address of the packets. You can specify either a subnet or all destinations. The following are the valid formats for specifying the destination: <table> <tr> <td><ip-addr>/<prefix> or <ip-addr> <reverse-mask></td><td>An IPv4 address, followed by a forward slash, then the prefix length. This matches any destination IP address within the specified subnet. Alternatively, you can also a reverse mask in dotted decimal format. Therefore, entering A.B.C.D/24 is the same as entering A.B.C.D 0.0.0.255.</td></tr> <tr> <td>any</td><td>Matches any destination IP address.</td></tr> </table>	<ip-addr>/<prefix> or <ip-addr> <reverse-mask>	An IPv4 address, followed by a forward slash, then the prefix length. This matches any destination IP address within the specified subnet. Alternatively, you can also a reverse mask in dotted decimal format. Therefore, entering A.B.C.D/24 is the same as entering A.B.C.D 0.0.0.255.	any	Matches any destination IP address.
<ip-addr>/<prefix> or <ip-addr> <reverse-mask>	An IPv4 address, followed by a forward slash, then the prefix length. This matches any destination IP address within the specified subnet. Alternatively, you can also a reverse mask in dotted decimal format. Therefore, entering A.B.C.D/24 is the same as entering A.B.C.D 0.0.0.255.				
any	Matches any destination IP address.				
<destport>	The destination port number, specified as an integer between 0 and 65535.				
eq	Matches port numbers equal to the port number specified immediately after this parameter.				
lt	Matches port numbers less than the port number specified immediately after this parameter.				
gt	Matches port numbers greater than the port number specified immediately after this parameter.				
ne	Matches port numbers not equal to the port number specified immediately after this parameter.				
log	Log the results.				

Syntax
[proto]

```
access-list extended <list-name> {deny|permit}
    {proto <ip-protocol>}
    {<source>|any} {<destination>|any} [log]

no access-list extended <list-name> {deny|permit}
    {proto <ip-protocol>}
    {<source>|any} {<destination>|any} [log]
```

Parameter	Description														
<i><list-name></i>	A user-defined name for the access-list.														
deny	The access-list rejects packets that match the type, source, and destination filtering specified with this command.														
permit	The access-list permits packets that match the type, source, and destination filtering specified with this command.														
any	The access-list matches any type of packet.														
<i><source></i>	The source address of the packets. You can specify either a subnet or all sources. The following are the valid formats for specifying the source: <table> <tr> <td><i><ip-addr>/<reverse-mask></i></td><td>An IPv4 address, followed by a forward slash, then the prefix length. This matches any source IP address within the specified subnet.</td></tr> <tr> <td>any</td><td>Matches any source IP address.</td></tr> </table>	<i><ip-addr>/<reverse-mask></i>	An IPv4 address, followed by a forward slash, then the prefix length. This matches any source IP address within the specified subnet.	any	Matches any source IP address.										
<i><ip-addr>/<reverse-mask></i>	An IPv4 address, followed by a forward slash, then the prefix length. This matches any source IP address within the specified subnet.														
any	Matches any source IP address.														
<i><destination></i>	The destination address of the packets. You can specify either a subnet or all destinations. The following are the valid formats for specifying the destination: <table> <tr> <td><i><ip-addr>/<reverse-mask></i></td><td>An IPv4 address, followed by a forward slash, then the prefix length. This matches any destination IP address within the specified subnet.</td></tr> <tr> <td>any</td><td>Matches any destination IP address.</td></tr> </table>	<i><ip-addr>/<reverse-mask></i>	An IPv4 address, followed by a forward slash, then the prefix length. This matches any destination IP address within the specified subnet.	any	Matches any destination IP address.										
<i><ip-addr>/<reverse-mask></i>	An IPv4 address, followed by a forward slash, then the prefix length. This matches any destination IP address within the specified subnet.														
any	Matches any destination IP address.														
log	Logs the results.														
proto	Matches only a specified type of IP Protocol.														
<i><ip-protocol></i>	The IP protocol number, as defined by IANA (Internet Assigned Numbers Authority www.iana.org ref: http://www.iana.org/assignments/protocol-numbers) <table> <tr> <th>Protocol Number</th><th>Protocol Description [RFC Reference]</th></tr> <tr> <td>1</td><td>Internet Control Message [RFC792]</td></tr> <tr> <td>2</td><td>Internet Group Management [RFC1112]</td></tr> <tr> <td>3</td><td>Gateway-to-Gateway [RFC823]</td></tr> <tr> <td>4</td><td>IP in IP [RFC2003]</td></tr> <tr> <td>5</td><td>Stream [RFC1190] [RFC1819]</td></tr> <tr> <td>6</td><td>TCP (Transmission Control Protocol) [RFC793]</td></tr> </table>	Protocol Number	Protocol Description [RFC Reference]	1	Internet Control Message [RFC792]	2	Internet Group Management [RFC1112]	3	Gateway-to-Gateway [RFC823]	4	IP in IP [RFC2003]	5	Stream [RFC1190] [RFC1819]	6	TCP (Transmission Control Protocol) [RFC793]
Protocol Number	Protocol Description [RFC Reference]														
1	Internet Control Message [RFC792]														
2	Internet Group Management [RFC1112]														
3	Gateway-to-Gateway [RFC823]														
4	IP in IP [RFC2003]														
5	Stream [RFC1190] [RFC1819]														
6	TCP (Transmission Control Protocol) [RFC793]														

Parameter(Continued)	Description(Continued)	
<code><ip-protocol></code> (cont.)	Protocol Number	Protocol Description [RFC Reference]
	8	EGP (Exterior Gateway Protocol) [RFC888]
	9	IGP (Interior Gateway Protocol) [IANA]
	11	Network Voice Protocol [RFC741]
	17	UDP (User Datagram Protocol) [RFC768]
	20	Host monitoring [RFC869]
	27	RDP (Reliable Data Protocol) [RFC908]
	28	IRTP (Internet Reliable Transaction Protocol) [RFC938]
	29	ISO-TP4 (ISO Transport Protocol Class 4) [RFC905]
	30	Bulk Data Transfer Protocol [RFC969]
	33	Datagram Congestion Control Protocol [RFC4340]
	48	DSR (Dynamic Source Routing Protocol) [RFC4728]
	50	ESP (Encap Security Payload) [RFC2406]
	51	AH (Authentication Header) [RFC2402]
	54	NARP (NBMA Address Resolution Protocol) [RFC1735]
	58	ICMP for IPv6 [RFC1883]
	59	No Next Header for IPv6 [RFC1883]
	60	Destination Options for IPv6 [RFC1883]
	88	EIGRP (Enhanced Interior Gateway Routing Protocol)
	89	OSPFv2 [RFC1583]
	97	Ethernet-within-IP Encapsulation / RFC3378
	98	Encapsulation Header / RFC1241
	108	IP Payload Compression Protocol / RFC2393
	112	Virtual Router Redundancy Protocol / RFC3768
	134	RSVP-E2E-IGNORE / RFC3175
	135	Mobility Header / RFC3775
	136	UDPLite / RFC3828
	137	MPLS-in-IP / RFC4023

Parameter(Continued)	Description(Continued)	
<i><ip-protocol></i> (cont.)	Protocol Number	Protocol Description [RFC Reference]
	138	MANET Protocols / RFC-ietf-manet-iana-07.txt
	139-252	Unassigned / IANA
	Protocol Number	Protocol Description [RFC Reference]
	253	Use for experimentation and testing / RFC3692
	254	Use for experimentation and testing / RFC3692
	255	Reserved / IANA

Mode Global Configuration

Example

```
awplus# configure terminal
awplus(config)# access-list extended TK deny tcp 2.2.2.3/24 eq
14 3.3.3.4/24 lt 12 log
```

Related Commands [show running-config](#)
[show ip access-list](#)

access-list standard (named)

This command configures an access list for filtering frames that permit or deny packets from a specific source IP address.

The no form removes a specified access-list.

Syntax `access-list standard <list-name> {deny|permit} <source> [exact-match]`
`no access-list standard <list-name> {deny|permit} <source> [exact-match]`

Parameter	Description				
<list-name>	A user-defined name for the access-list.				
deny	The access-list rejects packets that match the type, source, and destination filtering specified with this command.				
permit	The access-list permits packets that match the type, source, and destination filtering specified with this command.				
<source>	The source address of the packets. You can specify either a subnet or all sources. The following are the valid formats for specifying the source: <table border="1"> <tr> <td><ip-addr>/<reverse-mask></td><td>An IPv4 address, followed by a forward slash, then the prefix length. This matches any source IP address within the specified subnet.</td></tr> <tr> <td>any</td><td>Matches any source IP address.</td></tr> </table>	<ip-addr>/<reverse-mask>	An IPv4 address, followed by a forward slash, then the prefix length. This matches any source IP address within the specified subnet.	any	Matches any source IP address.
<ip-addr>/<reverse-mask>	An IPv4 address, followed by a forward slash, then the prefix length. This matches any source IP address within the specified subnet.				
any	Matches any source IP address.				
exact-match	Exact match of the prefixes.				

Mode Global Configuration

Related Commands `show running-config`
`show ip access-list`

clear ip prefix-list

Use this command to reset the hit count to zero in the prefix-list entries.

Syntax `clear ip prefix-list [<list-name>] [<ip-addr>/<mask>]`

Parameter	Description
<list-name>	specify the name of the prefix-list
<ip-addr>/<mask>	specify the IP prefix and length

Mode Privileged Exec

Example To clear a prefix-list named List1:

```
awplus# clear ip prefix-list List1
```

dos

Configures Denial-of-Service (DoS) features for a port. Six different DoS attacks can be detected: IP Options, Land, Ping-of-Death, Smurf, Synflood and Teardrop.

When the attack is detected, two different actions are available:

1. Shutdown the port for one minute
2. Cause a SNMP trap.

Both of these options can be specified. Also, all monitored traffic can be sent to the mirror port.

Syntax `dos {ipoptions|land|ping-of-death|smurf broadcast <a.b.c.d>|synflood|teardrop} action{shutdown|trap|mirror}`

Parameter	Description
dos	Denial-Of-Service
ipoptions	IP Options attack
land	Land attack
ping-of-death	Large ping attack
smurf	Ping to broadcast address
broadcast	Broadcast
<a.b.c.d>	Local IP Broadcast Address
synflood	SYN flood attack
teardrop	IP fragmentation attack
action	Action
shutdown	Shutdown port
trap	trap to SNMP
mirror	Send packets to mirror port

Mode Interface Configuration

Usage See the below table for more information about the DoS attacks recognized by this command:

Type of DoS attack	Description
<code>ipoptions</code>	This type of attack occurs when an attacker sends packets containing bad IP options to a victim node. There are many different types of IP options attacks and this software does not try to distinguish between them. Rather, if this defence is activated, the number of ingress IP packets containing IP options is counted. If the number exceeds 20 packets per second, the switch considers this a possible IP options attack. This defence does not require the CPU to monitor packets, so does not put extra load on the switch's CPU.
<code>land</code>	This type of attack occurs when the Source IP and Destination IP address are the same. This can cause a target host to be confused. Since packets with the same source and destination addresses should never occur, these packets are dropped when this attack is enabled. This defence does not require the CPU to monitor packets, so does not put extra load on the switch's CPU.
<code>ping-of-death</code>	This type of attack results from a fragmented packet which, when reassembled, would exceed the maximum size of a valid IP datagram. To detect this attack, the final fragment of ICMP packets has to be sent to the CPU for inspection. This defence can therefore load the CPU. Note that the extra CPU load will not affect normal traffic switching between ports, but other protocols such as IGMP and STP may be affected. This defence is not recommended where a large number of fragmented packets are expected.
<code>smurf</code>	This type of attack is an ICMP ping packet to a broadcast address. Although routers should not forward packets to local broadcast addresses anymore (see RFC2644), the Smurf attack can still be explicitly discarded with this command. In order for the Smurf attack to work, the broadcast IP address is required. Any ICMP Ping packet with this destination address is considered an attack. This defence does not require the CPU to monitor packets, so does not put extra load on the switch's CPU.
<code>synflood</code>	In this type of attack, an attacker, seeking to overwhelm a victim with TCP connection requests, sends a large number of TCP SYN packets with bogus source addresses to the victim. The victim responds with SYN ACK packets, but since the original source addresses are bogus, the victim node does not receive any replies. If the attacker sends enough requests in a short enough period, the victim may freeze operations once the requests exceed the capacity of its connections queue. To defend against this form of attack, a switch port monitors the number of ingress TCP-SYN packets it receives. An attack is recorded if a port receives more 60 TCP-SYN packets per second.
<code>teardrop</code>	In this DoS attack, an attacker sends a packet in several fragments with a bogus offset value, used to reconstruct the packet, in one of the fragments to a victim. This results in the victim being unable to reassemble the packet, possibly causing it to freeze operations.

Examples To configure SMURF DoS detection on port 1.0.1, and shutdown the interface if an attack is detected, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1
awplus(config-if)# dos smurf broadcast 192.168.1.0 action
shutdown
```

To configure LAND DoS detection on port 1.0.1, and shutdown the interface if an attack is detected, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1
awplus(config-if)# dos land action shutdown
```

ip access-group

This command adds (or removes) an IP hardware-based access-list to an interface. The number of access-lists that can be added is determined by the amount of available space in the hardware-based packet classification tables.

Syntax `ip access-group <3000-3699>`
`no ip access-group <3000-3699>`

Parameter	Description
ip	IP Information
access-group	Used to apply an Access Control List, of the same number, to a port or range
<3000-3699>	Hardware IP access list
no	Negate a command or set its defaults

Mode Interface Configuration

Usage First create an IP access list that applies the appropriate permit, deny requirements etc. Then use the `ip access-group` command to apply this access list to a specific port or range. Note that this command will apply the access list only to *incoming* data packets.

To apply ACLs to an LACP aggregated link, apply it to all the individual switch ports in the aggregated group. To apply ACLs to a static channel group, apply it to the static channel group itself. Do not apply an ACL to a dynamic (LACP) or static aggregated link that spans more than one switch instance ([Chapter 21, Link Aggregation Commands](#)).

Example To add access-list 3005 to interface port1.0.1:

```
awplus# configure terminal
awplus(config)# interface port1.0.1
awplus(config-if)# ip access-group 3005
```

To apply an ACL to static channel group 2 containing switch ports 1.1.5 and 1.1.6, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.1.5-1.1.6
awplus(config-if)# static-channel-group 2
awplus(config)# interface sa2
awplus(config-if)# ip access-group 3000
```

Related Commands [show interface access-group](#)

ip prefix-list

Use this command to create an entry for a prefix list.
Use the no parameter with this command to delete the prefix-list entry.

Syntax

```
ip prefix-list <list-name> seq <1-429496725> {deny|permit}
{any|<ip-prefix>} [ge <0-32>] [le <0-32>]

no ip prefix-list <list-name> seq <1-429496725>

ip prefix-list <list-name> description <text>
no ip prefix-list <list-name> description <text>

ip prefix-list sequence-number
no ip prefix-list sequence-number
```

Parameter	Description
<list-name>	specifies the name of a prefix list
seq <1-429496725>	sequence number of the prefix list entry
deny	specifies that the prefixes are excluded from the list
permit	specifies that the prefixes are included in the list
<ip-prefix>	A.B.C.D/M specifies the IP address and length of the network mask
any	Any prefix match. Same as 0.0.0.0/0 le 32
le <0-32>	specifies the maximum prefix length to be matched
ge <0-32>	specifies the minimum prefix length to be matched
description <text>	text description of the prefix list

Mode Global Configuration

Usage When the device processes a prefix list, it starts to match prefixes from the top of the prefix list, and stops whenever a match or deny occurs. To promote efficiency, use the seq parameter and place common matches or denials towards the top of the list. If you do not use the seq parameter, the sequence values are generated in the sequence of 5.

The parameters ge and le specify the range of the prefix length to be matched. When setting these parameters, set the le value to be less than 32, and the ge value to be less than the le value.

Example In this configuration, the ip prefix-list command matches all, but denies the IP address range, 76.2.2.0

```
awplus(config)# router bgp 100
awplus(config-router)# network 172.1.1.0
awplus(config-router)# network 172.1.2.0
awplus(config-router)# neighbor 10.6.5.3 remote-as 300
awplus(config-router)# neighbor 10.6.5.3 prefix-list mylist out
awplus(config-router)# exit

awplus(config)# ip prefix-list mylist seq 5 deny
                        76.2.2.0/24

awplus(config)# ip prefix-list mylist seq 100 permit any
```

To deny the IP addresses between 10.0.0.0/14 (10.0.0.0 255.252.0.0) and 10.0.0.0/22 (10.0.0.0 255.255.252.0) within the 10.0.0.0/8 (10.0.0.0 255.0.0.0) addressing range:.

```
awplus# configure terminal

awplus(config)# ip prefix-list mylist seq 12345 deny 10.0.0.0/
                        8 le 22 ge 14
```

Related Commands [match ip address](#)
[neighbor prefix-list](#)
[match route-type](#)

ipv6 access-list extended (Named)

This command configures an IPv6 software extended access list for filtering frames that permit or deny IP, ICMP, TCP, UDP packets or ICMP packets with a specific value based on the source or destination.

Use IPv6 software extended access lists to control the transmission of IPv6 packets on an interface, and restrict the content of routing updates. The switch stops checking the software IPv6 extended access list when a match is encountered.

The no form removes a specified IPv6 software extended access-list.

Syntax [any|icmp|ip]

```
ipv6 access-list extended <list-name> {deny|permit} {any|icmp|ip}
    {<ipv6-source-addr/p>|<ipv6-source-addr> <ipv6-source-wildcard>|
    any} {<ipv6-dest-addr/p>|<ipv6-dest-addr> <ipv6-source-wildcard>|
    any} [<icmp-type <icmp-type>][log]
```

```
no ipv6 access-list extended <list-name> {deny|permit} {any|icmp|ip}
    {<ipv6-source-addr/p>|<ipv6-source-addr> <ipv6-source-wildcard>|
    any} {<ipv6-dest-addr/p>|<ipv6-dest-addr> <ipv6-source-wildcard>|
    any} [<icmp-type <icmp-type>][log]
```

Parameter	Description
<list-name>	A user-defined name for the IPv6 software extended access-list.
deny	The IPv6 software extended access-list rejects packets that match the type, source, and destination filtering specified with this command.
permit	The IPv6 software extended access-list permits packets that match the type, source, and destination filtering specified with this command.
any	The IPv6 software extended access-list matches any type of packet.
ip	The IPv6 software extended access-list matches only IP packets.
icmp	The IPv6 software extended access-list matches only ICMP packets.
<ipv6-source-addr/p>	Specifies a source address and prefix length. The IPv6 address prefix uses the format X:X::/prefix-length. The prefix-length is usually set between 0 and 64, or has the value 128.
<ipv6-source-addr>	Specifies the IPv6 source address. The IPv6 address uses the format X:X::X:X.
<ipv6-source-wildcard>	Specifies source wildcard bits in IPv6 format x:x::x:x. Note that binary 1 represents a don't care condition, and binary 0 represents a match.
any	Matches any source IPv6 address.

Parameter(Continued)	Description(Continued)																										
<i><ipv6-dest-prefix/ prefix-length></i>	Specifies a destination address and prefix length. The IPv6 address uses the format X:X::X:X/Prefix-Length. The prefix-length is usually set between 0 and 64, or has the value 128.																										
<i><ipv6-dest-addr></i>	Specifies a destination address. The IPv6 address uses the format X:X::X:X.																										
<i><ipv6-dest-wildcard></i>	Specify destination Wildcard bits in IPv6 format x:x::x:x																										
any	Matches any destination IPv6 address.																										
icmp-type	Matches only a specified type of ICMP messages. This is valid only when the filtering is set to match ICMP packets.																										
<i><type-number></i>	The ICMP type, as defined in RFC792 and RFC950. Specify one of the following integers to create a filter for the ICMP message type: <table> <tr> <td>0</td><td>Echo replies.</td></tr> <tr> <td>3</td><td>Destination unreachable messages.</td></tr> <tr> <td>4</td><td>Source quench messages.</td></tr> <tr> <td>5</td><td>Redirect (change route) messages.</td></tr> <tr> <td>8</td><td>Echo requests.</td></tr> <tr> <td>11</td><td>Time exceeded messages.</td></tr> <tr> <td>12</td><td>Parameter problem messages.</td></tr> <tr> <td>13</td><td>Timestamp requests.</td></tr> <tr> <td>14</td><td>Timestamp replies.</td></tr> <tr> <td>15</td><td>Information requests.</td></tr> <tr> <td>16</td><td>Information replies.</td></tr> <tr> <td>17</td><td>Address mask requests.</td></tr> <tr> <td>18</td><td>Address mask replies.</td></tr> </table>	0	Echo replies.	3	Destination unreachable messages.	4	Source quench messages.	5	Redirect (change route) messages.	8	Echo requests.	11	Time exceeded messages.	12	Parameter problem messages.	13	Timestamp requests.	14	Timestamp replies.	15	Information requests.	16	Information replies.	17	Address mask requests.	18	Address mask replies.
0	Echo replies.																										
3	Destination unreachable messages.																										
4	Source quench messages.																										
5	Redirect (change route) messages.																										
8	Echo requests.																										
11	Time exceeded messages.																										
12	Parameter problem messages.																										
13	Timestamp requests.																										
14	Timestamp replies.																										
15	Information requests.																										
16	Information replies.																										
17	Address mask requests.																										
18	Address mask replies.																										
log	Logs the results.																										

Syntax
[tcp|udp]

```
access-list extended <list-name> {deny|permit} {tcp|udp}
    {<ipv6-source-addr/p>|<ipv6-source-addr> <ipv6-source-wildcard>|
    any} {eq|lt|gt|ne} <sourceport> {<ipv6-dest-addr/p>|<ipv6-dest-
    addr> <ipv6-source-wildcard>|any} {eq|lt|gt|ne} <destport> [log]
```

```
access-list extended <list-name> {deny|permit} {tcp|udp}
    {<ipv6-source-addr/p>|<ipv6-source-addr> <ipv6-source-wildcard>|
    any} {eq|lt|gt|ne} <sourceport> {<ipv6-dest-addr/p>|<ipv6-dest-
    addr> <ipv6-source-wildcard>|any} {eq|lt|gt|ne} <destport> [log]
```

Parameter	Description
<list-name>	A user-defined name for the IPv6 software extended access-list.
deny	The IPv6 software extended access-list rejects packets that match the type, source, and destination filtering specified with this command.
permit	The IPv6 software extended access-list permits packets that match the type, source, and destination filtering specified with this command.
tcp	The IPv6 software extended access-list matches only TCP packets.
udp	The IPv6 software extended access-list matches only UDP packet.
<ipv6-source-addr/p>	Specifies a source address and prefix length. The IPv6 address prefix uses the format X:X::/prefix-length. The prefix-length is usually set between 0 and 64, or has the value 128.
<ipv6-source-addr>	Specifies the IPv6 source address. The IPv6 address uses the format X:X::X:X.
<ipv6-source-wildcard>	Specifies source wildcard bits in IPv6 format X:X::X:X. Note that binary 1 represents a don't care condition, and binary 0 represents a match.
any	Matches any source IPv6 address.
<sourceport>	The source port number, specified as an integer between 0 and 65535.
<ipv6-dest-prefix/prefix-length>	Specifies a destination address and prefix length. The IPv6 address uses the format X:X::X/X/Prefix-Length. The prefix-length is usually set between 0 and 64, or has the value 128.
<ipv6-dest-addr>	Specifies a destination address. The IPv6 address uses the format X:X::X:X.
<ipv6-dest-wildcard>	Specify destination Wildcard bits in IPv6 format X:X::X:X
any	Matches any destination IPv6 address.
<destport>	The destination port number, specified as an integer between 0 and 65535.

Parameter(Continued)	Description(Continued)
eq	Matches port numbers equal to the port number specified immediately after this parameter.
lt	Matches port numbers less than the port number specified immediately after this parameter.
gt	Matches port numbers greater than the port number specified immediately after this parameter.
ne	Matches port numbers not equal to the port number specified immediately after this parameter.
log	Log the results.

Mode Global Configuration

Example

```
awplus# configure terminal
awplus(config)# ipv6 access-list extended TK deny tcp any eq
14 any lt 12 log
```

Related Commands [show running-config](#)
[show ipv6 access-list](#)

ipv6 access-list standard (Named)

This command configures an IPv6 software standard access list for filtering frames that permit or deny IPv6 packets from a specific source IPv6 address.

The no form removes a specified software IPv6 standard access-list.

Syntax

```
ipv6 access-list standard <list-name> {deny|permit} {<ipv6-source-addr/p>|<ipv6-source-addr> <ipv6-source-wildcard>|any} [exact-match]

no ipv6 access-list standard <list-name> {deny|permit} {<ipv6-source-addr/p>|<ipv6-source-addr> <ipv6-source-wildcard>|any} [exact-match]
```

Parameter	Description
<list-name>	A user-defined name for the IPv6 software standard access-list.
deny	The IPv6 software standard access-list rejects packets that match the type, source, and destination filtering specified with this command.
permit	The IPv6 software standard access-list permits packets that match the type, source, and destination filtering specified with this command.
<ipv6-source-addr/p>	Specifies a source address and prefix length. The IPv6 address prefix uses the format X:X::/prefix-length. The prefix-length is usually set between 0 and 64, or has the value 128.
<ipv6-source-addr>	Specifies the IPv6 source address. The IPv6 address uses the format X:X::X:X.
<ipv6-source-wildcard>	Specifies source wildcard bits in IPv6 format x:x::x:x. Note that binary 1 represents a don't care condition, and binary 0 represents a match.
any	Matches any source IPv6 address.
exact-match	Exact match of the prefixes.

Mode Global Configuration

Related Commands

```
show running-config
show ipv6 access-list
```

mac access-group

This command adds a MAC hardware-based access-list to an interface. The number of access-lists that can be added is determined by the amount of available space in the hardware-based packet classification tables.

Use the `no mac access-group` command to remove a MAC hardware-based access-list from an interface.

Syntax `mac access-group <4000-4699>`
`no mac access-group <4000-4699>`

Parameter	Description
<code>no</code>	Negate a command or set its defaults
<code>mac</code>	MAC Information
<code>access-group</code>	Used to apply an access Control List, of the same number, to a port or range
<code><4000-4699></code>	Hardware MAC access list

Mode Interface Configuration

Usage First create a mac access list that applies the appropriate permit, deny requirements etc. Then use the `mac access-group` command to apply this access list to a specific port or range. Note that this command will apply the access list only to *incoming* data packets.

Example To add access-list 4010 to interface port1.0.1:

```
awplus# configure terminal
awplus(config)# interface port1.0.1
awplus(config-if)# mac access-group 4010
```

To remove access-list 4010 from interface port1.0.1:

```
awplus# configure terminal
awplus(config)# interface port1.0.1
awplus(config-if)# no mac access-group 4010
```

Related Commands [show interface access-group](#)

maximum-access-list

Sets the maximum number of filters that can be added (using QoS) to a any access-list. These are access-lists within the ranges <1-199>, <1300-1999> and <2000-2699> and named standard and extended access-lists.

Hardware access-lists are excluded from this command. These lists are those within the ranges <3000-3699> and <4000-4699>.

The no variant of this command removes the limit on the number of filters that can be added to a software access-list

Syntax `maximum-access-list <1-4294967294>`
`no maximum-access-list`

Parameter	Description
<code>maximum-access-list</code>	Maximum access-list entries
<code><1-4294967294></code>	Filter range
<code>no</code>	Negate a command or set its defaults

Mode Global Configuration

Examples To set the maximum number of software filters to 200:

```
awplus# configure terminal
awplus(config)# maximum-access-list 200
```

Related Commands [remote-command](#)

show interface access-group

Use this command to display the access groups attached to a port. If an access group is specified, then the output only includes the ports that the specified access group is attached to. If no access group is specified then this command displays all access groups that are attached to the ports that are specified with *<port-list>*.

Note that access group is the term given for an access list when it is applied to an interface.

Note: This command will function on your switch in the stand alone mode, but is not supported when the device forms part of a VCS Stack.

Syntax `show interface <port-list> access-group [<3000-3699>|<4000-4699>]`

Parameter	Description
<i><port-list></i>	Optional. Specify the ports to display information. A port-list can be either: ■ a switch port (e.g. port1.2.12) a static channel group (e.g., sa3) or a dynamic (LACP) channel group (e.g., po3) ■ a continuous range of ports separated by a hyphen, e.g., port1.0.1-1.0.24 or port1.1.1-port1.1.24 or po1-po4 ■ a comma-separated list of ports and port ranges, e.g. port1.0.1,port1.1.1-1.2.24. Do not mix switch ports, static channel groups, and LACP channel groups in the same list.
<code>access group</code>	Select the access group whose details you want to show.
<i><3000-3699></i>	Optional. Specify the Hardware IP access list
<i><4000-4699></i>	Optional. Specify the Hardware MAC access list

Mode Exec and Privileged Exec

Examples To show all access-lists attached to port1.0.1:

```
awplus# show interface port1.0.1 access-group
```

Output Figure 51-1: Example output from the **show interface access-group** command

```
awplus#show interface port1.0.1 access-group
Interface port1.0.1
  access-group 3000
  access-group 3002
  access-group 3001
```

Related Commands [ip access-group](#)
[mac access-group](#)

show access-list

Shows the specified access-list, or all access-lists if none have been specified. Note that only defined access lists are displayed. An error message is displayed for an undefined access list

Syntax `show access-list [<1-99>|<100-199>|<1300-1999>|<3000-3699>|<4000-4499>|<list-name>]`

Parameter	Description
show	Show running system information
access-list	List access lists
<1-99>	IP standard access list
<100-199>	IP extended access list
<1300-1999>	IP standard access list (standard - expanded range)
<2000-2699>	IP extended access list (extended - expanded range)
<3000-3699>	Hardware IP access list
<4000-4499>	Hardware MAC access list
<list-name>	IP named access-list

Mode Privileged Exec

Example To show all access-lists configured on the switch:

```
awplus# show access-list
```

```
Standard IP access list 1
  deny 172.16.2.0, wildcard bits 0.0.0.255
Standard IP access list 20
  deny 192.168.10.0, wildcard bits 0.0.0.255
  deny 192.168.12.0, wildcard bits 0.0.0.255
Hardware IP access list 3001
  permit ip 192.168.20.0 255.255.255.0 any
Hardware IP access list 3020
  permit tcp any 192.0.2.0/24
awplus#show access-list 20
```

Example To show the access-list with an ID of 20:

```
awplus# show access-list 20
```

```
Standard IP access list 20
  deny 192.168.10.0, wildcard bits 0.0.0.255
  deny 192.168.12.0, wildcard bits 0.0.0.255
```

```
Standard IP access list 1
deny any
```

Note the below error message if you attempt to show an undefined access-list:

```
awplus# show access-list 2
```

```
% Can't find access list 2
```

Related Commands [access-list \(standard\)](#)
[access-list \(extended\)](#)

show ip access-list

Use this command to display IP access lists.

Syntax `show ip access-list [<1-99>|<100-199>|<1300-1999>|<2000-2699>|
<list-name>]`

Parameter	Description
<1-99>	IP standard access list
<100-199>	IP extended access list
<1300-1999>	IP standard access list (expanded range)
<2000-2699>	IP extended access list (expanded range)
<list-name>	IP named access-list

Mode Privileged Exec

Usage This command only displays the IP access lists; it does not display the hardware access lists, i.e. those in the ranges: 3000 to 3699 and 4000 to 4699.

Output [Figure 51-2: Example output from the show ip access-list command](#)

```
Standard IP access list 1
  permit 172.168.6.0, wildcard bits 0.0.0.255
  permit 192.168.6.0, wildcard bits 0.0.0.255
```

Example

```
awplus# show ip access-list
```

show ip prefix-list

Use this command to display the prefix-list entries. Note that this command is valid for RIP and BGP routing protocols only.

Syntax `show ip prefix-list [<list>|<detail>|<summary>]`

Parameter	Description
<list>	<ip-addr/mask> [first-match longer]
<ip-addr/mask>	IP address for the prefix list and mask <0-32> is the range for the mask
first-match	the show command displays the first matching routing table for the given IP address or prefix
longer	causes the show command to lookup longer prefixes
<detail>	detail [<word-detail>]
<word-detail>	name of prefix list when used after the keyword detail
<summary>	summary [<word-summary>]
<word-summary>	name of the prefix list when used after the keyword summary

Mode Privileged Exec

Usage The following sample output of the show ip prefix-list command shows prefix-list entries

Example

```
awplus# show ip prefix-list
awplus# show ip prefix-list 10.10.0.98/8 first-match
awplus# show ip prefix-list detail home
```

show ipv6 access-list

Use this command to display the IPv6 access list specified by name.

Syntax `show ipv6 access-list standard [<access-list-name>]`

Parameter	Description
<code><access-list-name></code>	Optional. Hardware IPv6 access list name.
<code>standard</code>	Named standard access list

Mode Privileged Exec

Example To show the ipv6 access-lists use the command:

```
awplus# show ipv6 access-list standard name
```

Output Figure 51-3: Example output from the **show ipv6 access-list** command

```
Named Standard IPv6 access list name
deny any
```


Chapter 52: Quality of Service (QoS)



Introduction.....	52.2
QoS Operations	52.2
QoS Packet Information	52.3
Link Layer QoS.....	52.3
Differentiated Services Architecture	52.4
The Differential Services Field.....	52.5
Processing pre-marked packets.....	52.6
Applying QoS on Your Switch.....	52.7
Classifying your Data	52.7
Class Maps.....	52.7
Policy Maps	52.10
Premark and Remark your Traffic.....	52.11
CoS to egress queue premarking.....	52.11
DSCP to egress queue premarking.....	52.13
Policing (Metering) Your Data	52.15
Single-rate three-color policing.....	52.15
Two rate three-color policing.....	52.16
Configuring and Applying a Policer	52.17
Remark Your Data.....	52.18
Configuring the Egress Queues	52.19
Egress Queues and QoS markers.....	52.19
Egress Queue Commands Hierarchy.....	52.19
Egress Queue Shaping	52.21
Drop Mode.....	52.22
Storm Protection	52.23
Policy-Based Routing.....	52.24
Practical Example.....	52.24

Introduction

This chapter introduces the concept of Quality of Service (QoS) with particular reference to Allied Telesis switches running the AlliedWare Plus™ Operating System. For additional information on using QoS on AT switches see, *How To Configure QoS on x900-24, x900-12, and SwitchBlade x908 Series Switches*. This How To Note is available from <http://www.alliedtelesis.com>.

The concept of QoS is a departure from the original networking concept of treating all network traffic in the same way. Without QoS, all traffic types are equally likely to be dropped when a link becomes oversubscribed. With QoS, certain traffic types can be given preferential treatment. QoS is therefore a very useful tool both to control congestion and to meter or cap data in order to apply pre-agreed service levels.

Operationally, QoS is applied within the link and network layers. Functionally it provides the capability to intelligently transport your network traffic in order to provide stable and predictable end-to-end network performance.

Business benefits Quality of Service mechanisms enable:

- network service providers to sell different levels of service to customers, based on what their customers require, and be confident in their ability to guarantee the reliable delivery of these services
- enterprise and educational organizations to actively manage and provide many services across one network, for example live video streaming and standard data services, with preferential treatment being given to mission-critical traffic
- network administrators to manage network congestion as network traffic levels increase and time-critical applications, such as streaming media, become more widely in demand by customers and organizations

QoS Operations

Quality of Service is typically based on how the switch performs the following functions:

- assigns priority to incoming frames (that do not already carry priority information)
- correlates prioritized frames with traffic classes, or maps frames to traffic classes based on other criteria
- correlates traffic classes with egress queues, or maps prioritized frames to egress queues
- provides minimum and maximum bandwidths for traffic classes, egress queues, and/or ports
- schedules frames in egress queues for transmission (for example, empty queues in strict priority or sample each queue)
- re-labels the priority of outgoing frames
- determines which frames to drop or re-queue if the network becomes congested
- reserves memory for switching/routing or QoS operation (for example, reserving buffers for egress queues or buffers to store packets with particular characteristics)


QoS Packet Information

Provision for QoS information to be embedded within the data fields exists within both the data link and network layer protocols. This information can then be used to assess the priority of the data and the resource preferences that need to be applied. The process of applying these service quality tags to your data is known as marking.

Link Layer QoS

Link layer frames entering a port may either be tagged or untagged. VLAN tagged frames contain the additional 802.1Q tag fields shown in [Figure 52-1 on page 52.3](#) below. Located within the TCI is a three bit User Priority field. This field is specifically provided to attach QoS based priority information, often referred to as the Class of Service (CoS) field.

Figure 52-1: IEEE 802.1Q Tagging



Appendix G of the IEEE Standard 802.1D provides some useful guidelines on applying priorities to 7 traffic types: These are summarized in the [Table 52-1](#) below:

Table 52-1: CoS Traffic Mapping Guidelines

User Priority	Traffic Types
1	Background
2	Spare
0	Best Effort
3	Excellent Effort
4	Controlled Load
5	Video <100 ms latency and jitter
6	Voice <10 ms latency and jitter
7	Network Control

On the switch you can use the command, [“match cos” on page 53.9](#) to select frames that match a particular User Priority value and assign them to a particular class-map. You can then map these incoming frames to one of eight egress queues. This facility enables you to accept frames that are already carrying meaningful priority information and automatically assign them to an appropriate egress queue. For example, you could decide to send frames with a User Priority value of 7 to queue 3, and frames with a User Priority value of 2 to queue 7. The process of assigning queues based on CoS tags is commonly known as “PreMarking”

Note: You configure the pre-marking steps to an ingress port. This process marks the data packets so that when they reach the egress port the decisions made during pre-marking can be applied in accordance with the configuration of the egress port.

Application with VLAN double tagging

Note that if you are using VLAN double tagging, you could use the “[match cos](#)” command to set the individual QoS requirements *within* each client network and also separately within the provider network. You can then use the “[match inner-cos](#)” on [page 53.11](#) command to apply particular “*client*” QoS requirements that you want to apply within the provider network. This process applies two levels of QoS within the provider network; one that operates specifically for the network provider, and another that is specific for traffic belonging to selected clients. See “[VLAN Double Tagging \(VLAN Stacking\)](#)” on [page 16.5](#).


At the network layer IPv4 packets contain an 8 bit field specifically to carry QoS information. This field, defined in RFC 1349, was originally named the Type of Service (ToS) field and contained a *ToS* component and a *Precedence* component. The ToS field however, has since been replaced by the Differentiated Services field.

Differentiated Services Architecture

Whilst a full description of the differential services model is outside the scope of this software reference, a brief introduction is provided. For further information, RFC 2475 provides an in depth definition of the architecture.

The basic differential services model envisages a multi router network within which common service qualities are applied. At the network boundary, *QoS Edge Routers* inspect the traffic and classify it into common service quality groups called Per Hop Behaviors (PHBs). A specific marker value called a Differential Services Code Point (DSCP) is added to the IP header of each packet, which allocates it to a PHB. *QoS Core Routers* within the network can then use the DSCP to decide on an appropriate service quality level to apply. When a network contains a consistently applied differential services code points DSCP it is referred as a Differential Services Domain (often shortened to DiffServe Domain). [Figure 52-2](#) shows a simple Differential Services Domain.

Figure 52-2: Differentiated Services Domain




The Differential Services Field

Figure 52-3 shows an IP header containing a Differentiated Services field. The format of this redefined field is explained in RFC 2474; the main difference being that the old ToS field has been replaced by a 6 byte Differentiated Services Code Point (DSCP) field, which now provides for up to 64 defined values.

By applying this model only the QoS edge routers need to fully interrogate the incoming data packets; the QoS core routers are then relieved of this processing task and need only to inspect the DSCP before applying its appropriate forwarding, queueing, and shaping rules.

Figure 52-3: The DSCP bits of the DS field in the IPv4 header



On the switch you can use the [match inner-vlan command on page 53.12](#) to select frames containing a particular DSCP value, and associate them with a particular class map and policy map.

Because the model offers considerable flexibility, and the mapping of traffic types to DCSs is individual for each network, this locally applied definition is known as a *Differential Services Domain*. The previous section introduced the concept of a Per Hop (service quality) Behaviors or PHBs. RFC 2597 defines a specific PHB group called Assured Forwarding (AF). The AF PHB group provides delivery of IP packets in four independently forwarded AF classes. Within each AF class, an IP packet can be assigned one of three different levels of drop precedence.

[Table 52-2](#) shows a list of recommended AF code points.

Table 52-2: Recommended DSCP Code Points

	(Lowest Priority) Class 1 (001xxxx)	Class 2 (010xxxx)	Class 3 (011xxxx)	(Highest Priority) Class 4 (100xxxx)
Low Drop Precedence	001010 AF11 Decimal 10	010010 AF21 Decimal 18	011010 AF31 Decimal 26	100010 AF41 Decimal 34
Medium Drop Precedence	001100 AF12 Decimal 12	010100 AF22 Decimal 20	011100 AF32 Decimal 28	100100 AF42 Decimal 36
High Drop Precedence	001110 AF13 Decimal 14	010110 AF23 Decimal 22	011110 AF33 Decimal 30	100110 AF43 Decimal 38

Processing pre-marked packets

A logical question to ask at this point is; how does the QoS switch deal with data that arrives with a pre-existing service level tag such as a DSCP? As previously touched on, the differentiated services model envisages a network that comprises QoS boundary routers at its edge and QoS core routers in its core network.

At the network edge the QoS boundary routers filter the incoming data based on specific packet components. Based on this filtering each packet is assigned a DSCP value. This value will determine the service level - priority, queueing etc - that will be applied.

Within the network core, the packet filtering required is reduced to simply reading the DSCP within each incoming packet, and applying a the appropriate set of service levels. This relieves the core routers of the processing overhead of applying complex filtering to its high speed data streams.


Applying QoS on Your Switch

This section steps you through the various stages of QoS set-up and introduces the QoS commands and how to apply them. Note that before you can configure any QoS functions on your switch, you must first enable QoS by using the [mls qos enable command on page 53.20](#).

Classifying your Data

One of the early steps in setting up QoS on a network is planning and applying your classification rules. Classification is the process of, *Filtering* and *Marking*. Filtering involves sorting your data into appropriate traffic types. Marking involves tagging the data so that downstream ports and routers can apply appropriate service policy rules. [Figure 52-4](#) illustrates the classifying process, and will be referred to in the examples that follow.

Figure 52-4: QoS Classification Process



At the premarking stage you can assign your data a particular priority level by giving it a link level user priority, see [“Link Layer QoS” on page 52.3](#), or a network level DSCP [“Differentiated Services Architecture” on page 52.4](#). You can also assign the data to a particular output (or egress) queue.

Class Maps

Class Maps are among the pivotal QoS components. They provide the means that associate the classified traffic with its appropriate QoS actions. They are the linking elements for the following functions:


- classification
- policy mapping
- pre-marking

Figure 52-5 on page 52.8 shows the relationship between a class-map and its associated functions. Note that the relationship between a class-map and a policy-map can be one-to-one or many-to-one. For information on policy-maps see the section, “Policy Maps” on page 52.10.

Note: If a conflict occurs between the settings in two class maps, priority will be applied to the class map that was created first.

An example of such a conflict is the arrival of a packet that meets the classification requirements of two class maps each configured to the same policy map and set to apply different priority settings to the packet.

Figure 52-5: Relationship between a class map and its associated functions



Creating a class-map

To create a class map, use the [class-map command](#) on page 53.3.

This example creates a class-map called video-traffic and another called data-traffic:

```
awplus# configure terminal
awplus(config)# class-map video-traffic
awplus(config-cmap)# exit
awplus(config)# class-map office-traffic
awplus(config-cmap)#
```


Creating and configuring default class-maps

These (automatically created) default class-maps serve as the means to specify the action that will apply to all unclassified data, i.e. all data within a policy-map that is not captured by any of the applied match commands that are applied to the policy-map by its class-maps.

Each time a new policy-map is created a new class map called “default” is also automatically created and assigned to the new policy map. You can configure any of the default class maps by using the [default-action command on page 53.5](#)

To set the default class-map for the policy-map *p-map1* to have the action of *deny*:

```
awplus# config
awplus(config)# policy-map p-map1
awplus(config-pmap)# default-action deny
```

Applying a match command to a class-map

To apply a matching filter to a class map use one of the match commands.

This example creates a filter to select vlan5 traffic and applies this filter to the class map named video-traffic.

```
awplus# config terminal
awplus(config)# class-map video-traffic
awplus(config-cmap)# match vlan 5
```

Associating a class-map with a policy-map

To associate a class map with a policy map, use the [class command on page 53.2](#).

Note: A maximum of 128 class maps may be attached to each policy map.


The following example creates a policy map called policy-one, and associates it with the class-maps named video-traffic, and database-traffic:

```
awplus# configure terminal
awplus(config)# policy-map policy-one
awplus(config-pmap)# class video-traffic
awplus(config-pmap-c)# exit
awplus(config-pmap)# class database-traffic
awplus(config-pmap-c)#
```

Policy Maps

Policy maps are the means by which you apply your class-map properties to physical switch ports. [Figure 52-8 on page 52.16](#) illustrates this concept. Note that whilst a policy map can be assigned to several ports, a port cannot have more than one policy-map assigned to it.

Figure 52-6: Policy Maps and Related Entities



To create and name a new policy map you use the [policy-map command on page 53.28](#). The following example creates two policy maps, corporate-users, and domestic-users.

To create a policy-map called `pmap1` use the commands

```
awplus# configure terminal
awplus(config)# policy-map pmap1
```

Having created the policy map `pmap1` we can use the [class command on page 53.2](#) to assign it to one or more class maps. Since we created the class-maps *video-traffic* and *office-traffic* earlier in this chapter, we can now attach the policy-map `pmap1` to both class-maps.

Use the [class](#) command to assign the policy map `pmap1` to the class-maps *video-traffic* and *office-traffic*:

```
awplus# configure terminal
awplus(config)# policy-map pmap1
awplus(config-pmap)# class video-traffic
awplus(config-pmap-c)# exit
awplus(config-pmap)# class office-traffic
awplus(config-pmap-c)#
```

Premarking and Remarking your Traffic

Premarking relates to adding QoS markers to your incoming data traffic before it is metered (policed). Remarking is the same process when applied after metering. Network switches will often be configured with two different premarking profiles, one for the QoS edge switches and another for the QoS core switches. This situation would apply if you are operating DSCP domains.

QoS markers can be applied at both the link layer (within the CoS field), and at the network layer (within the DSCP field). For more information on this topic see [“QoS Packet Information” on page 52.3](#).

For boundary QoS switches

Traffic entering QoS boundary switches is unlikely to contain pre-existing QoS tagging. In this case, you can apply one or more of the following QoS mapping options.

- Assign a CoS tag to data associated with a particular class-map.
- Use the `trust dscp` command to enable the `mls qos map premark DSCP map`. This map enables you to change the DSCP tag and also map the tag to an egress port queue, a CoS value, or both. At the premarking stage you can set this mapping using the command, `mls qos map premark-dscp to`. After policing, you can then use the `remark-map` command to change the DSCP based on the packet's bandwidth class, or remap the existing bandwidth class, to a new value.

For an untagged packet, if no other mapping is applied and the packet is untagged, (i.e. in the absence of any other queue selection) traffic will be sent to queue 2.

For core QoS switches

Traffic entering ports within the QoS core network will almost certainly contain some pre-existing QoS tagging. Where this is the case, you can apply one of the following QoS mapping options.

- Map the CoS tag to an egress queue. You can do this either for the whole switch or for specific ports via their assigned policy-maps. See [“CoS to egress queue premarking” on page 52.11](#).
- Map the DSCP tag to an output queue. You can do this either for the whole switch or for specific ports via their assigned policy-maps.
- Remap incoming data DSCP or CoS tags to values that are more appropriate for a particular switch or network.
- Assign bandwidth classes for your packets, based on the incoming DSCP. See [Setting the Trust DSCP Map command on page 52.14](#).

CoS to egress queue premarking

If you are using CoS tagging for your QoS functions, your traffic is likely to be either entering the switch with a pre existing CoS tag, or will have appropriate tags attached via your class-maps and policy-maps. You can now mark the data for a particular egress queue, which will take effect when the data reaches its output port. There are two fundamental methods of applying CoS tagged packets to egress queues:

1. Apply a global mapping of CoS tags to egress queues for all ports.
2. Apply a CoS to egress queue mapping for the class-map / policy-map. This mapping - which forms part of the policy map - is applied at an input port, but will take effect at the packet's destination output port. Note that this procedure takes priority over that described in method (1) above.

These methods and their related commands will be now be described in greater detail.

CoS tagging commands

Table 52-3 shows the commands you can use to change the CoS field within incoming packets.

Table 52-3: CoS Mapping Commands in Hierarchical Order

Command	Function
<code>mls qos map premark-dscp to</code>	Where a packet contains CoS tag and a DSCP tag. The table set by this command contains a configurable DSCP to CoS tag mapping.
<code>remark-map</code>	Configures the remark map. This command is applied when a policer is configured with the action parameter of the command, <code>police twin-rate action drop-red</code> set to <code>remark-transmit</code> .

Where a packet entering a port contains a pre-existing DSCP, You can use the command `mls qos map premark-dscp to` to change the following components, DSCP tag, CoS tag, bandwidth class.

Note: Where a packet contains both a CoS and a DSCP field, and each field maps to a different class-map; the switch will apply a priority that is based on the date that the class map was added to the policy map; the earlier the date, the higher the priority.

Mapping CoS tags to traffic types

The command `mls qos map cos-queue to`, enables you to create a switch-wide mapping of CoS values to egress queues. The default mappings for this command are:

```

COS :          0 1 2 3 4 5 6 7
-----
QUEUE:        2 0 1 3 4 5 6 7

```

These mappings match the CoS guidelines documented in Annex H.2 of ANSI/IEEE 802.1D 1988 Edition. Table H-15 on page 355 of the standard, shows a table of user priorities for specific traffic types. Table 52-4 shows an adapted version of the ANSI/IEEE table.

Table 52-4: Traffic Type Guidelines

User Priority (egress queue)	CoS Value	Acronym	Traffic type	Internal Traffic Queue Defaults
0 (lowest)	1	BK	Background	
1	2	-	Spare	
2	0	BE	Best Effort	Default
3	3	EE	Excellent Effort	
4	4	CL	Controlled Load	
5	5	VI	"Video," <100 ms latency and jitter	
6	6	VO	"Voice," <10 ms latency and jitter	EPSR-Management BPDU ARP-Requests
7 (highest)	7	NC	Network Control	Stack Management

CoS settings for VCS stack operation

In general you can apply the same principles when configuring QoS on a VCS stack as you would for single switch; however there are a few specific changes that you will need to make.

Switches within a VCS stack, exchange their stack management information and user data over their high speed inter-stacking links. The stack management information is pre-assigned to the egress queue 7. This is the highest value queue, and (in a stacked configuration) its traffic should not be shared with any user data. However, any CoS tagging of 7 applied to the incoming data will automatically be assign to queue 7 as it crosses the internal stacking links. You will therefore need to reconfigure your CoS to Queue settings to ensure that no user data is sent to queue 7.

To prevent this from happening, we recommend that you make appropriate changes to your queue settings (mappings) to reflect the stacking requirement previously described. For more information on this topic, see [“Mapping CoS tags to traffic types” on page 52.12](#).

This process should include (but not be limited to) running the following command to ensure that any remaining user still carrying a CoS 7 tag, will be mapped to egress queue 6.

To remap priority CoS traffic to egress queue 6, run the following command.

```
awplus# config terminal
awplus(config)# mls qos map cos-queue 7 to 6
```

DSCP to egress queue premarking

If you are using DSCP tagging for your QoS functions, your traffic is likely to be entering the switch either with a pre existing DSCP tag, or will have appropriate DSCP tags attached via your class-maps and policy-maps. You can now mark the data for a particular egress queue, which will take effect when the data reaches its output port.

If your switch forms part of a DSCP domain, you can adapt the steps in this section to apply the mappings and settings to match the standards you have selected for the domain. This mapping - which forms part of the policy map - is applied at an input port, but will take effect at the packet's destination output port.

DSCP to egress queue premarking commands

A number of commands can be used for mapping DSCP tags. Where these conflict, the switch applies a pre-defined set of priorities. [Table 52-5](#) lists these priorities in order (lowest priority first).

Where a packet that contains both CoS and a DSCP fields and each field maps to a different class-map / policy-map, the switch will apply a priority based on the creation date of class maps - the earlier the creation date, the higher the priority priorities.

Table 52-5: DSCP Mapping Commands in Hierarchical Order

Command	Function
<code>trust dscp</code>	Setting the trust dscp enables the <code>mls qos map premark-dscp</code> to command to apply. See, “Setting the Trust DSCP Map” on page 52.14 .
<code>mls qos map premark-dscp to</code>	With the trust dscp set, this command applies a remapping table whose values include the dscp and egress queues.

Setting the Trust DSCP Map

The Trust DSCP mapping table assigns a new set of QoS values for a DSCP value supplied as table input. To configure this table you use the command, `mls qos map premark-dscp to`.

Table 52-6: Drop Probability Table

Table Input	Table Output			
Existing DSCP	New DSCP Value	New CoS Value	New Queue No	New BW Class green yellow red

The Trust DSCP map is configured from the `mls qos map premark-dscp to` command and provides the highest priority of all the pre-marking controls. To apply this table you must first apply the trust setting by using the command `trust dscp`.


Policing (Metering) Your Data

Once you have set-up your classification and created your class-maps, you can start conditioning your traffic flows. One tool used for traffic conditioning is the policer (or meter). The principle of policing is to measure the data flow that matches the definitions for a particular class-map; then, by selecting appropriate data rates, allocate the flows into one of three categories, Red Yellow or Green. You then decide what action to apply to the Red, Yellow and Green data.

Single-rate three-color policing

This policing method is based that defined in RFC 2697. The principle of single-rate three-color policing is shown in Figure 52-7 on page 52.15. For a given class-map, a meter monitors both the token count in the buckets, and the input data flow.

Figure 52-7: Single-Rate Three-Color Policing



Each byte entering the meter is paired with a token in each bucket, and a token is removed as each byte is accepted. If the input data rate is the same as the CIR then the data passes through the port at the same rate as the bucket fills. Hence the bucket level remains constant. In this model, the data buffer is represented by two data buckets. You can specify the CIR using the `police single-rate action` command.


Initially both buckets have their full token count. A surge of data exceeding the CIR will begin to empty the bucket. As the data and tokens are paired, data bytes that match tokens below the CBS level are marked green, those that are between CBS and EBS will be marked yellow, and those that are above EBS are marked red.

Note that although the data is metered per byte, the color marking process is applied per packet. This means that if there were only sufficient tokens available to match part of a packet, then the whole packet would be marked red. Then, depending on the **action** parameter of the `police single-rate action` command, the whole packet will be either dropped or forwarded. In either situation, the red marked packet will leave the bucket counts unchanged.

Two rate three-color policing

This policing method is based that defined in RFC 2698. The principle of two-rate three-color policing is shown in Figure 52-8 on page 52.16.

Figure 52-8: Two-Rate Three-Color Policer



For a given class-map, the meter monitors the token count in both buckets, and the input data flow. Initially tokens enter both buckets until full. As the data enters a port, the meter pairs each byte to a token in one of the buckets, then removes a token from the appropriate bucket. Bucket C is topped up with tokens at the Committed Information Rate (CIR), and bucket P is topped up at the Peak Information Rate (PIR).

When data enters the port at the CIR, the bucket fills at the same rate as the incoming data, thus the token count in bucket C remains constant. Similarly, if data enters the port at the PIR, then the token count in bucket P remains constant. You can specify the CIR and the PIR by using the `police twin-rate action drop-red` command. The function of each of this command is explained in the section “Configuring and Applying a Policer” on page 52.17.

A surge of data exceeding the CIR will begin to empty bucket C. If bucket C empties to a point where it has insufficient tokens to match to an incoming data packet, then the data packet will be marked yellow. The data will now be measured against the level in bucket P and tokens will be removed from this bucket to match the incoming data. If the incoming data rate drops to less than the CIR then the data will continue to be marked yellow until the level in bucket C has had a chance to fill, whereupon it will be marked green.

If the incoming data is greater than the PIR, then bucket P begins to empty. If bucket P empties to a point where it has insufficient tokens to match to an incoming data packet, then the data packet will be marked red. In this situation no tokens are removed from either bucket.

Note that although the data is metered per byte, the color marking process is applied per packet. This means that if there were only sufficient tokens available to match part of a packet, then the whole packet would be marked red. Then, depending on the action parameter of the `police twin-rate action drop-red` command, the whole packet will be either dropped, or marked and forwarded. In either situation, the red marked packet will leave the bucket counts unchanged.

Configuring and Applying a Policer

The previous section showed how the policer works and how to select either the single rate or twin rate action. To apply a policy to class maps:

Select your policy-map and class-map from the command prompt, then enter either the `police single-rate action` command or the `police twin-rate action drop-red` command whilst selecting the appropriate command parameters.

This will apply the command to the selected class-map. By running this command several times, each for a different class-map, you can apply separate meter settings to each class-map.

Remarking Your Data

The remarking process enables you to change the QoS tagging and queue assignments etc from data that has already been marked by the policer. To do this you fill entries in the remarking table by using the [remark-map command on page 53.29](#). In order to remark your data ensure that the action parameter of either the [police single-rate action](#) or the [police twin-rate action drop-red](#) is set to remark-transmit.

The following table shows the remarking options

Table 52-7: Remarking Table

BANDWIDTH CLASS		
Green	New DSCP	New bandwidth class (Red, Yellow, or Green)
Yellow	New DSCP	New bandwidth class (Red, Yellow, or Green)
Red	New DSCP	New bandwidth class (Red, Yellow, or Green)

Example Traffic presently marked either Yellow or Red is to be remarked green and assigned a new DSCP value of 25:

Table 52-8: Remarking Table Example

BANDWIDTH CLASS		
Yellow	New DSCP = 25	New bandwidth class =Green

To configure this setting, you would enter the following commands:

```
awplus# configure terminal
awplus(config)# policy-map pmap1
awplus(config-pmap)# class cmap1
awplus(config-pmap-c)# remark-map bandwidth-class green to
                        new-dscp 25 new-bandwidth-class yellow
```

Further remarking can be achieved by using the [remark new-cos command on page 53.30](#). This command enables you to configure and remark either or both the CoS flag in the data packet, and the input into the CoS to queue map thus changing the destination egress queue.

Configuring the Egress Queues

Previous sections have explained the ingress functions. These include, how the incoming data can be classified and marked according to its priority and allocated to an egress queue, then finally how metering and remarking is applied. At this point the data then flows across the switch to its destination egress port where its transit to the egress queues is controlled.

The means by which data is applied to the egress queues is dependant on three functions:


- Egress queue and QoS markers that are set within each data packet
- Egress controls that are applied to the whole switch
- Egress that are applied to each individual switch port

Egress Queues and QoS markers

Once the data packets have been appropriately filtered, classified, policed, and remarked, they travel across the switch's internal paths carrying their assigned QoS tag markers such as their priority, class and destination queues. For more details on ingress data marking, refer to the earlier sections of this chapter. At the egress port these markers are read and used to determine which queues each data packet will be forwarded to, and the priorities that will be applied.

There are eight egress queues allocated to each egress port. The egress queue that a particular packet passes through is determined by either the configuration of the switch, or the markers contained within the packet itself.

Figure 52-9: Default Egress Queue



Egress Queue Commands Hierarchy

The destination queue that any one packet will take depends on the markers within the packet, and the way the queueing commands have been set. Also some queueing commands will override others. Here is how the switch prioritizes its queueing commands.

Imagine a packet entering an ingress port then traveling through the switch fabric to reach its appropriate egress port. In this situation the following hierarchy will apply:

1. If the packet enters an egress port carrying no QoS markers and no QoS queueing commands have been set on the switch, then the packet will exit the port via queue number 2.

2. If the packet containing CoS marker arrives at an egress port, then with no other configuration applying, then its queue mapping will be subject to the setting of the command, `mls qos map cos-queue to`.
3. Situations (1) and (2) can be overridden by the `remark new-cos` command. This command sets a default queue for each switch port.

Egress Queue Shaping

This section is concerned with how the egress queues are cleared.

Strict priority servicing

By default, all queues on all ports are serviced in a strict priority order. This means that the highest numbered priority queue (queue 7) is emptied first; then when it is completely empty, the next highest priority queue is processed, and so on. Thus, for a strict priority queue to be processed, all higher priority queues must be empty.

Strict priority servicing is the default setting; however if your system is configured for weighted-round-robin, you can return it to priority queueing by using the commands shown in the following example.

Example To return queue 3 of port 1.0.1 from WRR servicing to strict priority queueing:

```
awplus# configure terminal
awplus(config)# interface port1.0.1
awplus(config-if)# priority-queue 3
```

Weighted round robin servicing

The following examples show how to configure round robin servicing.

Example To configure a wrr-queue by applying a weighting value of 6 to queues 0 1 2:

```
awplus# configure terminal
awplus(config)# interface port1.0.1
awplus(config-if)# wrr-queue weight 6 queues 0 1 2
```

Example In this example port 1.0.1 has queues configured as follows:

- queues 6 and 7 are configured strict priority
- queues 3 4 and 5 are configured as WRR with weighting values of 6,
- queue 5 is configured as WRR with weighting values of 12
- queues 0, 1 and 2 are configured as WRR with weighting values of 4,

```
awplus# configure terminal
awplus(config)# interface port1.0.1
awplus(config-if)# priority-queue 6 7
awplus(config-if)# wrr-queue weight 6 queues 3 4
awplus(config-if)# wrr-queue weight 12 queues 5
```

In this example, the queues are processed as follows:

1. Queue 7 is processed first.
2. If queue 7 is empty, Queue 6 is processed next.

3. If queues 6 and 7 are empty, queue 5 is processed next.
4. If queue 5 is empty, queues color 3 and 4 are process with equal weighting.

Drop Mode

The drop mode sets the limits for packets in the eight egress queues and determines how packets will be dropped if the queues become congested. Your switch supports the Tail Drop mode and is pre-configured with the following defaults:

Data packets will be dropped per color at the following buffer usage:

Red at 60%, Yellow at 80%, and Green at 100%.

These settings cannot be reconfigured.

Tail Drop

In this drop mode each egress queue is configured with a maximum threshold value. This value represents the point where the egress buffer queues are full and the egress port must start dropping data. The port does this by dropping data packets destined for the full queue on a “last in first dropped” basis. This enables the port to clear its data already queued for egress.

If a “reliable” transport protocol, such as TCP is used, this data should be retransmitted, but at a slower rate due to lack of returning “acknowledgements”.

Storm Protection

Storm protection uses QoS mechanisms to classify on traffic likely to cause a packet storm (broadcast and multicast). Unless you are running an enhanced storm protection feature such as Loop Protection. The per-port storm protection mechanism simply discards any traffic over the configured limit. However, with QoS storm protection, several actions are possible when a storm is detected:

- You can disable the port physically.
- You can disable the port logically.
- You can disable the port for a particular VLAN.

When a storm is detected on a port, a message is automatically recorded in the log, and you can configure an SNMP trap to signal that a port has been disabled. When a storm is detected on a trunk or port group, the entire trunk or port group is disabled.

The following table explains the basic concepts involved with storm protection.

Concept	Description
Window	The frequency at which traffic is measured to determine whether storm protection should be activated.
Rate	The amount of traffic per second that must be exceeded before the switch takes the configured action.
Action	What the switch does when it detects a storm on a port.
Timeout	The length of time the port remains disabled after a port has been disabled due to a packet storm.

To set the action to take when triggered by QoS Storm Protection (QSP), use the [storm-protection command on page 53.45](#).

To set the time to re-enable the port once disabled by QSP, use the [storm-downtime command on page 53.44](#).

To enable the Policy Based Storm Protection QSP, use the command [storm-protection command on page 53.45](#).

Policy-Based Routing

Policy based routing provides a means to create multiple paths to the same destination. The specific path that any particular packet will take can be based on configurable network metrics such as priority, protocol, or VLAN membership. For example, policy based routing can implement policies to allow or deny paths based on the identity of user devices, application, or packet sizes.

Practical Example

The example shown makes use of policy based routing to achieve the following:

1. Ensure that traffic being sent between local VLANs is switched normally.
2. Selects a particular egress path for traffic destined for the wide area networks.

Configuration Overview

A large government building houses employees from three separate government departments: Health, Welfare, and Employment. Each department has its own local subnet, and an associated VLAN; these are:


- 10.10.0.0/16 Health, VLAN 10
- 10.20.0.0/16 Welfare, VLAN 20
- 10.30.0.0/16 Employment, VLAN 30

Enquiries to each department are fed through a common Allied Telesis switch. The switch has 3 uplink ports, each of which (for simplicity) will be in a different VLAN and each will supply a connection to its relevant government department and to the Internet via each departments particular ISP (Internet Service Provider). These are:

- Port 1.0.1 Health Uplink, VLAN 110
- Port 1.0.5 Welfare Uplink, VLAN 120
- Port 1.0.21 Employment Uplink, VLAN 130

This configuration is illustrated in [Figure 52-10](#):

Figure 52-10: Policy-Based Routing Example




Configuration Steps

The following steps can be used to setup this example network. Since each step involves entering several instances of a command type, a single practical command entry is shown at the end of each step. The set of steps comprise the following:

1. Create VLANs on the switch.
2. Create access control lists (ACLs) that will match the data flows between local subnets.
3. Create ACLs that will match the data flows between local devices and other destinations.
4. Setup class-maps for each department and apply an access-list to each of the class maps.
5. Setup class-maps for each department's wide area connection and apply an access-list to each of these class maps.
6. Create the departmental policy-maps and associate them with their appropriate class-maps.
7. Apply these policy-maps to their appropriate ports.

These class-maps and ACLs are shown diagrammatically in [Figure 52-11](#) below.

Figure 52-11: Policy Based Routing Example - ClassMaps and ACLs.



Step 1: Create VLANs on the switch

- Create VLANs 10, 20, and 30
- Apply these VLANs to their appropriate local ports

Practical example: Create VLAN 10 and apply it to ports 1.0.2 to 1.0.8 .

```

awplus# configure terminal

awplus(config)# interface port port1.0.2-port1.0.8

awplus(config)# switchport mode access

awplus(config)# switchport access vlan 10
  
```

- Create VLANs 110, 120, and 130
- Apply these VLANs to their appropriate WAN ports

Practical example: Create VLAN 110 and apply it to port 1.0.1.

```

awplus# configure terminal

awplus(config)# interface port port1.0.1

awplus(config)# switchport mode access

awplus(config)# switchport access vlan 110
  
```

Step 2: Create access control lists (ACLs) that will match the data flows between local user devices.

- `access-list 3000 permit ip 10.10.0.0/16 10.20.0.0/16`
Matches for packets from the Health user devices to Welfare user devices.
- `access-list 3001 permit ip 10.10.0.0/16 10.30.0.0/16`
Matches packets from the Health user devices to Employment user devices.
- `access-list 3002 permit ip 10.20.0.0/16 10.10.0.0/16`
Matches packets from the Welfare user devices to Health user devices.
- `access-list 3003 permit ip 10.20.0.0/16 10.30.0.0/16`
Matches packets from the Welfare user devices to Employment user devices.
- `access-list 3004 permit ip 10.30.0.0/16 10.10.0.0/16`
Matches packets from the Employment user devices to Health user devices.
- `access-list 3005 permit ip 10.30.0.0/16 10.20.0.0/16`
Matches packets from the Employment user devices to Welfare user devices.

Practical example: Create an ACL that matches packets from the Health user devices to Welfare user devices.

```
awplus# configure terminal
awplus(config)# access-list 3000 permit ip 10.10.0.0/16
10.20.0.0/16
```

Step 3: Create access control lists (ACLs) that will match the data flows between user devices and all other destinations.

- `access-list 3006 permit ip 10.10.0.0/16 any`
Matches packets from Health user devices to all other destinations.
- `access-list 3007 permit ip 10.20.0.0/16 any`
Matches packets from Welfare user devices all other destinations.
- `access-list 3008 permit ip 10.30.0.0/16 any`
Matches packets from Employment user devices to all other destinations.

Practical example: Matches packets from the Health user devices to all other destinations.

```
awplus# configure terminal
awplus(config)# access-list 3006 permit ip 10.10.0.0/16 any
```

Step 4: Setup class-maps for each department and apply an access-list to each of the class maps.

- **class-map CM-Health-to-Welfare**
Creates a class map called CM-Health-to-Welfare
- **match access-group 3000**
Applies the access-list 3000 to the CM-Health-to-Welfare class-map, so that this class-map applies to all packets matching this ACL.
- **class-map CM-Health-to-Employment**
Creates a class map called CM-Health-to-Employment.
- **match access-group 3001**
Applies the access-list 3001 to the CM-Health-to-Employment class-map, so that this class-map applies to all packets matching this ACL.
- **class-map CM-Welfare-to-Health**
Creates a class map called CM-Welfare-to-Health.
- **match access-group 3002**
Applies the access-list 3002 to the CM-Welfare-to-Health class-map, so that this class-map applies to all packets matching this ACL.
- **class-map CM-Welfare-to-Employment**
Creates a class map called CM-Welfare-to-Employment.
- **match access-group 3003**
Applies the access-list 3003 to the CM-Welfare-to-Employment class-map, so that this class-map applies to all packets matching this ACL.
- **class-map CM-Employment-to-Health**
Creates a class map called Employment-to-Health.
- **match access-group 3004**
Applies the access-list 3004 to the CM-Employment-to-Health class-map, so that this class-map applies to all packets matching this ACL.
- **class-map CM-Employment-to-Health**
Creates a class map called CM-Employment-to-Health.
- **match access-group 3005**
Applies the access-list 3005 to the class-map CM-Employment-to-Health class-map, so that this class-map applies to all packets matching this ACL.

Practical example: Create the class-map Health-to-Welfare, then apply access list 3000 to it.

```
awplus# configure terminal
awplus(config)# class-map Health-to-Welfare
awplus(config-cmap)# match access-group 3000
```

Step 5: Setup class-maps for each department's wide area connection and apply an access-list to each of these class maps.

- `class-map CM-Health-to-WAN`
Creates a class map called CM-Health-to-WAN.
- `match access-group 3006`
Applies the access-list 3006 to the CM-Health-to-WAN class-map, so that this class-map applies to all packets matching this ACL.
- `class-map CM-Welfare-to-WAN`
Creates a class map called Welfare-to-WAN
- `match access-group 3007`
Applies the access-list 3007 to the CM-Welfare-to-WAN class-map, so that this class-map applies to all packets matching this ACL.
- `class-map CM-Employment-to-WAN`
Creates a class map called Employment-to-WAN.
- `match access-group 3008`
Applies the access-list 3008 to the CM-Employment-to-WAN class-map, so that this class-map applies to all packets matching this ACL.

Practical example: Create the class-map Health-to-Welfare, then apply access list 3006 to it.

```
awplus# configure terminal
awplus(config)# class-map CM-Health-to-WAN
awplus(config-cmap)# match access-group 3006
```

Step 6: Create the Departmental Policy-Maps and associate them with their appropriate Class-Maps.

- `policy-map PM-Health`
Creates the policy-map called PM-Health
- `class CM-Health-to-Welfare`
- `class CM-Health-to-Education`
Attaches the local Health class-maps to the PM-Health policy-map. Note that no action is applied to these two class maps. Packets that match either of these two class-maps will be forwarded across the local network using normal routing / forwarding procedures.
- `class CM-Health-to-WAN`
- `set ip next-hop 172.34.7.5`
Attaches the CM-Health-to-WAN class-map to this policy-map, and gives it a policy-routing action.
- `policy-map PM-Welfare`
Creates the policy-map called PM-Welfare
- `class CM-Welfare-to-Health`
- `class CM-Welfare-to-Employment`
Attaches the local Welfare class-maps to the PM-Welfare policy-map. Note that no action is applied to these two class maps. Packets that match either of these two class-maps will be forwarded across the local network using normal routing / forwarding procedures.
- `class CM-Welfare-to-WAN`

- `set ip next-hop 18.25.2.6`
Attaches the Welfare-to-WAN class-map to this policy-map, and gives it a policy-routing action.
- `policy-map PM-Employment`
Creates the policy-map called PM- Employment
- `class CM-Employment-to-Health`
- `class CM-Employment-to-Welfare`
Attaches the local Employment class-maps to the PM-Employment policy-map. Note that no action is applied to these two class maps. Packets that match either of these two class-maps will be forwarded across the local network using normal routing / forwarding procedures.
- `class CM-Employment-to-WAN`
- `set ip next-hop 34.56.4.5`
Attaches the Employment-to-WAN class-map to this policy-map, and gives it a policy-routing action.

Practical example: Create the policy-map called PM-Employment and attach its appropriate classmaps.

```
awplus# configure terminal
awplus(config)# policy-map PM-Employment
awplus(config-pmap)# class CM-Employment-to-Health
awplus(config-pmap-c)# exit
awplus(config-pmap)# class CM-Employment-to-Welfare
awplus(config-pmap-c)# exit
awplus(config-pmap)# class CM-Employment-to-WAN
awplus(config-pmap-c)# set ip next-hop 34.56.4.5
```

Step 7: Apply these Policy Maps to appropriate ports.

- `service-policy input Health-to-WAN`
- `service-policy input Welfare-to-WAN`
- `service-policy input Employment-to-WAN`

Practical example: To apply a policy map named pm-employment to port 1.0.15:

```
awplus# configure terminal
awplus(config)# interface port1.0.15
awplus(config-if)# service-policy input pm-employment
```

Chapter 53: QoS Commands

Command List	53.2
class	53.2
class-map	53.3
clear mls qos interface policer-counters	53.4
default-action	53.5
description (QoS policy map)	53.6
egress-rate-limit	53.7
match access-group	53.8
match cos	53.9
match dscp	53.10
match inner-cos	53.11
match inner-vlan	53.12
match ip-precedence	53.13
match mac-type	53.14
match protocol	53.15
match tcp-flags	53.18
match vlan	53.19
mls qos enable	53.20
mls qos map cos-queue to	53.21
mls qos map premark-dscp to	53.22
no police	53.23
police single-rate action	53.24
police twin-rate action drop-red	53.26
policy-map	53.28
priority-queue	53.28
remark-map	53.29
remark new-cos	53.30
service-policy input	53.32
set ip next-hop (PBR)	53.33
show class-map	53.34
show mls qos interface	53.34
show mls qos interface policer-counters	53.37
show mls qos interface queue-counters	53.38
show mls qos interface storm-status	53.39
show mls qos maps cos-queue	53.40
show mls qos maps premark-dscp	53.41
show policy-map	53.42
storm-action	53.43
storm-downtime	53.44
storm-protection	53.45
storm-rate	53.46
storm-window	53.47
trust dscp	53.48
wrr-queue egress-rate-limit queues	53.49
wrr-queue weight queues	53.50

Command List

This chapter provides an alphabetical reference for Quality of Service commands. For more information, see [Chapter 52, Quality of Service \(QoS\)](#) and [Chapter 51, Access Control List \(ACL\) Commands](#).

class

Use this command to associate an existing class map to a policy or policy map (traffic classification), and to enter Policy Map Class Configuration mode to configure the class map. Use the `no` parameter with this command to delete an existing class-map.

For more information on class-maps and policy maps, see the following sections: “[Class Maps](#)” on page 52.7 and “[Policy Maps](#)” on page 52.10.

Note: If your class map does not exist, you can create it by using the [class-map](#) command.

Syntax

```
class {<name>|default}
no class <name>
```

Parameter	Description
<name>	name of the (already existing) class map
default	specify the default class map
no	delete the named class map

Mode Policy Map Class

Example The following example creates the policy map `pmap1` (using the `policy-map` command), then associates this to an already existing class map named `cmap1`.

```
awplus# configure terminal
awplus(config)# policy-map pmap1
awplus(config-pmap)# class cmap1
awplus(config-pmap-c)#
```

Related Commands

- [class-map](#)
- [policy-map](#)

class-map

Use this command to create a class map.

Syntax `class-map <name>`
 `no class-map <name>`

Parameter	Description
<name>	name of the class map to be created
no	delete the named class map

Mode Global Configuration

Example This example creates a class-map called `cmap1`:

```
awplus# configure terminal
awplus(config)# class-map cmap1
awplus(config-cmap)#
```

clear mls qos interface policer-counters

Resets an interface's policer counters to zero. This can either be for a specific class-map or for all class-maps.

Syntax `clear mls qos interface <port> policer-counters
[class-map <class_map>]`

Parameter	Description
clear	Reset functions
mls	Multi-Layer Switch (L2/L3).
qos	Quality of Service.
interface	Select an interface
<port>	The port may be a switch port (e.g., port1.1.4), a static channel group (e.g., sa3), or an LACP channel group (e.g., po4).
policer-counters	Reset policer counters
class-map	Select a class-map
<class_map>	Class-map name

Mode Privileged Exec

Example To reset the policy counters to zero for all class maps for port1.0.1:

```
awplus# clear mls qos interface port1.0.1 policer-counters
```

Related Commands [show mls qos interface policer-counters](#)

default-action

Sets the action for the default class-map belonging to a particular policy-map. The action for a non-default class-map depends on the action of any ACL that is applied to the policy-map.

The default action can therefore be thought of as specifying the action that will be applied to any data that does not meet the criteria specified by the applied matching commands.

Use the `no default-action` command to reset to the default action of 'permit'.

Syntax `default-action [permit|deny|send-to-cpu|copy-to-cpu|copy-to-mirror|
send-to-mirror]`
`no default-action`

Parameter	Description
<code>no</code>	negate a command or set its defaults
<code>default-action</code>	specify or reset the action for the default class-map
<code>permit</code>	packets to permit
<code>deny</code>	packets to deny
<code>send-to-cpu</code>	specify packets to send to the CPU
<code>copy-to-cpu</code>	specify packets to copy to the CPU
<code>copy-to-mirror</code>	specify packets to copy to the mirror port
<code>send-to-mirror</code>	specify packets to send to the mirror port

Mode Policy Map

Example To set the action for the default class-map to deny

```
awplus(config-pmap)# default-action deny
```

description (QoS policy map)

Adds a textual description of the policy-map. This can be up to 80 characters long.

Use the no description command to remove the current description from the policy-map.

Syntax `description <line>`

`no description`

Parameter	Description
no	Negate a command or set its defaults
description	Specify or remove policy-map description
<line>	Up to 80 character long line description

Mode Policy Map

Example To add the description, VOIP traffic:

```
awplus(config-pmap)# description VOIP traffic
```

egress-rate-limit

Sets a limit on the amount of traffic that can be transmitted per second from this port. The default unit is in Kb, but Mb or Gb can also be specified. The minimum is 64 Kb.

Use the no egress-rate-limit command to disable the limiting of traffic egressing on the interface.

Syntax `egress-rate-limit <bandwidth>`

Parameter	Description
<code>egress-rate-limit</code>	Limits the amount of traffic egressing the interface
<code><bandwidth></code>	Bandwidth <1-10000000 kbits per second> (usable units : k, m, g)

`no egress-rate-limit`

Parameter	Description
<code>no</code>	Negate a command or set its defaults
<code>egress-rate-limit</code>	Disables the limiting of traffic egressing the interface

Mode Interface Configuration

Usage The egress rate limit can be configured in multiples of 64kbps. If you configure a value that is not an exact multiple of 64kbps, then the value will be rounded up to the nearest higher exact multiple of 64kbps. Note that the command syntax is not case sensitive, so a value such as 20 mb will be taken to mean 20 mega bits.

Examples To enable egress rate limiting on a port enter the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1
awplus(config-if)# egress-rate-limit 64k
% Egress rate limit has been set to 64 Kb
```

To disable egress rate limiting on a port enter the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1
awplus(config-if)# no egress-rate-limit
```

match access-group

Use this command to define match criterion for a class map.

Syntax `match access-group <group-number>`
`no match access-group <group-number>`

Parameter	Description
<code>access-group</code>	Used to apply an access control list of the same number
<code><group-number></code>	The access-group number (this will have the same number as the access list it is applying). The number selected can be any between the following ranges: 3000 to 3699 and 4000 to 4699.
<code>no</code>	Negate a command or set its defaults

Mode Global Configuration

Usage First create an access list that applies the appropriate permit, deny requirements etc. Then use the match access-group command to apply this access list for matching to a class map. Note that this command will apply the access list matching only to *incoming* data packets.

Example The following example configures a class map named `cmap1` with one match criterion: `access-list 3001`, which allows traffic from any source to any destination:

```
awplus# configure terminal
awplus(config)# access-list 3001 permit any any
awplus(config)# class-map cmap1
awplus(config-cmap)# match access-group 3001
```

Related Commands [class-map](#)

match cos

Sets the CoS for a class-map to match on. Use the `no match cos` command to remove CoS.

Syntax `match cos <0-7>`
`no match cos`

Parameter	Description
<code>match</code>	Specifies that this is a match command
<code>cos<0-7></code>	Specifies the CoS value
<code>no</code>	Negate a command or set its defaults

Mode Class Map

Examples To set the class-map's CoS to 4:

```
awplus# config terminal
awplus(config)# class-map cmap1
awplus(config-cmap)# match cos 4
```

To remove CoS from a class-map:

```
awplus# config terminal
awplus(config)# class-map cmap1
awplus(config-cmap)# no match cos
```

match dscp

Use this command to define the DSCP to match against incoming packets.

Use the `no match dscp` command to remove a previously defined DSCP.

Syntax `match dscp <0-63>`

`no match dscp`

Parameter	Description
<code>match</code>	Define the match criteria
<code><0-63></code>	Specify DSCP value (only one value can be selected)
<code>no</code>	Negate a command or set its defaults

Mode Class Map

Usage Use the `match dscp` command to define the match criterion after creating a class map.

Examples To configure a class map named `cmap1` with criterion that matches IP DSCP 56.

```
awplus# configure terminal
awplus(config)# class-map cmap1
awplus(config-cmap)# match dscp 56
```

To remove a previously defined DSCP from a class map named `cmap1`:

```
awplus# configure terminal
awplus(config)# class-map cmap1
awplus(config-cmap)# no match dscp
```

Related Commands [class-map](#)

match inner-cos

Sets the Inner CoS for a class-map to match on. Use the no match inner-cos to remove CoS.

Syntax `match inner-cos <0-7>`

`no match inner-cos`

Parameter	Description
<code>match</code>	Define the match criteria
<code>inner-cos<0-7></code>	Specify the Inner CoS value
<code>no</code>	Negate a command or set its defaults

Mode Class Map

Examples To set the class-map's inner-cos to 4:

```
awplus# config terminal
awplus(config)# class-map cmap1
awplus(config-cmap)# match inner-cos 4
```

To remove CoS from the class_map:

```
awplus# config terminal
awplus(config)# class-map cmap1
awplus(config-cmap)# no match inner-cos
```

match inner-vlan

Use this command to define the inner VLAN ID used as match criteria to classify a traffic class. Use the no parameter with this command to disable the VLAN ID used as match criteria.

Syntax `match inner-vlan <1-4094>`
`no match inner-vlan`

Parameter	Description
match	Define the match criteria
vlan	Virtual Local Area Network
<1-4094>	The VLAN number
no	Negate a command or set its defaults

Mode Class Map

Usage This command is used in double-tagged networks to match on a VLAN VID belonging to the client network. For more information on VLAN double-tagged networks, see [“VLAN Double Tagging \(VLAN Stacking\)” on page 16.5](#).

Examples To configure a class-map named `cmap1` to include traffic from inner VLAN 3:

```
awplus# config terminal
awplus(config)# class-map cmap1
awplus(config-cmap)# match inner-vlan 3
```

To disable the configured VLAN ID as a match criteria for the class-map named `cmap1`:

```
awplus# config terminal
awplus(config)# class-map cmap1
awplus(config-cmap)# no match inner-vlan
```

match ip-precedence

Use this command to identify IP precedence values as match criteria.

Use the no parameter with this command to remove IP precedence values from a class map.

Syntax `match ip-precedence <0-7>`
`no match ip-precedence`

Parameter	Description
<code>match</code>	Define the match criteria
<code>ip-precedence</code>	The precedence value set in the IPv4 header
<code><0-7></code>	The precedence value to be matched
<code>no</code>	Negate a command or set its defaults

Mode Class Map

Example To configure a class-map named `cmap1` to evaluate all IPv4 packets for a precedence value of 5:

```
awplus# configure terminal
awplus(config)# class-map cmap1
awplus(config-cmap)# match ip-precedence 5
```

match mac-type

Sets the mac type for a class-map to match on. Use no match mac-type to remove mac type.

Syntax `match mac-type {l2broadcast|l2mcast|l2ucast}`
`no match mac-type`

Parameter	Description
match	Define the match criteria
mac-type	Specify MAC type
l2broadcast	Layer 2 Broadcast
l2mcast	Layer 2 Multicast
l2ucast	Layer 2 Unicast
no	Negate a command or set its defaults

Mode Class Map

Examples To set the class-map's MAC type to layer 2 broadcast:

```
awplus# config terminal
awplus(config)# class-map cmap1
awplus(config-cmap)# match mac-type l2broadcast
```

To remove the class-map's MAC type:

```
awplus# config terminal
awplus(config)# class-map cmap1
awplus(config-cmap)# no match mac-type
```

match protocol

Sets the ethernet format and protocol for a class-map to match on.

Select one layer two eth-format “and” one layer three protocol.

Use the no match protocol eth-format command to remove ethernet format and protocol from a class-map.

Syntax `match eth-format {<layer-two-format>} protocol {<layer-three-protocol>}`

Parameter	Description
<i><layer-two-formats></i>	
eth-format	Specifies that an ethernet format type will follow this parameter
802dot2-tagged	802.2 Tagged Packets (enter the parameter name)
802dot2-untagged	802.2 Untagged Packets (enter the parameter name)
ethii-tagged	EthII Tagged Packets (enter the parameter name)
ethii-untagged	EthII Untagged Packets (enter the parameter name)
netwareraw-tagged	Netware Raw Tagged Packets (enter the parameter name)
netwareraw-untagged	Netware Raw Untagged Packets (enter the parameter name)
snap-tagged	SNAP Tagged Packets (enter the parameter name)
snap-untagged	SNAP Untagged Packets (enter the parameter name)
<i><layer-three-protocols></i>	
protocol	Specifies that a layer three network protocol type will follow this parameter
<word>	A Valid Protocol Number in hexadecimal
any	Any protocol
sna-path-control	Protocol Number 04 (enter the parameter name or its number)
proway-lan	Protocol Number 0E (enter the parameter name or its number)
eia-rs Protocol	Number 4E (enter the parameter name or its number)
proway Protocol	Number 8E (enter the parameter name or its number)
ipx-802dot2	Protocol Number E0 (enter the parameter name or its number)
netbeui	Protocol Number F0 (enter the parameter name or its number)

Parameter	Description
iso-clns-is	Protocol Number FE (enter the parameter name or its number)
xdot75-internet	Protocol Number 0801(enter the parameter name or its number)
nbs-internet	Protocol Number 0802 (enter the parameter name or its number)
ecma-internet	Protocol Number 0803 (enter the parameter name or its number)
chaosnet	Protocol Number 0804 (enter the parameter name or its number)
xdot25-level-3	Protocol Number 0805 (enter the parameter name or its number)
arp Protocol	Number 0806 (enter the parameter name or its number)
xns-compatible	Protocol Number 0807 (enter the parameter name or its number)
banyan-systems	Protocol Number 0BAD (enter the parameter name or its number)
bbn-simnet	Protocol Number 5208 (enter the parameter name or its number)
dec-mop-dump-ld	Protocol Number 6001 (enter the parameter name or its number)
dec-mop-rem-cdots	Protocol Number 6002 (enter the parameter name or its number)
dec-decnet	Protocol Number 6003 (enter the parameter name or its number)
dec-lat	Protocol Number 6004 (enter the parameter name or its number)
dec-diagnostic	Protocol Number 6005 (enter the parameter name or its number)
dec-customer	Protocol Number 6006 (enter the parameter name or its number)
dec-lavc	Protocol Number 6007 (enter the parameter name or its number)
rarp	Protocol Number 8035 (enter the parameter name or its number)
dec-lanbridge	Protocol Number 8038 (enter the parameter name or its number)
dec-encryption	Protocol Number 803D (enter the parameter name or its number)
appletalk	Protocol Number 809B (enter the parameter name or its number)

Parameter	Description
ibm-sna	Protocol Number 80D5 (enter the parameter name or its number)
appletalk-aarp	Protocol Number 80F3 (enter the parameter name or its number)
snmp	Protocol Number 814Cv
ethertalk-2	Protocol Number 809B (enter the parameter name or its number)
ethertalk-2-aarp	Protocol Number 80F3 (enter the parameter name or its number)
ipx-snap	Protocol Number 8137 (enter the parameter name or its number)
ipx-802dot3	Protocol Number FFFF (enter the parameter name or its number)
ip	Protocol Number 0800 (enter the parameter name or its number)
ipx	Protocol Number 8137 (enter the parameter name or its number)
ipv6	Protocol Number 86DD (enter the parameter name or its number)

Syntax `no match {{eth-format protocol}}|{protocol eth-format}}`

Parameter	Description
no	Negate a command or set its defaults
match	Define the match criteria
eth-format	Specify Ethernet format
protocol	Specify Protocol

Mode Class Map

Examples To remove the eth-format and protocol from the class-map:

```
awplus# config terminal
awplus(config)# class-map
awplus(config-cmap)# no match eth-format protocol
```

The following command sets the class-map's eth-format to ethii-tagged and protocol to 0800 (IP).

```
awplus# config terminal
awplus(config)# class-map
awplus(config-cmap)# match eth-format ethii-tagged protocol
0800
or
awplus(config-cmap)# match eth-format ethii-tagged protocol ip
```

match tcp-flags

Sets one or more tcp flags (control bits) for a class-map to match on.

Syntax `match tcp-flags {[ack][fin][rst][syn][urg]}`
`no match tcp-flags {[ack][fin][rst][syn][urg]}`

Parameter	Description
match	Define the match criteria
tcp-flags	Specify TCP flags
ack	Acknowledge
fin	Finish
rst	Reset
syn	Synchronize
urg	Urgent
no	Negate a command or set its defaults

Mode Class Map

Examples To set the class-map's tcp flags to ack and syn:

```
awplus# config terminal
awplus(config)# class-map
awplus(config-cmap)# match tcp-flags ack syn
```

To remove the tcp-flags ack and rst:

```
awplus# config terminal
awplus(config)# class-map
awplus(config-cmap)# no match tcp-flags ack rst
```


match vlan

Use this command to define the VLAN ID used as match criteria to classify a traffic class. Use the no parameter with this command to disable the VLAN ID used as match criteria.

Syntax `match vlan <1-4094>`
`no match vlan`

Parameter	Description
<code>match</code>	Define the match criteria
<code>vlan</code>	Virtual Local Area Network
<code><1-4094></code>	The VLAN number
<code>no</code>	Negate a command or set its defaults

Mode Class Map Mode

Examples To configure a class-map named `cmap1` to include traffic from VLAN 3:

```
awplus# config terminal
awplus(config)# class-map cmap1
awplus(config-cmap)# match vlan 3
```

To disable the configured VLAN ID as a match criteria for the class-map named `cmap1`:

```
awplus# config terminal
awplus(config)# class-map cmap1
awplus(config-cmap)# no match vlan
```

mls qos enable

Use this command to globally enable QoS on the switch or stack.

Use the no variant of this command to globally disable QoS and remove all QoS configuration.

Mode Global Configuration mode

Syntax mls qos enable
no mls qos

Parameter	Description
mls	Multi-Layer Switch(L2/L3)
qos	Quality of Service
enable	enables QoS
no	Removes all QoS configuration. It removes all class-maps policy-maps policers queue-sets that have been created. ¹

1. Running the no mls qos command will therefore remove all pre-existing QoS configurations on the switch.

Example To enable QoS on the switch:

```
awplus# config terminal
awplus(config)# mls qos enable
```

mls qos map cos-queue to

Used to set the default CoS to queue mapping. This is the default queue mapping for packets that do not get assigned a queue via any other QoS functionality.

Use the `no mls qos map cos-queue` command to reset the cos-queue map back to its default setting. The default mappings for this command are: For more information see, [“Mapping CoS tags to traffic types” on page 52.12](#).

```
CoS Priority :      0 1 2 3 4 5 6 7
-----
CoS QUEUE:        2 0 1 3 4 5 6 7
```

Syntax `mls qos map cos-queue <cos-priority> to <queue-number>`
`no mls qos map cos-queue`

Parameter	Description
mls	Multi-Layer Switch(L2/L3)
qos	Quality of Service
map	Specify maps
cos-queue	Modify the CoS to queue map
<cos-priority>	CoS priority value, Can take a value 0 to 7
to	
<queue-number>	Queue number. Can take a value 0 to 7
no	Negate a command or set its defaults

Mode Global Configuration

Examples To set the cos-queue map back to its defaults, use the command:

```
awplus# config terminal
awplus(config)# no mls qos map cos-queue
```

:To map CoS 2 to queue 3:

```
awplus# config terminal
awplus(config)# mls qos map cos-queue 2 to 3
```

Related Commands [show mls qos interface](#)

mls qos map premark-dscp to

Configures the premark-dscp map. This is used when traffic is classified by a class-map that has [trust dscp](#) configured. Based on a lookup DSCP, the map determines a new DSCP, COS, queue and bandwidth class for the traffic.

The no variant of this command resets the premark-dscp map to its defaults. This is used when traffic is classified by a class-map that has [trust dscp](#) configured. Based on a lookup DSCP, the map determines a new DSCP, COS, queue and bandwidth class for the traffic.

Syntax

```
mls qos map premark-dscp <0-63> to {[new-dscp <0-63>]
[new-cos<0-7>] [new-bandwidth-class{green|yellow|red}]}
```

```
no mls qos map premark-dscp [<0-63>]
```

Parameter	Description
premark-dscp<0-63>	The DSCP value on ingress
new-dscp<0-63>	The DSCP value that the packet will have on egress. If unspecified, this value will remain the DSCP ingress value.
new-cos<0-7>	The CoS value that the packet will have on egress. If unspecified, this value will be set to zero.
new-bandwidth-class	Modify Egress Bandwidth-class. If unspecified, this value will be set to green.
green	Egress Bandwidth-class green (marked down Bandwidth-class)
yellow	Egress Bandwidth-class yellow (marked down Bandwidth-class)
red	Egress Bandwidth-class red (marked down Bandwidth-class)

Mode Global Configuration

Examples To set the entry for DSCP 1 to use a new DSCP of 2, a new CoS of 3, a new queue of 4 and a new bandwidth class of yellow, use the command:

```
awplus# config terminal
```

```
awplus(config)# mls qos map premark-dscp 1 to new-dscp 2 new-
cos 3 new-queue 4 new-bandwidth-class yellow
```

To reset the entry for DSCP 1 use the command:

```
awplus# config terminal
```

```
awplus(config)# no mls qos map premark-dscp 1
```

Related Commands [show mls qos maps premark-dscp](#)
[trust dscp](#)

no police

Disables any policer previously configured on the class-map.

Syntax `no police`

Parameter	Description
<code>no</code>	Negate a command or set its defaults
<code>police</code>	Disable policing of traffic

Mode Priority Map Class

Usage This command disables any policer previously configured on the class-map

Example To disable policing on a class-map use the command:

```
awplus# config
awplus(config)# policymap name
awplus(config-pmap)# class classname
awplus(config-pmap-c)# no police
```

Related Commands [police single-rate action](#)
[police twin-rate action drop-red](#)

police single-rate action

Configures a single-rate policer for a class-map.

Syntax `police single-rate <cir> <cbs> <ebs> action
{drop-red|remark-transmit}`

Parameter	Description
<code>police</code>	Specify a policer for the classified traffic.
<code>single-rate</code>	Single rate meter (one rate and two burst sizes).
<code><cir></code>	Specify the Committed Information Rate (CIR) (1-16000000 kbps).
<code><cbs></code>	Specify the Committed Burst Size (CBS) (0-16777216 bytes).
<code><ebs></code>	Specify a Excess Burst Size (EBS) (0-16777216 bytes).
<code>action</code>	Specify the action if rate is exceeded.
	<code>drop-red</code> Drop the red packets.
	<code>remark-transmit</code> Modify the packets using the <i>remark map</i> , then transmit. You can configure the remark map using the remark-map command on page 53.29 .

Mode Policy Map Class

Usage A policer can be used to meter the traffic classified by the class-map and as a result will be given one of three bandwidth classes. These are green (conforming), yellow (partially-conforming), and red (non-conforming). A single-rate policer is based on three values. These are the average rate, minimum burst and maximum burst.

Color	Definition
<code>green</code>	The traffic rate is less than the average rate and minimum burst.
<code>yellow</code>	The traffic rate is between the minimum burst and the maximum burst.
<code>red</code>	The traffic rate exceeds the average rate and the maximum burst.

Using an action of drop-red means that any packets classed as red will be discarded.

Note: *This command will not take effect when applied to a class map that attaches to a channel group whose ports span processor instances.*

Example To configure a single rate meter measuring traffic of 10 Mbps that drops any traffic bursting over 1024 bytes of this use the command:

```
awplus# config
awplus(config)# policy-map name
awplus(config-pmap)# class classname
awplus(config-pmap-c)# police single-rate 10000 512 1024 action
drop-red
```

Related Commands [no police](#)
[police twin-rate action drop-red](#)

police twin-rate action drop-red

Configures a twin-rate policer for a class-map.

Syntax `police twin-rate <cir> <pir> <cbs> <pbs> action {drop-red|remark-transmit}`

Parameter	Description
<code>police</code>	Specify a policer for the classified traffic.
<code>twin-rate</code>	Twin rate meter (two rates and two burst sizes)
<code><cir></code>	Specify the Committed Information Rate (CIR) (1-16000000 kbps).
<code><pir></code>	Specify the Peak Information Rate (PIR) (kbps).
<code><pbs></code>	Specify the Peak Burst Size (PBS) (0-16777216 bytes).
<code>action</code>	Specify the action if rate is exceeded.
<code>drop-red</code>	Drop the packet.
<code>remark-transmit</code>	Change packet per policed-dscp map and send it.

Mode Policy Map Class

Usage A policer can be used to meter the traffic classified by the class-map and as a result will be given one of three bandwidth classes. These are green (conforming), yellow (partially-conforming), and red (non-conforming).

A twin-rate policer is based on four values. These are the minimum rate, minimum burst size, maximum rate, and maximum burst size.

Bandwidth Class	Definition
<code>green</code>	The sum of the number of existing (buffered) bytes plus those arriving at the port per unit time, result in a value that is less than that set for the CBS.
<code>yellow</code>	The sum of the number of existing (buffered) bytes plus those arriving at the port per unit time, result in a value that is between those set for the CBS and the PBS
<code>red</code>	The sum of the number of existing (buffered) bytes plus those arriving at the port per unit time, result in a value that exceeds that set for the PBS

Using an action of drop-red means that any packets classed as red will be discarded.

When using an action of policed-dscp-transmit the packet will be remarked with the values configured in the policed-dscp map. The index into this map is determined by the DSCP in the packet.

Example To configure a twin rate meter measuring a minimum rate of 10 Mbps and a maximum rate of 20 Mbps that uses the policed-dscp map to remark any non-conforming traffic, use the command: bursting over 1024 bytes of this use the command:

```
awplus# config
awplus(config)# policy-map name
awplus(config-pmap)# class classname
awplus(config-pmap-c)# police twin-rate 10000 20000 1024 1024
                        action policed-dscp-transmit
```

Related Commands [no police](#)
[police twin-rate action drop-red](#)

policy-map

Use this command to create a policy map and to enter Policy Map Configuration mode to configure the specified policy map.

Syntax `policy-map <name>`
`no policy-map <name>`

Parameter	Description
<name>	name of the policy map
no	Use with this command to delete an existing policy map.

Mode Global Configuration

Example To create a policy-map called `pmap1` use the commands

```
awplus# configure terminal
awplus(config)# policy-map pmap1
awplus(config-pmap)#
```

Related Commands [class-map](#)

priority-queue

Configures strict priority based scheduling on the specified egress queues. You must specify at least one queue.

Syntax `priority-queue {1}[2][3][4][5][6][7][8]`

Parameter	Description
<code>priority-queue</code>	Configure priority based egress scheduling
<code>1 to 8</code>	Specifies the queues to apply the scheduling rule

Mode Interface Configuration

Example To apply priority based scheduling to egress queues 5, 6 and 7 use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.1.12
awplus(config-if)# priority-queue 5 6 7
```

remark-map

Configures the remark map. This command is applied when a policer is configured with the action parameter of the command, [police single-rate action](#) set to remark-transmit

Syntax `remark-map [bandwidth-class {green|yellow|red}] to {[new-dscp <0-63>][new-bandwidth-class {green|yellow|red}]}`
`no remark-map`

Parameter	Description
<i>remark-map</i>	Configure the map for remarking policed packets
<i>bandwidth-class</i>	Specify the bandwidth class of packets to remark
<i>green</i>	Remark green packets
<i>yellow</i>	Remark yellow packets
<i>red</i>	Remark red packets
<i>to</i>	To
<i>new-dscp</i>	Specify the new dscp value
<i><0-63></i>	The DSCP value
<i>new-bandwidth-class</i>	Specify the new bandwidth class
<i>green</i>	Remark the packet green
<i>yellow</i>	Remark the packet yellow
<i>red</i>	Remark the packet red
<i>no</i>	The no variant of this command resets the remark map to its defaults. Specifying the bandwidth class is optional. If no bandwidth class is specified, then all bandwidth classes are reset to their defaults.

Mode Policy Map Class

Examples To remark the policed green traffic to a new DSCP of 2 and a new bandwidth class of yellow, use the following commands

```
awplus# configure terminal
awplus(config)# policy-map pmap1
awplus(config-pmap)# class cmap1
awplus(config-pmap-c)# remark-map bandwidth-class green to
new-dscp 2 new-bandwidth-class yellow
```

To reset the DSCP for all bandwidth classes, use the following commands:

```
awplus# configure terminal
awplus(config)# policy-map pmap1
awplus(config-pmap)# class cmap1
awplus(config-pmap-c)# no remark-map to new dscp
```

remark new-cos

Enables you to configure and remark either or both the CoS flag in the data packet, and the input into the CoS to queue map thus changing the destination egress queue.

Syntax `remark new-cos <0-7> [internal|external|both]`
`no remark-map`

Parameter	Description
<code>remark</code>	Set new values for either (or both) the CoS tag and the input into the CoS to queue map.
<code>new-cos</code>	Remarks the original CoS value. Takes parameters external, internal or both. The default value is both.
<code>external</code>	remarks the CoS flag in the packet.
<code>internal</code>	remarks the new-CoS input into the CoS to queue map.
<code>both</code>	remarks (with the same value) both the CoS flag in the packet and the input to the CoS to queue map.
<code><0-7></code>	The new value for either the CoS flag or the input into the CoS to queue map.


Mode Policy Map Class

Usage The default CoS to Queue mappings are shown in the following table:

CoS Value	0	1	2	3	4	5	6	7
Egress Queue No	2	0	1	3	4	5	6	7

The relationship between this command and the CoS to queue map is shown in [Figure 53-1](#).

Figure 53-1: Remarking and the CoS to Q Map



CoS to Egress Queue Remarking Function

Input	Command	Output
CoS field = 1	Remark new-cos (not configured)	CoS value = 1 Packet sent to egress queue 0
CoS field = 1	Remark new-cos 2 external	CoS value = 2 Packet sent to egress queue 0
CoS set to 1	Remark new-cos 2 internal	CoS value = 1 Packet sent to egress queue 1
CoS set to 1	Remark new-cos 2 both	CoS value = 2 Packet sent to egress queue 1

Note: This table assumes that the CoS to Queue map is set to its default values.

Example For policy-map `pmap3` and class-map `cmap1`, set the CoS value to 2 and also set the input to the CoS to queue map so that the traffic is assigned to egress queue 1:

```
awplus# configure terminal
awplus(config)# policy-map pmap3
awplus(config-pmap)# class cmap1
awplus(config-pmap-c)# remark new-cos 2 both
```

Related Commands `mls qos map cos-queue to`
`show mls qos maps cos-queue`

service-policy input

Use this command to apply a policy map to the input of an interface.

Use the no parameter with this command to remove a policy map and interface association.

Syntax `service-policy input <policy-map>`
`no service-policy input <policy-map>`

Parameter	Description
<code><policy-map></code>	policy map name that the input will applied to.

Mode Interface Configuration

Usage This command can be applied to switch ports or static channel groups, but not to dynamic (LACP) channel groups.

Example To apply a policy map named `pmap1` to interface `port1.1.2`:

```
awplus# configure terminal
awplus(config)# interface port1.1.2
awplus(config-if)# service-policy input pmap1
```

set ip next-hop (PBR)

Forwards traffic matching this class map to the specified nexthop.

When this command is set, all packets that match a selected class map will be forwarded to the specified nexthop.

The no variant of this command removes the next-hop address (in the context of its policy-map and class-map) from the configuration.

Syntax `set ip next-hop <ip-addr>`

`no set ip next-hop`

Parameter	Description
<ip-addr>	The IP address of the next hop destination.

Mode Policy Map Class

Usage In typical deployments of policy-based routing, some traffic types require normal routing (i.e. via the routes in the IP routing table) while other traffic types require policy based routing.

Where the traffic to be policy routed is a subset of the traffic that is to be normally routed, then the configuration is reasonably simple. The policy-map will contain one or more classes that match the traffic to be policy routed, and will have their next-hop configured by this command - set ip next-hop (PBR). The remaining traffic will be conventionally routing routed according to the rules set for the default class - providing that this is not subject to the set ip next-hop (PBR).

The situation becomes a little more complex where the traffic requiring normal routing is a subset of the traffic to be policy-routed. In this situation the policy-map would need to contain one, or more, classes that match the requirement for normal routing. These classes would not be configured with a set ip next-hop (PBR) command. Then the remaining traffic classes that require normal routing would have the set ip next-hop (PBR) command applied to them. Note that this traffic could be just the default class, if ALL other traffic types were to be policy-routed.

Also note that the order in which the classes are configured in the policy-map is important; because traffic is matched against the classes in the order that they were assigned to the policy map.

Details of a practical example of such a policy-based routing is shown in [“Policy-Based Routing” on page 52.24.](#)

Example To forward a packet to a 192.168.1.1 use the commands:

```
awplus# configure terminal
awplus(config)# policy-map pmap1
awplus(config-pmap)# class cmap1
awplus(config-pmap-c)# set ip next-hop 192.168.1.1
```

show class-map

Use this command to display the QoS class maps to define the match criteria to classify traffic.

Syntax `show class-map <class-map name>`

Parameter	Description
<code><class-map name></code>	name of the class map.

Mode Exec and Privileged Exec

Example To display the QoS class maps to define the match criteria to classify traffic, use the command:

```
awplus# show class-map cmap1
```

Output Figure 53-2: Example output from the **show class-map** command

```
CLASS-MAP-NAME: cmap1
    Set IP DSCP: 56
    Match IP DSCP: 7
```

Related Commands `class-map`

show mls qos interface

Displays the current settings for the interface. This includes its default CoS and queue, scheduling used for each queue, and any policies/maps that are attached.

Syntax `show mls qos interface [<port>]`

Parameter	Description
<code><port></code>	Switch port

Mode Exec and Privileged Exec

Example To display current CoS and queue settings for interface `port1.0.1`, use the command:

```
awplus# show mls qos interface port1.0.1
```


Output Figure 53-3: Example output from the **show mls qos interface** command

```

Default CoS: 7
Default Queue: 7
Number of egress queues: 8
Queue Set: 1
Egress Queue: 0
  Status: Enabled
  Scheduler: Strict Priority
  Queue Limit: 12%
  Egress Rate Limit: 0 Kb
Egress Queue: 1
  Status: Enabled
  Scheduler: Strict Priority
  Queue Limit: 12%
  Egress Rate Limit: 0 Kb
Egress Queue: 2
  Status: Enabled
  Scheduler: Strict Priority
  Queue Limit: 12%
  Egress Rate Limit: 0 Kb
Egress Queue: 3
  Status: Enabled
  Scheduler: Wrr Group 2
  Weight: 10
  Queue Limit: 12%
  Egress Rate Limit: 0 Kb
Egress Queue: 4
  Status: Enabled
  Scheduler: Wrr Group 1
  Weight: 10
  Queue Limit: 12%
  Egress Rate Limit: 0 Kb
Egress Queue: 5
  Status: Enabled
  Scheduler: Strict Priority
  Queue Limit: 12%
  Egress Rate Limit: 0 Kb
Egress Queue: 6
  Status: Enabled
  Scheduler: Strict Priority
  Queue Limit: 12%
  Egress Rate Limit: 0 Kb
Egress Queue: 7
  Status: Enabled
  Scheduler: Strict Priority
  Queue Limit: 12%
  Egress Rate Limit: 0 Kb

```

Output Parameter	Meaning
Default CoS	The default CoS priority that will be applied to all packets arriving on this interface.
Default Queue	The default queue that will be applied to all packets arriving on this interface.
Number of egress queues	The total number of egress queues available on this interface.
Queue Set	Drop queue set that has been applied to the port. This could either be operating in threshold or random-detect mode.
Egress Queue X	Number of this egress queue.

Output Parameter	Meaning
Status	Queue can either be enabled or disabled.
Scheduler	The scheduling mode being used for servicing the transmission of packets on this port.
Queue Limit	The percentage of the ports buffers that have been allocated to this queue.
Egress Rate Limit	The amount of traffic that can be transmitted via this queue per second. 0 Kb means there is currently no rate-limiting enabled.

show mls qos interface policer-counters

Display an interface's policer counters. This can either be for a specific class-map or for all class-maps attached to the interface. If no class-map is specified all class-map policer counters attached to the interface will be displayed.

These are the counters based on metering performed on the specified class-map. Therefore, the 'Dropped packets' counter is the number of bytes dropped due to metering. This is different from the packets dropped via a 'deny' action in the ACL.

You must enable the QoS counter platform enhancemode before running this command.

Syntax `show mls qos interface <port> policer-counters [class-map <class_map>]`

Parameter	Description
show	Show running system information
mls	Multi-Layer Switch(L2/L3)
qos	Quality of Service
interface	Select an interface
<port>	Switch port
policer-counters	Display policer counters
class-map	Select a class-map
<class_map>	Class-map name

Mode Exec and Privileged Exec

Example To show the counters for all class-maps attached to port1.0.1 enter the command:

```
awplus# show mls qos interface port1.0.1 policier-counters
```

Output Figure 53-4: Example output from the **show mls qos interface policer-counters** command

```
Interface:          port1.0.1
Class-map:          cmap1
Aggregate Bytes:    128
Green Bytes:        128
Yellow Bytes:       0
Red Bytes:          0
Dropped Bytes:      0
```

show mls qos interface queue-counters

Display an interface's egress queue counters. This can either be for a specific queue or for all queues on the interface. If no queue is specified all queue counters on the interface will be displayed.

The counters show the number of frames currently in the queue and the maximum number of frames allowed in the queue, for individual egress queues and the port's queue (which will be a sum of all eight egress queues).

Syntax `show mls qos interface <port> queue-counters queue [<0-7>]`

Parameter	Description
show	Show running system information
mls	Multi-Layer Switch (L2/L3)
qos	Quality of Service
interface	Select an interface
<port>	Switch port.
queue-counters	Display queue counters
queue	Select a queue
<0-7>	Queue

Mode Exec and Privileged Exec

Example To show the counters for all queues on port1.0.1 enter the command:

```
awplus# show mls qos interface port1.0.1 queue-counters
```

Output Figure 53-5: Example output from the **show mls qos interface queue-counters** command

```
Interface port1.0.1 Queue Counters:
  Port queue length      0 (maximum 896)
  Egress Queue length:
    Queue 0              0 (maximum 112)
    Queue 1              0 (maximum 112)
    Queue 2              0 (maximum 112)
    Queue 3              0 (maximum 112)
    Queue 4              0 (maximum 112)
    Queue 5              0 (maximum 112)
    Queue 6              0 (maximum 112)
    Queue 7              0 (maximum 112)
```

Output Parameter	Meaning
Interface	Port we are showing the counters for
Port queue length	Number of frames in the port's queue. This will be the sum of all egress queues on the port.
Egress Queue length	Number of frames in a specific egress queue.

show mls qos interface storm-status

Show the current configuration and status of the QoS Storm Protection (QSP) on the given port.

Syntax `show mls qos interface <port> storm-status`

Parameter	Description
show	Show running system information
mls	Multi-Layer Switch (L2/L3)
qos	Quality of Service
interface	Select an interface
<port>	Switch port.
storm-status	Display storm-status

Mode Exec and Privileged Exec

Examples To see the QSP status on port1.0.1, use command:

```
awplus# show mls qos interface port1.0.1 storm-status
```

Output Figure 53-6: Example output from the **show mls qos interface storm-status** command

```
Interface:          port1.0.1
Storm-Protection:   Enabled
Port-status:       Enabled
Storm Action:       vlandisable
Storm Window:       5000 ms
Storm Downtime:     0 s
Timeout Remaining:  0 s
Last read data-rate: 0 kbps
Storm Rate:         1000 kbps
```

Related Commands

- storm-action
- storm-downtime
- storm-protection
- storm-rate
- storm-window

show mls qos maps cos-queue

Syntax show mls qos maps cos-queue

Parameter	Description
show	Show running system information
mls	Multi-Layer Switch(L2/L3)
qos	Quality of Service
maps	Select QoS map
cos-queue	Queue to CoS priority map

Mode Exec and Privileged Exec

Examples To display the current configuration of the `cos-queue` map, use the command:

```
awplus# show mls qos maps cos-queue
```

Output Figure 53-7: Example output from the **show mls qos maps cos-queue** command

```
COS-TO-QUEUE-MAP:
COS :          0 1 2 3 4 5 6 7
-----
QUEUE:         0 7 1 3 4 5 6 7
```

Related Commands mls qos map cos-queue to

show mls qos maps premark-dscp

Displays the premark-dscp map. This map is used when the [trust dscp](#) command has been specified for a policymap's class-map to replace the DSCP, CoS, queue, and bandwidth class of a packet matching the class-map based on a lookup DSCP value.

Syntax `show mls qos maps premark-dscp [<0-63>]`

Parameter	Description
show	Show running system information
mls	Multi-Layer Switch(L2/L3)
qos	Quality of Service
maps	Select QoS map
premark-dscp	Premark-dscp map
<0-63>	DSCP table entry

Mode Exec and Privileged Exec

Examples To display the premark-dscp map for DSCP 1 enter the command:

```
awplus# show mls qos maps premark-dscp 1
```

Output Figure 53-8: Example output from the [show mls qos maps premark-dscp](#) command

```
PREMARK-DSCP-MAP:
DSCP 1
Bandwidth Class      Green      Yellow      Red
-----
New DSCP              1          -          -
New CoS               0          -          -
New Queue             0          -          -
New Bandwidth Class   green      -          -
```

Related Commands [mls qos map premark-dscp to trust dscp](#)

show policy-map

Displays the policy-maps configured on the switch. The output also shows whether or not they are connected to a port (attached / detached) and shows their associated class-maps.

Syntax `show policy-map [<name>]`

Parameter	Description
show	Show running system information
policy-map	The policy maps configured on the switch
<name>	The name of a specific policy map

Mode Exec and Privileged Exec

Examples To display a listing of the policy-maps configured on the switch:

```
awplus# show policy-map
```

Output Figure 53-9: Example output from the **show policy-map** command

```
POLICY-MAP-NAME: general-traffic
State: attached
  Default class-map action: permit
CLASS-MAP-NAME: default
CLASS-MAP-NAME: database-traffic
```

Related Commands [service-policy input](#)

storm-action

Sets the action to take when triggered by QoS Storm Protection (QSP). There are three available options:

- PORTDISABLE will disable the port in SW.
- VLANDISABLE will disable the port from the vlan matched by the class-map in class-map.
- LINKDOWN will physically bring the port down. The VLANDISABLE requires the match vlan class-map to be present in the class-map.

Syntax `storm-action {portdisable|vlandisable|linkdown}`
`no storm-action`

Parameter	Description
<code>storm-action</code>	Action to take at the storm detection
<code>portdisable</code>	Disables the port in software
<code>vlandisable</code>	Disables the vlan
<code>linkdown</code>	Shutdown the port physically
<code>no</code>	Negate a command or set its defaults

Mode Policy Map Class

Examples To apply the storm protection of vlandisable to the policy map named `pmap2`, and the class-map named `cmap1`, use commands:

```
awplus(config)# policy map pmap2
awplus(config-cmap)# class-map cmap1
awplus(config-pmap-c# storm-action vlandisable
```

Related Commands `storm-downtime`
`storm-protection`
`storm-rate`
`storm-window`

storm-downtime

Sets the time to re-enable the port once disabled by QoS Storm Protection (QSP). The time is given in seconds, from a minimum of one second to maximum of 86400 seconds (i.e. one day).

Syntax storm-downtime <1-86400>
 no storm-downtime

Parameter	Description
storm-downtime	time before resetting the storm action
<1-86400>	seconds
no	resets the default value

Default 10 seconds

Mode Priority Map Class

Examples To re-enable the port in 1 minute, use command:

```
awplus(config)# class-map cmap2
awplus(config-cmap)# class cmap1
awplus(config-pmap-c)# storm-downtime 60
```

Related Commands storm-action
 storm-protection
 storm-rate
 storm-window

storm-protection

Enables the Policy Based Storm Protection (such as QSP - QoS Storm Protection).

Syntax `storm-protection`
`no storm-protection`

Parameter	Description
<code>storm-protection</code>	Policy-based storm protection
<code>no</code>	Negate a command or set its defaults

Mode Policy Map Class

Examples To enable QSP on `cmap2` in `pmap2`, use the commands:

```
awplus# policy-map pmap2
awplus(config-pmap)# class-map cmap2
awplus(config-pmap-c)# storm-protection
```

Related Commands `storm-action`
`storm-downtime`
`storm-rate`
`storm-window`
`storm-downtime`
`storm-protection`
`storm-rate`
`storm-window`

storm-rate

Sets the data rate that triggers the storm-action. The rate is in kbps and the range is from 1kbps to 10Gbps.

Note that this setting is made in conjunction with the `Storm Window` command.

Syntax `storm-rate <1-10000000>`
`no storm-rate`

Parameter	Description
<code>storm-rate</code>	Data limit in Kbps to trigger the storm action
<code><1-10000000></code>	The range of the storm-rate
<code>no</code>	Negate a command or set its defaults

Default No default

Mode Policy Map Class

Usage Note that this setting is made in conjunction with the [storm-window command on page 53.47](#).

Examples To the limit to 1Mbps, use the commands:

```
awplus# policy-map pmap2
awplus(config-pmap)# class-map cmap2
awplus(config-pmap-c)# storm-rate 1000
```

Related Commands [storm-action](#)
[storm-downtime](#)
[storm-protection](#)
[storm-window](#)

storm-window

Sets the window size of QoS Storm Protection (QSP). This sets the time to poll the data-rate every given milliseconds. Minimum window size of 100 ms and the maximum is 60 sec.

Syntax `storm-window <100-60000>`

Parameter	Description
<code>storm-window</code>	The time interval in milliseconds to check for the storm.
<code><100-60000></code>	The window size, measured in milliseconds.
<code>no</code>	Negate a command or set its defaults.

Default No default

Mode Policy Map Class

Usage This command should be set in conjunction with the [storm-rate command on page 53.46](#).

Examples To set the QSP window size to 5000 ms, use the commands:

```
awplus# policy-map pmap2
awplus(config-pmap)# class-map cmap2
awplus(config-pmap-c)# storm-window 5000
```

Related Commands [storm-action](#)
[storm-downtime](#)
[storm-protection](#)
[storm-rate](#)

trust dscp

Use this command to enable the premark-dscp map to replace the bandwidth-class, cos, dscp, and queue of classified traffic based on a lookup DSCP value.

Syntax `trust dscp`
`no trust dscp`

Parameter	Description
<code>trust</code>	Specify trust state for policy-map
<code>dscp</code>	Trust DSCP
<code>no</code>	Negate a command or set its defaults

Mode Policy Map

Examples To enable the premark-dscp map lookup use the command:

```
awplus# configure terminal
awplus(config)# policy-map pmap1
awplus(config-pmap)# trust dscp
```

Related Commands [mls qos map premark-dscp to](#)

wrr-queue egress-rate-limit queues

Sets a limit on the amount of traffic that can be transmitted per second from these queues. The default unit is in Kb, but Mb or Gb can also be specified. The minimum is 651Kb.

Syntax `wrr-queue egress-rate-limit bandwidth queues [0] [1] [2] [3] [4] [5] [6] [7]`
`no wrr-queue egress-rate-limit bandwidth queues`
`[0] [1] [2] [3] [4] [5] [6] [7]`

Parameter	Description
wrr-queue	WRR queue
egress-rate-limit	Limit the amount of traffic egressing the queue
bandwidth	Bandwidth <1-10000000 kbits> (usable units :k, m, g)
queues	List queue's to configure egress rate limiting on
[1] [2] . . . [7]	Selects one or more queues numbered 0 to 7
no	Negate a command or set its defaults

Mode Interface Configuration

Examples To set enable egress rate limiting on queues 1-3 enter the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1
awplus(config-if)# wrr-queue egress-rate-limit 500M queues 1 2 3
```

Related Commands [show mls qos interface](#)

wrr-queue weight queues

Configures weighted round-robin based scheduling on the specified egress queues. The weights are specified as ratio's relative to each other.

Syntax `wrr-queue weight <6-255> queues [0] [1] [2] [3] [4] [5] [6] [7]`

Parameter	Description
<code>wrr-queue</code>	Wrr queue
<code>weight</code>	Weighting applied to these queues
<code><6-255></code>	Weight (the higher the number the greater will be the queue servicing)
<code>queues</code>	List of queues to configure
<code>[0] [1] . . . [7]</code>	Egress queues 0-7

Mode Interface Configuration

Examples To apply a wrr weight of 6 to queues 0 1 2, on port1.0.1, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1
awplus(config-if)# wrr-queue weight 6 queues 0 1 2
```

To share the bandwidth on port1.0.1 between queues 1 to 3 such that queue 2 gets serviced twice as often as queue 1 and queue 3 gets serviced twice as often as queue 2:

```
awplus# configure terminal
awplus(config)# interface port1.0.1
awplus(config-if)# wrr-queue weight 1 queues 1
awplus(config-if)# wrr-queue weight 2 queues 2
awplus(config-if)# wrr-queue weight 3 queues 4
```

Related Commands [priority-queue](#)
[show mls qos interface](#)

Chapter 54: 802.1X Configuration



Introduction.....	54.2
The 802.1X Implementation.....	54.2
Configuring 802.1X.....	54.2

Introduction

The IEEE Standard 802.1X provides a method of restricting access to networks based on authentication information. 802.1X provides port-based network access control for devices connected to the Ethernet. This allows a network controller to restrict external devices from gaining access to the network behind an 802.1X controlled port. External devices that wish to access services via a port under 802.1X control must firstly authenticate themselves and gain authorization before any packets originating from, or destined for, the external device are allowed to pass through the 802.1X controlled port.

The 802.1X Implementation

802.1X port access control is achieved by making devices attached to a controlled port authenticate themselves via communication with an authentication server before these devices are allowed to access the network behind the controlled port.

Authentication is required on a per-port basis. The main components of an 802.1X implementation are:

- the authenticator - the port on this device that wishes to enforce authentication before allowing access to services that are accessible behind it.
- the supplicant - the port that wishes to access services offered by the authenticator's system. The supplicant may be a port on a PC or other device connected to this device.
- the authentication server - a device that uses the authentication credentials supplied by the supplicant, via the authenticator, to determine if the authenticator should grant access to its services.

Configuring 802.1X

The following example explains how to configure 802.1X.

In this example, the RADIUS Server keeps the Client information, validating the identity of the Client and updating the switch about the authentication status of the client. The switch is the physical access between the two clients and the server. It requests information from the client, relays information to the server and then back to the client.

To configure 802.1X authentication, first enable authentication on port1.0.1 and port1.0.2 and then specify the RADIUS Server IP address and port.




Table 54-1: 802.1X configuration on the switch

<code>awplus#</code>	Enter the Configure mode.
<code>configure terminal</code>	
<code>awplus(config)#</code>	Enable authentication globally.
<code>aaa authentication dot1x default group radius</code>	
<code>awplus(config)#</code>	Specify the interface (port1.0.1) to be configured and enter the Interface mode.
<code>interface port1.0.1</code>	
<code>awplus(config-if)#</code>	Enable authentication (via RADIUS) on port1.0.1.
<code>dot1x port-control auto</code>	
<code>awplus(config-if)#</code>	Block traffic in both directions, other than authentication packets, until authentication is complete.
<code>dot1x control-direction both</code>	
<code>awplus(config-if)#</code>	Exit the Interface mode and enter the Configure mode.
<code>exit</code>	
<code>awplus(config)#</code>	Specify the interface (port1.0.2) you are configuring and enter the Interface mode.
<code>interface port1.0.2</code>	
<code>awplus(config-if)#</code>	Enable authentication (via Radius) on port1.0.2.
<code>dot1x port-control auto</code>	
<code>awplus(config-if)#</code>	Exit the Interface mode and enter the Configure mode.
<code>exit</code>	
<code>awplus(config)#</code>	Specify the Radius Server address (192.126.12.1) and authentication port.
<code>radius-server host 192.126.12.1 auth-port 1812</code>	
<code>awplus(config)#</code>	Specify the shared key <code>secret</code> between the radius server and the client.
<code>radius-server key secret</code>	
<code>awplus(config)#</code>	Specify the vlan (vlan4) to be configured and enter the Interface mode.
<code>interface vlan4</code>	
<code>awplus(config-if)#</code>	Set the IP address on vlan4.
<code>ip address 192.126.12.2/24</code>	

Commands Used	dot1x port-control radius-server host radius-server key
Validation Commands	show dot1x show dot1x interface

Chapter 55: 802.1X Commands



Command List	55.2
debug dot1x	55.2
dot1x control-direction	55.3
dot1x eap	55.4
dot1x eapol-version	55.5
dot1x initialize interface	55.6
dot1x keytransmit	55.7
dot1x max-reauth-req	55.8
dot1x port-control	55.9
dot1x timeout tx-period	55.11
show debugging dot1x	55.12
show dot1x	55.13
show dot1x diagnostics	55.15
show dot1x interface	55.16
show dot1x sessionstatistics	55.21
show dot1x statistics interface	55.22
show dot1x supplicant	55.23
show dot1x supplicant interface	55.25

Command List

This chapter provides an alphabetical reference of commands used to configure 802.1X port access control. For more information, see [Chapter 54, 802.1X Configuration](#).

debug dot1x

Use this command to enable 802.1X IEEE Port-Based Network Access Control troubleshooting functions. Use the no parameter with this command to disable this function.

Syntax debug dot1x [all|auth-web|event|nsm|packet|timer]
 no debug all dot1x
 no debug dot1x [all|auth-web|event|nsm|packet|timer]

Parameter	Description
all	Used with the no form exclusively; turns off all debugging for 802.1X
auth-web	Specifies debugging for 802.1X auth-web information
events	Specifies debugging for 802.1X events
nsm	Specifies debugging for NSM messages
packet	Specifies debugging for 802.1X packets
timer	Specifies debugging for 802.1X timers

Mode Privileged Exec and Global Configuration

Usage This command without any parameters turns on normal 802.1X debug information.

```
awplus# debug dot1x
```

```
awplus# show debugging dot1x
```

```
802.1X debugging status:
802.1X events debugging is
802.1X timer debugging is on
802.1X packets debugging is on
802.1X NSM debugging is on
```

Examples

```
awplus# debug dot1x
```

```
awplus# debug dot1x all
```

Related Commands [show debugging dot1x](#)

dot1x control-direction

This command sets the direction of the filter for the unauthorized interface.

If the optional in parameter is specified with this command then packets entering the specified port are discarded. The in parameter discards the ingress packets received from the supplicant.

If the optional both parameter is specified with this command then packets entering (ingress) and leaving (egress) the specified port are discarded. The both parameter discards the packets received from the supplicant and sent to the supplicant.

The no dot1x control-direction command sets the direction of the filter to both. The port will then discard both ingress and egress traffic.

Syntax dot1x control-direction {in|both}
no dot1x control-direction

Parameter	Description
no	Negate a command or set its defaults
dot1x	IEEE 802.1X Port-Based Access Control
control-direction	Specify packet control direction
in	Discard received packets from the supplicant (ingress packets)
both	Discard received packets from the supplicant (ingress packets) and transmitted packets to the supplicant (egress packets)

Default The authentication port direction is set to both by default.

Mode Interface Configuration for either a static channel or a dynamic (LACP) channel group or a switch port.

Examples To set the port direction to the default (both) for port1.0.2, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# no dot1x control-direction
```

To set the port direction to in for port1.0.2, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# dot1x control-direction in
```

Validation Commands show dot1x
show dot1x interface
show auth-mac interface
show auth-web interface

dot1x eap

This command selects the transmit mode for the EAP packet. If the authentication feature is not enabled then EAP transmit mode is not enabled. The default setting discards EAP packets.

Syntax `dot1x eap {discard|forward|forward-untagged-vlan|forward-vlan}`

Parameter	Description
dot1x	IEEE 802.1X Port-Based Access Control
eap	EAP packets
discard	Discard
forward	Forward to all ports on the switch
forward-untagged-vlan	Forward to ports with the same untagged vlan
forward-vlan	Forward to ports with the same vlan

Default The transmit mode is set to `discard` EAP packets by default.

Mode Global Configuration

Examples To set the transmit mode of EAP packet to `forward` to forward EAP packets to all ports on the switch, use the following commands:

```
awplus# configure terminal
awplus(config)# dot1x eap forward
```

To set the transmit mode of EAP packet to `discard` to discard EAP packets, use the following commands:

```
awplus# configure terminal
awplus(config)# dot1x eap discard
```

To set the transmit mode of EAP packet to `forward-untagged-vlan` to forward EAP packets to ports with the same untagged vlan, use the following commands:

```
awplus# configure terminal
awplus(config)# dot1x eap forward-untagged-vlan
```

To set the transmit mode of EAP packet to `forward-vlan` to forward EAP packets to ports with the same vlan, use the following commands:

```
awplus# configure terminal
awplus(config)# dot1x eap forward-vlan
```


dot1x eapol-version

This command sets the EAPOL protocol version for EAP packets when 802.1X port authentication is applied.

Use the `no dot1x eapol-version` command to set the EAPOL protocol version to 1.

The default EAPOL protocol version is version 1.

Syntax `dot1x eapol-version <1-2>`

`no dot1x eapol-version`

Parameter	Description
<code>no</code>	Negate a command or set its defaults
<code>dot1x</code>	IEEE 802.1X Port-Based Access Control
<code>eapol-version</code>	Set the protocol version
<code><1-2></code>	EAPOL version (default 1)

Default The EAP version for 802.1X authentication is set to 1 by default.

Mode Interface Configuration for either a static channel or a dynamic (LACP) channel group or a switch port.

Examples To set the EAPOL protocol version to 2 for `port1.0.2`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# dot1x eapol-version 2
```

To set the EAPOL protocol version to the default version (1) for interface `port1.0.2`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# no dot1x eapol-version
```

Validation Commands `show dot1x`
`show dot1x interface`

dot1x initialize interface

This command initializes the 802.1X status on the specified interface, and attempts reauthentication.

Use this command to unauthorize a port, and attempt reauthentication on the specified interface, which may be a static channel (or static aggregator) or a dynamic (or LACP) channel group or a switch port.

Syntax `dot1x initialize interface <port-list>`

Parameter	Description
<code>dot1x</code>	IEEE 802.1X Port-Based Access Control
<code>initialize</code>	Initialize the port to attempt reauthentication
<code>interface</code>	Select a switch port to initialize
<code><interface-list></code>	The interfaces or ports to configure. An interface-list can be: ■ an interface, a switch port, or a channel group (e.g., <code>vlan2</code>, <code>port1.1.12</code>, <code>sa3</code>, or <code>po4</code>) ■ a continuous range of interfaces, ports, or channel groups separated by a hyphen, e.g. <code>vlan2-vlan8</code> or <code>port1.1.1-port1.1.24</code> or <code>sa2-4</code>, <code>po1-3</code> ■ a comma-separated list of the above, e.g., <code>port1.0.1,port1.1.1-1.2.24</code>. Do not mix interface types in a list. The specified interfaces must exist.

Mode Privileged Exec

Examples To initialize 802.1X port authentication on the interface `port1.0.2`, use the following command:

```
awplus# dot1x initialize interface port1.0.12
```

To unauthorize switch port 1.0.1 and attempt reauthentication on switch `port1.0.1` enter:

```
awplus# dot1x initialize interface port1.0.1
```

To unauthorize all switch ports for a 24 switch port device and attempt reauthentication enter:

```
awplus# dot1x initialize interface port1.0.1-port1.0.24
```

dot1x keytransmit

This command enables key transmission on the interface specified previously in Interface mode.

The no dot1x keytransmit command disables key transmission on the interface specified.

Syntax dot1x keytransmit
no dot1x keytransmit

Parameter	Description
no	Negate a command or set its defaults
dot1x	IEEE 802.1X Port-Based Access Control
keytransmit	Transmit 802.1X authentication key

Default Key transmission for port authentication is enabled by default.

Usage Use this command to enable key transmission over an Extensible Authentication Protocol (EAP) packet between the authenticator and supplicant. Use the no version of this command to disable key transmission.

Mode Interface Configuration for either a static channel or a dynamic (LACP) channel group or a switch port.

Examples To enable the key transmit feature on interface port1.0.2, after it has been disabled by negation, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# dot1x keytransmit
```

To disable the key transmit feature from the default startup configuration on interface port1.0.2, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# no dot1x keytransmit
```

Validation Commands show dot1x
show dot1x interface

dot1x max-reauth-req

This command sets the number of reauthentication attempts before an interface is unauthorized.

The no dot1x max-reauth-req command resets the reauthentication delay to the default (2).

Syntax dot1x max-reauth-req <1-10>
no dot1x max-reauth-req

Parameter	Description
no	Negate a command or set its defaults
dot1x	IEEE 802.1X Port-Based Access Control
max-reauth-req	Number of reauthentication attempts before becoming unauthorized (default 2)
<1-10>	Count

Default The default maximum reauthentication count for port authentication is 2.

Usage Use this command to set the maximum reauthentication attempts after failure.

Mode Interface Configuration for either a static channel or a dynamic (LACP) channel group or a switch port.

dot1x port-control

This command enables 802.1X port authentication on the interface specified, and sets the control of the authentication port. When port-control is set to auto, the 802.1X authentication feature is executed on the interface, but only if the aaa authentication dot1x command has been issued.

The no dot1x port-control command disables the port authentication on the interface specified.

Syntax dot1x port-control {force-unauthorized|force-authorized|auto}
no dot1x port-control

Parameter	Description
no	Negate a command or set its defaults
dot1x	IEEE 802.1X Port-Based Access Control
port-control	Port control commands
force-unauthorized	Force port state to unauthorized. Specify to force a port to always be in an unauthorized state.
force-authorized	Force port state to authorized. Specify to force a port to always be in an authorized state.
auto	Allow port client to negotiate authentication. Specify to enable authentication on port.

Default 802.1X port control is disabled by default.

Mode Interface Configuration for either a static channel or a dynamic (LACP) channel group or a switch port.

Usage Use this command to force a port state. Note that all dot1x commands can only be applied to switch ports. They cannot be applied to dynamic (LACP) or static channel groups.

Examples To enable port authentication on the interface port1.0.2, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# dot1x port-control auto
```

To enable port authentication force authorized on the interface port1.0.2, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# dot1x port-control force-authorized
```

To disable port authentication on the interface `port1.0.2`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# no dot1x port-control
```

**Validation
Commands** `show dot1x interface`

Related Commands `aaa authentication dot1x`

dot1x timeout tx-period

This command sets the transmit timeout for the authentication request on the specified interface. The `no dot1x timeout tx-period` command resets the transmit timeout period to the default (30 seconds).

Syntax `dot1x timeout tx-period <1-65535>`
`no dot1x timeout tx-period`

Parameter	Description
<code>no</code>	Negate a command or set its defaults
<code>dot1x</code>	IEEE 802.1X Port-Based Access Control
<code>timeout</code>	Set a timeout parameter
<code>tx-period</code>	Seconds between successive request id attempts (default is 30 seconds). Specify the period in seconds between successive request ID attempts.
<code><1-65535></code>	Seconds

Default The default transmit period for port authentication is 30 seconds.

Mode Interface Configuration for either a static channel or a dynamic (LACP) channel group or a switch port.

Usage Use this command to set the interval between successive attempts to request an ID.

Examples To set the transmit timeout period to 5 seconds on interface `port1.0.2`, use the below commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# dot1x timeout tx-period 5
```

To reset transmit timeout period to the default (30 seconds) on interface `port 1.0.2`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# no dot1x timeout tx-period
```

Validation Commands `show dot1x`
`show dot1x interface`

show debugging dot1x

Use this command to display the 802.1X debugging option set.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show debugging dot1x`

Mode Privileged Exec

Usage This is a sample output from the `show debugging dot1x` command.

```
awplus# debug dot1x
```

```
awplus# show debugging dot1x
```

```
802.1X debugging status:
 802.1X events debugging is on
 802.1X timer debugging is on
 802.1X packets debugging is on
 802.1X NSM debugging is on
```

Example

```
awplus# show debugging dot1x
```

Related Commands [debug dot1x](#)

show dot1x

This command shows authentication information for dot1x (802.1X) port authentication.

If you specify the optional all parameter then this command also displays all authentication information for each port available on the switch.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax show dot1x [all]

Parameter	Description
show	Show running system information
dot1x	IEEE 802.1X Port-Based Access Control
all	All

Mode Exec and Privileged Exec

Example

```
awplus# show dot1x all
```

Table 55-1: Example output from the show dot1x command

```
awplus# show dot1x all
802.1X Port-Based Authentication Enabled
RADIUS server address: 150.87.18.89:1812
Next radius message id: 5
RADIUS client address: not configured
Authentication info for interface port1.0.12
portEnabled: true - portControl: Auto
portStatus: Authorized
reAuthenticate: disabled
reAuthPeriod: 3600
PAE: quietPeriod: 60 - maxReauthReq: 2 - txPeriod: 30
BE: suppTimeout: 30 - serverTimeout: 30
CD: adminControlledDirections: in
KT: keyTxEnabled: false
critical: disabled
guestVlan: disabled
dynamicVlanCreation: single-dynamic-vlan
    assignFailActionRule: deny
hostMode: multi-supplicant
    maxSupplicant: 1024
dot1x: enabled
    protocolVersion: 1
authMac: enabled
    method: PAP
    reauthRelearning: disabled
authWeb: enabled
    method: PAP
    lockCount: 3
    packetForwarding: disabled
```

Table 55-1: Example output from the show dot1x command (Continued)

```

supplicantMac: none
Supplicant name: manager
Supplicant address: 00d0.59ab.7037
  authenticationMethod: 802.1X Authentication
  portStatus: Authorized - currentId: 1
  abort:F fail:F start:F timeout:F success:T
  PAE: state: Authenticated - portMode: Auto
  PAE: reAuthCount: 0 - rxRespId: 0
  PAE: quietPeriod: 60 - maxReauthReq: 2 - txPeriod: 30
  BE: state: Idle - reqCount: 0 - idFromServer: 0
  CD: adminControlledDirections: in - operControlledDirections: in
  CD: bridgeDetected: false
  KR: rxKey: false
  KT: keyAvailable: false - keyTxEnabled: false
  criticalState: off
  dynamicVlanId: 2
802.1X statistics for interface port1.0.12
  EAPOL Frames Rx: 5 - EAPOL Frames Tx: 16
  EAPOL Start Frames Rx: 0 - EAPOL Logoff Frames Rx: 0
  EAP Rsp/Id Frames Rx: 3 - EAP Response Frames Rx: 2
  EAP Req/Id Frames Tx: 8 - EAP Request Frames Tx: 2
  Invalid EAPOL Frames Rx: 0 - EAP Length Error Frames Rx: 0
  EAPOL Last Frame Version Rx: 1 - EAPOL Last Frame Src: 00d0.59ab.7037
Authentication session statistics for interface port1.0.12
  session user name: manager
  session authentication method: Remote server
  session time: 19440 secs
  session terminate cause: Not terminated yet
Authentication Diagnostics for interface port1.0.12
  Supplicant address: 00d0.59ab.7037
  authEnterConnecting: 2
  authEaplogoffWhileConnecting: 1
  authEnterAuthenticating: 2
  authSuccessWhileAuthenticating: 1
  authTimeoutWhileAuthenticating: 1
  authFailWhileAuthenticating: 0
  authEapstartWhileAuthenticating: 0
  authEaplogoggWhileAuthenticating: 0
  authReauthsWhileAuthenticated: 0
  authEapstartWhileAuthenticated: 0
  authEaplogoffWhileAuthenticated: 0
  BackendResponses: 2
  BackendAccessChallenges: 1
  BackendOtherrequestToSupplicant: 3
  BackendAuthSuccess: 1
  BackendAuthFails: 0

```

show dot1x diagnostics

This command shows 802.1X authentication diagnostics for the specified interface (optional), which may be a static channel (or static aggregator) or a dynamic (or LACP) channel group or a switch port.

If no interface is specified then authentication diagnostics are shown for all interfaces.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show dot1x diagnostics [interface <interface-list>]`

Parameter	Description
show	Show running system information
dot1x	IEEE 802.1X Port-Based Access Control
diagnostics	Diagnostics
interface	Specify a port to show
<interface-list>	The interfaces or ports to configure. An interface-list can be: ■ an interface, a switch port, or a channel group (e.g., vlan2, port1.1.12, sa3, or po4) ■ a continuous range of interfaces, ports, or channel groups separated by a hyphen, e.g. vlan2-vlan8 or port1.1.1-port1.1.24 or sa2-4, po1-3 ■ a comma-separated list of the above, e.g., port1.0.1,port1.1.1-1.2.24. Do not mix interface types in a list. The specified interfaces must exist.

Mode Exec and Privileged Exec

Example See the sample output below showing 802.1X authentication diagnostics for port 1.0.12:

```
awplus# show dot1x diagnostics interface port1.0.12
```

```
Authentication Diagnostics for interface port1.0.12
Supplicant address: 00d0.59ab.7037
authEnterConnecting: 2
authEaplogoffWhileConnecting: 1
authEnterAuthenticating: 2
authSuccessWhileAuthenticating: 1
authTimeoutWhileAuthenticating: 1
authFailWhileAuthenticating: 0
authEapstartWhileAuthenticating: 0
authEaplogoggWhileAuthenticating: 0
authReauthsWhileAuthenticated: 0
authEapstartWhileAuthenticated: 0
authEaplogoffWhileAuthenticated: 0
BackendResponses: 2
BackendAccessChallenges: 1
BackendOtherrequestToSupplicant: 3
BackendAuthSuccess: 1
```

show dot1x interface

This command shows the status of 802.1X port-based authentication on the specified interface, which may be a static channel (or static aggregator) or a dynamic (or LACP) channel group or a switch port.

Use the optional diagnostics parameter to show authentication diagnostics for the specified interfaces. Use the optional sessionstatistics parameter to show authentication session statistics for the specified interfaces. Use the optional statistics parameter to show authentication diagnostics for the specified interfaces. Use the optional supplicant parameter to show the supplicant state for the specified interfaces.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show dot1x interface <interface-list>
[diagnostics|sessionstatistics|statistics|supplicant [brief]]`

Parameter	Description
show	Show running system information
dot1x	IEEE 802.1X Port-Based Access Control
interface	Specify an interface to show
<interface-list>	The interfaces or ports to configure. An interface-list can be: ■ an interface, a switch port, or a channel group (e.g., vlan2, port1.1.12, sa3, or po4) ■ a continuous range of interfaces, ports, or channel groups separated by a hyphen, e.g. vlan2-vlan8 or port1.1.1-port1.1.24 or sa2-4, po1-3 ■ a comma-separated list of the above, e.g., port1.0.1,port1.1.1-1.2.24. Do not mix interface types in a list. The specified interfaces must exist.
diagnostics	Diagnostics
sessionstatistics	Session Statistics
statistics	Statistics
supplicant	Supplicant
brief	Brief summary of supplicant state

Mode Exec and Privileged Exec

Example See the sample output below showing 802.1X authentication status for port1.0.12:

```
awplus# show dot1x interface port1.0.12
```

Table 55-2: Example output from the **show dot1x interface** command for a port

```
awplus#show dot1x interface port1.0.12
Authentication info for interface port1.0.12
  portEnabled: true - portControl: Auto
  portStatus: Authorized
  reAuthenticate: disabled
  reAuthPeriod: 3600
  PAE: quietPeriod: 60 - maxReauthReq: 2 - txPeriod: 30
  BE: suppTimeout: 30 - serverTimeout: 30
  CD: adminControlledDirections: in
  KT: keyTxEnabled: false
  critical: disabled
  guestVlan: disabled
  dynamicVlanCreation: single-dynamic-vlan
    assignFailActionRule: deny
  hostMode: multi-supPLICANT
    maxSupPLICANT: 1024
  dot1x: enabled
    protocolVersion: 1
  authMac: enabled
    method: PAP
    reauthRelearning: disabled
  authWeb: enabled
    method: PAP
    lockCount: 3
    packetForwarding: disabled
  supPLICANTMac: none
```

See the sample output below showing 802.1X authentication session statistics for port1.0.12:

```
awplus# show dot1x interface port1.0.12 sessionstatistics
```

```
awplus#show dot1x interface port1.0.12 sessionstatistics
Authentication session statistics for interface port1.0.12
  session user name: manager
    session authentication method: Remote server
    session time: 19440 secs
    session terminat cause: Not terminated yet
```

See sample output below showing 802.1X authentication diagnostics for port1.0.12:

```
awplus# show dot1x interface port1.0.12 diagnostics
```

```
awplus#show dot1x interface port1.0.12 diagnostics
Authentication Diagnostics for interface port1.0.12
  Supplicant address: 00d0.59ab.7037
    authEnterConnecting: 2
    authEaplogoffWhileConnecting: 1
    authEnterAuthenticating: 2
    authSuccessWhileAuthenticating: 1
    authTimeoutWhileAuthenticating: 1
    authFailWhileAuthenticating: 0
    authEapstartWhileAuthenticating: 0
    authEaplogoggWhileAuthenticating: 0
    authReauthsWhileAuthenticated: 0
    authEapstartWhileAuthenticated: 0
    authEaplogoffWhileAuthenticated: 0
    BackendResponses: 2
    BackendAccessChallenges: 1
    BackendOtherrequestToSupplicant: 3
    BackendAuthSuccess: 1
```

See sample output below showing the supplicant on the interface port1.0.12:

```
awplus# show dot1x interface port1.0.12 supplicant
```

```
awplus#show dot1x interface port1.0.12 supplicant
authenticationMethod: dot1x
  totalSupplicantNum: 1
  authorizedSupplicantNum: 1
    macBasedAuthenticationSupplicantNum: 0
    dot1xAuthenticationSupplicantNum: 1
    webBasedAuthenticationSupplicantNum: 0
Supplicant name: manager
Supplicant address: 00d0.59ab.7037
  authenticationMethod: dot1x
  portStatus: Authorized - currentId: 4
  abort:F fail:F start:F timeout:F success:T
  PAE: state: Authenticated - portMode: Auto
  PAE: reAuthCount: 0 - rxRespId: 0
  PAE: quietPeriod: 60 - maxReauthReq: 2 - txPeriod: 30
  BE: state: Idle - reqCount: 0 - idFromServer: 3
  BE: suppTimeout: 30 - serverTimeout: 30
  CD: adminControlledDirections: in - operControlledDirections:
in
  CD: bridgeDetected: false
  KR: rxKey: false
  KT: keyAvailable: false - keyTxEnabled: false
```

See sample output below showing 802.1X (dot1x) authentication statistics for port1.0.12:

```
awplus# show dot1x statistics interface port1.0.12
```

```
awplus#show dot1x statistics interface port1.0.12
802.1X statistics for interface port1.0.12
EAPOL Frames Rx: 5 - EAPOL Frames Tx: 16
EAPOL Start Frames Rx: 0 - EAPOL Logoff Frames Rx: 0
EAP Rsp/Id Frames Rx: 3 - EAP Response Frames Rx: 2
EAP Req/Id Frames Tx: 8 - EAP Request Frames Tx: 2
Invalid EAPOL Frames Rx: 0 - EAP Length Error Frames Rx: 0
EAPOL Last Frame Version Rx: 1 - EAPOL Last Frame
Src:00d0.59ab.7037
```

Output

Table 55-3: Parameters in the output of the **show dot1x interface** command

Parameter	Description
portEnabled	Interface operational status (Up-true/down-false)
portControl	Current control status of the port for 802.1X control
portStatus	802.1X status of the port (authorized/unauthorized)
reAuthenticate	reAuthentication enabled/disabled status on port
reAuthPeriod	Value holds meaning only if reAuthentication is enabled
abort	indicates that authentication should be aborted when set to true
fail	indicates failed authentication attempt when set to false
start	indicates authentication should be started when set to true
timeout	indicates authentication attempt timed out when set to true
success	indicates authentication successful when set to true
state	Current 802.1X operational state of interface
mode	configured 802.1X mode
reAuthCount	Reauthentication count
quietperiod	time between reauthentication attempts
reAuthMax	Maximum reauthentication attempts
BE	Backend Authentication state machine variables and constants
state	state of the state machine
reqCount	Count of requests sent to server
suppTimeout	Supplicant timeout
serverTimeout	Server timeout
maxReq	Maximum requests to be sent
CD	Controlled Directions State machine
adminControlledDirections	Administrative value (Both/In)
operControlledDirections	Operational Value (Both/In)
KR	Key receive state machine
rxKey	true when EAPOL-Key message is received by supplicant or authenticator. false when key is transmitted

Table 55-3: Parameters in the output of the **show dot1x interface** command (Continued)

Parameter	Description
KT	Ket Transmit State machine
keyAvailable	false when key has been transmitted by authenticator, true when new key is available for key exchange
keyTxEnabled	Key transmission enabled/disabled status

Related Commands [show auth-web diagnostics](#)
[show dot1x sessionstatistics](#)
[show dot1x statistics interface](#)
[show dot1x supplicant interface](#)

show dot1x sessionstatistics

This command shows authentication session statistics for the specified interface, which may be a static channel (or static aggregator) or a dynamic (or LACP) channel group or a switch port.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show dot1x sessionstatistics [interface <interface-list>]`

Parameter	Description
show	Show running system information
dot1x	IEEE 802.1X Port-Based Access Control
sessionstatistics	Session statistics
interface	Specify an port to show
<interface-list>	The interfaces or ports to configure. An interface-list can be: ■ an interface, a switch port, or a channel group (e.g., vlan2, port1.1.12, sa3, or po4) ■ a continuous range of interfaces, ports, or channel groups separated by a hyphen, e.g. vlan2-vlan8 or port1.1.1-port1.1.24 or sa2-4, po1-3 ■ a comma-separated list of the above, e.g., port1.0.1,port1.1.1-1.2.24. Do not mix interface types in a list. The specified interfaces must exist.

Mode Exec and Privileged Exec

Example See sample output below showing 802.1X (dot1x) authentication session statistics for port 1.0.12:

```
awplus# show dot1x sessionstatistics interface port1.0.12
```

```
Authentication session statistics for interface port1.0.12
session user name: manager
session authentication method: Remote server
session time: 19440 secs
session terminat cause: Not terminated yet
```

show dot1x statistics interface

This command shows the authentication statistics for the specified interface, which may be a static channel (or static aggregator) or a dynamic (or LACP) channel group or a switch port.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show dot1x statistics interface <interface-list>`

Parameter	Description
show	Show running system information
dot1x	IEEE 802.1X Port-Based Access Control
statistics	Statistics
interface	Specify an port to show
<interface-list>	The interfaces or ports to configure. An interface-list can be: ■ an interface, a switch port, or a channel group (e.g., vlan2, port1.1.12, sa3, or po4) ■ a continuous range of interfaces, ports, or channel groups separated by a hyphen, e.g. vlan2-vlan8 or port1.1.1-port1.1.24 or sa2-4, po1-3 ■ a comma-separated list of the above, e.g., port1.0.1,port1.1.1-1.2.24. Do not mix interface types in a list. The specified interfaces must exist.

Mode Exec and Privileged Exec

Example See sample output below showing 802.1X authentication statistics for port1.0.12:

```
awplus# show dot1x statistics interface port1.0.12
```

```
802.1X statistics for interface port1.0.12
EAPOL Frames Rx: 5 - EAPOL Frames Tx: 16
EAPOL Start Frames Rx: 0 - EAPOL Logoff Frames Rx: 0
EAP Rsp/Id Frames Rx: 3 - EAP Response Frames Rx: 2
EAP Req/Id Frames Tx: 8 - EAP Request Frames Tx: 2
Invalid EAPOL Frames Rx: 0 - EAP Length Error Frames Rx: 0
EAPOL Last Frame Version Rx: 1 - EAPOL Last Frame
Src:00d0.59ab.7037
```

show dot1x supplicant

This command shows the supplicant state of the authentication mode set for the switch.

This command shows a summary when the optional brief parameter is used.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show dot1x supplicant [<macadd>] [brief]`

Parameter	Description
show	Show running system information
dot1x	IEEE 802.1X Port-Based Access Control
supplicant	Specify a supplicant to show
<macadd>	Mac (hardware) address of the Supplicant
brief	Brief summary of the Supplicant state

Mode Exec and Privileged Exec

Example See sample output below showing the 802.1X authenticated supplicant on the switch:

```
awplus# show dot1x supplicant
```

```
authenticationMethod: dot1x
totalSupplicantNum: 1
authorizedSupplicantNum: 1
macBasedAuthenticationSupplicantNum: 0
dot1xAuthenticationSupplicantNum: 1
webBasedAuthenticationSupplicantNum: 0
Supplicant name: manager
Supplicant address: 00d0.59ab.7037
  authenticationMethod: dot1x
  portStatus: Authorized - currentId: 4
  abort:F fail:F start:F timeout:F success:T
  PAE: state: Authenticated - portMode: Auto
  PAE: reAuthCount: 0 - rxRespId: 0
  PAE: quietPeriod: 60 - maxReauthReq: 2 - txPeriod: 30
  BE: state: Idle - reqCount: 0 - idFromServer: 3
  BE: suppTimeout: 30 - serverTimeout: 30
  CD: adminControlledDirections: in - operControlledDirections:
in
  CD: bridgeDetected: false
  KR: rxKey: false
  KT: keyAvailable: false - keyTxEnabled: false
```

See sample output below showing the supplicant on the switch using the `brief` parameter:

```
awplus# show dot1x supplicant 00d0.59ab.7037 brief
```

```
Interface port1.0.12
  authenticationMethod: dot1x
  totalSupplicantNum: 1
  authorizedSupplicantNum: 1
    macBasedAuthenticationSupplicantNum: 0
    dot1xAuthenticationSupplicantNum: 1
    webBasedAuthenticationSupplicantNum: 0
Interface VID Mode MAC Address Status IP Address Username
===== == == =====
port1.0.12 2 D 00d0.59ab.7037Authenticated 192.168.2.201 manager
```

Related Commands [show dot1x supplicant interface](#)

show dot1x supplicant interface

This command shows the supplicant state of the authentication mode set for the interface, which may be a static channel (or static aggregator) or a dynamic (or LACP) channel group or a switch port.

This command shows a summary when the optional brief parameter is used.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show dot1x supplicant interface <interface-list> [brief]`

Parameter	Description
show	Show running system information
dot1x	IEEE 802.1X Port-Based Access Control
supplicant	Specify a supplicant to show
interface	Specify an port to show
<interface-list>	The interfaces or ports to configure. An interface-list can be: ■ an interface, a switch port, or a channel group (e.g., vlan2, port1.1.12, sa3, or po4) ■ a continuous range of interfaces, ports, or channel groups separated by a hyphen, e.g. vlan2-vlan8 or port1.1.1-port1.1.24 or sa2-4, po1-3 ■ a comma-separated list of the above, e.g., port1.0.1,port1.1.1-1.2.24. Do not mix interface types in a list. The specified interfaces must exist.
brief	Brief summary of the Supplicant state

Mode Exec and Privileged Exec

Example See sample output below showing the supplicant on the interface port1.0.19:

```
awplus# show dot1x supplicant interface port1.0.19
```

```

Interface port1.0.19
authenticationMethod: dot1x
totalSupplicantNum: 1
authorizedSupplicantNum: 1
    macBasedAuthenticationSupplicantNum: 0
    dot1xAuthenticationSupplicantNum: 1
    webBasedAuthenticationSupplicantNum: 0
    otherAuthenticationSupplicantNum: 0

Supplicant name: VCSPCVLAN10
Supplicant address: 0000.cd07.7b60
authenticationMethod: 802.1X
portStatus: Authorized - currentId: 3
abort:F fail:F start:F timeout:F success:T
PAE: state: Authenticated - portMode: Auto
PAE: reAuthCount: 0 - rxRespId: 0
PAE: quietPeriod: 60 - maxReauthReq: 2
BE: state: Idle - reqCount: 0 - idFromServer: 2
CD: adminControlledDirections:in - operControlledDirections:in
CD: bridgeDetected: false
KR: rxKey: false
KT: keyAvailable: false - keyTxEnabled: false

```

See sample output below showing the supplicant on the switch using the brief parameter:

```
awplus# show dot1x supplicant interface brief
```

```

Interface port1.0.12
authenticationMethod: dot1x
totalSupplicantNum: 1
authorizedSupplicantNum: 1
    macBasedAuthenticationSupplicantNum: 0
    dot1xAuthenticationSupplicantNum: 1
    webBasedAuthenticationSupplicantNum: 0

Interface VID Mode MAC Address      Status      IP Address      Username
=====
port1.0.12 2   D   00d0.59ab.7037 Authenticated 192.168.2.201 manager

```

See the sample output below for static channel group (static aggregator) interface sa1:

```
awplus# show dot1x interface sa1 supplicant brief
```

```

awplus#show dot1x interface sa1 supplicant brief
Interface sa1
authenticationMethod: dot1x
totalSupplicantNum: 1
authorizedSupplicantNum: 1
    macBasedAuthenticationSupplicantNum: 0
    dot1xAuthenticationSupplicantNum: 1
    webBasedAuthenticationSupplicantNum: 0
    otherAuthenticationSupplicantNum: 0

Interface VID Mode MAC Address      Status      IP Address      Username
=====
sa1        1   D   00d0.59ab.7037 Authenticated --             test1

```

Related Commands [show dot1x supplicant](#)

Chapter 56: Authentication Configuration



Authentication Introduction	56.2
Tri-Authentication Introduction	56.2
Tri-Authentication Configuration	56.2
Configuring a Guest VLAN	56.3
Roaming Authentication	56.4
Roaming Authentication Overview	56.5
Roaming Authentication Feature Interactions	56.6
Unauthenticated Supplicant Traffic	56.7
Deciding when a supplicant fails authentication	56.9

Authentication Introduction

Authentication commands enable you to specify three different types of device authentication.

Tri-Authentication Introduction

The switch supports three types of authentication for devices that connect to switch ports:

- 802.1X authentication of devices connecting to switch ports
- MAC authentication of devices connecting to switch ports
- Web-based authentication of devices connecting to switch ports

All three types can be configured to run simultaneously on a switch port. The simultaneous configuration and authentication of all three types on a port is called tri-authentication.

Tri-Authentication Configuration

Follow the below three steps to configure tri-authentication across a range of switch ports:

Step 1: Define the RADIUS Server:

Define the RADIUS Server where the switch will send authentication requests using the below commands:

```
awplus# configure terminal
awplus(config)# radius-server host <ip-address> key
                    <key-string>
```

These commands add the RADIUS Server address and set parameters to the RADIUS server. The key parameter specifies the secret key for the server.

Note: The RADIUS Server, where the switch sends authentication requests, could be the switch's own Local RADIUS Server. For information on how to configure Local RADIUS Server see [Chapter 61, Local RADIUS Server Introduction and Configuration](#)

Step 2: Define the default authentication server lists:

Define the default authentication server lists for 802.1X authentication, Web-based authentication, and MAC-based authentication:

```
awplus# configure terminal
awplus(config)# aaa authentication dot1x default group radius
awplus(config)# aaa authentication auth-web default group
                    radius
awplus(config)# aaa authentication auth-mac default group
                    radius
```


Step 3: Configure 802.1X, Web-based, and MAC-based authentication:

Configure 802.1X authentication, Web-based authentication, MAC-based authentication on switch ports to attach supplicant devices:

```
awplus# configure terminal

awplus(config)# interface <interface-range>

awplus(config-if)# switchport mode access

awplus(config-if)# switchport access vlan 1

awplus(config-if)# auth-web enable

awplus(config-if)# auth-mac enable

awplus(config-if)# dot1x port-control auto

awplus(config-if)# auth dynamic-vlan-creation
```

Configuring a Guest VLAN

You can configure 802.1X to accept a Dynamic VLAN assignment, or fall back to a Guest VLAN upon failure.

If 802.1X authentication has been configured on access ports in the network, you might still want to provide limited network access to those users whose devices do not have 802.1x supplicant enabled, or who have unrecognized authentication credentials.

The mechanism to achieve this is known as a guest VLAN. The idea is that if the user device fails 802.1X authentication, or is not even performing any 802.1X authentication, then its connection port can be put into the guest VLAN.

To configure a switch to perform 802.1x authentication, and assign VLAN IDs to ports where devices authentication successfully, and put non-authenticated users into a Guest VLAN, proceed as follows:

```
awplus# configure terminal

awplus(config)# radius-server host <ip-address> key
                        <key-string>

awplus(config)# aaa authentication dot1x default group
                        radius

awplus(config)# interface <interface-range>

awplus(config-if)# switchport mode access

awplus(config-if)# dot1x port-control auto

awplus(config-if)# auth dynamic-vlan-creation


awplus(config-if)# auth guest-vlan 100
```

Roaming Authentication

When network security is required, the usability of network security must be considered. The Roaming Authentication feature improves the usability of network security by enabling users to move within the network without requiring them to re-authenticate each time they move.


If a supplicant (client device) moves from one wireless access point to another wireless access point, and the wireless access points are connected to different ports, then the switch (authenticator) recognizes that the supplicant has been authenticated and accepts the supplicant without requiring re-authentication.

Figure 56-1: Diagram showing **Roaming Authentication** running on a standalone switch



Web and MAC authentication are the authentication methods in a Wireless LAN environment, and 802.1X is the authentication method used for supplicants attached to edge switches.

Roaming Authentication is normally enabled using the [auth roaming enable command on page 57.13](#) command. However, Roaming Authentication has been extended (with the [auth roaming disconnected command on page 57.11](#)) to work where an interface is link down. This allows you to enable supplicants to move from authenticated interfaces that are link down, without requiring re-authentication. Roaming Authentication is available for use with the VcStack feature, and is available on static and dynamic (LACP) channel group interfaces.

Figure 56-2: Diagram showing **Roaming Authentication** running with VCStack

Roaming Authentication Overview

Without the Roaming Authentication feature enabled, if a supplicant moves from one switch port to another switch port, the supplicant's authenticated status, authentication, and assigned VLAN is deleted and the supplicant is re-authenticated so the supplicant can access the network, and all traffic from the supplicant is dropped while the supplicant is being re-authenticated.

With the Roaming Authentication feature enabled, a switch port inherits the status of a supplicant from the switch port that the supplicant was moved from. If the Roaming Authentication feature is enabled on a switch, then once a supplicant (client device) is authenticated on the switch it does not have to be re-authenticated if it moves between ports of that switch. Supplicant traffic is not dropped because there is no delay for re-authentication, during which the supplicant cannot access the network.

For example, when the Roaming Authentication feature is used in an wireless LAN environment with wireless access points, then the wireless clients can roam between wireless access points connected to different switch ports without re-authentication.

The Roaming Authentication feature also supports VCStack operation and works on defined static channel group (static aggregators) and dynamic channel group (LACP) interfaces. When VCStack and Roaming Authentication features are used together, the status of a supplicant is inherited from one aggregated interface to another aggregated interface over the stack.

See the [auth roaming disconnected command on page 57.11](#) and the [auth roaming enable command on page 57.13](#) for further information about configuring Roaming Authentication.

Roaming Authentication Feature Interactions

When the Roaming Authentication feature is disabled, a supplicant must be re-authenticated on the destination interface when it roams. When the Roaming Authentication is enabled, the following supplicant authentication status and information is inherited from the source interface:

- Authentication status
- Authentication method
- Supplicant MAC address
- Supplicant IP address
(if an authenticated interface is configured for Web authentication)
- Supplicant name
- Authorized dynamic VLAN ID
- Authorized RADIUS server
- Reauthentication timer
(if configured using the [auth timeout reauth-period command on page 57.18](#))

Roaming Authentication is only supported between interfaces with the same authentication configuration. If source and destination interfaces have different authentication configuration then the supplicant will be re-authenticated at the destination interface.

When the host mode is set with the [auth host-mode command on page 57.8](#), a supplicant is not authenticated on a destination interface, and the authentication status is deleted on the source interface.

When a supplicant moves from an interface with authentication configured to an interface without authentication configured, the supplicant's authentication status is deleted.

A supplicant is re-authenticated when it moves to a destination interface that is configured on a different VLAN than the VLAN that is configured for the source interface.

See the below Roaming Authentication feature interactions on x600 series switches:

- Multiple Dynamic VLANs are supported when configured with the [auth dynamic-vlan-creation command on page 57.4](#) using the multi parameter. Multiple Dynamic VLANs are disabled by default.
- Supplicants are re-authenticated on the destination interface if the VLAN ID changes when Single Dynamic VLANs are configured with the [auth dynamic-vlan-creation command on page 57.4](#) the using the single parameter. Single Dynamic VLANs are disabled by default.
- The Roaming Authentication feature is supported on Guest VLANs configured by the [auth guest-vlan command on page 57.6](#),

When the Roaming Authentication feature is configured for use on a stack with the VCStack feature, note that supplicants are initialized and re-authenticated if a VCStack fail over occurs.

Unauthenticated Supplicant Traffic

When any authentication is configured on a switch port, the question arises as to what the switch does with packets that arrive into the switch port from unauthenticated supplicants.

Unauthenticated supplicants fall into three categories listed below:

- Newly attached supplicants, which are still in the process of their first authentication attempt
- Supplicants that have made an authentication attempt, but have failed authentication
- Supplicants that have been attached, but have not made an authentication attempt. For example, on a port that has only 802.1x authentication enabled, any supplicant that has no 802.1x client software will not be able to attempt 802.1x authentication.

In switches that are running the AlliedWare Plus operating system, packets from all these three categories of unauthenticated supplicants are treated equally; no distinction is made between these three categories. The treatment of the traffic from unauthenticated supplicants does, however, depend on two factors:

- Whether a Guest VLAN has been configured on the switch port to which the supplicant is attached
- Whether Web authentication has been configured on the switch port to which the supplicant is attached

The rules governing the treatment of packets from unauthenticated supplicants are laid out in the table below.

Switch port configuration	No Guest VLAN configured	Guest VLAN configured
Web authentication configured	Packets from unauthenticated supplicants are associated with the Native VLAN of the port. Packets from unauthenticated supplicants are processed according to these rules: ■ Packets destined to the WebAuth server IP address/TCP port are forwarded to the server (which may well be the switch itself). ■ DHCP packets are sent to the CPU, to be processed by a local DHCP server, or relayed to another DHCP server, depending on the configuration of the switch. ■ DNS packets are forwarded to the CPU, and then sent on to a DNS server, if the switch is configured with a DNS server address. ■ ARP packets are forwarded to the CPU, and an ARP entry for the supplicant is learnt. ■ If web-auth forwarding is enabled for particular types of packets, then those packets will be forwarded within the Native VLAN ■ All other packets are dropped.	Packets from unauthenticated supplicants are associated with the Guest VLAN of the port. Packets from unauthenticated supplicants are processed according to these rules: ■ Packets destined to the WebAuth server IP address/TCP port are forwarded to the server (which may well be the switch itself). ■ DHCP packets are sent to the CPU, to be processed by a local DHCP server, or relayed to another DHCP server, depending on the configuration of the switch. ■ DNS packets are forwarded to the CPU, and then sent on to a DNS server, if the switch is configured with a DNS server address. ■ ARP packets are forwarded to the CPU, and an ARP entry for the supplicant is learnt. ■ Drop all other packets destined to the IP address of the Guest VLAN. ■ Layer-2 forward packets destined to other addresses within the Guest VLAN. ■ All other packets are dropped.
No Web authentication configured	All non-eap packets from unauthenticated supplicants are dropped.	Packets from unauthenticated supplicants are associated with the Guest VLAN of the port. The packets are processed according to these rules: ■ Drop packets destined to the IP address of the Guest VLAN. ■ Layer-2 forward packets destined to other addresses within the Guest VLAN. ■ Drop all other packets.

Deciding when a supplicant fails authentication

Although the treatment of packets from unauthenticated supplicants does not differentiate between the three categories of supplicant, it is still useful to know for sure when the switch decides that a supplicant has failed authentication.

The rules for deciding that a supplicant has failed authentication are listed below for each type of authentication available:

Deciding when a supplicant fails 802.1X authentication

If the supplicant responds to EAP authentication requests, and the supplicant's authentication information is sent to the RADIUS server, and the RADIUS server replies with an Authentication-Reject, then the supplicant is immediately deemed to have failed authentication.

If the supplicant does not respond to EAP authentication requests, then the switch will resend the authentication requests up to a maximum number of attempts set by the command `dot1x max-reauth-req` (the default is 2) . The interval between the attempts is set by the command `dot1x timeout tx-period` (the default is 30 seconds). If the supplicant still has not responded after this, it is deemed to have not attempted authentication.

See [Chapter 55, 802.1X Commands](#) for 802.1X authentication command information.

Deciding when a supplicant fails Web authentication

As soon as the supplicant attempts any web-browsing, the switch will intercept the web session, and present the supplicant with an authentication request page. If the user enters a username and password, and clicks the login button, then the switch will send the username and password to the RADIUS server. If the RADIUS server replies with an Authentication-Reject, then the supplicant is immediately deemed to have failed authentication.

Until the supplicant has attempted any web-browsing, or has received the authentication request page, but not yet clicked the login button, the supplicant is deemed to be not yet authenticated (as against not able to authenticate).

See [Chapter 57, Authentication Commands](#) for Web authentication command information.

Deciding when a supplicant fails MAC authentication

As soon as the supplicant sends any packet, the source MAC address from the packet will be sent to the RADIUS server for authentication. If the RADIUS server replies with an Authentication-Reject, then the supplicant is immediately deemed to have failed authentication.

With MAC auth there really is no concept of not-yet-attempted authentication, because authentication is attempted as soon as a supplicant sends a packet.

See [Chapter 57, Authentication Commands](#) for MAC authentication command information.

Chapter 57: Authentication Commands

Command List	57.3
auth critical	57.3
auth dynamic-vlan-creation	57.4
auth guest-vlan	57.6
auth host-mode	57.8
auth max-supplicant	57.9
auth reauthentication	57.10
auth roaming disconnected	57.11
auth roaming enable	57.13
auth supplicant-mac	57.15
auth timeout quiet-period	57.17
auth timeout reauth-period	57.18
auth timeout server-timeout	57.19
auth timeout supp-timeout	57.20
auth-mac enable	57.21
auth-mac method	57.22
auth-mac reauth-relearning	57.23
auth-web enable	57.24
auth-web forward	57.25
auth-web max-auth-fail	57.27
auth-web method	57.28
auth-web-server http-redirect	57.29
auth-web-server ipaddress	57.30
auth-web-server ping-poll enable	57.31
auth-web-server ping-poll failcount	57.32
auth-web-server ping-poll interval	57.33
auth-web-server ping-poll reauth-fresh	57.34
auth-web-server ping-poll timeout	57.35
auth-web-server port	57.36
auth-web-server redirect-url	57.37
auth-web-server session-keep	57.38
auth-web-server ssl	57.39
auth-web-server sslport	57.40
copy web-auth-https-file	57.41
erase web-auth-https-file	57.41
show auth-mac	57.42
show auth-mac diagnostics	57.43
show auth-mac interface	57.44
show auth-mac sessionstatistics	57.46
show auth-mac statistics interface	57.47
show auth-mac supplicant	57.47
show auth-mac supplicant interface	57.48
show auth-web	57.49
show auth-web diagnostics	57.50
show auth-web interface	57.51
show auth-web sessionstatistics	57.53
show auth-web statistics interface	57.54

show auth-web supplicant	57.55
show auth-web supplicant interface	57.56
show auth-web-server	57.57

Command List

This chapter provides an alphabetical reference for Authentication commands. For more information, see [Chapter 56, Authentication Configuration](#), and [Chapter 59, AAA Commands](#).

auth critical

This command enables the critical port feature on the interface. When the critical port feature is enabled on an interface, and all the RADIUS servers are unavailable, then the interface becomes authorized.

The no auth critical command disables critical port feature on the interface.

Syntax `auth critical`
`no auth critical`

Parameter	Description
no	Negate a command or set its defaults
auth	Port Authentication
critical	Operation in case there is no response from radius server

Default The critical port of port authentication is disabled.

Mode Interface Configuration for a static channel, a dynamic (LACP) channel group, or a switch port.

Examples To enable the critical port feature on interface `port1.0.2`, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# auth critical
```

To disable the critical port feature on interface `port1.0.2`, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# no auth critical
```

**Validation
Commands** `show auth-web-server`
`show dot1x`
`show dot1x interface`
`show running-config`

auth dynamic-vlan-creation

This command enables and disables the Dynamic VLAN assignment feature.

The Dynamic VLAN assignment feature allows a supplicant to be placed into a specific VLAN based on information returned from the RADIUS server during authentication, on a given interface.

Use the `no auth dynamic-vlan-creation` command to disable the Dynamic VLAN assignment feature.

Syntax `auth dynamic-vlan-creation [rule {deny|permit}][type {multi|single}]`
`no auth dynamic-vlan-creation`

Parameter	Description
<code>auth</code>	Port Authentication
<code>dynamic-vlan-creation</code>	Dynamic VLAN creation
<code>rule</code>	VLAN assignment rule
<code>deny</code>	Deny a differently assigned VLAN ID. This is the default rule.
<code>permit</code>	Permit a differently assigned VLAN ID
<code>type</code>	Specifies whether multiple different VLANs can be assigned to supplicants attached to the port, or whether only a single VLAN can be assigned to supplicants on the port.
<code>multi</code>	Multiple Dynamic VLAN
<code>single</code>	Single Dynamic VLAN

Default By default, the Dynamic VLAN assignment feature is disabled.

Mode Interface Configuration for a static channel, a dynamic (LACP) channel group, or a switch port.

Usage If the Dynamic VLAN assignment feature is enabled (disabled by default), VLAN assignment is dynamic. If the Dynamic VLAN assignment feature is disabled then RADIUS attributes are ignored and configured VLANs are assigned to ports. Dynamic VLANs may be associated with authenticated MAC addresses if the type parameter is applied with the rule parameter.

The rule parameter deals with the case where there are multiple supplicants attached to a port, and the type parameter has been set to single-vlan. The parameter specifies how the switch should act if different VLAN IDs end up being assigned to different supplicants. The keyword value `deny` means that once a given VID has been assigned to the first supplicant, then if any subsequent supplicant is assigned a different VID, that supplicant is rejected. The keyword value `permit` means that once a given VID has been assigned to the first supplicant, then if any subsequent supplicant is assigned a different VID, that supplicant is accepted, but it is actually assigned the same VID as the first supplicant.

If you issue an `auth dynamic-vlan-creation` command without an optional rule parameter and a required `deny` or `permit` keyword value then a second supplicant with a different VLAN ID is rejected. It is not assigned to the first supplicant's VLAN. Issuing an `auth dynamic-vlan-creation`

command without an optional rule parameter has the same effect as issuing an `auth dynamic-vlan-creation rule deny` command rejecting supplicants with differing VIDs.

The `type` parameter specifies whether multiple different VLANs can be assigned to supplicants attached to the port, or whether only a single VLAN can be assigned to supplicants on the port. The `type` parameter can select the port base VLAN or the MAC base VLAN from the RADIUS VLAN ID. This can be used when the `host-mode` is set to `multi-supplicant`. For single-host ports, the VLAN ID will be assigned to the port. It is not supported with the Guest VLAN feature. Display the ID assigned using a `show vlan` command. For multi-host ports, the VLAN ID will be assigned to the MAC address of the authenticated supplicant. The VLAN ID assigned for the MAC Base VLAN is displayed using the `show platform table vlan` command.

Examples To enable the Dynamic VLAN assignment feature on interface `port1.0.2`, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# auth dynamic-vlan-creation
```

To disable the Dynamic VLAN assignment feature on interface `port1.0.2`, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# no auth dynamic-vlan-creation
```

**Validation
Commands** `show dot1x`
`show dot1x interface`
`show running-config`

Related Commands `auth host-mode`

auth guest-vlan

This command enables the Guest VLAN feature on the interface specified by associating a guest VLAN with an interface. This command does not start authentication. The supplicant's traffic is associated with the native VLAN of the interface if its not already associated with another VLAN.

The `no auth guest-vlan` command disables the guest vlan feature on the interface specified.

Syntax `auth guest-vlan <1-4094>`
`no auth guest-vlan`

Parameter	Description
<code>no</code>	Negate a command or set its defaults
<code>auth</code>	Port Authentication
<code>guest-vlan</code>	set guest vlan
<code><1-4094></code>	VLAN ID (VID)

Default The Guest VLAN authentication feature is disabled by default.

Mode Interface Configuration for a static channel, a dynamic (LACP) channel group, or a switch port.

Usage The Guest VLAN feature may be used by supplicants (client devices) that have not attempted authentication, or have failed the authentication process. Note that if a port is in multi-supplicant mode with per-port dynamic VLAN configuration, after the first successful authentication, subsequent hosts cannot use the guest VLAN due to the change in VLAN ID. This may be avoided by using per-user dynamic VLAN assignment.

When using the Guest VLAN feature with the multi-host mode, a number of supplicants can communicate via a guest VLAN before authentication. A supplicant's traffic is associated with the native VLAN of the specified switch port. The supplicant must belong to a VLAN before traffic from the supplicant can be associated.

Note that you must first define the VLAN with the `vlan` command that you will assign as a guest VLAN using this command. Also note that 802.1X must first be enabled on the port.

Examples To define `vlan100` and assign the guest vlan feature to `vlan100` on interface `port1.0.2`, use the following commands:

```
awplus# configure terminal
awplus(config)# vlan database
awplus(config-vlan)# vlan 100
awplus(config-vlan)# exit
awplus(config)# interface port1.0.2
awplus(config-if)# dot1x port-control auto
awplus(config-if)# auth guest-vlan 100
```

To disable the guest vlan feature on interface `port1.0.2`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# no auth guest-vlan
```

**Validation
Commands** `show dot1x`
`show dot1x interface`
`show running-config`

Related Commands `dot1x port-control`
`vlan`

auth host-mode

This command selects host mode on the interface. Multi-host is an extension to IEEE802.1X. Use the no auth host-mode command to set host mode to the default setting (single host).

Syntax `auth host-mode {single-host|multi-host|multi-supPLICant}`
`no auth host-mode`

Parameter	Description
no	Negate a command or set its defaults
auth	Port Authentication
host-mode	Set host-mode on a port
single-host	Single host mode
multi-host	Multi host mode
multi-supPLICant	Multi supplicant mode

Default The default host mode for port authentication is for a single host.

Mode Interface Configuration for a static channel, a dynamic (LACP) channel group, or a switch port.

Examples To set the host mode to multi-supPLICant on interface port 1.0.2, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# auth host-mode multi-supPLICant
```

To set the host mode to default (single host) on interface port 1.0.2, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# no auth host-mode
```

Validation Commands `show dot1x`
`show dot1x interface`
`show running-config`

auth max-suppliant

This command sets the maximum number of supplicants on the interface that can be authenticated. After this value is exceeded supplicants are not authenticated.

The no auth max-suppliant command resets the maximum supplicant number to the default (1024).

Syntax `auth max-suppliant <2-1024>`

`no auth max-suppliant`

Parameter	Description
no	Negate a command or set its defaults
auth	Port Authentication
max-suppliant	Max supplicant for port
<2-1024>	Limit number

Default The max supplicant of port authentication is 1024.

Mode Interface Configuration for a static channel, a dynamic (LACP) channel group, or a switch port.

Examples To set the maximum number of supplicants to 10 on interface port 1.0.2, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# auth max-suppliant 10
```

To reset the maximum number of supplicant to default on interface port 1.0.2, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# no auth max-suppliant
```

**Validation
Commands** `show dot1x`
`show dot1x interface`
`show running-config`

auth reauthentication

This command enables re-authentication on the interface specified in the Interface mode, which may be a static channel group (or static aggregator) or a dynamic (or LACP) channel group or a switch port.

Use the no auth reauthentication command to disables reauthentication on the interface.

Syntax `auth reauthentication`
`no auth reauthentication`

Parameter	Description
no	Negate a command or set its defaults
auth	Port Authentication
reauthentication	Enable reauthentication on a port

Default Reauthentication of port authentication is disabled by default.

Mode Interface Configuration for a static channel, a dynamic (LACP) channel group, or a switch port.

Example To enable reauthentication on interface `port1.0.2`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# auth reauthentication
```

To disable reauthentication on interface `port1.0.2`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# no auth reauthentication
```

**Validation
Commands** `show dot1x`
`show dot1x interface`
`show running-config`

auth roaming disconnected

This command enables the roaming authentication feature on an authenticated interface that is link down. A supplicant is not reauthenticated when moved between authenticated interfaces, providing both interfaces have the roaming authentication feature enabled before the supplicant is moved.

Use the [auth roaming enable](#) command before using this command. The [auth roaming disconnected](#) command on its own will have no effect on the operation of the switch. This command will only come into effect once the base Roaming Authentication feature is enabled, using the [auth roaming enable](#) command.

The no form of this command disables the roaming authentication feature on an interface, and forces a supplicant to be reauthenticated when moving between interfaces.

See [“Roaming Authentication” on page 56.4](#) for further information about this feature.

Syntax `auth roaming disconnected`
`no auth roaming disconnected`

Default The roaming authentication `disconnected` feature is disabled by default on an interface. Authentication status for a roaming supplicant is deleted by default when an interface goes down.

Mode Interface Configuration for a static channel, a dynamic (LACP) channel group, or a switch port.

Usage This command allows a supplicant to move to another authenticating interface without reauthentication, if the link is down for the interface that the supplicant is moved from.

Note that 802.1X port authentication, or MAC authentication, or Web Authentication must first be enabled on an interface to use this feature. The port that the supplicant is moving to must have the same authentication configuration as the port the supplicant is moving from.

Configure [auth roaming enable](#) on an interface before configuring [auth roaming disconnected](#) if you require [auth roaming disconnected](#) configured on an interface for a roaming supplicant.

Examples To enable roaming authentication `disconnected` feature for `port1.0.2`, after enabling 802.1x authentication and enabling roaming authentication `enable`, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# dot1x port-control auto
awplus(config-if)# auth roaming enable
awplus(config-if)# auth roaming disconnected
```

To disable roaming authentication `disconnected` feature for `port1.0.2`, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# no auth roaming disconnected
```

**Validation
Commands** `show running-config`

Related Commands `auth-mac enable`
 `auth roaming enable`
 `auth-web enable`
 `dot1x port-control`
 `show auth-mac interface`
 `show auth-web interface`
 `show dot1x interface`

auth roaming enable

This command enables the roaming authentication feature on an authenticated interface that is link up. A supplicant is not reauthenticated when moved between authenticated interfaces, providing both interfaces have the roaming authentication feature enabled before the supplicant is moved.

Use the `auth roaming enable` command before using `auth roaming disconnected` command. The `auth roaming disconnected` command on its own will have no effect on the operation of the switch. This command will only come into effect once the base Roaming Authentication feature is enabled, using the `auth roaming enable` command.

The no form of this command disables the roaming authentication feature on an interface, and forces a supplicant to be reauthenticated when moving between interfaces.

See “Roaming Authentication” on page 56.4 for further information about this feature.

Syntax `auth roaming enable`
`no auth roaming enable`

Default The roaming authentication enable feature is disabled by default on an interface. Authentication status for a roaming supplicant is deleted by default when an interface goes down.

Mode Interface Configuration for a static channel, a dynamic (LACP) channel group, or a switch port.

Usage This command allows a supplicant to move to another authenticating interface without reauthentication, providing the link is up for the interface that the supplicant is moved from.

Note that 802.1X port authentication, or MAC authentication, or Web Authentication must first be enabled on an interface to use this feature. The port that the supplicant is moving to must have the same authentication configuration as the port the supplicant is moving from.

Configure `auth roaming enable` on an interface before configuring `auth roaming disconnected` if you require `auth roaming disconnected` configured on an interface for a roaming supplicant.

Examples To enable the roaming authentication enable feature for interface `port1.0.4`, after enabling 802.1x authentication, since an authentication method is required, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.4
awplus(config-if)# dot1x port-control auto
awplus(config-if)# auth roaming enable
```

To disable roaming authentication enable for `port1.0.4`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.4
awplus(config-if)# no auth roaming enable
```

**Validation
Commands** `show running-config`

Related Commands `auth-mac enable`
 `auth roaming disconnected`
 `auth-web enable`
 `dot1x port-control`
 `show auth-mac interface`
 `show auth-web interface`
 `show dot1x interface`

auth supplicant-mac

This command adds a supplicant mac address on a given interface with the parameters as specified in the table below.

Use the no auth supplicant-mac command to delete the supplicant MAC address added by the auth supplicant-mac command, and resets to the default for the supplicant parameter.

Syntax

```
auth supplicant <mac-addr>
    [max-reauth-req <1-10>]
    [port-control {auto | force-authorized | force-unauthorized}]
    [quiet-period <1-65535>]
    [reauth-period <1-4294967295>]
    [supp-timeout <1-65535>]
    [server-timeout <1-65535>] [reauthentication]

no auth supplicant-mac <macadd> [reauthentication]
```

Parameter	Description
no	Negate a command or set its defaults
auth	IEEE 802.1X Port-Based Access Control (Port Authentication)
supplicant-mac	Enable port authentication specified MAC address
<mac-addr>	MAC (hardware) address of the Supplicant entry in HHHH.HHHH.HHHH MAC address hexadecimal format
port-control	Port control commands
auto	Allow port client to negotiate authentication
force-authorized	Force port state to authorized
force-unauthorized	Force port state to unauthorized
quiet-period	Quiet period in the HELD state (default 60 seconds)
<1-65535>	Seconds for quiet period
reauth-period	Seconds between reauthorization attempts (default 3600 seconds)
<1-4294967295>	Seconds for reauthorization attempts (reauth-period)
supp-timeout	Supplicant response timeout (default 30 seconds)
<1-65535>	Seconds for supplicant response timeout
server-timeout	Authentication server response timeout (default 30 seconds)
<1-65535>	Seconds for authentication server response timeout
reauthentication	Enable reauthentication on a port
max-reauth-req	No of reauthentication attempts before becoming unauthorized (default 2)
<1-10>	Count of reauthentication attempts

Default No supplicant MAC address for port authentication exists by default until first created with the `auth supplicant-mac` command. The defaults for parameters applied are as shown in the table.

Mode Interface Configuration for a static channel, a dynamic (LACP) channel group, or a switch port.

Examples To add the supplicant MAC address 0009.41A4.5943 to force authorized port control for interface `port1.0.2`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# auth supplicant-mac 0009.41A4.5943 port-
control force-authorized
```

To delete the supplicant MAC address 0009.41A4.5943 for interface `port1.0.2`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# no auth supplicant-mac 0009.41A4.5943
```

To reset reauthentication to disable for the supplicant MAC address 0009.41A4.5943, for interface `port1.0.2` use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# no auth supplicant-mac 0009.41A4.5943
reauthentication
```

**Validation
Commands** `show dot1x`
`show dot1x interface`
`show running-config`

auth timeout quiet-period

This command sets the time period for which the authentication request is not accepted on a given interface, after the authentication request has failed an authentication.

Use the `no auth timeout quiet-period` command to reset quiet period to the default (60 seconds).

Syntax `auth timeout quiet-period <1-65535>`
`no auth timeout quiet-period`

Parameter	Description
<code>no</code>	Negate a command or set its defaults
<code>auth</code>	Port Authentication
<code>timeout</code>	Set a timeout parameter
<code>quiet-period</code>	Quiet period in the HELD state (default is 60 seconds)
<code><1-65535></code>	Seconds

Default The quiet period of port authentication is 60 seconds.

Mode Interface Configuration for a static channel, a dynamic (LACP) channel group, or a switch port.

Examples To set the quiet period to 10 for interface `port1.0.2`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# auth timeout quiet-period 10
```

To reset the quiet period to the default (60 seconds) for interface `port1.0.2`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# no auth timeout quiet-period
```

auth timeout reauth-period

This command sets the timer for reauthentication on a given interface. The re-authentication for the Supplicant is executed at this timeout. The timeout is only applied if the auth reauthentication command is applied.

Use the no auth timeout reauth-period command to reset the reauth-period parameter to the default value (3600 seconds).

Syntax `auth timeout reauth-period <1-4294967295>`
`no auth timeout reauth-period`

Parameter	Description
no	Negate a command or set its defaults
auth	Port Authentication
timeout	Set a timeout parameter
reauth-period	Seconds between reauthorization attempts (default is 3600 seconds)
<1-4294967295>	Seconds

Default The default reauthentication period for port authentication is 3600 seconds, when reauthentication is enabled on the port.

Mode Interface Configuration for a static channel, a dynamic (LACP) channel group, or a switch port.

Examples To set the reauthentication period to 1 day for interface `port1.0.2`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# auth timeout reauth-period 86400
```

To reset the reauthentication period to the default (3600 seconds) for interface `port1.0.2`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# no auth timeout reauth-period
```

Validation Commands `show dot1x`
`show dot1x interface`
`show running-config`

Related Commands `auth reauthentication`

auth timeout server-timeout

This command sets the timeout for the waiting response from the RADIUS server on a given interface.

The no auth timeout server-timeout command resets the server-timeout to the default value (30 seconds).

Syntax `auth timeout server-timeout <1-65535>`
`no auth timeout server-timeout`

Parameter	Description
no	Negate a command or set its defaults
auth	Port Authentication
timeout	Set a timeout parameter
server-timeout	Authentication server response timeout (default 30 seconds)
<1-65535>	Seconds

Default The server timeout for port authentication is 30 seconds.

Mode Interface Configuration for a static channel, a dynamic (LACP) channel group, or a switch port.

Examples To set the server timeout to 120 seconds for interface `port1.0.2`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# auth timeout server-timeout 120
```

To set the server timeout to the default (30 seconds) for interface `port1.0.2`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# no auth timeout server-timeout
```

**Validation
Commands** `show dot1x`
`show dot1x interface`
`show running-config`

auth timeout supp-timeout

This command sets the timeout of the waiting response from the supplicant on a given interface.

The `no auth timeout supp-timeout` command resets the supplicant timeout to the default (30 seconds).

Syntax `auth timeout supp-timeout <1-65535>`

`no auth timeout supp-timeout`

Parameter	Description
no	Negate a command or set its defaults
auth	Port Authentication
timeout	Set a timeout parameter
supp-timeout	Supplicant response timeout (default 30 seconds)
<1-65535>	Seconds

Default The supplicant timeout of port authentication is 30 seconds.

Mode Interface Configuration (either a static channel or a dynamic (LACP) channel group or a switch port)

Examples To set the server timeout to 2 seconds for interface `port1.0.2`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# auth timeout supp-timeout 2
```

To reset the server timeout to the default (30 seconds) for interface `port1.0.2`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# no auth timeout supp-timeout
```

**Validation
Commands** `show dot1x`
`show dot1x interface`
`show running-config`

auth-mac enable

This command enables MAC based authentication on the interface specified in the Interface command mode.

Use the no auth-mac enable command to disable MAC based authentication on an interface.

Syntax `auth-mac enable`
`no auth-mac enable`

Parameter	Description
no	Negate a command or set its defaults
auth-mac	MAC-Based Authentication
enable	Enables MAC authentication on the interface
disable	Disables MAC authentication on the interface

Default MAC authentication is disabled by default.

Mode Interface Configuration (either a static channel or a dynamic (LACP) channel group or a switch port)

Examples To enable MAC authentication on interface port 1.0.2 , use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# auth-mac enable
```

To disable MAC authentication on interface port 1.0.2 , use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# no auth-mac enable
```

Validation Commands `show auth-mac`
`show auth-mac interface`
`show running-config`

Related Commands `aaa accounting auth-mac default`
`aaa authentication auth-mac`

auth-mac method

This command sets the type of authentication method for MAC authentication that is used with RADIUS on the interface specified in the Interface command mode.

The no auth-mac method command resets the authentication method used to the default method (PAP) as the RADIUS authentication method used by the MAC authentication.

Syntax `auth-mac method [eap-md5|pap]`

`no auth-mac method`

Parameter	Description
no	Negate a command or set its defaults
auth-mac	MAC-Based Authentication
method	Authentic method (for RADIUS)
eap-md5	Enable EAP-MD5 of authentication method
pap	Enable PAP of authentication method

Default The mac authentication method is PAP.

Mode Interface Configuration (either a static channel or a dynamic (LACP) channel group or a switch port)

Examples To set the MAC authentication method to pap on interface port1.0.2, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# auth-mac method pap
```

To set the MAC authentication method to the default on interface port1.0.2, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# no auth-mac method
```

**Validation
Commands** `show auth-mac`
`show auth-mac interface`
`show running-config`

auth-mac reauth-relearning

This command sets the MAC address learning of the supplicant to re-learning for re-authentication on the interface specified in the Interface command mode.

Use the no auth-mac reauth-relearning command to disable the auth-mac re-learning option.

Syntax `auth-mac reauth-relearning`
`no auth-mac reauth-relearning`

Parameter	Description
no	Negate a command or set its defaults
auth-mac	MAC-Based Authentication
reauth-relearning	Relearning of MAC based Authentication

Default Re-learning for port authentication is disabled by default.

Mode Interface Configuration (either a static channel or a dynamic (LACP) channel group or a switch port)

Examples To enable the re-authentication re-learning feature on interface `port1.0.2`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# auth-mac reauth-relearning
```

To disable the re-authentication re-learning feature on interface `port1.0.2`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# no auth-mac reauth-relearning
```

**Validation
Commands** `show auth-mac`
`show auth-mac interface`
`show running-config`

auth-web enable

This command enables Web-based authentication in Interface mode on the interface specified. Use the `no auth-web enable` command to disable Web-based authentication on an interface.

Syntax `auth-web enable`
`no auth-web enable`

Parameter	Description
<code>no</code>	Negate a command or set its defaults
<code>auth-web</code>	Web-based Authentication
<code>enable</code>	Enables Web-based authentication
<code>disable</code>	Disables Web-based authentication

Default Web authentication is disabled by default.

Mode Interface Configuration (either a static channel or a dynamic (LACP) channel group or a switch port)

Examples To enable Web authentication on interface `port1.0.2`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# auth-web enable
```

To disable Web authentication on interface `port1.0.2`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# no auth-web enable
```

Validation Commands `show auth-web`
`show auth-web interface`
`show running-config`

Related Commands `aaa accounting auth-web default`
`aaa authentication auth-web`

auth-web forward

This command enables the web authentication packet forwarding feature on the interface specified. This command also enables ARP forwarding, and adds forwarded packets to the tcp or udp port number specified.

The no auth-web forwarding command disables or deletes the packet forwarding feature on the interface.

Syntax `auth-web forward {arp|dhcp|dns|tcp <1-65535>|udp <1-65535>}`
`no auth-web forward [arp|dhcp|dns|tcp <1-65535>|udp <1-65535>]`

Parameter	Description
no	Negate a command or set its defaults
auth-web	Web-Based Authentication
forward	Enable packet forwarding on a port
arp	Enable forwarding of ARP
dhcp	Enable forwarding of DHCP (67/udp)
dns	Enable forwarding of DNS (53/udp)
tcp	Enable forwarding of TCP specified port number
<1-65535>	TCP Port number
udp	Enable forwarding of UDP specified port number
<1-65535>	UDP Port number

Default Packet forwarding for port authentication is disabled by default.

Mode Interface Configuration (either a static channel or a dynamic (LACP) channel group or a switch port)

Examples To enable the arp forwarding feature on interface `port1.0.2`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# auth-web forward arp
```

To add the tcp forwarding port 137 on interface `port1.0.2`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# auth-web forward tcp 137
```

To disable the ARP forwarding feature on interface `port1.0.2`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# no auth-web forward arp
```

To delete the tcp forwarding port 137 on interface `port1.0.2`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# no auth-web forward tcp 137
```

To delete the all of tcp forwarding on interface `port1.0.2`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# no auth-web forward tcp
```

**Validation
Commands** `show auth-web`
 `show auth-web interface`
 `show running-config`

auth-web max-auth-fail

This command sets the number of authentication failures allowed before rejecting further authentication requests. When the supplicant fails more than has been set to the maximum number of authentication failures then login requests are refused during the quiet period.

The no auth-web max-auth-fail command resets the maximum number of authentication failures to the default value (3 authentication failures).

Syntax `auth-web max-auth-fail <0-10>`

`no auth-web max-auth-fail`

Parameter	Description
no	Negate a command or set its defaults
auth-web	Web-Based Authentication
max-auth-fail	The number of Web authentication failures that causes a transition to the HELD state for Web authentication.
<0-10>	Lock count specified

Default The max-auth-fail lock counter is set to 3 authentication failures by default.

Mode Interface Configuration (either a static channel or a dynamic (LACP) channel group or a switch port)

Examples To set the lock count to 5 on interface `port1.0.2`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# auth-web max-auth-fail 5
```

To set the lock count to the default on interface `port1.0.2`, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# no auth-web max-auth-fail
```

Validation Commands `show auth-web`
`show auth-web interface`
`show running-config`

Related Commands `auth timeout quiet-period`

auth-web method

This command sets the authentication method of WEB authentication that is used with RADIUS on the interface specified.

The no auth-web method command sets the authentication method to PAP for the interface specified when Web authentication is also used with the RADIUS authentication method.

Syntax `auth-web method {eap-md5|pap}`

`no auth-web method`

Parameter	Description
auth-web	Web-Based Authentication
method	Authentic method (for RADIUS)
eap-md5	Enable EAP-MD5 as the authentication method
pap	Enable PAP as the authentication method

Default The web authentication method is set to PAP by default.

Mode Interface Configuration (either a static channel or a dynamic (LACP) channel group or a switch port)

Example To set the web authentication method to eap-md5 on interface port 1.0.2, use the following commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# auth-web method eap-md5
```

**Validation
Commands** `show auth-web`
`show auth-web interface`
`show running-config`

auth-web-server http-redirect

This command enables the HTTP redirect feature on every interface on which web-based port authentication is enabled. When the HTTP redirect feature is enabled, any HTTP request received on an unauthorized interface is redirected to the web authentication server automatically.

Use the `no auth-web-server http-redirect` command to disable the HTTP redirect feature.

Syntax `auth-web-server http-redirect`
`no auth-web-server http-redirect`

Parameter	Description
<code>no</code>	Negate a command or set its defaults
<code>auth-web-server</code>	web authentication server configuration commands
<code>http-redirect</code>	redirect http request to web authentication server

Default The HTTP redirect feature is enabled by default.

Mode Global Configuration

Examples To disable the HTTP redirect feature, use the following commands:

```
awplus# configure terminal
awplus(config)# no auth-web-server http-redirect
```

To re-enable the HTTP redirect feature, use the following commands:

```
awplus# configure terminal
awplus(config)# auth-web-server http-redirect
```

Validation Commands `show auth-web`
`show auth-web-server`
`show running-config`

auth-web-server ipaddress

This command sets the IP address for the web authentication server.

Use the `no auth-web-server ipaddress` command to delete the IP address for the web authentication server.

Syntax `auth-web-server ipaddress <ip-addr>`
`no auth-web-server ipaddress`

Parameter	Description
<code>no</code>	Negate a command or set its defaults
<code>auth-web-server</code>	web authentication server configuration commands
<code>ipaddress</code>	Set local web authentication server address
<code><ip-addr></code>	web authentication server dotted decimal ip address (A.B.C.D format)

Default The web authentication server address on the system is not set by default.

Mode Global Configuration

Examples To set the IP address 10.0.0.1 to the web authentication server, use the following commands:

```
awplus# configure terminal
awplus(config)# auth-web-server ipaddress 10.0.0.1
```

To delete the IP address from the web authentication server, use the following commands:

```
awplus# configure terminal
awplus(config)# no auth-web-server ipaddress
```

**Validation
Commands** `show auth-web`
`show auth-web-server`
`show running-config`

auth-web-server ping-poll enable

This command enables the ping polling to the supplicant that is authenticated by web authentication.

The no auth-web-server ping-poll enable command disables the ping polling to the supplicant that is authenticated by web authentication.

Syntax `auth-web-server ping-poll enable`
`no auth-web-server ping-poll enable`

Parameter	Description
no	Negate a command or set its defaults
auth-web-server	web authentication server configuration commands
ping-poll	Ping polling configuration commands
enable	Enable ping polling

Default The ping polling feature for web authentication is disabled by default.

Mode Global Configuration

Examples To enable the ping polling feature for web authentication, use the following commands:

```
awplus# configure terminal
awplus(config)# auth-web-server ping-poll enable
```

To disable the ping polling feature for web authentication, use the following commands:

```
awplus# configure terminal
awplus(config)# no auth-web-server ping-poll enable
```

**Validation
Commands** `show auth-web`
`show auth-web-server`
`show running-config`

auth-web-server ping-poll failcount

This command sets a fail count for the ping polling feature when used with web authentication. The failcount parameter specifies the number of unanswered pings. A supplicant is logged off when the number of unanswered pings are greater than the failcount set with this command.

Use the no auth-web-server ping-poll failcount command to resets the fail count for the ping polling feature to the default (5 pings).

Syntax `auth-web-server ping-poll failcount <1-100>`
`no auth-web-server ping-poll failcount`

Parameter	Description
no	Negate a command or set its defaults
auth-web-server	web authentication server configuration commands
ping-poll	Ping polling configuration commands
failcount	Set the number of pings that is unanswered (default 5)
<1-100>	Count

Default The default failcount for ping polling is 5 pings.

Mode Global Configuration

Examples To set the failcount of ping polling to 10 pings, use the following commands:

```
awplus# configure terminal
awplus(config)# auth-web-server ping-poll failcount 10
```

To set the failcount of ping polling to default, use the following commands:

```
awplus# configure terminal
awplus(config)# no auth-web-server ping-poll failcount
```

**Validation
Commands** `show auth-web`
`show auth-web-server`
`show running-config`

auth-web-server ping-poll interval

This command is used to change the ping poll interval. The interval specifies the time period between pings when the supplicant is reachable.

Use the no auth-web-server ping-poll interval command to reset to the default period for ping polling (30 seconds).

Syntax `auth-web-server ping-poll interval <1-65535>`
`no auth-web-server ping-poll interval`

Parameter	Description
no	Negate a command or set its defaults
auth-web-server	web authentication server configuration commands
ping-poll	Ping polling configuration commands
interval	Set ping polling interval (default 30 seconds)
<1-65535>	Seconds

Default The interval for ping polling is 30 seconds by default.

Mode Global Configuration

Examples To set the interval of ping polling to 60 seconds, use the following commands:

```
awplus# configure terminal
awplus(config)# auth-web-server ping-poll interval 60
```

To set the interval of ping polling to the default (30 seconds), use the following commands:

```
awplus# configure terminal
awplus(config)# no auth-web-server ping-poll interval
```

**Validation
Commands** `show auth-web`
`show auth-web-server`
`show running-config`

auth-web-server ping-poll reauth-fresh

This command modifies the reauth-fresh parameter for the web-authentication feature. The reauth-fresh parameter specifies whether a re-authentication timer is reset and when the response from supplicant is received.

Use the no auth-web-server ping-poll reauth-fresh command to reset the reauth-fresh parameter to the default setting (disabled).

Syntax `auth-web-server ping-poll reauth-fresh`
`no auth-web-server ping-poll reauth-fresh`

Parameter	Description
no	Negate a command or set its defaults
auth-web-server	web authentication server configuration commands
ping-poll	Ping polling configuration commands
reauth-fresh	Enable reauthentication period updating when the response from supplicant is received

Default The reauth-fresh parameter is disabled by default.

Mode Global Configuration

Examples To enable the reauth-fresh timer, use the following commands:

```
awplus# configure terminal
awplus(config)# auth-web-server ping-poll reauth-fresh
```

To disable the reauth-fresh timer, use the following commands:

```
awplus# configure terminal
awplus(config)# no auth-web-server ping-poll reauth-fresh
```

**Validation
Commands** `show auth-web`
`show auth-web-server`
`show running-config`

auth-web-server ping-poll timeout

This command modifies the ping poll timeout parameter for the web authentication feature. The timeout parameter specifies the time in seconds to wait for a response to a ping packet.

Use the `no auth-web-server ping-poll timeout` command to reset the timeout of ping polling to the default (1 second).

Syntax `auth-web-server ping-poll timeout <1-30>`

`no auth-web-server ping-poll timeout`

Parameter	Description
<code>no</code>	Negate a command or set its defaults
<code>auth-web-server</code>	web authentication server configuration commands
<code>ping-poll</code>	Ping polling configuration commands
<code>timeout</code>	Set response waiting time (default 1sec)
<code><1-30></code>	Seconds

Default The default timeout for ping polling is 1 second.

Mode Global Configuration

Examples To set the timeout of ping polling to 2 seconds, use the command:

```
awplus# configure terminal
```

```
awplus(config)# auth-web-server ping-poll timeout 2
```

To set the timeout of ping polling to the default (1 second), use the command:

```
awplus# configure terminal
```

```
awplus(config)# no auth-web-server ping-poll timeout
```

**Validation
Commands** `show auth-web`
`show auth-web-server`
`show running-config`

auth-web-server port

This command sets the HTTP port number for the web authentication server. Use the `no auth-web-server port` command to reset the HTTP port number to the default value (80). Specify a TCP port number in the range 1-65535 using the `auth-web-server port` command.

Syntax `auth-web-server port <port_num>`

`no auth-web-server port`

Parameter	Description
<code>no</code>	Negate a command or set its defaults
<code>auth-web-server</code>	web authentication server configuration commands
<code>port</code>	local web authentication server port number
<code><port_num></code>	Set the local web authentication server port within the TCP port number range <1-65535>

Default The web authentication server HTTP port number is set to 80 by default.

Mode Global Configuration

Examples To set the HTTP port number 8080 for the web authentication server, use the following commands:

```
awplus# configure terminal
awplus(config)# auth-web-server port 8080
```

To reset to the default HTTP port number 80 for the web authentication server, use the following commands:

```
awplus# configure terminal
awplus(config)# no auth-web-server port
```

**Validation
Commands** `show auth-web`
`show auth-web-server`
`show running-config`

auth-web-server redirect-url

This command sets a URL for supplicant authentication. When a supplicant is authorized it will be automatically redirected to the specified URL. Note that if the http redirect feature is used then this command is ignored.

Use the no auth-web-server redirect-url command to delete the URL string set previously.

Syntax `auth-web-server redirect-url <url>`

`no auth-web-server redirect-url`

Parameter	Description
no	Negate a command or set its defaults
auth-web-server	web authentication server configuration commands
redirect-url	jump to the URL after the supplicant is authorized
<url>	URL (hostname or dotted IP notation)

Default The redirect URL for the web authentication server feature is not set by default (null).

Mode Global Configuration

Examples To enable and set redirect a URL string `www.alliedtelesis.com` for the web authentication server, use the following commands:

```
awplus# configure terminal
awplus(config)# auth-web-server redirect-url
                  www.alliedtelesis.com
```

To delete a redirect URL string, use the following commands:

```
awplus# configure terminal
awplus(config)# no auth-web-server redirect-url
```

**Validation
Commands** `show auth-web`
`show auth-web-server`
`show running-config`

Related Commands `auth-web-server http-redirect`

auth-web-server session-keep

This command enables the session-keep feature to jump to the original URL after being authorized by web authentication.

Use the no auth-web-server session-keep command to disable the session keep feature.

Syntax `auth-web-server session-keep`
`no auth-web-server session-keep`

Parameter	Description
no	Negate a command or set its defaults
auth-web-server	Web authentication server configuration commands
session-keep	Jump to the requested URL after being authorized by web authentication

Default The session-keep feature is disabled by default.

Mode Global Configuration

Examples To enable the session-keep feature, use the following commands:

```
awplus# configure terminal
awplus(config)# auth-web-server session-keep
```

To disable the session-keep feature, use the following commands:

```
awplus# configure terminal
awplus(config)# no auth-web-server session-keep
```

**Validation
Commands** `show auth-web`
`show auth-web-server`
`show running-config`

auth-web-server ssl

This command enables HTTPS functionality for the web authentication server feature.

Use the `no auth-web-server ssl` command to disable HTTPS functionality for the web authentication server.

Syntax `auth-web-server ssl`
`no auth-web-server ssl`

Parameter	Description
<code>no</code>	Negate a command or set its defaults
<code>auth-web-server</code>	web authentication server configuration commands
<code>ssl</code>	Enable ssl web authentication server access

Default HTTPS functionality for the web authentication server feature is disabled by default.

Mode Global Configuration

Examples To enable HTTPS functionality for the web authentication server feature, use the following commands:

```
awplus# configure terminal
```

```
awplus(config)# auth-web-server ssl
```

To disable HTTPS functionality for the web authentication server feature, use the following commands:

```
awplus# configure terminal
```

```
awplus(config)# no auth-web-server ssl
```

**Validation
Commands** `show auth-web`
`show auth-web-server`
`show running-config`

auth-web-server sslport

This command sets the HTTPS port number for the web authentication server feature. Specify a TCP port number in the range 1-65535 using the auth-web-server sslport command.

Use the no auth-web-server sslport command to reset the HTTPS port number to the default port number (443) for the web authentication server feature.

Syntax `auth-web-server sslport <1-65535>`
`no auth-web-server sslport`

Parameter	Description
no	Negate a command or set its defaults
auth-web-server	web authentication server configuration commands
sslport	local web authentication server ssl port number
<1-65535>	Set the local web authentication server port within the TCP port number range <1-65535>

Default The HTTPS port number for the web authentication server feature is set to 443 by default.

Mode Global Configuration

Examples To set the HTTPS port number to 4433 for the web authentication server, use the command:

```
awplus# configure terminal
awplus(config)# auth-web-server sslport 4433
```

To reset the HTTPS port number for the web authentication server to the default (443), use the command:

```
awplus# configure terminal
awplus(config)# no auth-web-server sslport
```

**Validation
Commands** `show auth-web`
 `show auth-web-server`
 `show running-config`

copy web-auth-https-file

Use this command to download the SSL server certificate for web-based authentication. The file must be in PEM (Privacy Enhanced Mail) format, and contain the private key and the server certificate.

Syntax `copy <filename> web-auth-https-file`

Parameter	Description
<code><filename></code>	The URL of the server certificate file.

Mode Privileged Exec

Example To download the server certificate file `verisign_cert.pem` from the TFTP server directory `server`, use the command:

```
awplus# copy tftp://server/verisign_cert.pem web-auth-https-file
```

Related Commands

- `auth-web-server ssl`
- `erase web-auth-https-file`
- `show auth-web-server`

erase web-auth-https-file

Use this command to remove the SSL server certificate for web-based authentication.

Syntax `erase web-auth-https-file`

Use this command to remove the SSL server certificate for web-based authentication.

Mode Privileged Exec

Examples To remove the SSL server certificate file for web-based authentication use the command:

```
awplus# erase web-auth-https-file
```

Related Commands

- `auth-web-server ssl`
- `copy web-auth-https-file`
- `show auth-web-server`

show auth-mac

This command shows authentication information for MAC-based authentication.

If the all parameter is specified then this command also displays all authentication information for each authenticated interface available on the switch.

Syntax `show auth-mac [all]`

Parameter	Description
all	Show all authentication information for each authenticated interface available on the switch.

Mode Exec and Privileged Exec

Example See the below example showing all MAC based authentication information:

```
awplus# show auth-mac all
```

```
802.1X Port-Based Authentication Disabled
MAC-based Port Authentication Enabled
WEB-based Port Authentication Disabled
```

Related Commands [show dot1x](#)
[show auth-web](#)

show auth-mac diagnostics

This command shows MAC authentication diagnostics, optionally for the specified interface, which may be a static channel (or static aggregator) or a dynamic (or LACP) channel group or a switch port.

If no interface is specified then authentication diagnostics are shown for all interfaces.

Syntax `show auth-mac diagnostics [interface <interface-list>]`

Parameter	Description
interface	Specify ports to show
<interface-list>	The interfaces or ports to configure. An interface-list can be: ■ an interface, a switch port, or a channel group (e.g., vlan2, port1.1.12, sa3, or po4) ■ a continuous range of interfaces, ports, or channel groups separated by a hyphen, e.g. vlan2-vlan8 or port1.1.1-port1.1.24 or sa2-4, po1-3 ■ a comma-separated list of the above, e.g., port1.0.1,port1.1.1-1.2.24. Do not mix interface types in a list. The specified interfaces must exist.

Mode Exec and Privileged Exec

Example See the sample output below showing authentication diagnostics for port1.0.12:

```
awplus# show auth-mac diagnostics interface port1.0.12
```

```
Authentication Diagnostics for interface port1.0.12
  Supplicant address: 00d0.59ab.7037
    authEnterConnecting: 2
    authEaplogoffWhileConnecting: 1
    authEnterAuthenticating: 2
    authSuccessWhileAuthenticating: 1
    authTimeoutWhileAuthenticating: 1
    authFailWhileAuthenticating: 0
    authEapstartWhileAuthenticating: 0
    authEaplogoggWhileAuthenticating: 0
    authReauthsWhileAuthenticated: 0
    authEapstartWhileAuthenticated: 0
    authEaplogoffWhileAuthenticated: 0
    BackendResponses: 2
    BackendAccessChallenges: 1
    BackendOtherrequestToSupplicant: 3
    BackendAuthSuccess: 1
```

show auth-mac interface

This command shows the status for MAC based authentication on the specified interface, which may be a static channel (or static aggregator) or a dynamic (or LACP) channel group or a switch port.

Use the optional diagnostics parameter to show authentication diagnostics for the specified interface. Use the optional sessionstatistics parameter to show authentication session statistics for the specified interface. Use the optional statistics parameter to show authentication diagnostics for the specified interface. Use the optional supplicant parameter to show the supplicant state for the specified interface.

Syntax `show auth-mac interface <interface-list>
[diagnostics|sessionstatistics|statistics|supplicant [brief]]`

Parameter	Description
<code><interface-list></code>	The interfaces or ports to configure. An interface-list can be: ■ an interface, a switch port, or a channel group (e.g., vlan2, port1.1.12, sa3, or po4) ■ a continuous range of interfaces, ports, or channel groups separated by a hyphen, e.g. vlan2-vlan8 or port1.1.1-port1.1.24 or sa2-4, po1-3 ■ a comma-separated list of the above, e.g., port1.0.1,port1.1.1-1.2.24. Do not mix interface types in a list. The specified interfaces must exist.
<code>diagnostics</code>	Diagnostics
<code>sessionstatistics</code>	Session statistics
<code>statistics</code>	Statistics
<code>supplicant</code>	Supplicant
<code><brief></code>	Brief summary of supplicant state

Mode Exec and Privileged Exec

Example See the sample output below showing MAC based authentication status for port1.0.12:

```
awplus# show auth-mac interface port1.0.2
```

```
% Port-Control not configured on port1.0.2
```

See the sample output below showing MAC authentication diagnostics for port1.0.12:

```
awplus# show auth-mac interface port1.0.12 diagnostics
```

```
Authentication Diagnostics for interface port1.0.12
  Supplicant address: 00d0.59ab.7037
    authEnterConnecting: 2
    authEaplogoffWhileConnecting: 1
    authEnterAuthenticating: 2
    authSuccessWhileAuthenticating: 1
    authTimeoutWhileAuthenticating: 1
    authFailWhileAuthenticating: 0
    authEapstartWhileAuthenticating: 0
    authEaplogoggWhileAuthenticating: 0
    authReauthsWhileAuthenticated: 0
    authEapstartWhileAuthenticated: 0
    authEaplogoffWhileAuthenticated: 0
    BackendResponses: 2
    BackendAccessChallenges: 1
    BackendOtherrequestToSupplicant: 3
    BackendAuthSuccess: 1
```

See the sample output below showing authentication session statistics for port1.0.12:

```
awplus# show auth-mac interface port1.0.12 sessionstatistics
```

```
Authentication session statistics for interface port1.0.12
  session user name: manager
    session authentication method: Remote server
    session time: 19440 secs
    session terminat cause: Not terminated yet
```

To view MAC authentication statistics for port1.0.12 issue the command:

```
awplus# show auth-mac interface port1.0.12 statistics
```

To show the MAC authenticated supplicant on interface port1.0.12 issue the command:

```
awplus# show auth-mac interface port1.0.12 supplicant
```

Related Commands

- [show auth-web diagnostics](#)
- [show dot1x sessionstatistics](#)
- [show dot1x statistics interface](#)
- [show dot1x supplicant interface](#)

show auth-mac sessionstatistics

This command shows authentication session statistics for the specified interface, which may be a static channel (or static aggregator) or a dynamic (or LACP) channel group or a switch port.

Syntax `show auth-mac sessionstatistics [interface <interface-list>]`

Parameter	Description
interface	Specify ports to show
<interface-list>	The interfaces or ports to configure. An interface-list can be: ■ an interface, a switch port, or a channel group (e.g., vlan2, port1.1.12, sa3, or po4) ■ a continuous range of interfaces, ports, or channel groups separated by a hyphen, e.g. vlan2-vlan8 or port1.1.1-port1.1.24 or sa2-4, po1-3 ■ a comma-separated list of the above, e.g., port1.0.1,port1.1.1-1.2.24. Do not mix interface types in a list. The specified interfaces must exist.

Mode Exec and Privileged Exec

Example See the sample output below showing MAC authentication session statistics for port1.0.12:

```
awplus# show auth-mac sessionstatistics interface port1.0.12
```

```
Authentication session statistics for interface port1.0.12
session user name: manager
session authentication method: Remote server
session time: 19440 secs
session terminat cause: Not terminated yet
```

show auth-mac statistics interface

This command shows the authentication statistics for the specified interface, which may be a static channel (or static aggregator) or a dynamic (or LACP) channel group or a switch port.

Syntax `show auth-mac statistics [interface <interface-list>]`

Parameter	Description
interface	Specify ports to show
<interface-list>	The interfaces or ports to configure. An interface-list can be: ■ an interface, a switch port, or a channel group (e.g., vlan2, port1.1.12, sa3, or po4) ■ a continuous range of interfaces, ports, or channel groups separated by a hyphen, e.g. vlan2-vlan8 or port1.1.1-port1.1.24 or sa2-4, po1-3 ■ a comma-separated list of the above, e.g., port1.0.1,port1.1.1-1.2.24. Do not mix interface types in a list. The specified interfaces must exist.

Mode Exec and Privileged Exec

Example To show MAC authentication statistics for port1.0.12 issue the command:

```
awplus# show auth-mac statistics interface port1.0.12
```

Related Commands [show dot1x interface](#)

show auth-mac supplicant

This command shows the supplicant state when MAC authentication is configured for the switch. This command shows a summary when the optional brief parameter is used.

Syntax `show auth-mac supplicant [<macadd>] [brief]`

Parameter	Description
<macadd>	Mac (hardware) address of the Supplicant Entry format is HHHH.HHHH.HHHH (hexadecimal)
brief	Brief summary of the Supplicant state

Mode Exec and Privileged Exec

Example To show the MAC authenticated supplicant for MAC address 00d0.59ab.7037 issue the command:

```
awplus# show auth-mac supplicant 00d0.59ab.7037
```

show auth-mac supplicant interface

This command shows the supplicant state for the MAC authenticated interface, which may be a static channel (or static aggregator) or a dynamic (or LACP) channel group or a switch port. This command shows a summary when the optional brief parameter is used.

Syntax `show auth-mac supplicant [interface <interface-list>] [brief]`

Parameter	Description
interface	Specify ports to show
<interface-list>	The interfaces or ports to configure. An interface-list can be: ■ an interface, a switch port, or a channel group (e.g., vlan2, port1.1.12, sa3, or po4) ■ a continuous range of interfaces, ports, or channel groups separated by a hyphen, e.g. vlan2-vlan8 or port1.1.1-port1.1.24 or sa2-4, po1-3 ■ a comma-separated list of the above, e.g., port1.0.1,port1.1.1-1.2.24. Do not mix interface types in a list. The specified interfaces must exist.
brief	Brief summary of the Supplicant state

Mode Exec and Privileged Exec

Example To show the MAC authenticated supplicant on the interface port1.0.12 issue the command:

```
awplus# show auth-mac supplicant interface port1.0.12
```

To show brief summary output for the MAC authenticated supplicant issue the command:

```
awplus# show auth-mac supplicant brief
```

show auth-web

This command shows authentication information for Web-based authentication.

If you specify the optional all parameter then this command also displays all authentication information for each authenticated interface, which may be a static channel (or static aggregator) or a dynamic (or LACP) channel group or a switch port, available on the switch.

Syntax `show auth-web [all]`

Parameter	Description
all	Show all authentication information for each authenticated interface on the switch.

Mode Exec and Privileged Exec

Example See the below example showing all Web authentication information:

```
awplus# show auth-web all
```

```
802.1X Port-Based Authentication Disabled
MAC-based Port Authentication Disabled
WEB-based Port Authentication Enabled
```

Related Commands `show dot1x`
`show auth-mac`

show auth-web diagnostics

This command shows Web authentication diagnostics, optionally for the specified interface, which may be a static channel (or static aggregator) or a dynamic (or LACP) channel group or a switch port.

If no interface is specified then authentication diagnostics are shown for all interfaces.

Syntax `show auth-web diagnostics [interface <interface-list>]`

Parameter	Description
interface	Specify ports to show
<interface-list>	The interfaces or ports to configure. An interface-list can be: ■ an interface, a switch port, or a channel group (e.g., vlan2, port1.1.12, sa3, or po4) ■ a continuous range of interfaces, ports, or channel groups separated by a hyphen, e.g. vlan2-vlan8 or port1.1.1-port1.1.24 or sa2-4, po1-3 ■ a comma-separated list of the above, e.g., port1.0.1,port1.1.1-1.2.24. Do not mix interface types in a list. The specified interfaces must exist.

Mode Exec and Privileged Exec

Example See the sample output below showing authentication diagnostics for port1.0.12:

```
awplus# show auth-web diagnostics interface port1.0.12
```

```
Authentication Diagnostics for interface port1.0.12
  Supplicant address: 00d0.59ab.7037
    authEnterConnecting: 2
    authEaplogoffWhileConnecting: 1
    authEnterAuthenticating: 2
    authSuccessWhileAuthenticating: 1
    authTimeoutWhileAuthenticating: 1
    authFailWhileAuthenticating: 0
    authEapstartWhileAuthenticating: 0
    authEaploggogWhileAuthenticating: 0
    authReauthsWhileAuthenticated: 0
    authEapstartWhileAuthenticated: 0
    authEaplogoffWhileAuthenticated: 0
    BackendResponses: 2
    BackendAccessChallenges: 1
    BackendOtherrequestToSupplicant: 3
    BackendAuthSuccess: 1
```

Related Commands [show dot1x interface](#)

show auth-web interface

This command shows the status for Web based authentication on the specified interface, which may be a static channel (or static aggregator) or a dynamic (or LACP) channel group or a switch port.

Use the optional diagnostics parameter to show authentication diagnostics for the specified interface. Use the optional sessionstatistics parameter to show authentication session statistics for the specified interface. Use the optional statistics parameter to show authentication diagnostics for the specified interface. Use the optional supplicant parameter to show the supplicant state for the specified interface.

Syntax `show auth-web interface <interface-list>
[diagnostics|sessionstatistics|statistics|supplicant [brief]]`

Parameter	Description
<interface-list>	The interfaces or ports to configure. An interface-list can be: ■ an interface, a switch port, or a channel group (e.g., vlan2, port1.1.12, sa3, or po4) ■ a continuous range of interfaces, ports, or channel groups separated by a hyphen, e.g. vlan2-vlan8 or port1.1.1-port1.1.24 or sa2-4, po1-3 ■ a comma-separated list of the above, e.g., port1.0.1,port1.1.1-1.2.24. Do not mix interface types in a list. The specified interfaces must exist.
diagnostics	Diagnostics
sessionstatistics	Session statistics
statistics	Statistics
supplicant	Supplicant
brief	Brief summary of supplicant state

Mode Exec and Privileged Exec

Example See the sample output below showing the Web based authentication status for port1.0.12:

```
awplus# show auth-web interface port1.0.2
```

```
% Port-Control not configured on port1.0.2
```

See the sample output below showing Web authentication diagnostics for port 1.0.12:

```
awplusshow auth-web interface port1.0.12 diagnostics
Authentication Diagnostics for interface port1.0.12
  Supplicant address: 00d0.59ab.7037
    authEnterConnecting: 2
    authEaplogoffWhileConnecting: 1
    authEnterAuthenticating: 2
    authSuccessWhileAuthenticating: 1
    authTimeoutWhileAuthenticating: 1
    authFailWhileAuthenticating: 0
    authEapstartWhileAuthenticating: 0
    authEaplogoggWhileAuthenticating: 0
    authReauthsWhileAuthenticated: 0
    authEapstartWhileAuthenticated: 0
    authEaplogoffWhileAuthenticated: 0
    BackendResponses: 2
    BackendAccessChallenges: 1
    BackendOtherrequestToSupplicant: 3
    BackendAuthSuccess: 1
```

See the sample output below showing Web authentication session statistics for port1.0.12:

```
awplus# show auth-web interface port1.0.12 sessionstatistics
```

```
Authentication session statistics for interface port1.0.12
  session user name: manager
    session authentication method: Remote server
    session time: 19440 secs
    session terminat cause: Not terminated yet
```

To view Web authentication statistics for port 1.0.12 issue the command:

```
awplus# show auth-web statistics interface port1.0.12
```

To show the Web authenticated supplicant on interface port1.0.12 issue the command:

```
awplus# show auth-web interface port1.0.12 supplicant
```

Related Commands

- [show auth-web diagnostics](#)
- [show dot1x sessionstatistics](#)
- [show dot1x statistics interface](#)
- [show dot1x supplicant interface](#)

show auth-web sessionstatistics

This command shows authentication session statistics for the specified interface, which may be a static channel (or static aggregator) or a dynamic (or LACP) channel group or a switch port.

Syntax `show auth-web sessionstatistics [interface <interface-list>]`

Parameter	Description
interface	Specify ports to show
<interface-list>	The interfaces or ports to configure. An interface-list can be: ■ an interface, a switch port, or a channel group (e.g., vlan2, port1.1.12, sa3, or po4) ■ a continuous range of interfaces, ports, or channel groups separated by a hyphen, e.g. vlan2-vlan8 or port1.1.1-port1.1.24 or sa2-4, po1-3 ■ a comma-separated list of the above, e.g., port1.0.1,port1.1.1-1.2.24. Do not mix interface types in a list. The specified interfaces must exist.

Mode Exec and Privileged Exec

Example See the sample output below showing Web authentication session statistics for port 1.0.12:

```
awplus# show auth-web sessionstatistics interface port1.0.12
```

```
Authentication session statistics for interface port1.0.12
session user name: manager
session authentication method: Remote server
session time: 19440 secs
session terminat cause: Not terminated yet
```

show auth-web statistics interface

This command shows the authentication statistics for the specified interface, which may be a static channel (or static aggregator) or a dynamic (or LACP) channel group or a switch port.

Syntax `show auth-web statistics interface <interface-list>`

Parameter	Description
<code><interface-list></code>	The interfaces or ports to configure. An interface-list can be: ■ an interface, a switch port, or a channel group (e.g., vlan2, port1.1.12, sa3, or po4) ■ a continuous range of interfaces, ports, or channel groups separated by a hyphen, e.g. vlan2-vlan8 or port1.1.1-port1.1.24 or sa2-4, po1-3 ■ a comma-separated list of the above, e.g., port1.0.1,port1.1.1-1.2.24. Do not mix interface types in a list. The specified interfaces must exist.

Mode Exec and Privileged Exec

Example To show Web authentication statistics for port1.0.12 issue the command:

```
awplus# show dot1x statistics interface port1.0.12
```

Related Commands [show dot1x interface](#)

show auth-web supplicant

This command shows the supplicant state when Web authentication is configured for the switch. This command shows a summary when the optional `brief` parameter is used.

Syntax `show auth-web supplicant [<macadd>] [brief]`

Parameter	Description
<macadd>	Mac (hardware) address of the Supplicant Entry format is HHHH.HHHH.HHHH (hexadecimal)
brief	Brief summary of the Supplicant state

Mode Exec and Privileged Exec

Example To show Web authenticated supplicant information on the switch issue the command:

```
awplus# show auth-web supplicant
```

To show brief summary output for the Web authenticated supplicant on the switch issue the command:

```
awplus# show auth-web supplicant brief
```

show auth-web supplicant interface

This command shows the supplicant state for the Web authenticated interface, which may be a static channel (or static aggregator) or a dynamic (or LACP) channel group or a switch port. This command shows a summary when the optional brief parameter is used.

Syntax `show auth-web supplicant interface <interface-list> [brief]`

Parameter	Description
<interface-list>	The interfaces or ports to configure. An interface-list can be: ■ an interface, a switch port, or a channel group (e.g., vlan2, port1.1.12, sa3, or po4) ■ a continuous range of interfaces, ports, or channel groups separated by a hyphen, e.g. vlan2-vlan8 or port1.1.1-port1.1.24 or sa2-4, po1-3 ■ a comma-separated list of the above, e.g., port1.0.1,port1.1.1-1.2.24. Do not mix interface types in a list. The specified interfaces must exist.
brief	Brief summary of the Supplicant state

Mode Exec and Privileged Exec

Example To show the Web authenticated supplicant on the interface `port1.0.12` issue the command:

```
awplus# show auth-web supplicant interface port1.0.12
```

To show brief summary output for the Web authenticated supplicant the command:

```
awplus# show auth-web supplicant brief
```

show auth-web-server

This command shows the web authentication server configuration and status on the switch.

Syntax show auth-web-server

Mode Exec and Privileged Exec

Example See the sample output below showing web authentication server status using this command:

```
awplus# show auth-web-server
```

```
Web authentication server
  Server status: enabled
  Server address: -
  HTTP Port No: 80
  Security: enabled
  Certification: default
  SSL Port No: 443
  Redirect URL:
  HTTP Redirect: disabled
  Session keep: disabled
  PingPolling: disable
  PingInterval: 30
  Timeout: 1
  FailCount: 5
  ReauthFresh: disabled
```

Related Commands [auth-web-server http-redirect](#)
 [auth-web-server ipaddress](#)
 [auth-web-server port](#)
 [auth-web-server redirect-url](#)
 [auth-web-server session-keep](#)
 [auth-web-server ssl](#)
 [auth-web-server sslport](#)

Chapter 58: AAA Introduction and Configuration



AAA Introduction.....	58.2
Available functions and server types	58.2
Server Groups and Method Lists	58.2
Configuring AAA Login Authentication.....	58.4
AAA Configuration Tasks.....	58.4

AAA Introduction

AAA is the collective title for the three related functions of Authentication, Authorization and Accounting. These function can be applied in a variety of methods with a variety of servers. The purpose of the AAA commands is to map instances of the AAA functions to sets of servers.

The Authentication function can be performed in multiple contexts, such as authentication of users logging in at a console, or 802.1x authentication of devices connecting to Ethernet ports.

For each of these contexts, you may want to use different sets of servers for examining the proffered authentication credentials and deciding if they are valid. AAA Authentication commands enable you to specify which servers will be used for different types of authentication.

Available functions and server types

Authentication and Accounting functions are available.

Authentication is performed in the following contexts:

- Login authentication of user shell sessions on the console port, and via telnet/SSH
- 802.1x authentication of devices connecting to switch ports
- MAC authentication of devices connecting to switch ports
- Web-based authentication of devices connecting to switch ports

Accounting is performed in the following contexts

- Accounting of console login sessions
- Accounting of 802.1x-authenticated connections
- Accounting of MAC-authenticated connections
- Accounting of Web-authenticated connections

There are two types of servers that can be used:

- Local user database
- RADIUS servers

Server Groups and Method Lists

There are two constructs that underlie the structure of the AAA commands:

- Server groups are lists of RADIUS servers
- Method Lists are lists of server types

A server group is defined by the command `aaa group server`. This command puts you into Server Group configuration mode. Once in that mode you can add servers to the group by using the command `server auth-port`.

Any number of servers can be added to a group. Typically, you will add servers which have already been configured by the command `radius-server host`. If you add a server that has not yet been configured by the command `radius-server host`, you will receive a warning that the server has not yet been configured, but the command will be accepted.

There is one server group that is always present on the switch by default that cannot be removed. It is the group simply named radius that comprises all servers that have been configured using the command `radius-server host`. As soon as a server is configured by the command `radius-server host`, it is automatically a member of the server group radius and cannot be removed from it.

A method list defines the set of server types that you want to be used for authenticating a user/device, and the order in which you want the server types to be used.

- You may want the usernames proffered for logging in at the console to be checked for in the user database first then checked for on a group of RADIUS servers if not found in the user database. You can create a server list that specifies local followed by group.
- You may want to check the RADIUS servers first, and resort to the local user database if none of the RADIUS servers respond. You can create a server list that specifies group first, followed by local.

A method list defines the servers where authentication requests are sent. The first server listed is used to authenticate users; if that server fails then the next authentication server type in the method list is selected. This process continues until there is a successful authentication or until all server types fail.

Default Method Lists

For every authentication or accounting type, it is always possible to define a method list called default. For most of the authentication and accounting types, the only method list that can be defined is default.

As soon as the default method list is defined for a given authentication or accounting type, it is automatically applied as the method list to be used for any instance of that type of authentication or accounting, except for instances to which another named method list has been specifically applied.

Configuring AAA Login Authentication

To configure AAA authentication, create default or a named method list for different authentication types. In the case of login authentication, the named method lists are then applied to consoles or VTY lines.

AAA Configuration Tasks

There are three steps to define how a given accounting or authentication type will be applied to a given port or line:

- Create a server group using the `aaa group server radius` command
- Create a method list for the authentication or accounting type as required
- Apply that method list to the port or line as required

Step 1: Define a group of RADIUS Servers:

- Create a server group using the `aaa group server radius` command:

To create a RADIUS server group named `GROUP1` with hosts `192.168.1.1`, `192.168.2.1` and `192.168.3.1`, use the commands:

```
awplus(config)# aaa group server radius GROUP1

awplus(config-sg)# server 192.168.1.1 auth-port 1812 acct-
port 1813

awplus(config-sg)# server 192.168.2.1 auth-port 1812 acct-
port 1813

awplus(config-sg)# server 192.168.3.1 auth-port 1812 acct-
port 1813
```

Step 2: Specify the login authentication Method List :

- Create a method list for the authentication or accounting type as required:

To configure a user login authentication method list called `USERS` to use first the local user database and then the RADIUS server group `GROUP1` for user login authentication, use the following commands:

```
awplus# configure terminal

awplus(config)# aaa authentication login USERS local group
GROUP1
```

Step 3: Apply Method List to Interface Port or Line:

- Apply that method list to the port or line as required:

```
awplus# configure terminal

awplus(config)# line console 0

awplus(config-line)# login authentication USERS
```

For most Authentication and Accounting types, the only possible server list is default, and the only server that can be put into it is radius. You will typically use all RADIUS servers, so the group radius can be used, rather than having to create a specific user group. Often the configuration of a given Authentication or Accounting type will consist of a single command, the command that defines the default server list, which contains just one server.

AAA 802.1x Authentication Configuration:

- AAA 802.1x authentication will typically be configured with the following commands:

To enable 802.1x Authentication globally for all RADIUS servers, use the following commands:

```
awplus# configure terminal
```

```
awplus(config)# aaa authentication dot1x default group radius
```


Chapter 59: AAA Commands



Command List	59.2
aaa accounting auth-mac default	59.2
aaa accounting auth-web default	59.4
aaa accounting dot1x	59.6
aaa accounting login	59.8
aaa accounting update	59.10
aaa authentication auth-mac	59.11
aaa authentication auth-web	59.13
aaa authentication dot1x	59.14
aaa authentication login	59.16
aaa group server	59.18
accounting login	59.19
clear aaa local user lockout	59.20
debug aaa	59.21
login authentication	59.22
show debugging aaa	59.23

Command List

This chapter provides an alphabetical reference for AAA commands for Authentication, Authorization and Accounting. For more information, see [Chapter 58, AAA Introduction and Configuration](#).

aaa accounting auth-mac default

This command configures a default accounting method list for MAC-based Authentication. The default accounting method list specifies what type of accounting messages are sent and specifies which RADIUS Servers the accounting messages are sent to. The default accounting method list is automatically applied to interfaces with MAC-based Authentication enabled.

There are two ways to define servers where RADIUS accounting messages will be sent:

- **group radius** : use all RADIUS servers configured by **radius-server host** command
- **group <group-name>** : use the specified RADIUS server group

Configure the <group-name> using the **aaa group server** command. Configure the RADIUS server for group radius using the **radius-server host** command.

The accounting event to send to the RADIUS server is configured with the following options:

- **start-stop** : sends a start accounting message at the beginning of a session and a stop accounting message at the end of the session.
- **stop-only** : sends a stop accounting message at the end of a session.
- **none** : disables accounting.

Use the **no aaa accounting auth-mac** command to disable AAA accounting for MAC-based Authentication globally.

Syntax

```
aaa accounting auth-mac default {start-stop|stop-only|none} group
    {<group-name>|radius}

no aaa accounting auth-mac default
```

Parameter	Description
auth-mac	Set accounting method list for auth-mac
default	Default accounting method list
start-stop	Start and stop records to be sent
stop-only	Stop records to be sent
none	No accounting record to be sent
group	Use a server group
radius	Use all RADIUS servers
<group-name>	Server group name

Default RADIUS accounting for MAC-based Authentication is disabled by default

Mode Global Configuration

Examples To enable RADIUS accounting for MAC-based Authentication, and use all available RADIUS Servers, use the commands:

```
awplus# configure terminal
awplus(config)# aaa accounting auth-mac default start-stop
group radius
```

To disable RADIUS accounting for MAC-based Authentication, use the commands:

```
awplus# configure terminal
awplus(config)# no aaa accounting auth-mac default
```

Related Commands [aaa authentication auth-mac](#)

aaa accounting auth-web default

This command configures a default accounting method list for Web-based Port Authentication. The default accounting method list specifies what type of accounting messages are sent and specifies which RADIUS Servers the accounting messages are sent to. The default accounting method list is automatically applied to interfaces with Web-based Authentication enabled.

There are two ways to define servers where RADIUS accounting messages will be sent:

- **group radius** : use all RADIUS servers configured by radius-server host command
- **group <group-name>** : use the specified RADIUS server group

Configure the <group-name> using the **aaa group server** command. Configure the RADIUS server for group radius using the **radius-server host** command.

Configure the accounting event to be sent to the RADIUS server with the following options:

- **start-stop** : sends a start accounting message at the beginning of a session and a stop accounting message at the end of the session.
- **stop-only** : sends a stop accounting message at the end of a session.
- **none** : disables accounting.

Use the **no aaa accounting auth-web** command to disable AAA accounting for Web-based Port Authentication globally.

Syntax

```
aaa accounting auth-web default {start-stop|stop-only|none}
    group {<group-name>|radius}

no aaa accounting auth-web default
```

Parameter	Description
no	Negate a command or set its defaults
aaa	Authentication, Authorization and Accounting
accounting	Configure accounting parameters
auth-web	Set accounting method list for auth-web
default	Default accounting method list
start-stop	Start and stop records to be sent
stop-only	Stop records to be sent
none	No accounting record to be sent
group	Use a server group
radius	Use all RADIUS servers
<group-name>	Server group name

Default RADIUS accounting for WEB-based Port Authentication is disabled by default.

Mode Global Configuration

Examples To enable RADIUS accounting for Web-based Authentication, and use all available RADIUS Servers, use the commands:

```
awplus# configure terminal
awplus(config)# aaa accounting auth-web default start-
stop group radius
```

To disable RADIUS accounting for Web-based Authentication, use the commands:

```
awplus# configure terminal
awplus(config)# no aaa accounting auth-web default
```

Related Commands [aaa authentication auth-web](#)

aaa accounting dot1x

This command configures the default accounting method list for IEEE 802.1x-based Authentication. The default accounting method list specifies what type of accounting messages are sent and specifies which RADIUS Servers the accounting messages are sent to. The default accounting method list is automatically applied to interfaces with IEEE 802.1x-based Authentication enabled.

There are two ways to define servers where RADIUS accounting messages will be sent:

- **group radius** : use all RADIUS servers configured by radius-server host command
- **group <group-name>** : use the specified RADIUS server group

Configure the *group-name* using the **aaa group server** command. Configure the RADIUS server for group radius using the **radius-server host** command.

The accounting event to send to the RADIUS server is configured by the following options:

- **start-stop** : sends a start accounting message at the beginning of a session and a stop accounting message at the end of the session.
- **stop-only** : sends a stop accounting message at the end of a session.
- **none** : disables accounting.

Use the **no aaa accounting dot1x** command to disable AAA accounting for 802.1x-based Port Authentication globally.

Syntax

```
aaa accounting dot1x default {start-stop|stop-only|none}
    group {<group-name>|radius}

no aaa accounting dot1x default
```

Parameter	Description
no	Negate a command or set its defaults
aaa	Authentication, Authorization and Accounting
accounting	Configure accounting parameters
dot1x	Set accounting method list for 802.1X
default	Default accounting method list
start-stop	Start and stop records to be sent
stop-only	Stop records to be sent
none	No accounting record to be sent
group	Use a server group
radius	Use all RADIUS servers
<group-name>	Server group name

Default RADIUS accounting for 802.1X-based Port Authentication is disabled by default. (There is no default server set by default).

Mode Global Configuration

Usage Use this command to enable accounting on all switch ports with 802.1X enabled, and to specify which accounting messages to send and the ordered list of servers to use for accounting. Use the no version of this command to remove the default accounting server for 802.1X. This disables 802.1X accounting.

Examples To enable RADIUS accounting for 802.1x-based Authentication, and use all available RADIUS Servers, use the commands:

```
awplus# configure terminal
awplus(config)# aaa accounting dot1x default start-stop group
radius
```

To disable RADIUS accounting for 802.1x-based Authentication, use the commands:

```
awplus# configure terminal
awplus(config)# no aaa accounting dot1x default
```

Related Commands [aaa accounting update](#)
[aaa authentication dot1x](#)
[aaa group server](#)
[dot1x port-control](#)
[radius-server host](#)

aaa accounting login

This command configures RADIUS accounting for login shell sessions. The specified method list name can be used by the accounting login command in the Line Configuration mode. If the default parameter is specified, then this creates a default method list that is applied to every console and vty line, unless another accounting method list is applied on that line.

Use the `no aaa accounting login` command to remove an accounting method list for login shell sessions configured by an `aaa accounting login` command. If the method list being deleted is already applied to a console or vty line, accounting on that line will be disabled. If the default method list name is removed by this command, it will disable accounting on every line that has the default accounting configuration.

Syntax

```
aaa accounting login {default|<list-name>}
                    {start-stop|stop-only|none} {group {radius|<group-name>}}
```

```
no aaa accounting login {default|<list-name>}
```

Parameter	Description
no	Negate a command or set its defaults
aaa	Authentication, Authorization and Accounting
accounting	Configure accounting parameters
login	Set authentication method list for login session
default	Default accounting method list
<list-name>	Named accounting method list
start-stop	Start and stop records to be sent
stop-only	Stop records to be sent
none	No accounting record to be sent
group	Use server group
radius	Use all RADIUS servers
<group-name>	Server group name

Usage This command enables you to define a named accounting method list. The items that you define in the accounting options are:

- the types of accounting packets that will be sent
- the set of servers to which the accounting packets will be sent

You can define a default method list the name `default`) and any number of other named method list. The `<list-name>` for any method list that you define can then be used as the `<list-name>` parameter in the `accounting login` command available from Line Configuration mode.

If the method list name already exists, the command will replace the existing configuration with the new one.

There are two ways to define servers where RADIUS accounting messages will be sent:

- `group radius` : use all RADIUS servers configured by `radius-server host` command
- `group group-name` : use the specified RADIUS server group

Configure the *group-name* using the `aaa group server` command. Configure the RADIUS server for `group radius` using the `radius-server host` command.

The accounting event to send to the RADIUS server is configured with the following options:

- `start-stop` : sends a start accounting message at the beginning of a session and a stop accounting message at the end of the session.
- `stop-only` : sends a stop accounting message at the end of a session.
- `none` : disables accounting.

Default RADIUS accounting is disabled by default for all login shell sessions.

Mode Global Configuration

Examples To configure RADIUS accounting for login shell sessions, use the following commands:

```
awplus# configure terminal
awplus(config)# aaa accounting login default start-stop group
radius
```

To reset the configuration of the default accounting list, use the following commands:

```
awplus# configure terminal
awplus(config)# no aaa accounting login default
```

Related Commands `aaa authentication login`
`aaa accounting login`
`accounting login`

aaa accounting update

This command enables periodic accounting reporting to the RADIUS accounting server(s) wherever RADIUS accounting has been configured.

When periodic accounting report is enabled, interim accounting records are sent periodically according to the specified interval in the **periodic** parameter. The default interval is 30 minutes.

Use the **no aaa accounting update** command to disable periodic accounting reporting to the RADIUS accounting server(s).

Syntax `aaa accounting update [periodic <1-65535>]`
`no aaa accounting update`

Parameter	Description
no	Negate a command or set its defaults
aaa	Authentication, Authorization and Accounting
accounting	Configure accounting parameters
update	Configure interim accounting update
periodic	Send accounting records periodically
<1-65535>	Intervals to send accounting update (in minutes)

Default Periodic accounting update is disabled by default.

Mode Global Configuration

Usage Use this command to enable the device to send periodic AAA accounting reports to the accounting server. When periodic accounting updates are enabled, interim accounting records are sent periodically at the specified intervals. Use the **no** version of this command to disable periodic accounting updates to the accounting server.

Examples To configure the switch to send period accounting updates every 10 minutes, use the following commands:

```
awplus# configure terminal
awplus(config)# aaa accounting update periodic 10
```

To disable periodic accounting update wherever RADIUS accounting has been configured, use the following commands:

```
awplus# configure terminal
awplus(config)# no aaa accounting update
```

Related Commands [aaa accounting auth-mac default](#)
 [aaa accounting auth-web default](#)
 [aaa accounting dot1x](#)

aaa authentication auth-mac

This command enables MAC-based Port Authentication globally and allows you to specify an authentication method list. It is automatically applied to every interface running MAC-based Port Authentication.

There are two ways to define servers where RADIUS authentication messages will be sent:

- **group radius** : use all RADIUS servers configured by `radius-server host` command
- **group group-name** : use the specified RADIUS server group

Configure the *group-name* using the `aaa group server` command. Configure the RADIUS server for **group radius** using the `radius-server host` command.

Use the **no aaa authentication auth-mac** command to globally disable MAC-based Port Authentication.

Syntax `aaa authentication auth-mac default group {<group-name>|radius}`
`no aaa authentication auth-mac default`

Parameter	Description
no	Negate a command or set its defaults
aaa	Authentication, Authorization and Accounting
authentication	Configure Authentication parameters
auth-mac	Set authentication method list for auth-mac
default	Default authentication method list
group	Use server group
radius	Use all RADIUS servers
<group-name>	Server group name

Default MAC-based Port Authentication is disabled by default.

Usage A RADIUS Server is configured using the `radius-server host` command. All configured RADIUS Servers are automatically members of the server group radius.

Other named server groups are configured using the `aaa group server` command. If a server is added to a named group, it also remains a member of the group radius.

Mode Global Configuration

Examples To enable MAC-based Port Authentication globally for all RADIUS servers, and use all available RADIUS servers, use the commands:

```
awplus# configure terminal
awplus(config)# aaa authentication auth-mac default group
radius
```

To disable MAC-based Port Authentication, use the commands:

```
awplus# configure terminal
```

```
awplus(config)# no aaa authentication auth-mac default
```

Related Commands [aaa accounting auth-mac default](#)
[auth-mac enable](#)

aaa authentication auth-web

This command enables Web-based Port Authentication globally and allows you to enable an authentication method list (in this case, a list of RADIUS Servers). It is automatically applied to every interface running Web-based Port Authentication.

There are two ways to define servers where RADIUS authentication messages will be sent:

- `group radius` : use all RADIUS servers configured by `radius-server host` command
- `group group-name` : use the specified RADIUS server group

Configure the `group-name` using the `aaa group server` command. Configure the RADIUS server for group radius using the `radius-server host` command.

Use the `no aaa authentication auth-web` command to globally disable Web-based Port Authentication.

Syntax `aaa authentication auth-web default group {<group-name>|radius}`
`no aaa authentication auth-web default`

Parameter	Description
<code>no</code>	Negate a command or set its defaults
<code>aaa</code>	Authentication, Authorization and Accounting
<code>authentication</code>	Configure Authentication parameters
<code>auth-web</code>	Define the authentication method list for auth-web
<code>default</code>	Default authentication method list
<code>group</code>	Use server group
<code>radius</code>	Use all RADIUS servers
<code><group-name></code>	Server group name

Default Web-based Port Authentication is disabled by default.

Mode Global Configuration

Examples To enable Web-based Port Authentication globally for all RADIUS servers, and use all available RADIUS servers, use the commands:

```
awplus# configure terminal
awplus(config)# aaa authentication auth-web default group
radius
```

To disable Web-based Port Authentication, use the commands:

```
awplus# configure terminal
awplus(config)# no aaa authentication auth-web default
```

Related Commands `aaa accounting auth-web default`

auth-mac enable

aaa authentication dot1x

This command enables 802.1X-based Port Authentication globally and allows you to enable an authentication method list. It is automatically applied to every interface running 802.1X-based Port Authentication.

There are two ways to define servers where RADIUS authentication messages will be sent:

- **group radius** : use all RADIUS servers configured by radius-server host command
- **group group-name** : use the specified RADIUS server group

Configure the *group-name* using the [aaa group server](#) command. Configure the RADIUS server for group radius using the [radius-server host](#) command.

Use the no aaa authentication dot1x command to globally disable 802.1X-based Port Authentication.

Syntax `aaa authentication dot1x default group {<group-name>|radius}`
`no aaa authentication dot1x default`

Parameter	Description
no	Negate a command or set its defaults
aaa	Authentication, Authorization and Accounting
authentication	Configure Authentication parameters
dot1x	Set authentication method list for 802.1X
default	Default authentication method list
group	Use server group
radius	Use all RADIUS servers
<group-name>	Server group name

Default 802.1X-based Port Authentication is disabled by default.

Mode Global Configuration

Usage Use this command to specify the default method list to use for authentication on all switch ports with 802.1X enabled. Use the no version of this command to reset the default authentication method list for 802.1X, to its default, that is, to use the group radius, containing all RADIUS servers configured by the radius-server host command.

Examples To enable 802.1X-based Port Authentication globally with all RADIUS servers, and use all available RADIUS servers, use the command:

```
awplus# configure terminal
awplus(config)# aaa authentication dot1x default group radius
```

To disable 802.1X-based Port Authentication, use the command:

```
awplus# configure terminal
```

```
awplus(config)# no aaa authentication dot1x default
```

Related Commands aaa accounting dot1x
 aaa group server
 dot1x port-control
 radius-server host

aaa authentication login

Use this command to create an ordered list of methods to use to authenticate user login, or to replace an existing method list with the same name. Specify one or more of the options local or group, in the order you want them to be applied. If the default method list name is specified, it is applied to every console and VTY line immediately unless another method list is applied to that line by the [login authentication](#) command. To apply a non-default method list, you must also use the login authentication command.

Use the no version of this command to remove an authentication method list for user login. The specified method list name is deleted from the configuration. If the method list name has been applied to any console or VTY line, user login authentication on that line will fail.

Note that the no aaa authentication login default command does not remove the default method list. This will return the default method list to its default state (local is the default).

Syntax

```
aaa authentication login {default|<list-name>} [local]
    [group {radius|<group-name>}]

no aaa authentication login {default|<list-name>}
```

Parameter	Description
default	Set the default authentication server for user login
<list-name>	Name of authentication server
local	Use the local username database
group radius	Use all RADIUS servers configured by the radius-server host command on page 60.6.
group <group-name>	Use the specified RADIUS server group, as configured by the aaa group server command.

Default If the default server is not configured using this command, user login authentication uses the local user database only. If the default method list name is specified, it is applied to every console and VTY line immediately unless method list server is applied to that line by the login authentication command.

local is the default state for the default method list. Reset to the default method list using the no aaa authentication login default command.

Mode Global Configuration

Examples To configure the default authentication method list for user login to use all available RADIUS servers and then the local user database, use the following commands:

```
awplus# configure terminal

awplus(config)# aaa authentication login default group radius
local
```


To configure a user login authentication method list called `USERS` to use first the local user database and then the RADIUS server group `RAD_GROUP1` for user login authentication, use the following commands:

```
awplus# configure terminal
awplus(config)# aaa authentication login USERS local group
RAD_GROUP1
```

To return to the default method list (local is the default server), use the following commands:

```
awplus# configure terminal
awplus(config)# no aaa authentication login default
```

To delete an existing authentication method list `USERS` created for user login authentication, use the following commands:

```
awplus# configure terminal
awplus(config)# no aaa authentication login USERS
```

Related Commands [login authentication](#)

aaa group server

This command configures a RADIUS server group. A server group can be used to specify a subset of RADIUS servers in aaa commands. The group name radius is predefined, which includes all RADIUS servers configured by the radius-server host command.

RADIUS servers are added to a server group using the server command. Each RADIUS server should be configured using the radius-server host command. Use the no aaa group command to remove an existing RADIUS server group.

Syntax `aaa group server radius <group-name>`
`no aaa group server`

Parameter	Description
no	Negate a command or set its defaults
aaa	Authentication, Authorization and Accounting
group	Configure AAA group
server	Configure AAA server group
radius	Configure RADIUS server group
<group-name>	Server-group name

Mode Global Configuration

Usage Use this command to create an AAA group of RADIUS servers, and to enter Server Group Configuration mode, in which you can add servers to the group. Use a server group to specify a subset of RADIUS servers in AAA commands. Each RADIUS server must be configured by the radius-server host command. To add RADIUS servers to a server group, use the server command.

Example s To create a RADIUS server group named GROUP1 with hosts 192.168.1.1, 192.168.2.1 and 192.168.3.1, use the commands:

```
awplus(config)# aaa group server radius GROUP1
awplus(config-sg)# server 192.168.1.1 auth-port 1812 acct-
port 1813
awplus(config-sg)# server 192.168.2.1 auth-port 1812 acct-
port 1813
awplus(config-sg)# server 192.168.3.1 auth-port 1812 acct-
port 1813
```

To remove a RADIUS server group named GROUP1 from the configuration, use the command:

```
awplus(config)# no aaa group server radius GROUP1
```

Related Commands [aaa accounting auth-mac default](#)
[aaa accounting auth-web default](#)

```
aaa accounting dot1x
aaa accounting login
aaa authentication auth-mac
aaa authentication auth-web
aaa authentication dot1x
aaa authentication login
radius-server host
server (Server Group)
```

accounting login

This command applies a login accounting method list to console or vty lines for user login. When login accounting is enabled using the `aaa accounting login` command, logging events generate an accounting record to the accounting server configured using `aaa accounting login`.

The accounting method list must be configured first using the `aaa accounting login` command. If an accounting method list is specified that has not been created by the `aaa accounting login` command then accounting will be disabled on the specified lines.

The `no accounting login` command resets AAA (Authentication, Authorization, Accounting) Accounting applied to console or vty lines for local or remote login. default login accounting is applied after issuing the `no accounting login` command. Accounting is disabled with default.

Syntax `accounting login {default|<list-name>}`
`no accounting login`

Parameter	Description
<code>no</code>	Negate a command or set its defaults
<code>accounting</code>	Configure accounting parameters
<code>login</code>	Set accounting method list for login session
<code>default</code>	Default accounting method list
<code><list-name></code>	Named accounting method list

Default By default login accounting is disabled in the default accounting server. No accounting will be performed until accounting is enabled using the `aaa accounting login` command beforehand.

Mode Line Configuration

Examples To apply the accounting server `USERS` to all vty lines use the following commands:

```
awplus# configure terminal
awplus(config)# line vty 0 32
awplus(config-line)# accounting login USERS
```

To reset accounting for login sessions on the console, use the following commands:

```
awplus# configure terminal
awplus(config)# line console 0
awplus(config-line)# no accounting login
```

Related Commands [aaa accounting login](#)

clear aaa local user lockout

Use this command to clear the lockout on a specific user account or all user accounts.

Syntax `clear aaa local user lockout {username <username>|all}`

Parameter	Description
username	clear lockout for the specified user
<username>	specifies the user account
all	clear lockout for all user accounts

Mode Privileged Exec

Examples To unlock the user account 'bob' use the following command:

```
awplus# clear aaa local user lockout username bob
```

To unlock all user accounts use the following command:

```
awplus# clear aaa local user lockout all
```

debug aaa

This command enables AAA debugging.

- If authentication is specified with debug aaa, debugging for AAA authentication is enabled.
- If accounting is specified with debug aaa, debugging for AAA accounting is enabled.
- If all is specified with debug aaa, all debugging options are enabled.
- If no option is specified with debug aaa, all debugging options are enabled.

Use the no debug aaa command to disable AAA debugging.

- If authentication is specified with no debug aaa, debugging for AAA authentication is disabled.
- If accounting is specified with no debug aaa, debugging for AAA accounting is disabled.
- If all is specified with no debug aaa, all debugging options are disabled.
- If no option is specified with no debug aaa, all debugging options are disabled.

Syntax debug aaa [accounting|all|authentication]
no debug aaa [accounting|all|authentication]

Parameter	Description
no	Negate a command or set its defaults
debug	Debugging functions (see also 'undebug')
aaa	Authentication, Authorization and Accounting
authentication	Authentication
accounting	Accounting
all	Turn on all debugging

Default AAA debugging is disabled by default.

Mode Privileged Exec

Examples To enable authentication debugging for AAA, use the command:

```
awplus# debug aaa authentication
```

To disable authentication debugging for AAA, use the command:

```
awplus# no debug aaa authentication
```

Related Commands show debugging aaa

login authentication

Use this command to apply an AAA server for authenticating user login attempts from a console or remote logins on these console or VTY lines. The authentication method list must be specified by the `aaa authentication login` command. If the method list has not been configured by the `aaa authentication login` command, login authentication will fail on these lines.

Use the `no` version of this command to reset AAA Authentication configuration to use the default method list for login authentication on these console or VTY lines.

Command Syntax `login authentication {default|<list-name>}`
`no login authentication`

Parameter	Description
<code>login</code>	Configure user login
<code>authentication</code>	Set authentication parameters
<code>default</code>	The default authentication method list. If the default method list has not been configured by the aaa authentication login command, the local user database is used for user login authentication.
<code><list-name></code>	Named authentication server

Default The default login authentication method list, as specified by the [aaa authentication login](#) command, is used to authenticate user login. (If this has not been specified, the default is to use the local user database.)

Mode Line Configuration

Examples To apply the authentication method list called `CONSOLE` to the console, use the following commands::

```
awplus# configure terminal
awplus(config)# line console 0
awplus(config-line)# login authentication CONSOLE
```

To reset user authentication configuration on all VTY lines, use the following commands:

```
awplus# configure terminal
awplus(config)# line vty 0 32
awplus(config-line)# no login authentication
```

Related Commands [aaa authentication login](#)
[line](#)

show debugging aaa

This command displays the current debugging status for AAA (Authentication, Authorization, Accounting).

Syntax `show debugging aaa`

Parameter	Description
show	Show running system information
debugging	Debugging functions (see also 'undebug')
aaa	Authentication, Authorization and Accounting

Mode Privileged Exec

Example To display the current debugging status of AAA, use the command:

```
awplus# show debug aaa
```

Output Figure 59-1: Example output from the show debug aaa command

```
AAA debugging status:
  Authentication debugging is on
  Accounting debugging is off
```


Chapter 60: RADIUS Commands



Command List	60.2
deadtime (RADIUS server group)	60.2
debug radius.....	60.3
ip radius source-interface	60.4
radius-server deadtime	60.5
radius-server host	60.6
radius-server key	60.10
radius-server retransmit	60.11
radius-server timeout.....	60.13
server (Server Group).....	60.15
show debugging radius.....	60.17
show radius	60.17
show radius statistics.....	60.20

Command List

This chapter provides an alphabetical reference for commands used to configure the device to use RADIUS servers.

deadtime (RADIUS server group)

Use this command to configure the deadtime parameter for the RADIUS server group. This command overrides the global dead-time configured by the [radius-server deadtime command on page 60.5](#). The configured deadtime is the time period in minutes to skip a RADIUS server for authentication or accounting requests if the server is "dead". Note that a RADIUS server is considered "dead" if there is no response from the server within a defined time period.

Use the no version of this command to reset the deadtime configured for the RADIUS server group. If the global deadtime for RADIUS server is configured the value will be used for the servers in the group. The global deadtime for the RADIUS server is set to 0 minutes by default.

Syntax `deadtime <0-1440>`
`no deadtime`

Parameter	Description
<code>deadtime</code>	Configure dead-time parameter
<code><0-1440></code>	Amount of time in minutes (default: 0)

Default The deadtime is set to 5 minutes by default.

Mode Server Group Configuration

Usage If the RADIUS server does not respond to a request packet, the packet is retransmitted the number of times configured for the `retransmit` parameter (after waiting for a timeout period to expire). The server is then marked "dead", and the time is recorded. The deadtime parameter configures the amount of time to skip a dead server; if a server is dead, no request message is sent to the server for the deadtime period.

Examples To configure the deadtime for 5 minutes for the RADIUS server group "GROUP1", use the command:

```
awplus(config)# aaa group server radius GROUP1
awplus(config-sg)# server 192.168.1.1
awplus(config-sg)# deadtime 5
```

To remove the deadtime configured for the RADIUS server group "GROUP1", use the command:

```
awplus(config)# aaa group server radius GROUP1
awplus(config-sg)# no deadtime
```

Related Commands [aaa group server](#)
[radius-server deadline](#)

debug radius

This command enables RADIUS debugging. If no option is specified, all debugging options are enabled.

Use the no version of this command to disable RADIUS debugging. If no option is specified, all debugging options are disabled.

Syntax `debug radius [packet|event|all]`
`no debug radius [packet|event|all]`

Parameter	Description
no	Negate a command or set its defaults
debug	Debugging functions (see also 'undebug')
radius	RADIUS protocol
packet	Debugging for RADIUS packets is enabled or disabled.
event	Debugging for RADIUS events is enabled or disabled.
all	Enable or disable all debugging options.

Default RADIUS debugging is disabled by default.

Mode Privileged Exec

Example s To enable debugging for RADIUS packets, use the command:

```
awplus# debug radius packet
```

To enable debugging for RADIUS events, use the command:

```
awplus# debug radius event
```

To disable debugging for RADIUS packets, use the command:

```
awplus# no debug radius packet
```

To disable debugging for RADIUS events, use the command:

```
awplus# no debug radius event
```

Related Commands [show debugging radius](#)

ip radius source-interface

This command configures the source IP address of every outgoing RADIUS packet to use a specific IP address or the IP address of a specific interface. If the specified interface is down or there is no IP address on the interface, then the source IP address of outgoing RADIUS packets will depend on the interface the packets leave by.

The no version of this command removes the source interface configuration made by ip radius source-interface command. With no source interface configured the source IP address of outgoing RADIUS packets will depend on the interface the packets leave by.

Syntax `ip radius source-interface {<interface>|<ipaddr>}`
`no ip radius source-interface`

Parameter	Description
source-interface	Set interface for source address in radius packets
<interface>	Interface name
<ipaddr>	IP address in the dotted decimal format A.B.C.D

Default Source IP address of outgoing RADIUS packets depends on the interface the packets leave.

Mode Global Configuration

Usage Use this command to configure the source IP address of every outgoing RADIUS packet to use a specific IP address or the IP address of a specific interface. If the specified interface is down or there is no IP address on the interface, then the source IP address of outgoing RADIUS packets depends on the interface the packets leave. Use the no version of this command to remove the source interface configuration. The source IP address in outgoing RADIUS packets will be the IP address of the interface from which the packets are sent.

Example To configure all outgoing RADIUS packets to use the IP address of the interface "vlan1" for the source IP address, use the following commands:

```
awplus# configure terminal
awplus(config)# ip radius source-interface vlan1
```

To configure the source IP address of all outgoing RADIUS packets to use 192.168.1.10, use the following commands:

```
awplus# configure terminal
awplus(config)# ip radius source-interface
192.168.1.10
```

To reset the source interface configuration for all outgoing RADIUS packets, use the following commands:

```
awplus# configure terminal
awplus(config)# no ip radius source-interface
```

Related Commands [radius-server host](#)
[show radius statistics](#)

radius-server deadtime

Use this command to specify the global deadtime for all RADIUS servers. If a RADIUS server is considered dead, it will be skipped for the specified deadtime. Use the no form of this command to reset the global deadtime to the default value of 0, so that RADIUS servers are not skipped even if they are dead.

This command sets the dead time to use RADIUS authentication on the system. When a server is marked 'dead' the server is not used for the dead time period as specified in minutes with the deadtime parameter from this command. The no radius-server deadtime command sets the dead time counter to default.

Syntax `radius-server deadtime <minutes>`
`no radius-server deadtime`

Parameter	Description
radius-server	RADIUS server configuration commands
deadtime	RADIUS server deadtime commands Time in minutes that a dead RADIUS server is skipped over by transaction requests, up to a maximum of 1440 minutes (24 hours). If 0 is specified, RADIUS servers are not skipped even if they are dead.
<minutes>	RADIUS server deadtime in minutes <0-1440>

Default The default RADIUS deadtime configured on the system is 0 seconds.

Mode Global Configuration

Usage Use this command to specify the number of minutes a RADIUS server, which is not responding to authentication requests, is passed over by requests for RADIUS authentication. Use the no form of this command to set deadtime to the default value of 0.

The RADIUS client considers a RADIUS server to be dead if it fails to respond to a request after it has been retransmitted as often as specified globally by the radius-server retransmit command or for the server by the radius-server host command. To improve RADIUS response times when some servers may be unavailable, set a deadtime to skip dead servers.

Examples To set the dead time of the RADIUS server to 60 minutes, use the following commands:

```
awplus# configure terminal
awplus(config)# radius-server deadtime 60
```

To disable the dead time of the RADIUS server, use the following commands:

```
awplus# configure terminal
awplus(config)# no radius-server deadtime
```

Related Commands [deadtime \(RADIUS server group\)](#)
[radius-server host](#)
[radius-server retransmit](#)
[show radius statistics](#)

radius-server host

Use this command to specify a remote RADIUS server host for authentication or accounting, and to set server-specific parameters. The parameters specified with this command override the corresponding global parameters for RADIUS servers.

This command adds the RADIUS server address and sets parameters to the RADIUS server. The RADIUS server is added to the running configuration after you issue this command. If parameters are not set using this command then common system settings are applied.

This command configures a RADIUS server with server-specific parameters. The specified parameters override the global configurations for RADIUS servers. A RADIUS server is identified by IP address, authentication port and accounting port. Thus a host can be configured multiple times with a different authentication or accounting port.

Use the no version of this command to remove the specified server host as a RADIUS authentication and/or accounting server and set the destination port to the default RADIUS server port number (1812).

Syntax `radius-server host {<host-name>|<ip-address>} [acct-port <0-65535>]
[auth-port <0-65535>] [key <key-string>] [retransmit <0-100>]
[timeout <1-1000>]`

`no radius-server host {<host-name>|<ip-address>}
[acct-port <0-65535>] [auth-port <0-65535>]`

Parameter	Description
no	Negate a command or set its defaults
radius-server	RADIUS server configuration commands
host	Configure RADIUS server host
<host-name>	Server host name. The DNS name of the RADIUS server host.
<ip-address>	The IP address of the RADIUS server host.
acct-port	Accounting port. Specifies the UDP destination port for RADIUS accounting requests. If 0 is specified, the server is not used for accounting. The default UDP port for accounting is 1813.
<0-65535>	UDP port number (Accounting port number is set to 1813 by default) Specifies the UDP destination port for RADIUS accounting requests. If 0 is specified, the host is not used for accounting.
auth-port	Authentication port. Specifies the UDP destination port for RADIUS authentication requests. If 0 is specified, the server is not used for authentication. The default UDP port for authentication is 1812.

Parameter	Description
<0-65535>	UDP port number (Authentication port number is set to 1812 by default) Specifies the UDP destination port for RADIUS authentication requests. If 0 is specified, the host is not used for authentication.
timeout	Specifies the amount of time to wait for a response from the server. If this parameter is not specified the global value configured by the radius-server timeout command is used.
<1-1000>	Time in seconds to wait for a server reply (timeout is set to 5 seconds by default) The time interval (in seconds) to wait for the RADIUS server to reply before retransmitting a request or considering the server dead. This setting overrides the global value set by the radius-server timeout command. If no timeout value is specified for this server, the global value is used.
retransmit	Specifies the number of retries before skip to the next server. If this parameter is not specified the global value configured by the radius-server retransmit command is used.
<0-100>	Maximum number of retries (maximum number of retries is set to 3 by default) The maximum number of times to resend a RADIUS request to the server, if it does not respond within the timeout interval, before considering it dead and skipping to the next RADIUS server. This setting overrides the global setting of the radius-server retransmit command. If no retransmit value is specified, the global value is used.
key	Set shared secret key with RADIUS servers
<key-string>	Shared key string applied Specifies the shared secret authentication or encryption key for all RADIUS communications between this device and the RADIUS server. This key must match the encryption used on the RADIUS daemon. All leading spaces are ignored, but spaces within and at the end of the string are used. If spaces are used in the string, do not enclose the string in quotation marks unless the quotation marks themselves are part of the key. This setting overrides the global setting of the radius-server key command. If no key value is specified, the global value is used.

Default The RADIUS client address is not configured (null) by default. No RADIUS server is configured.

Mode Global Configuration

Usage Multiple RADIUS-server host commands can be used to specify multiple hosts. The software searches for hosts in the order they are specified. If no host-specific timeout, retransmit, or key values are specified, the global values apply to that host. If there are multiple RADIUS servers for this client, use this command multiple times—once to specify each server. If you specify a host without specifying the auth port or the acct port, it will by default be configured for both authentication and accounting, using the default UDP ports. To set a host to be a RADIUS server for authentication requests only, set the acct-port parameter to 0; to set the host to be a RADIUS server for accounting requests only, set the auth-port parameter to 0.

A RADIUS server is identified by IP address, authentication port and accounting port. A single host can be configured multiple times with different authentication or accounting ports. All the RADIUS servers configured with this command are included in the predefined RADIUS server group radius, which may be used by AAA authentication, authorization and accounting commands. The client transmits (and retransmits, according to the retransmit and timeout parameters) RADIUS authentication or accounting requests to the servers in the order you specify them, until it gets a response.

Examples To add the RADIUS server 10.0.0.20, use the following commands:

```
awplus# configure terminal
awplus(config)# radius-server host 10.0.0.20
```

To set the secret key to allied the RADIUS server 10.0.0.20, use the following commands:

```
awplus# configure terminal
awplus(config)# radius-server host 10.0.0.20 key
allied
```

To delete the RADIUS server 10.0.0.20, use the following commands:

```
awplus# configure terminal
awplus(config)# no radius-server host 10.0.0.20
```

To set the RADIUS port number to the default RADIUS server IP address is 10.0.0.20, use the following commands:

```
awplus# configure terminal
awplus(config)# no radius-server host 10.0.0.20
auth-port
```

To configure rad1.company.com for authentication only, use the following commands:

```
awplus# configure terminal
awplus(config)# radius-server host rad1.company.com acct-
port 0
```

To configure rad2.company.com for accounting only, use the following commands:

```
awplus# configure terminal
awplus(config)# radius-server host rad2.company.com auth-
port 0
```


To configure 192.168.1.1 with authentication port 1000, accounting port 1001 and retransmit count 5, use the following commands:

```
awplus# configure terminal
awplus(config)# radius-server host 192.168.1.1 auth-port 1000
                  acct-port 1001 retransmit 5
```

Related Commands

- aaa group server
- radius-server key
- radius-server retransmit
- radius-server timeout
- show radius statistics

radius-server key

This command sets a global secret key to use RADIUS authentication on the switch.

Note that if no secret key is explicitly specified for a RADIUS server, the global secret key will be used for the shared secret for the server.

Use the no radius-server key to reset the secret key to the default value (null).

Syntax radius-server key <key>
no radius-server key

Parameter	Description
radius-server	RADIUS server configuration commands
key	RADIUS server key commands
<key>	Shared secret among radius server and 802.1X client

Default The RADIUS server secret key on the system is not set by default (null).

Mode Global Configuration

Usage Use this command to set the global secret key shared between this client and its RADIUS servers. If no secret key is specified for a particular RADIUS server using the radius-server host command, this global key is used.

Use the no version of this command to clear the global secret key for all RADIUS servers.

Examples To set the global secret key to allied for RADIUS server, use the following commands:

```
awplus# configure terminal
awplus(config)# radius-server key allied
```

To set the global secret key to secret for RADIUS server, use the following commands:

```
awplus# configure terminal
awplus(config)# radius-server key secret
```

To delete the global secret key for RADIUS server, use the following commands:

```
awplus# configure terminal
awplus(config)# no radius-server key
```

Related Commands radius-server host
show radius statistics

radius-server retransmit

This command sets the retransmit counter to use RADIUS authentication on the switch. This command configures the retransmit parameter for RADIUS servers globally. If the retransmit parameter is not specified for a RADIUS server by the radius-server host command then the global configuration set by this command is used for the server instead.

Use the no version of this command to reset the re-transmit counter to default (3).

Syntax radius-server retransmit <retries>

no radius-server retransmit

Parameter	Description
no	Negate a command or set its defaults
radius-server	RADIUS server configuration commands
retransmit	RADIUS server retransmit commands
<retries>	RADIUS server retries in the range <1-100> (set to 3 retries by default) The number of times a request is resent to a RADIUS server that does not respond, before the server is considered dead and the next server is tried. If no retransmit value is specified for a particular RADIUS server using the radius-server host command, this global value is used.

Default The RADIUS retransmit count on the switch is set to 3 by default.

Mode Global Configuration

Usage Use this command to specify the global RADIUS server retransmit count. This is the number of times to retransmit each request to a RADIUS server that does not respond, before considering it dead. Use the no version of this command to reset the retransmit counter to 3.

Examples To set the RADIUS retransmit count to 1, use the following commands:

```
awplus# configure terminal
awplus(config)# radius-server retransmit 1
```

To set the RADIUS retransmit count to the default (3), use the following commands:

```
awplus# configure terminal
awplus(config)# no radius-server retransmit
```

To configure the RADIUS retransmit count globally with 5, use the following commands:

```
awplus# configure terminal
awplus(config)# radius-server retransmit 5
```

To disable retransmission of requests to a RADIUS server, use the following commands:

```
awplus# configure terminal
```

```
awplus(config)# radius-server retransmit 0
```

Related Commands radius-server deadline
 radius-server host
 show radius statistics

radius-server timeout

This command sets the transmit timeout to use RADIUS authentication on the system.

Note that this command configures the timeout parameter for RADIUS servers globally. If the timeout parameter is not explicitly specified for a RADIUS server by the radius-server host command then the global configuration set by this command is used for the server instead.

The no version of this command resets the transmit timeout to default (5 seconds).

Syntax radius-server timeout <seconds>

no radius-server timeout

Parameter	Description
timeout	RADIUS server timeout commands
<seconds>	RADIUS server timeout in secs <1-1000> The global time in seconds to wait for a RADIUS server to reply to a request before retransmitting the request, or considering the server to be dead (depending on the radius-server retransmit command).

Default The RADIUS transmit timeout on the system is 5 seconds.

Mode Global Configuration

Usage Use this command to specify the RADIUS global timeout value. This is how long the device waits for a reply to a RADIUS request before retransmitting the request, or considering the server to be dead. If no timeout is specified for the particular RADIUS server by the radius-server host command, it uses this global timeout value.

Use the no parameter to reset the timeout to the default value (5).

Examples To globally set the device to wait 20 seconds before retransmitting a RADIUS request to unresponsive RADIUS servers, use the following commands:

```
awplus# configure terminal
awplus(config)# radius-server timeout 20
```

To set the RADIUS timeout parameter to 1 second, use the following commands:

```
awplus# configure terminal
awplus(config)# radius-server timeout 1
```

To set the RADIUS timeout parameter to the default (5 seconds), use the following commands:

```
awplus# configure terminal
awplus(config)# no radius-server timeout
```

To configure the RADIUS server timeout period globally with 3 seconds, use the following commands:

```
awplus# configure terminal
awplus(config)# radius-server timeout 3
```

To reset the global timeout period for RADIUS servers to the default, use the following command:

```
awplus# configure terminal
awplus(config)# no radius-server timeout
```

Related Commands

- [radius-server deadtime](#)
- [radius-server host](#)
- [radius-server retransmit](#)
- [show radius statistics](#)

server (Server Group)

This command adds a RADIUS server to a server group in Server-Group Configuration mode. The RADIUS server should be configured by the radius-server host command.

The server is appended to the server list of the group, and the order of configuration determines the precedence of servers. If the server exists in the server group already, it will be removed before adding the new one.

The server is identified by IP address, authentication and accounting UDP port numbers. So a RADIUS server can have multiple entries in a group with different authentication and/or accounting UDP ports. The auth-port specifies the UDP destination port for authentication requests to the server. To disable authentication for the server, set auth-port to 0. If the authentication port is missing, the default port number is 1812. The acct-port specifies the UDP destination port for accounting requests to the server. To disable accounting for the server, set acct-port to 0. If the accounting port is missing, the default port number is 1813.

Use the no server command to remove a RADIUS server from the server group.

Syntax

```
server {<hostname>|<ip-address>}[auth-port <0-65535>]
    [acct-port <0-65535>]

no server {<hostname>|<ip-address>}[auth-port <0-65535>]
    [acct-port <0-65535>]
```

Parameter	Description
no	Negate a command or set its defaults
server	Configure RADIUS server
<hostname>	Server host name
<ip-address>	Server IP address The server is identified by IP address, authentication and accounting UDP port numbers. So a RADIUS server can have multiple entries in a group with different authentication and/or accounting UDP ports.
auth-port	Authentication port The auth-port specifies the UDP destination port for authentication requests to the server. To disable authentication for the server, set auth-port to 0. If the authentication port is missing, the default port number is 1812.
<0-65535>	UDP port number (default: 1812)
acct-port	Accounting port The acct-port specifies the UDP destination port for accounting requests to the server. To disable accounting for the server, set acct-port to 0. If the accounting port is missing, the default port number is 1813.
<0-65535>	UDP port number (default: 1813)

Default The Authentication port number is 1812 and the Accounting port number is 1813 by default.

Mode Server Group Configuration

Usage The RADIUS server to be added must be configured by the radius-server host command. In order to add or remove a server, the auth-port and acct-port parameters in this command must be the same as the corresponding parameters in the radius-server host command.

The server is appended to the server list of the group, and the order of configuration determines the precedence of servers. If the server exists in the server group already, it will be removed before adding the new one.

The server is identified by IP address and authentication and accounting UDP port numbers. So a RADIUS server can have multiple entries in a group with different authentication and/or accounting UDP ports.

Examples To create a RADIUS server group RAD_AUTH1 for authentication, use the following commands:

```
awplus# configure terminal
awplus(config)# aaa group server radius RAD_AUTH1
awplus(config-sg)# server 192.168.1.1 acct-port 0
awplus(config-sg)# server 192.168.2.1 auth-port 1000 acct-
port 0
```

To create a RADIUS server group RAD_ACCT1 for accounting, use the following commands:

```
awplus# configure terminal
awplus(config)# aaa group server radius RAD_ACCT1
awplus(config-sg)# server 192.168.2.1 auth-port 0 acct-
port 1001
awplus(config-sg)# server 192.168.3.1 auth-port 0
```

To remove server 192.168.3.1 from the existing server group GROUP1, use the following commands:

```
awplus# configure terminal
awplus(config)# aaa group server radius GROUP1
awplus(config-sg)# no server 192.168.3.1
```

Related Commands

- aaa accounting auth-mac default
- aaa accounting auth-web default
- aaa accounting dot1x
- aaa accounting login
- aaa authentication auth-mac
- aaa authentication auth-web
- aaa authentication login
- aaa group server
- radius-server host

show debugging radius

This command displays the current debugging status for the RADIUS servers.

Syntax `show debugging radius`

Parameter	Description
show	Show running system information
debugging	Debugging functions (see also 'undebug')
radius	RADIUS servers

Mode Privileged Exec

Examples To display the current debugging status of RADIUS servers, use the command:

```
awplus# show debug radius
```

Output Figure 60-1: Example output from the **show debugging radius** command

```
RADIUS debugging status:
  RADIUS event debugging is off
  RADIUS packet debugging is off
```

show radius

This command displays the current RADIUS server configuration and status.

Syntax `show radius`

Parameter	Description
show	Show running system information
radius	RADIUS protocol

Mode Privileged Exec

Output Description

Output Parameter	Meaning
Source Interface	The interface name or IP address to be used for the source address of all outgoing RADIUS packets
Secret Key	A shared secret key to a radius server
Timeout	A time interval in seconds

Output Parameter	Meaning
Retransmit Count	The number of retry count if a RADIUS server does not response
Deadtime	A time interval in minutes to mark a RADIUS server as "dead"
Interim-Update	A time interval in minutes to send Interim-Update Accounting report
Group Deadtime	The deadtime configured for RADIUS servers within a server group
Server Host	The RADIUS server hostname or IP address
Authentication Port	The destination UDP port for RADIUS authentication requests.
Accounting Port	The destination UDP port for RADIUS accounting requests.
Auth Status	The status of the authentication port. The status ("dead", "error", or "alive") of the RADIUS authentication server and, if dead, how long it has been dead for. • Alive : the server is alive • Error : the service is not responding • Dead : the service is detected as dead and it will not be used for deadtime period. The time displayed in the output shows the server is in dead status for that amount of time. • Unknown : the server is never used or the status is unknown
Acct Status	The status of the accounting port The status ("dead", "error", or "alive") of the RADIUS accounting server and, if dead, how long it has been dead for.

Example To display the current status of RADIUS servers, use the command:

```
awplus# show radius
```

Output Figure 60-2: Example output from the **show debugging radius** command

```
RADIUS Global Configuration
Source Interface : not configured
Secret Key : secret
Timeout : 5 sec
Retransmit Count : 3
Deadtime : 20 min

Server Host : 192.168.1.10
Authentication Port : 1812
Accounting Port : 1813
Secret Key : secret
Timeout : 3 sec
Retransmit Count : 2
Server Host : 192.168.1.11
Authentication Port : 1812
Accounting Port : not configured
```

Server Name/ IP Address	Auth Port	Acct Port	Auth Status	Acct Status
192.168.1.10	1812	1813	Alive	Alive
192.168.1.11	1812	N/A	Alive	N/A

See the sample output below showing RADIUS client status and RADIUS configuration:

```
awplus# show radius
```

Output Figure 60-3: Example output from the **show debugging radius** command

```
RADIUS global interface name: awplus
Secret key:
Timeout: 5
Retransmit count: 3
Deadtime: 0

Server Address: 150.87.18.89
Auth destination port: 1812
Accounting port: 1813
Secret key: swg
Timeout: 5
Retransmit count: 3
Deadtime: 0show radius local-server group
```

show radius statistics

This command shows the RADIUS client statistics for the switch.

Syntax `show radius statistics`

Parameter	Description
show	Show running system information
radius	RADIUS Server configuration and RADIUS status
statistics	RADIUS Server statistics

Mode Privileged Exec

Example See the sample output below showing RADIUS client statistics and RADIUS configuration:

```
awplus# show radius statistics
```

Output Figure 60-4: Example output from the **show radius statistics** command

```
RADIUS statistics for Server: 150.87.18.89
  Access-Request Tx      : 5 - Retransmit      : 0
  Access-Accept Rx      : 1 - Access-Reject Rx : 2
  Access-Challenge Rx   : 2
  Unknown Type          : 0 - Bad Authenticator : 0
  Malformed Access-Resp : 0 - Wrong Identifier  : 0
  Bad Attribute         : 0 - Packet Dropped   : 0
  TimeOut               : 0 - Dead count       : 0
  Pending Request       : 0
```

Chapter 61: Local RADIUS Server

Introduction and Configuration



Local RADIUS Server Introduction.....	61.2
Enable the Local RADIUS Server.....	61.2
Add the Local RADIUS Server as a RADIUS Server	61.3
Add authenticators to the list of authenticators.....	61.3
Configure the Local RADIUS Server User Database	61.4
Authenticating login sessions	61.4
Creating certificates for single users and all users.....	61.6
Defined RADIUS attributes list.....	61.7

Local RADIUS Server Introduction

Local RADIUS Server provides a user authentication service feature. This feature must be enabled on the switch, because it is disabled by default. For details of commands used to configure the local RADIUS server, see [Chapter 62, Local RADIUS Server Commands](#).

Enable the Local RADIUS Server

The Local RADIUS Server is disabled by default. Enter the following commands to enable the Local RADIUS Server:

```
awplus# configure terminal
awplus(config)# radius-server local
awplus(config-radsrv)# server enable
```

This will automatically initialize the internal Certificate Authority (CA) in the switch. It will also automatically create a server certificate and enrol the certificate with the Local CA by implicitly executing the following commands:

```
awplus(config)# crypto pki trustpoint local
awplus(config)# crypto pki enroll local
```

The `crypto pki trustpoint local` command declares the Local CA as the CA from which to obtain Certificates. The Local CA has be defined first so Certificates can be obtained from it. The `crypto pki enroll local` command obtains the system certificate from the Local CA.

The switch is automatically added to the list of authenticators that may send authentication requests to the Local RADIUS Server by implicitly executing the following commands:

```
awplus# configure terminal
awplus(config)# radius-server local
awplus(config-radsrv)# nas 127.0.0.1 key awplus-local-radius-server
```

Note: The key `awplus-local-radius-server` is a pre-defined component that can be used for internal exchanges between the switch's RADIUS client and its RADIUS server.

Add the Local RADIUS Server as a RADIUS Server

Although the switch is automatically defined as a NAS (Network Access Server) for the Local RADIUS Server, you must manually add the Local RADIUS Server to the server list defined for the Local RADIUS Client.

Use the following commands to add the Local RADIUS Server as a RADIUS Server. The Local RADIUS Client can then send authentication requests to its Local RADIUS Server:

```
awplus# configure terminal
awplus(config)# radius-server host 127.0.0.1 key awplus-local-
radius-server
```

Add authenticators to the list of authenticators

Authenticators can send authentication requests to the Local RADIUS Server.

Use the following commands to add other authenticators to the list of authenticators.

```
awplus# configure terminal
awplus(config)# radius-server local
awplus(config-radsrv)# nas <nas-ip-address> key <nas-keystring>
```

Configure the Local RADIUS Server User Database

Add users to the RADIUS user list without assigning VLANs

For entries that will be used to authenticate dot1x supplicants, but not assign them to a VLAN, the following commands will add users to the RADIUS user list:

```
awplus# configure terminal
awplus(config)# radius-server local
awplus(config-radsrv)# user <radius-user-name> password <user-
password>
```

Add users to the RADIUS user list and assign VLANs

Add users to the RADIUS user list, and define a VLAN ID that will be assigned to them

To add entries to be used to authenticate dot1x supplicants, and assign them to a VLAN, follow the two steps shown below:

Step 1: Create groups associated with the VLANs that will be allocated

Enter the following commands to create groups with the VLANs that will be allocated to them:

```
awplus# configure terminal
awplus(config)# radius-server local
awplus(config-radsrv)# group VLAN10Users
awplus(config-radsrv)# vlan 10
awplus(config-radsrv)# group VLAN11Users
awplus(config-radsrv)# vlan 11
```

Step 2: Add the users after creating groups

Add the users and refer to the relevant group in the command that creates the user as below:

```
awplus# configure terminal
awplus(config)# radius-server local
awplus(config-radsrv)# user VCSPCVLAN10 password VCSPCPass
group VLAN10Users
awplus(config-radsrv)# user VCSPCVLAN11 password VCSPCPass
group VLAN11Users
```

Authenticating login sessions

Authentication can be performed in multiple contexts, such as the authentication of users logging in at a console, as well as tri-authentication of devices connecting to switch ports, see [Tri-Authentication Configuration](#) in [Chapter 56, Authentication Configuration](#).

Add users to the RADIUS user list for authenticating login sessions

Adding entries to be used to authenticate login sessions on switches (by console, telnet or SSH) is also a two-step process:

Step 1: Create a group for administrative users

Create a group for administrative users and associate the appropriate service-type with this group with the following commands:

```
awplus# configure terminal
awplus(config)# radius-server local
awplus(config-radsrv)# group logins
awplus(config-radsrv)# attribute Service-Type 6
```

For a full list of attributes and values for each attribute, please refer to [Defined RADIUS attributes list](#) below.

Step 2: Add the users to the group

Add the users, and refer to the group in the command that creates the user as shown below:

```
awplus# conf t
awplus(config)# radius-server local
awplus(config-radsrv)# user netadmin password 45elephant98
                        group logins
```

Removing users from the RADIUS users list

To remove the user Tom from the user database of the Local RADIUS server, use the commands:

```
awplus# configure terminal
awplus(config)# radius-server local
awplus(config-radsrv)# no user Tom
```

Creating certificates for single users and all users

Create a certificate for a single user

A certificate for user Tom can be created from the local CA by using the commands:

```
awplus# configure terminal
awplus(config)# crypto pki enroll local user Tom
```

Create a certificate for all users

Certificates can be created for all currently defined users by using the commands:

```
awplus# configure terminal
awplus(config)# crypto pki enroll local local-radius-all-users
```

Exporting certificates

User certificates can be exported in PKCS12 format.

To export a certificate for user Tom and upload it to the TFTP server at 192.168.1.1, use the commands:

```
awplus# configure terminal
awplus(config)# crypto pki export local pkcs12 Tom tftp://
192.168.1.1/tomcert.pkcs
```

Defined RADIUS attributes list

This is a full list of valid attributes and pre-defined values that may be used in conjunction with the [attribute command on page 62.2](#), to show or configure defined RADIUS attributes.

[Table 61-1](#) lists all Standard attributes and values, [Table 61-2](#) lists the Vendor-Specific attribute (attribute ID 26) names and values.

More detailed information can be found in the following RFCs, defining the attributes and values for RADIUS server:

- [RFC2865 : Remote Authentication Dial In User Service \(RADIUS\)](#)
- [RFC2866 : RADIUS Accounting](#)
- [RFC2867 : RADIUS Accounting Modifications for Tunnel Protocol Support](#)
- [RFC2868 : RADIUS Attributes for Tunnel Protocol Support](#)
- [RFC2869 : RADIUS Extensions](#)
- [RFC3579 : RADIUS \(Remote Authentication Dial In User Service\) Support For Extensible Authentication Protocol \(EAP\)](#)
- [RFC3580 : IEEE 802.1X Remote Authentication Dial In User Service \(RADIUS\) Usage Guidelines](#)

Table 61-1: Standard RADIUS Attributes

Attribute ID and Name		Value Type/Pre-defined Values
1	User-Name	string
2	User-Password	string
3	CHAP-Password	octets (Hexadecimal string followed by 0x)
4	NAS-IP-Address	ipaddr (IPv4 address)
5	NAS-Port	Integer
6	Service-Type	Integer. Valid values are: ■ Administrative-User (6) ■ Authenticate-Only (8) ■ Authorize-Only (17) ■ Callback-Administrative (11) ■ Callback-Framed-User (4) ■ Callback-Login-User (3) ■ Callback-NAS-Prompt (9) ■ Call-Check (10) ■ Framed-User (2) ■ Login-User (1) ■ NAS-Prompt-User (7) ■ Outbound-User (5)
7	Framed-Protocol	Integer. Valid values are: ■ ARAP (3) ■ Gandalf-SLML (4) ■ PPP (1) ■ SLIP (2) ■ X.75-Synchronous (6) ■ Xylogics-IPX-SLIP (5)
8	Framed-IP-Address	ipaddr (IPv4 address)

Table 61-1: Standard RADIUS Attributes (Continued)

Attribute ID and Name		Value Type/Pre-defined Values
9	Framed-IP-Netmask	ipaddr (IPv4 address)
10	Framed-Routing	integer. Valid values are: ■ Broadcast (1) ■ Broadcast-Listen (3) ■ Listen (2) ■ None (0)
11	Filter-Id	string
12	Framed-MTU	Integer
13	Framed-Compression	Integer. Valid values are: ■ IPX-Header-Compression (2) ■ None (0) ■ Stac-LZS (3) ■ Van-Jacobson-TCP-IP (1)
14	Login-IP-Host	IP Address
15	Login-Service	Integer. Valid values are: ■ LAT (4) ■ PortMaster (3) ■ Rlogin (1) ■ TCP-Clear (2) ■ TCP-Clear-Quiet (8) ■ Telnet (0) ■ X25-PAD (5) ■ X25-T3POS (6)
16	Login-TCP-Port	Integer. Valid values are: ■ Rlogin (513) ■ Rsh (514) ■ Telnet (23)
18	Reply-Message	string
19	Callback-Number	string
20	Callback-Id	string
22	Framed-Route	string
23	Framed-IPX-Network	IP address
24	State	octets (Hexadecimal string followed by 0x)
25	Class	octets (Hexadecimal string followed by 0x)
26	Vendor-Specific	Use the Vendor-specific Attribute Name. For valid values, see “Vendor-Specific RADIUS Attributes” on page 61.13.
27	Session-Timeout	Integer
28	Idle-Timeout	Integer

Table 61-1: Standard RADIUS Attributes (Continued)

Attribute ID and Name		Value Type/Pre-defined Values
29	Termination-Action	Integer. Valid values are: ■ Default (0) ■ RADIUS-Request (1)
30	Called-Station-Id	string
31	Calling-Station-Id	string
32	NAS-Identifier	string
33	Proxy-State	octets (Hexadecimal string followed by 0x)
34	Login-LAT-Service	string
35	Login-LAT-Node	string
36	Login-LAT-Group	octets (Hexadecimal string followed by 0x)
37	Framed-AppleTalk-Link	Integer
38	Framed-AppleTalk-Network	Integer
39	Framed-AppleTalk-Zone	string
40	Acct-Status-Type	Integer. Valid values are: ■ Accounting-Off (8) ■ Accounting-On (7) ■ Alive (3) ■ Failed (15) ■ Interim-Update (3) ■ Start (1) ■ Stop (2) ■ Tunnel-Link-Reject (14) ■ Tunnel-Link-Start (12) ■ Tunnel-Link-Stop (13) ■ Tunnel-Reject (11) ■ Tunnel-Start (9) ■ Tunnel-Stop (10)
41	Acct-Delay-Time	Integer
42	Acct-Input-Octets	Integer
43	Acct-Output-Octets	Integer
44	Acct-Session-Id	string
45	Acct-Authentic	Integer. Valid values are: ■ Diameter (4) ■ Local (2) ■ RADIUS (1) ■ Remote (3)
46	Acct-Session-Time	Integer
47	Acct-Input-Packets	Integer
48	Acct-Output-Packets	Integer

Table 61-1: Standard RADIUS Attributes (Continued)

Attribute ID and Name	Value Type/Pre-defined Values
49 Acct-Terminate-Cause	Integer. Valid values are: ■ Admin-Reboot (7) ■ Admin-Reset (6) ■ Callback (16) ■ Host-Request (18) ■ Idle-Timeout (4) ■ Lost-Carrier (2) ■ Lost-Service (3) ■ NAS-Error (9) ■ NAS-Reboot (11) ■ NAS-Request (10) ■ Port-Disabled (22) ■ Port-Error (8) ■ Port-Preempted (13) ■ Port-Reinit (21) ■ Port-Suspended (14) ■ Port-Unneeded (12) ■ Reauthentication-Failure (20) ■ Service-Unavailable (15) ■ Session-Timeout (5) ■ Supplicant-Restart (19) ■ User-Error (17) ■ User-Request (1)
50 Acct-Multi-Session-Id	string
51 Acct-Link-Count	Integer
52 Acct-Input-Gigawords	Integer
53 Acct-Output-Gigawords	Integer
55 Event-Timestamp	date (Not supported)
56 Egress-VLANID	Integer
57 Ingress-Filters	Integer. Valid values are: ■ Disabled (2) ■ Enabled (1)
58 Egress-VLAN-Name	string
59 User-Priority-Table	octets (Hexadecimal string followed by 0x)
60 CHAP-Challenge	octets (Hexadecimal string followed by 0x)
61 NAS-Port-Type	Integer. Valid values are: ■ ADSL-CAP (12) ■ ADSL-DMT (13) ■ Async (0) ■ Cable (17) ■ Ethernet (15) ■ FDDI (21) ■ G.3-Fax (10) ■ HDLC-Clear-Channel (7)

Table 61-1: Standard RADIUS Attributes (Continued)

Attribute ID and Name	Value Type/Pre-defined Values
61 NAS-Port-Type (cont.)	Integer. Valid values are: ■ IDSL (14) ■ ISDN (2) ■ ISDN-V110 (4) ■ ISDN-V120 (3) ■ PIAFS (6) ■ SDSL (11) ■ Sync (1) ■ Token-Ring (20) ■ Virtual (5) ■ Wireless-802.11 (19) ■ Wireless-Other (18) ■ X.25 (8) ■ X.75 (9) ■ xDSL (16)
62 Port-Limit	Integer
63 Login-LAT-Port	Integer
64 Tunnel-Type	Integer. Valid values are: ■ AH (6) ■ ATMP (4) ■ DVS (11) ■ ESP (9) ■ GRE (10) ■ IP (7) ■ IP-in-IP (12) ■ L2F (2) ■ L2TP (3) ■ MIN-IP (8) ■ PPTP (1) ■ VLAN (13) ■ VTP (5)
65 Tunnel-Medium-Type	Integer. Valid values are: ■ Appletalk (12) ■ Banyan-Vines (14) ■ BBN-1822 (5) ■ DecNet-IV (13) ■ E.163 (7) ■ E.164 (8) ■ E.164-NSAP (15) ■ F.69 (9) ■ HDLC (4) ■ IEEE-802 (6) ■ IP (1) ■ IPv4 (1) ■ IPv6 (2) ■ IPX (11) ■ NSAP (3) ■ X.121 (10)
66 Tunnel-Client-Endpoint	string

Table 61-1: Standard RADIUS Attributes (Continued)

Attribute ID and Name		Value Type/Pre-defined Values
67	Tunnel-Server-Endpoint	string
68	Acct-Tunnel-Connection	string
69	Tunnel-Password	string
70	ARAP-Password	octets (Hexadecimal string followed by 0x)
71	ARAP-Features	octets (Hexadecimal string followed by 0x)
72	ARAP-Zone-Access	Integer. Valid values are: ■ Default-Zone (1) ■ Zone-Filter-Exclusive (4) ■ Zone-Filter-Inclusive (2)
73	ARAP-Security	Integer
74	ARAP-Security-Data	string
75	Password-Retry	integer
76	Prompt	integer. Valid values are: ■ Echo (1) ■ No-Echo (0)
77	Connect-Info	string
78	Configuration-Token	string
79	EAP-Message	octets (Hexadecimal string followed by 0x)
80	Message-Authenticator	octets (Hexadecimal string followed by 0x)
81	Tunnel-Private-Group-Id	string
82	Tunnel-Assignment-Id	string
83	Tunnel-Preference	Integer
84	ARAP-Challenge-Response	octets (Hexadecimal string followed by 0x)
85	Acct-Interim-Interval	Integer
86	Acct-Tunnel-Packets-Lost	Integer
87	NAS-Port-Id	string
88	Framed-Pool	string
89	Chargeable-User-Identity	string
90	Tunnel-Client-Auth-Id	string
91	Tunnel-Server-Auth-Id	string
95	NAS-IPv6-Address	ipv6addr (IPv6 address)
96	Framed-Interface-Id	ifid (Not supported)
97	Framed-IPv6-Prefix	ipv6prefix (Not supported)

Table 61-1: Standard RADIUS Attributes (Continued)

Attribute ID and Name		Value Type/Pre-defined Values
98	Login-IPv6-Host	ipv6addr (IPv6 address)
99	Framed-IPv6-Route	string
100	Framed-IPv6-Pool	string
101	Error-Cause	Integer. Valid values are: - Administratively-Prohibited (501) - Invalid-EAP-Packet (202) - Invalid-Request (404) - Missing-Attribute (402) - NAS-Identification-Mismatch (403) - Proxy-Processing-Error (505) - Proxy-Request-Not-Routable (502) - Request-Initiated (507) - Residual-Context-Removed (201) - Resources-Unavailable (506) - Session-Context-Not-Found (503) - Session-Context-Not-Removable (504) - Unsupported-Attribute (401) - Unsupported-Extension (406) - Unsupported-Service (405)

Table 61-2: Vendor-Specific RADIUS Attributes

Vendor-Specific Attribute Name	Value Type/Pre-defined Value
Actual-Data-Rate-Downstream	integer
Actual-Data-Rate-Upstream	integer
Actual-Interleaving-Delay-Downstream	integer
Actual-Interleaving-Delay-Upstream	integer
ADSL-Agent-Circuit-Id	string
ADSL-Agent-Remote-Id	string
Attainable-Data-Rate-Downstream	integer
Attainable-Data-Rate-Upstream	integer
call-id	string
Cisco-Abort-Cause	string
Cisco-Account-Info	string
Cisco-Assign-IP-Pool	integer
Cisco-AVPair	string
Cisco-Call-Filter	integer
Cisco-Call-Type	string

Table 61-2: Vendor-Specific RADIUS Attributes (Continued)

Vendor-Specific Attribute Name	Value Type/Pre-defined Value
Cisco-Command-Code	string
Cisco-Control-Info	string
Cisco-Data-Filter	integer
Cisco-Data-Rate	integer
Cisco-Disconnect-Cause	integer. Valid values are: ■ CLID-Authentication-Failure - 4 ■ Control-C-Detected - 27 ■ EXEC-Program-Destroyed - 28 ■ Exit-Raw-TCP - 24 ■ Exit-Telnet-Session - 22 ■ Failed-PPP-CHAP-Auth - 43 ■ Failed-PPP-LCP-Negotiation - 41 ■ Failed-PPP-PAP-Auth-Fail - 42 ■ Failed-PPP-Remote-Auth - 44 ■ Idle-Timeout - 21 ■ Invalid-Protocol - 120 ■ Lost-Carrier - 1 ■ No-Carrier - 0 ■ No-Detected-Result-Codes - 2 ■ No-Remote-IP-Addr - 23 ■ Password-Fail - 25 ■ PPP-Closed-Event - 46 ■ PPP-Remote-Terminate - 45 ■ Raw-TCP-Disabled - 26 ■ Session-End-Callback - 02 ■ Session-Failed-Security - 01 ■ Session-Timeout - 00 ■ Timeout-PPP-LCP - 40 ■ Unknown - 2 ■ User-Ends-Session - 20
Cisco-Email-Server-Ack-Flag	string
Cisco-Email-Server-Address	string
Cisco-Fax-Account-Id-Origin	string
Cisco-Fax-Auth-Status	string
Cisco-Fax-Connect-Speed	string
Cisco-Fax-Coverpage-Flag	string
Cisco-Fax-Dsn-Address	string
Cisco-Fax-Dsn-Flag	string
Cisco-Fax-Mdn-Address	string
Cisco-Fax-Mdn-Flag	string
Cisco-Fax-Modem-Time	string
Cisco-Fax-Msg-Id	string

Table 61-2: Vendor-Specific RADIUS Attributes (Continued)

Vendor-Specific Attribute Name	Value Type/Pre-defined Value
Cisco-Fax-Pages	string
Cisco-Fax-Process-Abort-Flag	string
Cisco-Fax-Recipient-Count	string
Cisco-Gateway-Id	string
Cisco-Idle-Limit	integer
Cisco-IP-Direct	integer
Cisco-IP-Pool-Definition	string
Cisco-Link-Compression	integer
Cisco-Maximum-Channels	integer
Cisco-Maximum-Time	integer
Cisco-Multilink-ID	integer
Cisco-NAS-Port	string
Cisco-Num-In-Multilink	integer
Cisco-Port-Used	string
Cisco-PPP-Async-Map	integer
Cisco-PPP-VJ-Slot-Comp	integer
Cisco-Pre-Input-Octets	integer
Cisco-Pre-Input-Packets	integer
Cisco-Pre-Output-Octets	integer
Cisco-Pre-Output-Packets	integer
Cisco-PreSession-Time	integer
Cisco-PW-Lifetime	integer
Cisco-Route-IP	integer
Cisco-Service-Info	string
Cisco-Target-Util	integer
Cisco-Xmit-Rate	integer
gw-final-xlated-cdn	string
gw-final-xlated-cgn	string
gw-rxd-cdn	string
gw-rxd-cgn	string
h323-billing-model	string

Table 61-2: Vendor-Specific RADIUS Attributes (Continued)

Vendor-Specific Attribute Name	Value Type/Pre-defined Value
h323-call-origin	string
h323-call-type	string
h323-conf-id	string
h323-connect-time	string
h323-credit-amount	string
h323-credit-time	string
h323-currency	string
h323-disconnect-cause	string
h323-disconnect-time	string
h323-gw-id	string
h323-incoming-conf-id	string
h323-preferred-lang	string
h323-prompt-id	string
h323-redirect-ip-address	string
h323-redirect-number	string
h323-remote-address	string
h323-return-code	string
h323-setup-time	string
h323-time-and-day	string
h323-voice-quality	string
incoming-req-uri	string
IWF-Session	octets
Maximum-Data-Rate-Downstream	integer
Maximum-Data-Rate-Upstream	integer
Maximum-Interleaving-Delay-Downstream	integer
Maximum-Interleaving-Delay-Upstream	integer
method	string
Minimum-Data-Rate-Downstream	integer
Minimum-Data-Rate-Downstream-Low-Power	integer
Minimum-Data-Rate-Upstream	integer
Minimum-Data-Rate-Upstream-Low-Power	integer

Table 61-2: Vendor-Specific RADIUS Attributes (Continued)

Vendor-Specific Attribute Name	Value Type/Pre-defined Value
MS-Acct-Auth-Type	integer. Valid values are: ■ CHAP - 2 ■ EAP - 5 ■ MS-CHAP-1 - 3 ■ MS-CHAP-2 - 4 ■ PAP - 1
MS-Acct-EAP-Type	integer. Valid values are: ■ Generic-Token-Card - 6 ■ MD5 - 4 ■ OTP - 5 ■ TLS -13
MS-ARAP-PW-Change-Reason	integer. Valid values are: ■ Admin-Requires-Password-Change - 3 ■ Expired-Password - 2 ■ Just-Change-Password - 1 ■ Password-Too-Short - 4
MS-BAP-Usage	integer. Valid values are: ■ Allowed - 1 ■ Not-Allowed - 0 ■ Required - 2
MS-CHAP2-CPW	octets
MS-CHAP2-Response	octets
MS-CHAP2-Success	octets
MS-CHAP-Challenge	octets
MS-CHAP-CPW-1	octets
MS-CHAP-CPW-2	octets
MS-CHAP-Domain	string
MS-CHAP-Error	string
MS-CHAP-LM-Enc-PW	octets
MS-CHAP-MPPE-Keys	octets
MS-CHAP-NT-Enc-PW	octets
MS-CHAP-Response	octets
MS-Filter	octets
MS-Link-Drop-Time-Limit	integer
MS-Link-Utilization-Threshold	integer
MS-MPPE-Encryption-Policy	octets
MS-MPPE-Encryption-Type	octets
MS-MPPE-Encryption-Types	octets

Table 61-2: Vendor-Specific RADIUS Attributes (Continued)

Vendor-Specific Attribute Name	Value Type/Pre-defined Value
MS-MPPE-Recv-Key	octets
MS-MPPE-Send-Key	octets
MS-New-ARAP-Password	octets
MS-Old-ARAP-Password	octets
MS-Primary-DNS-Server	ipaddr
MS-Primary-NBNS-Server	ipaddr
MS-RAS-Vendor	integer
MS-RAS-Version	string
MS-Secondary-DNS-Server	ipaddr
MS-Secondary-NBNS-Server	ipaddr
next-hop-dn	string
next-hop-ip	string
outgoing-req-uri	string
prev-hop-ip	string
prev-hop-via	string
release-source	string
remote-media-address	string
session-protocol	string
sip-hdr	string
subscriber	string

Chapter 62: Local RADIUS Server Commands

Command List	62.2
attribute	62.2
authentication	62.5
clear radius local-server statistics	62.6
copy local-radius-user-db (from file)	62.7
copy local-radius-user-db (to file)	62.8
crypto pki enroll local	62.9
crypto pki enroll local local-radius-all-users	62.10
crypto pki enroll local user	62.11
crypto pki export local pem	62.12
crypto pki export local pkcs12	62.13
crypto pki trustpoint local	62.14
debug crypto	62.15
egress-vlan-id	62.16
egress-vlan-name	62.17
group	62.19
nas	62.20
radius-server local	62.21
server auth-port	62.22
server enable	62.23
show crypto pki certificates	62.24
show crypto pki certificates local-radius-all-users	62.26
show crypto pki certificates user	62.27
show crypto pki trustpoints	62.28
show radius local-server group	62.29
show radius local-server nas	62.30
show radius local-server statistics	62.31
show radius local-server user	62.32
user (RADIUS server)	62.34
vlan (RADIUS server)	62.36

Command List

This chapter provides an alphabetical reference for commands used to configure the local RADIUS server on the device. For more information, see [Chapter 61, Local RADIUS Server Introduction and Configuration](#).

attribute

Use this command to define a RADIUS attribute for the local RADIUS server user group.

For a complete list of defined RADIUS attributes and values, see [“Defined RADIUS attributes list” on page 61.7](#).

When used with the help parameter the attribute command displays a list of standard and vendor specific valid RADIUS attributes that are supported by the local RADIUS server.

If an attribute name is specified with the help parameter, then the attribute command displays a list of predefined attribute names. Note that you can only use the defined RADIUS attribute names and not define your own.

When used with the value parameter the attribute command configures RADIUS attributes to the user group. If the specified attribute is already defined then it is replaced with the new value.

Use the no version of this command to delete an attribute from the local RADIUS server user group.

Syntax

```
attribute [<attribute-name>|<attribute-id>] help
attribute {<attribute-name>|<attribute-id>} <value>
no attribute {<attribute-name>|<attribute-id>}
```

Parameter	Description
<attribute-name>	RADIUS attribute name for standard attributes (see Table 61-1 on page 61.7) or Vendor-Specific attributes (see Table 61-2 on page 61.13).
<attribute-id>	RADIUS attribute numeric identifier for standard attributes (Table 61-1 on page 61.7).
<value>	RADIUS attribute value.
help	Display a list of available attribute types.

Default By default, no attributes are configured.

Mode RADIUS Server Group Configuration

Usage For the Standard attributes, the attribute may be specified using either the attribute name, or its numeric identifier. For example, command:

```
awplus(config-radsrv-group)# attribute acct-terminate-cause
help
```


will produce the same results as command:

```
awplus(config-radsrv-group)# attribute 49 help
```

In the same way, where the specific attribute has a pre-defined value, the parameter *<value>* may be substituted with the Value Name or with its numeric value, for example command:

```
awplus(config-radsrv-group)# attribute acct-terminate-cause  
user-request
```

will produce the same results as command:

```
awplus(config-radsrv-group)# attribute 49 1
```

or command:

```
awplus(config-radsrv-group)# attribute acct-terminate-cause 1
```

Examples To check a list of all available defined RADIUS attribute names, use the following commands:

```
awplus# configure terminal  
awplus(config)# radius-server local  
awplus(config-radsrv)# group Admin  
awplus(config-radsrv-group)# attribute help
```

A list of Vendor-specific Attributes displays after the list of defined Standard Attributes.

To get help for valid RADIUS attribute values for the attribute Service-Type, use the following commands:

```
awplus# configure terminal  
awplus(config)# radius-server local  
awplus(config-radsrv)# group Admin  
awplus(config-radsrv-group)# attribute Service-Type help
```

```
Service-Type : integer (Integer number)  
Pre-defined values :  
Administrative-User (6)  
Authenticate-Only (8)  
Authorize-Only (17)  
Callback-Administrative (11)  
Callback-Framed-User (4)  
Callback-Login-User (3)  
Callback-NAS-Prompt (9)  
Call-Check (10)  
Framed-User (2)  
Login-User (1)  
NAS-Prompt-User (7)  
Outbound-User (5)
```

To define the attribute name 'Service-Type' with Administrative User (6) to the RADIUS User Group 'Admin', use the following commands:

```
awplus# configure terminal
awplus(config)# radius-server local
awplus(config-radsrv)# group Admin
awplus(config-radsrv-group)# attribute Service-Type 6
```

To delete the attribute 'Service-Type' from the RADIUS User Group 'Admin', use the following commands:

```
awplus# configure terminal
awplus(config)# radius-server local
awplus(config-radsrv)# group Admin
awplus(config-radsrv-group)# no attribute Service-Type
```

Related Commands [egress-vlan-id](#)
[egress-vlan-name](#)

authentication

Use this command to enable the specified authentication methods on the local RADIUS server.

Use the no version of this command to disable specified authentication methods on the local RADIUS server.

Syntax `authentication {mac|eapmd5|eaptls|peap}`
`no authentication {mac|eapmd5|eaptls|peap}`

Parameter	Description
mac	Enable MAC authentication method
eapmd5	Enable EAP-MD5 authentication method
eaptls	Enable EAP-TLS authentication method
peap	Enable EAP-PEAP authentication method

Default All authentication methods are enabled by default.

Mode RADIUS Server Configuration

Examples The following commands enable EAP-MD5 authentication methods on the local RADIUS server.

```
awplus# configure terminal
awplus(config)# radius-server local
awplus(config-radsrv)# authentication eapmd5
```

The following commands disable EAP-MD5 authentication methods on Local RADIUS server.

```
awplus# configure terminal
awplus(config)# radius-server local
awplus(config-radsrv)# no authentication eapmd5
```

Related Commands `server enable`
`show radius local-server statistics`

clear radius local-server statistics

Use this command to clear the statistics stored on the switch for the local RADIUS server.

Use this command without any parameters to clear all types of local RADIUS server statistics.

Syntax `clear radius local-server statistics [nas|server|user]`

Parameter	Description
nas	Clear the NAS (Network Access Server) statistics on the switch. For example, clearing statistics stored for NAS server invalid passwords.
server	Clear the Local RADIUS Server statistics on the switch. For example, clearing Local RADIUS Servers statistics for all failed login attempts.
user	Clear the Local RADIUS Server user statistics. For example, clearing statistics stored for the number of successful user logins.

Mode Privileged Exec

Usage Refer to the sample output for the [show radius local-server statistics](#) for further information about the type of statistics each parameter option for this command clears. Both the `nas` and `server` parameters clear unknown username and invalid passwords statistics, while the `user` parameter clears the number of successful and failed logins for each local RADIUS server user.

Examples To clear the NAS (Network Access Server) statistics stored on the switch, use the command:

```
awplus# clear radius local-server statistics nas
```

To clear the local RADIUS server statistics stored on the switch, use the command:

```
awplus# clear radius local-server statistics server
```

To clear the local RADIUS server user statistics stored on the switch, use the command:

```
awplus# clear radius local-server statistics user
```

Related Commands [show radius local-server statistics](#)

copy local-radius-user-db (from file)

Use this command to copy the Local RADIUS server user data from a file. The file, including the RADIUS user data in the file, must be in the CSV (Comma Separated Values) format.

You can select add or replace as the copy method. The add parameter option copies the contents of specified file to the local RADIUS server user database. If the same user exists then the old user is removed before adding a new user. The replace parameter option deletes all contents of the local RADIUS server user database before copying the contents of specified file.

Syntax `copy <source-url> local-radius-user-db [add|replace]`

Parameter	Description
copy	Copy from one file to another
<source-url>	URL of the source file
local-radius-user-db	Copy to the local RADIUS server user data
add	Add file contents to local RADIUS server user database
replace	Replace current local RADIUS server user database with file contents. (Default)

Mode Privileged Exec

Default When no copy method is specified with this command the replace option is applied.

Examples To replace the current local RADIUS server user data to the contents of http://datahost/user.csv, use the following command:

```
awplus# copy http://datahost/user.csv local-radius-user-db
```

To add the contents of http://datahost/user.csv to the current local RADIUS server user database, use the following command:

```
awplus# copy http://datahost/user.csv local-radius-user-db add
```

Related commands [copy local-radius-user-db \(to file\)](#)

copy local-radius-user-db (to file)

Use this command to copy the local RADIUS server user data to a file. The output file produced is CSV (Comma Separated Values) format.

Syntax `copy local-radius-user-db {flash|nvs|card|tftp|scp|<destination-url>}`

Parameter	Description
copy	Copy from one file to another
local-radius-user-db	Copy from RADIUS server user database
flash	Copy to flash memory
nvs	Copy to NVS memory
card	Copy to SD card
tftp	Copy to TFTP destination
scp	Copy to SCP destination
<destination-url>	URL of the Destination file

Mode Privileged Exec

Example Copy the current local RADIUS server user data to http://datahost/user.csv.

```
awplus# copy local-radius-user-db http://datahost/user.csv
```

Related Commands [copy local-radius-user-db \(from file\)](#)

crypto pki enroll local

Use this command to obtain a system certificate from the Local CA (Certificate Authority).

Use the no crypto pki enroll local command to delete system certificates created by a Local CA (Certificate Authority).

Syntax crypto pki enroll local
no crypto pki enroll local

Parameter	Description
no	Negate a command or set its defaults
crypto	Security Specific Commands
pki	Public Key Infrastructure (PKI) Commands
enroll	Enroll to specified trustpoint
local	Local Certificate Authority

Default The system certificate is not available until this command is issued.

Mode Global Configuration

Examples The following commands obtain the system certificate from the Local CA (Certificate Authority).

```
awplus# configure terminal
awplus(config)# crypto pki enroll local
```

The following commands delete the system certificate created by the Local CA (Certificate Authority).

```
awplus# configure terminal
awplus(config)# no crypto pki enroll local
```

Related Commands crypto pki trustpoint local
group

crypto pki enroll local local-radius-all-users

Use this command to create certificates for all users registered in the local RADIUS server. These certificates are created by the Local Certificate Authority (CA) on the switch.

Syntax `crypto pki enroll local local-radius-all-users`

Parameter	Description
crypto	Security Specific Commands
pki	Public Key Infrastructure (PKI) Commands
enroll	Enroll to specified trustpoint
local	Local Certificate Authority
local-radius-all-users	Certificates for all users registered to local RADIUS server

Default By default, there are no certificates for users in the local RADIUS server.

Mode Global Configuration

Example The following commands obtain the local RADIUS server certificates for the user from the Local CA (Certificate Authority).

```
awplus# configure terminal
```

```
awplus(config)# crypto pki enroll local local-radius-all-users
```

Related Commands [crypto pki trustpoint local](#)
[show crypto pki certificates](#)

crypto pki enroll local user

Use this command to obtain a local user certificate from the Local CA (Certificate Authority).

Use the no crypto pki enroll local user command to delete user certificates created by the Local CA (Certificate Authority).

Syntax `crypto pki enroll local user <user-name>`
`no crypto pki enroll local user <user-name>`

Parameter	Description
no	Negate a command or set its defaults
crypto	Security Specific Commands
pki	Public Key Infrastructure (PKI) Commands
enroll	Enroll to specified trustpoint
local	Local Certificate Authority
user	Certificates for user
<user-name>	User name

Default By default, there is no user certificate.

Mode Global Configuration

Example The following commands obtain Tom's certificate from the Local CA (Certificate Authority).

```
awplus# configure terminal
awplus(config)# crypto pki enroll local user Tom
```

The following commands delete Tom's certificates created by the Local CA (Certificate Authority):

```
awplus# configure terminal
awplus(config)# no crypto pki enroll local user Tom
```

Related Commands `crypto pki trustpoint local`
`show crypto pki certificates`

crypto pki export local pem

Use this command to export the certificate associated with the Local CA to a PEM format file.

Syntax `crypto pki export local pem url <url>`

Parameter	Description
crypto	Security Specific Commands
pki	Public Key Infrastructure (PKI) Commands
export	Export certificates
local	Local Certificate Authority
pem	Export Local CA certificate to PEM format file
url	Specify destination url
<url>	Url string

Mode Global Configuration

Example The following commands export the Local CA certificate to a PEM format file.

```
awplus# configure terminal
awplus(config)# crypto pki export local pem url tftp://
192.168.1.1/cacert.pem
```

Related Commands `crypto pki enroll local`

crypto pki export local pkcs12

Use this command to export a specified certificate to a PKCS12 format file.

This command cannot be used for exporting certificates for the local system.

Syntax `crypto pki export local pkcs12 <user-name> <destination-url>`

Parameter	Description
crypto	Security Specific Commands
pki	Public Key Infrastructure (PKI) Commands
export	Export certificates
local	Local Certificate Authority
pkcs12	Export user certificate to PKCS12 format file
<user-name>	User name
<destination-url>	Destination url string

Mode Global Configuration

Example The following commands export a certificate for a user named client to a PKCS12 format file.

```
awplus# configure terminal
```

```
awplus(config)# crypto pki export local pkcs12 client tftp://
192.168.1.1/cacert.pem
```

To export Tom's certificate to PKSC12 format file, use the commands:

```
awplus# configure terminal
```

```
awplus(config)# crypto pki export local pksc12 Tom tftp://
192.168.1.1/tom.pfx
```

Related Commands `crypto pki enroll local`

crypto pki trustpoint local

Use this command to declare the Local CA (Certificate Authority) as the trustpoint that the system uses. The ca-trustpoint configuration mode is available after this command is issued.

Use the no crypto pki trustpoint local command to delete all information and certificates associated with Local CA as the trustpoint.

Syntax crypto pki trustpoint local
 no crypto pki trustpoint local

Parameter	Description
crypto	Security Specific Commands
pki	Public Key Infrastructure (PKI) Commands
trustpoint	Declare trustpoint
local	Local Certificate Authority

Default Local CA is not a trustpoint by default.

Mode Global Configuration

Examples Use the following commands to declare the Local CA as the trustpoint.

```
awplus# configure terminal
awplus(config)# crypto pki trustpoint local
```

Use the following commands to delete all information and certificates associated with the Local CA.

```
awplus# configure terminal
awplus(config)# no crypto pki trustpoint local
```

To create a client certificate for all users registered to the local RADIUS server, use the following commands:

```
awplus(config)# crypto pki trustpoint local
awplus(ca-trust-point)# exit
awplus(config)# crypto pki enroll local alternative
```

Related Commands crypto pki enroll local
 show crypto pki trustpoints

debug crypto

Use this command to enable Public Key Infrastructure (PKI) debugging. When PKI debugging is enabled, the PKI module starts generating diagnostic messages to the system log.

Use the no debug crypto command to disable Public Key Infrastructure (PKI) debugging. When PKI debugging is disabled, the PKI module stops generating diagnostic messages to the system log.

Syntax debug crypto pki
 no debug crypto pki

Parameter	Description
debug	Debugging functions (see also 'undebug')
crypto	Security Specific
pki	Public Key Infrastructure (PKI)

Default PKI debugging is disabled by default

Mode Privileged Exec

Example To enable the PKI debugging facility, use the command:

```
awplus# debug crypto pki
```

To disable the PKI debugging facility, use the command:

```
awplus# no debug crypto pki
```

egress-vlan-id

Use this command to configure the standard RADIUS attribute 'Egress-VLANID (56)' for the local RADIUS Server user group.

Use the no version of this command to remove the Egress-VLANID attribute from the local RADIUS server user group.

Syntax `egress-vlan-id <vid> [tagged|untagged]`
`no egress-vlan-id`

Parameter	Description
<vid>	The VLAN identifier to be used for the Egress VLANID attribute, in the range 1 to 4094.
tagged	Set frames on the VLAN as tagged. This sets the tag indication field to indicate that all frames on this VLAN are tagged.
untagged	Set all frames on the VLAN as untagged. This sets the tag indication field to indicate that all frames on this VLAN are untagged.

Default By default, no Egress-VLANID attributes are configured.

Mode RADIUS Server Group Configuration

Usage When a Voice VLAN is configured for dynamic VLAN allocation ([switchport voice vlan command on page 17.21](#)), the RADIUS server must be configured to send the VLAN information when an IP phone is successfully authenticated. Use either the [egress-vlan-id command](#) or the [egress-vlan-name command on page 62.17](#), and specify the tagged parameter.

Examples To set the 'Egress-VLANID' attribute for the NormalUsers local RADIUS server user group to VLAN identifier 200, with tagged frames, use the commands:

```
awplus# configure terminal
awplus(config)# radius-server local
awplus(config-radsrv)# group NormalUsers
awplus(config-radsrv-group)# egress-vlan-id 200 tagged
```

To remove the 'Egress-VLANID' attribute for the NormalUsers local RADIUS server user group, use the commands:

```
awplus# configure terminal
awplus(config)# radius-server local
awplus(config-radsrv)# group NormalUsers
awplus(config-radsrv-group)# no egress-vlan-id
```

Related Commands [attribute](#)
[egress-vlan-name](#)
[switchport voice vlan](#)

egress-vlan-name

Use this command to configure the standard RADIUS attribute 'Egress-VLAN-Name (58)' for the local RADIUS server user group.

Use the no version of this command to remove the Egress-VLAN-Name attribute from the local RADIUS server user group.

Syntax `egress-vlan-name <vlan-name> [tagged|untagged]`
`no egress-vlan-name`

Parameter	Description
<code>egress-vlan-name</code>	Set Egress-VLAN-Name attribute
<code><vlan-name></code>	The VLAN name to be configured as the Egress-VLAN-Name attribute.
<code>tagged</code>	Set frames on the VLAN as tagged. This sets the tag indication field to indicate that all frames on this VLAN are tagged.
<code>untagged</code>	Set all frames on the VLAN as untagged. This sets the tag indication field to indicate that all frames on this VLAN are untagged.

Default By default, no Egress-VLAN-Name attributes are configured.

Mode RADIUS Server Group Configuration

Usage When a Voice VLAN is configured for dynamic VLAN allocation ([switchport voice vlan command on page 17.21](#)), the RADIUS server must be configured to send the VLAN information when an IP phone is successfully authenticated. Use either the [egress-vlan-id command on page 62.16](#) or the [egress-vlan-name](#) command, and specify the tagged parameter.

Examples To configure the 'Egress-VLAN-Name' attribute for the RADIUS server user group NormalUsers with the VLAN name 'vlan2' and all frames on this VLAN tagged, use the commands:

```
awplus# configure terminal
awplus(config)# radius-server local
awplus(config-radsrv)# group NormalUsers
awplus(config-radsrv-group)# egress-vlan-name vlan2 tagged
```

To delete the 'Egress-VLAN-Name' attribute for the NormalUsers group, use the commands:

```
awplus# configure terminal
awplus(config)# radius-server local
awplus(config-radsrv)# group NormalUsers
awplus(config-radsrv-group)# no egress-vlan-name
```

Related Commands attribute
 egress-vlan-id
 switchport voice vlan

group

Use this command to create a local RADIUS server user group, and enter local RADIUS Server User Group Configuration mode.

Use the no group command to delete the local RADIUS server user group.

Syntax `group <user-group-name>`
`no group <user-group-name>`

Parameter	Description
group	RADIUS user group configuration commands
<user-group-name>	User group name string

Mode RADIUS Server Configuration

Example The following commands create the user group NormalUsers.

```
awplus# configure terminal
awplus(config)# radius-server local
awplus(config-radsrv)# group NormalUsers
```

The following commands delete user group NormalUsers.

```
awplus# configure terminal
awplus(config)# radius-server local
awplus(config-radsrv)# no group NormalUsers
```

Related Commands `user (RADIUS server)`
`show radius local-server user`
`vlan (RADIUS server)`

nas

This command adds a client device (the Network Access Server or the NAS) to the list of devices that are able to send authentication requests to the local RADIUS server. The NAS is identified by its IP address and a shared secret (also referred to as a shared key) must be defined that the NAS will use to establish its identity.

Use the `no nas` command to remove a NAS client from the list of devices that are allowed to send authentication requests to the local RADIUS server.

Syntax `nas <ip-address> key <nas-keystring>`
`no nas <ip-address>`

Parameter	Description
<code>nas</code>	RADIUS NAS configuration commands
<code><ip-address></code>	RADIUS NAS IP address
<code>key</code>	Specify the shared key for NAS
<code><nas-keystring></code>	NAS shared keystring

Mode RADIUS Server Configuration

Example The following commands add the NAS with an IP address of 192.168.1.2 to the list of clients that may send authentication requests to the local RADIUS server. Note the shared key that this NAS will use to establish its identify is NAS_PASSWORD.

```
awplus# configure terminal
awplus(config)# radius-server local
awplus(config-radsrv)# nas 192.168.1.2 key NAS_PASSWORD
```

The following commands remove the NAS with an IP address of 192.168.1.2 from the list of clients that are allowed to send authentication requests to the local RADIUS server:

```
awplus# configure terminal
awplus(config)# radius-server local
awplus(config-radsrv)# no nas 192.168.1.2
```

Related Commands `show radius local-server nas`

radius-server local

Use this command to navigate to the Local RADIUS server configuration mode (config-radsrv) from the Global Configuration mode (config).

Syntax radius-server local

Parameter	Description
radius-server	RADIUS server
local	Local RADIUS server commands

Mode Global Configuration

Example Local RADIUS Server commands are available from config-radsrv configuration mode. To change mode from Exec mode to the Local RADIUS Server mode (config-radsrv), use the commands:

```
awplus# configure terminal
awplus(config)# radius-server local
awplus(config-radsrv)#
```

Output

```
awplus(config)#radius-server local
Creating Local CA repository.....OK
Enrolling Local System to local trustpoint..OK
awplus(config-radsrv)#
```

Related Commands

- server enable
- show radius local-server group
- show radius local-server nas
- show radius local-server statistics
- show radius local-server user

server auth-port

Use this command to change the UDP port number for local RADIUS server authentication.

Use the no server auth-port command to reset the RADIUS server authentication port back to the default.

Syntax server auth-port <1-65535>

no server auth-port

Parameter	Description
server	RADIUS local server configuration commands
auth-port	Set local server's authentication port
<1-65535>	UDP port number

Default The default local RADIUS server UDP authentication port number is 1812.

Mode RADIUS Server Configuration

Example The following commands set the RADIUS server authentication port to 10000.

```
awplus# configure terminal
awplus(config)# radius-server local
awplus(config-radsrv)# server port 10000
```

The following commands reset the RADIUS server authentication port back to the default UDP port of 1812.

```
awplus# configure terminal
awplus(config)# radius-server local
awplus(config-radsrv)# no server port
```

Related Commands server enable
show radius local-server statistics

server enable

This command enables the local RADIUS server. The local RADIUS server feature is started immediately when this command is issued.

The no version of this command disables local RADIUS server. When this command is issued, the local RADIUS server stops operating.

Syntax server enable
 no server enable

Default The local RADIUS server is disabled by default and must be enabled for use with this command.

Mode RADIUS Server Configuration

Examples To enable the local RADIUS server, use the following commands:

```
awplus# configure terminal
awplus(config)# radius-server local
awplus(config-radsrv)# server enable
```

To disable the local RADIUS server, use the command:

```
awplus# configure terminal
awplus(config)# radius-server local
awplus(config-radsrv)# no server enable
```

Related Commands server auth-port
 show radius local-server statistics

show crypto pki certificates

Use this command to display certificate information.

Syntax `show crypto pki certificates [local-ca|local|<certificate-name>]`

Parameter	Description
show	Show running system information
crypto	Security Specific
pki	Public Key Infrastructure (PKI)
certificates	Certificate information
local-ca	Local CA certificate
local	Local system certificate
<certificate-name>	Certificate name

Mode Privileged Exec

Examples The following command displays Local CA (Certificate Authority) certificate information.

```
awplus# show crypto pki certificates local-ca
```

The following command displays Local System certificate information.

```
awplus# show crypto pki certificates local
```

The following command displays Tom's local certificate information.

```
awplus# show crypto pki certificates Tom
```

The following command displays information of all certificates.

```
awplus# show crypto pki certificates
```

Output

Figure 62-1: Example output from the show crypto pki certificates command

```
Certificate: Local CA
Version: 3 (0x2)
Serial Number: 0 (0x0)
Signature Algorithm: sha1WithRSAEncryption
Issuer: O=Allied-Telesis, CN=AlliedwarePlusCA
Validity
Not Before: Mar 20 08:46:29 2008 GMT
Not After : Mar 15 08:46:29 2028 GMT
Subject: O=Allied-Telesis, CN=AlliedwarePlusCA
Certificate: Local System
Version: 3 (0x2)
Serial Number: 4 (0x4)
Signature Algorithm: sha1WithRSAEncryption
Issuer: O=Allied-Telesis, CN=AlliedwarePlusCA
Validity
Not Before: Mar 20 09:03:01 2008 GMT
Not After : Mar 18 09:03:01 2018 GMT
Subject: O=Allied-Telesis, CN=AlliedwarePlusSystem
```

Table 62-1: Parameters in the output from the show crypto pki certificates command

Parameter	Description
Certificate	Certificate name
Version	Protocol version
Serial Number	Serial number of the certificate
Signature Algorithm	Algorithm used for the certificate signature
Issuer	Subject of issuer creating the certificate
Validity	Validity period
Subject	Subject of the certificate

Related Commands [crypto pki enroll local](#)

show crypto pki certificates local-radius-all-users

Use this command to display certificate information for local RADIUS server users.

Syntax `show crypto pki certificates local-radius-all-users`

Parameter	Description
show	Show running system information
crypto	Security Specific
pki	Public Key Infrastructure (PKI)
certificates	Certificate information
local-radius-all-users	All Local RADIUS server users

Mode Privileged Exec

Example The following command displays information of all local RADIUS server user certificates.

```
awplus# show crypto pki certificates local-radius-all-users
```

Output

Figure 62-2: Example output from the show crypto pki certificates local-radius-all-users command

```
Certificate: Alice
Not exist.
Certificate: Tom
Version: 3 (0x2)
Serial Number: 13 (0xd)
Signature Algorithm: sha1WithRSAEncryption
Issuer: O=Allied-Telesis, CN=AlliedwarePlusCA
Validity
Not Before: Mar 22 07:17:15 2008 GMT
Not After : Mar 20 07:17:15 2018 GMT
Subject: O=Allied-Telesis, CN=Tom
```

Table 62-2: Parameters in the output from the show crypto pki certificates local-radius-all-users command

Parameter	Description
Certificate	Certificate name
Version	Protocol version
Serial Number	Serial number of the certificate
Signature Algorithm	Algorithm used for the certificate signature
Issuer	Subject of issuer creating the certificate
Validity	Validity period
Subject	Subject of the certificate

Related Commands `crypto pki enroll local local-radius-all-users`

show crypto pki certificates user

Use this command to display certificate information for local RADIUS server users.

Syntax `show crypto pki certificates user [<user-name>]`

Parameter	Description
show	Show running system information
crypto	Security Specific
pki	Public Key Infrastructure (PKI)
certificates	Certificate information
user	All local RADIUS server users
<user-name>	user name

Mode Privileged Exec

Example The following command displays Tom's certificate information.

```
awplus# show crypto pki certificates user Tom
```

Output

Figure 62-3: Example output from the show crypto pki certificates user command

```
Certificate: Tom
Version: 3 (0x2)
Serial Number: 13 (0xd)
Signature Algorithm: sha1WithRSAEncryption
Issuer: O=Allied-Telesis, CN=AlliedwarePlusCA
Validity
Not Before: Mar 22 07:17:15 2008 GMT
Not After : Mar 20 07:17:15 2018 GMT
Subject: O=Allied-Telesis, CN=Tom
```

Table 62-3: Parameters in the output from the show crypto pki certificates user command

Parameter	Description
Certificate	Certificate name
Version	Protocol version
Serial Number	Serial number of the certificate
Signature Algorithm	Algorithm used for the certificate signature
Issuer	Subject of issuer creating the certificate
Validity	Validity period
Subject	Subject of the certificate

Related Commands `crypto pki enroll local user`

show crypto pki trustpoints

Use this command to display trustpoint information.

Syntax `show crypto pki trustpoints`

Parameter	Description
show	Show running system information
crypto	Security Specific
pki	Public Key Infrastructure (PKI)
trustpoints	Trustpoint information

Mode Privileged Exec

Example The following command displays trustpoint information.

```
awplus# show crypto pki trustpoint
```

Output

Figure 62-4: Example output from the show crypto pki trustpoints command

```
Trustpoint local:
Subject Name:
CN = AlliedwarePlusCA
o = Allied-Telesis
Serial Number:0C
```

Table 62-4: Parameters in the output from the `show crypto pki trustpoints` command

Parameter	Description
Subject Name	CA certificate subject
Serial Number	Current serial number of CA

Related Commands `crypto pki enroll local`

show radius local-server group

Use this command to display information about the local RADIUS server user group.

Syntax `show radius local-server group [<user-group-name>]`

Parameter	Description
show	Show running system information
radius	RADIUS protocol
local-server	Local RADIUS server
group	RADIUS user group
<user-group-name>	User group name string

Mode Privileged Exec

Example The following command displays Local RADIUS server user group information.

```
awplus# show radius local-server group
```

Output

Figure 62-5: Example output from the show radius local-server group command

Group-Name	Vlan
-----	-----
NetworkOperators	ManagementNet
NormalUsers	CommonNet

Table 62-5: Parameters in the output from the show radius local-server group command

Parameter	Description
Group-Name	Group name
Vlan	VLAN name assigned to the group

Related Commands `group`

show radius local-server nas

Use this command to display information about NAS (Network Access Servers) registered to the local RADIUS server.

Syntax `show radius local-server nas [<ip-address>]`

Parameter	Description
show	Show running system information
radius	RADIUS protocol
local-server	Local RADIUS server
nas	RADIUS NAS
<ip-address>	Specify NAS IP address for show output

Mode Privileged Exec

Example The following command displays NAS information.

```
awplus# show radius local-server nas
```

Output Figure 62-6: Example output from the show radius local-server nas command

NAS-Address	Shared-Key

127.0.0.1	awplus-local-radius-server

Table 62-6: Parameters in the output from the show radius local-server nas command

Parameter	Description
NAS-Address	IP address of NAS
Shared-Key	Shared key used for RADIUS connection

Related Commands `nas`

show radius local-server statistics

Use this command to display statistics about the local RADIUS server.

Syntax show radius local-server statistics

Parameter	Description
show	Show running system information
radius	RADIUS protocol
local-server	Local RADIUS server
statistics	Statistics

Mode Privileged Exec

Examples The following command displays Local RADIUS server statistics.

```
awplus# show radius local-server statistics
```

Output

Figure 62-7: Example output from the show radius local-server statistics command

```
awplus#show radius local-server statistics
Server status : Run (administrative status is enable)
Enabled methods: MAC EAP-MD5 EAP-TLS EAP-PEAP

Successes :0 Unknown NAS :0
Unknown username :0 Invalid passwords :0
Invalid packet from NAS:0 Internal Error :0
Unknown Error :0

NAS : 127.0.0.1
Successes :0 Shared key mismatch :0
Unknown username :0 Invalid passwords :0
Unknown RADIUS message :0 Unknown EAP message :0
Unknown EAP auth type :0 Corrupted packet :0

Username Successes Failures
Alice 0 0
Tom 0 0
```

Related Commands

- clear radius local-server statistics
- radius-server local
- server enable
- server auth-port

show radius local-server user

Use this command to display information about the local RADIUS server user.

Syntax `show radius local-server user [<user-name>]`
`show radius local-server user <user-name> format csv`

Parameter	Description
<user-name>	RADIUS user name. If no user name is specified, information for all users is displayed.
format	File format
csv	Comma separated value format

Mode Privileged Exec

Usage You can send output from any show command, including the CSV format output from this command, to a file. See [“Controlling “show” command output” on page 1.33](#).

Examples The following command displays Local RADIUS server user information for user Tom.

```
awplus# show radius local-server user Tom
```

Figure 62-8: Example output from the show radius local-server user command

User-Name	Password	Group	Vlan
Tom	abcd	NetworkOperators	ManagementNet

The following command displays all Local RADIUS server information for all users.

```
awplus# show radius local-server user
```

The following command displays Local RADIUS server user information for TOM in CSV format.

```
awplus# show radius local-server user Tom format csv
```

Figure 62-9: Example output from the show radius local-server user ... csv command

true,"NetworkOperators","Tom", "abcd",0,2099/01/ 01,1,"","","ManagementNet",false,3600,false,0,"",false,"

Table 62-7: Parameters in the output from the show radius local-server user command

Parameter	Description
User-Name	User name
Password	User password
Group	Group name assigned to the user
Vlan	VLAN name assigned to the user

Related Commands group
 user (RADIUS server)

user (RADIUS server)

Use this command to register a user to the local RADIUS server.

Use the no user command to delete a user from the local RADIUS server.

Syntax `user <radius-user-name> [encrypted] password <user-password> [group <user-group>]`

`no user <radius-user-name>`

Parameter	Description
<code><radius-user-name></code>	RADIUS user name
<code>encrypted</code>	Specifies that the password is being entered in its encrypted form, so that it is not further encrypted. When creating a new user, enter the password in plaintext, and do not use the encrypted parameter. Use the encrypted parameter only when referring to a user that has previously been created. For instance, when adding an existing user from another RADIUS server, use the encrypted parameter, and enter the encrypted version of the password that appears in the output of show commands for the user.
<code><user-password></code>	User password
<code>group</code>	Specify the group for the user
<code><user-group></code>	User group name

Mode RADIUS Server Configuration

Usage RADIUS user names cannot contain question mark (?), space (), or quote (" ") characters. RADIUS user names containing the below characters cannot use certificate authentication:

`/ \ ' $ & ( ) * ; < > ` |`

Certificates cannot be created and exported for RADIUS user names that contain the above characters. We advise you to avoid using these characters in RADIUS user names if you need to use certificate authentication, because you will not be able to create and export certificates.

Example The following commands add user Tom to the local RADIUS server and sets his password to QwerSD.

```
awplus# configure terminal
awplus(config)# radius-server local
awplus(config-radsrv)# user Tom password QwerSD
```


The following commands add user `Tom` to the local RADIUS server user group `NormalUsers` and sets his password `QwerSD`.

```
awplus# configure terminal
awplus(config)# radius-server local
awplus(config-radsrv)# user Tom password QwerSD group
NormalUsers
```

The following commands remove user `Tom` from the local RADIUS server:

```
awplus# configure terminal
awplus(config)# radius-server local
awplus(config-radsrv)# no user Tom
```

Related Commands [group](#)
[show radius local-server user](#)

vlan (RADIUS server)

Use this command to set the VLAN ID or name for the local RADIUS server user group. The VLAN information is used for authentication with the dynamic VLAN feature.

Use the no version of this command to clear the VLAN ID or VLAN name for the local RADIUS server user group.

Syntax `vlan {<vid>|<vlan-name>}`
`no vlan`

Parameter	Description
<code>vlan</code>	Set VLAN information
<code><vid></code>	VLAN ID
<code><vlan-name></code>	VLAN name

Default VLAN information is not set by default.

Mode RADIUS Server Group Configuration

Example The following commands set VLAN ID 200 to the group named NormalUsers:

```
awplus# configure terminal
awplus(config)# radius-server local
awplus(config-radsrv)# group NormalUsers
awplus(config-radsrv-group)# vlan 200
```

The following commands remove VLAN ID 200 from the group named NormalUsers:

```
awplus# configure terminal
awplus(config)# radius-server local
awplus(config-radsrv)# group NormalUsers
awplus(config-radsrv-group)# no vlan
```

Related Commands `group`
 `show radius local-server user`

Chapter 63: Secure Shell (SSH) Introduction



Introduction.....	63.2
Secure Shell on the AlliedWare Plus™ OS	63.2
Configuring the SSH Server	63.4
Creating a Host Key.....	63.4
Enabling the Server.....	63.4
Modifying the Server	63.5
Validating the Server Configuration.....	63.6
Adding SSH Users.....	63.6
Authenticating SSH Users	63.7
Adding a Login Banner	63.7
Monitoring the Server and Managing Sessions.....	63.8
Debugging the Server	63.8
Configuring the SSH Client.....	63.9
Modifying the Client.....	63.9
Adding SSH Servers.....	63.10
Authenticating with a Server.....	63.10
Connecting to a Server and Running Commands.....	63.11
Copying files to and from the Server.....	63.11
Debugging the Client	63.11

Introduction

This chapter describes how the Secure Shell protocol is implemented in the AlliedWare Plus™ OS. It covers:

- support for Secure Shell
- configuring your device as a Secure Shell server and client
- using Secure Shell to manage your device

The AlliedWare Plus™ OS supports SSH version 2 and SSH version 1.5, making it backwards compatible with SSH version 1.

Secure management is important in modern networks, as the ability to easily and effectively manage switches and routers, and the requirement for security, are two almost universal requirements. Protocols such as Telnet and rlogin allow you to manage devices remotely, but can have serious security problems, such as relying on reusable plaintext passwords that are vulnerable to wiretapping or password guessing. The Secure Shell (SSH) protocol is superior to these protocols by providing encrypted and strongly authenticated remote login sessions.

SSH provides sessions between a host running a SSH server and a machine with a SSH client. The AlliedWare Plus™ OS includes both a SSH server and a SSH client to enable you to securely—with the benefit of cryptographic authentication and encryption—manage your devices over an insecure network:

- SSH replaces Telnet for remote terminal sessions; SSH is strongly authenticated and encrypted.
- Remote command execution allows you to send commands to a device securely and conveniently, without requiring a terminal session on the device.
- SSH allows you to connect to another host from your switch or router.

The AlliedWare Plus™ OS supports Secure Copy (SCP) and SSH File Transfer Protocol (SFTP). Both these protocols allow you to securely copy files between your device and remote machines. SFTP provides additional features from SCP, such as allowing you to manipulate the remote files, and halt or resume file transfers without closing the session.

Secure Shell on the AlliedWare Plus™ OS

The AlliedWare Plus™ OS implementation of SSH is compatible with the following RFCs and Internet Drafts:

- The Secure Shell (SSH) Protocol Architecture (RFC 4251)
- The Secure Shell (SSH) Authentication Protocol (RFC 4252)
- The Secure Shell (SSH) Transport Layer Protocol (RFC 4253)
- The Secure Shell (SSH) Connection Protocol (RFC 4254)
- The SSH (Secure Shell) Remote Login Protocol (draft-ylonen-ssh-protocol-00.txt)
- SSH File Transfer Protocol (draft-ietf-secsh-filexfer-13.txt)

Secure Shell supports the following features for both SSH version 2 and SSH version 1.5:

- inbound SSH connections (server mode) and outbound SSH connections (client mode).
- file loading to and from remote machines using Secure Copy, using either the SSH client or SSH server mode.
- RSA public keys with lengths of 768–32768 bits, and DSA keys with lengths of 1024 bits. Keys are stored in a format compatible with other SSH implementations, and mechanisms are provided to copy keys to and from your device.
- Secure encryption, such as Triple DES and Blowfish.
- remote non-interactive shell that allows arbitrary commands to be sent securely to your device, possibly automatically.
- Compression of Secure Shell traffic.
- Tunnelling of TCP/IP traffic.

Secure Shell supports the following features for SSH version 2 only:

- File loading from remote machines using SSH File Transfer Protocol (SFTP).
- a login banner on the SSH server, that displays when SSHv2 clients connect to the server.

Configuring the SSH Server

This section provides instructions on:

- [Creating a Host Key](#)
- [Enabling the Server](#)
- [Modifying the Server](#)
- [Validating the Server Configuration](#)
- [Adding SSH Users](#)
- [Authenticating SSH Users](#)
- [Adding a Login Banner](#)
- [Monitoring the Server and Managing Sessions](#)
- [Debugging the Server](#)

Creating a Host Key

The SSH server uses either an RSA or DSA host key to authenticate itself with SSH clients. This key must be configured before the SSH server can operate. If no host key exists, you cannot start the SSH server.

Once created, the host key is stored securely on the device. To generate a host key for the SSH server, use the command:

```
awplus(config)# crypto key generate hostkey {dsa|rsa|rsa1} [<768-32768>]
```

This command has two parameters for creating RSA keys. The `rsa` parameter creates a host key for SSH version 2 sessions only. To create a host key for SSH version 1 sessions, use the `rsa1` parameter.

To destroy a host key, use the command:

```
awplus(config)# crypto key destroy hostkey {dsa|rsa|rsa1}
```

To display a host key stored on your device, use the command:

```
awplus(config)# show crypto key hostkey [dsa|rsa|rsa1]
```

Enabling the Server

You must enable the SSH server before connections from SSH, SCP, and SFTP clients are accepted. When the SSH server is disabled it rejects connections from SSH clients. The SSH server is disabled by default on your device.

To enable the SSH server, use the command:

```
awplus(config)# service ssh [ip|ipv6]
```

To disable the SSH server, use the command:

```
awplus(config)# no service ssh [ip|ipv6]
```

When enabled, the SSH server allows SCP and SFTP sessions by default. To disable these services, use the commands:

```
awplus(config)# no ssh server scp
```

```
awplus(config)# no ssh server sftp
```

This allows you to reject SCP or SFTP file transfer requests, while still allowing Secure Shell connections. To re-enable SCP and SFTP services, use the command:

```
awplus(config)# ssh server scp
```

```
awplus(config)# ssh server sftp
```

Modifying the Server

To modify the SSH version that the server supports, or the TCP port that the server listens to for incoming sessions, use the command:

```
awplus(config)# ssh server {[v1v2|v2only]<1-65535>}
```

The server listens on port 22 for incoming sessions, and supports both SSH version 2 and SSH version 1, by default.

To modify session and login timeouts on the SSH server, and the number of unauthenticated connections the server allows, use the command:

```
awplus(config)# ssh server {[session-timeout <0-3600>] [login-timeout <1-600>]  
[max-startups <1-128>]}
```

The SSH server waits 60 seconds for a client to authenticate itself, by default. You can alter this waiting time by using the login-timeout parameter. If the client is still not authenticated after the set timeout, then the SSH server disconnects the session.

The SSH server only allows only 10 unauthenticated SSH sessions at any point in time, by default. You can modify the number of unauthenticated sessions it allows, by using the max-startups parameter.

Once a client has authenticated, the SSH session does not time out, by default. Use the session-timeout parameter to set a maximum time period the server waits before deciding that a session is inactive and terminating it

For example, to set the session timeout to 600 seconds, the login timeout to 30 seconds, and the maximum number of concurrent unauthenticated sessions to 5, use the command::

```
awplus(config)# ssh server session-timeout 600 login-timeout  
30 max-startups 5
```

To remove the configured session timeout, login timeout, or maximum startups, use the command:

```
awplus(config)# no ssh server session-timeout login-timeout  
max-startups
```

Validating the Server Configuration

To validate the SSH server configuration, use the command:

```
awplus(config)# show running-config ssh
```

Adding SSH Users

The SSH server requires you to register SSH users. Users that are not registered cannot access the SSH server. Ensure first that you have defined the user in the Authorized User Database of your device. To add a new user, use the command:

```
awplus(config)# username USERNAME (privilege 1-15) password  
PASSWORD
```

To register a user with the SSH server, use the command:

```
awplus(config)# ssh server allow-users <username_pattern> [<hostname_pattern>]
```

Registered entries can contain just the username, or the username with some host details, such as an IP address range. Additionally you can specify a range of users or hostname details by using an asterisk to match any string of characters. For example, to allow any user from the IP range 192.168.1.1 to 192.168.1.255, use the command:

```
awplus(config)# ssh server allow-users * 192.168.1.*
```

To display the list of allowed users, use the command:

```
awplus# show ssh server allow-users
```

To delete an entry from the list of allowed users, use the command:

```
awplus(config)# no ssh server allow-users <username_pattern>  
[<hostname_pattern>]
```

The SSH server also contains a list of denied users. The server checks all incoming sessions against this list and denies any matching session, regardless of whether the session matches an entry in the allowed users list. To add an entry to the list of denied users, use the command:

```
awplus(config)# ssh server deny-users <username_pattern> [<hostname_pattern>]
```

This allows you to deny specific users from a range of allowed users. For example, to deny a user with the IP address 192.168.1.12, use the command:

```
awplus(config)# ssh server deny-users * 192.168.1.12
```

To display the database of denied users, use the command:

```
awplus# show ssh server deny-users
```


To delete a client from the database of denied users, use the command:

```
awplus(config)# no ssh server deny-users <username_pattern>
[<hostname_pattern>]
```

Authenticating SSH Users

SSH users can use either their password or public key authentication to authenticate themselves with the SSH server. To use public key authentication, copy the user's public key file from their client device to the SSH server. To associate the key with a user, use the command:

```
awplus(config)# crypto key pubkey-chain userkey <username> [<filename>]
```

For example, to associate the file key.pub with the user "langley", use the command:

```
awplus(config)# crypto key pubkey-chain userkey langley
key.pub
```

To add a key as text into the terminal for user "geoff", first enter the command:

```
awplus(config)# crypto key pubkey-chain userkey geoff
```

then paste or type the key in as text.

You can add multiple keys for the same user. To display the list of public keys associated with a user, use the command:

```
awplus(config)# show crypto key pubkey-chain userkey <username> [<1-65535>]
```

The <1-65535> parameter allows you to display an individual key.

To delete a key associated with a user from your device, use the command:

```
awplus(config)# no crypto key pubkey-chain userkey <username> <1-65535>
```

Adding a Login Banner

You can add a login banner to the SSH server for sessions with SSH version 2 clients. The server displays the banner to clients before the login prompt. To set the login banner's message, use the command:

```
awplus(config)# banner login
```

then enter your message and use Ctrl+D to finish.

To view the configured login banner, use the command:

```
awplus# show banner login
```

To remove the configured message for the login banner, use the command:

```
awplus(config)# no banner login
```

Monitoring the Server and Managing Sessions

To display the current status of the SSH server, use the command:

```
awplus# show ssh server
```

To display the current status of SSH sessions on your device, use the command:

```
awplus# show ssh
```

Note that this displays both SSH server and SSH client sessions that your Allied Telesis device is running. Use this command to view the unique identification number assigned to each incoming or outgoing SSH session. You need the ID number when terminating a specific session from your device.

To terminate a session, or all sessions, use the command:

```
awplus# clear ssh {<1-65535>|all}
```

Debugging the Server

Information which may be useful for troubleshooting the SSH server is available using the SSH debugging function. You can enable server debugging while the SSH server is functioning. Use the command:

```
awplus# debug ssh server [brief|full]
```

To disable SSH server debugging, use the command:

```
awplus# no debug ssh server
```

Configuring the SSH Client

This section provides instructions on:

- [Modifying the Client](#)
- [Adding SSH Servers](#)
- [Authenticating with a Server](#)
- [Connecting to a Server and Running Commands](#)
- [Copying files to and from the Server](#)
- [Debugging the Client](#)

Modifying the Client

You can configure a selection of variables when using the SSH client. Note that the following configuration commands apply only to client sessions initiated after the command. The configured settings are not saved; after you have logged out from the SSH client, the client returns to using the default settings. Use the command:

```
awplus(config)# ssh client {port <1-65535>|version {1|2}|session-timeout  
                        <0-3600>|connect-timeout <1-600>}
```

The SSH client uses TCP port 22, by default. You can change the TCP port for the remote SSH server by using the port parameter.

The client supports both SSH version 1 and version 2 sessions, by default. To change the SSH client to only use a specific SSH version for sessions, for example SSH version 1, use the version parameter.

The client terminates sessions that are not established after 30 seconds, by default. You can change this time period by using the session-timeout parameter.

Once the client has authenticated with a server, the client does not time out the SSH session, by default. Use the session-timeout parameter to set a maximum time period the client waits before deciding that a session is inactive and terminating the session.

To modify the SSH client so that it uses port 2000 for sessions, and supports only SSH version 1 connections, use the command:

```
awplus(config)# ssh client port 2000 version 1
```

To modify the SSH client so that unestablished sessions time out after 60 seconds, and inactive sessions time out after 100 seconds, use the command:

```
awplus(config)# ssh client session-timeout 100  
                connect-timeout 100
```

To remove the configured port, SSH version, session timeout, and connection timeout settings, use the command:

```
awplus(config)# no ssh client port version session-timeout  
                connect-timeout
```

Adding SSH Servers

SSH servers identify themselves using a host key (see [“Creating a Host Key”](#) on page 63.4). Before the SSH client establishes a session with a SSH server, it confirms that the host key sent by the server matches its database entry for the server. If the database does not contain a host key for the server, then the SSH client requires you to confirm that the host key sent from the server is correct.

To add an SSH server to the client's database, use the command:

```
awplus(config)# crypto key pubkey-chain knownhosts <hostname>
{dsa|rsa|rsa1}
```

To display the SSH servers in the client's database, use the command:

```
awplus# show crypto key pubkey-chain knownhosts [<1-65535>]
```

To remove an entry in the database, use the command:

```
awplus(config)# no crypto key pubkey-chain knownhosts
<1-65535>
```

Authenticating with a Server

You can authenticate your session with a server by either using a password, or using RSA or DSA public key authentication. To use public key authentication, you must generate a pair of keys, one private and one public, and copy the public key onto the SSH server.

To generate an RSA or DSA set of private and public keys for an SSH user, use the command:

```
awplus(config)# crypto key generate userkey <username> {dsa|rsa|rsa1}
[<768-32768>]
```

You can generate one key of each encryption type per user on your client. When authenticating with an SSH server that supports SSH version 1 only, you must use a key generated by the `rsa1` parameter.

To copy the public key onto the SSH server, you must display the key onscreen. To display the public key associated with a user, use the command:

```
awplus# show crypto key userkey <username> [dsa|rsa|rsa1]
```

To display the public keys set for other users, you must specify their username. Only users with the highest privilege setting can use this command to view the keys of other users.

To delete a public and private pair of keys associated with a user, use the command:

```
awplus(config)# crypto key destroy userkey <username> {dsa|rsa|rsa1}
```

Connecting to a Server and Running Commands

To connect to a remote SSH server and execute a command, use the command:

```
awplus# ssh [ip|ipv6][{user <username>|port <1-65535>|version {1|2}}]
<hostname> [<line>]
```

By default, the SSH client attempts to use SSH version 2 with the SSH server. If this fails, the client uses SSH version 1.

For example, to connect to the SSH server at 192.168.1.2 as user “john”, and execute the command “show sys”, use the command:

```
awplus# ssh user john 192.168.1.2 “show sys”
```

Copying files to and from the Server

You can use either the SCP or SFTP client to transfer files from a remote SSH server. Use the command:

```
awplus# copy <source-url> <destination-url>
```

For example, to use SFTP to load a file from the SSH server 192.168.1.2, onto the flash memory of your device, use the command:

```
awplus# copy sftp://192.168.1.2/key.pub flash
```

To upload files to the SSH server, you must use SCP. For example, to upload the file bobskey.pub as the user “bob”, use the command:

```
awplus# copy flash:/bobskey.pub scp://bob@192.168.1.2
```

For more information see [Chapter 6, Creating and Managing Files](#).

Debugging the Client

Information which may be useful for troubleshooting the SSH client is available using the SSH debugging function. You can enable client debugging while the SSH client is functioning. Use the command:

```
awplus# debug ssh client [brief|full]
```

To disable SSH client debugging, use the command:

```
awplus# no debug ssh client
```


Chapter 64: Secure Shell (SSH) Configuration



SSH Server Configuration Example.....	64.2

SSH Server Configuration Example

This chapter provides a Secure Shell server configuration example. For more information about the SSH server, see [Chapter 63, Secure Shell \(SSH\) Introduction](#). For detailed information about the commands used to configure the SSH server, see [Chapter 65, Secure Shell \(SSH\) Commands](#).

The following example configures a SSH server where:

- the SSH server uses RSA encryption
- the SSH server is compatible with both SSH version 1 and version 2 clients
- three SSH users are configured: Manager, John and Asuka. “Manager” can connect from only a defined range of hosts, while “john” and “asuka” can SSH from all hosts
- the SSH users use RSA private and public key authentication

This example shows how to create RSA encryption keys, configure the Secure Shell server, and register users to make Secure Shell connections to your device.

Step 1: Login as a highest Privileged User.

To create the keys and add users, you must login as a privileged user.

Step 2: Create encryption keys.

Two RSA private keys are required before enabling the Secure Shell server for each type of SSH version. Use the commands:

```
awplus(config)#crypto key generate hostkey rsa
awplus(config)#crypto key generate hostkey rsal
```

To verify the key creation, use the command:

```
awplus#show crypto key hostkey
```

Step 3: Enable the Secure Shell server.

Enable Secure Shell on the device using the command:

```
awplus(config)#service ssh
```

Modify the SSH server settings as desired. For example, to set the login-timeout to 60, and the session-timeout to 3600, use the commands:

```
awplus(config)#ssh server session-timeout 3600 login-timeout 60
```

To verify the server configuration, use the command:

```
awplus#show ssh
```

Step 4: Create SSH users.

In order to connect and execute commands, you must register users in the SSH user database, and in the User Authentication Database of the device.

To create the users “john” and “asuka” in the User Authentication Database, use the commands:

```
awplus(config)#username john privilege 15 password secret
awplus(config)#username asuka privilege 15 password very-secret
```


To register “john” and “asuka” as SSH clients, use the commands:

```
awplus(config)#ssh server allow-users john
```

```
awplus(config)#ssh server allow-users asuka
```

To register “manager” as an SSH client so that can only connect from the IP address 192.168.1.1, use the command:

```
awplus(config)#ssh server allow-users manager 192.168.1.1
```

Step 5: Set up Authentication.

SSH users cannot connect unless the server can authenticate them. There are two ways to authenticate an SSH session: password authentication, and RSA or DSA private/public key authentication. When using password authentication, the user must supply their User Authentication Database password.

To use private/public key authentication, copy the public keys for each user onto the device. To copy the files onto flash from the key directory of an attached TFTP server, use the command:

```
awplus#copy tftp://key/john.pub flash:/john.pub
```

```
awplus#copy tftp://key/asuka.pub flash:/asuka.pub
```

To associate the key file with each user, use the command:

```
awplus(config)#crypto key pubkey-chain userkey john john.pub
```

```
awplus(config)#crypto key pubkey-chain userkey asuka asuka.pub
```

```
awplus(config)#crypto key pubkey-chain userkey manager  
manager.pub
```


Chapter 65: Secure Shell (SSH) Commands

Command List	65.2
banner login (SSH)	65.2
clear ssh	65.3
crypto key destroy hostkey	65.4
crypto key destroy userkey	65.5
crypto key generate hostkey	65.6
crypto key generate userkey	65.7
crypto key pubkey-chain knownhosts	65.8
crypto key pubkey-chain userkey	65.10
debug ssh client	65.11
debug ssh server	65.12
service ssh	65.13
show banner login	65.14
show crypto key hostkey	65.15
show crypto key pubkey-chain knownhosts	65.16
show crypto key pubkey-chain userkey	65.17
show crypto key userkey	65.18
show running-config ssh	65.19
show ssh	65.20
show ssh client	65.21
show ssh server	65.22
show ssh server allow-users	65.23
show ssh server deny-users	65.24
ssh	65.25
ssh client	65.27
ssh server	65.29
ssh server allow-users	65.31
ssh server authentication	65.32
ssh server deny-users	65.33
ssh server scp	65.34
ssh server sftp	65.34

Command List

This chapter provides an alphabetical reference for commands used to configure Secure Shell (SSH). For more information, see [Chapter 63, Secure Shell \(SSH\) Introduction](#), and [Chapter 64, Secure Shell \(SSH\) Configuration](#).

banner login (SSH)

This command configures a login banner on the SSH server. This displays a message on the remote terminal of the SSH client before the login prompt. SSH client version 1 does not support this banner.

To add a banner, first enter the command `banner login`, and hit [Enter]. Write your message. You can use any character and spaces. Use Ctrl+D at the end of your message to save the text and re-enter the normal command line mode.

The banner message is preserved if the device restarts.

The `no` form deletes the login banner from the device.

Syntax `banner login`
 `no banner login`

Mode Global Configuration

Default No banner is defined by default.

Examples To set a login banner message, use the command:

```
awplus(config)#banner login
Type CNTL/D to finish.
... banner message comes here ...
^D
awplus(config)#
and enter the message. Use Ctrl+D to finish.
To remove the login banner message, use the command:
awplus(config)#no banner login
```

Related Commands [show banner login](#)

clear ssh

This command deletes Secure Shell sessions currently active on the device. This includes both incoming and outgoing sessions. The deleted sessions are closed. You can only delete an SSH session if you are a system manager or the user who initiated the session. If all is specified then all active SSH sessions are deleted.

Syntax `clear ssh {<1-65535>|all}`

Parameters	Description
<1-65535> <i>or</i>	The sessions that you wish to delete. Specify a session ID <1-65535> to delete a specific session. Specify all to delete all SSH sessions.
all	Default: no default

Mode Privileged Exec

Examples To stop the current SSH session 123, use the command:

```
awplus#clear ssh 123
```

To stop all SSH sessions active on the device, use the command:

```
awplus#clear ssh all
```

Related Commands [service ssh](#)
[ssh](#)

crypto key destroy hostkey

This command deletes the existing public and private keys of the SSH server. Note that for an SSH server to operate it needs at least one set of hostkeys configured before an SSH server is started.

Syntax `crypto key destroy hostkey {dsa|rsa|rsa1}`

Parameters	Description
dsa or rsa or rsa 1	The algorithm type of the configured public and private key. Default: no default
dsa	Deletes the existing DSA public and private keys.
rsa	Deletes the existing RSA public and private keys configured for SSH version 2 connections.
rsa1	Deletes the existing RSA public and private keys configured for SSH version 1 connections.

Mode Global Configuration

Example To destroy the RSA host key used for SSH version 2 connections, use the command:

```
awplus(config)#crypto key destroy hostkey rsa
```

Related Commands [crypto key generate hostkey](#)
[service ssh](#)

crypto key destroy userkey

This command destroys the existing public and private keys of an SSH user configured on the device.

Syntax `crypto key destroy userkey <username> {dsa|rsa|rsa1}`

Parameters	Description
<username>	Name of the user whose userkey you are destroying. The username must begin with a letter. Valid characters are all numbers, letters, and the underscore, hyphen and full stop symbols.
dsa or rsa or rsa1	The algorithm type of the public and private key pair. Default: no default
	dsa Deletes the existing DSA userkey.
	rsa Deletes the existing RSA userkey configured for SSH version 2 connections.
	rsa1 Deletes the existing RSA userkey for SSH version 1 connections.

Mode Global Configuration

Examples To destroy the RSA user key for the SSH user `remoteuser`, use the command:

```
awplus(config)#crypto key destroy userkey remoteuser rsa
```

Related Commands [crypto key generate hostkey](#)
[show ssh](#)
[show crypto key hostkey](#)

crypto key generate hostkey

This command generates public and private keys for the SSH server using either an RSA or DSA cryptography algorithm. You must define a host key before enabling the SSH server. Start SSH server using the service ssh command. If a host key exists with the same cryptography algorithm, this command replaces the old host key with the new key.

This command is not saved in the device configuration. However, the device saves the keys generated by this command in the non-volatile memory.

Syntax `crypto key generate hostkey {dsa|rsa|rsa1} [<768-32768>]`

Parameters	Description
dsa or rsa or rsa1	The algorithm type of the public and private key pair. Default: no default
dsa	Creates a DSA hostkey. Both SSH version 1 and 2 connections can use the DSA hostkey.
rsa	Creates an RSA hostkey for SSH version 2 connections.
rsa1	Creates an RSA hostkey for SSH version 1 connections.
<768-32768>	The length in bits of the generated key. The default is 1024 bits.

Mode Global Configuration

Default 1024 bits is the default key length. The DSA algorithm supports 1024 bits.

Examples To generate an RSA host key for SSH version 2 connections that is 2048 bits in length, use the command:

```
awplus(config)#crypto key generate hostkey rsa 2048
```

To generate DSA host key, use the command:

```
awplus(config)#crypto key generate dsa
```

Related Commands [crypto key destroy hostkey](#)
[service ssh](#)
[show crypto key hostkey](#)

crypto key generate userkey

This command generates public and private keys for an SSH user using either an RSA or DSA cryptography algorithm. To use public key authentication, copy the public key of the user onto the remote SSH server.

This command is not saved in the device configuration. However, the device saves the keys generated by this command in the non-volatile memory.

Syntax `crypto key generate userkey <username> {dsa|rsa|rsa1} [<768-32768>]`

Parameters	Description
<username>	Name of the user that the user key is generated for. The username must begin with a letter. Valid characters are all numbers, letters, and the underscore, hyphen and full stop symbols.
dsa or rsa or rsa1	The algorithm type of the public and private key pair. Default: no default
	dsa Creates a DSA userkey. Both SSH version 1 and 2 connections can use a key created with this command.
	rsa Creates an RSA userkey for SSH version 2 connections.
	rsa1 Creates an RSA userkey for SSH version 1 connections.
<768-32768>	The length in bits of the generated key. The DSA algorithm supports only 1024 bits. Default: 1024

Mode Global Configuration

Examples To generate a 2048-bits RSA user key for SSH version 2 connections for the user “bob”, use the command:

```
awplus(config)#crypto key generate userkey bob rsa 2048
```

To generate a DSA user key for the user “lapo”, use the command:

```
awplus(config)#crypto key generate userkey lapo dsa
```

Related Commands `crypto key destroy userkey`
`show crypto key userkey`

crypto key pubkey-chain knownhosts

This command adds a public key of the specified SSH server to the known host database on your switch. The SSH client on your switch uses this public key to verify the remote SSH server.

The key is retrieved from the server. Before adding a key to this database, check that the key sent to you is correct.

If the server's key changes, or if your SSH client does not have the public key of the remote SSH server, then your SSH client will inform you that the public key of the server is unknown or altered.

The no form deletes the public key of the specified SSH server from the known host database on your device.

Syntax `crypto key pubkey-chain knownhosts [ip|ipv6] <hostname> [rsa|dsa|rsa1]`

`no crypto key pubkey-chain knownhosts <1-65535>`

Parameter	Description
no	Negate a command or reset a command to its default
crypto	Security Specific Commands
key	Key management
pubkey-chain	Public key chain
knownhosts	Add or delete the public key of a remote SSH server
ip	Keyword used prior to specifying an IPv4 address
ipv6	Keyword used prior to specifying an IPv6 address
<hostname>	IPv4/IPv6 address or hostname of a remote server in the format a.b.c.d for an IPv4 address, or in the format x:x::x:x for an IPv6 address
rsa	Specify the RSA public key of the server to be added to the known host database.
dsa	Specify the DSA public key of the server to be added to the known host database.
rsa1	Specify the SSHv1 public key of the server to be added to the known host database.
<1-65535>	Specify a key identifier when removing a key using the no parameter.

Mode Privilege Exec

Default If no cryptography algorithm is specified, then rsa is used as the default cryptography algorithm.

Usage This command adds a public key of the specified SSH server to the known host database on the switch. The key is retrieved from the server. The remote SSH server is verified by using this public key. The user is requested to check the key is correct before adding it to the database.

If the remote server's host key is changed, or if the device does not have the public key of the

remote server, then SSH clients will inform the user that the public key of the server is altered or unknown.

Example To add the RSA host key of the remote SSH host IPv4 address 192.0.2.11 to the known host database, use the command:

```
awplus# crypto key pubkey-chain knownhosts 192.0.2.11
```

To delete the second entry in the known host database, use the command:

```
awplus# no crypto key pubkey-chain knownhosts 2
```

Validation Commands `show crypto key pubkey-chain knownhosts`

crypto key pubkey-chain userkey

This command adds a public key for an SSH user onto the SSH server. This allows the server to support public key authentication for the user. When configured, the user can access the SSH server without providing a password from the remote host.

You should import the public key file from the client node. The device can read the data from a file on the flash or user terminal.

To add a key as text into the terminal, first enter the command `crypto key pubkey-chain userkey USERNAME`, and hit [Enter]. Enter the key as text. Use Ctrl+D at the end to save the text and re-enter the normal command line mode.

The `no` form removes a public key for the specified SSH user that has been added to the public key chain. When a user's public key is removed, the user can no longer login using public key authentication.

Syntax `crypto key pubkey-chain userkey <username> [<filename>]`
`no crypto key pubkey-chain userkey <username> <1-65535>`

Parameters	Description
<code><username></code>	Name of the user that the SSH server associates the key with. The username must begin with a letter. Valid characters are all numbers, letters, and the underscore, hyphen and full stop symbols. Default: no default
<code><filename></code>	Filename of a key saved in flash. Valid characters are any printable character. You can add a key as a hexadecimal string directly into the terminal if you do not specify a filename.
<code><1-65535></code>	The key ID number of the user's key. Specify the key ID to delete a key.

Mode Global Configuration mode

Examples To add a public key for the user `graydon` from the file `key.pub`, use the command:

```
awplus(config)#crypto key pubkey-chain userkey graydon key.pub
```

To add a public key for the user `tamara` from the terminal, use the command:

```
awplus(config)#crypto key pubkey-chain userkey tamara
```

and enter the key. Use Ctrl+D to finish.

To remove the first key entry from the public key chain of the user `john`, use the command:

```
awplus(config)#crypto key pubkey-chain userkey john 1
```

Related Commands [show crypto key pubkey-chain userkey](#)

debug ssh client

This command enables the SSH client debugging facility. When enabled, any SSH, SCP and SFTP client sessions send diagnostic messages to the login terminal.

The no form disables the SSH client debugging facility. This stops the SSH client from generating diagnostic debugging message.

SSH client debugging is disabled by default.

Syntax `debug ssh client [brief|full]`
`no debug ssh client`

Parameter	Description
brief or full	Changes the amount of debugging information sent to the terminal. Specifying brief enables brief debug mode. Specifying full enables full debug mode. Not specifying either of these options enables normal debug mode. Default: normal

Mode Global Configuration and Privileged Exec

Examples To start SSH client debugging, use the command:

```
awplus#debug ssh client
```

To start SSH client debugging with extended output, use the command:

```
awplus#debug ssh client full
```

To disable SSH client debugging, use the command:

```
awplus#no debug ssh client
```

Related Commands `debug ssh server`
`show ssh client`

debug ssh server

This command enables the SSH server debugging facility. When enabled, the SSH server sends diagnostic messages to the system log. To display the debugging messages on the terminal, use the terminal monitor command.

The no form disables the SSH server debugging facility. This stops the SSH server from generating diagnostic debugging messages.

SSH server debugging is disabled by default.

Syntax `debug ssh server [brief|full]`
`no debug ssh server`

Parameter	Description
brief or full	Changes the amount of debugging information sent to the terminal. Specifying brief enables brief debug mode. Specifying full enables full debug mode. Not specifying either of these options enables normal debug mode. Default: normal

Mode Global Configuration and Privileged Exec

Examples To start SSH server debugging, use the command:

```
awplus#debug ssh server
```

To start SSH server debugging with extended output, use the command:

```
awplus#debug ssh server full
```

To disable SSH server debugging, use the command:

```
awplus#no debug ssh server
```

Related Commands [debug ssh client](#)
[show ssh server](#)

service ssh

This command enables the Secure Shell server on the device. Once enabled, connections coming from SSH clients are accepted.

SSH server needs a host key before it starts. If an SSHv2 host key does not exist, then this command fails. If SSHv1 is enabled but a host key for SSHv1 does not exist, then SSH service is unavailable for version 1.

The no form disables the Secure Shell server. When the Secure Shell server is disabled, connections from SSH, SCP, and SFTP clients are not accepted. This command does not affect existing SSH sessions. To terminate existing sessions, use the [clear ssh](#) command.

Syntax `service ssh [ip|ipv6]`
 `no service ssh [ip|ipv6]`

Mode Global Configuration

Default The Secure Shell server is disabled by default. Both IPv4 and IPv6 Secure Shell server are enabled when you issue `service ssh` without specifying the optional `ip` or `ipv6` parameters.

Examples To enable both the IPv4 and the IPv6 Secure Shell server, use the command:

```
awplus(config)#service ssh
```

To enable the IPv4 Secure Shell server only, use the command:

```
awplus(config)#service ssh ip
```

To enable the IPv6 Secure Shell server only, use the command:

```
awplus(config)#service ssh ipv6
```

To disable both the IPv4 and the IPv6 Secure Shell server, use the command:

```
awplus(config)#no service ssh
```

To disable the IPv4 Secure Shell server only, use the command:

```
awplus(config)#no service ssh ip
```

To disable the IPv6 Secure Shell server only, use the command:

```
awplus(config)#no service ssh ipv6
```

Related Commands [crypto key generate hostkey](#)
 [show running-config ssh](#)
 [show ssh server](#)
 [ssh server allow-users](#)
 [ssh server deny-users](#)

show banner login

This command displays the banner message configured on the device. The banner message is displayed to the remote user before user authentication starts.

Syntax `show banner login`

Mode Exec, Privileged Exec, Global Configuration, Interface Configuration, Line Configuration

Example To display the current login banner message, use the command:

```
awplus#show banner login
```

Related Commands [banner login \(SSH\)](#)

show crypto key hostkey

This command displays the SSH host keys generated by RSA and DSA algorithm.

A host key pair (public and private keys) is needed to enable SSH server. The private key remains on the device secretly. The public key is copied to SSH clients to identify the server

Syntax `show crypto key hostkey [dsa|rsa|rsa1]`

Parameter	Description
dsa or rsa or rsa1	The public key you wish to display, identified by its algorithm. Default: displays all keys
dsa	Displays the DSA algorithm public key.
rsa	Displays the RSA algorithm public key for SSH version 2 connections.
rsa1	Displays the RSA algorithm public key for SSH version 1 connections.

Mode Global Configuration and Privileged Exec

Output Figure 65-1: Example output from the **show crypto key hostkey** command

Type	Bits	Fingerprint
rsa	2058	4e:7d:1d:00:75:79:c5:cb:c8:58:2e:f9:29:9c:1f:48
dsa	1024	fa:72:3d:78:35:14:cb:9a:1d:ca:1c:83:2c:7d:08:43
rsa1	1024	e2:1c:c8:8b:d8:6e:19:c8:f4:ec:00:a2:71:4e:85:8b

Table 65-1: Parameters in output of the show crypto key hostkey command

Parameter	Meaning
Type	Algorithm used to generate the key.
Bits	Length in bits of the key.
Fingerprint	Checksum value for the public key.

Examples To show the public keys generated on the device for SSH server, use the command:

```
awplus#show crypto key hostkey
```

To display the RSA public key of the SSH server, use the command:

```
awplus#show crypto key hostkey rsa
```

Related Commands [crypto key destroy hostkey](#)
[crypto key generate hostkey](#)

show crypto key pubkey-chain knownhosts

This command displays the list of public keys maintained in the known host database on the device.

Syntax `show crypto key pubkey-chain knownhosts [<1-65535>]`

Parameter	Description
<1-65535>	Key identifier for a specific key. Displays the public key of the entry if specified. Default: displays all keys

Mode Privileged Exec

Output Figure 65-2: Example output from the show crypto key public-chain knownhosts command

No	Hostname	Type	Fingerprint
1	172.16.23.1	rsa	c8:33:b1:fe:6f:d3:8c:81:4e:f7:2a:aa:a5:be:df:18
2	172.16.23.10	rsa	c4:79:86:65:ee:a0:1d:a5:6a:e8:fd:1d:d3:4e:37:bd
3	3ffe::1	dsa	61:90:92:ba:da:33:b8:08:52:32:08:3b:f2:48:1b:19
4	5ffe:1053:ac21:ff00:0101:bcd:f:ffff:0001	rsa1	af:4e:b4:a2:26:24:6d:65:20:32:d9:6f:32:06:ba:57

Table 65-2: Parameters in output of the show crypto key public-chain knownhosts command

Parameter	Meaning
No	Number ID of the key.
Hostname	Host name of the known SSH server.
Type	The algorithm used to generate the key.
Fingerprint	Checksum value for the public key.

Examples To display public keys of known SSH servers, use the command:

```
awplus#show crypto key pubkey-chain knownhosts
```

To display the key data of the first entry in the known host data, use the command:

```
awplus#show crypto key pubkey-chain knownhosts 1
```

Related Commands [crypto key pubkey-chain knownhosts](#)

show crypto key pubkey-chain userkey

This command displays the public keys registered with the SSH server for SSH users. These keys allow remote users to access the device using public key authentication. By using public key authentication, users can access the SSH server without providing password.

Syntax `show crypto key pubkey-chain userkey <username> [<1-65535>]`

Parameter	Description
<username>	User name of the remote SSH user whose keys you wish to display. The username must begin with a letter. Valid characters are all numbers, letters, and the underscore, hyphen and full stop symbols. Default: no default
<1-65535>	Key identifier for a specific key. Default: displays all keys

Mode Privileged Exec

Output [Figure 65-3: Example output from the show crypto key public-chain userkey command](#)

```
No Type Bits Fingerprint
-----
1 dsa 1024 2b:cc:df:a8:f8:2e:8f:a4:a5:4f:32:ea:67:29:78:fd
2 rsa 2048 6a:ba:22:84:c1:26:42:57:2c:d7:85:c8:06:32:49:0e
```

Table 65-3: Parameters in output of the show crypto key userkey command

Parameter	Meaning
No	Number ID of the key.
Type	The algorithm used to generate the key.
Bits	Length in bits of the key.
Fingerprint	Checksum value for the key.

To display the public keys for the user “manager” that are registered with the SSH server, use the command:

```
awplus#show crypto key pubkey-chain userkey manager
```

Related Commands [crypto key pubkey-chain userkey](#)

show crypto key userkey

This command displays the public keys created on this device for the specified SSH user.

Syntax `show crypto key userkey <username> [dsa|rsa|rsa1]`

Parameter	Description
<username>	User name of the local SSH user whose keys you wish to display. The username must begin with a letter. Valid characters are all numbers, letters, and the underscore, hyphen and full stop symbols.
dsa or rsa or rsa1	The public key you wish to display, identified by its algorithm type. Default: displays all of the specified user's keys
dsa	Displays the DSA public key
rsa	Displays the RSA public key used for SSH version 2 connections.
rsa1	Displays the RSA key used for SSH version 1 connections.

Mode Privileged Exec

Output Figure 65-4: Example output from the show crypto key userkey command

```

Type Bits      Fingerprint
-----
rsa  2048      e8:d6:1b:c0:f4:b6:e6:7d:02:2e:a9:d4:a1:ca:3b:11
rsa1 1024      12:25:60:95:64:08:8e:a1:8c:3c:45:1b:44:b9:33:9b

```

Table 65-4: Parameters in output of the show crypto key userkey command

Parameter	Meaning
Type	The algorithm used to generate the key.
Bits	Length in bits of the key.
Fingerprint	Checksum value for the key.

Examples To show the public key generated for the user, use the command:

```
awplus#show crypto key userkey manager
```

To store the RSA public key generated for the user manager to the file "user.pub", use the command:

```
awplus#show crypto key userkey manager rsa > manager-rsa.pub
```

Related Commands `crypto key generate userkey`

show running-config ssh

This command displays the current running configuration of Secure Shell (SSH).

Syntax show running-config ssh

Mode Privileged Exec

Output Figure 65-5: Example output from the show running-config ssh command

```
!  
ssh server session-timeout 600  
ssh server login-timeout 30  
ssh server allow-users manager 192.168.1.*  
ssh server allow-users john  
ssh server deny-user john*.a-company.com  
ssh server
```

Table 65-5: Parameters in output of the show running-config ssh command

Parameter	Meaning
ssh server	SSH server is enabled.
ssh server v2	SSH server is enabled and only support SSHv2.
ssh server <port>	SSH server is enabled and listening on the specified TCP port.
no ssh server scp	SCP service is disabled.
no ssh server sftp	SFTP service is disabled.
ssh server session-timeout	Configure the server session timeout.
ssh server login-timeout	Configure the server login timeout.
ssh server max-startups	Configure the maximum number of concurrent sessions waiting authentication.
no ssh server authentication password	Password authentication is disabled.
no ssh server authentication publickey	Public key authentication is disabled.
ssh server allow-users	Add the user (and hostname) to the allow list.
ssh server deny-users	Add the user (and hostname) to the deny list.

Example To display the current configuration of SSH, use the command:

```
awplus#show running-config ssh
```

Related Commands service ssh
show ssh server

show ssh

This command displays the active SSH sessions on the device, both incoming and outgoing.

Syntax `show ssh`

Mode Privileged Exec

Output Figure 65-6: Example output from the show ssh command

```
Secure Shell Sessions:
ID  Type Mode   Peer Host      Username      State      Filename
-----
414 ssh  server 172.16.23.1    root          open
456 ssh  client 172.16.23.10   manager       user-auth
459 scp  client 172.16.23.12   root          download    550dev_.awd
463 ssh  client 5ffe:33fe:5632:ffbb:bc35:ddee:0101:ac51
                                manager       user-auth
```

Table 65-6: Parameters in output of the show ssh command

Parameter	Meaning																						
ID	Unique identifier for each SSH session.																						
Type	Session type; either SSH, SCP, or SFTP.																						
Mode	Whether the device is acting as an SSH client (client) or SSH server (server) for the specified session.																						
Peer Host	The hostname or IP address of the remote server or client.																						
Username	Login user name of the server.																						
State	The current state of the SSH session. One of: <table border="1"> <tr> <td>connecting</td><td>The device is looking for a remote server.</td></tr> <tr> <td>connected</td><td>The device is connected to the remote server.</td></tr> <tr> <td>accepted</td><td>The device has accepted a new session.</td></tr> <tr> <td>host-auth</td><td>host-to-host authentication is in progress.</td></tr> <tr> <td>user-auth</td><td>User authentication is in progress.</td></tr> <tr> <td>authenticated</td><td>User authentication is complete.</td></tr> <tr> <td>open</td><td>The session is in progress.</td></tr> <tr> <td>download</td><td>The user is downloading a file from the device.</td></tr> <tr> <td>upload</td><td>The user is uploading a file from the device.</td></tr> <tr> <td>closing</td><td>The user is terminating the session.</td></tr> <tr> <td>closed</td><td>The session is closed.</td></tr> </table>	connecting	The device is looking for a remote server.	connected	The device is connected to the remote server.	accepted	The device has accepted a new session.	host-auth	host-to-host authentication is in progress.	user-auth	User authentication is in progress.	authenticated	User authentication is complete.	open	The session is in progress.	download	The user is downloading a file from the device.	upload	The user is uploading a file from the device.	closing	The user is terminating the session.	closed	The session is closed.
connecting	The device is looking for a remote server.																						
connected	The device is connected to the remote server.																						
accepted	The device has accepted a new session.																						
host-auth	host-to-host authentication is in progress.																						
user-auth	User authentication is in progress.																						
authenticated	User authentication is complete.																						
open	The session is in progress.																						
download	The user is downloading a file from the device.																						
upload	The user is uploading a file from the device.																						
closing	The user is terminating the session.																						
closed	The session is closed.																						
Filename	Local filename of the file that the user is downloading or uploading.																						

Example To display the current SSH sessions on the device, use the command:

```
awplus#show ssh
```

Related Commands `clear ssh`

show ssh client

This command displays the current configuration of the Secure Shell client.

Syntax `show ssh client`

Mode Privileged Exec

Output Figure 65-7: Example output from the **show ssh client** command

```
Secure Shell Client Configuration
-----
Port                : 22
Version             : 2,1
Connect Timeout     : 30 seconds
Session Timeout     : 0 (off)
Debug               : NONE
```

Table 65-7: Parameters in output of the show ssh client command

Parameter	Meaning
Port	SSH server TCP port where the SSH client connects to. The default is port 22.
Version	SSH server version; either "1", "2" or "2,1".
Connect Timeout	Time in seconds that the SSH client waits for an SSH session to establish. If the value is 0, the connection is terminated when it reaches the TCP timeout.
Debug	Whether debugging is active on the client.

Example To display the current configuration for SSH clients on the login shell, use the command:

```
awplus#show ssh client
```

Related Commands [show ssh server](#)

show ssh server

This command displays the current configuration of the Secure Shell server.

Note that changes to the SSH configuration affects only new SSH sessions coming from remote hosts, and does not affect existing sessions.

Syntax `show ssh server`

Mode Privileged Exec

Output Figure 65-8: Example output from the **show ssh server** command

```
Secure Shell Server Configuration
-----
SSH Server           : Enabled
Port                 : 22
Version              : 2
Services             : scp, sftp
User Authentication  : publickey, password
Idle Timeout         : 60 seconds
Maximum Startups     : 10
Debug                : NONE
```

Table 65-8: Parameters in output of the show ssh server command

Parameter	Meaning
SSH Server	Whether the Secure Shell server is enabled or disabled.
Port	TCP port where the Secure Shell server listens for connections. The default is port 22.
Version	SSH server version; either "1", "2" or "2,1".
Services	List of the available Secure Shell service; one or more of SHELL, SCP or SFTP.
Authentication	List of available authentication methods.
Login Timeout	Time (in seconds) that the SSH server will wait the SSH session to establish. If the value is 0, the client login will be terminated when TCP timeout reaches.
Idle Timeout	Time (in seconds) that the SSH server will wait to receive data from the SSH client. The server disconnects if this timer limit is reached. If set at 0, the idle timer remains off.
Maximum Startups	The maximum number of concurrent connections that are waiting authentication. The default is 10.
Debug	Whether debugging is active on the server.

Examples To display the current configuration of the Secure Shell server, use the command:

```
awplus#show ssh server
```

Related Commands `show ssh`
`show ssh client`

show ssh server allow-users

This command displays the user entries in the allow list of the SSH server.

Syntax `show ssh server allow-users`

Mode Privileged Exec

Output Figure 65-9: Example output from the **show ssh server allow-users** command

Username	Remote Hostname (pattern)
awplus	192.168.*
john	
manager	*.alliedtelesis.com

Table 65-9: Parameters in output of the show ssh server allow-users command

Parameter	Meaning
Username	User name that is allowed to access the SSH server.
Remote Hostname (pattern)	IP address or hostname pattern of the remote client. The user is allowed requests from a host that matches this pattern. If no hostname is specified, the user is allowed from all hosts.

Example To display the user entries in the allow list of the SSH server, use the command:

```
awplus(config)#show ssh server allow-users
```

Related Commands [ssh server allow-users](#)
[ssh server deny-users](#)

show ssh server deny-users

This command displays the user entries in the deny list of the SSH server. The user in the deny list is rejected to access the SSH server. If a user is not included in the access list of the SSH server, the user is also rejected.

Syntax `show ssh server deny-users`

Mode Privileged Exec

Output Figure 65-10: Example output from the **show ssh server deny-user** command

Username	Remote Hostname (pattern)
john	*.b-company.com
manager	192.168.2.*

Table 65-10: Parameters in output of the show ssh server deny-user command

Parameter	Meaning
Username	The user that this rule applies to.
Remote Hostname (pattern)	IP address or hostname pattern of the remote client. The user is denied requests from a host that matches this pattern. If no hostname is specified, the user is denied from all hosts.

Example To display the user entries in the deny list of the SSH server, use the command:

```
awplus(config)#show ssh server deny-users
```

Related Commands `ssh server allow-users`
`ssh server deny-users`

ssh

This command initiates a Secure Shell connection to a remote SSH server.

If the server requests a password for the user login, the user needs to type in the correct password on "Password:" prompt.

SSH client identifies the remote SSH server by its public key registered on the client device. If the server identification is changed, server verification fails. If the public key of the server has been changed, it is required that the public key of the server should be explicitly added to the known host database.

Note: *Note that any hostname specified with ssh cannot begin with a hyphen (-) character.*

Syntax `ssh [ip|ipv6][{user <username>|port <1-65535>|version {1|2}}]
<hostname> [<line>]`

Parameter	Description
ip	Specify IPv4 SSH.
ipv6	Specify IPv6 SSH.
user	Login user. If user is specified, the username is used for login to the remote SSH server when user authentication is required. Otherwise the current user name is used. <username> User name to login on the remote server.
port	SSH server port. If port is specified, the SSH client connects to the remote SSH server with the specified TCP port. Other- wise, the client port configured by "ssh client" command or the default TCP port (22) is used. <1-65535> TCP port.
version	SSH client version. If version is specified, the SSH client supports only the specified SSH version. By default, SSH client uses SSHv2 first. If the server does not support SSHv2, it will try SSHv1. The default version can be configured by "ssh client" command. 1 Use SSH version 1. 2 Use SSH version 2.
<hostname>	IPv4/IPv6 address or hostname of a remote server in the format a . b . c . d for an IPv4 address, or in the format x : x : : x : x for an IPv6 address corresponding to the ip or ipv6 optional keywords used. Note that any hostname specified with ssh cannot begin with a hyphen (-) character.
<line>	Command to execute on the remote server. If a command is specified, the command is executed on the remote SSH server and the session is disconnected when the remote command finishes.

Mode Exec and Privileged Exec

Examples To login to the remote SSH server at 192.0.2.5, use the command:

```
awplus# ssh ip 192.0.2.5
```

To login to the remote SSH server at 192.0.2.5 as user manager, use the command:

```
awplus# ssh ip user manager 192.0.2.5
```

To login to the remote SSH server at 192.0.2.5 that is listening TCP port 2000, use the command:

```
awplus# ssh port 2000 192.0.2.5
```

To login to the remote SSH server with example_host using IPv6 session, use the command:

```
awplus# ssh ipv6 example_host
```

To run the cmd command on the remote SSH server at 192.0.2.5, use the command:

```
awplus# ssh ip 192.0.2.5 cmd
```

Related Commands

- [crypto key generate userkey](#)
- [crypto key pubkey-chain knownhosts](#)
- [debug ssh client](#)
- [ssh client](#)

ssh client

This command modifies the default configuration parameters of the Secure Shell (SSH) client. The configuration is used for any SSH client on the device to connect to remote SSH servers. Any parameters specified on SSH client explicitly override the default configuration parameters.

The change affects the current user shell only. When the user exits the login session, the configuration does not persist. This command does not affect existing SSH sessions.

The `no` form resets configuration parameters of the Secure Shell (SSH) client changed by the `ssh client` command, and restores the default values.

This command does not affect the existing SSH sessions.

Syntax `ssh client {port <1-65535>|version {1|2}|session-timeout <0-3600>|connect-timeout <1-600>}`

`no ssh client {port|version|session-timeout|connect-timeout}`

Parameter	Description				
port	The default TCP port of the remote SSH server. If an SSH client specifies an explicit port of the server, it overrides the default TCP port. Default: 22 <1-65535> TCP port number.				
version	The SSH version used by the client for SSH sessions. The SSH client supports both version 2 and version 1 Default: version 2 Note: SSH version 2 is the default SSH version. SSH client supports SSH version 1 if SSH version 2 is not configured using a <code>ssh version</code> command. <table> <tr> <td>1</td><td>SSH clients on the device supports SSH version 1 only.</td></tr> <tr> <td>2</td><td>SSH clients on the device supports SSH version 2 only</td></tr> </table>	1	SSH clients on the device supports SSH version 1 only.	2	SSH clients on the device supports SSH version 2 only
1	SSH clients on the device supports SSH version 1 only.				
2	SSH clients on the device supports SSH version 2 only				
session-timeout	The global session timeout for SSH sessions. If the session timer lapses since the last time an SSH client received data from the remote server, the session is terminated. If the value is 0, then the client does not terminate the session. Instead, the connection is terminated when it reaches the TCP timeout. Default: 0 (session timer remains off) <0-3600> Timeout in seconds.				
connect-timeout	The maximum time period that an SSH session can take to become established. The SSH client terminates the SSH session if this timeout expires and the session is still not established. Default: 30 <1-600> Timeout in seconds.				

Mode Privileged Exec

Examples To configure the default TCP port for SSH clients to 2200, and the session timer to 10 minutes, use the command:

```
awplus# ssh client port 2200 session-timeout 600
```

To configure the connect timeout of SSH client to 10 seconds, use the command:

```
awplus# ssh client connect-timeout 10
```

To restore the connect timeout to its default, use the command:

```
awplus# no ssh client connect-timeout
```

Related Commands [show ssh client](#)
[ssh](#)

ssh server

This command modifies the configuration of the SSH server. Changing these parameters affects new SSH sessions connecting to the device.

The no form restores the configuration of a specified parameter to its default value. The change affects the SSH server immediately if the server is running. Otherwise, the configuration is used when the server starts.

To enable the SSH server, use the [service ssh](#) command.

Syntax

```
ssh server {[v1v2|v2only] [<1-65535>]}
ssh server {[session-timeout <0-3600>] [login-timeout <1-600>]
[max-startups <1-128>]}
no ssh server {[session-timeout] [login-timeout] [max-startups]}
```

Parameter	Description
v1v2 or v2only	The SSH versions that the server supports. Default: v1v2
v1v2	Supports both SSHv2 and SSHv1client connections.
v2only	Supports SSHv2 client connections only.
<1-65535>	The TCP port number that the server listens to for incoming SSH sessions. Default: 22
session- timeout	There is a maximum time period that the server waits before deciding that a session is inactive and should be terminated. The server considers the session inactive when it has not received any data from the client, and when the client does not respond to keep alive messages. Default: 0 (session timer remains off)
<0-3600>	Timeout in seconds.
login- timeout	The maximum time period the server waits before disconnecting an unauthenticated client. Default: 60
<1-600>	Timeout in seconds.
max- startups	The maximum number of concurrent unauthenticated connections the server accepts. When the number of SSH connections awaiting authentication reaches the limit, the server drops any additional connections until authentication succeeds or the login timer expires for a connection. Default: 10
<1-128>	Number of sessions.

Mode Global Configuration

Example To configure the session timer of SSH server to 10 minutes, use the command:

```
awplus(config)#ssh server session-timeout 600
```

To configure the login timeout of SSH server to 30 seconds, use the command:

```
awplus(config)#ssh server login-timeout 30
```

To limit the number of SSH client connections waiting authentication from SSH server to 3, use the command:

```
awplus(config)#ssh server max-startups 3
```

To set max-startups parameters of SSH server to the default configuration, use the command:

```
awplus(config)#no ssh server max-startups
```

To support the Secure Shell server with TCP port 2200, use the command:

```
awplus(config)#ssh server 2200
```

To force the Secure Shell server to support SSHv2 only, use the command:

```
awplus(config)#ssh server v2only
```

To support both SSHv2 and SSHv1, use the command:

```
awplus(config)#ssh server v1v2
```

Related Commands [show ssh server](#)
 [ssh client](#)

ssh server allow-users

This command adds a username pattern to the allow list of the SSH server. If the user of an incoming SSH session matches the pattern, the session is accepted.

When there are no registered users in the server's database of allowed users, the SSH server does not accept SSH sessions even when enabled.

SSH server also maintains the deny list. The server checks the user in the deny list first. If a user is listed in the deny list, then the user access is denied even if the user is listed in the allow list.

The no form deletes a username pattern from the allow list of the SSH server. To delete an entry from the allow list, the username and hostname pattern should match exactly with the existing entry.

Syntax

```
ssh server allow-users <username_pattern> [<hostname_pattern>]
no ssh server allow-users <username_pattern> [<hostname_pattern>]
```

Parameter	Description
<username_pattern>	The username pattern that users can match to. An asterisk acts as a wildcard character that matches any string of characters.
<hostname_pattern>	The host name pattern that hosts can match to. If specified, the server allows the user to connect only from hosts matching the pattern. An asterisk acts as a wildcard character that matches any string of characters.

Mode Global Configuration

Example To allow the user john to create an SSH session from any host, use the command:

```
awplus(config)#ssh server allow-users john
```

To allow the user john to create an SSH session from a range of IP address (from 192.168.1.1 to 192.168.1.255), use the command:

```
awplus(config)#ssh server allow-users john 192.168.1.*
```

To allow the user john to create a SSH session from a-company.com domain, use the command:

```
awplus(config)#ssh server allow-users john *.a-company.com
```

To delete the existing user entry john 192.168.1.* in the allow list, use the command:

```
awplus(config)#no ssh server allow-users john 192.168.1.*
```

Related Commands

- show running-config ssh
- show ssh server allow-users
- ssh server deny-users

ssh server authentication

This command enables RSA public-key or password user authentication for SSH Server. Apply the password keyword with the ssh server authentication command to enable password authentication for users. Apply the publickey keyword with the ssh server authentication command to enable RSA public-key authentication for users.

Use the no ssh server authentication command to disable RSA public-key or password user authentication for SSH Server. Apply the password keyword with the no ssh authentication command to disable password authentication for users. Apply the required publickey keyword with the no ssh authentication command to disable RSA public-key authentication for users.

Syntax ssh server authentication {password|publickey}
 no ssh server authentication {password|publickey}

Parameter	Description
password	Specifies user password authentication for SSH server.
publickey	Specifies user publickey authentication for SSH server.

Mode Global Configuration

Default Both RSA public-key authentication and password authentication are enabled by default.

Usage For password authentication to authenticate a user, password authentication for a user must be registered in the local user database or on an external RADIUS server, before using the ssh server authentication password command.

For RSA public-key authentication to authenticate a user, a public key must be added for the user, before using the ssh server authentication publickey command.

Example To enable password authentication for users connecting through SSH, use the commands:

```
awplus#configure terminal
```

```
awplus(config)#ssh server authentication password
```

To enable publickey authentication for users connecting through SSH, use the commands:

```
awplus#configure terminal
```

```
awplus(config)#ssh server authentication publickey
```

To disable password authentication for users connecting through SSH, use the commands:

```
awplus#configure terminal
```

```
awplus(config)#no ssh server authentication password
```

To disable publickey authentication for users connecting through SSH, use the commands:

```
awplus#configure terminal
```

```
awplus(config)#no ssh server authentication publickey
```

Related Commands [crypto key pubkey-chain userkey](#)
 [service ssh](#)
 [show ssh server](#)

ssh server deny-users

This command adds a username pattern to the deny list of the SSH server. If the user of an incoming SSH session matches the pattern, the session is rejected.

SSH server also maintains the allow list. The server checks the user in the deny list first. If a user is listed in the deny list, then the user access is denied even if the user is listed in the allow list.

If a hostname pattern is specified, the user is denied from the hosts matching the pattern.

The no form deletes a username pattern from the deny list of the SSH server. To delete an entry from the deny list, the username and hostname pattern should match exactly with the existing entry.

Syntax

```
ssh server deny-users <username_pattern> [<hostname_pattern>]
no ssh server deny-users <username_pattern> [<hostname_pattern>]
```

Parameter	Description
<username_pattern>	The username pattern that users can match to. The username must begin with a letter. Valid characters are all numbers, letters, and the underscore, hyphen, full stop and asterisk symbols. An asterisk acts as a wildcard character that matches any string of characters.
<hostname_pattern>	The host name pattern that hosts can match to. If specified, the server denies the user only when they connect from hosts matching the pattern. An asterisk acts as a wildcard character that matches any string of characters.

Mode Global Configuration

Example To deny the user john to access SSH login from any host, use the command:

```
awplus(config)#ssh server deny-users john
```

To deny the user john to access SSH login from a range of IP address (from 192.168.2.1 to 192.168.2.255), use the command:

```
awplus(config)#ssh server deny-users john 192.168.2.*
```

To deny the user john to access SSH login from b-company.com domain, use the command:

```
awplus(config)#ssh server deny-users john*.b-company.com
```

To delete the existing user entry john 192.168.2.* in the deny list, use the command:

```
awplus(config)#no ssh server deny-users john 192.168.2.*
```

Related Commands

- show running-config ssh
- show ssh server deny-users
- ssh server allow-users

ssh server scp

This command enables the Secure Copy (SCP) service on the SSH server. Once enabled, the server accepts SCP requests from remote clients.

You must enable the SSH server as well as this service before the device accepts SCP connections. The SCP service is enabled by default as soon as the SSH server is enabled.

The no form disables the SCP service on the SSH server. Once disabled, SCP requests from remote clients are rejected.

Syntax `ssh server scp`
`no ssh server scp`

Mode Global Configuration

Examples To enable the SCP service, use the command:

```
awplus(config)#ssh server scp
```

To disable the SCP service, use the command:

```
awplus(config)#no ssh server scp
```

Related Commands `show running-config ssh`
`show ssh server`

ssh server sftp

This command enables the Secure FTP (SFTP) service on the SSH server. Once enabled, the server accepts SFTP requests from remote clients.

You must enable the SSH server as well as this service before the device accepts SFTP connections. The SFTP service is enabled by default as soon as the SSH server is enabled. If the SSH server is disabled, SFTP service is unavailable.

The no form disables SFTP service on the SSH server. Once disabled, SFTP requests from remote clients are rejected.

Syntax `ssh server sftp`
`no ssh server sftp`

Mode Global Configuration

Examples To enable the SFTP service, use the command:

```
awplus(config)#ssh server sftp
```

To disable the SFTP service, use the command:

```
awplus(config)#no ssh server sftp
```

Related Commands `show running-config ssh`
`show ssh server`

Part 6: Network Availability



- Chapter 66 VRRP Introduction
- Chapter 67 VRRP Commands
- Chapter 68 EPSR Introduction
- Chapter 69 EPSR Commands

Chapter 66: VRRP Introduction



Introduction.....	66.2
Virtual Router Redundancy Protocol	66.3
VRRP Configuration	66.4
VRRP Election and Preempt	66.6
VRRP Authentication.....	66.7
VRRP Debugging.....	66.8
Configuration Examples.....	66.9

Introduction

This chapter describes the Virtual Router Redundancy Protocol (VRRP) feature provided by the switch, and how to configure the switch to participate in a virtual router.

One function of a switch is to act as a gateway to the WAN for hosts on a LAN. On larger LANs, two or more switches may act as the gateway, and hosts use a dynamic routing protocol, such as RIP or OSPF, to determine the gateway switch to use as the next hop in order to reach a specific IP destination. However, there are a number of factors, such as administrative or processing overhead, that may make it undesirable to use a dynamic routing protocol. One alternative is to use static routing; however, if the statically configured first hop switch fails, the hosts on the LAN are unable to communicate with those on the WAN.

The Virtual Router Redundancy Protocol defined in RFC 2338 provides a solution to the problem by combining two or more physical switches into a logical grouping called a *virtual router* (VR). The physical switches then operate together to provide a single logical gateway for hosts on the LAN.

Virtual Router Redundancy Protocol

The virtual router has a virtual MAC address that is known by all its participating switches or routers. The virtual MAC address is derived from the virtual router identifier - a user-defined value from 1 to 255. At the network level, all hosts on the LAN are configured with a common IP address that is used as the first hop. This IP address is typically owned by the virtual router's preferred individual switch or router. When available, this device performs the duties of the virtual router, and is referred to as the *master*. The switch that owns the IP address associated with the virtual router is referred to as the *preferred master*. When a virtual router is configured so that none of the participating switches owns the IP address, the virtual router has no preferred master.

When a switch takes the role of master for a virtual router, it is responsible for the following:

- Responding to ARP packets that contain IP addresses associated with the virtual router. The ARP response contains the virtual MAC address of the virtual router so that the hosts on the LAN associate the virtual MAC address with their configured first-hop IP address.
- Forwarding packets with a destination link layer MAC address equal to the virtual router MAC address.
- Accepting packets addressed to the IP addresses associated with the virtual router, but only if it actually owns the address(es).
- Broadcasting advertisement packets at regular intervals (at the specified advertisement interval) to inform backup switches that it is still acting as the master switch.

In accordance with the RFC standard, a user does not receive a response to ping or Telnet packets sent to the VR address unless the switch owns this address.

Each of the other switches participating in the virtual router is considered to be a backup switch. A switch can be part of several different virtual routers on one LAN, but all the virtual routers must have different virtual router identifiers (VRID). When a switch has the role of backup for a virtual router, it must be able to perform the following tasks:

- Receive advertisement packets from the master and check that the information contained in them is consistent with their own configuration; ignoring and discarding advertisement packets that do not match.
- Assume the role of master for the virtual router if an advertisement packet is not received for a given period, (the master-down time), based on the specified advertisement interval, (for example: `awplus(config-router)# advertisement-interval 5` will set the advertisement-interval to 5 seconds). The master-down time is approximately three times the advertisement interval.
- Assume the role of master if it receives an advertisement packet from another switch with a lower priority than its own, and if preempt mode is on.

If the master switch fails, the backup switch assumes control and starts processing traffic. If a backup switch is about to assume the role of master of the VR because it has not received an advertisement for the master-down period, it first checks the operational status of the interface to which the VR is attached. If the interface is down, it does not enter the master state. Instead, it stays in the backup state and checks the interface again after another master-down period, assuming it does not receive an advertisement during that time.

VRRP Configuration

VRRP is disabled by default. Once you have defined a virtual router session, you must enable VRRP to make the session operational. You can then enable or disable the virtual router as shown:

To enable VRRP

<code>awplus(config)#</code>	
<code>router vrrp 1</code>	Create a new VRRP session on the router and specify the virtual router ID (VRID) for the session.

<code>awplus(config-router)#</code>	
<code>enable</code>	Enable the VRRP session on the switch.

<code>awplus(config-router)#</code>	
<code>exit</code>	Return to the Global Configuration mode.

To disable VRRP

<code>awplus(config)#</code>	
<code>router vrrp 1</code>	Specify an existing VRRP session.

<code>awplus(config-router)#</code>	
<code>disable</code>	Disable the VRRP session on the switch.

<code>awplus(config-router)#</code>	
<code>exit</code>	Return to the Global Configuration mode.

A virtual router must be defined on at least two switches before it operates correctly. Use the following steps to configure virtual routing on a switch: Note that this example assumes that VLAN 2 already exists on the switch. See [“Configuring VLANs” on page 16.3](#).

To configure virtual routing on a switch

<code>awplus#</code>	
<code>configure terminal</code>	Enter the Global Configuration mode.

<code>awplus(config)#</code>	
<code>router vrrp 1</code>	Create a new VRRP session on the router and specify the VRID for the session.

<code>awplus(config-router)#</code>	
<code>virtual-ip 10.10.10.50 master</code>	Set the virtual IP address for the VRRP session. Define the default state (master or backup) of the VRRP router within the virtual router.

<code>awplus(config-router)#</code>	
<code>interface vlan2</code>	Specify the interface (VLAN 2) that will participate in virtual routing.

<code>awplus(config-router)#</code>	
<code>priority 255</code>	Set the VRRP priority for the switch.

To configure virtual routing on a switch(Continued)

```
awplus(config-router)#
    enable    Enable the VRRP session on the switch.
```

```
awplus(config-router)#
    exit      Return to the Global Configuration mode.
```

```
awplus(config)#    Global Configuration mode prompt.
```

To destroy a virtual router on the LAN, it must be removed from all participating switches. Use the following commands to remove a virtual router so that the switch no longer participates in virtual routing.

To remove the virtual router VRRP 1 from a switch

```
awplus#
configure terminal    Enter the Global Configuration mode.
```

```
awplus(config)#
no router vrrp 1      Remove the VRRP session on the switch.
```

```
awplus(config-router)#
    exit              Return to the Global Configuration mode.
```

```
awplus(config)#    Global Configuration mode prompt.
```

Alternatively, you can simply disable the virtual router and retain the configuration.

To disable the router and retain the configuration

```
awplus#
configure terminal    Enter the Global Configuration mode.
```

```
awplus(config)#
router vrrp 1         Select the VRRP session on the switch.
```

```
awplus(config-router)#
    disable            Disable the VRRP session on the switch.
```

```
awplus(config-router)#
    exit              Return to the Global Configuration mode.
```

```
awplus(config)#    Global Configuration prompt.
```

VRRP Election and Preempt

If the switch that is the current VRRP master becomes unavailable, the master role is taken by the switch with the next highest priority. The priority is a value from 1 to 255, with a default of 100. The value 255 is reserved for the switch that owns the virtual router's IP address. The new master takes over all the responsibilities of the original master.

By default, when a switch becomes available that has a higher priority than the master, this switch takes over as master. This is referred to as preempt mode and can be set on or off. Even with preempt mode off, the switch that owns the IP address always becomes the master when available. Preempt mode should be the same for all switches in the virtual router.

If two switches are configured with the same priority and a conflict occurs when they both transition to master simultaneously, the one with the highest IP address has higher priority. Due to timing differences the conflict may not always occur and simply the first switch to respond will become the master.

Hosts on the LAN can continue sending packets to the virtual MAC address they originally associated with the first hop IP address, even though the switch that owns the IP address is not currently available. When the original switch becomes available again, and if it is a preferred switch (i.e. it owns the virtual router IP address) then it resumes the role of master.

Use the following commands to set the priority and preempt mode when you create the virtual router:

To set the priority and preempt mode for VRRP 1

<code>awplus#</code>	
<code>configure terminal</code>	Enter the Global Configuration mode.
<code>awplus(config)#</code>	
<code>router vrrp 1</code>	Select the VRRP session on the switch.
<code>awplus(config-router)#</code>	
<code>priority 255</code>	Set the VRRP priority for the switch
<code>awplus(config-router)#</code>	
<code>preempt true</code>	Select the preempt mode for VRRP 1.
<code>awplus(config-router)#</code>	
<code>enable</code>	Enable the VRRP session on the switch.
<code>awplus(config-router)#</code>	
<code>exit</code>	Return to the Global Configuration mode.
<code>awplus(config)#</code>	Global Configuration prompt

The advertisement interval determines the rate that the master sends its advertisement packets. This rate must be the same value for all switches in the virtual router. The default advertisement interval of 1second can be used for most networks. However, you can modify this interval by using the `advertisement-interval` command, as shown in the following procedure:

To set the advertisement interval to 5 seconds on VRRP1

awplus#	
<code>configure terminal</code>	Enter the Global Configuration mode.
awplus(config)#	
<code>router vrrp 1</code>	Select the VRRP session on the switch.
awplus(config-router)#	
<code>advertisement-interval 5</code>	Set the advertisement interval to 5 seconds.

VRRP Authentication

Each of the switches in the virtual router can be configured for plaintext authentication, or no authentication. Authentication is appropriate where there is either a security risk, or the configuration is complex.

Plaintext password authentication protects against accidental miscommunication and prevents a switch from inadvertently backing up another switch. This kind of miscommunication could occur, for example, where multiple virtual routers exist on the same LAN.

The authentication type and, in the case of plaintext authentication, the password, must be the same for all switches in the virtual router. By default, the virtual router has no authentication. Authentication must be defined against the relevant interface in the interface configuration mode as shown: This example assumes that VLAN 2 already exists on the switch. See [“Configuring VLANs” on page 16.3](#).

To set the authentication string “guest” to VLAN 2

awplus(config)#	
<code>interface vlan2</code>	Specify the interface (vlan2) that will participate in virtual routing.
awplus(config)#	
<code>ip vrrp authentication mode text</code>	Apply text mode authentication to interface vlan2.
awplus(config)#	
<code>ip vrrp authentication string guest</code>	Specify the authentication string or password used by the key.
awplus(config)#	
<code>exit</code>	Return to the Privileged Exec mode prompt
awplus#	Privileged Exec mode prompt

In order to maintain consistent authentication level, each switch in the virtual router must have at least the minimum allowable level of security that meets the network environment.

VRRP Debugging

VRRP debugging displays data that is useful for troubleshooting. To enable or disable debugging use the following commands:

To select and deselect VRRP debugging

<code>awplus#</code>	
<code>configure terminal</code>	Enter the Global Configuration mode.

<code>awplus(config)#</code>	
<code>debug vrrp [all events packet]</code>	Enable the selected debugging type.

<code>awplus(config)#</code>	
<code>no debug vrrp [all events packet]</code>	Disable the selected debugging type.

It is important that all switches involved in a virtual router are configured with the same values for the following:

- VRRP virtual router identifier
- IP address
- advertisement interval
- preempt mode
- authentication type
- password

Inconsistent configuration causes advertisement packets to be rejected and the virtual router cannot perform properly.


Configuration Examples

The following examples show how to configure a virtual router in a LAN:

- Preferred Master with Backup Switch
- Authenticated Virtual Router with No Preferred Master

Master with Backup Switch

This example show how to configure a basic virtual router with a preferred master and a backup.



Switch_A owns the IP address of the virtual router, and always assumes the role of master whenever it is available. Switch_B is the backup, and assumes the role of master, backing up this IP address if A becomes unavailable. No authentication is used for this simple virtual router.

Step 1: Configure Switch_A:

At this point we assume that you have already created VLAN 2 on Switch_A. See [“Configuring VLANs” on page 16.3.](#)

Configure IP

awplus#	
configure terminal	Enter the Global Configuration mode.
awplus(config)#	
hostname Switch_A	Assign a host name to Switch_A.
Switch_A(config)#	
interface vlan2	Specify the interface (vlan2) that will participate in virtual routing.
Switch_A(config)#	
ip address 192.168.1.1/24	Specify the IP address and mask for interface vlan2.

Create the Virtual Router

Switch_A(config)#	
spanning-tree mode stp	Configure STP for interfaces on Switch_A.
Switch_A(config)#	
router vrrp 1	Create a new VRRP session on the router and specify the VRID for the session.
Switch_A(config-router)#	
virtual-ip 192.168.1.1 master	Set the virtual IP address for the VRRP session. Define the default state of the VRRP router within the virtual router.
Switch_A(config-router)#	
interface vlan2	Specify the interface (vlan2) that will participate in virtual routing.
Switch_A(config-router)#	
enable	Enable the VRRP session on the router.
Switch_A(config-router)#	
exit	Exit the Router Configuration mode and enter the Global Configuration mode.
Switch_A(config)#	
exit	Exit the Global Configuration mode and enter the Privileged Exec mode.
Switch_A#	Privileged Exec mode prompt.

Step 2: Configure Switch_B:

At this point we assume that you have already created VLAN 2 on Switch_B. See [“Configuring VLANs” on page 16.3](#).

Configure IP

awplus#	
configure terminal	Enter Global Configuration mode.
awplus(config)#	
hostname Switch_B	Assign a host name to Switch_B.
Switch_B(config)#	
interface vlan2	Specify the interface (vlan2) that will participate in virtual routing.
Switch_B(config)#	
ip address 192.168.1.2/24	Specify the IP address and mask for interface

Create the Virtual Router

Switch_B(config)#	
router vrrp 1	Create a new VRRP session on the router and specify the VRID for the session.
Switch_B(config-router)#	
virtual-ip 192.168.1.1	Set the virtual IP address for the VRRP session.
backup	Define the default state of the VRRP router within the virtual router.
Switch_B(config-router)#	
interface vlan2	Specify the interface (vlan2) that will participate in virtual routing.
Switch_B(config-router)#	
enable	Enable the VRRP session on the router.
Switch_B(config-router)	
exit	Exit the Interface Configuration mode and enter the Global Configuration mode.
Switch_B(config)#	
exit	Return to the Privileged Exec mode.
Switch_B#	Privileged Exec mode prompt.

Authenticated Virtual Router with an Independent Preferred Master

This example shows how to configure a virtual router with its own IP address. The address is not owned by any of the switches participating in the virtual router. Switch A has a higher priority for becoming the master, Switch B has the next highest priority, and Switch C takes the master role when A or B are unavailable. The default preempt mode (preempt on) ensures that the switch with the highest priority (when it is available) always takes the master role from a lower priority switch acting as master. Plaintext authentication protects against accidental misconfiguration.

Although the switch with the highest priority will be master, it is important to remember that when creating VRRP you must also define the default role. In the following example Switch_A will be defined as being the master.

At this point we assume that you have already created VLAN 2 on Switches A, B and C. See [“Configuring VLANs” on page 16.3](#).

Step 1: Configure IP.

On switch_A, add an IP interface to the virtual router.

```
awplus#
configure terminal  Enter Global Configuration mode.

awplus(config)#
hostname Switch_A  Assign a host name to Switch_A.

Switch_A(config)#
interface vlan2    Specify the interface (vlan2) that will participate in
                  virtual routing.

Switch_A(config)#
ip address 192.168.1.1/24  Add the IP address and mask for interface vlan2.
```

On switch_B, add a different IP interface to virtual router.

```
awplus#
configure terminal  Enter Global Configuration mode.

awplus(config)#
hostname Switch_B  Assign a host name to Switch_B.

Switch_B(config)#
interface vlan2    Specify the interface (vlan2) that will participate in
                  virtual routing.

Switch_B(config)#
ip address 192.168.1.2/24  Add the IP address and mask for interface vlan2.
```

On switch_C, add a third IP interface to the virtual router.

awplus#	
configure terminal	Enter Global Configuration mode.
awplus(config)#	
hostname Switch_C	Assign a host name to Switch_C.
Switch_C(config)#	
interface vlan2	Specify the interface (vlan2) that will participate in virtual routing.
Switch_C(config)#	
ip address 192.168.1.3/24	Add the IP address and mask for interface vlan2.

Step 2: Create the virtual router.

On switch A, create virtual router vrrp2 with IP address 192.168.1.4, plaintext authentication with password trip4e, and a high priority.

To configure the virtual router on switch_A

Switch_A#	
configure terminal	Enter the Global Configuration mode.
Switch_A(config)#	
router vrrp2	Create a new VRRP session on the router and specify the VRID for the session.
Switch_A(config)#	
virtual-ip 192.168.1.4 backup	Set the virtual IP address for the VRRP session. Define the default state of the VRRP router within the virtual router.
Switch_A(config)#	
interface vlan2	Specify the interface (vlan2) that will participate in virtual routing.
Switch_A(config)#	
preempt-mode on	Turn on preempt mode.
Switch_A(config)#	
priority 254	Set the VRRP priority of 254 for the switch.
Switch_A(config)#	
enable	Enable VRRP on the switch.
Switch_A(config)#	
interface vlan2	Specify the interface (vlan2) that will participate in virtual routing.
Switch_A(config)#	
ip vrrp authentication mode text	Apply text mode authentication to vlan2.
Switch_A(config)#	
ip vrrp authentication string trip4e	Specify the authentication string trip4e used by the key.

To configure the virtual router on switch_A

Switch_A(config)#	
exit	Return to the Privileged Exec mode prompt.
Switch_A#	Privileged Exec mode prompt.

On switch B, create the same virtual router, but with a lower priority.

To configure the virtual router on switch_B

Switch_B#	
configure terminal	Enter the Global Configuration mode.
Switch_B(config)#	
router vrrp2	Create a new VRRP session on the router and specify the VRID for the session.
Switch_B(config)#	
virtual-ip 192.168.1.4 backup	Set the virtual IP address for the VRRP session. Define the default state of the VRRP router within the virtual router.
Switch_B(config)#	
interface vlan2	Specify the interface (vlan2) that will participate in virtual routing.
Switch_B(config)#	
preempt-mode on	Turn on preempt mode.
Switch_B(config)#	
priority 200	Set the VRRP priority of 200 for the switch.
Switch_B(config)#	
enable	Enable VRRP on the switch.
Switch_B(config)#	
interface vlan2	Specify the interface (vlan2) that will participate in virtual routing.
Switch_B(config)#	
ip vrrp authentication mode text	Apply text mode authentication to vlan2.
Switch_B(config)#	
ip vrrp authentication string trip4e	Specify the authentication string trip4e used by the key.
Switch_B(config)#	
exit	Return to the Privileged Exec mode prompt.
Switch_B#	Privileged Exec mode prompt.

On switch C, create the same virtual router with the default priority of 100.

To configure the virtual router on switch_C

Switch_C#	
configure terminal	Enter the Global Configuration mode.
Switch_C(config)#	
router vrrp2	Create a new VRRP session on the router and specify the VRID for the session.
Switch_C(config)#	
virtual-ip 192.168.1.4 backup	Set the virtual IP address for the VRRP session. Define the default state (master or backup) of the VRRP router within the virtual router.
Switch_C(config)#	
interface vlan2	Specify the interface (vlan2) that will participate in virtual routing.
Switch_C(config)#	
preempt-mode on	Turn on preempt mode.
Switch_C(config)#	
priority 100	Set the VRRP priority of 100 for the switch.
Switch_C(config)#	
enable	Enable VRRP on the switch.
Switch_C(config)#	
interface vlan2	Specify the interface (vlan2) that will participate in virtual routing.
Switch_C(config)#	
ip vrrp authentication mode text	Apply text mode authentication to vlan2.
Switch_C(config)#	
ip vrrp authentication string trip4e	Specify the authentication string trip4e used by the key.
Switch_C(config)#	
exit	Return to the Privileged Exec mode prompt
Switch_C#	Privileged Exec mode prompt

The default preempt mode ensures that the highest priority switch available always takes the master role. However, if there are no significant disadvantages to the lower priority switches having the master role, and if changes where the switch takes the master role are to be avoided (for example, when a high cost is associated with each change) then you should instead set the preempt mode to off.

Chapter 67: VRRP Commands



Command List	67.2
advertisement-interval	67.2
circuit-failover	67.3
debug vrrp	67.4
debug vrrp events	67.4
debug vrrp packet	67.5
disable (VRRP)	67.5
enable (VRRP)	67.6
interface (VRRP)	67.6
ip vrrp authentication mode	67.7
ip vrrp authentication string	67.8
preempt-mode	67.9
priority	67.10
router vrrp	67.11
show debugging vrrp	67.11
show running-config router vrrp	67.12
show vrrp	67.12
show vrrp (session)	67.13
undebug vrrp	67.13
undebug vrrp events	67.14
undebug vrrp packet	67.14
virtual-ip	67.15
vrrp vmac	67.15

Command List

This chapter provides an alphabetical reference for commands used to configure the Virtual Router Redundancy Protocol (VRRP). For more information, see [Chapter 66, VRRP Introduction](#).

For information about modifying or redirecting the output from show commands to a file, see [“Controlling “show” command output” on page 1.33](#).

advertisement-interval

Use this command to configure the advertisement interval of the virtual router. This is the length of time, in seconds, between each advertisement sent from the master to its backup(s).

Use the no advertisement-interval command to remove an advertisement interval of the virtual router, which has been set using the advertisement-interval command.

Syntax advertisement-interval <1-255>
no advertisement-interval

Parameter	Description
<1-255>	Specifies the advertisement interval in seconds. Default advertisement interval is 1 second.

Mode Router Configuration

Default The default advertisement interval is 1 second.

Examples

```
awplus# configure terminal
awplus(config)# router vrrp 3 vlan2
awplus(config-router)# advertisement-interval 6

awplus# configure terminal
awplus(config)# router vrrp 3 vlan2
awplus(config-router)# no advertisement-interval
```


circuit-failover

Use this command to enable the VRRP circuit failover feature.

Use the no parameter with this command to disable this feature.

Syntax `circuit-failover <interface> <1-253>`
`no circuit-failover [<interface> <1-253>]`

Parameter	Description
<interface>	The interface of the router that will participate in the virtual router. Interface must exist on the router.
<1-253>	Delta value. The value by which virtual routers decrement their priority value during a circuit failover event. Configure this value to be greater than the difference of priorities on the master and backup routers.

Mode Router Configuration

Examples

```
awplus# configure terminal
awplus(config)# router vrrp 1 vlan1
awplus(config-router)# circuit-failover vlan2 30

awplus# configure terminal
awplus(config)# router vrrp 1 vlan1
awplus(config-router)# no circuit-failover
```

Related Commands `router vrrp`

debug vrrp

Use this command to specify debugging options for VRRP. The `all` parameter turns on all the debugging options.

Use the `no` parameter with this command to disable this function.

Syntax `debug vrrp [all]`
`no debug vrrp [all]`

Mode Global Configuration and Privileged Exec

Example

```
awplus# configure terminal
awplus(config)# debug vrrp all
```

debug vrrp events

Use this command to specify debugging options for VRRP event troubleshooting.

Use the `no` parameter with this command to disable this function.

Syntax `debug vrrp events`
`no debug vrrp events`

Mode Global Configuration and Privileged Exec

Usage The `debug vrrp events` command enables the display of debug information related to VRRP internal events.

Example

```
awplus# configure terminal
awplus(config)# debug vrrp events
```

debug vrrp packet

Use this command to specify debugging options for VRRP packets.

Use the no parameter with this command to disable this function.

Syntax `debug vrrp packet [send|recv]`
`no debug vrrp packet [send|recv]`

Parameter	Description
send	Specifies the debug option set for sent packets.
recv	Specifies the debug option set for received packets.

Mode Global Configuration and Privileged Exec

Usage The debug vrrp packet command enables the display of debug information related to the sending and receiving of packets.

Example

```
awplus# configure terminal
awplus(config)# debug vrrp packet send
```

disable (VRRP)

Use this command to disable a VRRP session on the router to stop it participating in virtual routing.

Syntax `disable`

Mode Router Configuration

Example

```
awplus# configure terminal
awplus(config)# router vrrp 5 vlan2
awplus(config-router)# disable
```

Related Commands [enable \(VRRP\)](#)

enable (VRRP)

Use this command to enable the VRRP session on the router to make it participate in virtual routing.

Syntax enable

Mode Router Configuration

Usage You must configure the virtual IP address and define the interface for the VRRP session (using the virtual-ip and interface commands) before using this command.

Example

```
awplus# configure terminal
awplus(config)# router vrrp 5
awplus(config-router)# enable
```

Related Commands [disable \(VRRP\)](#)

interface (VRRP)

Use this command define the physical interface that will participate in virtual routing. This interface is used for two purposes - to send/receive advertisement messages and to forward on behalf of the virtual router when in master state. Note that you can also specify the interface within the circuit-failover and the router vrrp commands without specifying the interface later.

Syntax interface <interface>

Parameter	Description
<interface>	Specify the name of the interface that will participate in the virtual routing. Interface must exist on the router.

Mode Router Configuration

Usage Use the no router vrrp command to remove the specified interface from participating in virtual routing.

Example To configure an interface on which VRRP is enabled enter the commands shown below:

```
awplus# configure terminal
awplus(config)# router vrrp 5
awplus(config-router)# interface vlan2
```

Related Commands [router vrrp.](#)

ip vrrp authentication mode

Use this command to enable clear text password authentication used for VRRP packets.

Use the [ip vrrp authentication string](#) command after this command to specify the password.

Use the no ip vrrp authentication command to reset to the default of no text authentication.

Syntax `ip vrrp authentication mode text`
`no ip vrrp authentication mode [text]`

Parameter	Description
text	Specifies the clear text or simple password authentication.

Default No text authentication.

Usage RFC 3768 *Virtual Router Redundancy Protocol (VRRP)* recommends no authentication. VRRP authentication commands are available for backwards compatibility the earlier VRRP RFC 2338. See [“VRRP Authentication” on page 66.7](#) for further information about VRRP Authentication.

Mode Interface Configuration for a VLAN interface.

Example The following example shows text authentication configured on the `vlan2` interface ensuring authentication packets received on this interface.

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip vrrp authentication mode text
```

Related Commands [ip vrrp authentication string](#)

ip vrrp authentication string

Use this command to specify the authentication string or password used by a key.

Use this command after [ip vrrp authentication mode](#) that enables clear text authentication.

Use the no parameter with this command to remove a configured authentication string.

Syntax `ip vrrp authentication string <password>`
`no ip vrrp authentication string`

Parameter	Description
<code><password></code>	the authentication string or password

Mode Interface Configuration for a VLAN interface.

Example In the following example, the interface `vlan2` is configured to have an authentication string as `guest`, any receiving packet in that interface should have the same string as password.

```
awplus# configure terminal
awplus(config)# interface vlan2
awplus(config-if)# ip vrrp authentication mode text
awplus(config-if)# ip vrrp authentication string guest
```

See [“VRRP Authentication” on page 66.7](#) for further information about VRRP Authentication.

Related Commands [ip vrrp authentication mode](#)

preempt-mode

Use this command to configure preempt mode. If set to true, the highest priority backup will always be the master when the default master is unavailable. If set to false, a higher priority backup will not preempt a lower priority backup who is acting as master.

Syntax `preempt-mode true`
`preempt-mode false`

Parameter	Description
true	Preemption enabled. Default is true.
false	Preemption disabled.

Mode Router Configuration

Usage When the master router fails, the backup routers come online in priority order—highest to lowest. Preempt mode means that a higher priority back up router will take over the master role from a lower priority back up. Preempt mode on true allows a higher priority backup router to relieve a lower priority backup router.

See “[VRRP Election and Preempt](#)” on page 66.6 for further information on preempt mode.

Example

```
awplus# configure terminal
awplus(config)# router vrrp 4 vlan2
awplus(config-router)# preempt-mode false
```

Related Commands `circuit-failover`
`priority`

priority

Use this command to configure the VRRP router priority within the virtual router. The highest priority router is Master (unless [preempt-mode](#) is false). Use the `no priority` command to remove the VRRP router priority within the virtual router, which has been set using the `priority` command.

Syntax `priority <1-255>`
`no priority`

Parameter	Description
<1-255>	The priority. For the master router, use 255 for this parameter; otherwise use any number from the range <1-254>.

Mode Router Configuration

Default Default values for priority are: master router = 255; backup = 100.

Example

```
awplus# configure terminal
awplus(config)# vrrp 3 vlan2
awplus(config-router)# priority 101
```

Related Commands [circuit-failover](#)
[preempt-mode](#)

router vrrp

Use this command to configure VRRP. This command allows you to enter the `Router` mode.

Use the `no` parameter with this command to remove the VRRP configuration. Disable the VRRP session before using the `no router vrrp` command.

Syntax `router vrrp <vrid> [<interface>]`
`no router vrrp <vrid> [<interface>]`

Parameter	Description
<code><vrid></code>	<code><1-255></code> The ID of the virtual router session to create.
<code><interface></code>	Specify the name of the interface that will participate in the virtual routing. The interface must exist on the router.

Mode Global Configuration

Example

```
awplus# configure terminal
awplus(config)# router vrrp 5 vlan2
awplus(config-router)#
```

Related Commands [circuit-failover](#)
[interface \(VRRP\)](#)

show debugging vrrp

Use this command to display the set VRRP debugging option.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show debugging vrrp`

Mode Privileged Exec

Example

```
awplus# show debugging vrrp
```

show running-config router vrrp

Use this command to show the configuration for VRRP.

- This command is available only if VRRP is enabled.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax show running-config router vrrp

Mode Privileged Exec, Global Configuration, Line Configuration, and Interface Configuration.

Example

```
awplus# show running-config router vrrp
```

```
!  
router vrrp 2 vlan2  
    circuit-failover vlan1 3  
    advertisement-interval 4  
!
```

show vrrp

Use this command to display information about all VRRP sessions.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax show vrrp

Mode Exec and Privileged Exec

Example

```
awplus# show vrrp
```

```
awplus#show vrrp  
VrId <1>  
State is Master  
Virtual IP is 10.0.0.222 (Not IP owner)  
Interface is vlan2  
Priority is 100  
Advertisement interval is 1 sec  
Preempt mode is TRUE
```

show vrrp (session)

Use this command to display information for a particular VRRP session.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show vrrp <vrid> <interface>`

Parameter	Description
<code><vrid></code>	<code><1-255></code> The virtual router ID for which to display information. Session must already exist.
<code><interface></code>	The interface to display information about, for instance, <code>vlan2</code> .

Mode Exec and Privileged Exec

Usage The following is a sample output from the `show vrrp` command displaying relevant information about VRRP session 1.

```
awplus# show vrrp 1 vlan2
```

```
VRID:          1
  State is Master
  Virtual IP is 10.10.11.250 (Not IP owner)
  Interface is vlan2
  Priority is 100
  Advertisement interval is 1 sec
  Preempt mode is TRUE
```

Example The following command shows information about VRRP session 5 for interface `vlan2`.

```
awplus# show vrrp 5 vlan2
```

undebg vrrp

Use this command to disable all VRRP debugging.

Syntax `undebg vrrp [all]`

Mode Privileged Exec

Example

```
awplus# undebg vrrp all
```

undebg vrrp events

Use this command to disable debugging options for VRRP event troubleshooting.

Syntax `undebg vrrp events`

Mode Privileged Exec

Example

```
awplus# undebg vrrp events
```

undebg vrrp packet

Use this command to disable debugging options for VRRP packets.

Syntax `undebg vrrp packet [send|recv]`

Parameter	Description
send	Disable the debug option set for sent packets.
recv	Disable the debug option set for received packets.

Mode Privileged Exec

Usage The undebg vrrp packet command disables the debugging option set for sent and received VRRP packets.

Example

```
awplus# undebg vrrp packet send
```

virtual-ip

Use this command to set the virtual IP address for the VRRP session. This is the IP address of the virtual router that end hosts set as their default gateway.

Use the no parameter with this command to disable this feature.

Syntax `virtual-ip <ip-address> master`
`virtual-ip <ip-address> backup`
`no virtual-ip`

Parameter	Description
<code><ip-address></code>	The virtual IP address of the virtual router, entered in the format A.B.C.D.
<code>master</code>	Sets the default state of the VRRP router within the Virtual Router as <code>master</code> . For master, the router must own the Virtual IP address.
<code>backup</code>	Sets the default state of the VRRP router within the Virtual Router as <code>backup</code> .

Mode Router Configuration

Example

```
awplus# configure terminal
awplus(config)# router vrrp 5 vlan2
awplus(config-router)# virtual-ip 192.0.2.30 master
```

vrrp vmac

Use this command to enable or disable the Virtual MAC feature.

Syntax `vrrp vmac {enable|disable}`

Mode Global Configuration

Example To enable Virtual MAC enter:

```
awplus# configure terminal
awplus(config)# vrrp vmac enable
```

To disable Virtual MAC enter:

```
awplus# configure terminal
awplus(config)# vrrp vmac disable
```


Chapter 68: EPSR Introduction



Introduction.....	68.2
Ring Components and Operation	68.2
Fault Detection and Recovery.....	68.4
Fault Recovery.....	68.4
Restoring Normal Operation	68.6
Managing Rings with Two Breaks.....	68.7
Recovery When One Break is Restored	68.8
Configuration Examples.....	68.10
Single Domain, Single Ring Network	68.10
Single Ring, Dual Domain Network.....	68.15
EPSR and Spanning Tree Operation	68.16


Introduction

Ethernet Protection Switching Ring (EPSR) is a protection system that prevents loops within Ethernet ring based topologies. EPSR offers a rapid detection and recovery time (in the order of 50 ms, depending on configuration) if a link or node fails. This rapid recovery time makes EPSR a more effective alternative to spanning tree options when using ring-based topologies to create high speed resilient layer two networks.

Ring Components and Operation

EPSR operates only on ring-based topologies. An EPSR ring comprises a series of nodes (Ethernet bridges) connected end to end. The figure below shows a basic ring configuration. A ring comprises one master node and a number of transit nodes. Each node connects to the ring via two ports. On the master node one port is configured to be the primary port and the other, the secondary port.

Figure 68-1: Simple EPSR ring configuration



EPSR instances and domains

Each physical EPSR ring contains one or more EPSR instances. An EPSR instance can be thought of as a component of an EPSR ring existing on a single node. A set of instances across the whole ring is called a "domain." Therefore a ring whose individual nodes each have two instances results in a two domain ring. Each instance contains a control VLAN and a number of data VLANs.

The EPSR control VLAN and its associated data VLANs form a Ring Domain. Although a physical ring can have more than one domain, each domain must operate as a separate logical group of VLANs and must have its own master node. This means that several domains may share the same physical network, but must operate as logically separate VLAN groups.

- Control VLAN** The function of the control VLAN is to monitor the ring domain and maintain its operational functions. To do this it transmits and monitors operational healthcheck messages using EPSR healthcheck control frames. The control VLAN carries no user data.
- Data VLAN** The data VLAN carries the user data around the ring. Several data VLANs can share a common control VLAN.
- Master node** The master node controls the ring operation. It issues healthcheck messages at regular intervals from its primary port and monitors their arrival back at its secondary port - after they have circled the ring. Under normal operating conditions the master node's secondary port is always in the blocking state to all data VLAN traffic. This is to prevent data loops forming within the ring. This port however, operates in the forwarding state for the traffic on the control VLAN. Loops do not occur on the control VLAN because the control messages stop at the secondary port, having completed their path around the ring.
- Transit nodes** The transit nodes operate as conventional Ethernet bridges, but with the additional capability of running the EPSR protocol. This protocol requires the transit nodes to forward the healthcheck messages from the master node, and respond appropriately when a ring fault is detected. The fault condition procedure is explained in [“Fault Detection and Recovery” on page 68.4](#).

Fault Detection and Recovery

EPSR uses the following methods to detect outages in a node or a link in the ring:

- Master node polling fault detection
- Transit node unsolicited fault detection

Master node polling

The master node issues healthcheck messages from its primary port as a means of checking the condition of the EPSR network ring. These messages are sent at regular periods, controlled by the `hellotime` parameter of the [epsr command on page 69.3](#). A failover timer is set each time a healthcheck message leaves the master node's primary port. The timeout value for this timer is set by the `failover` parameter of the [epsr command on page 69.3](#). If the failover timer expires before the transmitted healthcheck message is received by the master node's secondary port, the master node assumes that there is a fault in the ring, and implements its fault recovery procedures. Because this method relies on a timer expiry, its operation is inherently slower than the "transit node unsolicited detection method" described next.

Transit node unsolicited

Transmit note unsolicited fault detection relies on transit nodes detecting faults at their interfaces, and immediately notifying master nodes about the break. When a transit node detects a connectivity loss, it sends a "links down" message over its good link. Because a link spans two nodes, both nodes send the "links down" message back to the master node. These nodes also change their state from "links up" to "links down," and change the state of the port connecting to the broken link, from "forwarding" to "blocking."

Fault Recovery


When the master node detects an outage in the ring by using its detection methods, it does the following:

1. Declares the ring to be in a "failed" state.
2. Unblocks its secondary port to enable the data VLAN traffic to pass between its primary and secondary ports.
3. Flushes its own forwarding database (FDB) for (only) the two ring ports.
4. Sends an EPSR Ring-Down-Flush-FDB control message to all the transit nodes, via both its primary and secondary ports.

Transit nodes respond to the Ring-Down-Flush-FDB message by flushing their forward databases for each of their ring ports. As the data starts to flow in the ring's new configuration, each of the nodes (master and transit) re-learn their layer 2 addresses. During this period, the master node continues to send health check messages over the control VLAN. This situation continues until the faulty link or node is repaired. For a multi-domain ring, this process occurs separately for each domain within the ring.

The following figure shows the flow of control frames under fault conditions.

Figure 68-2: EPSR Fault Detection Messages



Restoring Normal Operation

Transit nodes Once a fault in the ring or node has been rectified, the transit nodes that span the previously faulty link section detect that link connectivity has returned. They then move their appropriate ring port state, from Links-Down to Pre-Forwarding, and await the Ring-Up-Flush control message from the master node.

Once these transit nodes receive the Ring-Up-Flush message, they:

- flush their forward databases for both their ring ports.
- change the state of their ports from blocking to forwarding, which allows data to flow through their previously blocked ring ports.

Note: The transit nodes do not enter the forward state until they have received the Ring-Up-Flush message. This prevents the possibility of a loop condition occurring caused by the transit nodes moving into the forwarding state before the master node secondary port can return to the blocking state. During such a period, the ring would have no ports blocked.


Master node With the link restored, the healthcheck messages that are sent from the primary port of the master node now complete the loop and arrive at the master node's secondary port. The master node restores normal conditions as follows:

1. Declares the ring to be in a “complete” state.
2. Blocks its secondary port for data (non-control) traffic.
3. Flushes its forwarding database for its two ring ports.
4. Sends a Ring-Up-Flush-FDB message from its primary port, to all transit nodes.

Managing Rings with Two Breaks


To restore a link with two breaks you need to run the EPSR Recovery feature. Consider the network shown below:

Figure 68-3: EPSR Ring with Two Breaks



In this situation the ring will attempt to recover as previously described in “Fault Recovery” on page 68.4. This will result in the split-ring operation shown in Figure 68-4 on page 68.7.

Figure 68-4: EPSR Split Ring




In this operational mode each portion of the ring operates as an independent link layer broadcast domain each containing the original data VLANs and control VLAN.

Recovery When One Break is Restored

Figure 68-5 on page 68.8 shows a ring with the link between nodes A and B restored. At this point the ring's behavior will depend on whether the `epsr enhancedrecovery enable` command on page 69.6 has been set.

Figure 68-5: EPSR Ring with One Link Restored




Enhanced Recovery Disabled

With the enhanced recovery feature turned enabled, the Hello messages will now reach the remaining ring break; however from a users perspective, the ring will remain as shown in the split state shown in [Figure 68-5](#).

Enhanced Recovery Enabled

With the enhanced recovery feature turned enabled, switch nodes A and B are able to detect the restored link, and will place all their ring ports in the forwarding state. Although the ring will remain in the “failed” state because of the remaining break; communication between the nodes is restored. The network then operates as shown in [Figure 68-6](#).

Figure 68-6: EPSR Operation in Partially Recovered State



Configuration Examples


This section describes how to configure EPSR in following ways:

- Single Domain, Single Ring Network
- Single Ring, Dual Domain Network
- EPSR and Spanning Tree Operation

Single Domain, Single Ring Network

This example shows a simple single ring, single domain configuration with no connecting lobes.

Figure 68-7: EPSR single domain, single ring network



Configure the Master Node

Step 1: Create the control and data VLANs on the Master Node (bridge-group 1)

<code>awplus#</code>	
<code>configure terminal</code>	Enter the command config mode.
<code>awplus(config)#</code>	
<code>vlan database</code>	Enter the VLAN configuration mode.
<code>awplus(config-vlan)#</code>	
<code>vlan 5 name control_vlan state enable</code>	Enable VLAN 5 called <i>control_vlan</i> on the Master Node. Specifying the enable state allows forwarding of frames on the VLAN-aware node.
<code>awplus(config-vlan)#</code>	
<code>vlan 40 name data_vlan state enable</code>	Enable VLAN 40 called <i>data_vlan</i> on the Master Node. Specifying the enable state allows forwarding of frames on the VLAN-aware node.
<code>awplus(config-vlan)#</code>	
<code>exit</code>	Exit the VLAN configuration mode and enter Configure mode.

Step 2: Add port port1. 0. 1 to these VLANs

<code>awplus(config)#</code>	
<code>interface port1.0.1</code>	Specify the interface (port1.0.1) that you are configuring and enter the Interface mode.
<code>awplus(config-if)#</code>	
<code>switchport mode trunk</code>	Set the switching characteristics of this port to <i>trunk</i> mode.
<code>awplus(config-if)#</code>	
<code>switchport trunk allowed vlan add 5</code>	Enable VLAN 5 on this port.
<code>awplus(config-if)#</code>	
<code>switchport trunk allowed vlan add 40</code>	Enable VLAN 40 on this port.
<code>awplus(config-if)#</code>	
<code>exit</code>	Exit the Interface mode and enter the Configure mode.

Step 3: Add port port1. 0. 2 to these VLANs

<code>awplus(config)# interface port1.0.2</code>	Specify the interface (port1.0.2) that you are configuring and enter the Interface mode.
<code>awplus(config-if)# switchport mode trunk</code>	Set the switching characteristics of this port to <i>trunk</i> mode.
<code>awplus(config-if)# switchport trunk allowed vlan add 5</code>	Enable VLAN 5 on this port.
<code>awplus(config-if)# switchport trunk allowed vlan add 40</code>	Enable VLAN 40 on this port.
<code>awplus(config-if)# exit</code>	Exit the Interface mode and enter the Configure mode.

Step 4: Create the EPSR Instance called “blue” on the master node, make VLAN 5 the control VLAN and port 1.0.1 the primary port. ,

<code>awplus(config)# epsr configuration</code>	Change the CLI mode to epsr
<code>awplus(config-epsr)# epsr blue mode master controlvlan 5 primaryport port1.0.1</code>	Create epsr instance called “blue” on vlan5. Make vlan5 the control vlan Make port 1.0.1 the primary port. Make this node the master.

Step 5: Add a data VLAN to the EPSR Instance called “blue” on the Master Node

<code>awplus(config-epsr)# epsr blue datavlan 40</code>	On epsr instance called “blue” make vlan40 the data vlan.

Step 6: Enable the EPSR Instance called “blue” on the Master Node

<code>awplus(config-epsr)# epsr blue state enable</code>	enable the epsr named blue
<code>awplus(config-epsr)# exit</code>	Exit the epsr mode.

Now you can configure the transit nodes.

Step 7: Create the Control and Data VLANs on a Transit Node

<code>awplus#</code>	
<code>configure terminal</code>	Enter the command config mode.
<code>awplus(config)#</code>	
<code>vlan database</code>	Enter the VLAN configuration mode.
<code>awplus(config-vlan)#</code>	
<code>vlan 5 name control_vlan state enable</code>	Enable VLAN 5 called <i>control_vlan</i> on the Transit Node. Specifying the enable state allows forwarding of frames on the VLAN-aware node.
<code>awplus(config-vlan)#</code>	
<code>vlan 40 name data_vlan state enable</code>	Enable VLAN 40 called <i>data_vlan</i> on the Transit Node. Specifying the enable state allows forwarding of frames on the VLAN-aware node.
<code>awplus(config-vlan)#</code>	
<code>exit</code>	Exit the VLAN configuration mode and enter Configure mode.

Step 8: Add port port1. 0. 1 to the VLANs

<code>awplus(config)#</code>	
<code>interface port1.0.1</code>	Specify the interface (port1.0.1) that you are configuring and enter the Interface mode.
<code>awplus(config-if)#</code>	
<code>switchport mode trunk</code>	Set the switching characteristics of this port to <i>trunk</i> mode.
<code>awplus(config-if)#</code>	
<code>switchport trunk allowed vlan add 5</code>	Enable VLAN 5 on this port.
<code>awplus(config-if)#</code>	
<code>switchport trunk allowed vlan add 40</code>	Enable VLAN 40 on this port.
<code>awplus(config-if)#</code>	
<code>exit</code>	Exit the Interface mode and enter the Configure mode.

Step 9: Add port port1. 0. 2 to the VLANs

<code>awplus(config)#</code>	
<code>interface port1.0.2</code>	Specify the interface (port1.0.2) that you are configuring and enter the Interface mode.

<code>awplus(config-if)#</code>	
<code>switchport mode trunk</code>	Set the switching characteristics of this port to <i>trunk</i> mode.

<code>awplus(config-if)#</code>	
<code>switchport trunk allowed vlan add 5</code>	Enable VLAN 5 on this port.

<code>awplus(config-if)#</code>	
<code>switchport trunk allowed vlan add 40</code>	Enable VLAN 40 on this port.

<code>awplus(config-if)#</code>	
<code>exit</code>	Exit the Interface mode and enter the Configure mode.

Step 10: Create the EPSR Instance called “blue” on a transit node, make VLAN 5 the control VLAN

<code>awplus(config)#</code>	
<code>epsr configuration</code>	Change the CLI mode to epsr

<code>awplus(config-epsr)#</code>	
<code>epsr blue mode transit controlvlan 5</code>	Create epsr instance called “blue” on vlan5. Make vlan5 the control vlan Make this node a transit node.

Step 11: Add a data VLAN to the EPSR Instance called “blue” on the transit node

<code>awplus(config-epsr)#</code>	
<code>epsr blue datavlan 40</code>	On EPSR instance called “blue” make vlan40 the data vlan.

Step 12: Enable the EPSR Instance called “blue” on the transit node

<code>awplus(config-epsr)#</code>	
<code>epsr blue state enable</code>	Enable the EPSR named blue


<code>awplus(config-epsr)#</code>	
<code>exit</code>	Exit the EPSR mode.

Now you can use the same procedure to configure the remaining transit nodes.

Single Ring, Dual Domain Network

This example shows an EPSR configuration where two EPSR domains share the same physical ring. This configuration enables two sets of users to run totally separate layer two networks. Better load distribution around the ring can be achieved by configuring different nodes to be the master for each ring.

Figure 68-8: EPSR single ring network, two domain network.




EPSR and Spanning Tree Operation

EPSR and the Spanning Tree protocol (STP) address data loop prevention, although they do it differently. EPSR is manually configured to explicitly identify which links are broken in the defined ring, whereas STP/RSTP calculates where to break links based on user-provided values (metrics) that are compared to determine the "best" (or lowest cost) paths for data traffic.

At the practical level you can use these two techniques to create complementary hybrid EPSR /STP configurations. This configuration might have a high speed fibre loop topology backbone-controlled and managed using EPSR. Lobes could extend out from each loop node into a user mesh network. Any loops in this mesh network would be controlled and managed using STP/RSTP. Note that EPSR and STP cannot share the same ports.

The following figure shows a basic combined EPSR / STP network.

Figure 68-9: EPSR and spanning tree operation



Chapter 69: EPSR Commands



Command List	69.2
debug epsr	69.2
epsr	69.3
epsr configuration	69.4
epsr datavlan	69.5
epsr enhancedrecovery enable	69.6
epsr mode master controlvlan primaryport	69.7
epsr mode transit controlvlan	69.8
epsr state	69.9
epsr trap	69.10
show debugging epsr	69.11
show epsr	69.11
show epsr word	69.12
show epsr word counters	69.12
show epsr counters	69.13

Command List

This chapter provides an alphabetical reference for commands used to configure EPSR. For more information, see [Chapter 68, EPSR Introduction](#).

For information about modifying or redirecting the output from show commands to a file, see [“Controlling “show” command output” on page 1.33](#).

debug epsr

This command enables EPSR debugging. Use `no debug epsr` to disable EPSR debugging.

Syntax

```
debug epsr {info|msg|pkt|state|all}
no debug epsr {info|msg|pkt|state|all}
```

Parameter	Description
no	Negate a command or set its defaults
debug	Debugging functions (see also 'undebug')
epsr	Ethernet Protection Switching Ring (EPSR)
info	Echo general EPSR information to console. Do not echo general EPSR information to console (when negated)
msg	Echo decoded display of received and transmitted EPSR packets to console. Do not echo decoded display of received and transmitted EPSR packets to console
pkt	Echo raw ASCII display of received and transmitted EPSR packets to console. Do not echo raw ASCII display of received and transmitted EPSR packets to console
state	Echo EPSR state transitions to console
all	Turn on all EPSR debugging

Mode Privileged Exec

Examples To enable state transition debugging, use the command:

```
awplus# debug epsr state
```

To disable EPSR packet debugging, use the command::

```
awplus# no debug epsr pkt
```


epsr

This command sets the timer values for an EPSR instance. It is only valid for master nodes.

The no epsr command destroys an EPSR instance.

Syntax `epsr <epsr> {hellotime <1-32767>|failovertime <2-65535>|
ringflaptime <0-65535>}`

`no epsr name`

Parameter	Description
no	Negate a command or set its defaults
epsr	Ethernet Protection Switching Ring (EPSR).
<epsr>	Name of the EPSR.
hellotime	The interval between transmitting health check messages (1-32767) seconds.
failovertime	The period a master waits for a health check before declaring a broken ring (2-65535) seconds.
ringflaptime	The minimum period that a master must remain in the failed state, (0-65535) seconds.

Mode EPSR Configuration

Examples To set the hellotimer to 3 seconds for the EPSR instance called blue, use the command:

```
awplus(config-epsr)# epsr blue hellotime 3
```

Note: The failovertime must be at least twice the hellotime, or the hellotime must be less than equal to half the failovertime. Do not setting hellotime at or below failovertime.

To destroy an EPSR instance called blue, use the command:

```
awplus(config-epsr)# no epsr blue
```

Related Commands `epsr mode master controlvlan primaryport`
`epsr mode transit controlvlan`
`epsr configuration`
`epsr datavlan`
`epsr state`
`epsr trap`
`show epsr`

epsr configuration

Use this command to enter EPSR Configuration mode so that EPSR can be configured.

Syntax `epsr configuration`

Parameter	Description
<code>epsr</code>	Ethernet Protection Switching Ring (EPSR)
<code>configuration</code>	Configure EPSR settings

Mode Global Configuration

Example To change to EPSR mode, use the command:

```
awplus(config)# epsr configuration
```

Related Commands `epsr mode master control`
`vlan primaryport`
`epsr`
`show epsr`

epsr datavlan

This command adds a data VLAN or a range of VLAN identifiers to a specified EPSR instance.

The no epsr datavlan command removes a data vlan or data vlan range from an EPSR instance.

Syntax

```
epsr <epsr> datavlan {<vlanid>|<vlanid-range>}
no epsr <epsr> datavlan {<vlanid>|<vlanid-range>}
```

Parameter	Description
no	Negate a command or set its defaults
epsr	Ethernet Protection Switching Ring (EPSR)
<name>	Name of the EPSR
datavlan	Adds a data VLAN to be protected by the EPSR instance / Deletes a data VLAN from the EPSR instance (when negated)
<vlanid>	The VLAN's VID - a number between 1 and 4094 excluding the number selected for the control VLAN.
<vlanid-range>	Specified a range of VLAN identifiers using hyphen to separate identifiers.

Mode EPSR Configuration

Usage We suggest setting the epsr controlvlan to vlan2 using the [epsr mode master controlvlan primaryport](#) and [epsr mode transit controlvlan](#) commands, then setting the EPSR data VLAN between to be a value 3 and 4094 using the [epsr datavlan](#) command.

Example To add vlan3 to the EPSR instance called blue, use the command:

```
awplus(config-epsr)# epsr blue datavlan vlan3
```

To add vlan2 and vlan3 to the EPSR instance called blue, use the command:

```
awplus(config-epsr)# epsr blue datavlan vlan2-vlan3
```

To remove vlan3 from the EPSR instance called blue, use the command:

```
awplus(config-epsr)# no epsr blue datavlan vlan3
```

To remove vlan2 and vlan3 from the EPSR instance called blue, use the command:

```
awplus(config-epsr)# no epsr blue datavlan vlan2-vlan3
```

Related Commands

- [epsr mode master controlvlan primaryport](#)
- [epsr mode transit controlvlan](#)
- [show epsr](#)

epsr enhancedrecovery enable

This command enables EPSR's enhanced recovery mode. Enhanced recovery mode enables a ring to apply additional recovery procedures when a ring with more than one break, partially mends. For more information see, [“Managing Rings with Two Breaks” on page 68.7](#).

Syntax `epsr <name> enhancedrecovery enable`

`no epsr enhancedrecovery enable`

The no variant of this command disables the enhancedrecovery mode.

Default is enhancedrecovery mode disabled.

Parameter	Description
<code><name></code>	Name of the EPSR instance

Mode EPSR Configuration

Example To apply enhanced recovery on the EPSR instance called blue, use the command:

```
awplus(config-epsr)# epsr blue enhancedrecovery enable
```

Related Commands [show epsr](#)

epsr mode master controlvlan primaryport

This command creates a master EPSR instance.

Syntax `epsr <name> mode master controlvlan <2-4094> primaryport <port>`

Parameter	Description
epsr	Ethernet Protection Switching Ring (EPSR)
<name>	Name of the EPSR instance
mode	Determines whether the node is acting as a master or transit node
master	Sets switch to be the master node for the named EPSR ring
controlvlan	The VLAN that will transmit EPSR control frames.
<2-4094>	VLAN id
primaryport	Primary port for the EPSR instance
<port>	The primary port. The port may be a switch port (e.g., port1.1.4) or a static channel group (e.g., sa3). It cannot be a dynamic (LACP) channel group.

Note: The software allows you to configure more than two ports or static channel groups to the control VLAN within a single switch or stacked node. However, we advise against this because in certain situations it can produce unpredictable results.

If the control VLAN contains more than two ports (or static channels) an algorithm selects the two ports or channels with the lowest number to be the ring ports. However if the switch has only one channel group is defined to the control vlan, EPSR will not operate on the secondary port.

Epsr does not support Dynamic link aggregation (LACP).

Mode EPSR Configuration

Example To create a master EPSR instance called blue with vlan2 as the control VLAN and port1.0.1 as the primary port, use the command:

```
awplus(config-epsr)# epsr blue mode master controlvlan vlan2
primaryport port1.0.1
```

Related Commands `epsr mode transit controlvlan`
`show epsr`

epsr mode transit controlvlan

This command creates a transit EPSR instance.

Syntax `epsr <epsr> mode transit controlvlan <2-4094>`

Parameter	Description
epsr	Ethernet Protection Switching Ring (EPSR)
<word>	Name of the EPSR
mode	Determines whether the node is acting as a master or transit node
transit	Sets switch to be the transit node for the named EPSR ring
controlvlan	The VLAN that will transmit EPSR control
<2-4094>	VLAN id

Note: The software allows you to configure more than two ports or static channel groups to the control VLAN within a single switch or stacked node. However, we advise against this because in certain situations it can produce unpredictable results.

If the control VLAN contains more than two ports (or static channels) an algorithm selects the two ports or channels with the lowest number to be the ring ports. However if the switch has only one channel group is defined to the control vlan, EPSR will not operate on the secondary port.

Epsr does not support Dynamic link aggregation (LACP).

Mode EPSR Configuration

Example To create a transit EPSR instance called blue with vlan2 as the control VLAN, use the command:

```
awplus(config-epsr)# epsr blue mode transit controlvlan vlan2
```

Related Commands `epsr mode master controlvlan primaryport`
 `epsr mode transit controlvlan`
 `show epsr`

epsr state

This command enables or disables an EPSR instance.

Syntax `epsr <epsr> state {enabled|disabled}`

Parameter	Description
<epsr>	The name of the EPSR ring instance.
state	The operational state of the ring: one of, enabled or disabled.

Mode EPSR Configuration

Example To enable the EPSR instance called 'blue', use the command:

```
awplus(config-epsr)# epsr blue state enabled
```

Related Commands [epsr mode master controlvlan primaryport](#)
[epsr mode transit controlvlan](#)

epsr trap

This command enables SNMP traps for an EPSR instance. The traps will be sent when the EPSR instance changes state.

The no epsr trap command disables SNMP traps for an EPSR instance. The traps will no longer be sent when the EPSR instance changes state.

Syntax `epsr <epsr> trap`

Parameter	Description
no	Negate a command or set its defaults
epsr	Ethernet Protection Switching Ring (EPSR)
<epsr>	Name of the EPSR
trap	Enables SNMP trap for the EPSR instance / Disables SNMP trap for the EPSR instance (when negated)

Mode EPSR Configuration

Example To enable traps for the EPSR instance called blue, use the command:

```
awplus(config-epsr)# epsr blue trap
```

To disable traps for the EPSR instance called blue, use the command:

```
awplus(config-epsr)# no epsr blue trap
```

Related Commands `epsr mode master controlvlan primaryport`
`epsr mode transit controlvlan`
`show epsr`

show debugging epsr

This command shows the debugging modes enabled for EPSR.

Syntax `show debugging epsr`

Parameter	Description
show	Show running system information
debugging	Debugging functions (see also 'undebug')
epsr	Ethernet Protection Switching Ring (EPSR)

Mode Exec and Privileged Exec

Example To show the enabled debugging modes, use the command:

```
awplus# show debugging epsr
```

Related Commands [debug epsr](#)

show epsr

This command displays information about all EPSR instances.

Syntax `show epsr`

Parameter	Description
show	Show running system information
epsr	Ethernet Protection Switching Ring (EPSR)

Mode Exec and Privileged Exec

Example To show the current settings of all EPSR instances, use the command:

```
awplus# show epsr
```

Related Commands [epsr mode master controlvlan primaryport](#)
[epsr mode transit controlvlan](#)
[show epsr counters](#)

show epsr word

This command displays information about the specified EPSR instance.

Syntax `show epsr <epsr>`

Parameter	Description
show	Show running system information
epsr	Ethernet Protection Switching Ring (EPSR)
<epsr>	Name of the EPSR

Mode Exec and Privileged Exec

Example To show the current settings of the EPSR instance called blue, use the command:

```
awplus# show epsr blue
```

Related Commands [epsr mode master controlvlan primaryport](#)
[epsr mode transit controlvlan](#)
[show epsr counters](#)

show epsr word counters

This command displays counter information about the specified EPSR instance.

Syntax `show epsr <epsr> counters`

Parameter	Description
show	Show running system information
epsr	Ethernet Protection Switching Ring (EPSR)
<epsr>	Name of the EPSR
counters	Show the counters for the EPSR instance

Mode Exec and Privileged Exec

Example To show the counters of the EPSR instance called blue, use the command:

```
awplus# show epsr blue counters
```

Related Commands [epsr mode master controlvlan primaryport](#)
[epsr mode transit controlvlan](#)
[show epsr](#)

show epsr counters

This command displays counter information about all EPSR instances.

Syntax `show epsr counters`

Parameter	Description
show	Show running system information
epsr	Ethernet Protection Switching Ring (EPSR)
counters	Show the counters for the EPSR instance

Mode Exec mode and Privileged Exec mode

Example To show the counters of all EPSR instances, use the command:

```
awplus# show epsr counters
```

Related Commands `epsr mode master controlvlan primaryport`
`epsr mode transit controlvlan`
`show epsr`

Part 7: Network Management



- Chapter 70 NTP Introduction
- Chapter 71 NTP Commands
- Chapter 72 Dynamic Host Configuration Protocol (DHCP) Introduction
- Chapter 73 Dynamic Host Configuration Protocol (DHCP) Commands
- Chapter 74 SNMP Introduction
- Chapter 75 SNMP Commands
- Chapter 76 SNMP MIBs
- Chapter 77 LLDP Introduction
- Chapter 78 LLDP Commands
- Chapter 79 SMTP Commands
- Chapter 80 RMON Introduction
- Chapter 81 RMON Commands
- Chapter 82 Triggers Introduction
- Chapter 83 Triggers Configuration
- Chapter 84 Trigger Commands
- Chapter 85 Ping Polling Introduction
- Chapter 86 Ping Polling Commands

Chapter 70: NTP Introduction



Introduction.....	70.2
Overview	70.2
NTP on the Switch	70.3
Troubleshooting	70.4
Configuration Example	70.5

Introduction

This chapter describes the Network Time Protocol (NTP) service provided by the switch, and how to configure and monitor NTP on the switch.

NTP is a protocol for synchronizing the time clocks on a collection of network devices using a distributed client/server mechanism. NTP uses UDP (User Datagram Protocol) as the transport mechanism. NTP evolved from the Time Protocol (RFC 868) and the ICMP Timestamp message (RFC 792).

NTP provides protocol mechanisms to specify the precision and estimated error of the local clock and the characteristics of the reference clock to which it may be synchronized.

For detailed information about the commands used to configure NTP, see [Chapter 71, NTP Commands](#).

Overview

NTP uses a subnetwork with primary reference clocks, gateways, secondary reference clocks, and local hosts. These are organized into a hierarchy with the more accurate clocks near the top and less accurate ones near the bottom.

A number of primary reference clocks, synchronized to national standards, are connected to widely accessible resources (such as backbone gateways or switches) operating as primary time servers. The primary time servers use NTP between them to crosscheck clocks, to mitigate errors due to equipment or propagation failures, and to distribute time information to local secondary time servers. The secondary time servers redistribute the time information to the remaining local hosts.

The hierarchical organization and distribution of time information reduces the protocol overhead, and allows selected hosts to be equipped with cheaper but less accurate clocks. NTP provides information which organizes this hierarchy on the basis of precision or estimated error.

- An NTP entity may be in one of the following operating modes; however, the switch's implementation of NTP supports two modes: client and server.
- An NTP entity operating in a client mode sends periodic messages to its peers, requesting synchronization by its peers.
- An NTP entity enters the server mode temporarily when it receives a client request message from one of its peers, and remains in server mode until the reply to the request has been transmitted.
- An NTP entity operating in symmetric active mode sends messages announcing its willingness to synchronize and be synchronized by its peers.
- An NTP entity enters symmetric passive mode in response to a message from a peer operating in Symmetric Active mode. An NTP entity operating in this mode announces its willingness to synchronize and be synchronized by its peers.
- An NTP entity operating in broadcast mode periodically sends messages announcing its willingness to synchronize all of its peers but not to be synchronized by any of them.

The same message format is used for both requests and replies. When a request is received, the server interchanges addresses and ports, fills in or overwrites certain fields in the message, recalculates the checksum, and returns it immediately. The information included in the NTP message allows each client/ server peer to determine the timekeeping characteristics of its peers, including the expected accuracies of their clocks. Each peer uses this information and

selects the best time from possibly several other clocks, updates the local clock, and estimates its accuracy.

There is no provision in NTP for peer discovery, acquisition, or authentication. Data integrity is provided by the IP and UDP checksums. No reachability, circuit-management, duplicate-detection, or retransmission facilities are provided or necessary.

By its very nature clock synchronization requires long periods of time (hours or days) and multiple comparisons in order to maintain accurate timekeeping. The more comparisons performed, the greater the accuracy of the timekeeping.

NTP on the Switch

The implementation of NTP on the switch is based on the following RFCs:

- RFC 958, Network Time Protocol (NTP)
- RFC 1305, Network Time Protocol (Version 3) Specification, Implementation and Analysis
- RFC 1510, The Kerberos Network Authentication Service (V5)

Two modes of operation are supported: client and server. The switch is in client mode most of the time where it polls the configured peer at least once every preconfigured minimum time period.

The peer that the switch refers to must be a more accurate clock source than the switch itself or another switch directly connected to a more accurate clock source. The switch operates as a secondary time server. It cannot operate as a primary time server unless the primary clock source is operating in server mode. A primary clock source usually operates in broadcast mode, which is not supported by the switch's implementation of NTP. There is no support for clock selection or filtering. When the switch receives a valid reply from the peer, it synchronizes its own internal clock according to the information from the reply.

If the switch receives a synchronization request from an NTP client, it temporarily changes to server mode. It replies to the request with the current time from the switch's internal clock along with other information useful for synchronization. The switch's internal clock is accurate to 0.005 seconds.

Troubleshooting

Problem The switch is not assigning the time to devices on the LAN.

- Solutions**
- Check that the NTP peer's IP address is entered correctly.
 - Check that the NTP peer can reach the switch, by pinging the switch from the NTP peer.

Problem The switch's clock does not synchronize with the NTP peer.

- Solution**
- The switch's clock can synchronize with the NTP peer only when its initial time is similar to the NTP peer's time (after setting the UTC offset). Manually set the switch's time so that it is approximately correct, and enable NTP again.
 - Check that the UTC offset is correct.

Problem The switch's time is incorrect, even though it assigns the correct time to devices on the LAN.

Solution The UTC offset is probably incorrect, or needs to be adjusted for the beginning or end of summer time.

Configuration Example

NTP requires the IP module to be enabled and configured correctly.

The switch's implementation of NTP supports two modes: client and server mode. When a synchronization request is received from a client (e.g. a PC on a LAN), the switch enters server mode and responds with time information derived from the switch's own internal clock. Periodically the switch enters client mode, sending synchronization requests to a predefined peer to synchronize its own internal clock. The peer is assumed to be a primary clock source or another switch connected directly to a primary clock source.

This example illustrates how to configure two switches, one at a Head Office and one at a Regional Office, to provide a network time service. The Head Office switch is connected to a primary time server and provides the most accurate time information. The switch at the Regional Office uses the Head Office switch as its peer to avoid the cost of an additional WAN connection but provides slightly less accurate time information.

To configure NTP on the switch, the NTP module must be enabled and an NTP peer must be defined. NTP transfers time information in UTC format.

To set the switch to automatically change the time when summer time starts and ends, enable a summer time offset setting.

Example configuration parameters for a network time service:

Site	Regional Office	Head Office
Switch Name	RG1	HO1
IP Address of Switch	192.168.35.114	192.168.35.113
IP Address of Peer	192.168.35.113	192.168.13.3

Step 1: Enable NTP and define the NTP peer.

The NTP feature must be enabled on all switches that are to provide a network time service. Each switch must have a peer defined where the switch synchronizes its own internal clock. Enable NTP on the Head Office switch and specify a primary time server as the peer by using the commands:

```
awplus# ntp peer 192.168.13.3
```

Step 2: Configure the NTP parameters.

On each switch, the offset of local time from UTC time must be specified. In this example, both switches are in the same time zone, which is 12 hours ahead of UTC time. Use the following commands on both switches:

```
awplus# clock timezone utc plus 12
```

Note: The range of offset is <0-12>

Step 3: Check the NTP configuration.

Check the NTP configuration on each switch by using the command:

```
awplus# show ntp status
```

This command displays the following information on the Head Office switch.

```
Clock is synchronized, stratum 0, actual frequency is 0.0000  
Hz, precision is 20 reference time is 00000000.00000000  
(6:28:16.000 UTC Fri Feb 7 2036)clock offset is 0.000 msec,  
root delay is 0.000 msec root dispersion is 0.000 msec,
```

Chapter 71: NTP Commands



Command List	71.2
ntp access-group	71.2
ntp authenticate	71.3
ntp authentication-key	71.3
ntp broadcastdelay	71.4
ntp master	71.4
ntp peer	71.6
ntp server	71.7
ntp trusted-key	71.7
show counter ntp	71.8
show ntp associations	71.9
show ntp status	71.10

Command List

This chapter provides an alphabetical reference for commands used to configure the Network Time Protocol (NTP). For more information, see [Chapter 70, NTP Introduction](#).

For information about modifying or redirecting the output from show commands to a file, see [“Controlling “show” command output” on page 1.33](#).

ntp access-group

This command creates an NTP access group, and applies a basic IP access list to it. This allows you to control access to NTP services.

The no form removes the NTP access group.

Syntax

```
ntp access-group [peer|query-only|serve|serve-only] [<1-99>|
<1300-1999>]

no ntp access-group [peer|query-only|serve|serve-only]
```

Parameter	Description
peer	Allows time requests and NTP control queries, and allows the system to synchronize itself to a system whose address passes the access list criteria.
query-only	Allows only NTP control queries from a system whose address passes the access list criteria.
serve	Allows time requests and NTP control queries, but does not allow the system to synchronize itself to a system whose address passes the access list criteria.
serve-only	Allows only time requests from a system whose address passes the access list criteria.
<1-99>	Standard IP access list.
<1300-1999>	Expanded IP access list.

Mode Global Configuration

Example

```
awplus# configure terminal
awplus(config)# ntp access-gr peer 1998
```

ntp authenticate

This command enables NTP authentication. This allows NTP to authenticate the associations with other systems for security purposes.

The no form disables NTP authentication.

Syntax ntp authenticate
no ntp authenticate

Mode Global Configuration

Example To enable NTP authentication, use the command:

```
awplus# configure terminal
awplus(config)# ntp authenticate
```

ntp authentication-key

This command defines each of the authentication keys. Each key has a key number, a type, and a value. Currently, the only key type supported is MD5.

The no form disables the authentication key assigned previously using ntp authentication-key.

Syntax ntp authentication-key <keynum> md5 <key>
no ntp authentication-key <keynum> md5 <key>

Parameter	Description
<keynum>	<1-4294967295> The key number
<key>	The authentication key

Mode Global Configuration

Example

```
awplus# configure terminal
awplus(config)# ntp authentication-key 134343 md5 mystring
```

ntp broadcastdelay

Use this command to set the estimated round-trip delay for broadcast packets.

User the no ntp broadcastdelay command to reset the round-trip delay for broadcast packets.

Syntax ntp broadcastdelay <delay>
no ntp broadcastdelay

Parameter	Description
<delay>	<1-999999> broadcast delay in microseconds

Mode Global Configuration

Example

```
awplus# configure terminal
awplus(config)# ntp broadcastdelay 23464
```

ntp master

Use this command to make the device to be an authoritative NTP server, even if the system is not synchronized to an outside time source. Note that no stratum number is set by default.

Use the no ntp master command to stop the device being the designated NTP server.

Syntax ntp master [<stratum>]
no ntp master

Parameter	Description
<stratum>	<1-15> The stratum number.

Mode Global Configuration

Usage The stratum number is null by default and must be set using this command. The stratum levels define the distance from the reference clock and exist to prevent cycles in the hierarchy. Stratum 1 is used to indicate time servers, which are more accurate than Stratum 2 servers.

Example To stop the switch from being the designated NTP server use the commands:

```
awplus# configure terminal
awplus(config)# no ntp master
```


To make the switch the designated NTP server with stratum number 2 use the commands:

```
awplus# configure terminal  
awplus(config)# ntp master 2
```

ntp peer

Use this command to configure a peer association. An NTP association is a peer association if this system is willing to either synchronize to the other system, or allow the other system to synchronize to it.

Use the no command to remove configuration.

Syntax

```
ntp peer <peeraddress>  
no ntp peer <peeraddress>  
ntp peer <peeraddress> [prefer|<key>|<version>]  
no ntp peer <peeraddress> [prefer|<key>|<version>]
```

Parameter	Description
<peeraddress>	The IP address of the peer, entered in the form A.B.C.D.
prefer	Prefer this peer when possible
<key>	<1-4294967295> Configure peer authentication key
<version>	<1-4> Configure for this NTP version

Mode Global Configuration

Example

```
awplus# configure terminal  
awplus(config)# ntp peer 192.0.2.23  
awplus(config)# ntp peer 192.0.2.23 prefer version 4 key  
1234536
```

ntp server

Use this command to configure an NTP server. This means that this system will synchronize to the other system, and not vice versa.

Syntax

```
ntp server <serveraddress>
no ntp server <serveraddress>
ntp server <serveraddress> [prefer|<key>|<version>]
```

Parameter	Description
<serveraddress>	The IP address of the server, entered in the form A.B.C.D.
prefer	Prefer this server when possible
<key>	<1-4294967295> Configure server authentication key
<version>	<1-4> Configure for this NTP version

Mode Global Configuration

Example

```
awplus# configure terminal
awplus(config)# ntp server 192.0.2.23
awplus(config)# ntp server 192.0.2.23 prefer version 4 key
1234536
```

ntp trusted-key

This command defines a list of trusted authentication keys. If a key is trusted, this system will be ready to synchronize to a system that uses this key in its NTP packets.

Syntax

```
ntp trusted-key <1-4294967295>
no ntp trusted-key <1-4294967295>
```

Parameter	Description
<1-4294967295>	The specific key number.

Mode Global Configuration

Example

```
awplus# configure terminal
awplus(config)# ntp trusted-key 234676
```

show counter ntp

This command displays packet counters for NTP.

Syntax `show counters ntp`

Mode Exec and Privileged Exec

Output Figure 71-1: Example output from the show counter ntp command

```
NTP counters
Pkts Sent                ..... 0
Pkts Received            ..... 3
Pkts Processed           ..... 3
Pkts current version     ..... 3
Pkts old version         ..... 0
Pkts unknown version     ..... 0
Pkts access denied       ..... 0
Pkts bad length          ..... 0
Pkts bad auth            ..... 0
Pkts rate exceed         ..... 0
```

Table 71-1: Parameters in the output from the show counter ntp command

Parameter	Meaning
Pkts Sent	Total number of NTP client and server packets sent by your device.
Pkts Received	Total number of NTP client and server packets received by your device.
Pkts Processed	The number of packets processed by NTP. NTP processes a packet once it has determined that the packet is valid by checking factors such as the packet's authentication, format, access rights and version.
Pkts current version	The number of version 4 NTP packets received.
Pkts old version	The number of NTP packets received that are from an older version, down to version 1, of NTP. NTP is compatible with these versions and processes these packets.
Pkts unknown version	The number of NTP packets received that are an earlier version than version 1, or a higher version than version 4. NTP cannot process these packets.
Pkts access denied	The number of NTP packets received that do not match any access list statements in the NTP access-groups. NTP drops these packets.
Pkts bad length	The number of NTP packets received that do not conform to the standard packet length. NTP drops these packets.
Pkts bad auth	The number of NTP packets received that failed authentication. NTP drops these packets. Packets can only fail authentication if NTP authentication is enabled with the <code>ntp authenticate</code> command.
Pkts rate exceed	The number of packets dropped because the packet rate exceeded its limits.

Examples To display counters for NTP, use the command:

```
awplus# show counter ntp
```

show ntp associations

Use this command to display the status of NTP associations. Use the detail option for displaying detailed information about the associations.

Syntax `show ntp associations [detail]`

Mode Exec and Privileged Exec

Usage See the sample output of the `show ntp associations` and `show ntp associations detail` command displaying the status of NTP associations.

```
awplus#show ntp associations
address      ref clock    st  when  poll reach  delay  offset  disp
*~ 127.127.1.0 127.127.1.0 5    22    64   377   0.0    0.0    1.0
*master(synced),# master(unsynced),+ selected,- candidate,~configured
```

Example

```
awplus# show ntp associations detail
```

Figure 71-2: Example output from the show ntp associations command

```
awplus#sh ntp associations detail
172.80.1.1 configured, sane, valid, leap_sub, stratum 16
ref ID , time 00000000.00000000 (06:28:16.000 UTC Thu Feb 7 2036)
our mode active, peer mode unspec, our poll intvl 1024, peer poll intvl 1024
root delay 0.00 msec, root disp 0.00, reach 000,
delay 0.00 msec, offset 0.0000 msec, dispersion 0.00
precision 2**-20,
org time cba7db00.e2da554b (00:17:04.886 UTC Thu Apr 10 2008)
rcv time cba7db63.0d33f423 (00:18:43.051 UTC Thu Apr 10 2008)
xmt time cba7d9df.5ccb8e08 (00:12:15.362 UTC Thu Apr 10 2008)
filtdelay = 0.00 0.00 0.00 0.00 0.00 0.00 0.00 0.00
filtoffset = 0.00 0.00 0.00 0.00 0.00 0.00 0.00 0.00
filtererror = 16000.00 16000.00 16000.00 16000.00 16000.00 16000.00 16000.00
16000.00
```

Table 71-2: Parameters in the output from the show ntp associations command

Parameter	Meaning
address	Peer IP address
ref clock	IP address for reference clock
st	Stratum. The number of hops between the server and the accurate time source.
poll	Time between NTP requests from the device to the server.
reach	Shows whether or not the NTP server responded to the last request.
delay	Round trip delay between the device and the server.
offset	Difference between the device clock and the server clock.
disp	Lowest measure of error associated with peer offset based on delay.

show ntp status

Use this command to display the status of the Network Time Protocol (NTP).

Syntax `show ntp status`

Mode Exec and Privileged Exec

Usage This is a sample output of the `show ntp status` command displaying information about the Network Time Protocol.

```
awplus#show ntp status
Clock is synchronized, stratum 6, reference is 127.127.1.0
actual frequency is 51.2010 Hz, precision is 2**-15
reference time is c389fad6.a9a8ac5c (13:42:46.662 UTC Wed Dec 16
2003)
clock offset is 0.000 msec, root delay is 0.000 msec
root dispersion is 11201.000 msec,
```

Example

```
awplus# show ntp status
```

```
awplus#show ntp status
Clock is unsynchronized, stratum 16, reference is INIT
actual frequency is 0.0000 Hz, precision is 2**-20
reference time is 00000000.00000000 (06:28:16.000 UTC Thu Feb 7
2036)
clock offset is 0.000 msec, root delay is 0.000 msec
root dispersion is 140850.000 msec,
awplus#
```

Chapter 72: Dynamic Host Configuration Protocol (DHCP) Introduction



Introduction.....	72.2
BOOTP	72.2
DHCP	72.2
DHCP Relay Agents	72.2
Configuring the DHCP Server	72.3
Create the Pool.....	72.3
Define the Network.....	72.3
Define the Range.....	72.4
Set the Lease.....	72.4
Set the Options.....	72.4
Configuring the DHCP Relay Agent.....	72.6
Configuring the DHCP Relay Agent	72.6
DHCP Relay Agent Option 82.....	72.7
Configuring the DHCP Client.....	72.10

Introduction

This chapter describes the Dynamic Host Configuration Protocol (DHCP) support provided by your device. This includes how to configure your device to:

- act as a DHCP and BOOTP server
- act as a DHCP relay agent
- use the DHCP client to obtain IP addresses for its own interfaces

Note that you can configure your device to operate as both a DHCP relay agent and a DHCP/BOOTP server.

BOOTP

Bootstrap Protocol (BOOTP) is a UDP-based protocol that enables a booting host to dynamically configure itself without external interventions. A BOOTP server responds to requests from BOOTP clients for configuration information, such as the IP address the client should use. BOOTP is defined in RFC 951, Bootstrap Protocol (BOOTP).

RFC 1542, Clarifications and Extensions for the Bootstrap Protocol, defines extensions to the BOOTP protocol, including the behavior of a DHCP relay agent.

DHCP

DHCP is widely used to dynamically assign host IP addresses from a centralized server that reduces the overhead of administrating IP addresses. DHCP helps conserve the limited IP address space because IP addresses no longer need to be permanently assigned to hosts. DHCP centrally manages IP address assignment for a large number of subscribers.

DHCP is based on BOOTP, and is defined in RFC 2131. It extends the BOOTP mechanism by providing:

- a method for passing configuration information to hosts on a TCP/IP network
- automatic allocation of reusable network addresses
- other additional configuration options

When your device is configured as a DHCP server, it allocates IP addresses and other IP configuration parameters to clients (hosts), when the client requests them. This lets you configure your IP network without manually configuring every client. Note that each client must also be configured to receive its IP address automatically.

As well as addresses, a DHCP server assigns a wide range of parameters to clients, including subnet information and mask, domain and hostname, server addresses, keepalive times, MTUs, boot settings, encapsulation settings, time settings, and TCP settings.

DHCP is designed to interoperate with BOOTP clients and DHCP clients, without the BOOTP clients needing any change to their initialization software.

DHCP Relay Agents

DHCP relay agents pass BOOTP and DHCP messages between servers and clients. Networks where the DHCP or BOOTP server does not reside on the same IP subnet as its clients need the intermediate routers to act as relay agents.

Configuring the DHCP Server

The DHCP server uses *address pools* when responding to DHCP client requests. Address pools contains specific IP configuration details that the DHCP server can allocate to a client. You can configure multiple address pools on the device for different networks.

To configure a pool, you must:

- Create the Pool and enter its configuration mode.
- Define the Network the pool applies to.
- Define the Range of IP addresses that the server can allocate to clients. You can specify multiple address ranges for each pool.
- Set the Lease for the clients. This defines whether the clients receive a dynamic, permanent, or static IP address.
- Set the Options (standard and user-defined) that the clients of a pool require when configuring their IP details.

After configuring the address pools, you can then enable the DHCP server by using the command:

```
awplus(config)# service dhcp-server
```

For networks where you do not want the server to respond to BOOTP requests, you can configure the DHCP server so that it ignores them, by using the command:

Create the Pool

```
awplus(config)# ip dhcp bootp ignore
```

A DHCP pool is identified by a name. To create a DHCP pool and enter the configuration mode for the pool, use the command:

```
awplus(config)# ip dhcp pool <pool-name>
```

Define the Network

Define the network that the DHCP clients are in. You can define one network per address pool. Use the following command to define the network after defining the DHCP pool first:

```
awplus(dhcp-config)# network
```

- For remote clients, set the network address to the network of the remote clients. The `network` command does not need to match a specific interface's network, because the DHCP server listens on all IP interfaces for DHCP requests.
- For locally connected clients, ensure that the desired interface has an IP address and subnet mask defined; use the `ip address IPADDR` command to set a static address. Enter the configuration mode for the pool, and set the DHCP address pool's network to match the interface's network. Pools that span multiple interfaces are possible only if the interface networks are contiguous.

Define the Range

Configure an IP address range for the pool. This range must be in the same subnet as the pool's network setting. Use the command:

```
awplus(dhcp-config)# range <ip-address> [<ip-address>]
```

The first IPv4 address specifies the low end of the range, while the second IP address is the high end. You can set the range to a single IP address by specifying only one IP address.

Set the Lease

The DHCP server assigns IP settings to hosts for specific times (the lease time). Each DHCP pool has one lease time setting. You can use DHCP to allocate the following types of addresses:

- *A dynamic IP addresses*
These are available to a host for a limited amount of time. When the lease expires, the server can reallocate the IP address to another device. To set the lease time for the DHCP pool so that it assigns dynamic IP addresses, use the command:

```
awplus(dhcp-config)# lease <days> <hours> <minutes>
```

- *A permanent IP addresses*
These are available to a host for an unlimited amount of time. To set the lease time to assign permanent IP addresses, use the command:

```
awplus(dhcp-config)# lease infinite
```

- *A static IP addresses*
These are allocated to a particular client. The DHCP server recognizes the client by its MAC address. This lets you use DHCP to manage most of your network automatically, while having unchanging IP addresses on key devices such as servers. To assign a static IP address to a device, use the command:

```
awplus(dhcp-config)# host <ip-address> <mac-address>
```

BOOTP requests can be satisfied by pools with leases set to infinity.

Set the Options

DHCP allows clients to receive options from the DHCP server. Options describe the network configuration, and various services that are available on the network. Options are configured separately on each DHCP pool. You can configure both standard predefined options and user-defined options for a DHCP pool.

To create a user-defined option, use the command:

```
awplus(config)# ip dhcp option <1-254> [name <option-name>] [<option-type>]
```

To add a user-defined option to a DHCP address pool, use the command sequence:

```
awplus(config)# ip dhcp pool <pool-name>
```

```
awplus(dhcp-config)# option [<1-254>|<option-name>] <option-value>
```

It is possible to add a user-defined option with the same number as an existing pre-defined option. If this situation occurs, the user-defined option takes precedence—that is, it overrides but does not eliminate the standard option.

You can set some pre-defined options using the following commands:

To set a subnet mask (option 1) for the address pool, use the command:

```
awplus(dhcp-config)# subnet-mask <mask>
```

To add a domain name (option 15) for the address pool, use the command:

```
awplus(dhcp-config)# domain-name <domain-name>
```

To add a default router (option 3) for the address pool, use the command:

```
awplus(dhcp-config)# default-router <ip-address>
```

To add a DNS server (option 6) for the address pool, use the command:

```
awplus(dhcp-config)# dns-server <ip-address>
```

Configuring the DHCP Relay Agent

DHCP relay agents pass BOOTP messages between servers and clients. Networks where the DHCP or BOOTP server does not reside on the same IP subnet as its clients need the routers attached to the subnet to act as DHCP relay agents.

Note that both BOOTP and DHCP use BOOTP messages, allowing DHCP relay agents to relay all their packets.

Your device's DHCP Relay Agent relays these message types:

- BOOTREQUEST messages originating from any of the device's interfaces to a user-defined destination
- BOOTREPLY messages addressed to BOOTP clients on networks directly connected to the device

The relay agent ignores BOOTREPLY messages addressed to clients on networks not directly connected to the device. The device treats these as ordinary IP packets for forwarding.

A BOOTREQUEST message may be relayed via unicast, multicast or broadcast methods. In the last case, the message does not re-broadcast to the interface from which it was received. The relay destinations are configured independently of other broadcast forwarders' destinations (e.g. TFTP).

The hops field in a BOOTP message records the number of hops (routers) the message has been through. If the value of the hops field exceeds a predefined threshold, the relay agent discards the message.

Configuring the DHCP Relay Agent

To enable the DHCP relay agent on your device, use the command:

```
awplus(config)# service dhcp-relay
```

You must define a relay destination on one of the device's interfaces before the relay agent can relay packets. This is the path to the DHCP server. To define a relay destination, use the commands:

```
awplus(config)# interface <ifname>
awplus(config-if)# ip dhcp-relay server-address <ip-addr>
```

You can define more than one relay destination on your device. The following table describes how the relay agent forwards the packets.

If an interface has...	Then the relay agent relays BOOTP packets it receives on that interface to...
one relay destination defined	the relay destination.
multiple relay destinations defined	each defined relay destination.

To delete a relay destination, use the command:

```
awplus(dhcp-config)# no ip dhcp-relay server-address <ip-addr>
```

When the 'hops' field in a BOOTP message exceeds a predefined threshold the BOOTP message is discarded. The default of the threshold is 10. To set the threshold, use the command:

```
awplus(config-if)# ip dhcp-relay maxhops <1-255>
```

To display the current configuration of the DHCP relay agent, use the command:

```
awplus# show ip dhcp-relay [interface <interface>]
```

DHCP Relay Agent Option 82

Enabling the DHCP option-82 feature on the switch enables the switch to insert extra information into the DHCP packets that it is relaying. This information enables more accurate identification of a subscriber, as it states which switch port on which relay switch the subscriber is connected to. The information is stored in a specific optional field in the DHCP packet, namely, the agent-information field, which has option ID 82.

The DHCP relay agent inserts the option 82 information into the DHCP packets that it is relaying to a DHCP server. DHCP servers that are configured to recognize option 82 may use the information to implement IP addresses, or other parameter assignment policies, based on the network location of the client device. Alternatively, the server can simply log this information to create a detailed audit trail of the locations of the clients to which given addresses were allocated at given times.

When you enable the DHCP relay agent option 82, the following actions happen:

- The DHCP client generates a DHCP request and broadcasts it on the network.
- The DHCP relay agent intercepts the broadcast DHCP request packet and inserts the relay agent information option (option 82) in the packet.
- The DHCP relay agent forwards the DHCP request that includes the option-82 field to the DHCP server.
- The DHCP server receives the packet.
- The DHCP server echoes the option-82 field in the DHCP reply. If the server does not support option 82, it ignores the option and does not echo it in the reply.
- The DHCP server unicasts the reply to the relay agent.
- The relay agent removes the option-82 field and forwards the packet to the switch port that connects to the DHCP client, which sent the DHCP request.

For more information about DHCP Relay Agent Option 82, see RFC 3046. Option 82 can be:

- added to packets relayed from the DHCP client to DHCP server
- removed from packets relayed from DHCP server to DHCP client
- checked from sources closer to the client

To enable the relay agent to insert its details into the option 82 field in requests received from clients attached to a particular interface, use the command:

```
awplus(config)# interface <ifname>
awplus(config-if)# ip dhcp-relay agent-option
```

This applies to requests received with no other agent relay information in the option 82 field.

Dealing with client-originated packets that already contain option-82 information

The discussion above deals with the case where the DHCP requests arriving from the clients do not already contain option-82 information. However, it is possible that the requests arriving from the clients to the relay agent could already contain option-82 information. There are two main circumstances in which this can occur:

1. A client is maliciously inserting bogus information into the packet in an attempt to subvert the process of identifying the client's location
2. A layer-2 DHCP snooping switch, that sits between the clients and the DHCP relay, is validly inserting the option-82 information into the packets. The DHCP snooping switch is not acting as a relay agent, so it is not filling in the giaddr field (the relay IP address field) in the packet; it is only inserting the option-82 information.

In case 1, you would want to drop the packets that contain the bogus information (or, at least remove the bogus information). In case 2, you would want to forward the valid information to the DHCP server.

To configure the switch to check for the presence of option-82 information in incoming DHCP requests, configure DHCP-relay agent-option checking, with the command (in interface mode):

```
awplus(config)# interface <ifname>
awplus(config-if)# ip dhcp-relay agent-option checking
```

By default, this will cause the switch to act as follows:

- If the incoming DHCP request has a null IP address (0.0.0.0) in the giaddr field, and contains option-82 information, drop the packet. This assumes that such a packet has been maliciously created by a client.
- If an incoming DHCP request has a non-null in the giaddr field, and contains option-82 information, then replace the option-82 field with the current switch's own information. This assumes that a non-null giaddr field indicates that the packet has already passed through a valid DHCP relay device, and so the presence of the option-82 information is not an indication of malicious intent.

The action taken on packets that have a null giaddr field and an option-82 field present cannot be altered once the agent-option check has been enabled. But, the action taken on packets with a non-null giaddr field and an option-82 field is configurable. The command to configure this action is shown below:

```
awplus(config)# interface <ifname>
awplus(config-if)# ip dhcp-relay information policy
```

This command takes parameters that can configure the switch to:

- Leave the existing option-82 field untouched
- Append its own option-82 field after the existing field
- Drop the packet
- Replace the existing option-82 information with its own (the default).

DHCP Relay Agent Option 82 maximum message length

Where a DHCP relay (that has option 82 insertion enabled) receives a *request* packet from a *DHCP client*, it will append the *option 82* component data, and forward the packet to the DHCP server. The DHCP client will sometimes issue packets containing pad option fields that can be overwritten with *option 82* data. Where there are insufficient pad option fields to contain all the option 82 data, the DHCP relay will increase the packet size to accommodate the option 82 data. If the new (increased) packet size exceeds that defined by the maximum-message-length parameter, of the [ip dhcp-relay max-message-length command on page 73.17](#) then the DHCP relay will drop the packet.

```
awplus(config)# interface <ifname>
awplus(config-if)# ip dhcp-relay max-message-length 1200
```

Configuring the DHCP Client

You can configure an interface on your device with a static IP address, or with a dynamic IP address assigned using your device's DHCP client. When you use the DHCP client, it obtains the IP address for the interface, and other IP configuration parameters, from a DHCP server. To configure an interface and gain its IP configuration using the DHCP client, use the command:

```
awplus(config)# interface <ifname>
awplus(config-if)# ip address dhcp [client-id <interface>] [hostname <hostname>]
```

The DHCP client supports the following IP configuration options:

- Option 1 - the subnet mask for your device.
- Option 3 - a list of default routers.
- Option 6 - a list of DNS servers. This list appends the DNS servers set on your device with the `ip name-server` command.
- Option 15 - a domain name used to resolve host names. This option replaces the domain name set with the `ip domain-name` command. Your device ignores this domain name if it has a domain list set using the `ip domain-list` command.
- Option 51 - lease expiration time.

If an IP interface is configured to get its IP address and subnet mask from DHCP, the interface does not take part in IP routing until the IP address and subnet mask have been set by DHCP.

For information on configuring static IP address on an interface, see the [ip address command on page 25.9](#).

Chapter 73: Dynamic Host Configuration Protocol (DHCP) Commands

Command List.....	73.2
bootfile	73.2
default-router.....	73.3
dns-server	73.4
domain-name.....	73.5
host.....	73.6
ip address dhcp.....	73.7
ip dhcp bootp ignore	73.8
ip dhcp option.....	73.9
ip dhcp pool	73.11
ip dhcp-relay agent-option.....	73.12
ip dhcp-relay agent-option checking	73.13
ip dhcp-relay information policy	73.15
ip dhcp-relay maxhops.....	73.16
ip dhcp-relay max-message-length	73.17
ip dhcp-relay server-address	73.18
lease	73.19
network (DHCP).....	73.20
next-server	73.21
option.....	73.22
range	73.24
service dhcp-relay.....	73.25
service dhcp-server	73.26
show counter dhcp-client.....	73.27
show counter dhcp-relay	73.28
show counter dhcp-server.....	73.30
show dhcp lease.....	73.31
show ip dhcp binding	73.32
show ip dhcp pool.....	73.33
show ip dhcp-relay	73.36
show ip dhcp server statistics.....	73.37
show ip dhcp server summary.....	73.38
subnet-mask.....	73.39

Command List

This chapter provides an alphabetical reference for commands used to configure DHCP. For more information, see [Chapter 72, Dynamic Host Configuration Protocol \(DHCP\) Introduction](#).

For information about modifying or redirecting the output from show commands to a file, see [“Controlling “show” command output” on page 1.33](#).

bootfile

This command sets the boot filename for a DHCP server pool. This is the name of the boot file that the client should use in its bootstrap process. It may need to include a path.

The no parameter removes the boot filename from a DHCP server pool.

Syntax `bootfile <filename>`
`no bootfile`

Parameter	Description
bootfile	Configures the boot file name
<filename>	The boot file name

Mode DHCP Configuration

Examples To configure the boot filename for a pool P2, use the command:

```
awplus# configure terminal
awplus(config)# ip dhcp pool P2
awplus(dhcp-config)# bootfile boot/main_boot.bt
```

default-router

This command adds a default router to the DHCP address pool you are configuring. You can use this command multiple times to create a list of default routers on the client's subnet. This sets the router details using the pre-defined option 3. Note that if you add a user-defined option 3 using the option command, then you will override any settings created with this command.

The no parameter removes either the specified default router, or all default routers from the DHCP pool.

Syntax `default-router <ip-address>`
`no default-router [<ip-address>]`

Parameter	Description
<code><ip-address></code>	IPv4 address of the default router, in dotted decimal notation.

Mode DHCP Configuration

Examples To add a router with an IP address 192.168.1.2 to the DHCP pool named P2, use the following commands:

```
awplus# configure terminal
awplus(config)# ip dhcp pool P2
awplus(dhcp-config)# default-router 192.168.1.2
```

To remove a router with an IP address 192.168.1.2 to the DHCP pool named P2, use the following commands:

```
awplus# configure terminal
awplus(config)# ip dhcp pool P2
awplus(dhcp-config)# no default-router 192.168.1.2
```

To remove all routers from the DHCP pool named P2, use the following commands:

```
awplus# configure terminal
awplus(config)# ip dhcp pool P2
awplus(dhcp-config)# no default-router
```

dns-server

This command adds a Domain Name System (DNS) server to the DHCP address pool you are configuring. You can use this command multiple times to create a list of DNS name servers available to the client. This sets the DNS server details using the pre-defined option 6. Note that if you add a user-defined option 6 using the [option command on page 73.22](#), command, then you will override any settings created with this command.

The no parameter removes either the specified DNS server, or all DNS servers from the DHCP pool.

Syntax `dns-server <ip-address>`
`no dns-server [<ip-address>]`

Parameter	Description
<code><ip-address></code>	IPv4 address of the DNS server, in dotted decimal notation.

Mode DHCP Configuration

Examples To add the DNS server with the assigned IP address 192.168.1.1 to the DHCP pool named P1, use the following commands:

```
awplus# configure terminal
awplus(config)# ip dhcp pool P2
awplus(dhcp-config)# dns-server 192.168.1.1
```

To remove the DNS server with the assigned IP address 192.168.1.1 from the DHCP pool named P1, use the following commands:

```
awplus# configure terminal
awplus(config)# ip dhcp pool P2
awplus(dhcp-config)# no dns-server 192.168.1.1
```

To remove all DNS servers from the DHCP pool named P1, use the following commands:

```
awplus# configure terminal
awplus(config)# ip dhcp pool P2
awplus(dhcp-config)# no dns-server
```

Related Commands [default-router](#)
[option](#)
[service dhcp-server](#)
[show ip dhcp pool](#)
[subnet-mask](#)

domain-name

This command adds a domain name to the DHCP address pool you are configuring. Use this command to specify the domain name that a client should use when resolving host names using the Domain Name System. This sets the domain name details using the pre-defined option 15. Note that if you add a user-defined option 15 using the [option command on page 73.22](#), then you will override any settings created with this command.

The no parameter removes the domain name from the address pool.

Syntax domain-name <domain-name>
no domain-name

Parameter	Description
<domain-name>	The domain name you wish to assign the DHCP pool. Valid characters are any printable character. If the name contains spaces then you must enclose it in "quotation marks".

Mode DHCP Configuration

Examples To add the domain name Nerv_Office to DHCP pool P2, use the commands:

```
awplus# configure terminal
awplus(config)# ip dhcp pool P2
awplus(dhcp-config)# domain-name Nerv_Office
```

To remove the domain name Nerv_Office from DHCP pool P2, use the commands:

```
awplus# configure terminal
awplus(config)# ip dhcp pool P2
awplus(dhcp-config)# no domain-name Nerv_Office
```

Related Commands default-router
dns-server
option
service dhcp-server
show ip dhcp pool
subnet-mask

host

This command adds a static host address to the DHCP address pool you are configuring. The client with the matching MAC address is permanently assigned this IP address. No other clients can request it.

The no parameter removes the specified host address from the DHCP pool. Use the no host all command to remove all static host addresses from the DHCP pool.

Syntax `host <ip-address> <mac-address>`

`no host <ip-address>`

`no host all`

Parameter	Description
<code><ip-address></code>	IPv4 address of the DHCP client, in dotted decimal notation in the format A.B.C.D
<code><mac-address></code>	MAC address of the DHCP client, in hexadecimal notation in the format HHHH.HHHH.HHHH

Mode DHCP Configuration

Usage Note that a network/mask must be configured using a network command before issuing a host command. Also note that a host address must match a network to add a static host address.

Examples To add the host at 192.168.1.5 with the MAC address 000a.451d.6e34 to DHCP pool 1, use the commands:

```
awplus# configure terminal
awplus(config)# ip dhcp pool 1
awplus(dhcp-config)# network 192.168.1.0/24
awplus(dhcp-config)# host 192.168.1.5 000a.451d.6e34
```

To remove the host at 192.168.1.5 with the MAC address 000a.451d.6e34 from DHCP pool 1, use the commands:

```
awplus# configure terminal
awplus(config)# ip dhcp pool 1
awplus(dhcp-config)# no host 192.168.1.5 000a.451d.6e34
```

Related Commands

- [lease](#)
- [range](#)
- [show ip dhcp pool](#)

ip address dhcp

This command activates the DHCP client on the interface you are configuring. This allows the interface to use the DHCP client to obtain its IP configuration details from a DHCP server on its connected network.

The client-id and hostname parameters are identifiers that you may want to set in order to interoperate with your existing DHCP infrastructure. If neither option is needed, then the DHCP server uses the MAC address field of the request to identify the host.

The DHCP client supports the following IP configuration options:

- Option 1 - the subnet mask for your device.
- Option 3 - a list of default routers.
- Option 6 - a list of DNS servers. This list appends the DNS servers set on your device with the `ip name-server` command.
- Option 15 - a domain name used to resolve host names. This option replaces the domain name set with the `ip domain-name` command. Your device ignores this domain name if it has a domain list set using the `ip domain-list` command.
- Option 51 - lease expiration time.

The `no` parameter stops the interface from obtaining IP configuration details from a DHCP server.

Syntax `ip address dhcp [client-id <interface>] [hostname <hostname>]`
`no ip address dhcp`

Parameter	Description
<code><interface></code>	The name of the interface you are activating the DHCP client on. If you specify this, then the MAC address associated with the specified interface is sent to the DHCP server in the optional identifier field. Default: no default
<code><hostname></code>	The hostname for the DHCP client on this interface. Typically this name is provided by the ISP. Default: no default

Mode Interface Configuration for a VLAN interface.

Examples To set the interface `vlan10` to use DHCP to obtain an IP address, use the command:

```
awplus# configure terminal
awplus(config)# interface vlan10
awplus(config-if)# ip address dhcp
```

To stop the interface `vlan10` from using DHCP to obtain its IP address, use the command:

```
awplus# configure terminal
awplus(config)# interface vlan10
awplus(config-if)# no ip address dhcp
```

Related Commands [ip address](#)

**Validation
Commands** [show running-config](#)
 [show running-config access-list](#)

ip dhcp bootp ignore

This command configures the DHCP server to ignore any BOOTP requests it receives. The DHCP server accepts BOOTP requests by default.

The `no` parameter configures the DHCP server to accept BOOTP requests. This is the default setting.

Syntax `ip dhcp bootp ignore`
 `no ip dhcp bootp ignore`

Mode Global Configuration

Examples To configure the DHCP server to ignore BOOTP requests, use the command:

```
awplus# configure terminal
awplus(config)# ip dhcp bootp ignore
```

To configure the DHCP server to respond to BOOTP requests, use the command:

```
awplus# configure terminal
awplus(config)# no ip dhcp bootp ignore
```

Related Commands [show ip dhcp server summary](#)

ip dhcp option

This command creates a user-defined DHCP option. You can then use this option when configuring a DHCP pool, by using the [option](#) command. Options with the same number as one of the pre-defined options override the standard option definition. The pre-defined options use the option numbers 1, 3, 6, 15, and 51.

The no parameter removes either the specified user-defined option, or removes all user-defined options. This also automatically removes the user-defined options from the associated DHCP address pools.

Syntax `ip dhcp option <1-254> [name <option-name>] [<option-type>]`
`no ip dhcp option [<1-254>|<option-name>]`

Parameter	Description										
<1-254>	The option number of the option. Options with the same number as one of the standard options overrides the standard option definition.										
<option-name>	Option name used to identify the option. You cannot use a number as the option name. Valid characters are any printable character. If the name contains spaces then you must enclose it in "quotation marks". Default: no default										
<option-type>	The option value. You must specify a value that is appropriate to the option type: <table> <tr> <td>ascii</td><td>An ASCII text string</td></tr> <tr> <td>hex</td><td>A hexadecimal string. Valid characters are the numbers 0–9 and letters a–f. Embedded spaces are not valid. The string must be an even number of characters, from 2 and 256 characters long.</td></tr> <tr> <td>ip</td><td>An IPv4 address or mask that has the dotted decimal A.B.C.D notation. To create a list of IP addresses, you must add each IP address individually by using the option command multiple times.</td></tr> <tr> <td>integer</td><td>A number from 0 to 4294967295.</td></tr> <tr> <td>flag</td><td>A value that either sets (to 1) or unsets (to 0) a flag: true, on, or enabled will set the flag false, off or disabled will unset the flag.</td></tr> </table>	ascii	An ASCII text string	hex	A hexadecimal string. Valid characters are the numbers 0–9 and letters a–f. Embedded spaces are not valid. The string must be an even number of characters, from 2 and 256 characters long.	ip	An IPv4 address or mask that has the dotted decimal A.B.C.D notation. To create a list of IP addresses, you must add each IP address individually by using the option command multiple times.	integer	A number from 0 to 4294967295.	flag	A value that either sets (to 1) or unsets (to 0) a flag: true, on, or enabled will set the flag false, off or disabled will unset the flag.
ascii	An ASCII text string										
hex	A hexadecimal string. Valid characters are the numbers 0–9 and letters a–f. Embedded spaces are not valid. The string must be an even number of characters, from 2 and 256 characters long.										
ip	An IPv4 address or mask that has the dotted decimal A.B.C.D notation. To create a list of IP addresses, you must add each IP address individually by using the option command multiple times.										
integer	A number from 0 to 4294967295.										
flag	A value that either sets (to 1) or unsets (to 0) a flag: true, on, or enabled will set the flag false, off or disabled will unset the flag.										

Mode Global Configuration

Examples To define a user-defined ASCII string option as option 66, without a name, use the command:

```
awplus# configure terminal
awplus(config)# ip dhcp option 66 ascii
```

To define a user-defined hexadecimal string option as option 46, with the name “tcpip-node-type”, use the command:

```
awplus# configure terminal
awplus(config)# ip dhcp option 46 name tcpip-node-type hex
```

To define a user-defined IP address option as option 175, with the name special-address, use the command:

```
awplus# configure terminal
awplus(config)# ip dhcp option 175 name special-address ip
```

To remove the specific user-defined option with the option number 12, use the command:

```
awplus# configure terminal
awplus(config)# no ip dhcp option 12
```

To remove the specific user-defined option with the option name perform-router-discovery, use the command:

```
awplus# configure terminal
awplus(config)# no ip dhcp option perform-router-discovery
```

To remove all user-defined option definitions, use the command:

```
awplus# configure terminal
awplus(config)# no ip dhcp option
```

Related Commands

- default-router
- dns-server
- domain-name
- option
- service dhcp-server
- show ip dhcp server summary
- subnet-mask

ip dhcp pool

This command will enter the configuration mode for the pool name specified. If the name specified is not associated with an existing pool, the switch will create a new pool with this name, then enter the configuration mode for the new pool.

Once you have entered the DHCP configuration mode, all commands executed before the next exit command will apply to this pool.

You can create multiple DHCP pools on devices with multiple interfaces. This allows the device to act as a DHCP server on multiple interfaces to distribute different information to clients on the different networks.

The no parameter deletes the specific DHCP pool.

Syntax `ip dhcp pool <pool-name>`
`no ip dhcp pool <pool-name>`

Parameter	Description
<name>	Description used to identify this DHCP pool. Valid characters are any printable character. If the name contains spaces then you must enclose it in "quotation marks".

Mode Global Configuration

Examples To create the DHCP pool called P2, use the command:

```
awplus# configure terminal
awplus(config)# ip dhcp pool P2
```

Related Commands [service dhcp-server](#)

ip dhcp-relay agent-option

This command enables the DHCP relay agent to insert the relay agent information option (*option 82*) into the client-request packets that it relays to its DHCP server. This allows the relay agent to pass on information to the server about the network location of the client device. The relay agent then strips the *option 82* field out of the server's response, so that the client does never sees this field.

When the relay agent appends its option 82 data into the packet, it first overwrites any pad options present; then if necessary, it increases the packet length to accommodate the option 82 data.

The no parameter stops the relay agent from appending the *option 82* field onto DHCP requests before forwarding it to the server.

Syntax `ip dhcp-relay agent-option`
`no ip dhcp-relay agent-option`

Parameter	Description
<code>ip dhcp-relay</code>	A device that forwards DHCP packets between a DHCP client and a DHCP server, usually located on a different network.
<code>agent-option</code>	Applies the DHCP relay agent option.
<code>no</code>	The no form of this command removes the DHCP relay agent option.

Mode Interface Configuration for a VLAN interface.

Default The DHCP relay agent feature is disabled by default.

Usage Use this command to alter the relay agent's *option 82* setting when your device is the first hop for the DHCP client. To limit the maximum length of the packet, use the [ip dhcp-relay max-message-length command on page 73.17](#).

Examples To make the relay agent listening on `vlan15` append the option 82 field, use the commands:

```
awplus# configure terminal
awplus(config)# interface vlan15
awplus(config-if)# ip dhcp-relay agent-option
```

To stop the relay agent from appending the option 82 field on `vlan15`, use the commands:

```
awplus# configure terminal
awplus(config)# interface vlan15
awplus(config-if)# no ip dhcp-relay agent-option
```

Related Commands [ip dhcp-relay information policy](#)
[ip dhcp-relay max-message-length](#)
[service dhcp-relay](#)

ip dhcp-relay agent-option checking

This command controls the way that the DHCP-relay service deals with packets arriving from the client side that have:

- option-82 information present in the packet
- a giaddr field (relay agent IP address field) of 0.0.0.0

By default such packets are accepted and passed through. This assumes that the option-82 field has been inserted into the packet by a trusted device, such as a layer-2 DHCP-snooping switch.

However, if you do not have such a trusted device between the relay switch and the clients, then packets arriving with no relay address but containing option-82 information are treated with suspicion and dropped.

The command `ip dhcp-relay agent-option checking` will cause such packets to be dropped. Packets which contain option-82 information, but have a non-zero address in the giaddr field will continue to be forwarded.

The `no` form of the commands returns this feature to the default state, whereby the DHCP-relay service does not check the state of the giaddr field in packets that contain option-82 information.

Note: The DHCP-relay service might also alter the content of the option-82 field, if the commands `ip dhcp-relay agent-option` and `ip dhcp-relay information policy` have also been configured.

Syntax `ip dhcp-relay agent-option checking`
`no ip dhcp-relay agent-option checking`

Parameter	Description
<code>ip dhcp-relay</code>	A device that forwards DHCP packets between a DHCP agent and a DHCP server, usually located on a different network.
<code>agent-option</code>	Applies the DHCP relay option.
<code>checking</code>	Enables the DHCP relay option 82 server response checking
<code>no</code>	The <code>no</code> form of this command removes the DHCP relay checking option.

Mode Interface Configuration for a VLAN interface.

Examples To make the relay agent listening on `vlan10` check the Agent ID suboption field, use the commands:

```
awplus# configure terminal
awplus(config)# interface vlan10
awplus(config-if)# ip dhcp-relay agent-option checking
```

To stop the relay agent on `vlan10` from checking the Agent ID suboption field, use the commands:

```
awplus# configure terminal
awplus(config)# interface vlan10
awplus(config-if)# no ip dhcp-relay agent-option checking
```

Related Commands [service dhcp-relay](#)

ip dhcp-relay information policy

This command sets the policy for how the DHCP relay deals with packets arriving from the client that contain option-82 information.

If the command `ip dhcp-relay agent-option` has not been configured, then this command has no effect at all - no alteration is made to option-82 information in packets arriving from the client side.

However, if the command `ip dhcp-relay agent-option` has been configured, this command modifies how the DHCP relay service deals with cases where the packet arriving from the client side already contains option-82 information.

By default, the relay agent replaces any existing option-82 field with its own relay agent field. This is equivalent to the functionality of the `replace` parameter.

The `no` parameter removes the policy, and returns it to the default behavior - i.e. replacing the existing option-82 field.

Syntax `ip dhcp-relay information policy [append|drop|keep|replace]`
`no ip dhcp-relay information policy`

Parameter	Description
<code>append</code>	The relay agent appends the option 82 field of the packet with its own option 82 details.
<code>drop</code>	The relay agent discards the packet.
<code>keep</code>	The relay agent forwards the packet without altering the option 82 field.
<code>replace</code>	The relay agent replaces the existing relay agent details in the option 82 field with its own details before forwarding the packet.
<code>no</code>	The <code>no</code> form of this command removes the DHCP relay information policy.

Mode Interface Configuration for a VLAN interface.

Examples To make the relay agent listening on `vlan15` drop any client requests that already contain option-82 information, use the command:

```
awplus(config)# interface vlan15
awplus(config-if)# ip dhcp-relay information policy drop
```

To remove the DHCP relay information policy set with the `ip dhcp information policy` command, use the command:

```
awplus(config)# interface vlan15
awplus(config-if)# no ip dhcp-relay information policy
```

Related Commands [ip dhcp-relay agent-option](#)
[service dhcp-server](#)

ip dhcp-relay maxhops

This command sets the hop count threshold for discarding BOOTP messages. When the hops field in a BOOTP message exceeds the threshold, the relay agent discards the BOOTP message. The hop count threshold is set to 10 hops by default.

Use the `no ip dhcp-relay maxhops` negation command to reset the hop count to the default.

Syntax `ip dhcp-relay maxhops <1-255>`
`no ip dhcp-relay maxhops`

Parameter	Description
<1-255>	The maximum hop count value. Default: 10

Mode Interface Configuration for a VLAN interface.

Default The hop count threshold is set to 10 hops by default, and is reset to the default with negation.

Examples To set the maximum number of hops to 5 for packets arriving in interface `vlan15`, use the command:

```
awplus(config)# interface vlan15
awplus(config-if)# ip dhcp-relay maxhops 5
```

Related Commands [service dhcp-relay](#)

ip dhcp-relay max-message-length

This command applies when the switch is acting as a *DHCP relay* and Option 82 insertion is enabled. It sets the maximum DHCP message length (in bytes) for the DHCP packet with its option 82 data inserted. From this value it calculates the maximum packet size that it will accept at its input. Packets that arrive greater than this value will be dropped.

Syntax `ip dhcp-relay max-message-length <548-1472>`

Parameter	Description
<code>ip dhcp-relay</code>	A device that forwards DHCP packets between a DHCP client and a DHCP server, usually located on a different network.
<code>max-message-length</code>	The maximum length of the DHCP message (in bytes) including the option 82 fields.
<code><548-1472></code>	The maximum DHCP message length (this is the message header plus the inserted DHCP option fields) Default: 1400
<code>no</code>	The no form of this command sets the maximum message length to its default of 1400 bytes.

Mode Interface Configuration for a VLAN interface.

Usage Where a DHCP relay (that has option 82 insertion enabled) receives a *request* packet from a *DHCP client*, it will append the *option 82* component data, and forward the packet to the DHCP server. The DHCP client will sometimes issue packets containing pad option fields that can be overwritten with *option 82* data. Where there are insufficient pad option fields to contain all the option 82 data, the DHCP relay will increase the packet size to accommodate the option 82 data. If the new (increased) packet size exceeds that defined by the maximum-message-length parameter, then the DHCP relay will drop the packet.

Note: *Before setting this command, you must first run the `ip dhcp-relay agent-option` command on page 73.12. This will allow the option 82 fields to be appended.*

Examples To set the maximum DHCP message length to 1200 for packets arriving in interface `vlan7`, use the command:

```
awplus# configure terminal
awplus(config)# interface vlan7
awplus(config-if)# ip dhcp-relay max-message-length 1200
```

Related Commands [service dhcp-relay](#)

ip dhcp-relay server-address

This command adds a server for DHCP relay to forward client DHCP packets to on a particular interface. You can add up to five servers on each interface that the DHCP relay agent is listening on.

The no parameter deletes the specified DHCP server from the list of servers available to the DHCP relay agent.

Syntax `ip dhcp-relay server-address <ip-addr>`
`no ip dhcp-relay server-address <ip-addr>`

Parameter	Description
<ip-addr>	IPv4 address of the DHCP server, in dotted decimal notation.

Mode Interface Configuration for a VLAN interface.

Examples To add a DHCP server 192.0.2.200 to forward to on the interface `vlan100`, use the commands:

```
awplus# configure terminal
awplus(config)# interface vlan100
awplus(config-if)# ip dhcp-relay server-address 192.0.2.200
```

To delete the DHCP server 192.0.2.200 from the list of servers available to the DHCP relay agent on `vlan100`, use the commands:

```
awplus# configure terminal
awplus(config)# interface vlan100
awplus(config-if)# no ip dhcp-relay server-address 192.0.2.200
```

Related Commands [service dhcp-relay](#)

lease

This command sets the expiration time for a leased address for the DHCP address pool you are configuring. The time set by the days, hours, and minutes is cumulative. The default lease time is one day.

The lease details use the pre-defined option 51. Note that if you add a user-defined option 51 using the option command, then you will override any settings created with this command.

Use the infinite parameter to set the lease expiry time to infinite (leases never expire). Use the no parameter to return the lease expiration time back to the default of one day.

Syntax

```
lease <days> <hours> <minutes>
lease infinite
no lease
```

Parameter	Description
<days>	The number of days, from 0 to 30, that the lease expiry time is configured. Default: 1
<hours>	The number of hours, from 0 to 24, that the lease expiry time is configured. Default: 0
<minutes>	The number of minutes, from 0 to 60, the lease expiry time is configured. Default: 0
infinite	The lease never expires.

Mode DHCP Configuration

Examples To set the lease expiration time for address pool P2 to 35 minutes, use the commands:

```
awplus# configure terminal
awplus(config)# ip dhcp pool P2
awplus(dhcp-config)# lease 0 0 35
```

To set the lease expiration time for the address pool Nerv_Office to 1 day, 5 hours, and 30 minutes, use the commands:

```
awplus# configure terminal
awplus(config)# ip dhcp pool Nerv_Office
awplus(dhcp-config)# lease 1 5 30
```

To set the lease expiration time for the pool to never expire, use the command:

```
awplus(dhcp-config)# lease infinite
```

To return the lease expiration time to the default of one day, use the command:

```
awplus(dhcp-config)# no lease
```

Related Commands [service dhcp-server](#)

network (DHCP)

This command sets the network (subnet) that the DHCP address pool applies to.

The no parameter removes the network (subnet) from the DHCP address pool.

Syntax `network {<ip-subnet-addr/prefix-length>|<ip-subnet-addr/mask>}`
`no network`

Parameter	Description
<code><ip-subnet-addr/prefix-length></code>	The IPv4 subnet address in dotted decimal notation followed by the prefix length in slash notation.
<code><ip-subnet-addr/mask></code>	The IPv4 subnet address in dotted decimal notation followed by the subnet mask in dotted decimal notation.

Mode DHCP Configuration

Usage This command will fail if it would make existing ranges invalid. For example, if they do not lie within the new network you are configuring.

The no form of this command will fail if ranges still exist in the pool. You must remove all ranges in the pool before issuing a no network command to remove a network from the pool.

Examples To configure a network for the address pool P2, where the subnet is 192.0.2.5 and the mask is 255.255.255.0, use the commands:

```
awplus# configure terminal
awplus(config)# ip dhcp pool P2
awplus(dhcp-config)# network 192.0.2.5/24
```

or you can use dotted decimal notation instead of slash notation for the subnet-mask:

```
awplus# configure terminal
awplus(config)# ip dhcp pool P2
awplus(dhcp-config)# network 192.0.2.5 255.255.255.0
```

Related Commands [service dhcp-server](#)
[subnet-mask](#)

next-server

This command sets the next server address for a DHCP server pool. It is the address of the next server that the client should use in its bootstrap process.

The no parameter removes the next server address from the DHCP address pool.

Syntax `next-server <ip-address>`
`no next-server`

Parameter	Description
<code>next-server</code>	Configures the IP address of the next server in the boot process.
<code><ip-address></code>	The server IP address, entered in dotted decimal notation.
<code>no</code>	Removes the server IP address

Mode DHCP Configuration

Examples To set the next-server address for the address pool P2, use the commands:

```
awplus# configure terminal
awplus(config)# ip dhcp pool P2
awplus(dhcp-config)# next-server 192.0.2.2
```

option

This command adds a user-defined option to the DHCP address pool you are configuring. For the hex, integer, and flag option types, if the option already exists, the new option overwrites the existing option's value. Options with an ip type can hold a list of IP addresses or masks (i.e. entries that have the A.B.C.D address format), so if the option already exists in the pool, then the new IP address is added to the list of existing IP addresses.

Options with the same number as one of the pre-defined options override the standard option definition. The pre-defined options use the option numbers 1, 3, 6, 15, and 51.

The no parameter removes the specified user-defined option from the DHCP pool, or all user-defined options from the DHCP pool.

Syntax `option [<1-254>|<option-name>] <option-value>`
`no option [<1-254>|<option-value>]`

Parameter	Description
<code><1-254></code>	The option number of the option. Options with the same number as one of the standard options overrides the standard option definition.
<code><option-name></code>	Option name associated with the option.
<code><option-value></code>	The option value. You must specify a value that is appropriate to the option type:
hex	A hexadecimal string. Valid characters are the numbers 0–9 and letters a–f. Embedded spaces are not valid. The string must be an even number of characters, from 2 and 256 characters long.
ip	An IPv4 address or mask that has the dotted decimal A.B.C.D notation. To create a list of IP addresses, you must add each IP address individually using the option command multiple times.
integer	A number from 0 to 4294967295.
flag	A value of either true, on, or enabled to set the flag, or false, off or disabled to unset the flag.

Mode DHCP Configuration

Examples To add the ASCII-type option named `tftp-server-name` to the pool P2 and give the option the value `server1`, use the commands:

```
awplus# configure terminal
awplus(config)# ip dhcp pool P2
awplus(dhcp-config)# option tftp-server-name server1
```

To add the hex-type option named `tcpip-node-type` to the pool `P2` and give the option the value `08af`, use the commands:

```
awplus# configure terminal
awplus(config)# ip dhcp pool P2
awplus(dhcp-config)# option tcpip-node-type 08af
```

To add multiple IP addresses for the `ip-type` option `175`, use the command:

```
awplus(dhcp-config)# option 175 192.0.2.6
awplus(dhcp-config)# option 175 192.0.2.12
awplus(dhcp-config)# option 175 192.0.2.33
```

To add the option `179` to a pool, and give the option the value `123456`, use the command:

```
awplus(dhcp-config)# option 179 123456
```

To add a user-defined flag option with the name `perform-router-discovery`, use the command:

```
awplus(dhcp-config)# option perform-router-discovery yes
```

To clear all user-defined options from a DHCP address pool, use the command:

```
awplus(dhcp-config)# no option
```

To clear a user-defined option, named `tftp-server-name`, use the command:

```
awplus(dhcp-config)# no option tftp-server-name
```

Related Commands [ip dhcp option](#)
 [service dhcp-server](#)
 [show ip dhcp pool](#)

range

This command adds an address range to the DHCP address pool you are configuring. The DHCP server responds to client requests received from the pool's network. It assigns an IP addresses within the specified range. The IP address range must lie within the network. You can add multiple address ranges and individual IP addresses for a DHCP pool by using this command multiple times.

The no parameter removes an address range from the DHCP pool. Use the no range all command to remove all address ranges from the DHCP pool.

Syntax

```
range <ip-address> [<ip-address>]
no range <ip-address> [<ip-address>]
no range all
```

Parameter	Description
<ip-address>	IPv4 address range for DHCP clients, in dotted decimal notation. The first IP address is the low end of the range, the second IP address is the high end. Specify only one IP address to add an individual IP address to the address pool.

Mode DHCP Configuration

Examples To add an address range of 192.0.2.5 to 192.0.2.16 to the pool Nerv_Office, use the command:

```
awplus# configure terminal
awplus(config)# ip dhcp pool Nerv_Office
awplus(dhcp-config)# range 192.0.2.5 192.0.2.16
```

To add the individual IP address 192.0.2.2 to a pool, use the command:

```
awplus(dhcp-config)# range 192.0.2.2
```

To remove all address ranges from a pool, use the command:

```
awplus(dhcp-config)# no range all
```

Related Commands

- ip dhcp pool
- service dhcp-server
- show ip dhcp pool

service dhcp-relay

This command enables the DHCP relay agent on the device. However, on a given IP interface, no DHCP forwarding takes place until at least one DHCP server is specified to forward/relay all clients' DHCP packets to.

The no parameter disables the DHCP relay agent on the device for all interfaces.

Syntax service dhcp-relay
 no service dhcp-relay

Mode Global Configuration

Default The DHCP-relay service is enabled by default.

Examples To enable the DHCP relay global function, use the command:

```
awplus# configure terminal
awplus(config)# service dhcp-relay
```

To disable the DHCP relay global function, use the command:

```
awplus# configure terminal
awplus(config)# no service dhcp-relay
```

Related Commands ip dhcp-relay agent-option
 ip dhcp-relay agent-option checking
 ip dhcp-relay information policy
 ip dhcp-relay maxhops
 ip dhcp-relay server-address

service dhcp-server

This command enables the DHCP server on your device. The server then listens for DHCP requests on all IP interfaces. It will not run if there are no IP interfaces configured.

The no parameter disables the DHCP server.

Syntax service dhcp-server
 no service dhcp-server

Mode Global Configuration

Examples To enable the DHCP server, use the command:

```
awplus# configure terminal
awplus(config)# service dhcp-server
```

Related Commands ip dhcp pool
 show ip dhcp server summary
 subnet-mask

show counter dhcp-client

This command shows counters for the dhcp client on your device.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show counter dhcp-client`

Mode Exec and Privileged Exec

Examples To display the message counters for the DHCP client on your device, use the command:

```
awplus# show counter dhcp-client
```

Output Figure 73-1: Example output from the **show counter dhcp-client** command

```
show counter dhcp-client

DHCPDISCOVER out      ..... 10
DHCPREQUEST out       ..... 34
DHCPDECLINE out       ..... 4
DHCPRELEASE out       ..... 0
DHCPOFFER in          ..... 22
DHCPACK in            ..... 18
DHCPNAK in            ..... 0
```

Table 73-1: Parameters in the output from the show counter dhcp-client command

Parameter	Meaning
DHCPDISCOVER out	The number of DHCP Discover messages sent by the client.
DHCPREQUEST out	The number of DHCP Request messages sent by the client.
DHCPDECLINE out	The number of DHCP Decline messages sent by the client.
DHCPRELEASE out	The number of DHCP Release messages sent by the client.
DHCPOFFER in	The number of DHCP Offer messages received by the client.
DHCPACK in	The number of DHCP Acknowledgement messages received by the client.
DHCPNAK in	The number of DHCP Negative Acknowledgement messages received by the client.

Related Commands [ip address dhcp](#)

show counter dhcp-relay

This command shows counters for the DHCP relay agent on your device.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show counter dhcp-relay`

Mode Exec and Privileged Exec

Examples To display counters for the DHCP relay agent on your device, use the command:

```
awplus# show counter dhcp-relay
```

Output Figure 73-2: Example output from the `show counter dhcp-relay` command

```
show counter dhcp-relay

Requests In           ..... 4
Replies In            ..... 4
Relayed To Server     ..... 4
Relayed To Client     ..... 4
Out To Server Failed  ..... 0
Out To Client Failed  ..... 0
Invalid hlen          ..... 0
Bogus giaddr          ..... 0
Corrupt Agent Option  ..... 0
Missing Agent Option  ..... 0
Bad Circuit ID        ..... 0
Missing Circuit ID     ..... 0
Option Insert Failed  ..... 0
```

Table 73-2: Parameters in the output from the `show counter dhcp-relay` command

Parameter	Meaning
Requests In	The number of DHCP Request messages received from clients.
Replies In	The number of DHCP Reply messages received from servers.
Relayed To Server	The number of DHCP Request messages relayed to servers.
Relayed To Client	The number of DHCP Reply messages relayed to clients.
Out To Server Failed	The number of failures when attempting to send request messages to servers. This is an internal debugging counter.
Out To Client Failed	The number of failures when attempting to send reply messages to clients. This is an internal debugging counter.
Invalid hlen	The number of incoming messages dropped due to an invalid hlen field.
Bogus giaddr	The number of incoming DHCP Reply messages dropped due to bogus giaddr field.
Corrupt Agent Option	The number of incoming DHCP Reply messages dropped due to corrupt agent option.
Missing Agent Option	The number of incoming DHCP Reply messages dropped due to missing agent option.
Bad Circuit ID	The number of incoming DHCP Reply messages dropped due to bad circuit ID.

Table 73-2: Parameters in the output from the **show counter dhcp-relay** command

Parameter	Meaning
Missing Circuit ID	The number of incoming DHCP Reply messages dropped due to missing circuit ID.
Option Insert Failed	The number of incoming DHCP Request messages dropped due to an error adding the relay agent information (option 82). This counter increments when: the relay agent is set to drop packets with the option 82 field already filled by another relay agent. This policy is set with the ip dhcp-relay information policy command. there is a packet error that stops the relay agent from being able to append the packet with its relay agent option information.

Related Commands [service dhcp-relay](#)
[show ip dhcp-relay](#)

show counter dhcp-server

This command shows counters for the DHCP server on your device.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show counter dhcp-server`

Mode Exec and Privileged Exec

Examples To display counters for the DHCP server on your device, use the command:

```
awplus# show counter dhcp-server
```

Output Figure 73-3: Example output from the **show counter dhcp-server** command

```
DHCP server counters
DHCPDISCOVER in      ..... 20
DHCPREQUEST in       ..... 12
DHCPDECLINE in        ..... 1
DHCPRELEASE in        ..... 0
DHCPINFORM in         ..... 0
DHCPOFFER out         ..... 8
DHCPACK out           ..... 4
DHCPNAK out           ..... 0
BOOTREQUEST in        ..... 0
BOOTREPLY out         ..... 0
```

Table 73-3: Parameters in the output from the **show counter dhcp-server** command

Parameter	Meaning
DHCPDISCOVER in	The number of Discover messages received by the DHCP server.
DHCPREQUEST in	The number of Request messages received by the DHCP server.
DHCPDECLINE in	The number of Decline messages received by the DHCP server.
DHCPRELEASE in	The number of Release messages received by the DHCP server.
DHCPINFORM in	The number of Inform messages received by the DHCP server.
DHCPOFFER out	The number of Offer messages sent by the DHCP server.
DHCPACK out	The number of Acknowledgement messages sent by the DHCP server.
DHCPNAK out	The number of Negative Acknowledgement messages sent by the DHCP server. The server sends these after receiving a request that it cannot fulfil because either there are no available IP addresses in the related address pool, or the request has come from a client that doesn't fit the network setting for an address pool.
BOOTREQUEST in	The number of bootp messages received by the DHCP server from bootp clients.
BOOTREPLY out	The number of bootp messages sent by the DHCP server to bootp clients.

Related Commands

- `service dhcp-server`
- `show ip dhcp binding`
- `show ip dhcp server statistics`

show ip dhcp pool

show dhcp lease

This command shows details about the leases that the DHCP client has acquired from a DHCP server for interfaces on the device.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax show dhcp lease [<interface>]

Parameter	Description
<interface>	Interface name to display dhcp lease details for

Mode Exec and Privileged Exec

Examples To show the current lease expiry times for all interfaces, use the command:

```
awplus# show dhcp lease
```

To show the current lease for vlan1, use the command:

```
awplus# show dhcp lease vlan1
```

Output Figure 73-4: Example output from the **show dhcp lease [<interface>]** command

```
Interface vlan1
-----
IP Address:                192.168.22.4
Expires:                   13 Mar 2007 20:10:19
Renew:                     13 Mar 2007 18:37:06
Rebind:                    13 Mar 2007 19:49:29
Server:
Options:
  subnet-mask              255.255.255.0
  routers                  19.18.2.100,12.16.2.17
  dhcp-lease-time          3600
  dhcp-message-type        5
  domain-name-servers      192.168.100.50,19.88.200.33
  dhcp-server-identifier   192.168.22.1
  domain-name              alliedtelesis.com

Interface vlan2
-----
IP Address:                100.8.16.4
Expires:                   13 Mar 2007 20:15:39
Renew:                     13 Mar 2007 18:42:25
Rebind:                    13 Mar 2007 19:54:46
Server:
Options:
  subnet-mask              255.255.0.0
  routers                  10.58.1.51
  dhcp-lease-time          1000
  dhcp-message-type        5
  dhcp-server-identifier   100.8.16.1
```

Related Commands ip address dhcp

show ip dhcp binding

This command shows the lease bindings that the DHCP server has allocated clients.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip dhcp binding [<ip-addr>|<addr-pool>]`

Parameter	Description
<code><ip-addr></code>	IPv4 address of a leased IP address, in dotted decimal notation. This displays the lease information for the specified IP address.
<code><addr-pool></code>	Name of an address pool. This displays the lease information for all clients within the address pool.

Mode Exec and Privileged Exec

Examples To display all leases for every client in all address pools, use the command:

```
awplus# show ip dhcp binding
```

To display the details for the leased IP address 172.16.2.16, use the command:

```
awplus# show ip dhcp binding 172.16.2.16
```

To display the leases from the address pool MyPool, use the command:

```
awplus# show ip dhcp binding MyPool
```

Output Figure 73-5: Example output from the **show ip dhcp binding** command

```
Pool 30_2_network Network 172.16.2.0/24
DHCP Client Entries
IP Address      ClientId                Type      Expiry
-----
172.16.2.100    0050.fc82.9ede          Dynamic   21 Sep 2007 19:02:58
172.16.2.101    000e.a6ae.7c14          Static    Infinite
172.16.2.102    000e.a6ae.7c4c          Static    Infinite
172.16.2.103    000e.a69a.ac91          Static    Infinite
172.16.2.104    00e0.189d.5e41          Static    Infinite
172.16.2.150    00e0.2b04.5800          Static    Infinite
172.16.2.167    4444.4400.35c3          Dynamic   21 Sep 2007 14:58:41
```

Related Commands

- `ip dhcp pool`
- `lease`
- `range`
- `service dhcp-server`
- `show ip dhcp pool`

show ip dhcp pool

This command displays the configuration details and system usage of the DHCP address pools configured on the device.

For information on output options, see [“Controlling “show” command output” on page 1.33.](#)

Syntax `show ip dhcp pool [<addr-pool>]`

Parameter	Description
<name>	Name of a specific address pool. This displays the configuration of the specified address pool only.

Mode Exec and Privileged Exec

Example 1

```
awplus# show ip dhcp pool
```

Output Figure 73-6: Example output from the **show ip dhcp pool** command

```
Pool p1 :
network: 192.168.1.0/24
address ranges:
  addr: 192.168.1.10 to 192.168.1.18
static host addresses:
  addr: 192.168.1.12      MAC addr: 1111.2222.3333
lease <days:hours:minutes:seconds> <1:0:0:0>
subnet mask: 255.255.255.0 (pool's network mask)
Dynamic addresses:
  Total:      8
  Leased:     2
  Utilization: 25.0 %
Static host addresses:
  Total:      1
  Leased:     1
```

Example 2

awplus# show ip dhcp pool

Output Figure 73-7: Example output from the **show ip dhcp pool** command with IP address 192.168.1.12 assigned to a VLAN interface on the device:

```
Pool p1 :
  network: 192.168.1.0/24
  address ranges:
    addr: 192.168.1.10 to 192.168.1.18
        (interface addr 192.168.1.12 excluded)
        (static host addr 192.168.1.12 excluded)
  static host addresses:
    addr: 192.168.1.12      MAC addr: 1111.2222.3333
        (= interface addr, so excluded)
  lease <days:hours:minutes:seconds> <1:0:0:0>
  subnet mask: 255.255.255.0 (pool's network mask)
  Dynamic addresses:
    Total:      8
    Leased:     2
    Utilization: 25.0 %
  Static host addresses:
    Total:      1
    Leased:     1
```

Table 73-4: Parameters in the output of the show ip dhcp pool command

Parameter	Meaning
Pool	Name of the pool.
network	Subnet and mask length of the pool.
address ranges	Individual IP addresses and address ranges configured for the pool. The DHCP server can offer clients an IP address from within the specified ranges only. Any of these addresses that match an interface address on the device, or a static host address configured in the pool, will be automatically excluded from the range, and a message to this effect will appear beneath the range entry.
static host addresses	The static host addresses configured on the pool. Each IP address is permanently assigned to the client with the matching MAC address. Any of these addresses that match an interface address on the device will be automatically excluded, and a message to this effect will appear beneath the static host entry.
lease <days:hours:minutes>	The lease duration for address allocated by this pool.
domain	The domain name sent by the pool to clients. This is the domain name that the client should use when resolving host names using DNS.
subnet mask	The subnet mask sent by the pool to clients.
dns servers	The DNS server addresses sent to by the pool to clients.
default-router(s)	The default router addresses sent by the pool to clients.
user-defined options	The list of user-defined options sent by the pool to clients.
Dynamic addresses - Total	The total number of IP addresses that have been configured in the pool for dynamic allocation to DHCP clients.

Table 73-4: Parameters in the output of the show ip dhcp pool command

Parameter	Meaning
Dynamic addresses - Leased	The number of IP addresses in the pool that have been dynamically allocated (leased) to DHCP clients.
Dynamic addresses - Utilization	The percentage of IP addresses in the pool that are currently dynamically allocated to clients.
Static host addresses - Total	The number of static IP addresses configured in the pool for specific DHCP client hosts.
Static host addresses - Leased	The number of static IP addresses assigned to specific DHCP client hosts.

Example 3 To display the configuration and usage details for all DHCP pools, use the command:

```
awplus# show ip dhcp pool
```

Related Commands

- ip dhcp pool
- range
- service dhcp-server
- subnet-mask

show ip dhcp-relay

This command shows the configuration of the DHCP relay agent on each interface.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show ip dhcp-relay [interface <interface>]`

Parameter	Description
<interface>	Name of a specific interface. This displays the DHCP configuration for the specified interface only.

Mode Exec and Privileged Exec

Examples To display the DHCP relay agent's configuration on the interface `vlan100`, use the command:

```
awplus# show ip dhcp-relay interface vlan100
```

Output Figure 73-8: Example output from the **show ip dhcp-relay** command

```
DHCP Relay Service is enabled
vlan100 is up, line protocol is up
Maximum hop count is 10
Insertion of Relay Agent Option is disabled
Checking of Relay Agent Option is disabled
Relay information policy is to append new relay agent information
List of servers :    192.168.1.200
```

Related Commands

- `ip dhcp-relay agent-option`
- `ip dhcp-relay agent-option checking`
- `ip dhcp-relay information policy`
- `ip dhcp-relay maxhops`
- `ip dhcp-relay server-address`

show ip dhcp server statistics

This command shows statistics related to the DHCP server.

You can display the server counters using the `show counter dhcp-server` command as well as with this command.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show ip dhcp server statistics`

Mode Exec and Privileged Exec

Examples To display the server statistics, use the command:

```
awplus# show ip dhcp server statistics
```

Output Figure 73-9: Example output from the `show counter dhcp server statistics` command

```
DHCP server counters
DHCPDISCOVER in      ..... 20
DHCPREQUEST in       ..... 12
DHCPDECLINE in       ..... 1
DHCPRELEASE in       ..... 0
DHCPIFORM in         ..... 0
DHCP OFFER out        ..... 8
DHCPACK out          ..... 4
DHCPNAK out           ..... 0
BOOTREQUEST in       ..... 0
BOOTREPLY out        ..... 0
```

Figure 73-10: Parameters in the output from the `show counter dhcp server statistics` command

Parameter	Meaning
DHCPDISCOVER in	The number of Discover messages received by the DHCP server.
DHCPREQUEST in	The number of Request messages received by the DHCP server.
DHCPDECLINE in	The number of Decline messages received by the DHCP server.
DHCPRELEASE in	The number of Release messages received by the DHCP server.
DHCPIFORM in	The number of Inform messages received by the DHCP server.
DHCP OFFER out	The number of Offer messages sent by the DHCP server.
DHCPACK out	The number of Acknowledgement messages sent by the DHCP server.
DHCPNAK out	The number of Negative Acknowledgement messages sent by the DHCP server. The server sends these after receiving a request that it cannot fulfil because either there are no available IP addresses in the related address pool, or the request has come from a client that doesn't fit the network setting for an address pool.
BOOTREQUEST in	The number of bootp messages received by the DHCP server from bootp clients.
BOOTREPLY out	The number of bootp messages sent by the DHCP server to bootp clients.

Related Commands [show counter dhcp-server](#)
[service dhcp-server](#)
[show ip dhcp binding](#)
[show ip dhcp pool](#)

show ip dhcp server summary

This command shows the current configuration of the DHCP server. This includes:

- whether the DHCP server is enabled
- whether the DHCP server is configured to ignore BOOTP requests
- the details of any user-defined options
- a list of the names of all DHCP address pools currently configured

This show command does not include any configuration details of the address pools. You can display these using the [show ip dhcp pool](#) command.

For information on output options, see “Controlling “show” command output” on page 1.33.

Syntax `show ip dhcp server summary`

Mode Exec and Privileged Exec

Examples To display the current configuration of the DHCP server, use the command:

```
awplus# show ip dhcp server summary
```

Output Figure 73-11: Example output from the **show ip dhcp** command

```
dhcp server enabled
dhcp server BOOTP ignore disabled
dhcp server user-defined option definitions:
  num: 46      name: tcpip-node-type      type: hex string
  num: 175     name: special-address      type: IP address
  num: 179     name:                      type: integer
dhcp pool list: p1 p2
```

Related Commands [ip dhcp pool](#)
[service dhcp-server](#)

subnet-mask

This command sets the subnet mask option for a DHCP address pool you are configuring. Use this command to specify the client's subnet mask as defined in RFC 950. This sets the subnet details using the pre-defined option 1. Note that if you create a user-defined option 1 using the [option](#) command, then you will override any settings created with this command. If you do not specify a subnet mask using this command, then the pool's network mask (specified using the [next-server](#) command) is applied.

The no parameter removes a subnet mask option from a DHCP pool. The pool reverts to using the pool's network mask.

Syntax subnet-mask <mask>

no subnet-mask

Parameter	Description
<mask>	Valid IPv4 subnet mask, in dotted decimal notation.

Mode DHCP Configuration

Examples To set the subnet mask option to 255.255.255.0 for DHCP pool P2, use the commands:

```
awplus# configure terminal
awplus(config)# ip dhcp pool P2
awplus(dhcp-config)# subnet-mask 255.255.255.0
```

To remove the subnet mask option from DHCP pool P2, use the commands:

```
awplus# configure terminal
awplus(config)# ip dhcp pool P2
awplus(dhcp-config)# no subnet-mask
```

Related Commands

- default-router
- dns-server
- domain-name
- next-server
- option
- service dhcp-server
- show ip dhcp pool

Chapter 74: SNMP Introduction

Introduction.....	74.2
Network Management Framework.....	74.2
Structure of Management Information.....	74.4
Names.....	74.5
Instances.....	74.6
Syntax.....	74.6
Access.....	74.6
Status.....	74.7
Description.....	74.7
The SNMP Protocol.....	74.8
SNMP Versions.....	74.8
SNMP Messages.....	74.8
Polling versus Event Notification.....	74.9
Message Format for SNMPv1 and SNMPv2c.....	74.9
SNMP Communities (Version v1 and v2c).....	74.10
SNMPv3 Entities.....	74.10
SNMP Engine.....	74.10
SNMPv3 Message Protocol Format.....	74.11
SNMPv1 and SNMPv2c.....	74.12
SNMP MIB Views for SNMPv1 and SNMPv2c.....	74.12
SNMP Communities.....	74.12
Configuration Example (SNMPv1 and v2).....	74.14
SNMPv3.....	74.16
SNMP MIB Views for SNMPv3.....	74.16
SNMP Groups.....	74.16
SNMP Users.....	74.16
SNMP Target Addresses.....	74.16
SNMP Target Params.....	74.16
Configuration Example (SNMPv3).....	74.17
Using SNMP to Manage Files and Software.....	74.17
Copy a File to or from a TFTP Server.....	74.18
Upgrade Software and Configuration Files.....	74.19

Introduction

The Simple Network Management Protocol (SNMP) is the network management protocol of choice for the Internet and IP-based internetworks.

This chapter describes the main features of SNMP Version 1 (SNMPv1), SNMP Version 2c (SNMPv2c) and Version 3 (SNMPv3). It also describes support for SNMP on the switch, and how to configure the switch's SNMP agent.

Unless a particular version of SNMP is named, "SNMP" in this chapter refers to versions SNMPv1, SNMPv2c and SNMPv3.


See also [Chapter 75, SNMP Commands](#) and [Chapter 76, SNMP MIBs](#).

Network Management Framework

A network management system has the following components:

- One or more *managed devices*, each containing an agent that provides the management functions. A managed device may be any computing device with a network capability, for example, a host system, workstation, terminal server, printer, router, switch, bridge, hub or repeater.
- One or more *Network Management Stations (NMS)*. An NMS is a host system running a network management protocol and network management applications, enabling the user to manage the network.
- A *network management protocol* used by the NMS and agents to exchange information.

Figure 74-1: Components of a network management system



The Internet-standard Network Management Framework is the framework used for network management in the Internet. The framework was originally defined by the following documents:

- RFC 1155, *Structure and identification of management information for TCP/IP based internets* (referred to as the SMI), details the mechanisms used to describe and name the objects to be managed.
- RFC 1213, *Management Information Base for network management of TCP/ IP-based internets: MIB-II* (referred to as MIB-II), defines the core set of managed objects for the Internet suite of protocols. The set of managed objects can be extended by adding other MIBs specific to particular protocols, interfaces or network devices.
- RFC 1157, *A Simple Network Management Protocol (SNMP)*, is the protocol used for communication between management stations and managed devices.

Subsequent documents that have defined SNMPv2c are:

- RFC 1901, *Introduction to Community-based SNMPv2*
- RFC 1902, *Structure of Management Information for Version 2 of the Simple Network Management Protocol (SNMPv2)*
- RFC 1903, *Textual Conventions for Version 2 of the Simple Network Management Protocol (SNMPv2)*
- RFC 1904, *Conformance Statements for Version 2 of the Simple Network Management Protocol*
- RFC 1905, *Protocol Operations for Version 2 of the Simple Network Management Protocol (SNMPv2)*
- RFC 1906, *Transport Mappings for Version 2 of the Simple Network Management Protocol (SNMPv2)*
- RFC 1907, *Management Information Base for Version 2 of the Simple Network Management Protocol (SNMPv2)*
- RFC 2576, *Coexistence between Version 1, Version 2, and Version 3 of the Internet-standard Network Management Framework*
- RFC 2578, *Structure of Management Information Version 2 (SMIv2)*
- RFC 2579, *Textual Conventions for SMIv2*
- RFC 2580, *Conformance Statements for SMIv2*

Subsequent documents that have defined SNMPv3 are:

- RFC 3410, *Introduction and Applicability Statements for Internet Standard Management Framework*
- RFC 3411, *An Architecture for Describing Simple Network Management Protocol (SNMP) Management Frameworks*
- RFC 3412, *Message Processing and Dispatching for the Simple Network Management Protocol (SNMP)*
- RFC 3413, *Simple Network Management Protocol (SNMP) Applications*
- RFC 3414, *User-based Security Model (USM) for version 3 of the Simple Network Management Protocol (SNMPv3)*
- RFC 3415, *View-based Access Control Model (VACM) for the Simple Network Management Protocol (SNMP)*
- RFC 3416, *Version 2 of the Protocol Operations for the Simple Network Management Protocol (SNMP)*
- RFC 3417, *Transport Mappings for the Simple Network Management Protocol (SNMP)*
- RFC 3418, *Management Information Base (MIB) for the Simple Network Management Protocol (SNMP)*


Structure of Management Information

The structure of management information (SMI) defines the schema for a collection of managed objects residing in a virtual store called the management information base (MIB). The information in a MIB includes administrative and operational configuration information, as well as counters of system events and activities.

The MIB is organized into a tree-like hierarchy in which nodes are each assigned an identifier consisting of a non-negative integer and an optional brief textual description.

Each managed object is represented by a leaf node and is defined by its name, syntax, access mode, status and description. It can also be specifically identified by its unique position within the tree. This position is expressed as a series of dot-delimited sub-identifiers that start at the root node and end in the sub-identifier at the particular object's leaf node. For example, in [Figure 74-2](#) the object named interfaces would be uniquely identified by the string of individual sub-identifiers, 1.3.6.1.2.1.2.

Figure 74-2: Top levels of the Internet-standard Management Information Base (MIB)



Objects defined in the Internet-standard MIB (MIB-II) reside in the mib(1) sub-tree.

Names

Names are used to identify managed objects, and are hierarchical in nature. An object identifier is a globally unique, authoritatively assigned sequence of non-negative integers which traverse the MIB tree from the root to the node containing the object.

Object identifiers may be represented in one of the following forms:

- Dotted notation lists the integer values found by traversing the tree from the root to the node in question, separated by dots. For example, the following identifies the MIB-II sub-tree:

```
1.3.6.1.2.1
```

The following identifies the sysDescr object in the system group of MIB-II:

```
1.3.6.1.2.1.1.1
```

- Textual notation lists the textual descriptions found by traversing the tree from the root to the node in question, separated by spaces and enclosed in braces. For following example identifies the internet sub-tree:

```
{ iso org dod 1 }
```

The name may be abbreviated to a relative form. The following example identifies the first (directory) node of the internet sub-tree:

```
{ internet 1 }
```

- Combined notation lists both the integer values and textual descriptions found by traversing the tree from the root to the node in question. The integer value is placed in parentheses after the textual description. The labels are separated by spaces and enclosed in braces. For example, the following identifies the first (directory) node in the internet sub-tree:

```
{iso(1) org(3) dod(6) internet(1) 1}
```

The name may be abbreviated to the following:

```
directory(1)
```

Since there is no effective limit to the magnitude of non-negative integers, and no effective limit to the depth of the tree, the MIB provides an unlimited name space.

An object is also usually assigned an object descriptor. The object descriptor is a unique, mnemonic, printable string intended for humans to use when discussing the MIB.

Instances

Objects are just templates for data types. An actual value that can be manipulated by an NMS is an instance of an object. An instance is named by appending an instance identifier to the end of the object's object identifier. The instance identifier depends on the object's data type:

- If the object is not a column in a table, the instance identifier is 0 (zero). For example, the instance of the sysDescr object is:

```
sysDescr.0
or 1.3.6.1.2.1.1.1.0
```

- If the object is a column in a table, the method used to assign an instance identifier varies. Typically, the value of the index column or columns is used.

The object ifTable in MIB-II contains information about interfaces and is indexed by the interface number, ifIndex. The instance of the ifDescr object for the first interface is:

```
ifDescr.1
or 1.3.6.1.2.1.2.2.1.2.1
```

If the index column is an IP address, the entire IP address is used as the instance identifier. The object ipRouteTable in MIB-II contains information about IP routes and is indexed by the destination address, ipRouteDest. The instance of the ipRouteNextHop object for the route 131.203.9.0 is:

```
ipRouteNextHop.131.203.9.0
or 1.3.6.1.2.1.4.21.1.7.131.203.9.0
```

If the table has more than one index, the values of all the index columns are combined to form the instance identifier. The object tcpConnTable in MIB-II contains information about existing TCP connections and is indexed by the local IP address (tcpConnLocalAddress), the local port number (tcpConnLocalPort), the remote IP address (tcpConnRemAddress) and the remote port number (tcpConnRemPort) of the TCP connection. The instance of the tcpConnState object for the connection between 131.203.8.36,23 and 131.203.9.197,1066 is:

```
tcpConnState.131.203.8.36.23.131.203.9.197.1066
or 1.3.6.1.2.1.6.13.1.1.131.203.8.36.23.131.203.9.197.1066
```

Syntax

The syntax of an object describes the abstract data structure corresponding to that object type. For example, INTEGER or OCTET STRING.

Access

The access mode of an object describes the level of access for the object.

Access modes for MIB objects:

Access	Description
Read-only	The object's value can be read but not set.
Read-write	The object's value can be read and set.
Write-only	The object's value can be set but not read.
Not-accessible	The object's value cannot be read or set.

Status

The status of an object describes the implementation requirements for the object.

Status values for MIB objects:

Status	Description
Mandatory	Managed devices must implement the object.
Optional	Managed devices may implement the object.
Obsolete	Managed devices need no longer implement the object.
Deprecated	Managed devices should implement the object. However, the object may be deleted from the next version of the MIB. A new object with equal or superior functionality is defined.

Description

The definition of an object may include an optional textual description of the meaning and use of the object. This description is often essential for successful understanding of the object.

The SNMP Protocol

The SNMP protocol provides a mechanism for management entities, or stations, to extract information from the Management Information Base (MIB) of a managed device.

The normal method of accessing information in a MIB is to use a Network Management Station (NMS), typically a PC or workstation, to send commands to the managed device (in this case the switch) using the SNMP protocol.

SNMP can use a number of different protocols as its underlying transport mechanism, but the most common transport protocol, and the only one supported by the switch, is UDP. Therefore the IP module must be enabled and properly configured in order to use SNMP. SNMP trap messages are sent to UDP port 162; all other SNMP messages are sent to UDP port 161. The switch's SNMP agent accepts SNMP messages up to the maximum UDP length the switch can receive.

Other transport mappings have been defined (e.g. OSI [RFC 1418], AppleTalk [RFC 1419] and IPX [RFC 1420]), but the standard transport mapping for the Internet (and the one the switch uses) is UDP. The IP module must be enabled and configured correctly. See [Chapter 25, IP Addressing and Protocol Commands](#) for detailed descriptions of the commands required to enable and configure IP.

SNMP Versions

The switch supports SNMP version 1 (SNMPv1), SNMP version 2c (SNMPv2c) and SNMP Version 3 (SNMPv3). The three versions operate similarly.

SNMPv2c updated the original protocol, and offered the following main enhancements:

- a new format for trap messages.
- the get-bulk-request PDU allows for the retrieval of large amounts of data, including tables, with one message.
- more error codes mean that error responses to set messages have more detail than is possible with SNMPv1.
- three new exceptions to errors can be returned for get, get-next and get-bulk-request messages. These are: noSuchObject, noSuchInstance, and endOfMibView.

SNMPv3 provides significant enhancements to address the security weaknesses existing in the earlier versions. This is achieved by implementing two new major features:

- Authentication - by using password hashing and time stamping.
- Privacy - by using message encryption.

Support for multiple versions of SNMP is achieved by responding to each SNMP request with a response of the same version. For example, if an SNMPv1 request is sent to the switch, an SNMPv1 response is returned. If an SNMPv2c request is sent, an SNMPv2c response is returned. Therefore, authentication and encryption functions are not invoked when messages are detected as having either an SNMPv1 or SNMPv2c protocol format.

SNMP Messages

The SNMP protocol is termed simple because it has only six operations, or messages—get, get-next, get-response, set, and trap, and SNMPv2c also has the get-bulk-request message. The replies from the managed device are processed by the NMS and generally used to provide a graphical representation of the state of the network. The two major SNMP operations available to a management station for interacting with a client are the get and set operations. The SNMP

set operator can lead to security breaches, since SNMP is not inherently very secure. When forced to operate in either SNMPv1 or v2 mode, when operating with older management stations for example, care must be taken in the choice and safe-guarding of community names, which are effectively passwords for SNMP.

Polling versus Event Notification

SNMP employs a polling paradigm. A Network Management Station (NMS) polls the managed device for information as and when it is required, by sending get-request, get-next-request, and/or get-bulk-request PDUs to the managed device. The managed device responds by returning the requested information in a get-response PDU. The NMS may manipulate objects in the managed device by sending a set-request PDU to the managed device.

The only time that a managed device initiates an exchange of information is in the special case of a trap PDU. A managed device may generate a limited set of traps to notify the NMS of critical events that may affect the ability of the NMS to communicate with the managed device or other managed devices on the network, and therefore to “manage” the network. Such events include the restarting or re-initialization of a device, a change in the status of a network link (up or down), or an authentication failure.

Message Format for SNMPv1 and SNMPv2c

Fields in an SNMP message:

Field	Function
Version	The version of the SNMP protocol. The value is version-1 (0) for the SNMP protocol as defined in RFC 1157, or version-2c (1) for the SNMP protocol as defined in RFC 1902.
Community	The name of an SNMP community, for authentication purposes
SNMP PDU	An SNMP Protocol Data Unit (PDU).

SNMP PDUs:

PDU	Function
get-request	Sent by an NMS to an agent, to retrieve the value of an object.
get-next-request	Sent by an NMS to an agent, to retrieve the value of the next object in the sub-tree. A sub-tree is traversed by issuing a get-request PDU followed by successive get-next-request PDUs.
get-bulk-request	Sent by an NMS to an agent to request a large amount of data with a single message. This is for SNMPv2c messages.
set-request	Sent by an NMS to an agent, to manipulate the value of an object. SNMP PDU Version Community
get-response	Sent by an agent to an NMS in response to a get-request, get-next-request, get-bulk-response, or set-request PDU.
trap	Sent by an agent to an NMS to notify the NMS of an extraordinary event.
report	Although not explicitly defined in the RFCs, reports are used for specific purposes such as EngineID discovery and time synchronization.

Generic SNMP traps

Value	Meaning
coldStart	The agent is re-initializing itself. Objects may be altered.
warmStart	The agent is re-initializing itself. Objects are not altered.
linkDown	An interface has changed state from up to down.
linkUp	An interface has changed state from down to up.
authenticationFailure	An SNMP message has been received with an invalid community name.
egpNeighborLoss	An EGP peer has transitioned to down state.

SNMP Communities (Version v1 and v2c)

A community is a relationship between an NMS and an agent. The community name is used like a password for a trivial authentication scheme. Both SNMPv1 and SNMPv2c provide security based on the community name only. The concept of communities does not exist for SNMPv3, which instead provides for a far more secure communications method using entities, users, and groups.

Important We strongly recommend removing community membership from all SNMPv3 configured devices to prevent access to them via SNMPv1 and SNMPv2c, which could bypass the additional SNMPv3 security features.

SNMPv3 Entities

Entities comprise one of the basic components of the SNMPv3 enhanced architecture. They define the functionality and internal structure of the SNMP managers and agents. An in-depth description of entities can be found in RFC 3411, on which the following text is based. SNMPv3 defines two entity types, a manager and an agent. Both entity types contain two basic components: an SNMP engine and a set of applications.

SNMP Engine

The engine provides the basic services to support the agents component applications, in this respect it performs much of the functionality expected of the ISO Session and Presentation layers. These functions include, message transmission and reception, authentication and encryption, and access control to its managed objects database (MIB). The SNMP engine comprises the following components:

- Dispatcher
- Message processing Subsystem
- Security Subsystem
- Access Control Subsystem

The only security subsystem presently supported is the user based security model (USM).

Each SNMP engine is identified by an `snmpEngineID` that must be unique within the management system. A one to one association exists between an engine and the entity that contains it.

Entity Applications

The following applications are defined within the agent applications:

- Command Generator
- Notification Receiver
- Proxy Forwarder
- Command Responder
- Notification Originator
- Other

SNMPv3 Message Protocol Format

SNMPv3 PDUs

Value	Meaning
msgVersion	Identifies the message format to be SNMPv3.
msgID	An identifier used between SNMP entities to coordinate message requests and responses. Note that a message response takes the msgID value of the initiating message.
msgMaxSize	Conveys the maximum message size (in octets) an integer between 484 and $2^{31}-1$, supported by the sender of the message. Specified as msgFlags. A single octet whose last three bits indicate the operational mode for privacy, authentication, and report.
msgSecurityModel	An identifier used to indicate the security mode (i.e. SNMPv1, SNMPv2c or SNMPv3 to be used when processing the message. Note that although only the SNMPv3 identifier is accepted by the switch, these earlier version message formats are detected by the msgVersion field and processed appropriately.
msgAuthoritativeEngineID	The ID of the authoritative engine that relates to a particular message, i.e. the source engine ID for Traps, Responses and Reports, and the destination engine for Gets, GetNexts, Sets, and Informs.
msgAuthoritativeEngineBoots	A value that represents the number of times the authoritative engine has rebooted since its installation. Its value has the range 1 to $2^{31}-1$.
msgAuthoritativeEngineTime	The number of seconds since the authoritative engine snmpEngineBoots counter was last incremented.
msgUserName	The name of the user (principal) on whose behalf the message is being exchanged.
msgAuthenticationParameters	If the message has been authenticated, this field contains a serialized OCTET STRING representing the first 12 octets of the HMAC-MD5-96 output done over the whole message.
msgPrivacyParameters	For encrypted data, this field contains the "salt" used to create the DES encryption Initialization Vector (IV).
ContextEngineID	Within a particular administrative domain, this field uniquely identifies an SNMP entity that may realize an instance of a context with a particular contextName
ContextName	A unique name given to a context within a particular SNMP entity.

SNMPv1 and SNMPv2c

Although software levels 2.6.3 and higher support the specific facilities of SNMP v1 and v2, their documentation is available to provide backward compatibility with older network management systems. The far superior security features offered by implementing SNMPv3 should be used wherever possible.

The switch's implementation of SNMPv1 is based on RFC 1157, *A Simple Network Management Protocol (SNMP)*, and RFC 1812, *Requirements for IP Version 4 Routers*.

When the SNMP agent is disabled, the agent does not respond to SNMP request messages. The agent is disabled by default. The current state and configuration of the SNMP agent can be displayed.

SNMP MIB Views for SNMPv1 and SNMPv2c

An SNMP MIB view is a arbitrary subset of objects in the MIB. Objects in the view may be from any part of the object name space, and not necessarily the same sub-tree. An SNMP community profile is the pairing of an SNMP access mode (read-only or read-write) with the access mode defined by the MIB for each object in the view. For each object in the view, the community profile defines the operations that can be performed on the object.

Pairing an SNMP community with an SNMP community profile determines the level of access that the agent affords to an NMS that is a member of the specified community. When an agent receives an SNMP message, it checks the community name encoded in the message. If the agent knows the community name, the message is deemed to be authentic and the sending SNMP entity is accepted as a member of the community. The community profile associated with the community name then determines the sender's view of the MIB and the operations that can be performed on objects in the view.

SNMP Communities

SNMP communities were introduced into SNMPv1 and retained in version 2c. Although the switch's software still supports communities, this is to provide backward compatibility with legacy management systems. Communities should not be used where a secure network is required. Instead, use the secure network features offered by SNMPv3.

An SNMP community is a pairing of an SNMP agent with a set of SNMP application entities. Communities are the main configuration item in the switch's implementation of SNMPv1 and v2, and are defined in terms of a list of IP addresses which define the SNMP application entities (trap hosts and management stations) in the community.

Important Community names act as passwords and provide minimal authentication. Any SNMP application entity that knows a community name can read the value of any instance of any object in the MIB implemented in the switch. Any SNMP application entity that knows the name of a community with write access can change the value of any instance of any object in the MIB implemented in the switch, possibly affecting the operation of the switch. For this reason, take care with the security of community names.

When a trap is generated by the SNMP agent it is forwarded to all trap hosts in all communities. The community name and manager addresses are used to provide trivial authentication. An incoming SNMP message is deemed authentic if it contains a valid community name and originated from an IP address defined as a management station for that community.

When a community is disabled, the SNMP agent behaves as if the community does not exist and generates authentication failure traps for messages directed to the disabled community.

The SNMP agent does not support a default community called “public” with read-only access, traps disabled and open access as mandated in RFC 1812, as this is a security hole open for users who wish to use the switch with minimal modification to the default configuration. The default configuration of the switch has no defined communities. Communities must be explicitly created.

SNMP authentication (for SNMPv1 and v2) is a mechanism whereby an SNMP message is declared to be authentic, that is from an SNMP application entity actually in the community to which the message purports to belong. The mechanism may be trivial or secure. The only form of SNMP authentication implemented by the switch's SNMP agent is trivial authentication. The authentication failure trap may be generated as a result of the failure to authentication an SNMP message.

Switch interfaces can be enabled or disabled via SNMP by setting the ifAdminStatus object in the ifTable of MIB-II MIB to 'Up(1)' or 'Down(2)' for the corresponding ifIndex. If it is not possible to change the status of a particular interface the switch returns an SNMP error message.

The switch's implementation of the ifOperStatus object in the ifTable of MIB-II MIB supports two additional values—“Unknown(4)” and “Dormant(5)” (e.g. an inactive dial-on-demand interface).

Important An unauthorized person with knowledge of the appropriate SNMP community name could bring an interface up or down. Community names act as passwords for the SNMP protocol. When creating an SNMP community with write access, take care to select a secure community name and to ensure that only authorized personnel know it.

An SNMP MIB view is a subset of objects in the MIB that pertain to a particular network element. For example, the MIB view of a hub would be the objects relevant to management of the hub, and would not include IP routing table objects, for example. The switch's SNMP agent does not allow the construction of MIB views. The switch supports all relevant objects from all MIBs that it implements.

Note that the switch's standard set and show commands can also be used to access objects in the MIBs supported by the switch.

Defining Management Stations within Communities

You can add management stations to a community either individually, by entering just its IP address, or you can enter a range of management stations by entering an IP address that ends with a '/' character followed by a number between 1 and 32. The number that follows the '/' character operates as an address mask to define a range of addresses for the management stations. The following example shows how to allocate a band of three binary addresses to a portion of the subnet 146.15.1.X

Example

In this example we make provision for up to 8 possible management stations within a community called “admin”.

Step 1:

Decide on the number of management stations that you want to assign to a particular subnet, then decide how many binary digits are required to define this number of addresses. In this case we need up to 8 management stations, so we will assign 3 binary digits (3 binary digits can provide 8 different values). To assign the last 3 binary digits for management stations, we assign a prefix that is a count of all binary digits in the address minus those to be assigned as management stations. In this case the prefix is 29; this being the number of binary digits in an IP address (32) minus the number of digits assigned to the management stations (3).

Step 2:

The method used in this step depends on whether or not the community already exists.

- If the community called “admin” does not exist, create a new community called “admin” and allocate a three binary digit block of addresses to the address subnet 146.15.1.X.
- If the community called “admin” already exists, allocate a three binary digit block of addresses to an existing community called “admin” with the address subnet 146.15.1.X.

For security reasons, the common management prefix should be larger than the IP subnet. This prevents stations on one subnet from being considered valid management stations on a different subnet.

Configuration Example (SNMPv1 and v2)

This example shows how to configure the switch's SNMP agent. Two network management stations have been set up on a large network. The central NMS (IP address 192.168.11.5) monitors devices on the network and uses SNMP set messages to manage devices on the network. Trap messages are sent to this management station. The regional network management station (IP addresses 192.168.16.1) is used just to monitor devices on the network by using SNMP get messages. Link traps are enabled for all interfaces on this particular switch.

The IP module must be enabled and correctly configured in order to access the SNMP agent in the switch. This is because the IP module handles both the TCP transport functions, and the UDP functions that enable datagrams to transport SNMP messages. See Chapter 13, Internet Protocol (IP) for commands that enable and configure IP.

To configure SNMP

Step 1: Enable the SNMP agent.

Enable the SNMP agent and enable the generation of authenticate failure traps to monitor unauthorized SNMP access. SNMP is enabled by default in AlliedWare Plus.

Step 2: Create a community with write access for the central NMS.

Create a community called “private”, with write access for use only by the central network management station at 192.168.11.5 using an ACL with the `snmp-server community` command. All traps are sent to this NMS.

```
awplus(config)#access-list 66 permit 192.168.11.5
awplus(config)#snmp-server community private rw 66
```

Care must be taken with the security of community names. Do not use the name “private” in your network because it is too obvious. Community names act as passwords and provide only trivial authentication. Any SNMP application entity that knows a community name can read the value of any instance of any object in the MIB implemented in the switch. Any SNMP application entity that knows the name of a community with write access can change the value of any instance of any object in the MIB implemented in the switch, possibly affecting the operation of the switch.

Step 3: Create a community with read-only access for the regional NMS.

Create a community called “public”, with read-only access for use by the regional network management station at 192.168.16.1 using an ACL with the `snmp-server community` command.

```
awplus(config)#access-list 67 permit 192.168.16.1
awplus(config)#snmp-server community public ro 67
```

Step 4: Enable link traps.

Enable link traps for the switch's VLAN interfaces.

Step 5: Check the configuration.

Check that the current configuration of the SNMP communities matches the desired configuration:

```
awplus#show snmp-server
```

Check that the interface link up/down traps have been correctly configured:

```
awplus#show ip int vlan1.1 brief
```

SNMPv3

SNMPv3 is the third version of the Simple Network Management Protocol. The architecture comprises the following:

- entities that may be either managers, agents, or both
- a management information base (MIB)
- a transport protocol

At least one manager node runs the SNMP management software in every configuration. Managed devices such as routers, servers, and workstations are equipped with an agent software module. The agent provides access to local objects in the MIB that reflect activity and resources at the node. The agent also responds to manager commands to retrieve values from, and set values in the MIB.

SNMP MIB Views for SNMPv3

An SNMP MIB view is an arbitrary subset of objects in the MIB. Objects in the view may be from any part of the object name space, and not necessarily the same sub-tree.

SNMP Groups

Groups were introduced as part of SNMPv3. They are the means by which users are assigned their views and access control policy. Once a group has been created, users can be added to them. In practice a number of groups would be created, each with varying views and access security requirements. Users would then be added to their most appropriate groups. Each Group name and Security Level pair must be unique within a switch.

SNMP Users

Users were introduced as part of SNMPv3. From a system perspective a user is represented as an entity stored in a table that defines the access and authentication criteria to be applied to access or modify the SNMP MIB data.

SNMP Target Addresses

Target addresses were introduced as part of SNMPv3. They specify the destination and user that receives outgoing notifications such as trap messages. SNMP target address names must be unique within the managed device.

SNMP Target Params

Target params were introduced as part of SNMPv3. They specify an entry in the `snmpTargetParamsTable`. SNMP target params names must be unique within the managed device.

Configuration Example (SNMPv3)

This example shows how to configure the switch's SNMP agent. Two network management stations have been set up on a large network. The central NMS (IP address 192.168.11.5) monitors devices on the network and uses SNMP set messages to manage devices on the network. Trap messages are sent to this management station.

The IP module must be enabled and correctly configured in order to access the SNMP agent in the switch, since the IP module handles the UDP datagrams used to transport SNMP messages.

To configure SNMP

Step 1: Enable the SNMP agent.

Enable the SNMP agent and enable the generation of authenticate failure traps to monitor unauthorized SNMP access. SNMP is enabled by default in AlliedWare Plus.

Step 2: Add SNMP views.

You can specify views using their OID or the predefined MIB name.

```
awplus(config)#snmp-server view atmib 1.3.6.1.2.14 included
awplus(config)#snmp-server view atmib alliedtelesis included
```

Step 3: Add SNMP group.

```
awplus(config)#snmp-server group ord-user noauth read atmib
awplus(config)#snmp-server group admin-user auth read atmib write
atmib notify atmib
```

Step 4: Add SNMP users.

Add users to the groups by using commands such as:

```
awplus(config)#snmp-server user ken admin-user auth md5 mercury
```

Step 5: Add SNMP target parameters.

Step 6: Add SNMP target address.

Using SNMP to Manage Files and Software

The Allied Telesis Enterprise MIB ([Chapter 76, SNMP MIBs](#)) includes objects for managing files and software on the switch. This section includes procedures for using MIB objects on the switch to perform some common tasks, via an SNMP management application:

- “Copy a File to or from a TFTP Server” on page 74.18
- “Upgrade Software and Configuration Files” on page 74.19

For more details about the Allied Telesis Enterprise MIB and public MIBs on the switch, see [Chapter 76, SNMP MIBs](#).

Copy a File to or from a TFTP Server

Use this procedure to copy a file (for example, a software version file) to the switch from a TFTP server, or to copy a file (for example, a configuration file) from the switch to a TFTP server. The MIB objects in this procedure reside in the module atFilev2 { modules 600 }, with object ID 1.3.6.1.4.1.207.8.4.4.4.600. For detailed descriptions of the MIB objects used in this procedure, and other file management MIB objects, see [“AT-FILEv2-MIB” on page 76.45](#). Other MIB objects can be used in a similar way for moving and deleting files on the switch.

Table 74-1: Procedure for copying a file to or from a device using a TFTP server

Do this ...	By setting or reading this MIB object ...	Whose object ID is ...	To this value...
1. If the source device is part of a stack, set the stack ID. For a standalone switch, keep the default value, 1.	atFilev2SourceStackId	{ atFilev2Operation 1 }	<stack-id>
2. If the destination device is part of a stack, set the stack ID.	atFilev2DestinationStackId	{ atFilev2Operation 4 }	<stack-id>
3. Set the source device.	atFilev2SourceDevice	{ atFilev2Operation 2 }	1 (TFTP) or 2 (Flash)
4. Set the destination device.	atFilev2DestinationDevice	{ atFilev2Operation 5 }	1 (TFTP) or 2 (Flash)
5. Set the source filename. Include the path (if any) but not the device.	atFilev2SourceFileName	{ atFilev2Operation 3 }	<source-filename> e.g. /awp/config/ admin.cfg
6. Set the destination filename. Include the path (if any) but not the device.	atFilev2DestinationFileName	{ atFilev2Operation 6 }	<dest-filename> e.g. /config/admin.cfg
7. Set the IP address of the TFTP server.	atFilev2TftpIPAddr	{ atFilev2Tftp_4 1 }	<ip-addr>
8. Check that no other transfer is in progress, and that the required parameters have been set.	atFilev2CopyBegin	{ atFilev2Operation 7 }	Read: idle
9. Start the file transfer.	atFilev2CopyBegin	{ atFilev2Operation 7 }	Set: 1
10. Monitor file transfer progress.	atFilev2CopyBegin	{ atFilev2Operation 7 }	Read: In progress: copying <src> --> <dst> or Success: copy <src> --> <dst> success or Failure: copy <src> --> <dst> failure: <err-msg>

Upgrade Software and Configuration Files

Use this procedure to upgrade to a new software version and boot configuration file. For detailed descriptions of the MIB objects used in this procedure, and other MIB objects for managing software installation and configuration files, see “AT-SETUP-MIB” on page 76.35.

Table 74-2: Procedure for upgrading to a new software version and boot configuration

Do this ...	By reading or setting this MIB object ...	Whose object ID is ...	To this value...
1. Check that you have enough flash memory for the currently running software file, the new software version file, and any configuration scripts required.			
2. Check the version and name of the software currently running.	currSoftVersion currSoftName	1.3.6.1.4.1.207.8.4.4.4.500.2.1.1 1.3.6.1.4.1.207.8.4.4.4.500.2.1.2	Read: <software-name> <software-version>
3. If you do not already have the currently running software as a software version file in flash, save the currently running software with a file name to the flash root.	currSoftSaveAs	1.3.6.1.4.1.207.8.4.4.4.500.2.1.1	Set: <backup-filename.rel>
4. Check that the file saved successfully. (The most common failures result from lack of flash memory space.)	currSoftSaveAs	1.3.6.1.4.1.207.8.4.4.4.500.2.1.3	Read: saving <filename> or <filename> success or <filename> failure: <error-message>
5. Copy the new software version file to flash memory on the device	See Table 74-1.		
6. Set the new release file to be the current release that the device will install and run the next time it restarts. Include the path.	nextBootPath	1.3.6.1.4.1.207.8.4.4.4.500.2.2.2	Set: <next-filename> e.g.: flash:/ release.rel
7. Check the version of release file set to install next.	nextBootVersion	1.3.6.1.4.1.207.8.4.4.4.500.2.2.1	Read: <software-version>
8. Set the previous release file to be the backup release that the device will install and run if the device fails to boot successfully with the new release file. Include the path.	bckpPath	1.3.6.1.4.1.207.8.4.4.4.500.2.3.2	Set: <backup-filename> e.g.: flash:/ release.rel

Table 74-2: Procedure for upgrading to a new software version and boot configuration(Continued)

	Do this ...	By reading or setting this MIB object ...	Whose object ID is ...	To this value...
9.	Check the version of backup release file.	bckpVersion	1.3.6.1.4.1.207.8.4.4.4.500.2.3.1	Read: <software-version>
10.	If necessary, copy a configuration file to the device (Table 74-1), or save the current running configuration to a file in the root directory of flash. To save the running configuration, specify the filename, but not a device or path.	See Table 74-1. or runCnfgSaveAs	1.3.6.1.4.1.207.8.4.4.4.500.3.1.1	Set: <filename.cfg> e.g.: myconfig.cfg
11.	Check and if necessary set the file the device will use for configuration when it restarts. Include the full path.	bootCnfgPath	1.3.6.1.4.1.207.8.4.4.4.500.3.2.1	Read/set: <filename.cfg> e.g.: flash:/myconfig.cfg
12.	Check that a boot configuration file matching the boot configuration path exists.	bootCnfgExists	1.3.6.1.4.1.207.8.4.4.4.500.3.2.2	Read: TRUE (1) or FALSE (2)
13.	Check that the default configuration file flash:/default.cfg exists.	dfltCnfgExists	1.3.6.1.4.1.207.8.4.4.4.500.3.3.2	Read: TRUE (1) or FALSE (2)
14.	Restart the device.	restartDevice	1.3.6.1.4.1.207.8.4.4.4.500.1	1

Chapter 75: SNMP Commands



Command List	75.2
debug snmp	75.2
show counter snmp-server	75.3
show debugging snmp	75.6
show running-config snmp	75.6
show snmp-server	75.7
show snmp-server community	75.7
show snmp-server group	75.8
show snmp-server user	75.8
show snmp-server view	75.9
snmp trap link-status	75.10
snmp trap link-status suppress	75.11
snmp-server	75.12
snmp-server community	75.13
snmp-server contact	75.14
snmp-server enable trap	75.15
snmp-server engineID local	75.17
snmp-server group	75.18
snmp-server host	75.19
snmp-server location	75.21
snmp-server source-interface	75.22
snmp-server user	75.23
snmp-server view	75.25

Command List

This chapter provides an alphabetical reference for commands used to configure SNMP. For more information, see [Chapter 74, SNMP Introduction](#), and [Chapter 76, SNMP MIBs](#).

For information about modifying or redirecting the output from show commands to a file, see [“Controlling “show” command output” on page 1.33](#).

debug snmp

This command enables SNMP debugging.

The no form disables SNMP debugging.

Syntax debug snmp

no debug snmp

Mode Privileged Exec and Global Configuration

Examples To start SNMP debugging, use the command:

```
awplus# debug snmp
```

Related Commands [show debugging snmp](#)

show counter snmp-server

This command displays counters for SNMP messages received by the SNMP agent.

Syntax `show counter snmp-server`

Mode Exec and Privileged Exec

Example To display the counters for the SNMP agent, use the command:

```
awplus# show counter snmp-server
```

Output Figure 75-1: Example output from the show counter snmp-server command

```
SNMP-SERVER counters
inPkts                ..... 11
inBadVersions         ..... 0
inBadCommunityNames   ..... 0
inBadCommunityUses    ..... 0
inASNParseErrs        ..... 0
inTooBig              ..... 0
inNoSuchNames         ..... 0
inBadValues           ..... 0
inReadOnly            ..... 0
inGenErrs             ..... 0
inTotalReqVars        ..... 9
inTotalSetVars        ..... 0
inGetRequests         ..... 2
inGetNexts            ..... 9
inSetRequests         ..... 0
inGetResponses        ..... 0
inTraps               ..... 0
outPkts               ..... 11
outTooBig             ..... 0
outNoSuchNames        ..... 2
outBadValues          ..... 0
outGenErrs            ..... 0
outGetRequests        ..... 0
outGetNexts           ..... 0
outSetRequests        ..... 0
outGetResponses       ..... 11
outTraps              ..... 0
UnsupportedSecLevels   ..... 0
NotInTimeWindows      ..... 0
UnknownUserNames      ..... 0
UnknownEngineIDs       ..... 0
WrongDigest           ..... 0
DecryptionErrors       ..... 0
UnknownSecModels      ..... 0
InvalidMsgs           ..... 0
UnknownPDUHandlers    ..... 0
```

Table 75-1: Parameters in the output from the show counter snmp-server command

Parameter	Meaning
inPkts	The total number of SNMP messages received by the SNMP agent.
inBadVersions	The number of messages received by the SNMP agent for an unsupported SNMP version. It drops these messages. The SNMP agent on your device supports versions 1, 2C, and 3.

Table 75-1: Parameters in the output from the show counter snmp-server command

Parameter	Meaning
inBadCommunityNames	The number of messages received by the SNMP agent with an unrecognized SNMP community name. It drops these messages.
inBadCommunityUses	The number of messages received by the SNMP agent where the requested SNMP operation is not permitted from SNMP managers using the SNMP community named in the message.
inASNParseErrs	The number of ASN.1 or BER errors that the SNMP agent has encountered when decoding received SNMP Messages.
inTooBigs	The number of SNMP PDUs received by the SNMP agent where the value of the error-status field is 'tooBig'. This is sent by an SNMP manager to indicate that an exception occurred when processing a request from the agent.
inNoSuchNames	The number of SNMP PDUs received by the SNMP agent where the value of the error-status field is 'noSuchName'. This is sent by an SNMP manager to indicate that an exception occurred when processing a request from the agent.
inBadValues	The number of SNMP PDUs received by the SNMP agent where the value of the error-status field is 'badValue'. This is sent by an SNMP manager to indicate that an exception occurred when processing a request from the agent.
inReadOnlys	The number of valid SNMP PDUs received by the SNMP agent where the value of the error-status field is 'readOnly'. The SNMP manager should not generate a PDU which contains the value 'readOnly' in the error-status field. This indicates that there is an incorrect implementations of the SNMP.
inGenErrs	The number of SNMP PDUs received by the SNMP agent where the value of the error-status field is 'genErr'.
inTotalReqVars	The number of MIB objects that the SNMP agent has successfully retrieved after receiving valid SNMP Get-Request and Get-Next PDUs.
inTotalSetVars	The number of MIB objects that the SNMP agent has successfully altered after receiving valid SNMP Set-Request PDUs.
inGetRequests	The number of SNMP Get-Request PDUs that the SNMP agent has accepted and processed.
inGetNexts	The number of SNMP Get-Next PDUs that the SNMP agent has accepted and processed.
inSetRequests	The number of SNMP Set-Request PDUs that the SNMP agent has accepted and processed.
inGetResponses	The number of SNMP Get-Response PDUs that the SNMP agent has accepted and processed.
inTraps	The number of SNMP Trap PDUs that the SNMP agent has accepted and processed.
outPkts	The number of SNMP Messages that the SNMP agent has sent.
outTooBigs	The number of SNMP PDUs that the SNMP agent has generated with the value 'tooBig' in the error-status field. This is sent to the SNMP manager to indicate that an exception occurred when processing a request from the manager.
outNoSuchNames	The number of SNMP PDUs that the SNMP agent has generated with the value 'noSuchName' in the error-status field. This is sent to the SNMP manager to indicate that an exception occurred when processing a request from the manager.

Table 75-1: Parameters in the output from the show counter snmp-server command

Parameter	Meaning
outBadValues	The number of SNMP PDUs that the SNMP agent has generated with the value 'badValue' in the error-status field. This is sent to the SNMP manager to indicate that an exception occurred when processing a request from the manager.
outGenErrs	The number of SNMP PDUs that the SNMP agent has generated with the value 'genErr' in the error-status field. This is sent to the SNMP manager to indicate that an exception occurred when processing a request from the manager.
outGetRequests	The number of SNMP Get-Request PDUs that the SNMP agent has generated.
outGetNexts	The number of SNMP Get-Next PDUs that the SNMP agent has generated.
outSetRequests	The number of SNMP Set-Request PDUs that the SNMP agent has generated.
outGetResponses	The number of SNMP Get-Response PDUs that the SNMP agent has generated.
outTraps	The number of SNMP Trap PDUs that the SNMP agent has generated.
UnSupportedSecLevels	The number of received packets that the SNMP agent has dropped because they requested a securityLevel unknown or not available to the SNMP agent.
NotInTimeWindows	The number of received packets that the SNMP agent has dropped because they appeared outside of the authoritative SNMP agent's window.
UnknownUserNames	The number of received packets that the SNMP agent has dropped because they referenced an unknown user.
UnknownEngineIDs	The number of received packets that the SNMP agent has dropped because they referenced an unknown snmpEngineID.
WrongDigest	The number of received packets that the SNMP agent has dropped because they didn't contain the expected digest value.
DecryptionErrors	The number of received packets that the SNMP agent has dropped because they could not be decrypted.
UnknownSecModels	The number of messages received that contain a security model that is not supported by the server. Valid for SNMPv3 messages only.
InvalidMsgs	The number of messages received where the security model is supported but the authentication fails. Valid for SNMPv3 messages only.
UnknownPDUHandlers	The number of times the SNMP handler has failed to process a PDU. This is a system debugging counter.

Related Commands [show snmp-server](#)

show debugging snmp

This command displays whether SNMP debugging is enabled or disabled.

Syntax `show debugging snmp`

Mode Privileged Exec

Example To display the status of SNMP debugging, use the command:

```
awplus# show debugging snmp
```

Output

```
Snmp (SMUX) debugging status:  
Snmp debugging is on
```

Related Commands [debug snmp](#)

show running-config snmp

This command displays the current configuration of SNMP on your device.

Syntax `show running-config snmp`

Mode Privileged Exec

Example To display the current configuration of SNMP on your device, use the command:

```
awplus# show running-config snmp
```

Output

```
snmp-server contact AlliedTelesis  
snmp-server location Philippines  
snmp-server group grou1 auth read view1 write view1 notify view1  
snmp-server view view1 1 included  
snmp-server community public  
snmp-server user user1 group1 auth md5 password priv des password
```

Related Commands [show snmp-server](#)

show snmp-server

This command displays the status and current configuration of the SNMP server.

Syntax `show snmp-server`

Mode Exec and Privileged Exec

Example To display the status of the SNMP server, use the command:

```
awplus# show snmp-server
```

Output

```
SNMP Server ..... Enabled
IP Protocol ..... IPv4,IPv6
SNMPv3 Engine ID (configured) ..... Not set
SNMPv3 Engine ID (actual)..... 0x80001f888029af52e149198483
```

Related Commands [debug snmp](#)
[show counter snmp-server](#)
[snmp-server](#)

show snmp-server community

This command displays the SNMP server communities configured on the device. SNMP communities are specific to v1 and v2c.

Syntax `show snmp-server community`

Mode Exec and Privileged Exec

Example To display the SNMP server communities, use the command:

```
awplus# show snmp-server community
```

Output

```
SNMP community information:
Community Name ..... public
Access ..... Read-only
View ..... none
```

Related Commands [show snmp-server](#)
[snmp-server community](#)

show snmp-server group

This command displays information about SNMP server groups. This command is used with SNMP version 3 only.

Syntax `show snmp-server group`

Mode Exec and Privileged Exec

Example To display the SNMP groups configured on the device, use the command:

```
awplus# show snmp-server group
```

Output

```
SNMP group information:
  Group name ..... guireadgroup
  Security Level ..... priv
  Read View ..... guiview
  Write View ..... none
  Notify View ..... none

  Group name ..... guiwritegroup
  Security Level ..... priv
  Read View ..... none
  Write View ..... guiview
  Notify View ..... none
```

Related Commands [show snmp-server](#)
[snmp-server group](#)

show snmp-server user

This command displays the SNMP server users and is used with SNMP version 3 only.

Syntax `show snmp-server user`

Mode Exec and Privileged Exec

Example To display the SNMP server users configured on the device, use the command:

```
awplus# show snmp-server user
```

Output

Name	Group name	Auth	Privacy
-----	-----	-----	-----
freddy	guireadgroup	none	none

Related Commands [show snmp-server](#)
[snmp-server user](#)

show snmp-server view

This command displays the SNMP server views and is used with SNMP version 3 only.

Syntax `show snmp-server view`

Mode Exec and Privileged Exec

Example To display the SNMP server views configured on the device, use the command:

```
awplus# show snmp-server view
```

Output

```
SNMP view information:
View Name ..... view1
OID ..... 1
Type ..... included
```

Related Commands `show snmp-server`
`snmp-server view`

snmp trap link-status

Use this command to enable SNMP to send link status notifications (traps) for the interfaces when an interface goes up (linkUp) or down (linkDown).

Use the no version of this command to disable the sending of link status notifications.

Syntax `snmp trap link-status`
 `no snmp trap link-status`

Default By default, link status notifications are disabled.

Mode Interface Configuration

Usage The link status notifications can be enabled for the following interface types:

- switch port (e.g. port 1.0.1)
- VLAN (e.g. vlan2)
- static and dynamic link aggregation (e.g. sa2, po3)

To specify where notifications are sent, use the [snmp-server host command on page 75.19](#). To configure the switch globally to send other notifications, use the [snmp-server enable trap command on page 75.15](#).

Examples To enable SNMP to send link status notifications for ports 1.0.2 to 1.0.12, use following commands:

```
awplus# configure terminal
awplus(config)# interface 1.0.2-1.0.12
awplus(config-if)# snmp trap link-status
```

To disable the sending of link status notifications for port 1.0.2, use following commands:

```
awplus# configure terminal
awplus(config)# interface 1.0.2
awplus(config-if)# no snmp trap link-status
```

Related Commands [show interface](#)
 [snmp trap link-status suppress](#)
 [snmp-server enable trap](#)
 [snmp-server host](#)

snmp trap link-status suppress

Use this command to enable the suppression of link status notifications (traps) for the interfaces beyond the specified threshold, in the specified interval.

Use the no version of this command to disable the suppression of link status notifications for the ports.

Syntax

```
snmp trap link-status suppress
    {time {<1-60>|default}|threshold {<1-20>|default}} ...

no snmp trap link-status suppress
```

Parameter	Description
time	Set the suppression timer for link status notifications. Specify the suppress time as: - the time in seconds, in the range 1 to 60 - default (60)
threshold	Set the suppression threshold for link status notifications. This is the number of link status notifications after which to suppress further notifications within the suppression timer interval. Specify the threshold as: - a number in the range 1 to 20 - default (20)

Default By default, if link status notifications are enabled (they are enabled by default), the suppression of link status notifications is enabled: notifications that exceed the notification threshold (default 20) within the notification timer interval (default 60 seconds) are not sent.

Mode Interface Configuration

Usage An unstable network can generate many link status notifications. When notification suppression is enabled, a suppression timer is started when the first link status notification of a particular type (linkUp or linkDown) is sent for an interface. If the threshold number of notifications of this type is sent before the timer reaches the suppress time, any further notifications of this type generated for the interface during the interval are not sent. At the end of the interval, the sending of link status notifications resumes, until the threshold is reached in the next interval.

Examples To enable the suppression of link status notifications for ports 1.0.2 to 1.0.12 after 10 notifications have been sent in 40 seconds, use following commands:

```
awplus# configure terminal
awplus(config)# interface 1.0.2-1.0.12
awplus(config-if)# snmp trap link-status suppress time 40
threshold 10
```

To disable the suppression link status notifications for port 1.0.2, use following commands:

```
awplus# configure terminal
awplus(config)# interface 1.0.2
awplus(config-if)# no snmp trap link-status suppress
```

Related Commands [show interface](#)
[snmp trap link-status](#)

snmp-server

Use this command to enable the SNMP agent (server) on the switch. The SNMP agent receives and processes SNMP packets sent to the switch, and generates notifications (traps) that have been enabled by the [snmp-server enable trap command on page 75.15](#).

Use the no version of this command to disable the SNMP agent on the switch. When SNMP is disabled, SNMP packets received by the switch are discarded, and no notifications are generated. This does not remove any existing SNMP configuration.

Syntax `snmp-server [ip|ipv6]`
`no snmp-server [ip|ipv6]`

Parameter	Description
ip	Enable or disable the SNMP agent for IPv4
ipv6	Enable or disable the SNMP agent for IPv6

Default By default, the SNMP agent is enabled for both IPv4 and IPv6. If neither the ip parameter nor the ipv6 parameter is specified for this command, then SNMP is enabled or disabled for both IPv4 and IPv6.

Mode Global Configuration

Examples To enable SNMP on the switch for both IPv4 and IPv6, use the commands:

```
awplus# configure terminal
awplus(config)# snmp-server
```

To enable the SNMP agent for IPv4 on the device, use the commands:

```
awplus# configure terminal
awplus(config)# snmp-server ip
```

To disable the SNMP agent for both IPv4 and IPv6 on the switch, use the commands:

```
awplus# configure terminal
awplus(config)# no snmp-server
```

To disable the SNMP agent for IPv6, use the commands:

```
awplus(config)# no snmp-server ipv6
```

Related Commands [show snmp-server](#)
[show snmp-server community](#)
[show snmp-server user](#)

[snmp-server community](#)
[snmp-server contact](#)
[snmp-server enable trap](#)
[snmp-server engineID local](#)
[snmp-server group](#)
[snmp-server host](#)
[snmp-server location](#)
[snmp-server view](#)

snmp-server community

This command creates an SNMP community, optionally setting the access mode for the community. The default access mode is read only. If view is not specified, the community allows access to all the MIB objects. The SNMP communities are only valid for SNMPv1 and v2c and provide very limited security. Communities should not be used when operating SNMPv3.

The `no snmp-server community` command removes an SNMP community. The specified community must already exist on the device.

Syntax

```
snmp-server community <community-name>
    {view <view-name>|ro|rw|<access-list>}

no snmp-server community <community-name> [{view <view-name>|<access-
list>}]
```

Parameter	Description
<community-name>	Community name. The community name is a string up to 20 characters long and is case sensitive.
view	Configure SNMP view. If view is not specified, the community allows access to all the MIB objects.
<view-name>	View name. The view name is a string up to 20 characters long and is case sensitive.
ro	read-only community
rw	read-write community
<access-list>	<1-99> Access list number

Mode Global Configuration

Example The following command creates an SNMP community called "public" with read only access to all MIB variables from any management station.

```
awplus# configure terminal
awplus(config)# snmp-server community public ro
```

The following command removes an SNMP community called "public"

```
awplus# configure terminal
awplus(config)# no snmp-server community public
```

Related Commands [show snmp-server](#)
[show snmp-server community](#)
[snmp-server view](#)

snmp-server contact

This command sets the contact information for the system. The contact name is:

- displayed in the output of the [show system](#) command
- stored in the MIB object sysContact

The no form removes the contact information from the system.

Syntax `snmp-server contact <contact-info>`
`no snmp-server contact`

Parameter	Description
<code><contact-info></code>	The contact information for the system, from 0 to 255 characters long. Valid characters are any printable character and spaces.

Mode Global Configuration

Examples To set the system contact information to “support@alliedtelesis.co.nz”, use the command:

```
awplus# configure terminal
awplus(config)# snmp-server contact support@alliedtelesis.co.nz
```

Related Commands [show system](#)
[snmp-server location](#)
[snmp-server group](#)

snmp-server enable trap

Use this command to enable the switch to send the specified notifications (traps).

Use the no version of the command to disable the sending of the specified notifications.

Syntax

```
snmp-server enable trap {[auth] [bgp] [epsr] [loopprot] [lldp] [mstp]
[nsm] [ospf] [pim] [power-inline] [rmon] [vcs] [vrrp]}

no snmp-server enable trap {[auth] [bgp] [epsr] [loopprot] [lldp]
[mstp] [nsm] [ospf] [pim] [power-inline] [rmon] [vcs] [vrrp]}
```

Parameter	Description
auth	Authentication failure
bgp	BGP traps
epsr	EPSR traps
lldp	Link Layer Discovery Protocol (LLDP) traps
loopprot	Loop Protection traps
mstp	MSTP traps
nsm	NSM traps
ospf	OSPF traps
pim	PIM traps
power-inline	Power-inline traps (Power Ethernet MIB RFC 3621)
rmon	RMON traps
vcs	VCS traps
vrrp	Virtual Router Redundancy (VRRP) traps

Default By default, no notifications are generated.

Mode Global Configuration

Usage This command cannot be used to enable link status notifications globally. To enable link status notifications for particular interfaces, use the [snmp trap link-status command on page 75.10](#). To specify where notifications are sent, use the [snmp-server host command on page 75.19](#).

Examples To enable the device to send BGP and VRRP-related traps, use the following command:

```
awplus# configure terminal
awplus(config)# snmp-server enable trap bgp vrrp
```

To disable BGP traps being sent out by the device, use the following command:

```
awplus# configure terminal
```

```
awplus(config)# no snmp-server enable trap bgp
```

Related Commands show snmp-server
 snmp trap link-status
 snmp-server host

snmp-server engineID local

Use this command to configure the SNMP engine ID. It is used with SNMP version 3 only.

Use the **no** version of this command to set the SNMPv3 engine ID to its default value. This has the same effect as the **snmp-server engineID local default** command.

Syntax `snmp-server engineID local {<engine-id>|default}`
`no snmp-server engineID local`

Parameter	Description
<code><engine-id></code>	Specify SNMPv3 Engine ID value, a string of up to 32 characters
<code>default</code>	Set SNMPv3 engine ID to the system generated value.

Mode Global Configuration

Example To set the SNMPv3 engine ID to 800000cf030000cd123456, use the following command

```
awplus# configure terminal
awplus(config)# snmp-server engineID local
800000cf030000cd123456
```

The following command sets SNMPv3 engine ID back to the default value.

```
awplus# configure terminal
awplus(config)# no snmp-server engineID local
```

Output The following example shows the engine ID values after configuration:

```
awplus(config)#snmp-server engineid local asdgdfh231234d
awplus(config)#show snmp-server
awplus(config)#exit
awplus#show snmp-server

SNMP Server ..... Enabled
IP Protocol ..... IPv4,IPv6
SNMPv3 Engine ID (configured) ..... asdgdfh231234d
SNMPv3 Engine ID (actual).....
0x80001f888029af52e149198483

awplus(config)#no snmp-server engineid local
awplus(config)#exit
awplus#show snmp-server

SNMP Server ..... Enabled
IP Protocol ..... IPv4,IPv6
SNMPv3 Engine ID (configured) ..... Not set
SNMPv3 Engine ID (actual).....
0x80001f888029af52e149198483
```

Related Commands `show snmp-server`
`snmp-server group`

snmp-server group

This command is used with SNMP version 3 only, and adds an SNMP group, optionally setting the security level and view access modes for the group. The security and access views defined for the group represent the minimum required of its users in order to gain access.

The **no** snmp-server group command deletes an SNMP group, and is used with SNMPv3 only. The group with the specified authentication/encryption parameters must already exist.

Syntax

```
snmp-server group <groupname> {auth|noauth|priv}
    [read <readname>|write <writename>|notify <notifysname>]

no snmp-server group <groupname> {auth|noauth|priv}
```

Parameter	Description
<groupname>	Group name. The group name is a string up to 20 characters long and is case sensitive.
auth	Authentication
noauth	No authentication and no encryption
priv	Authentication and encryption
read	Configure read view
<readname>	Read view name
write	Configure write view
<writename>	Write view name. The view name is a string up to 20 characters long and is case sensitive.
notify	Configure notify view
<notifysname>	Notify view name. The view name is a string up to 20 characters long and is case sensitive.

Mode Global Configuration

Examples To add SNMP group, for ordinary users, use the following commands:

```
awplus# configure terminal
awplus(config)# snmp-server group usergroup noauth read
                useraccess write useraccess
```

To delete SNMP group usergroup, use the following commands

```
awplus# configure terminal
awplus(config)# no snmp-server group usergroup noauth
```

Related Commands

- snmp-server
- show snmp-server
- show snmp-server group
- show snmp-server user

snmp-server host

This command specifies an SNMP trap host destination to which Trap or Inform messages generated by the device are sent.

For SNMP version 1 and 2c you must specify the community name parameter. For SNMP version 3, specify the authentication/encryption parameters and the user name. If the version is not specified, the default is SNMP version 1. Inform messages can be sent instead of traps for SNMP version 2c and 3.

Use the no version of this command to remove an SNMP trap host. The trap host must already exist.

The trap host is uniquely identified by:

- host IP address (IPv4 or IPv6),
- inform or trap messages,
- community name (SNMPv1 or SNMP v2c) or the authentication/encryption parameters and user name (SNMP v3).

Syntax `snmp-server host {<ipv4-address>|<ipv6-address>} [traps] [version 1] <community-name>]`

`snmp-server host {<ipv4-address>|<ipv6-address>} [informs|traps] version 2c <community-name>`

`snmp-server host {<ipv4-address>|<ipv6-address>} [informs|traps] version 3 {auth|noauth|priv} <user-name>`

`no snmp-server host {<ipv4-address>|<ipv6-address>} [traps] [version 1] <community-name>`

`no snmp-server host {<ipv4-address>|<ipv6-address>} [informs|traps] version 2c <community-name>`

`no snmp-server host {<ipv4-address>|<ipv6-address>} [informs|traps] version 3 {auth|noauth|priv} <user-name>`

Parameter	Description
host	Configure SNMP trap host
no	Remove the specified SNMP trap host
<ipv4-address>	IPv4 trap host address in the format A.B.C.D, for example, 192.0.2.2
<ipv6-address>	IPv6 trap host address in the format x:x::x:x for example, 2001:db8::8a2e:7334
informs	Send Inform messages to this host
traps	Send Trap messages to this host (default)
version	SNMP version to use for notification messages. Default: version 1.
1	Use SNMPv1(default).
2c	Use SNMPv2c
3	Use SNMPv3

Parameter(Continued)	Description(Continued)
auth	Authentication
noauth	No authentication
priv	Encryption
<community-name>	The SNMPv1 or SNMPv2c community name
<user-name>	SNMPv3 user name

Mode Global Configuration

Examples To configure the device to send generated traps to the IPv4 host destination 192.0.2.5 with the SNMPv2c community name *public*, use the following command:

```
awplus# configure terminal
```

```
awplus(config)# snmp-server host 192.0.2.5 version 2c public
```

To configure the device to send generated traps to the IPv6 host destination 2001:db8::8a2e:7334 with the SNMPv2c community name *private*, use the following command:

```
awplus# configure terminal
```

```
awplus(config)# snmp-server host 2001:db8::8a2e:7334 version 2c
private
```

To remove a configured trap host of 192.0.2.5 with the SNMPv2c community name *public*, use the following command:

```
awplus# configure terminal
```

```
awplus(config)# no snmp-server host 192.0.2.5 version 2c public
```

Related Commands [snmp trap link-status](#)
[snmp-server enable trap](#)
[snmp-server view](#)

snmp-server location

This command sets the location of the system. The location is:

- displayed in the output of the `show system` command
- stored in the MIB object `sysLocation`

The `no` parameter removes the configured location from the system.

Syntax `snmp-server location <location-name>`
`no snmp-server location`

Parameter	Description
<code><location-name></code>	The location of the system, from 0 to 255 characters long. Valid characters are any printable character and spaces.

Mode Global Configuration

Examples To set the location to “server room 523”, use the following commands:

```
awplus# configure terminal
awplus(config)# system location server room 523
```

Related Commands `show snmp-server`
`show system`
`snmp-server contact`

snmp-server source-interface

Use this command to specify the interface that SNMP traps or informs originate from. You cannot specify an interface that does not already have an IP address assigned to the interface.

Use the `no snmp-server source-interface` command to reset to the default source interface that SNMP traps or informs originate from (the Egress interface as sent from by default).

Syntax `snmp-server source-interface {traps|informs} <interface-name>`
`no snmp-server source-interface {traps|informs}`

Parameter	Description
<code>no</code>	Negate a command or set its defaults
<code>snmp-server</code>	Manage SNMP server
<code>source-interface</code>	Source Interface
<code>traps</code>	SNMP traps
<code>informs</code>	SNMP informs
<code><interface-name></code>	Interface name (with an IP address already assigned)

Mode Global Configuration

Default By default the source interface is the Egress interface where traps or informs were sent from.

Usage An SNMP trap or inform sent from an SNMP server has the notification IP address of the interface where it was sent from. Use this command to monitor notifications from an interface.

Example To set the interface that SNMP informs originate from to port 1.0.2 for inform packets, use the following commands:

```
awplus# configure terminal
awplus(config)# snmp-server source-interface informs port1.0.2
```

To reset the interface to the default source interface (the Egress interface) that SNMP traps originate from for trap packets, use the following commands:

```
awplus# configure terminal
awplus(config)# no snmp-server source-interface traps
```

**Validation
Commands** `show running-config`

snmp-server user

Use this command to create or move users as members of specified groups. This command is used with SNMPv3 only.

The no form of this command removes an SNMPv3 user. The specified user must already exist.

Syntax

```
snmp-server user <username> <groupname> [encrypted]
    [auth {md5|sha} <auth-password>]
    [priv {des|aes} <privacy-password>]

no snmp-server user <username>
```

Parameter	Description
<username>	User name. The user name is a string up to 20 characters long and is case sensitive.
<groupname>	Group name. The group name is a string up to 20 characters long and is case sensitive.
encrypted	Use the encrypted parameter when you want to enter encrypted passwords.
auth	Authentication protocol
md5	MD5 Message Digest Algorithms
sha	SHA Secure Hash Algorithm
<auth-password>	Authentication password. The password is a string of 8 to 20 characters long and is case sensitive.
priv	Privacy protocol
des	DES Data Encryption Standard
aes	AES Advanced Encryption Standards
<privacy-password>	Privacy password. The password is a string of 8 to 20 characters long and is case sensitive.

Mode Global Configuration

Usage Additionally this command provides the option of selecting an authentication protocol and (where appropriate) an associated password. Similarly, options are offered for selecting a privacy protocol and password.

- Note that each SNMP user must be configured on both the manager and agent entities. Where passwords are used, these passwords must be the same for both entities.
- Use the encrypted parameter when you want to enter already encrypted passwords in encrypted form as displayed in the running and startup configs stored on the switch. For example, you may need to move a user from one group to another group and keep the same passwords for the user instead of removing the user to apply new passwords.
- User passwords are entered using plaintext without the encrypted parameter and are encrypted according to the authentication and privacy protocols selected.
- User passwords are viewed as encrypted passwords in running and startup configs shown

from `show running-config` and `show startup-config` commands respectively. Copy and paste encrypted passwords from running-configs or startup-configs to avoid entry errors.

Example To add SNMP user `authuser` as a member of group `usergroup`, with authentication protocol `md5`, authentication password `Authpass`, privacy protocol `des` and privacy password `Privpass`, use the following commands

```
awplus# configure terminal
awplus(config)# snmp-server user authuser usergroup auth md5
Authpass priv des Privpass
```

Validate the user is assigned to the group using the following command:

```
awplus#show snmp-server user
Name          Group name      Auth          Privacy
-----
authuser      usergroup      md5           des
```

To enter existing SNMP user `authuser` with existing passwords as a member of group `newusergroup` with authentication protocol `md5` plus the encrypted authentication password `0x1c74b9c22118291b0ce0cd883f8dab6b74`, privacy protocol `des` plus the encrypted privacy password `0x0e0133db5453ebd03822b004eeacb6608f`, use the following commands

```
awplus# configure terminal
awplus(config)# snmp-server user authuser newusergroup
encrypted auth md5
0x1c74b9c22118291b0ce0cd883f8dab6b74 priv des
0x0e0133db5453ebd03822b004eeacb6608f
```

Note: Copy and paste the encrypted passwords from the running-config or the startup-config displayed, using the `show running-config` and `show startup-config` commands respectively, into the command line to avoid key stroke errors issuing this command.

Validate the user has been moved from the first group using the following command:

```
awplus#show snmp-server user
Name          Group name      Auth          Privacy
-----
authuser      newusergroup    md5           des
```

To delete SNMP user `authuser`, use the following commands:

```
awplus# configure terminal
awplus(config)# no snmp-server user authuser
```

Related Commands `show snmp-server user`
`snmp-server view`

snmp-server view

Use this command to create an SNMP view that specifies a sub-tree of the MIB. Further sub-trees can then be added by specifying a new OID to an existing view. Views can be used in SNMP communities or groups to control the remote manager's access.

Note: The object identifier must be specified in a sequence of integers separated by decimal points.

The no snmp-server view command removes the specified view on the device. The view must already exist.

Syntax `snmp-server view <view-name> <mib-name> {included|excluded}`
`no snmp-server view <view-name>`

Parameter	Description
<view-name>	SNMP server view name. The view name is a string up to 20 characters long and is case sensitive.
<mib-name>	Object identifier of the MIB.
included	Include this OID in the view.
excluded	Exclude this OID in the view.

Mode Global Configuration

Examples The following command creates a view called "loc" that includes system location mib sub-tree.

```
awplus(config)# snmp-server view loc 1.3.6.1.2.1.1.6.0 included
```

To remove the view "loc" use the following command

```
awplus(config)# no snmp-server view loc
```

Related Commands [show snmp-server view](#)
[snmp-server community](#)

Chapter 76: SNMP MIBs



Introduction.....	76.2
About MIBs.....	76.2
About SNMP.....	76.2
Obtaining MIBs.....	76.2
Loading MIBs.....	76.3
Allied Telesis Enterprise MIB.....	76.5
AT-SMI-MIB.....	76.6
AT-PRODUCT-MIB.....	76.9
AT-BOARDS-MIB.....	76.10
AT-SYSINFO-MIB.....	76.12
AT-XEM-MIB.....	76.14
AT-ENVMONv2-MIB.....	76.15
AT-VCSTACK-MIB.....	76.21
AT-MIBVERSION-MIB.....	76.25
AT-USER-MIB.....	76.26
AT-RESOURCE-MIB.....	76.27
AT-LICENSE-MIB.....	76.28
AT-TRIGGER-MIB.....	76.31
AT-LOOPPROTECT-MIB.....	76.33
AT-SETUP-MIB.....	76.35
AT-DNS-CLIENT-MIB.....	76.38
AT-NTP-MIB.....	76.39
AT-EPSRv2-MIB.....	76.42
AT-FILEv2-MIB.....	76.45
AT-LOG-MIB.....	76.52
AT-IP-MIB.....	76.54
AT-VLAN-MIB.....	76.56
Public MIBs.....	76.58

Introduction

This chapter describes the Management Information Bases (MIBs) and managed objects supported by the AlliedWare Plus™ operation system. The following topics are covered:

- “Allied Telesis Enterprise MIB” on page 76.5 describes the objects implemented in the Allied Telesis Enterprise MIB
- “Public MIBs” on page 76.58 describes the public MIBs supported by the AlliedWare Plus operating system, and any variations from the standard implementation.

About MIBs

A MIB is a collection of managed objects organized into a tree-like hierarchy of nodes in which the managed objects form the leaves. Within the tree, each node is identified by a non-negative integer identifier that is unique among the node's siblings. The address, or object identifier, of any node within the tree is expressed as a series of dot-delimited node identifiers that trace the path from the root of the tree to the node. For example, the object identifier for the sysDescr object is 1.3.6.1.2.1.1.1.

For more information about MIBs and the structure of management information, see [Chapter 74, SNMP Introduction](#).

About SNMP

A network management station (NMS) uses a protocol known as Simple Network Management Protocol (SNMP) to query or change the values of objects in the MIB of managed devices.

A managed device uses SNMP to respond to queries from an NMS, and to send unsolicited alerts (traps) to an NMS in response to events.

For more information about the Simple Network Management Protocol (SNMP), see [Chapter 74, SNMP Introduction](#).

For information about configuring SNMP, see [Chapter 75, SNMP Commands](#).

Obtaining MIBs

You can download MIBs from the following locations:

Download this MIB...	From this location...
Allied Telesis Enterprise MIB	The MIB files are available with the software files from the Support area at http://www.alliedtelesis.com .
Public MIBs defined in RFCs	http://www.rfc-editor.org/rfc.html
IANAifType-MIB	http://www.iana.org/assignments/ianaiftype-mib

Loading MIBs

Individual MIBs define a portion of the total MIB for a device. For example, the MAU-MIB defines objects for managing IEEE 802.3 medium attachment units (MAUs), and forms a sub-tree under mib-2 with the object identifier snmpDot3MauMgt (1.3.6.1.2.1.26).

All the objects within a MIB are assigned object identifiers relative to a parent object. Most MIBs import the object identifier of the parent object, along with other object identifiers, textual conventions, macros and syntax types from the MIBs where they are defined. This creates dependencies between MIBs.

Some network management stations and MIB compilers will generate errors if you load a MIB that depends on another MIB that has not already been loaded. To avoid these errors, we recommend that you load MIBs in the following order:

1. RFC 1212
RFC 1239
RFC 2257
RFC 3410
2. RFC1155-SMI (RFC 1155)
SNMPv2-SMI (RFC 2578)
SNMPv2-PDU (RFC 3416)
3. RFC1213-MIB (RFC 1213)
RFC 1215
SNMPv2-TC (RFC 2579)
SNMPv2-CONF (RFC 2580)
4. IP-MIB (RFC 2011)
TCP-MIB (RFC 2012)
UDP-MIB (RFC 2013)
IP-FORWARD-MIB (RFC 2096)
SNMP-MPD-MIB (RFC 2572)
RMON-MIB (RFC 2819)
HCNUM-TC (RFC 2856)
SNMP-FRAMEWORK-MIB (RFC 3411)
SNMP-MPD-MIB (RFC 3412)
SNMPv2-TM (RFC 3417)
SNMPv2-MIB (RFC 3418)
INET-ADDRESS-MIB (RFC 4001)
IANAifType-MIB
5. IF-MIB (RFC 2863)
SNMP-TARGET-MIB (RFC 3413)
6. SNMP-COMMUNITY-MIB (RFC 2576)
EtherLike-MIB (RFC 3635)
MAU-MIB (RFC 3636)
BRIDGE-MIB (RFC 4188)
DISMAN-PING-MIB (RFC 4560)
SNMP-NOTIFICATION-MIB (RFC 3413)
SNMP-PROXY-MIB (RFC 3413)
7. P-BRIDGE-MIB (RFC 2674)
Q-BRIDGE-MIB (RFC 2674)
RSTP-MIB (RFC 4318)

LLDP-MIB
LLDP-EXT-DOT1-MIB
LLDP-EXT-DOT3-MIB
LLDP-EXT-MED-MIB
POE-MIB
VRRP-MIB

8. AT-SMI-MIB


9. AT-BOARDS-MIB
AT-PRODUCT-MIB
AT-SETUP-MIB
AT-SYSINFO-MIB
AT-TRIGGER-MIB
AT-XEM-MIB
AT-VCSTACK-MIB
AT-USER-MIB
AT-RESOURCE-MIB
AT-LICENSE-MIB
AT-LOOPPROTECT-MIB
AT-DNS-CLIENT-MIB
AT-NTP-MIB
AT-EPSRv2-MIB
AT-FILEv2-MIB
AT-LOG-MIB
AT-IP-MIB
AT-ENVMONv2-MIB
AT-MIBVERSION-MIB

Allied Telesis Enterprise MIB

The *Allied Telesis Enterprise MIB* defines a portion of the Management Information Base (MIB) for managing Allied Telesis products and features that are not supported by public MIBs. Objects defined in this MIB reside in the private(4) subtree and have the object identifier alliedTelesis ({ enterprises 207 }).

This document describes only those portions of the Allied Telesis Enterprise MIB supported by the AlliedWare Plus™ Operating System. [Figure 76-1](#) shows the structure of the Allied Telesis Enterprise MIB. Each component MIB is detailed in the following sections of this chapter.

Figure 76-1: The Allied Telesis Enterprise MIB sub-tree of the Internet-standard Management Information Base (MIB)



AT-SMI-MIB

AT-SMI-MIB defines the high-level structure and root objects of the Allied Telesis Enterprise MIB ([Table 76-1](#)). These objects are imported by other component MIBs of the Allied Telesis Enterprise MIB.

Table 76-1: AT Enterprise MIB - High Level Structure

Object	Object Identifier	Description
alliedTelesis	{ enterprises 207 } 1.3.6.1.4.1.207	Root of the Allied Telesis Enterprise MIB under the private(4) node defined in RFC1155-SMI.
products	{ alliedTelesis 1 } 1.3.6.1.4.1.207.1	Sub-tree of all product OIDs. Described in AT-PRODUCT-MIB
bridgeRouter	{ products 1 } 1.3.6.1.4.1.207.1.1	Sub-tree of bridge product MIB objects (not applicable for AW Plus).
routerSwitch	{ products 14 } 1.3.6.1.4.1.207.1.2	Sub-tree for all router and switch product MIB objects.
mibObject	{ alliedTelesis 8 } 1.3.6.1.4.1.207.8	Sub-tree for all managed objects.
brouterMib	{ mibObject 4 } 1.3.6.1.4.1.207.8.4	Sub-tree of objects for managing bridges, routers, and switches.
atRouter	{ brouterMib 4 } 1.3.6.1.4.1.207.8.4.4	Sub-tree of objects for managing multiprotocol routers and switches.
objects	{ atRouter 1 } 1.3.6.1.4.1.207.8.4.4.1	Sub-tree of OIDs for boards, releases, interface types, and chips.
traps	{ atRouter 2 } 1.3.6.1.4.1.207.8.4.4.2	Sub-tree for generic traps.
sysinfo	{ atRouter 3 } 1.3.6.1.4.1.207.8.4.4.3	Sub-tree of objects describing general system information.
modules	{ atRouter 4 } 1.3.6.1.4.1.207.8.4.4.4	Sub-tree of objects for monitoring and managing software features.
arInterfaces	{ atRouter 5 } 1.3.6.1.4.1.207.8.4.4.5	Sub-tree of objects describing boards, slots and physical interfaces.
protocols	{ atRouter 6 } 1.3.6.1.4.1.207.8.4.4.6	Sub-tree of OIDs for protocols.
atAgents	{ atRouter 7 } 1.3.6.1.4.1.207.8.4.4.7	Sub-tree of objects describing variations from standards.

[Table 76-2](#) lists the major modules of the AT-SMI-MIB grouped by their object identifiers. Note that this is also the order in which they are described in this chapter.

Table 76-2: AT-SMI-MIBs Listed by Object Group

MIB Section	OID	Description
AT-SMI-MIB		This section describes the structure of management information for the Allied Telesis Enterprise object, alliedTelesis { 1.3.6.1.4.1.207 }
AT-PRODUCT-MIB	1.3.6.1.4.1.207.1	Object identifiers for Allied Telesis products. See “AT-PRODUCT-MIB” on page 76.9
AT-BOARDS-MIB	1.3.6.1.4.1.207.8.4.4.1.1	Object identifiers for boards, interface types, and chip sets. See “AT-BOARDS-MIB” on page 76.10
AT-SYSINFO-MIB	1.3.6.1.4.1.207.8.4.4.3	Objects that describe generic system information and environmental monitoring. See “AT-SYSINFO-MIB” on page 76.12
AT-XEM-MIB	1.3.6.1.4.1.207.8.4.4.3.11	Objects for managing XEMs (Expansion Modules). See “AT-XEM-MIB” on page 76.14
AT-ENVMONv2-MIB	1.3.6.1.4.1.207.8.4.4.3.12	Objects and traps for monitoring fans, voltage rails, temperature sensors, and power supply bays. See “AT-ENVMONv2-MIB” on page 76.15
AT-VCSTACK-MIB	1.3.6.1.4.1.207.8.4.4.3.13	Objects for managing Virtual Chassis Stacking (VCS). See “AT-VCSTACK-MIB” on page 76.21
AT-MIBVERSION-MIB	1.3.6.1.4.1.207.8.4.4.3.15	Object to display the last software release that contained changes to the support AT Enterprise MIB definition files. See “AT-MIBVERSION-MIB” on page 76.25 .
AT-USER-MIB	1.3.6.1.4.1.207.8.4.4.3.20	Objects for displaying information of users currently logged into a device, or configured in the Local User Data base of the device. See “AT-USER-MIB” on page 76.26
AT-RESOURCE-MIB	1.3.6.1.4.1.207.8.4.4.3.21	Objects for displaying system hardware resource information. See “AT-RESOURCE-MIB” on page 76.27
AT-LICENSE-MIB	1.3.6.1.4.1.207.8.4.4.3.22	Objects for managing software licenses on devices using AlliedWare Plus operating system. See “AT-LICENSE-MIB” on page 76.28
AT-TRIGGER-MIB	1.3.6.1.4.1.207.8.4.4.4.53	Objects for managing triggers. See “AT-TRIGGER-MIB” on page 76.31
AT-LOOPPROTECT-MIB	1.3.6.1.4.1.207.8.4.4.4.54	Objects for managing Allied Telesis Loop Protection. See “AT-LOOPPROTECT-MIB” on page 76.33
AT-SETUP-MIB	1.3.6.1.4.1.207.8.4.4.4.500	Objects for managing software installation and configuration files. See “AT-SETUP-MIB” on page 76.35
AT-DNS-CLIENT-MIB	1.3.6.1.4.1.207.8.4.4.4.501	Objects for managing Allied Telesis DNS Client Configuration. See “AT-DNS-CLIENT-MIB” on page 76.38
AT-NTP-MIB	1.3.6.1.4.1.207.8.4.4.4.502	Objects for managing Allied Telesis Network Time Protocol (NTP) configuration. See “AT-NTP-MIB” on page 76.39
AT-EPSRv2-MIB	1.3.6.1.4.1.207.8.4.4.4.536	Objects for managing Allied Telesis EPSR. See “AT-EPSRv2-MIB” on page 76.42
AT-FILEv2-MIB	1.3.6.1.4.1.207.8.4.4.4.600	Objects for displaying and managing file content on local, stacked and remote sources. See “AT-FILEv2-MIB” on page 76.45

Table 76-2: AT-SMI-MIBs Listed by Object Group(Continued)

MIB Section	OID	Description
AT-LOG-MIB	1.3.6.1.4.1.207.8.4.4.4.601	Objects for listing log entries from the buffered and permanent logs. See “AT-LOG-MIB” on page 76.52
AT-IP-MIB	1.3.6.1.4.1.207.8.4.4.4.602	Objects for Allied Telesis specific IP address management. See “AT-IP-MIB” on page 76.54

AT-PRODUCT-MIB

AT-PRODUCT-MIB defines object identifiers for Allied Telesis products. Objects in this MIB have the object identifier products ({ alliedTelesis 1 }). [Table 76-3](#) lists object identifiers for products supported by the AlliedWare Plus operating system.

Table 76-3: Object identifiers for Allied Telesis products supported by the AlliedWare Plus operating system

Object	Object Identifier	Description
routerSwitch	{ products 14 }	Switch products
at_SwitchBladex908	{ routerSwitch 69 }	Switchblade x908 8 Slot Layer 3 Switch Chassis
at_x900_12XTS	{ routerSwitch 70 }	AT-x900-12XT/S Advanced Gigabit Layer 3+ Expandable Switch, 12 x combo ports (10/100/1000BASE-T copper or SFP), 1 x 30Gbps expansion bay
at_x900_24XT	{ routerSwitch 75 }	x900-24XT Enhanced Gigabit Layer 3+ Expandable Switch, 24 x 10/100/1000BASE-T copper ports (RJ-45 connectors), 2 x 20 Gigabit expansion bays
at_x900_24XS	{ routerSwitch 76 }	x900-24XS Enhanced Gigabit Layer 3+ Expandable Switch, 24 x 10/100/1000BASE-T copper ports (RJ-45 connectors), 2 x 20 Gigabit expansion bays
at_x900_24XT_N	{ routerSwitch 77 }	x900-24XT-N Enhanced Gigabit Layer 3+ Expandable Switch, 24 x 10/100/1000BASE-T copper ports (RJ-45 connectors), 2 x 20 Gigabit expansion bays, NEBS compliant
at_x600_24Ts	{ routerSwitch 80 }	x600-24Ts Stackable Managed L2+/L3 Ethernet Switch, 24 x 1000BASE-T ports, 4 x SFP (combo) ports
at_x600_24TsXP	{ routerSwitch 81 }	x600-24Ts/XP Stackable Managed L2+/L3 Ethernet Switch, 24 x 1000BASE-T ports, 4 x SFP (combo) ports, 2 x XFP ports
at_x600_48Ts	{ routerSwitch 82 }	x600-48Ts Stackable Managed L2+/L3 Ethernet Switch, 48 x 1000BASE-T ports, 4 x SFP ports
at_x600_48TsXP	{ routerSwitch 83 }	x600-48Ts/XP Stackable Managed L2+/L3 Ethernet Switch, 48 x 1000BASE-T ports, 4 x SFP ports, 2 x XFP ports
at_x600-24TsPoE	{ routerSwitch 91 }	x600-24Ts-POE Stackable Managed L2+/L3 Ethernet PoE Switch, 24 x 1000BASE-T PoE ports, 4 x SFP (combo) ports

AT-BOARDS-MIB

AT-BOARDS-MIB defines object identifiers for components of Allied Telesis products—base CPU and expansion boards, interface types, and chip sets. Objects in this MIB have the object identifier objects ({ atRouter 1 }), and are organized into the following groups:

- Base CPU and expansion boards (Table 76-4). These object identifiers are for use with the hrDeviceID object in the Host Resources MIB (see “Public MIBs” on page 76.58).
- Interface types (Table 76-5).
- Chip sets (Table 76-6).

Table 76-4: Object identifiers for base CPU and expansion boards

Object	Object Identifier	Description
boards	{ objects 1 }	
pprx90024XT	{ boards 271 }	x900-24XT Enhanced Gigabit Layer 3+ Expandable Switch, 24 x 10/100/1000BASE-T copper ports (RJ-45 connectors), 2 x 20 Gigabit expansion bays
pprx90024XS	{ boards 272 }	x900-24XS Enhanced Gigabit Layer 3+ Expandable Switch, 24 x 10/100/1000BASE-T copper ports (RJ-45 connectors), 2 x 20 Gigabit expansion bays
pprAtXum10Gi	{ boards 273 }	XEM-1XP Expansion Module, 1 x 10Gbe XFP port
pprAtXum12SFPi	{ boards 274 }	XEM-12S Expansion Module, 12 x SFP Gigabit ports
pprAtXum12Ti	{ boards 275 }	XEM-12T Expansion Module, 12 x 10/100/100BASE-T copper ports (RJ-45 connectors)
pprAtXum12TiN	{ boards 280 }	XEM-12T-N Expansion Module, 12 x 10/100/100BASE-T copper ports (RJ-45 connectors), NEBS compliant
pprx90024XTN	{ boards 281 }	x900-24XT Enhanced Gigabit Layer 3+ Expandable Switch, 24 x 10/100/1000BASE-T copper ports (RJ-45 connectors), 2 x 20 Gigabit expansion bays, NEBS compliant
pprSwitchBladex908	{ boards 282 }	Switchblade x908 8 Slot Layer 3 Switch Chassis
pprXumStk	{ boards 286 }	XEM-STK Expansion Module, 2 x stacking ports
pprx90012XTS	{ boards 288 }	AT-x900-12XT/S Advanced Gigabit Layer 3+ Expandable Switch, 12 x combo ports (10/100/1000BASE-T copper or SFP), 1 x 30Gbps expansion bay
pprAt9524TS	{ boards 290 }	x600-24Ts/XP, 24 x 1000BASE-T ports (RJ45 connectors), 4 x SFP (combo) ports
pprAt9524TSXP	{ boards 291 }	x600-24Ts/XP, 24 x 1000BASE-T ports (RJ45 connectors), 4 x SFP (combo) ports, 2 x XFP ports
pprAt9548TS	{ boards 294 }	x600-44Ts, 44 x 1000BASE-T ports, 4 x SFP ports
pprAt9548TSXP	{ boards 295 }	x600-44Ts/XP, 44 x 1000BASE-T ports, 4 x SFP ports, 2 x XFP ports
pprATStackXG	{ boards 307 }	x600 Expansion Module, Stacking
pprATEMXP	{ boards 308 }	x600 Expansion Module, 2 x 10G XFP ports
pprATLBM	{ boards 309 }	x600 Expansion Module, loopback
pprAtPWR05DC	{ boards 323 }	AT-PWR05 DC Power Supply Unit for SwitchBlade x908
pprXem2XT	{ boards 325 }	XEM-2XT Expansion Module, 2 x 10Gbe copper XEM port
pprx60024TSPOE	{ boards 326 }	x600-24Ts-POE, 24 x 1000BASE-T PoE ports (RJ45 connectors), 4 x SFP (combo) ports

Table 76-5: Object identifiers for interface types

Object	Object Identifier	Description
iftypes	{ objects 3 }	
ifaceEth	{ iftypes 1 }	Ethernet
ifaceSyn	{ iftypes 2 }	Synchronous
ifaceAsyn	{ iftypes 3 }	Asynchronous
ifaceBri	{ iftypes 4 }	BRI ISDN
ifacePri	{ iftypes 5 }	PRI ISDN
ifacePots	{ iftypes 6 }	POTS (voice)
ifaceGBIC	{ iftypes 7 }	GBIC (Gigabit Interface Converter)

Table 76-6: Object identifiers for chip sets

Object	Object Identifier	Description
chips	{ objects 4 }	
chip68020Cpu	{ chips 1 }	MC68020 CPU
chip68340Cpu	{ chips 2 }	MC68340 CPU
chip68302Cpu	{ chips 3 }	MC68302 CPU
chip68360Cpu	{ chips 4 }	MC68360 CPU
chip860TCpu	{ chips 5 }	MPC860T CPU
chipRtc1	{ chips 21 }	Real Time Clock v1
chipRtc2	{ chips 22 }	Real Time Clock v2
chipRtc3	{ chips 23 }	Real Time Clock v3
chipRtc4	{ chips 24 }	Real Time Clock v4
chipRam1mb	{ chips 31 }	1 MB RAM
chipRam2mb	{ chips 32 }	2 MB RAM
chipRam3mb	{ chips 33 }	3 MB RAM
chipRam4mb	{ chips 34 }	4 MB RAM
chipRam6mb	{ chips 36 }	6 MB RAM
chipRam8mb	{ chips 38 }	8 MB RAM
chipRam12mb	{ chips 42 }	12 MB RAM
chipRam16mb	{ chips 46 }	16 MB RAM
chipRam20mb	{ chips 50 }	20 MB RAM
chipRam32mb	{ chips 62 }	32 MB RAM
chipFlash1mb	{ chips 71 }	1 MB FLASH memory
chipFlash2mb	{ chips 72 }	2 MB FLASH memory
chipFlash3mb	{ chips 73 }	3 MB FLASH memory
chipFlash4mb	{ chips 74 }	4 MB FLASH memory
chipFlash6mb	{ chips 76 }	6 MB FLASH memory
chipFlash8mb	{ chips 78 }	8 MB FLASH memory
chipPem	{ chips 120 }	Processor Enhancement Module

AT-SYSINFO-MIB

AT-SYSINFO-MIB defines objects that describe generic system information and environmental monitoring. Objects in this group have the object identifier sysinfo ({ atRouter 3 }). [Table 76-7](#) lists the objects supported by the AlliedWare Plus operating system.

Table 76-7: Objects defined in AT-SYSINFO-MIB

Object	Object Identifier	Description
sysinfo	{ atRouter 3 }	Subtree containing generic system information.
cpu	{ sysinfo 3 }	A collection of objects containing information about the CPU utilization over different periods of time. All values are expressed as a percentage - integer in range 0 to 100.
cpuUtilisationMax	{ cpu 1 }	Maximum CPU utilization since the device was last restarted.
cpuUtilisationAvg	{ cpu 2 }	Average CPU utilization since the device was last restarted.
cpuUtilisationAvgLastMinute	{ cpu 3 }	Average CPU utilization over the past minute.
cpuUtilisationAvgLast10Seconds	{ cpu 4 }	Average CPU utilization over the past ten seconds.
cpuUtilisationAvgLastSecond	{ cpu 5 }	Average CPU utilization over the past second.
cpuUtilisationAvgMaxLast5Minutes	{ cpu 6 }	Maximum CPU utilization over the last 5 minutes.
cpuUtilisationAvgLast5Minutes	{ cpu 7 }	Average CPU utilization over the past 5 minutes.
atContactDetails	{ sysinfo 5 }	Contact details for Allied Telesis.
memory	{ sysinfo 7 }	A collection of objects and traps for monitoring memory usage and status.
freeMemory	{ memory 1 }	Percentage of free memory still available on device.
totalBuffers	{ memory 2 }	Total number of buffers available on device.
lowMemoryTrap	{ memory 11 }	Notification of low memory, generated when a device's memory is below a certain level. Will display the values in 'freeMemory' and 'totalBuffers'
xem	{ sysinfo 11 }	A collection of objects for monitoring XEMs installed in the device. See "AT-XEM-MIB" on page 76.14
atEnvMonv2	{ sysinfo 12 }	AT Environment Monitoring v2 MIB for managing and reporting data relating to voltage rails, fan speeds, temperature sensors and power supply units. See "AT-ENVMONv2-MIB" on page 76.15
vcstack	{ sysinfo 13 }	A collection of objects for managing Virtual Chassis Stacking in AlliedWare Plus. See "AT-VCSTACK-MIB" on page 76.21
atPortInfo	{ sysinfo 14 }	Objects containing information about the transceiver of an interface.
atVlanInfo	{ sysinfo 16 }	A collection of objects for counting bytes or incoming frames within a selected VLAN. See "AT-VLAN-MIB" on page 76.56

Table 76-7: Objects defined in AT-SYSINFO-MIB(Continued)

Object	Object Identifier	Description
atPortInfoTransceiverTable	{ atPortInfo 1 }	A table containing information about the transceiver of an interface. Indexed by: ■ atPortInfoTransceiverifIndex
atPortInfoTransceiverEntry	{ atPortInfoTransceiverTable 1 }	Description of a single transceiver.
atPortInfoTransceiverifIndex	{ atPortInfoTransceiverEntry 1 }	The interface index for the interface represented by this entry.
atPortInfoTransceiverType	{ atPortInfoTransceiverEntry 2 }	The type of transceiver on an interface. Can be one of the following: ■ rj45 (1) ■ sfp-px (2) ■ sfp-bx10 (3) ■ sfp-fx (4) ■ sfp-100base-lx (5) ■ sfp-t (6) ■ sfp-cx (7) ■ sfp-zx-cwldm (8) ■ sfp-lx (9) ■ sfp-sx (10) ■ sfp-oc3-lr (11) ■ sfp-oc3-ir (12) ■ sfp-oc3-mm (13) ■ xfp-srsw (14) ■ xfp-lrlw (15) ■ xfp-erew (16) ■ xfp-sr (17) ■ xfp-lr (18) ■ xfp-er (19) ■ xfp-lrm (20) ■ xfp-sw (21) ■ xfp-lw (22) ■ xfp-ew (23) ■ unknown (24) ■ empty (25)

AT-XEM-MIB

AT-XEM-MIB defines objects for managing XEMs (Expansion Modules) installed in the device (Table 76-8). Objects in this group have the object identifier xem ({ sysinfo 11 }) and reside in the sysinfo Group of the Allied Telesis Enterprise MIB.

Table 76-8: Objects defined in AT-XEM-MIB

Object	Object Identifier	Description
xemTraps	{ xem 0 }	Collection of traps generated when a XEM is inserted or removed.
xemInserted	{ xemTraps 1 }	Trap generated when a XEM card is inserted to the device. It returns the objects xemInfoStackId and xemInfoBayId.
xemRemoved	{ xemTraps 2 }	Trap generated when a XEM card is removed from the device. It returns the objects xemInfoStackId and xemInfoBayId.
xemInsertedFail	{ xemTraps 3 }	Trap generated when the insertion of a XEM card into the device fails. It returns the objects xemInfoStackId and xemInfoBayId.
xemNumOfXem	{ xem 1 }	Total number of XEMs installed in the device.
xemInfoTable	{ xem 2 }	Table of information about the XEMs installed in the device, indexed by xemInfoMemberId and xemInfoBayId.
xemInfoEntry	{ xemInfoTable 1 }	Information about a single XEM.
xemInfoMemberId	{ xemInfoEntry 1 }	Stack Member ID in which the XEM is installed.
xemInfoBayId	{ xemInfoEntry 2 }	Number of the XEM bay in which the XEM is installed.
xemInfoXemId	{ xemInfoEntry 3 }	Numeric board identity of the XEM. This information is displayed in the ID column of the SHOW SYSTEM command.
xemInfoBoardType	{ xemInfoEntry 4 }	Board type. For XEMs this is always "Expansion". This information is displayed in the Board column of the SHOW SYSTEM command.
xemInfoBoardName	{ xemInfoEntry 5 }	Name of the XEM. This information is displayed in the Board Name column of the SHOW SYSTEM command.
xemInfoRevision	{ xemInfoEntry 6 }	Board revision of the XEM. This information is displayed in the Rev column of the SHOW SYSTEM command.
xemInfoSerialNumber	{ xemInfoEntry 7 }	Serial number of the XEM. This information is displayed in the Serial Number column of the SHOW SYSTEM command.

AT-ENVMONv2-MIB

The AT Environment Monitoring v2 MIB (atEnvMonv2-MIB) contains objects for managing and reporting data relating to fans, voltage rails, temperature sensors and power supply units installed in the device (Table 76-9). Objects in this group have the object identifier EnvMonv2 ({ sysinfo 12 }).

Table 76-9: Objects defined in AT-ENVMONV2-MIB

Object / Object Identifier	Description
atEnvMonv2FanTable { EnvMonv2 1 }	Table of information about fans installed in the device that have their fan speeds monitored by environment monitoring hardware, indexed by: ■ atEnvMonv2FanStackMemberId ■ atEnvMonv2FanBoardIndex ■ atEnvMonv2FanIndex
atEnvMonv2FanEntry { atEnvMonv2FanTable 1 }	Description, current speed, lower threshold speed and current status of a single fan.
atEnvMonv2FanStackMemberId { atEnvMonv2FanEntry 1 }	Index of the stack member hosting this fan.
atEnvMonv2FanBoardIndex { atEnvMonv2FanEntry 2 }	Index of the board hosting this fan in the board table.
atEnvMonv2FanIndex { atEnvMonv2FanEntry 3 }	Numeric identifier of this fan on its host board.
atEnvMonv2FanDescription { atEnvMonv2FanEntry 4 }	Description of this fan.
atEnvMonv2FanCurrentSpeed { atEnvMonv2FanEntry 5 }	Current speed of this fan in revolutions per minute.
atEnvMonv2FanLowerThreshold { atEnvMonv2FanEntry 6 }	Minimum acceptable speed of the fan in revolutions per minute.
atEnvMonv2FanStatus { atEnvMonv2FanEntry 7 }	Whether this fan is currently in an alarm condition. The values can be: ■ Failed (1) means that the current speed is too low. ■ Good (2) means that the current speed is acceptable.
atEnvMonv2VoltageTable { atEnvMonv2 2 }	Table of information about voltage rails in the device that are monitored by environment monitoring hardware, indexed by: ■ atEnvMonv2VoltageStackMemberId ■ atEnvMonv2VoltageBoardIndex ■ atEnvMonv2VoltageIndex
atEnvMonv2VoltageEntry { atEnvMonv2VoltageTable 1 }	Description, current value, upper & lower threshold settings and current status of a single voltage rail.
atEnvMonv2VoltageStackMemberId { atEnvMonv2VoltageEntry 1 }	Index of the stack member hosting this voltage sensor.
atEnvMonv2VoltageBoardIndex { atEnvMonv2VoltageEntry 2 }	Index of the board hosting this voltage sensor in the board table.
atEnvMonv2VoltageIndex { atEnvMonv2VoltageEntry 3 }	Numeric identifier of this voltage rail on its host board.
atEnvMonv2VoltageDescription { atEnvMonv2VoltageEntry 4 }	Description of this voltage rail.
atEnvMonv2VoltageCurrent { atEnvMonv2VoltageEntry 5 }	Current reading of this voltage rail in millivolts.
atEnvMonv2VoltageUpperThreshold { atEnvMonv2VoltageEntry 6 }	Maximum acceptable reading of this voltage rail in millivolts.

Table 76-9: Objects defined in AT-ENVMONV2-MIB(Continued)

Object / Object Identifier	Description
atEnvMonv2VoltageLowerThreshold { atEnvMonv2VoltageEntry 7 }	Minimum acceptable reading of this voltage rail in millivolts.
atEnvMonv2VoltageStatus { atEnvMonv2VoltageEntry 8 }	Whether this voltage rail is currently in an alarm condition. Possible values are: ■ outOfRange (1) - means that the current reading is outside the threshold range. ■ inRange (2) - means that the current reading is acceptable.
atEnvMonv2TemperatureTable { atEnvMonv2 3 }	Table of information about temperature sensors in the device that are monitored by environment monitoring hardware, indexed by: ■ atEnvMonv2TemperatureStackMemberId ■ atEnvMonv2TemperatureBoardIndex ■ atEnvMonv2TemperatureIndex
atEnvMonv2TemperatureEntry { atEnvMonv2TemperatureTable 1 }	Description, current value, upper threshold setting and current status of a single temperature sensor.
atEnvMonv2TemperatureStackMemberId { atEnvMonv2TemperatureEntry 1 }	Index of the stack member hosting this temperature sensor.
atEnvMonv2TemperatureBoardIndex { atEnvMonv2TemperatureEntry 2 }	Index of the board hosting this temperature sensor in the board table.
atEnvMonv2TemperatureIndex { atEnvMonv2TemperatureEntry 3 }	Numeric identifier of this temperature sensor on its host board.
atEnvMonv2TemperatureDescription { atEnvMonv2TemperatureEntry 4 }	Description of this temperature sensor.
atEnvMonv2TemperatureCurrent { atEnvMonv2TemperatureEntry 5 }	Current reading of this temperature sensor in degrees Celsius.
atEnvMonv2TemperatureUpperThreshold { atEnvMonv2TemperatureEntry 6 }	Maximum acceptable reading for this temperature sensor in degrees Celsius.
atEnvMonv2TemperatureStatus { atEnvMonv2TemperatureEntry 7 }	Whether this temperature sensor is currently in an alarm condition. Can be: ■ outOfRange (1) - means that the current reading is outside the threshold range. ■ inRange (2) - means that the current reading is acceptable.
atEnvMonv2PsbObjects { atEnvMonv2 4 }	Collection of objects for monitoring power supply bays in the system and any devices that are installed. It contains the following objects: ■ atEnvMonv2PsbTable ■ atEnvMonv2PsbSensorTable
atEnvMonv2PsbTable { atEnvMonv2PsbObjects 1 }	Table of information about power supply bays in the system, indexed by: ■ atEnvMonv2PsbHostStackMemberId ■ atEnvMonv2PsbHostBoardIndex ■ atEnvMonv2PsbHostSlotIndex
atEnvMonv2PsbEntry { atEnvMonv2PsbTable 1 }	Description and current status of a single power supply bay device.
atEnvMonv2PsbHostStackMemberId { atEnvMonv2PsbEntry 1 }	Index of the stack member hosting this power supply bay.
atEnvMonv2PsbHostBoardIndex { atEnvMonv2PsbEntry 2 }	Index of the board hosting this power supply bay in the board table.
atEnvMonv2PsbHostSlotIndex { atEnvMonv2PsbEntry 3 }	Index of this power supply bay slot on its host board. This index is fixed for each slot, on each type of board.

Table 76-9: Objects defined in AT-ENVMONV2-MIB(Continued)

Object / Object Identifier	Description
atEnvMonv2PsbHeldBoardIndex { atEnvMonv2PsbEntry 4 }	Index of a board installed in this power supply bay. This value corresponds to atEnvMonv2PsbSensorBoardIndex for each sensor on this board. A value of 0 indicates that a board is either not present or not supported.
atEnvMonv2PsbHeldBoardId { atEnvMonv2PsbEntry 5 }	Type of board installed in this power supply bay. The values of this object are taken from the pprXxx object IDs under the boards sub-tree in the parent MIB. A value of 0 indicates that a board is either not present or not supported.
atEnvMonv2PsbDescription { atEnvMonv2PsbEntry 6 }	Description of this power supply bay.
atEnvMonv2PsbSensorTable { atEnvMonv2PsbObjects 2 }	Table of information about environment monitoring sensors on devices installed in power supply bays, indexed by: ■ atEnvMonv2PsbSensorStackMemberId ■ atEnvMonv2PsbSensorBoardIndex ■ atEnvMonv2PsbSensorIndex
atEnvMonv2PsbSensorEntry { atEnvMonv2PsbSensorTable 1 }	Description and current status of the sensor on a device installed in a power supply bay.
atEnvMonv2PsbSensorStackMemberId { atEnvMonv2PsbSensorEntry 1 }	Index of the stack member hosting this sensor.
atEnvMonv2PsbSensorBoardIndex { atEnvMonv2PsbSensorEntry 2 }	Index of the board hosting this sensor in the board table.
atEnvMonv2PsbSensorIndex { atEnvMonv2PsbSensorEntry 3 }	Index of this power supply bay environmental sensor on its host board.
atEnvMonv2PsbSensorType { atEnvMonv2PsbSensorEntry 4 }	Type of environmental variable this sensor detects. One of: ■ psbSensorTypeInvalid(0) ■ fanSpeedDiscrete(1) ■ temperatureDiscrete(2) ■ voltageDiscrete(3)
atEnvMonv2PsbSensorDescription { atEnvMonv2PsbSensorEntry 5 }	Description of this power supply bay environmental sensor.
atEnvMonv2PsbSensorStatus { atEnvMonv2PsbSensorEntry 6 }	Whether this environmental sensor is currently in an alarm condition. One of: ■ failed (1) - means that the device is in a failure condition ■ good(2) - means that the device is functioning normally. ■ notPowered (3) - a PSU is installed, but not powered up
atEnvMonv2Traps { atEnvMonv2 5 }	Collection of traps (notification) objects for monitoring fans, voltage rails, temperature sensors, and power supply bays.
atEnvMonv2FanAlarmSetEvent { atEnvMonv2Traps 1 }	Notification generated when the monitored speed of a fan drops below its lower threshold. It returns the value of: ■ atEnvMonv2FanStackMemberId ■ atEnvMonv2FanBoardIndex ■ atEnvMonv2FanIndex ■ atEnvMonv2FanDescription ■ atEnvMonv2FanLowerThreshold ■ atEnvMonv2FanCurrentSpeed

Table 76-9: Objects defined in AT-ENVMONV2-MIB(Continued)

Object / Object Identifier	Description
atEnvMonv2FanAlarmClearedEvent { atEnvMonv2Traps 2 }	Notification generated when the monitored speed of a fan returns to an acceptable value, the fan having previously been in an alarm condition. It returns the value of: ■ atEnvMonv2FanStackMemberId ■ atEnvMonv2FanBoardIndex ■ atEnvMonv2FanIndex ■ atEnvMonv2FanDescription ■ atEnvMonv2FanLowerThreshold ■ atEnvMonv2FanCurrentSpeed
atEnvMonv2VoltAlarmSetEvent { atEnvMonv2Traps 3 }	Notification generated when the voltage of a monitored voltage rail, goes out of tolerance by either dropping below its lower threshold, or exceeding its upper threshold. It returns the value of: ■ atEnvMonv2VoltageStackMemberId ■ atEnvMonv2VoltageBoardIndex ■ atEnvMonv2VoltageIndex ■ atEnvMonv2VoltageDescription ■ atEnvMonv2VoltageUpperThreshold ■ atEnvMonv2VoltageLowerThreshold ■ atEnvMonv2VoltageCurrent
atEnvMonv2VoltAlarmClearedEvent { atEnvMonv2Traps 4 }	Notification generated when the voltage of a monitored voltage rail returns to an acceptable value, having previously been in an alarm condition. It returns the value of: ■ atEnvMonv2VoltageStackMemberId ■ atEnvMonv2VoltageBoardIndex ■ atEnvMonv2VoltageIndex ■ atEnvMonv2VoltageDescription ■ atEnvMonv2VoltageUpperThreshold ■ atEnvMonv2VoltageLowerThreshold ■ atEnvMonv2VoltageCurrent
atEnvMonv2TempAlarmSetEvent { atEnvMonv2Traps 5 }	Notification generated when a monitored temperature exceeds its upper threshold. It returns the value of: ■ atEnvMonv2TemperatureStackMemberId ■ atEnvMonv2TemperatureBoardIndex ■ atEnvMonv2TemperatureIndex ■ atEnvMonv2TemperatureDescription ■ atEnvMonv2TemperatureUpperThreshold ■ atEnvMonv2TemperatureCurrent
atEnvMonv2TempAlarmClearedEvent { atEnvMonv2Traps 6 }	Notification generated when a monitored temperature returns to an acceptable value, having previously been in an alarm condition. It returns the value of: ■ atEnvMonv2TemperatureStackMemberId ■ atEnvMonv2TemperatureBoardIndex ■ atEnvMonv2TemperatureIndex ■ atEnvMonv2TemperatureDescription ■ atEnvMonv2TemperatureUpperThreshold

Table 76-9: Objects defined in AT-ENVMONV2-MIB(Continued)

Object / Object Identifier	Description
atEnvMonv2PsbAlarmSetEvent { atEnvMonv2Traps 7 }	Notification generated when a monitored parameter of a power supply bay device goes out of tolerance. It returns the value of: ■ atEnvMonv2PsbSensorStackMemberId ■ atEnvMonv2PsbSensorBoardIndex ■ atEnvMonv2PsbSensorIndex ■ atEnvMonv2PsbSensorType ■ atEnvMonv2PsbSensorDescription
atEnvMonv2PsbAlarmClearedEvent { atEnvMonv2Traps 8 }	Notification generated when a monitored parameter of a power supply bay device returns to an acceptable value, having previously been in an alarm condition. It returns the value of: ■ atEnvMonv2PsbSensorStackMemberId ■ atEnvMonv2PsbSensorBoardIndex ■ atEnvMonv2PsbSensorIndex ■ atEnvMonv2PsbSensorType ■ atEnvMonv2PsbSensorDescription
atEnvMonv2FaultLedTable { atEnvMonv2 6 }	Table detailing any LED fault indications on the device, indexed by: ■ atEnvMonv2FaultLedStackMemberId

Table 76-9: Objects defined in AT-ENVMONV2-MIB(Continued)

Object / Object Identifier	Description
atEnvMonv2FaultLedEntry { atEnvMonv2FaultLedTable 1 }	Information pertaining to a given fault LED.
atEnvMonv2FaultLedStackMemberId { atEnvMonv2FaultLedEntry 1 }	Index of the stack member hosting this fault LED.
atEnvMonv2FaultLed1Flash { atEnvMonv2FaultLedEntry 2 }	Indicates whether a fault LED is currently showing a system failure by flashing once. Values can be: ■ heatsinkFanFailure (1) - indicates that one or more heatsink fans have failed, or are operating below the recommended speed ■ noFault (2)
atEnvMonv2FaultLed2Flashes { atEnvMonv2FaultLedEntry 3 }	Indicates whether a fault LED is currently showing a system failure by flashing twice. Values can be: ■ chassisFanFailure (1) - indicates that one or both of the chassis fans are not installed, or the fans are operating below the recommended speed ■ noFault (2)
atEnvMonv2FaultLed3Flashes { atEnvMonv2FaultLedEntry 4 }	Indicates whether a fault LED is currently showing a system failure by flashing three times. Values can be: ■ sensorFailure (1) - indicates that the ability to monitor temperature or fans has failed ■ noFault (2)
atEnvMonv2FaultLed4Flashes { atEnvMonv2FaultLedEntry 5 }	Indicates whether a fault LED is currently showing a system failure by flashing four times. Values can be: ■ xemInitialisationFailure (1) - indicates that a XEM failed to initialise or is incompatible ■ noFault (2)
atEnvMonv2FaultLed5Flashes { atEnvMonv2FaultLedEntry 6 }	Indicates whether a fault LED is currently showing a system failure by flashing five times. This flashing sequence is not currently in use. Value is: ■ noFault (2)
atEnvMonv2FaultLed6Flashes { atEnvMonv2FaultLedEntry 7 }	Indicates whether a fault LED is currently showing a system failure by flashing six times. Values can be: ■ temperatureFailure (1) - indicates that the device's temperature has exceeded the recommended threshold ■ noFault (2)

AT-VCSTACK-MIB

AT-VCSTACK-MIB defines objects for managing virtual chassis stacking (Table 76-10). Objects in this group have the object identifier vcstack ({ sysinfo 13 }).

Figure 76-2 on page 76.21 shows the tree structure of the AT-VCSTACK objects.

Figure 76-2: The AT-VCSTACK MIB sub-tree




Table 76-10: Objects defined in AT-VCSTACK-MIB

Object	Object Identifier	Description
vcstack	{ sysinfo (13) }	Overall stack status.
vcstackStatus	{ vcstack 1 }	The stack status can take one of the following states: ■ normalOperation (1) ■ operatingInFailoverState (2) ■ standaloneUnit (3) ■ ringTopologyBroken (4)
vcstackOperationalStatus	{ vcstack 2 }	The operational status of the stack can be either: ■ enabled (1) ■ disabled (2)
vcstackMgmtVlanId	{ vcstack 3 }	The current stacking management VLAN ID
vcstackMgmtVlanSubnetAddr	{ vcstack 4 }	The current stacking management VLAN subnet address
vcstackTable	{ vcstack 5 }	Table of information about stack members, indexed by vcstackId.
vcstackEntry	{ vcstackTable 1 }	Information about a single stack member, indexed by vcstackId.
vcstackId	{ vcstackEntry 1 }	Stack member ID.
vcstackPendingId	{ vcstackEntry 2 }	Pending stack member ID.
vcstackMacAddr	{ vcstackEntry 3 }	Stack member's hardware MAC address.
vcstackPriority	{ vcstackEntry 4 }	Priority for election of the stack master. The lowest number has the highest priority.
vcstackRole	{ vcstackEntry 5 }	Stack member's role in the stack. Can be one of the following: ■ leaving (1) ■ discovering (2) ■ synchronizing (3) ■ backupMember (4) ■ pendingMaster (5) ■ disabledMaster (6) ■ fallbackMaster (7) ■ activeMaster (8)
vcstackLastRoleChange	{ vcstackEntry 6 }	Time and date when the stack member last changed its role in the stack.
vcstackHostname	{ vcstackEntry 7 }	Stack member's hostname.
vcstackProductType	{ vcstackEntry 8 }	Stack members product type.
vcstackSWVersionAutoSync	{ vcstackEntry 9 }	Whether or not the stack member's software is automatically upgraded.
vcstackFallbackConfigStatus	{ vcstackEntry 10 }	Status of the fallback configuration file. Can be one of: ■ fileExists (1) ■ fileNotFound (2) ■ notConfigured (3)
vcstackFallbackConfigFilename	{ vcstackEntry 11 }	Filename of the fallback configuration file.

Table 76-10: Objects defined in AT-VCSTACK-MIB(Continued)

Object	Object Identifier	Description
vcstackResiliencyLinkStatus	{ vcstackEntry 12 }	Status of the stack members resiliency link. Can be one of: ■ configured (1) ■ successful (2) ■ failed (3) ■ notConfigured (4)
vcstackResiliencyLinkInterfaceName	{ vcstackEntry 13 }	Name of the interface the resiliency link is configured on.
vcstackActiveStkHardware	{ vcstackEntry 14 }	Stack ports hardware type. Can be one of: ■ value (0) is now obsolete ■ xemStk (1) ■ builtinStackingPorts (2) ■ none (3) is now obsolete ■ stackXG (4)
vcstackStkPort1Status	{ vcstackEntry 15 }	Status of stack-port 1. Can be one of the following: ■ down (1) ■ neighbourIncompatible (2) ■ discoveringNeighbour (3) ■ learntNeighbour (4)
vcstackStkPort1NeighbourId	{ vcstackEntry 16 }	ID of the neighbor on stack-port 1. Zero indicates no learned neighbor.
vcstackStkPort2Status	{ vcstackEntry 17 }	Status of stack-port 2. Can be one of: ■ down (1) ■ neighbourIncompatible (2) ■ discoveringNeighbour (3) ■ learntNeighbour (4)
vcstackStkPort2NeighbourId	{ vcstackEntry 18 }	ID of the neighbor on stack-port 2. Zero indicates no learned neighbor.
vcstackNumMembersJoined	{ vcstackEntry 19 }	Number of times the stack has acquired a member.
vcstackNumMembersLeft	{ vcstackEntry 20 }	Number of times the stack has lost a member.
vcstackNumIdConflict	{ vcstackEntry 21 }	Number of times that a stack member ID conflict has occurred.
vcstackNumMasterConflict	{ vcstackEntry 22 }	Number of times that a stack master conflict has occurred.
vcstackNumMasterFailover	{ vcstackEntry 23 }	Number of times that the stack master has failed.
vcstackNumStkPort1NbrIncompatible	{ vcstackEntry 24 }	Number of times that the neighbor on stack port 1 was incompatible.
vcstackNumStkPort2NbrIncompatible	{ vcstackEntry 25 }	Number of times that the neighbor on stack port 2 was incompatible.
vcstackTraps	{ vcstack 6 }	List of traps (notifications) generated for the stack:
vcstackRoleChange	{ vcstackTraps 1 }	Notification generated when the stack member's role is changed. Displays the objects: ■ vcstackId ■ vcstackRole

Table 76-10: Objects defined in AT-VCSTACK-MIB(Continued)

Object	Object Identifier	Description
vcstackMemberJoin	{ vcstackTraps 2 }	Notification generated when a member joins the stack. Displays the objects: ■ vcstackId ■ vcstackNbrMemberId
vcstackMemberLeave	{ vcstackTraps 3 }	Notification generated when a member leaves the stack. Displays the objects: ■ vcstackId ■ vcstackNbrMemberId
vcstackResiliencyLinkHealthCheckReceiving	{ vcstackTraps 4 }	Notification generated when the resiliency link is activated. Displays the objects: ■ vcstackId ■ vcstackResiliencyLinkInterfaceName
vcstackResiliencyLinkHealthCheckTimeOut	{ vcstackTraps 5 }	Notification generated when the slave's receive timer has timed-out, indicating that the Slave has lost contact with the Master via the resiliency link. Displays the objects: ■ vcstackId ■ vcstackResiliencyLinkInterfaceName
vcstackStkPortLinkUp	{ vcstackTraps 6 }	Notification generated when the stack port link is up. Displays the objects: ■ vcstackId ■ vcstackStkPortName
vcstackStkPortLinkDown	{ vcstackTraps 7 }	Notification generated when the stack port link is down. Displays the objects: ■ vcstackId ■ vcstackStkPortName
vcstackNbrMemberId	{ vcstackTraps 8 }	The stack member id related to this trap
vcstackStkPortName	{ vcstackTraps 9 }	The stack port name related to this trap
vcstackVirtualMacAddressStatus	{vcstack 7}	Indicates whether the virtual MAC address is enabled or disabled. Read-only object.
vcstackVirtualChassisId	{vcstack 8}	Displays the current virtual chassis ID. Read-only object.
vcstackVirtualMacAddr	{vcstack 9}	Displays the virtual MAC address used by the stack. Read-only object.
vcstackMasterId	{vcstack 10}	Displays the stack ID of the master unit, or the stack ID of the standalone unit. Read-only object

AT-MIBVERSION-MIB

The AT-MIBVERSION-MIB contains an object to display the last software release that contained changes to the supported AT Enterprise MIB definition files ([Table 76-11](#)). Objects in this group have the object identifier atMibsetVersion ({ sysinfo 15 }).

Table 76-11: Object defined in AT-MIBVERSION-MIB

Object	Object Identifier	Description
atMibsetVersion	{ sysinfo 15 }	This object returns a five digit integer which indicates the last software release that contained changes to the supported AT Enterprise MIB definition files. For example, If the currently loaded software release on the device is 5.3.1-0.3 but the Enterprise MIBs have not changed since 5.3.1-0.1, then the value returned will be 53101.

AT-USER-MIB

The AT-USER-MIB contains objects for displaying information about users currently logged into a device, or configured in the Local User Database of the device (Table 76-12). Objects in this group have the object identifier user ({ sysinfo 20 }).

Table 76-12: Objects defined in AT-USER-MIB

Object	Object Identifier	Description
userInfoTable	{ user 1 }	Table containing information about users. Each entry in the table represents a user currently logged into the device. Indexed by: rscBoardType and rscBoardIndex
userInfoEntry	{ userInfoTable 1 }	Information about a single user logged into the device.
userInfoType	{ userInfoEntry 1 }	The type of connection through which the user logged into the device. Can be: ■ console (1) ■ aux (2) ■ telnet (3) ■ script (4) ■ stack (5)
userInfoIndex	{ userInfoEntry 2 }	Index of the line upon which the user logged into the device. Can be a value in range 1 to 16.
userInfoName	{ userInfoEntry 3 }	User name of the user logged into the device.
userInfoPrivilegeLevel	{ userInfoEntry 4 }	The user's privilege level. Can be a value in range 1 to 15.
userInfoIdleTime	{ userInfoEntry 5 }	The amount of time since the user was last active, in the form hh:mm:ss.
userInfoLocation	{ userInfoEntry 6 }	The user location or login method. It can be an IP Address used by the user to telnet into the device, or an asyn port, etc.
userConfigTable	{ user 2 }	Table containing user configuration information. Each entry in the table relates to a user configured in the Local User Database of the device. Indexed by userConfigIndex.
userConfigEntry	{ userConfigTable 1 }	Information about a single user configured in the Local User Database of the device.
userConfigIndex	{ userConfigEntry 1 }	Unique number used to identify entries in the userConfigTable.
userConfigName	{ userConfigEntry 2 }	The user's name.
userConfigPrivilegeLevel	{ userConfigEntry 3 }	The privilege level granted to the user. Can be a value in range 1 to 15.

AT-RESOURCE-MIB

The AT-RESOURCE-MIB contains objects for displaying system hardware resource and host information (Table 76-13). Objects in this group have the object identifier rsc ({ sysinfo 21 }).

Table 76-13: Objects defined in AT-RESOURCE-MIB

Object	Object Identifier	Description
resource	{ sysinfo 21 }	Contains objects for displaying system hardware resource and host information.
rscBoardTable	{ resource 1 }	Table containing information about boards installed in a device. Indexed by: ■ rscStkId ■ rscResourceId
rscBoardEntry	{ rscBoardTable 1 }	Information about a single board installed in the device.
rscStkId	{ rscBoardEntry 1 }	The ID of the stack member. It is a number from 1 to 8, assigned to a stackable unit by the operating system when it is stacked. A default value of 1 is given to a stand alone unit.
rscResourceId	{ rscBoardEntry 2 }	The resource ID number of the board. It is a number assigned to a hardware resource when the operating system detects its existence. Can be a value in range 1 to 4294967294.
rscBoardType	{ rscBoardEntry 3 }	The type of board. Can be one of the following: ■ Base ■ Expansion ■ Fan module ■ PSU, etc.
rscBoardName	{ rscBoardEntry 4 }	The name of the board. Can be one of the following: ■ SwitchBlade x908 ■ XEM-12S ■ AT-PWR05-AC, etc
rscBoardId	{ rscBoardEntry 5 }	The ID number of the board. Its value is an Allied Telesis assigned number, such as 274 for the XEM-12S, or 255 for the AT-9924Ts.
rscBoardBay	{ rscBoardEntry 6 }	The board installation location. Its value can be Bay1, Bay2, PSU1, etc. For a base board, it has a value of a single character space.
rscBoardRevision	{ rscBoardEntry 7 }	The revision number of the board.
rscBoardSerialNumber	{ rscBoardEntry 8 }	The serial number of the board.
hostInfoTable	{ resource 2 }	Table containing general system information. Indexed by rscStkId.
hostInfoEntry	{ hostInfoTable 1 }	Information about a single system parameter
hostInfoDRAM	{ hostInfoEntry 1 }	The host DRAM information.
hostInfoFlash	{ hostInfoEntry 2 }	The host Flash information.
hostInfoUptime	{ hostInfoEntry 3 }	The host up-time.
hostInfoBootloaderVersion	{ hostInfoEntry 4 }	The host boot loader version.

AT-LICENSE-MIB

The AT-LICENSE-MIB contains objects for managing the AlliedWare Plus operating system software licenses: listing applied software licenses, adding new licenses and deleting existing licenses (Table 76-14). The objects reside in the module license { sysinfo 22 }, organized in the following groups:

- Base Software License Table - a table containing the installed base software licenses on the device
- Installed Software License Table - a list of installed software licenses; used also to remove software license from the device
- Available Software Features Table
- LicenseNew - Objects used to install a new license

Table 76-14: Objects defined in AT-LICENSE-MIB

Object	Object Identifier	Description
license	{ sysinfo 22 }	MIB containing objects for listing applied software licenses, adding new licenses, and deleting existing licenses.
baseLicenseTable	{ license 1 }	Table containing information about base software licenses installed on a device. Indexed by: ■ baseLicenseStkId
baseLicenseEntry	{ baseLicenseTable 1 }	Information about a single license installed on the device.
baseLicenseStkId	{ baseLicenseEntry 1 }	The index number of the base license entry.
baseLicenseName	{ baseLicenseEntry 2 }	The name of the base license.
baseLicenseQuantity	{ baseLicenseEntry 3 }	The number of licenses issued for this entry.
baseLicenseType	{ baseLicenseEntry 4 }	The type of base license issued.
baseLicenseIssueDate	{ baseLicenseEntry 5 }	The date of issue of the base license.
baseLicenseExpiryDate	{ baseLicenseEntry 6 }	The expiry date of the base license.
baseLicenseFeatures	{ baseLicenseEntry 7 }	The feature set that this license enables, in the format of an octet string. Each bit in the returned octet string represents a particular feature that can be license-enabled. The bit position within the string maps to the feature entry with the same index, in licenseFeatureTable. A binary '1' indicates that the feature is included in the license; a binary '0' indicates that the feature is not included in the license.
licenseTable	{ license 2 }	Table containing information about software licenses installed on the device. Indexed by: ■ licenseIndex ■ licenseStackId
licenseEntry	{ licenseTable 1 }	Information about a single installed software license on the device.
licenseStackId	{ licenseEntry 1 }	The index number of the license entry.
licenseIndex	{ licenseEntry 2 }	The index number of the license entry.
licenseName	{ licenseEntry 3 }	The name of the license.
licenseCustomer	{ licenseEntry 4 }	The name of the customer of the license.
licenseQuantity	{ licenseEntry 5 }	The number of licenses issued for this entry.
licenseType	{ licenseEntry 6 }	The type of license issued.
licenseIssueDate	{ licenseEntry 7 }	The date of issue of the license.
licenseExpiryDate	{ licenseEntry 8 }	The expiry date of the license.

Table 76-14: Objects defined in AT-LICENSE-MIB(Continued)

Object	Object Identifier	Description
licenseFeatures	{ licenseEntry 9 }	The feature set that this license enables, in the format of octet string. Each bit in the returned octet string represents a particular feature that can be license-enabled. The bit position within the string maps to the feature entry with the same index, in licenseFeatureTable. A binary '1' indicates that the feature is included in the license; a binary '0' indicates that the feature is not included in the license.
licenseRowStatus	{ licenseEntry 10 }	The current status of the license. The following values may be returned when reading this object: ■ active (1) - the license is currently installed and valid ■ notInService (2) - the license has expired or is invalid The following value may be written to this object: ■ destroy (6) - the license will be removed from the device; this may result in some features being disabled. <i>Note: Note that a stacked device that has a license deleted may not be able to rejoin the stack after reboot, unless the license is also deleted on all other devices in the stack.</i>
licenseFeatureTable	{ license 3 }	Table containing all available Software Features. All features must be license-enabled to be utilized on the device.
licenseFeatureEntry	{ licenseFeatureTable 1 }	Information about a single feature that must be licensed-enabled in order to be utilized on the device.
licenseFeatureIndex	{ licenseFeatureEntry 1 }	The index number of the feature which must be license-enabled.
licenseFeatureName	{ licenseFeatureEntry 2 }	The name of the feature under licensing control.
licenseFeatureStkMembers	{ licenseFeatureEntry 3 }	The feature set of license features for all stacking members, in the format of an octet string. Each bit in the string maps to an individual stacking member, e.g. bit one represents stacking member one, bit two represents stacking member two, etc. In the case of a standalone unit, the first bit represents the device. A bit value of '1' indicates that the applicable feature is enabled on the matching device; a bit value of '0' indicates that the feature is disabled.
licenseNew	{ license 4 }	Group of objects available for updates, used when installing a new software license on the device.

Table 76-14: Objects defined in AT-LICENSE-MIB(Continued)

Object	Object Identifier	Description
licenseNewStackId	{ licenseNew 1 }	The ID of the stacking member upon which the new license is to be installed. The valid number range is 1 to 10. For a standalone unit, this should be set to the default value of 1.
licenseNewName	{ licenseNew 2 }	The name of the new license to be installed.
licenseNewKey	{ licenseNew 3 }	The key for the new license to be installed.
licenseNewInstall	{ licenseNew 4 }	Used to install new licenses. Values can be: ■ true (1) ■ false (2) To commence installation, a valid license name and key must first have been set via the licenseNewName and licenseNewKey respectively. This object should then be set to the value true (1). If either the license name or key is invalid, the write operation will fail. Once installed, the software modules affected by any newly enabled features will automatically be restarted. In some cases a system reboot will also be necessary. <i>Note: A stacked device that has a new license installed on it may not be able to rejoin the stack after reboot, unless the license is also added to all other devices in the stack.</i> When read, the object will always return the value false (2).

AT-TRIGGER-MIB

AT-TRIGGER-MIB defines objects for managing triggers ([Table 76-15](#)). Objects in this group have the object identifier trigger ({ modules 53 }). All objects in this group have read only access.

Table 76-15: Objects defined in AT-TRIGGER-MIB

Object Identifier	Description
triggerTraps { trigger 0 }	Sub-tree for all trigger traps.
triggerTrap { triggerTraps 1 }	Notification generated when a trigger is activated. It returns the value of triggerLastTriggerActivated.
triggerLastTriggerActivated { trigger 1 }	Trigger number of the most recent trigger activated on the switch.
triggerConfigInfoTable { trigger 9 }	Table of information about each trigger that has been configured, indexed by triggerNumber.
triggerConfigInfoEntry { triggerConfigInfoTable 1 }	Information about the configuration of a single trigger.
triggerNumber { triggerConfigInfoEntry 1 }	ID number of the trigger. Values are in range 1- 250.
triggerName { triggerConfigInfoEntry 2 }	Name and description of the trigger.
triggerTypeDetail { triggerConfigInfoEntry 3 }	Trigger type and its activation conditions.
triggerActiveDaysOrDate { triggerConfigInfoEntry 4 }	The days of a week or the date on which the trigger can be activated.
triggerActivateAfter { triggerConfigInfoEntry 5 }	Time after which the trigger can be activated.
triggerActivateBefore { triggerConfigInfoEntry 6 }	Time before which the trigger can be activated.
triggerActiveStatus { triggerConfigInfoEntry 7 }	Whether or not the trigger can be activated.
triggerTestMode { triggerConfigInfoEntry 8 }	Whether or not the trigger is operating in diagnostic (test) mode.
triggerSnmpTrap { triggerConfigInfoEntry 9 }	Whether or a not an SNMP trap will be generated when the trigger is activated.
triggerRepeatTimes { triggerConfigInfoEntry 10 }	Whether the trigger can repeat an unlimited number of times (continuous) or a specified number of times. If the trigger can repeat only a specified number of times, then the number of times the trigger has already been activated is displayed in brackets.
triggerLasttimeModified { triggerConfigInfoEntry 11 }	Date and time that the trigger configuration was last modified.
triggerNumberOfActivation { triggerConfigInfoEntry 12 }	Number of times the trigger has been activated since the last restart of the device.
triggerLasttimeActivation { triggerConfigInfoEntry 13 }	Date and time that the trigger was last activated.
triggerNumberOfScripts { triggerConfigInfoEntry 14 }	Number of scripts that this trigger will execute. Values are in range 0-5.

Table 76-15: Objects defined in AT-TRIGGER-MIB(Continued)

Object Identifier	Description
triggerScript1 { triggerConfigInfoEntry 15 }	Name of the first script that this trigger will execute if the trigger is activated.
triggerScript2 { triggerConfigInfoEntry 16 }	Name of the second script that this trigger will execute if the trigger is activated.
triggerScript3 { triggerConfigInfoEntry 17 }	Name of the third script that this trigger will execute if the trigger is activated.
triggerScript4 { triggerConfigInfoEntry 18 }	Name of the fourth script that this trigger will execute if the trigger is activated.
triggerScript5 { triggerConfigInfoEntry 19 }	Name of the fifth script that this trigger will execute if the trigger is activated.
triggerCounters { trigger 10 }	Collection of counters for trigger activations.
triggerNumOfActivation { triggerCounters 1 }	Number of times a trigger has been activated.
triggerNumOfActivationToday { triggerCounters 2 }	Number of times a trigger has been activated today.
triggerNumOfPeriodicActivationToday { triggerCounters 3 }	Number of times a periodic trigger has been activated today.
triggerNumOfInterfaceActivationToday { triggerCounters 4 }	Number of times an interface trigger has been activated today.
triggerNumOfResourceActivationToday { triggerCounters 5 }	Number of times a CPU or memory trigger has been activated today.
triggerNumOfRebootActivationToday { triggerCounters 6 }	Number of times a reboot trigger has been activated today.
triggerNumOfPingPollActivationToday { triggerCounters 7 }	Number of times a ping-poll trigger has been activated today.
triggerNumOfStackMasterFailActivationToday { triggerCounters 8 }	Number of times a stack master fail trigger has been activated today.
triggerNumOfStackMemberActivationToday { triggerCounters 9 }	Number of times a stack member trigger has been activated today.
triggerNumOfStackXemStkActivationToday { triggerCounters 10 }	Number of times a stack XEM trigger has been activated today.

AT-LOOPPROTECT-MIB

The atLoopProtect-MIB (Figure 76-3, Table 76-16) defines objects for managing Loop Protection objects and triggers. Objects in this group have the object identifier atLoopProtect ({ modules 4 }).

Figure 76-3: The ATLoopProtect MIB Sub-tree




Table 76-16: Objects Defined in the AT-Loop Protect MIB

Object	Object Identifier	Description
{ atLoopProtect }	{ modules 54 }	The root of the Loop Protect object sub tree.
{ atLoopProtectTrap }	{ atLoopProtect0 }	The Loop Protection node state transition trap. List of traps (notifications) generated for Loop Protection.
{ atLoopProtectDetected LoopBlockedTrap }	{ atLoopProtectTrap1 }	Notification generated when the Loop Protection feature blocks an interface with a loop. The following bindings are associated with this trap: ■ atLoopProtectIfIndex ■ atLoopProtectVlanId ■ atLoopProtectAction
{ atLoopProtectRecover LoopBlockedTrap }	{ atLoopProtectTrap2 }	Notification generated when the Loop Protection feature restores a blocked interface back to normal operation. The following bindings are associated with this trap: ■ atLoopProtectIfIndex ■ atLoopProtectVlanId ■ atLoopProtectAction
{ atLoopProtectDetected ByLoopDetectionTrap }	{ atLoopProtectTrap3 }	Notification generated when the Loop Protection feature detects a loop by Loop Detection method. The following bindings are associated with this trap: ■ atLoopProtectIfIndex ■ atLoopProtectVlanId ■ atLoopProtectRxLDFIfIndex ■ atLoopProtectRxLDFVlanId
{ atLoopProtectAction }	{ atLoopProtect1 }	The Action for the Loop Protection feature. The following values are defined: ■ atLoopProtectAction-LearnDisable (0) ■ atLoopProtectAction-LearnEnable (1) ■ atLoopProtectAction-PortDisable (2) ■ atLoopProtectAction-PortEnable (3) ■ atLoopProtectAction-LinkDown (4) ■ atLoopProtectAction-LinkUp (5) ■ atLoopProtectAction-VlanDisable (6) ■ atLoopProtectAction-VlanEnable (7)
{ atLoopProtectIfIndex }	{ atLoopProtect2 }	The interface on which the loop was detected.
{ atLoopProtectVlanId }	{ atLoopProtect3 }	The VLAN ID on which the loop was detected.
{ atLoopProtectRxLDFIfIndex }	{ atLoopProtect4 }	The interface on which the loop detection frame was received.
{ atLoopProtectRxLDFVlanId }	{ atLoopProtect5 }	The VLAN ID on which the loop detection frame was received.

AT-SETUP-MIB

AT-SETUP-MIB defines objects for managing software installation and configuration files (Figure 76-4, Table 76-17). Objects in this group have the object identifier setup ({ modules 500 }). The procedure in Table 74-2 on page 74.19 shows how to use these MIB objects to upgrade to a new software version and boot configuration file. For objects used for file copying, see “AT-FILEv2-MIB” on page 76.45.

Figure 76-4: The AT-SETUP-MIB sub-tree




Table 76-17: Objects defined in AT-SETUP-MIB

Object	Object Identifier	Description
restartDevice	{ setup 1 }	Object for restarting the device. When set to '1', the device will restart immediately.
firmware	{ setup 2 }	Objects for managing the software version files that the device will install and run.
currentFirmware	{ firmware 1 }	Information about the current software version installed on the device.
currSoftVersion	{ currentFirmware 1 }	Current Software version.
currSoftName	{ currentFirmware 2 }	Current Software name.
currSoftAs	{ currentFirmware 3 }	The file name to save the currently running software to the root of the flash. Only one save operation can be executed at a time across all SNMP users.
nextBootFirmware	{ firmware 2 }	Information about the software version to be installed on the device when booting.
nextBootVersion	{ nextBootFirmware 1 }	Provides information on the software version (major.minor.interim, for example version 5.3.1) that the device will boot from. A zero will be returned if the version cannot be determined.
nextBootPath	{ nextBootFirmware 2 }	The full path to the release file. In order to set this object, the file must meet the following conditions: ■ it must exist ■ it must be located in the root of the flash ■ it must not be the same as the backup release file ■ it must have a .rel suffix ■ it must pass several internal checks to ensure that it is a genuine release file.
backupFirmware	{ firmware 3 }	Information about the backup software version and path.
backupVersion	{ backupFirmware 1 }	Provides information on the backup software version (major.minor.interim, for example version 5.3.1) that the device will boot from. A zero will be returned if the version cannot be determined.
backupPath	{ backupFirmware 2 }	The full path to the backup release file. In order to set this object, the file must meet the following conditions: ■ it must exist ■ it must be located in the root of the flash ■ it must not be the same as the configured main release file ■ it must have a .rel suffix ■ it must pass several internal checks to ensure that it is a genuine release file.
deviceConfiguration	{ setup 3 }	Objects for managing device configuration.
runningConfig	{ deviceConfiguration 1 }	
runCnfgSaveAs	{ runningConfig 1 }	Sets the name of the running config file, to be saved in the root of the flash memory. For example, myconfig.cfg.
nextBootConfig	{ deviceConfiguration 2 }	

Table 76-17: Objects defined in AT-SETUP-MIB(Continued)

Object	Object Identifier	Description
bootCnfgPath	{ nextBootConfig 1 }	The full path to the configuration file that will be used the next time the device is rebooted. This object can be set with an empty string in order to clear the current boot configuration; otherwise, the path should be in the form: flash:/myconfig.cfg. In order to set this object, the file must meet the following conditions: ■ it must exist ■ it must be located in the root of the flash ■ it must have a .cfg suffix
bootCnfgExists	{ nextBootConfig 2 }	This object will return the value TRUE if the currently defined boot configuration file exists, or FALSE if it does not.
defaultConfig	{ deviceConfiguration 3 }	
dfltCnfgPath	{ defaultConfig 1 }	The full path of the configuration file to use as backup when the device is rebooted. This object is not settable; the default configuration file is always flash:/default.cfg
dfltCnfgExists	{ defaultConfig 2 }	This object will return the value TRUE if the currently defined default configuration file exists, or FALSE if it does not.
serviceConfig	{ setup 5 }	
srvcTelnetEnable	{ serviceConfig 1 }	This object is used to either read or set the state of the telnet server on a device. Telnet can be enabled by setting the value of this object to enable(1) or can be disabled by setting the value disable(2).
srvcSshEnable	{ serviceConfig 2 }	This object is used to either read or set the state of the SSH server on a device. SSH can be enabled by setting the value of this object to enable(1) or can be disabled by setting the value disable(2).
guiConfig	{ setup 6 }	
guiAppletConfig	{ guiConfig 1 }	
guiAppletSysSwVer	{ guiAppletConfig 1 }	This object represents the system software release that the currently selected GUI applet was designed to run on. The system automatically searches for GUI applet files that reside in the root directory of the flash memory, and selects the latest available file that is applicable to the currently running system software. This is the applet that will be uploaded to a user's web browser when they initiate the GUI.
guiAppletSwVer	{ guiAppletConfig 2 }	This object represents the software version of the currently selected GUI applet. The system automatically searches for GUI applet files residing in the root directory of the flash memory, and selects the latest available one that is applicable to the currently running system software. This is the applet that will be uploaded to a user's web browser when they initiate the GUI.

AT-DNS-CLIENT-MIB

AT-DNS-CLIENT-MIB contains definitions of managed objects for the Allied Telesis DNS Client Configuration.

Objects in this group have the object identifier atDns ({ Modules 501 }). [Table 76-18](#) lists the objects supported by the AlliedWare Plus operating system.

Table 76-18: Objects defined in AT-DNS-CLIENT-MIB

Object	Object Identifier	Description
atDnsClient	{ atDns 1 }	MIB File for DNS Client Configuration.
atDNSServerIndexNext	{ atDnsClient 1 }	The next available value for the object 'atDNSServerIndex'. The value is used by a management application to create an entry in the 'atDNSServerTable'.
atDNSServerTable	{ atDnsClient 2 }	Table of information about the Domain Name System (DNS) Server configurations in the system, indexed by 'atDNSServerIndex'.
atDNSServerEntry	{ atDNSServerTable 1 }	Information about a single DNS Server Configuration.
atDNSServerIndex	{ atDNSServerEntry 1 }	The index corresponding to the particular DNS Server Configuration. When creating a new entry in the table, the value of this object must be equal to the value in the 'atDNSServerIndexNext'.
atDNSServerAddrType	{ atDNSServerEntry 2 }	The Internet Address Type of the 'atDNSServerAddr' object. Can be one of the following: ■ unknown (0) ■ ipv4 (1) - default value ■ ipv6 (2) - not supported ■ ipv4z (3) - not supported ■ ipv6z (4) - not supported ■ dns (16) - not supported
atDNSServerAddr	{ atDNSServerEntry 3 }	The IP Address of the DNS Server. When a new entry is created, this object is set to the default value of '0.0.0.0' { '00000000'h }. The management application will change this to the desired value using a SET operation.
atDNSServerStatus	{ atDNSServerEntry 4 }	The status of the current entry (row). Can be one of the following: ■ active (1) ■ createAndGo (4) ■ destroy (6) To create a new entry the management application must set this object with value 'createAndGo (4)'. To delete an entry, the management application must set this object with value 'destroy (6)'. Once an entry is deleted, all subsequent entries in the table will be renumbered. The default value is 1 (active)

AT-NTP-MIB

This MIB contains objects for managing the Allied Telesis Network Time Protocol (NTP) configuration (Table 76-19). The objects reside in the module atNtp { modules 502 }, organized in the following groups:

- NTP Peer/Server Table - a table containing information on the Network Time Protocol (NTP) peers or server configurations in the system.
- Associations Table - a list of installed software; used also to remove software from the device.
- Status Table - Objects in this group are not supported.

Table 76-19: Objects defined in AT-NTP-MIB

Object	Object Identifier	Description
atNtp	{ modules 502 }	MIB containing objects for configuring NTP.
atNtpPeerIndexNext	{ atNtp 6 }	The next available index number to be used for object 'atNtpPeerIndex'.
atNtpPeerTable	{ atNtp 7 }	Table containing information on the Network Time Protocol (NTP) peers or server configurations in the system. Indexed by: ■ atNtpPeerIndex
atNtpPeerEntry	{ atNtpPeerTable 1 }	Information about a single NTP server or peer configuration.
atNtpPeerIndex	{ atNtpPeerEntry 1 }	The index number corresponding to a particular NTP server or peer configuration in the system. To create a new entry, the value of this object should be the same as that of the value of atNtpPeerIndexNext object, otherwise the entry creation will fail.
atNtpPeerNameAddr	{ atNtpPeerEntry 2 }	The host name, or the IP address of the NTP peer. When a new row (entry) is created, this object is set with a default value of '0.0.0.0', and the management application should change it to a desired value by using a SET operation.
atNtpPeerMode	{ atNtpPeerEntry 3 }	The mode of the peer. Can be one of the following: ■ server (1) ■ peer (2) - default value
atNtpPeerPreference	{ atNtpPeerEntry 4 }	The values in this object specifies whether this peer is the preferred one. Valid values are 0 to 2: ■ 0 - unknown - default value ■ 1 - not preferred ■ 2 - preferred When the value is 'not preferred' (1) NTP chooses the peer with which to synchronize the time on the local system. If the object is set to 'preferred' (2) NTP will choose the corresponding peer to synchronize the time with.

Table 76-19: Objects defined in AT-NTP-MIB(Continued)

Object	Object Identifier	Description
atNtpPeerVersion	{ atNtpPeerEntry 5 }	The NTP version the peer supports. Can be one of the following: ■ 0 - unknown - Default value ■ 1 - version 1 ■ 2 - version 2 ■ 3 - version 3 ■ 4 - version 4
atNtpPeerKeyNumber	{ atNtpPeerEntry 6 }	The authentication key number. Default number is 0.
atNtpPeerRow Status	{ atNtpPeerEntry 7 }	The current status of this peer entry. The following values may be returned when reading this object: ■ active (1) - this value is returned on reading of this entry. ■ createAndGo (4) - this value is set by the management application when creating a new entry ■ destroy (6) - value set by the management application when deleting the entry. When an entry is deleted, all subsequent entries in the table will be re-indexed.
atNtpAssociationTable	{ atNtp 10 }	Table containing information on the Network Time Protocol (NTP) associations. Indexed by: ■ atNtpAssociationIndex
atNtpAssociationEntry	{ atNtpAssociationTable 1 }	Information about a single NTP server or peer configuration.
atNtpAssociationIndex	{ atNtpAssociationEntry 1 }	The index number corresponding to a particular NTP server or peer configuration in the system. To create a new entry, the value of this object should be the same as that of the value of atNtpPeerIndexNext object, otherwise the entry creation will fail.
atNtpAssociationPeerAddr	{ atNtpAssociationEntry 2 }	The host name, or the IP address of the NTP peer. When a new row (entry) is created, this object is set with a default value of '0.0.0.0', and the management application should change it to a desired value by using a SET operation.
atNtpAssociationStatus	{ atNtpAssociationEntry 3 }	The status of this association. Can be one of the following: ■ master (syncd) ■ master (unsyncd) ■ selected ■ candidate ■ configured ■ unknown
atNtpAssociationConfigured	{ atNtpAssociationEntry 4 }	The value in this object specifies whether the association is from configuration or not. Value can be: ■ configured ■ dynamic
atNtpAssociationRefClkAddr	{ atNtpAssociationEntry 5 }	The IP Address for the reference clock.
atNtpAssociationStratum	{ atNtpAssociationEntry 6 }	The stratum of the peer clock.

Table 76-19: Objects defined in AT-NTP-MIB(Continued)

Object	Object Identifier	Description
atNtpAssociationPoll	{ atNtpAssociationEntry 7 }	The time between NTP requests from the device to the server, in seconds.
atNtpAssociationReach	{ atNtpAssociationEntry 8 }	An integer that indicates the reachability status of the peer.
atNtpAssociationDelay	{ atNtpAssociationEntry 9 }	The round trip delay between the device and the server.
atNtpAssociationOffset	{ atNtpAssociationEntry 10 }	The difference between the device clock and the server clock.
atNtpAssociationDisp	{ atNtpAssociationEntry 11 }	The lowest measure of error associated with peer offset, based on delay, in seconds.
atNtpStatus	{ atNtp 11 }	Group of objects containing system status information. The objects in this group are not supported.
atNtpSysClockSync	{ atNtpStatus 1 }	Not supported.
atNtpSysStratum	{ atNtpStatus 2 }	Not supported.
atNtpSysReference	{ atNtpStatus 3 }	Not supported.
atNtpSysFrequency	{ atNtpStatus 4 }	Not supported.
atNtpSysPrecision	{ atNtpStatus 5 }	Not supported.
atNtpSysRefTime	{ atNtpStatus 6 }	Not supported.
atNtpSysClkOffset	{ atNtpStatus 7 }	Not supported.
atNtpSysRootDelay	{ atNtpStatus 8 }	Not supported.
atNtpSysRootDisp	{ atNtpStatus 9 }	Not supported.

AT-EPSRV2-MIB

The Epsrv2 Group-MIB defines objects for managing Epsrv2 objects and triggers (Figure 76-5, Table 76-20). Objects in this group have the object identifier Epsrv2 ({ modules 536 }).

Figure 76-5: The AT-Epsrv2 MIB sub-tree




Table 76-20: atEpsrv2Objects Defined in the AT-Epsrv2 MIB

Object	Object Identifier	Description
{ at-Epsrv2 }	{ modules 536 }	The root of the Epsrv2 object sub tree.
{ atEpsrv2Events }	{ at-Epsrv2 1 }	
{ atEpsrv2NodeTraps }	{ atEpsrv2Events 1 }	EPSR Master/Transit node state transition trap. Note that there is a one to one relationship between nodes and domains.
{ Epsrv2NodeType }	{ atEpsrv2VariablesEntry 1 }	The EPSR node type: either master or transit.
{ atEpsrv2DomainName }	{ atEpsrv2VariablesEntry 2 }	The name of the EPSR domain.
{ atEpsrv2DomainID }	{ atEpsrv2VariablesEntry 3 }	The ID of the EPSR domain.
{ Epsrv2FromState }	{ atEpsrv2VariablesEntry 4 }	The previous state of the EPSR domain
{ Epsrv2Current State }	{ atEpsrv2VariablesEntry 5 }	The current state of the EPSR domain.
{ Epsrv2ControlVlanId }	{ atEpsrv2VariablesEntry 6 }	The VLAN identifier for the control VLAN.
{ Epsrv2PrimaryIfIndex }	{ atEpsrv2VariablesEntry 7 }	The IfIndex of the primary interface.
{ atEpsrv2PrimaryIfState }	{ atEpsrv2VariablesEntry 8 }	The current state of the primary interface.
{ atEpsrv2SecondaryIfIndex }	{ atEpsrv2VariablesEntry 9 }	The IfIndex of the secondary interface.
{ atEpsrv2SecondaryIfState }	{ atEpsrv2VariablesEntry 10 }	The state of the secondary interface.
{ atEpsrv2VariablesTable }	{ at-Epsrv2 2 }	The enterprise Epsrv2VariablesTable.
{ atEpsrv2VariablesEntry }	{ atEpsrv2VariablesTable 1 }	Contains entries within the enterprise atEpsrv2VariablesTable.
{ atEpsrv2NodeType }	{ atEpsrv2VariablesEntry 1 }	The EPSR domain node type: either ■ master (1) ■ transit (2)
{ atEpsrv2DomainName }	{ Epsrv2NodeType 2 }	The name of the EPSR domain.
{ atEpsrv2DomainID }	{ Epsrv2NodeType 3 }	The ID of the EPSR domain.
{ atEpsrv2FromState }	{ Epsrv2NodeType 4 }	The previous state of the EPSR domain
{ atEpsrv2Current State }	{ Epsrv2NodeType 5 }	The current state of the EPSR domain.
{ atEpsrv2ControlVlanId }	{ Epsrv2NodeType 6 }	The VLAN identifier for the control VLAN.
{ Epsrv2PrimaryIfIndex }	{ Epsrv2NodeType 7 }	The IfIndex of the primary interface.
{ atEpsrv2PrimaryIfState }	{ Epsrv2NodeType 8 }	The current state of the primary interface.
{ atEpsrv2SecondaryIfIndex }	{ Epsrv2NodeType 9 }	The IfIndex of the secondary interface.
{ atEpsrv2SecondaryIfState }	{ Epsrv2NodeType 10 }	The state of the secondary interface.
TEXTUAL CONVENTIONS		
{ atEpsrv2NodeState }		The trap states that can be advertised for an EPSR domain node. The following states are defined: ■ idle (1) ■ complete (2) ■ failed (3) ■ linksUp (4) ■ linksDown (5) ■ preForward (6) ■ unknown (7)

Table 76-20: atEpsrv2Objects Defined in the AT-Epsrv2 MIB(Continued)

Object	Object Identifier	Description
{ atEpsrv2InterfaceState }		The trap states that can advertised for an EPSR interface. The following states are defined: ■ unknown (1) ■ down (2) ■ blocked (3) ■ forward (4)

AT-FILEv2-MIB

This MIB contains objects for displaying and managing file content of flash, NVS and SD-cards on local and stacked devices, and copying, moving and deleting files from local, stacked and remote sources (Table 76-21).

The objects reside in the module atFilev2 { modules 600 }, organized in the following groups:

- The Options Table - a collection of codes used to configure file management options
- The File Table - a list of files present on the device and stack-member, specified by the atFilev2Device and atFilev2StackId objects
- The file operation devices - object for various devices supported for file operations
- The SD Card Table - information about the SD Cards configured on the device

The procedure in “Copy a File to or from a TFTP Server” on page 74.18 shows how to use these MIB objects to upgrade to a new software version and boot configuration file.

Table 76-21: Objects defined in AT-FILEv2-MIB

Object	Object Identifier	Description
atFilev2	{ modules 600 }	MIB containing objects for listing and managing files
atFilev2TableOptions	{ atFilev2 1 }	Collection of objects available for configuration, to enable various options for file listing
atFilev2Recursive	{ atFilev2TableOptions 1 }	Specifies recursive listing for directories contained in the object atFilev2Table. Valid values are 0 and 1. Set a value of '1' to enable recursive listing of directories in the atFilev2Table listing. The default value is '0'.
atFilev2AllFiles	{ atFilev2TableOptions 2 }	Specifies recursive listing for all files contained in the object atFilev2Table. Valid values are 0 and 1. Set a value of '1' to enable listing of all files (including hidden) in the atFilev2Table listing. The default value is '0'.
atFilev2Device	{ atFilev2TableOptions 3 }	Specifies the type of device where the files to be listed reside. Valid range values are from 1 to 3. Set a value that corresponds with the various devices, as below: ■ 1 - Flash - default value ■ 2 - Card ■ 3 - NVS Subsequent SNMP queries to the atFilev2Table will use this as the device to generate a file listing from.
atFilev2StackId	{ atFilev2TableOptions 4 }	An integer to correspond to the stack ID of a stack member. Subsequent SNMP queries to the atFilev2Table will use this as the stack member to generate a file listing from. If running a standalone unit, use the default value of '1'.
atFilev2Table	{ atFilev2 2 }	The file table, containing a list of files present on the device and stack member specified by the atFilev2Device and atFilev2StackId objects. Indexed by: ■ atFilev2FileName
atFilev2Entry	{ atFilev2Table 1 }	An entry in the list of file containing information about a single file.

Table 76-21: Objects defined in AT-FILEv2-MIB(Continued)

Object(Continued)	Object Identifier	Description
atFilev2FileName	{ atFilev2Entry 1 }	The name of the file, in the format octet string. Files are sorted in alphabetical order. Directory names end with '/', and have a 'd' present in the atFilev2FileAttrib object. The file name is truncated at 112 characters, due to SNMP OID length limitations. If two files are not uniquely distinguishable within the first 112 characters, the listing will halt after the first file.
atFilev2FileSize	{ atFilev2Entry 2 }	The size of the file in bytes.
atFilev2FileCreationTime	{ atFilev2Entry 3 }	File creation time in the form MMM DD YYYY HH:MM:SS. Example: 'Sep 7 2008 06:07:54'
atFilev2FileAttrib	{ atFilev2Entry 4 }	The standard file accessibility attributes in the form <drwx>, where each letter represents the following: ■ d - directory ■ r - readable ■ w - writable ■ x - executable If a file does not have a particular attribute set, the respective position will contain a '-'. For example, <-r-x> indicates a readable and executable file that is not a directory or writable.
atFilev2Operation	{ atFilev2 3 }	Collection of file operation objects available for configuration, to enable copying, moving and deleting files.
atFilev2SourceStackId	{ atFilev2Operation 1 }	Specifies the Stack ID of the source file. Set an integer corresponding to the stack ID of the stack member to use as the source. This value is ignored if the source device is set to TFTP. If running a standalone unit, use the default value of 1.
atFilev2SourceDevice	{ atFilev2Operation 2 }	Specifies the source device for the file to be copied. Valid values are 0 to 4. Set a value that corresponds with the various devices, as below: ■ 0 - Unconfigured (not settable) ■ 1 - Flash - default value ■ 2 - Card ■ 3 - NVS ■ 4 - TFTP For copying, you may use any combination of devices for the source and destination, except for copying from TFTP to TFTP. For moving files you cannot use TFTP as source or destination. For deleting, the source cannot be TFTP. To copy a file from TFTP to flash, use 4 for source and 1 for destination. You must fully configure all required parameters for each device. Only TFTP has an IP address required. Default value is: '1'b.

Table 76-21: Objects defined in AT-FILEv2-MIB(Continued)

Object(Continued)	Object Identifier	Description
atFilev2SourceFileName	{ atFilev2Operation 3 }	Specifies the filename of the source file to copy, move or delete. Include any path as required, but the storage type is not necessary. Setting a null string will return an error. For example, to copy the file latest.cfg from the backupconfigs/routers directory on the TFTP server, you would set: backupconfigs/routers/latest.cfg
atFilev2DestinationStackId	{ atFilev2Operation 4 }	Specifies the Stack ID for the destination file. Set an integer corresponding to the stack ID of the stack member to use as the destination. This value is ignored if the destination device is set to TFTP, or if a deletion operation is carried out. If running a standalone unit, use the default value of 1.
atFilev2DestinationDevice	{ atFilev2Operation 5 }	Specifies the destination device for the files to be copied into. Valid values are 0 to 4. Set a value that corresponds with the various devices, as below: ■ 0 - Unconfigured (not settable) ■ 1 - Flash - default value ■ 2 - Card ■ 3 - NVS ■ 4 - TFTP For copying, you may use any combination of devices for the source and destination, except for copying from TFTP to TFTP. For moving files you cannot use TFTP as source or destination. For deleting, the source cannot be TFTP. To copy a file from TFTP to flash, use 4 for source and 1 for destination. You must fully configure all required parameters for each device. Only TFTP has an IP address required. Default value is: '1'b.
atFilev2DestinationFileName	{ atFilev2Operation 6 }	Specifies the destination filename of the file to be copied or moved. Include any path as required, but the storage type is not necessary. For any operation other than a file deletion, setting a null string will return an error. For deletions, any value set to this object is ignored. Note: If the destination is set to flash, card or NVS, any file at the destination that shares the destination filename will be overwritten by a move or copy operation. The destination filename does not need to be the same as the source filename. For example, to copy a release file from the TFTP server to the local flash into the backup release directory, you would set: backuprelease/latest.rel

Table 76-21: Objects defined in AT-FILEv2-MIB(Continued)

Object(Continued)	Object Identifier	Description
atFilev2CopyBegin	{ atFilev2Operation 7 }	Represents the status of the copy file operation, in the form of octet string. A read on this object can return several possible values, depending on the current status of the system and the various file operation objects: ■ idle - There is no file operation in progress and all required objects have been set correctly. Setting a '1' to this object will begin the file copy. ■ Error codes: [1-7] - A copy operation cannot be started until these errors are resolved. See below for key. ■ [action]ing x [--> y] - A file operation is currently in progress. You cannot start another operation while the object is returning this value. ■ [action] x [--> y] success - The last copy, move or delete operation was successfully completed. ■ [action] x [--> y] failure: [err] - The last copy, move or delete operation failed, with the error message attached. Common failures include lack of space on the destination file system, incorrect source file names or communication errors with remote services. Upon reading a success or failure message, the message will be cleared and the next read will result in either an 'idle' message or an 'Error codes' message if not all required objects have been correctly set. If the read returned 'idle', a new file operation can now be started. Following are possible values returned as Error codes for file copy: ■ 1 - atFilev2SourceDevice has not been set ■ 2 - atFilev2SourceFilename has not been set ■ 3 - atFilev2DestinationDevice has not been set ■ 4 - atFilev2DestinationFilename has not been set ■ 5 - atFilev2SourceDevice and atFilev2DestinationDevice are both set to TFTP ■ 6 - the combination of source device, stackID and filename is the same as the destination device, stackID and filename (i.e. it is not valid to copy a file onto itself). ■ 7 - TFTP IP address has not been set and TFTP has been set for one of the devices Provided all above requirements are met, immediately upon executing the SNMP set, the device will indicate that it was a success. The actual file copy itself will be started and continue on the device until it has completed. For large files, operations can take several minutes to complete. Subsequent reads of the object will return one of messages shown in the first table, to allow for tracking of the progress of the copy operation.

Table 76-21: Objects defined in AT-FILEv2-MIB(Continued)

Object(Continued)	Object Identifier	Description
atFilev2MoveBegin	{ atFilev2Operation 8 }	Represents the status of the move file operation, in the form of octet string. A read on this object can return several possible values, depending on the current status of the system and the various file operation objects: ■ idle - There is no file operation in progress and all required objects have been set correctly. Setting a '1' to this object will begin the file move. ■ Error codes: [1-6] - A move operation cannot be started until these errors are resolved. See below for key. ■ [action]ing x [--> y] - A file operation is currently in progress. You cannot start another operation while the object is returning this value. ■ [action] x [--> y] success - The last copy, move or delete operation was successfully completed. ■ [action] x [--> y] failure: [err] - The last copy, move or delete operation failed, with the error message attached. Common failures include lack of space on the destination file system, incorrect source file names or communication errors with remote services. Upon reading a success or failure message, the message will be cleared and the next read will result in either an 'idle' message or an 'Error codes' message if not all required objects have been correctly set. If the read returned 'idle', a new file operation can now be started. Following are possible values returned as Error codes for file move: ■ 1 - atFilev2SourceDevice has not been set ■ 2 - atFilev2SourceFilename has not been set ■ 3 - atFilev2DestinationDevice has not been set ■ 4 - atFilev2DestinationFilename has not been set ■ 5 - either atFilev2SourceDevice or atFilev2DestinationDevice are set to TFTP ■ 6 - the combination of source device, stackID and filename is the same as the destination device, stackID and filename (i.e. it is not valid to move a file onto itself). Provided all above requirements are met, immediately upon executing the SNMP set, the device will indicate that it was a success. The actual file move itself will be started and continue on the device until it has completed. For large files, operations can take several minutes to complete. Subsequent reads of the object will return one of messages shown in the first table, to allow for tracking of the progress of the move operation.

Table 76-21: Objects defined in AT-FILEv2-MIB(Continued)

Object(Continued)	Object Identifier	Description
atFilev2DeleteBegin	{ atFilev2Operation 9 }	Represents the status of the delete file operation, in the form of octet string. A read on this object can return several possible values, depending on the current status of the system and the various file operation objects: ■ idle - There is no file operation in progress and all required objects have been set correctly. Setting a '1' to this object will begin the file deletion. ■ Error codes: [1-3] - A delete operation cannot be started until these errors are resolved. See below for key. ■ [action]ing x [--> y] - A file operation is currently in progress. You cannot start another operation while the object is returning this value. ■ [action] x [--> y] success - The last copy, move or delete operation was successfully completed. ■ [action] x [--> y] failure: [err] - The last copy, move or delete operation failed, with the error message attached. Common failures include lack of space on the destination file system, incorrect source file names or communication errors with remote services. Upon reading a success or failure message, the message will be cleared and the next read will result in either an 'idle' message or an 'Error codes' message if not all required objects have been correctly set. If the read returned 'idle', a new file operation can be started. File deletion operations ignore the values set in the atFilev2DestinationStackID, atFilev2DestinationDevice and atFilev2DestinationFilename objects. The file deletion operation is equivalent to the CLI 'delete force [file]' command, so it is possible to delete any normally-protected system files, such as the currently configured boot release. Following are possible values returned as Error codes for file move: ■ 1 - atFilev2SourceDevice has not been set ■ 2 - atFilev2SourceFilename has not been set ■ 3 - atFilev2SourceDevicehas not been set to TFTP Provided all above requirements are met, immediately upon executing the SNMP set, the device will indicate that it was a success. The actual file move itself will be started and continue on the device until it has completed. For large files, operations can take several minutes to complete. Subsequent reads of the object will return one of messages shown in the first table, to allow for tracking of the progress of the move operation.
atFilev2Flash_1	{ atFilev2Operation 10 }	Represents the Flash operation device object
atFilev2Card_2	{ atFilev2Operation 11 }	Represents the Card operation device object
atFilev2Nvs_3	{ atFilev2Operation 12 }	Represents the NVS operation device object
atFilev2Tftp_4	{ atFilev2Operation 13 }	Represents the TFTP operation device object

Table 76-21: Objects defined in AT-FILEv2-MIB(Continued)

Object(Continued)	Object Identifier	Description
atFilev2TftpIPAddr	{ atFilev2Tftp_4 1 }	The IP address of the TFTP server that is to be used for the file copy process. This IP Address needs to be reachable from the device, or the file copy will fail.
atFilev2SDcardTable	{ atFilev2 4 }	The SD Card table, containing information related to SD Cards. Indexed by: ■ atFilev2SDcardStackMemberId
atFilev2SDcardEntry	{ atFilev2SDcardTable 1 }	Data pertaining to an SD Card instance.
atFilev2SDcardStackMemberId	{ atFilev2SDcardEntry 1 }	The index of the stack member hosting this SD Card.
atFilev2SDcardPresence	{ atFilev2SDcardEntry 2 }	This object indicates whether or not an SD Card is inserted into a slot. Possible values are: ■ notPresent (1) ■ present (2)

AT-LOG-MIB

The AT Log MIB contains objects for listing log entries from the buffered and permanent logs (Table 76-22). The objects reside in the module log { modules 601 }, organized in the following groups:

- Log Table - objects containing the information from log messages issued by the system, ordered from oldest to newest entry
- Log Options - contains objects used to set up the log options configuration

Table 76-22: Objects defined in AT-LOG-MIB

Object	Object Identifier	Description
log	{ modules 601 }	MIB containing objects for listing log entries from the buffered and permanent logs.
logTable	{ log 1 }	A list of log entries from the source specified in the 'logSource' object. The list is ordered from oldest entry to newest entry. Indexed by: ■ logIndex
logEntry	{ logTable 1 }	Information about a single log entry, from the source specified in the 'logSource' object.
logIndex	{ logEntry 1 }	An index integer. This index is not directly tied to any specific log entry. Over time, the log will grow larger and eventually older entries will be removed from the log.
logDate	{ logEntry 2 }	The date of the log entry. Data resides in the format octet string, in the form YYYY MMM DD, e.g. 2008 Oct 9.
logTime	{ logEntry 3 }	The time of the log entry. Data resides in the format octet string, in the form HH:MM:SS, e.g. 07:15:04.
logFacility	{ logEntry 4 }	The syslog facility that generated the log entry, in the format octet string. See the reference manual for more information.
logSeverity	{ logEntry 5 }	The severity level of the log entry, in the format octet string. Severities are given below: ■ emerg Emergency, system is unusable ■ alert Action must be taken immediately ■ crit Critical conditions ■ errr Error conditions ■ warning Warning conditions ■ notice Normal, but significant, conditions ■ info Informational messages ■ debug Debug-level messages
logProgram	{ logEntry 6 }	The program that generated the log entry, in the format octet string. See the reference manual for more information.
logMessage	{ logEntry 7 }	The message of the log entry, in the format octet string.
logOptions	{ log 2 }	Contains objects used to set up the required log options configuration.

Table 76-22: Objects defined in AT-LOG-MIB(Continued)

Object	Object Identifier	Description
logSource	{ logOptions 1 }	An integer indicating the source from which the log entries are retrieved. The valid values are: ■ 1 - Buffered log (default) ■ 2 - Permanent log. This information is used when retrieving the logTable objects, and also specifies the log to be cleared when the 'clearLog' object is set.
logAll	{ logOptions 2 }	An integer indicating whether to display all log entries in the logTable objects, or not. The valid values are: ■ 0 - to display only the most recent log messages. This is the default ■ 1 - to show all available log entries. Note: Choosing to display all log entries may result in delays of several seconds when accessing the logTable objects.
clearLog	{ logOptions 3 }	An integer indicating whether to clear the log that is specified by the 'logSource' object. Valid values are: ■ 0 - do not clear log ■ 1 - clear log

AT-IP-MIB

This MIB contains objects for Allied Telesis specific IP address management (Table 76-23). The objects reside in the module atIpMib { modules 602 }.

Table 76-23: Objects defined in AT-IP-MIB

Object	Object Identifier	Description
atIpMib	{ modules 602 }	MIB containing objects for IP addressing management.
AtIpAddressAssignmentType	Textual Convention	Object containing conditional coded values for the IP address assignment type being applied to the interface, referred to by objects in this MIB. The possible values and explanation are: ■ notSet (0) - indicates that the IP address assignment type has not yet been configured. This value can only ever be read. ■ primary (1) - indicates that the address is a primary IP address; only one primary address is allowed per interface. ■ secondary (2) - indicates that the address is a secondary IP address; any number of secondary IP addresses may be applied
AtIpAddressTable	{ atIpMib 1 }	A table containing mappings between primary or secondary IP addresses, and the interfaces they are assigned to. Indexed by: ■ atIpAddressAddrType ■ atIpAddressAddr
AtIpAddressEntry	{ AtIpAddressTable 1 }	Information about the address mapping for a particular interface.
atIpAddressAddrType	{ AtIpAddressEntry 1 }	An indication of the IP version of 'atIpAddressAddr'
atIpAddressAddr	{ AtIpAddressEntry 2 }	The IP address to which this entry's addressing information pertains. The address type of this object is specified in object 'atIpAddressAddrType'.
atIpAddressPrefixLen	{ AtIpAddressEntry 3 }	An integer, specifying the prefix length of the IP address represented by this entry.
atIpAddressLabel	{ AtIpAddressEntry 4 }	The name assigned to the IP address represented by this entry.
atIpAddressIfIndex	{ AtIpAddressEntry 5 }	The index value that uniquely identifies the interface to which this entry is applicable. The interface identified by a particular value of this index corresponds to the interface identified by the same value of the IF-MIB's ifIndex.
atIpAddressAssignmentType	{ AtIpAddressEntry 6 }	The IP address assignment type for this entry (primary or secondary), as described in the Textual Convention 'AtIpAddressAssignmentType'.

Table 76-23: Objects defined in AT-IP-MIB(Continued)

Object	Object Identifier	Description
atIpAddressRowStatus	{ AtIpAddressEntry 7 }	The current status of the IP address entry. The following values may be returned when reading this object: ■ active (1) The IP address is currently mapped to an interface and is valid. ■ notReady (3) The IP address is currently partially configured and is not mapped to an interface. The following values may be written to this object: ■ active (1) An attempt will be made to map the IP address to the configured interface. ■ createAndWait (5) An attempt will be made to create a new IP address entry. ■ destroy (6) The IP address setting will be removed from the device. An entry cannot be made active until its atIpAddressPrefixLen, atIpAddressIfIndex and atIpAddressAssignmentType objects have been set to valid values.

AT-VLAN-MIB

The atVlanStatistics-MIB (Figure 76-3, and Table 76-16) defines objects for managing VLANs. The MIB contains a sub tree for managing VLAN statistics. Objects in the VLAN Statistics sub-tree have the object identifier ({atVlanInfo 1}).

Figure 76-6: The atVlanStatistics MIB tree




Table 76-24: Objects defined in AT-VLAN-MIB

Object	Object Identifier	Description
atVlanInfo	{ sysinfo 13 }	The VLAN MIB, used for retrieving VLAN specific system data.
atVlanStatistics	{ atVlanInfo 1 }	
atVlanStatNumCollections	{ atVlanStatistics 1 }	The number of unique VLAN statistics gathering instances defined on the device.
atVlanStatCollectionTable	{ atVlanStatistics 2 }	A table of VLAN statistic instances.
atVlanStatCollectionEntry	atVlanStatCollectionTable 1	A series of table entries where each entry represents a unique VLAN statistic gathering instance defined on the device.
atVlanStatCollectionName	atVlanStatCollectionEntry 1	The name of a VLAN statistics collection instance.
atVlanStatCollectionVlanId	atVlanStatCollectionEntry 2	The VLAN ID of ingress packets being monitored by this VLAN statistics collection instance.

Table 76-24: Objects defined in AT-VLAN-MIB(Continued)

Object	Object Identifier	Description
atVlanStatCollectionPortMap	atVlanStatCollectionEntry 3	A bitwise port map indicating the switch ports being monitored by this VLAN statistics collection instance. The bit position within the string, maps to the port with the same index in dot1dBasePortTable in BRIDGE-MIB. A binary '1' indicates that the port is being monitored by this VLAN statistics collection instance, with a '0' indicating that it is not.
atVlanStatCollectionIngressPkts	atVlanStatCollectionEntry 4	The number of ingress packets received and counted by this VLAN statistics collection instance.
atVlanStatCollectionIngressOctets	atVlanStatCollectionEntry 5	The number of octets of data received from ingress packets counted by this VLAN statistics collection instance.
atVlanStatCollectionResetStats	atVlanStatCollectionEntry 6	When read, this object will always return 2 (false). Setting its value to 1 (true) will cause the matching VLAN statistics collection instance's ingress packets and ingress octet values to be reset to zero.

Public MIBs

The following table lists the public MIBs supported by the AlliedWare Plus operating system. In general, all objects are supported except where the relevant protocol or feature is either not supported or not applicable to the device. Any variations from the standard are listed.

Table 76-25: Public MIBs Supported by AlliedWare Plus

MIB Name	Reference / Implementation
IANAifType-MIB	www.iana.org/assignments/ianaiftype-mib , IANAifType textual convention.
RFC1155-SMI	RFC 1155, <i>Structure and Identification of Management Information for TCP/IP-based Internets</i> .
-	RFC 1212, <i>Concise MIB Definitions</i> .
RFC1213-MIB	RFC 1213, <i>Management Information Base for Network Management of TCP/IP-based internets: MIB-II</i>. The following objects are not supported: ■ ipInReceives ■ ipInHdrErrors ■ ipInAddrErrors ■ ipForwDatagrams ■ ipInUnknownProtos ■ ipInDiscards ■ ipInDelivers ■ ipOutRequests ■ ipOutDiscards ■ ipOutNoRoutes ■ ipReasmTimeout ■ ipReasmReqds ■ ipReasmOKs ■ ipReasmFails ■ ipFragOKs ■ ipFragFails ■ ipFragCreates ■ ipAdEntReasmMaxSize ■ ipNetToMediaTable ■ ipRoutingDiscards ■ all objects in the egp group (EGP is not supported)
	RFC 1215, <i>A Convention for Defining Traps for use with the SNMP</i> .
	RFC 1239, <i>Reassignment of Experimental MIBs to Standard MIBs</i> .

Table 76-25: Public MIBs Supported by AlliedWare Plus(Continued)

MIB Name	Reference / Implementation
IP-MIB	RFC 2011, <i>SNMPv2 Management Information Base for the Internet Protocol using SMIv2</i>. The following objects are not supported: ■ ipInReceives ■ ipInHdrErrors ■ ipInAddrErrors ■ ipForwDatagrams ■ ipInUnknownProtos ■ ipInDiscards ■ ipInDelivers ■ ipOutRequests ■ ipOutDiscards ■ ipOutNoRoutes ■ ipReasmTimeout ■ ipReasmReqds ■ ipReasmOKs ■ ipReasmFails ■ ipFragOKs ■ ipFragFails ■ ipFragCreates ■ ipAdEntReasmMaxSize ■ ipNetToMediaTable ■ ipRoutingDiscards
TCP-MIB	RFC 2012, <i>SNMPv2 Management Information Base for the Transmission Control Protocol using SMIv2</i> .
UDP-MIB	RFC 2013, <i>SNMPv2 Management Information Base for the User Datagram Protocol using SMIv2</i> .
IP-FORWARD-MIB	RFC 2096, <i>IP Forwarding Table MIB</i>. The following objects are obsolete: ■ ipForwardNumber ■ ipForwardTable The following read-write objects are implemented as read-only: ■ ipCidrRouteIfIndex ■ ipCidrRouteType ■ ipCidrRouteInfo ■ ipCidrRouteNextHopAS ■ ipCidrRouteMetric1 ■ ipCidrRouteMetric2 ■ ipCidrRouteMetric3 ■ ipCidrRouteMetric4 ■ ipCidrRouteMetric5 ■ ipCidrRouteStatus
-	RFC 2257, <i>Agent Extensibility (AgentX) Protocol Version 1</i> .
SNMP-MPD-MIB	RFC 2572, <i>Message Processing and Dispatching for the Simple Network Management Protocol (SNMP)</i> .
SNMP-COMMUNITY-MIB	RFC 2576, <i>Coexistence between Version 1, Version 2, and Version 3 of the Internet-standard Network Management Framework</i> .
SNMPv2-SMI	RFC 2578, <i>Structure of Management Information Version 2 (SMIv2)</i> .
SNMPv2-TC	RFC 2579, <i>Textual Conventions for SMIv2</i> .
SNMPv2-CONF	RFC 2580, <i>Conformance Statements for SMIv2</i> .

Table 76-25: Public MIBs Supported by AlliedWare Plus(Continued)

MIB Name	Reference / Implementation
P-BRIDGE-MIB	RFC 2674, <i>Definitions of Managed Objects for Bridges with Traffic Classes, Multicast Filtering and Virtual LAN Extensions</i>. The following objects are not supported: ■ dot1dTpPortOverflowTable ■ dot1dTrafficClassesEnabled ■ dot1dGmrpStatus ■ dot1dPortCapabilitiesTable ■ dot1dUserPriority ■ dot1dTrafficClassPriority ■ dot1dPortOutboundAccessPriorityTable ■ all objects in the dot1dGarp group ■ all objects in the dot1dGmrp group The following read-write objects are implemented as read-only: ■ dot1dPortDefaultUserPriority ■ dot1dPortNumTrafficClasses ■ dot1dTrafficClass
Q-BRIDGE-MIB	RFC 2674, <i>Definitions of Managed Objects for Bridges with Traffic Classes, Multicast Filtering and Virtual LAN Extensions</i>. The following objects are not supported: ■ dot1qGvrpStatus ■ dot1qFdbId ■ dot1qTpFdbAddress ■ dot1qTpGroupTable ■ dot1qForwardAllTable ■ dot1qForwardUnregisteredTable ■ all objects in the dot1qStatic group ■ dot1qVlanTimeMark ■ dot1qVlanIndex ■ dot1qVlanCurrentEgressPorts ■ dot1qVlanCurrentUntaggedPorts ■ dot1qVlanForbiddenEgressPorts ■ dot1qPortGvrpStatus ■ dot1qPortGvrpFailedRegistrations ■ dot1qPortGvrpLastPduOrigin ■ dot1qPortRestrictedVlanRegistration ■ dot1qPortVlanStatisticsTable ■ dot1qPortVlanHCStatisticsTable ■ dot1qLearningConstraintsTable The following read-write objects are implemented as read-only: ■ dot1qPvid ■ dot1qPortAcceptableFrameTypes
VRRP-MIB	RFC 2787, <i>Definitions of Managed Objects for the Virtual Router Redundancy Protocol</i>. All objects with read-write and read-create access are implemented as read-only.

Table 76-25: Public MIBs Supported by AlliedWare Plus(Continued)

MIB Name	Reference / Implementation
HOST-RESOURCES-MIB	RFC 2790, <i>Host Resources MIB</i>. The following objects are not supported: ■ hrStorageAllocationFailures ■ All objects in hrDevice ■ All objects in hrSWRun ■ All objects in hrSWRunPerf ■ All objects in hrSWInstalled ■ All objects in hrMIBAdminInfo
SNMPv2-PDU	RFC 3416, <i>Version 2 of the Protocol Operations for the Simple Network Management Protocol (SNMP)</i> .
SNMPv2-TM	RFC 3417, <i>Transport Mappings for the Simple Network Management Protocol (SNMP)</i> .
SNMPv2-MIB	RFC 3418, <i>Management Information Base (MIB) for the Simple Network Management Protocol (SNMP)</i> .
POE-MIB	RFC 3621, <i>Power Ethernet MIB</i>. In each of the following objects, if one entry is set then all other entries for the same object in the table are set to the same value. ■ pethMainPseUsageThreshold ■ pethNotificationControlEnable The following objects indicate PSE threshold usage notification: ■ pethMainPowerUsageOnNotification ■ pethMainPowerUsageOffNotification The following read-write object is implemented as read-only: ■ pethPsePortPowerPairs
EtherLike-MIB	RFC 3635, <i>Definitions of Managed Objects for the Ethernet-like Interface Types</i>. The following objects are deprecated: ■ dot3StatsEtherChipSet ■ all objects in the dot3Tests group ■ all objects in the dot3Errors group The following read-write object is implemented as read-only: ■ dot3PauseAdminMode

Table 76-25: Public MIBs Supported by AlliedWare Plus(Continued)

MIB Name	Reference / Implementation
MAU-MIB	RFC 3636, <i>Definitions of Managed Objects for IEEE 802.3 Medium Attachment Units (MAUs)</i>. The following objects are not supported: ■ all objects in the dot3RpMauBasicGroup group ■ ifMauTypeListBits ■ ifMauHCFALSECarriers ■ all object identifiers in the dot3MauType group ■ ifMauAutoNegCapabilityBits ■ ifMauAutoNegCapAdvertisedBits ■ ifMauAutoNegCapReceivedBits ■ ifMauAutoNegRemoteFaultAdvertised ■ ifMauAutoNegRemoteFaultReceived ■ all objects in the mauMod group The following objects are deprecated: ■ ifMauTypeList ■ all objects in the dot3BroadMauBasicGroup group ■ ifMauAutoNegCapability ■ ifMauAutoNegCapAdvertised ■ ifMauAutoNegCapReceived The following read-write object is implemented as read-only: ■ ifMauStatus
INET-ADDRESS-MIB	RFC 4001, <i>Textual Conventions for Internet Network Addresses</i> .
BRIDGE-MIB	RFC 4188, <i>Definitions of Managed Objects for Bridges</i>. The following object is not supported: ■ dot1dStaticTable
RSTP-MIB	RFC 4318, <i>Definitions of Managed Objects for Bridges with Rapid Spanning Tree Protocol</i>. The following object is deprecated: ■ dot1dStpPathCostDefault
DISMAN-PING-MIB	RFC 4560, <i>Definitions of Managed Objects for Remote Ping, Traceroute, and Lookup Operations</i>. The following (lldpLocManAddrTable and lldpConfigManAddrTable) read-write object is implemented as read-only: ■ pingMaxConcurrentRequests You can specify multiple ping operations, but the device only performs one ping at a time (pingMaxConcurrentRequests). The device uses ICMP echo for ping operations (pingImplementationTypeDomains).
LLDP-MIB	IEEE Standard 802.1AB-2005, Section 12, <i>LLDP MIB Definitions</i>. The following local management address table supports only a single management address per port: ■ lldpConfigManAddrTable
LLDP-EXT-DOT1-MIB	IEEE Standard 802.1AB-2005, Annex F, <i>IEEE 802.1 Organizationally Specific TLVs</i>, Section F.7.1, <i>IEEE 802.1LLDP extension MIB module</i>. In each of the following tables, if one entry is set, all other entries in the table are set to the same value. ■ lldpXdot1ConfigVlanNameTxEnable ■ lldpXdot1ConfigProtoVlanTxEnable ■ lldpXdot1ConfigProtocolTxEnable

Table 76-25: Public MIBs Supported by AlliedWare Plus(Continued)

MIB Name	Reference / Implementation
LLDP-EXT-DOT3-MIB	<i>IEEE Standard 802.1AB-2005, Annex G, IEEE 802.3 Organizationally Specific TLVs, Section G.7.1, IEEE 802.3 LLDP extension MIB module</i>
LLDP-EXT-MED-MIB	<i>ANSI/TIA-1057- 2006, Section 13.3, LLDP-MED MIB Definition</i>

Chapter 77: LLDP Introduction



Introduction.....	77.2
Link Layer Discovery Protocol.....	77.2
LLDP-MED	77.3
Voice VLAN.....	77.3
LLDP Advertisements	77.4
Type-Length-Value (TLV).....	77.4
LLDP-MED: Location Identification TLV	77.7
Transmission and Reception.....	77.8
LLDP-MED Operation	77.9
Storing LLDP Information.....	77.10
Configuring LLDP.....	77.11
Configure LLDP.....	77.12
Configure LLDP-MED.....	77.14
Configure Authentication for Voice VLAN.....	77.18

Introduction

This chapter describes the Link Layer Discovery Protocol (LLDP), LLDP for Media Endpoint Devices (LLDP-MED) and Voice VLAN, and general configuration information for these.

LLDP is designed to be managed with the Simple Network Management Protocol (SNMP), and SNMP-based Network Management Systems (NMS). LLDP can be configured, and the information it provides can be accessed, using either the command line interface or SNMP.

- For detailed descriptions of the commands used to configure LLDP and LLDP-MED, see [Chapter 78, LLDP Commands](#).
- For Voice VLAN commands, see [Chapter 17, VLAN Commands](#).
- For information about the LLDP and LLDP-MED MIBs, see “Public MIBs” on page 76.58.

Link Layer Discovery Protocol

Link Layer Discovery Protocol (LLDP) is a Layer 2 protocol defined by the *IEEE Standard 802.1AB-2005*. This switch supports LLDP as specified in this standard, including *Annex F* and *Annex G*.

LLDP enables Ethernet network devices, such as switches and routers, to transmit and/or receive device-related information to or from directly connected devices on the network, and to store such information learned about other devices. The data sent and received by LLDP is useful for many reasons. The switch can discover neighbors—other devices directly connected to it. Devices can use LLDP to advertise some parts of their Layer 2 configuration to their neighbors, enabling some kinds of misconfiguration to be more easily detected and corrected.

LLDP is a link level (“one hop”) protocol; LLDP information can only be sent to and received from devices that are directly connected to each other, or connected via a hub or repeater. Advertised information is not forwarded on to other devices on the network.

The information transmitted in LLDP advertisements flows in one direction only, from one device to its neighbors, and the communication ends there. Transmitted advertisements do not solicit responses, and received advertisements do not solicit acknowledgement.

LLDP operates over physical ports (layer 2) only. For example, it can be configured on switch ports that belong to static or dynamic aggregated links (channel groups), but not on the aggregated links themselves; and on switch ports that belong to VLANs, but not on the VLANs themselves.

LLDP provides a way for the switch to:

- [transmit information about itself to neighbors](#)
- [receive device information from neighbors](#)
- [store and manage information in an LLDP MIB](#)

Each port can be configured to transmit local information, receive neighbor information, or both.

LLDP defines:

- a set of common advertisements (“LLDP Advertisements” on page 77.4)
- a protocol for transmitting and receiving advertisements (“Transmission and Reception” on page 77.8)
- a method for storing the information that is contained within received advertisements (“Storing LLDP Information” on page 77.10)

Interactions LLDP has the following interactions with other switch features:

- **Spanning tree**
Ports blocked by a spanning tree protocol can still transmit and receive LLDP advertisements.
- **802.1x**
Ports blocked by 802.1x port authorization cannot transmit or receive LLDP advertisements. If LLDP has stored information for a neighbor on the port before it was blocked, this information will eventually time out and be discarded.
- **VLAN tagging**
LLDP packets are untagged; they do not contain 802.1Q header information with VLAN identifier and priority tagging.
- **Virtual Chassis Stacking (VStack) resiliency link**
When a port is configured as a VStack resiliency link port, LLDP does not operate on the port; LLDP neither transmits nor receives advertisements, and any LLDP configuration and data stored for the port, including counters, is discarded.
- **Mirror ports**
LLDP does not operate on mirror analyzer ports.

LLDP-MED

LLDP for Media Endpoint Devices (LLDP-MED), is an extension of LLDP used between LAN network connectivity devices, such as this switch, and the media endpoint devices connected to them, such as IP phones. LLDP-MED is specified in *ANSI/TIA-1057-2006*. Of the application types specified in *ANSI/TIA-1057-2006*, the switch supports Application Type 1: Voice.

LLDP-MED uses the LLDP advertisement, transmission and storage mechanisms, but transmits, receives, and stores data specifically related to managing the voice endpoint devices. This includes information about network policy, location, hardware configuration, and, for Power over Ethernet-capable devices, power management.

Voice VLAN

Many IP phones (or other IP voice devices) have two interfaces: one to connect to the network and another that allows a computer or similar device to connect to the network via the IP phone. It is often desirable to treat the voice and data traffic separately so that appropriate Quality of Service (QoS) policies can be applied to each. The Voice VLAN feature uses LLDP-MED to convey configuration information (such as VLAN ID and User Priority tagging, and DiffServ Code Point (DSCP)—“[Differentiated Services Architecture](#)” on page 52.4) for the voice traffic to the IP phone. In response, the IP phone sends voice traffic according to this

configuration. The data traffic coming through the IP phone from the PC is sent with the default configuration, typically untagged with normal priority.

LLDP Advertisements

LLDP transmits advertisements as packets called LLDP Data Units (LLDPDUs). An LLDPDU consists of a set of Type-Length-Value elements (TLV), each of which contains a particular type of information about the device or port transmitting it.

Type-Length-Value (TLV)

A single LLDPDU contains multiple TLVs. TLVs are short information elements that communicate complex data, such as variable length strings, in a standardized format. Each TLV advertises a single type of information, such as its device ID, type, or management addresses. The following table describes fields in a TLV.

Table 77-1: Fields in a Type Length Value element

Field	Description
Type	Identifies the kind of information. It consists of a 7-bit Type code.
Length	Identifies the length of the information. It consists of a 9-bit value that specifies the number of bytes of data in the Value field.
Value	Contains the actual value of the advertised information. This is a variable length data field.

LLDP sends mandatory TLVs in each advertisement; it can also be configured to send one or more optional TLVs, from the following groups:

- Mandatory Base TLVs, included in all LLDP advertisements. See IEEE 802.1AB-2005.
- Optional Base TLVs, which may be included in any LLDP advertisements. See IEEE 802.1AB-2005.
- IEEE 802.1 Organizationally Specific TLVs (802.1 TLVs). See IEEE 802.1AB-2005 Annex F.
- IEEE 802.3 Organizationally Specific TLVs (802.3 TLVs). See IEEE 802.1AB-2005 Annex G.
- LLDP-MED Organizationally Specific TLVs (LLDP-MED TLVs), included in LLDP-MED advertisements. See ANSI/TIA-1057- 2006.

Mandatory and optional TLVs for LLDP and LLDP-MED advertisements are shown in Table 77-2.

Table 77-2: TLVs in LLDP advertisements

TLV	Description
Mandatory Base TLVs—IEEE 802.1AB-2005	
Chassis ID	Identifies the device's chassis. On this switch, this is the MAC address of the switch or stack.
Port ID	Identifies the port that transmitted the LLDPDU.

Table 77-2: TLVs in LLDP advertisements(Continued)

TLV	Description
Time To Live (TTL)	Indicates the length of time in seconds for which the information received in the LLDPDU remains valid. If the value is greater than zero, the information is stored in the LLDP remote system MIB. If the value is zero, the information previously received is no longer valid, and is removed from the MIB.
End of LLDPDU	Signals that there are no more TLVs in the LLDPDU.
Optional Base TLVs—IEEE 802.1AB-2005	
Port description	A description of the device's port in alpha-numeric format.
System name	The system's assigned name in alpha-numeric format.
System description	A description of the device in alpha-numeric format. This includes information about the device's hardware and operating system.
System capabilities	The device's router and bridge functions, and whether or not these functions are currently enabled.
Management address	The address of the local LLDP agent. This can be used to obtain information related to the local device.
IEEE 802.1 Organizationally Specific TLVs (802.1 TLVs)—IEEE 802.1AB-2005 Annex F	
Port VLAN	VLAN identifier that the local port associates with untagged or priority tagged frames.
Port & Protocol VLANs	Whether Port & Protocol VLAN is supported and enabled on the port, and the list of Port & Protocol VLAN identifiers.
VLAN Names	List of VLAN names that the port is assigned to.
Protocol IDs	List of protocols that are accessible through the port, for instance: ■ 9000 (Loopback) ■ 00 26 42 42 03 00 00 00 (STP) ■ 00 27 42 42 03 00 00 02 (RSTP) ■ 00 69 42 42 03 00 00 03 (MSTP) ■ 888e01 (802.1x) ■ aa aa 03 00 e0 2b 00 bb (EPSR) ■ 88090101 (LACP) ■ 00540000e302 (Loop protection) ■ 0800 (IPv4) ■ 0806 (ARP) ■ 86dd (IPv6)
IEEE 802.3 Organizationally Specific TLVs (802.3 TLVs)—IEEE 802.1AB-2005 Annex G	
MAC/PHY Configuration/Status	The current values of the following for the port: ■ Speed and duplex mode auto-negotiation support ■ Auto-negotiation status ■ PMD (physical media dependent) auto-negotiation advertised capability ■ Operational MAU type This TLV is always included in LLDP-MED advertisements.
Power Via MDI	The power-via-MDI capabilities. On devices that are LLDP-MED and PoE-capable, we recommend using the Extended Power-via-MDI TLV instead of this TLV.
Link Aggregation	Whether the link is capable of being aggregated, whether it is currently in an aggregation and if in an aggregation, the port of the aggregation.

Table 77-2: TLVs in LLDP advertisements(Continued)

TLV	Description
Maximum Frame Size	The maximum supported 802.3 frame size that the sending device is capable of receiving—larger frames will be dropped.
LLDP-MED Organizationally Specific TLVs (LLDP-MED TLVs)—ANSI/TIA-1057- 2006	
LLDP-MED Capabilities	Indicates an LLDP-MED capable device, and advertises which LLDP-MED TLVs are supported and enabled, and the device type. For this switch, the device type is Network Connectivity Device. An advertisement containing this TLV is an LLDP-MED advertisement.
Network Policy	Network policy information configured on the port for connected media endpoint devices. The switch supports Application Type 1: Voice, including the following network policy for connected voice devices to use for voice data: ■ Voice VLAN ID ■ Voice VLAN User Priority tagging ■ Voice VLAN Diffserv Code Point (DSCP)
Location Identification	Location information configured for the port, in one or more of the following formats: ■ Civic address ■ Coordinate-based LCI ■ Emergency Location Identification Number (ELIN) For more information, see “LLDP-MED: Location Identification TLV” on page 77.7 .
Extended Power-via-MDI	For PoE-capable devices, this TLV includes: ■ Power Type field: Power Sourcing Entity (PSE). ■ Power Source field: current power source, either Primary Power Source or Backup Power Source. ■ Power Priority field: power priority configured on the port. ■ Power Value field: In TLVs transmitted by a Power Sourcing Equipment (PSE) such as this switch, this advertises the power that the port can supply over a maximum length cable based on its current configuration (that is, it takes into account power losses over the cable). In TLVs received from Powered Device (PD) neighbors, the power value is the power the neighbor requests. Available on devices that are PoE-capable.
Inventory Management TLV Set	Includes the following TLVs, based on the current hardware platform and the software version, identical on every port on the switch: ■ Hardware Revision ■ Firmware Revision ■ Software Revision ■ Serial Number ■ Manufacturer Name ■ Model Name ■ Asset ID On Virtual Chassis Stacking devices, the inventory information is based on the current master.

LLDP-MED: Location Identification TLV

Location information can be configured for each port, and advertised to remote devices, which can then transmit this information in calls; the location associated with voice devices is particularly important for emergency call services. All ports may be configured with the location of the switch, or each port may be configured with the location of the remote voice device connected to it.

The location information for a particular port can be configured using one or more of the following three data formats: coordinate-based, Emergency Location Identification Number (ELIN), and civic address. Up to one location of each type can be assigned to a port.

Location configuration information (LCI) in all configured data formats is transmitted in Location Identification TLVs. When LLDP receives a Location Identification TLV, it updates the remote entry in the LLDP-MED MIB with this information.

Co-ordinate LCI Coordinate-based location data format uses geospatial data, that is, latitude, longitude, and altitude (height or floors), including indications of resolution, with reference to a particular datum: WGS 84, NAD83—North American Vertical Datum of 1988 (NAVD88), or NAD83—Mean Lower Low Water (MLLW). For more information, see *RFC 3825, Dynamic Host Configuration Protocol Option for Coordinate-based Location Configuration Information*.

ELIN LCI Emergency Location Identification Number (ELIN) location data format provides a unique number for each location for Emergency Call Services (ECS). In North America, ELINs are typically 10 digits long; ELINs up to 25 digits are supported.

Civic Address LCI The Civic Address location data format uses common street address format, as described in *RFC4776*.

Transmission and Reception

Table 77-3 describes the LLDP transmission and reception processes. Additional LLDP-MED processes are described in “LLDP-MED Operation” on page 77.9.

Table 77-3: LLDP transmission and reception processes

When ...	And ...	Then ...
LLDP is enabled	Ports are configured to transmit LLDP advertisements	Regular LLDP advertisements are sent via these ports at intervals determined by the transmit interval. Each advertisement contains local information (from the Local Systems MIB) for all the mandatory TLVs and the optional TLVs that the port is configured to send.
	Ports are configured to receive LLDP advertisements	Information received in advertisements via these ports is stored in the Neighbor table (Remote Systems MIB). This information is retained until it is replaced by a more recent advertisement from the same neighbor or it times out (the TTL elapses).
Local information changes	The transmission delay time has elapsed since the last advertisement was transmitted	New advertisements are sent containing the new set of local information.
Neighbor information changes	Notifications are enabled, and the notification interval has elapsed since the last notification was sent	The SNMP notification (trap) lldpRemTablesChange is sent.
LLDP transmission and reception is disabled on a port.	An LLDP command was used to do this	It transmits a final 'shutdown' LLDPDU with a Time-To-Live (TTL) TLV that has a value of "0". This tells any remote neighboring devices to remove the information associated with this switch from their remote systems MIB. Then it stops transmitting and receiving advertisements. The neighbor information remains in the Remote Systems MIB until it times out.
	A shutdown command was used on the port	It makes a best effort to send a shutdown LLDPDU. Then it stops transmitting and receiving advertisements. The neighbor information remains in the Remote Systems MIB until it times out.
	Something else disabled LLDP, such as Virtual Chassis Stacking (VCS) failover	It does not send a shutdown LLDPDU. It stops transmitting and receiving advertisements. The neighbor information remains in the Remote Systems MIB until it times out.
	It is enabled again	LLDP reinitializes and resumes transmitting and receiving advertisements after the reinitialization interval has elapsed.
The Neighbor table has 1600 neighbors		It discards any further neighbors.
LLDP receives a LLDPDU or TLV with a detectable error		It discards the incorrect TLV.
LLDP receives a TLV it does not recognize	It contains no basic format errors	It stores it for possible later retrieval by network management (in the unrecognized TLV information table lldpRemUnknownTLVTable in the LLDP MIB).

LLDP-MED Operation

When LLDP is enabled, LLDP-MED is enabled by default, and uses the same LLDP transmission and reception process described in [Table 77-3](#). When LLDP receives an advertisement indicating a newly connected LLDP-MED-capable device on a port, it transmits one LLDP-MED advertisement per second via this port, a configurable number of times (the *fast start count*). Thereafter, it sends regular advertisements at the LLDP transmit interval. When the last advertisement for an LLDP-MED-capable device connected to the port times out, it stops sending LLDP-MED advertisements via the port.

If LLDP-MED notifications are enabled for a port, and SNMP traps for LLDP are enabled, LLDP-MED generates a *Topology Change Notification (LLDP-MED lldpXMedTopology ChangeDetected)* when a new LLDP-MED compliant IP telephony device is connected to a port or removed from a port. This notification includes the following information:

- IP Phone Chassis ID and Chassis ID sub-type (IP address)
- LLDP Endpoint Device Class
- Switch Chassis ID (MAC address) and Port ID where the device is attached.

Storing LLDP Information

When an LLDP device receives a valid LLDP advertisement from a neighboring network device, it stores the information in an IEEE-defined Simple Network Management Protocol (SNMP) Management Information Base (MIB).

LLDP stores information in the LLDP MIB defined in Section 12 of the *IEEE Standard 802.1AB-2005*, its extensions defined in *Annex F*, *Annex G*, and *ANSI/TIA-1057- 2006*, about:

LLDP-EXT-MED-MIB ANSI/TIA-1057- 2006, Section 13.3, LLDP-MED MIB Definition

- **Local system information.** This is the information that LLDP can transmit in advertisements to its neighbors.
- **Remote systems information.** This is the data that the device receives in advertisements from its neighbors.
- **LLDP configuration.** This can be used with SNMP to configure LLDP on the device.
- **LLDP statistics.** This includes information about LLDP operation on the device, including packet and event counters.

This information can be accessed either via SNMP, or directly using the command line interface.

Local system

Information about your device is called local system information. The LLDP local system MIB maintains this information, which consists of device details, as well as any user-configured information that you have set up for your switch, for example a port description or a management address.

LLDP on this device can store one management address per port, and transmit this in LLDP advertisements. It can store multiple management addresses received from each neighbor.

Remote systems

Information gained from neighboring devices is called remote system information. The LLDP remote systems MIB maintains this information.

The length of time for which neighbor information remains in the LLDP remote systems MIB is determined by the Time-To-Live (TTL) value of received LLDPDUs. When it receives an advertisement from a neighbor, LLDP starts a timer based on the Time To Live (TTL) information in the advertisement. The Time To Live (TTL) information in an advertisement is: $TTL = \text{transmit interval} \times \text{holdtime multiplier}$. If the TTL elapses, for instance if the neighbor has been removed, LLDP deletes the neighbor's information from the MIB. This ensures that only valid LLDP information is stored.

Whenever a new neighbor is discovered, or an existing neighbor sends an advertisement with new information that differs from the previous advertisement, for example a new or changed TLV, a remote tables change event is activated. If SNMP notifications are enabled, the notification `lldpRemTablesChange` is sent.

To prevent the remote systems MIB from using large amounts of memory and possibly affecting the operation of your switch, it limits the number of neighbors it stores information for to 1600. If it is storing information from 1600 neighbors, and detects any more neighbors, it is considered to have too many neighbors, and discards advertisements from the rest. There is no per-port limit to the number of neighbors.

SNMP utilities

An SNMP utility can read the Neighbors table MIB (Remote Systems Data in the LLDP MIB) on a device to find out about the LLDP neighbors it is directly connected to on each port. Then it can read the Neighbors table MIB on each of these neighbors to find out about their neighboring LLDP devices, and so on.

Configuring LLDP

You can configure LLDP on the device using either:

- the command line interface. For detailed descriptions of the commands, see [Chapter 78, LLDP Commands](#), or
- SNMP—see [Chapter 76, SNMP MIBs](#).

This section includes the following command line interface configuration procedures:

- “Configure LLDP” on page 77.12— This procedure includes configuration for LLDP between network connectivity devices; it does not include LLDP-MED. If you are configuring LLDP-MED only, use the following procedure instead of this one.
- “Configure LLDP-MED” on page 77.14—This procedure includes the LLDP configuration required to support LLDP-MED, as well as specific LLDP-MED and Voice VLAN configuration.
- “Configure Authentication for Voice VLAN” on page 77.18—This procedure includes 802.1X port authentication configuration including dynamic VLAN assignment to be used with LLDP-MED. Use the previous procedure before using this one.

Because LLDP is often used together with SNMP, consider configuring SNMP before you configure LLDP. LLDP transmits large amounts of data about the network. For security reasons, we recommend configuring SNMP for SNMP version 3 only (for read and write access). Remove all SNMPv1 and SNMPv2 configuration. See [Chapter 74, SNMP Introduction](#), and [Chapter 75, SNMP Commands](#).

Configure LLDP

Use the procedure in [Table 77-4](#) below to configure LLDP.

Some optional TLVs send information that can be configured by other commands. If LLDP will be configured to send these TLVs, consider whether to configure the corresponding parameters first.

- Port Description. See the [description \(interface\) command](#) on [page 12.2](#).
- System Name. See the [hostname command](#) on [page 8.11](#).

Table 77-4: Configuration procedure for LLDP

Enable LLDP	
1. <code>awplus#configure terminal</code>	Enter Configuration mode.
2. <code>awplus(config)#lldp run</code>	Enable LLDP.
Configure ports for LLDP	
Configure each port to determine whether and which LLDP messages are transmitted and received. If all the ports running LLDP require the same configuration, configure them all together. Otherwise repeat these commands for each port or group of ports that requires a particular configuration.	
3. <code>awplus(config)# interface <port-list></code>	Enter Interface Configuration mode for the switch ports.
4. <code>awplus(config-if)#lldp tlv-select {[<tlv>]...}</code> <code>awplus(config-if)#lldp tlv-select all</code>	By default, the mandatory TLVs are included in LLDP messages. Enable the transmission of one or more optional TLVs through these port as required.
5. <code>awplus(config-if)#exit</code>	Return to Global Configuration mode.
6. <code>awplus(config)#interface <port-list></code>	By default, transmission and reception of LLDP advertisements is enabled on all ports. Enter Interface Configuration mode for any switch ports that should have transmission or reception disabled.
7. <code>awplus(config-if)#no lldp {[transmit][receive]}</code>	Disable transmission and/or reception as required.
8. <code>awplus(config-if)#exit</code>	Return to Global Configuration mode.
9. <code>awplus(config)#exit</code>	Return to Privileged Exec mode.
Check LLDP configuration	
10. <code>awplus#show lldp</code> <code>awplus#show lldp interface [<port-list>]</code> <code>awplus#show lldp local-info [base] [dot1] [dot3] [med] [interface <port-list>]</code> <code>awplus#show running-config lldp</code>	Review the LLDP configuration.
Monitor LLDP	
11. <code>awplus#show lldp neighbors</code> <code>awplus#show lldp neighbors detail</code> <code>awplus#show lldp statistics</code> <code>awplus#show lldp statistics interface [<port-list>]</code>	Monitor LLDP operations and display neighbor information as required.

Table 77-4: Configuration procedure for LLDP(Continued)

Advanced LLDP configuration

The configuration procedure above and the defaults for other settings suit most networks. Use the following commands for fine tuning if necessary.

Timer intervals should be long enough not to create unnecessarily high numbers of advertisements when there are topology changes. However, be aware that if the intervals are long, a neighbor's information can continue to be stored after its information has changed, or after it is disconnected.

12. <code>awplus#configure terminal</code>	Enter Configuration mode.
13. <code>awplus(config)#interface <port-list></code>	Enter Interface Configuration mode for the switch ports.
14. <code>awplus(config-if)#lldp management-address <ipaddr></code>	Override the default LLDP management address advertised through this port if required. This must be an IPv4 address that is already configured on the device. To see the management address that will be advertised, use the show lldp local-info command on page 78.37 .
15. <code>awplus(config-if)#lldp notifications</code>	By default, SNMP notifications are not transmitted. Enable them for these ports if required. (SNMP LLDP traps (notifications) must also be enabled.)
16. <code>awplus(config-if)#exit</code>	Return to Global Configuration mode.
17. <code>awplus(config)#lldp timer <5-32768></code>	The transmit interval determines how often regular LLDP transmits advertisements from each port. The transmit interval must be at least four times the transmission delay. Default: 30 seconds
18. <code>awplus(config)#lldp notification-interval <5-3600></code>	The notification interval determines the minimum interval between sending SNMP notifications (traps). Default: 5 seconds
19. <code>awplus(config)#lldp tx-delay <1-8192></code>	A series of successive changes over a short period of time can trigger the agent to send a large number of LLDPDUs. To prevent this, there is a transmission delay timer. This establishes a minimum length of time that must elapse between successive LLDP transmissions. The transmission delay cannot be greater than a quarter of the transmit interval. Default: 2 seconds
20. <code>awplus(config)#lldp reinit <1-10></code>	Reinitialization delay timer determines the minimum time after disabling LLDP on a port before it can reinitialize. Default: 2 seconds
21. <code>awplus(config)#lldp holdtime-multiplier <2-10></code>	The transmit interval is multiplied by the holdtime multiplier to give the Time To Live (TTL) value that is advertised to neighbors. Default: 4
22. <code>awplus(config)#exit</code>	Return to Privileged Exec mode.

Clear data

If necessary, you can clear either neighbor information or LLDP statistics for particular ports or all ports.

23. <code>awplus#clear lldp table [interface <port-list>]</code>	Clear the information from the table of neighbor information.
24. <code>awplus#clear lldp statistics [interface <port-list>]</code>	Clear LLDP statistics (packet and event counters).

Configure LLDP-MED

Use the procedure in [Table 77-5](#) to configure LLDP-MED and Voice VLAN for voice devices connected to the switch.

Consider whether you also need to configure:

- Simple Network Management Protocol ([Chapter 75, SNMP Commands](#))
- 802.1X port authentication ([Chapter 55, 802.1X Commands](#), [Chapter 57, Authentication Commands](#), [Chapter 59, AAA Commands](#))
- RADIUS server ([Chapter 62, Local RADIUS Server Commands](#), or [Chapter 60, RADIUS Commands](#))
- Quality of Service ([Chapter 53, QoS Commands](#))
- Access Control Lists ([Chapter 51, Access Control List \(ACL\) Commands](#))
- Power over Ethernet (PoE), if the switch supports PoE ([Chapter 23, Power over Ethernet Commands](#))

In most cases, configuring LLDP-MED using SNMP or using the CLI command line interface (CLI) described in [Chapter 78, LLDP Commands](#) has the same effect. However, the effect of configuring location information using SNMP differs from the CLI. When location information is assigned to a port by SNMP and a matching location is not found on the device, then a new location is automatically created and assigned to the specified port. If the location is unset by SNMP later, then the location is removed to prevent accumulating SNMP-set location information. However, if the location is being used for other ports, the automatically created location is not removed until no ports use it. Once it is modified or assigned to other ports by CLI commands, the location remains even after no ports use the location.

Table 77-5: Configuration procedure for Voice VLAN and LLDP-MED

Configure a Voice VLAN

Create a VLAN for voice data from voice endpoint devices connected to ports on the switch. Specify the network policy for voice data in this voice VLAN. LLDP-MED sends the network policy to voice devices connected to these ports. The voice devices use this network policy to determine the VLAN, priority and DSCP tagging of voice data it transmits.

1.	<code>awplus#configure terminal</code>	Enter Global Configuration mode.
2.	<code>awplus(config)#vlan database</code>	Enter VLAN Database Configuration mode.
3.	<code>awplus(config-vlan)#vlan <vid> [name <vlan-name>] [state {enable disable}]</code>	Create a VLAN to be used for the voice data to and from voice devices connected to the switch. By default, the new VLAN is enabled.
4.	<code>awplus(config-vlan)#exit</code>	Return to global configuration mode.
5.	<code>awplus(config)#interface <port-list></code>	Enter interface configuration mode for the ports to be configured with the same network policy. This may be all the switch ports with voice devices connected to them, or a subset if the network policy will differ between ports.
6.	<code>awplus(config-if)#switchport voice vlan [<vid> dot1p dynamic untagged]</code>	Specify the VLAN tagging to be used for voice data on these ports. Use the dynamic option if the VLAN tagging will be allocated dynamically by a RADIUS server. To configure authentication and dynamic VLAN allocation using the local RADIUS server, see the procedure in Table 77-6 on page 77.18 . Default: none.

Table 77-5: Configuration procedure for Voice VLAN and LLDP-MED

7.	<code>awplus(config-if)#switchport voice vlan priority <0-7></code>	Specify the priority-tagging that voice endpoint devices should put into their data packets. Default: 5.
8.	<code>awplus(config-if)#switchport voice dscp <0-63></code>	Specify the DSCP value that voice endpoint devices should put into their data packets. Default: 0.
9.	<code>awplus(config-if)#exit</code>	Return to global configuration mode.
Enable LLDP		
10.	<code>awplus(config)#lldp run</code>	Enable LLDP on the switch. Default: LLDP is disabled.
11.	<code>awplus(config)#interface <port-list></code>	Enter interface configuration mode for the switch ports LLDP is NOT to run on.
12.	<code>awplus(config-if)#no lldp {[transmit][receive]}</code>	Disable transmission or reception on these ports as required. Default: transmit and receive enabled.
13.	<code>awplus(config-if)#exit</code>	Return to global configuration mode.
Configure LLDP-MED location information		
Create civic address, coordinate, and/or ELIN locations, and assign them to switch ports.		
14.	<code>awplus(config)#location civic-location identifier <civic-loc-id></code>	Specify a civic location ID, and enter configuration mode for this identifier.
15.	<code>awplus(config-civic)#country <country></code> <code>awplus(config-civic)#city <city></code> <code>awplus(config-civic)#primary-road-name <primary-road-name></code> <code>awplus(config-civic)#street-suffix <street-suffix></code> <code>awplus(config-civic)#house-number <house-number></code> <code>awplus(config-civic)#<other-civic-location-parameters ...></code>	Specify the civic address location information for the civic address location ID. You must specify a country first, using the upper-case two-letter country code, and then at least one more parameter. For the full set of parameters you can use to specify civic address location, see the location civic-location configuration command on page 78.21 .
16.	<code>awplus(config-civic)#exit</code>	Return to global configuration mode.
17.	<code>awplus(config)#location coord-location identifier <coord-loc-id></code>	Specify a coordinate location identifier, and enter configuration mode for this identifier.
18.	<code>awplus(config-coord)#latitude <latitude></code> <code>awplus(config-coord)#lat-resolution <lat-resolution></code> <code>awplus(config-coord)#longitude <longitude></code> <code>awplus(config-coord)#long-resolution <long-resolution></code> <code>awplus(config-coord)#altitude <altitude> {meters floor}</code> <code>awplus(config-coord)#alt-resolution <alt-resolution></code> <code>awplus(config-coord)#datum {wgs84 nad83-navd nad83-mllw}</code>	Specify the coordinate location for the coordinate location identifier.
19.	<code>awplus(config-coord)#exit</code>	Return to global configuration mode.

Table 77-5: Configuration procedure for Voice VLAN and LLDP-MED

20.	<code>awplus(config)#location elin-location <elin> identifier <elin-loc-id></code>	Specify an ELIN location identifier, and the ELIN for this identifier.
21.	<code>awplus(config)#interface <port-list></code>	Enter interface configuration mode for one or more switch ports which require the same location information.
22.	<code>awplus(config-if)#location civic-location-id <civic-loc-id></code> <code>awplus(config-if)#location coord-location-id <coord-loc-id></code> <code>awplus(config-if)#location elin-location-id <elin-loc-id></code>	Assign the civic, coordinate, and/or ELIN location identifier to these ports. LLDP-MED will send the location information associated with a port to the voice endpoint device attached to it.
23.	<code>awplus(config-if)#exit</code>	Return to global configuration mode.
24.	<code>awplus(config)#exit</code>	Return to Privileged Exec mode.
Review the LLDP configuration		
25.	<code>awplus#show lldp</code>	Check general LLDP configuration settings.
26.	<code>awplus#show lldp interface [<port-list>]</code>	Check LLDP configuration for ports.
27.	<code>awplus#show lldp local-info [base] [dot1] [dot3] [med] [interface <port-list>]</code>	Check the information that may be transmitted in LLDP advertisements from ports.
28.	<code>awplus#show location {civic-location coord-location elin-location}</code> <code>awplus#show location {civic-location coord-location elin-location} identifier {<civic-loc-id> <coord-loc- id> <elin-loc-id>}</code> <code>awplus#show location {civic-location coord-location elin-location} interface <port-list></code>	Check the location information.
29.	<code>awplus#show running-config lldp</code>	If you want to display all the LLDP configuration, use this command.
Monitor LLDP-MED		
30.	<code>awplus#show lldp neighbors [interface <port-list>]</code> <code>awplus#show lldp neighbors detail [base] [dot1] [dot3] [med] [interface <port-list>]</code> <code>awplus#show lldp statistics</code> <code>awplus#show lldp statistics interface [<port-list>]</code>	Monitor LLDP operation.
Advanced configuration		
The configuration procedure above and the defaults for other settings suit most networks. Use the following commands for fine tuning if necessary. For information about other advanced configuration for LLDP, including LLDP timers, see Table 77-4 .		
31.	<code>awplus#configure terminal</code>	Enter Global Configuration mode.
32.	<code>awplus(config)#lldp faststart-count <1-10></code>	By default, when LLDP-MED detects an LLDP-MED capable device on a port, it sends 3 advertisements at 1s intervals. Change the fast start count if required. Default: fast start count is 3

Table 77-5: Configuration procedure for Voice VLAN and LLDP-MED

33	<code>awplus(config)#lldp non-strict-med-tlv-order-check</code>	By default non-strict order checking for LLDP-MED advertisements is disabled. That is, strict order checking is applied to LLDP-MED advertisements, and LLDP-MED TLVs in non-standard order are discarded. If you require LLDP-MED advertisements with non-standard TLV order to be received and stored, enable non-strict order checking.
34	<code>awplus(config)#interface <port-list></code>	Enter interface configuration mode for switch ports which will have the same advanced configuration.
35	<code>awplus(config-if)#lldp management-address <ipaddr></code>	Override the default LLDP management address advertised through this port if required. This must be an IPv4 address that is already configured on the device. To see the management address that will be advertised, use the show lldp local-info command on page 78.37.
36	<code>awplus(config-if)#lldp med-notifications</code>	By default, SNMP notifications are not transmitted. Enable LLDP-MED Topology Change Detected notifications for these ports if required. (SNMP LLDP traps (notifications) must also be enabled.) Default: LLDP-MED notifications disabled
37	<code>awplus(config-if)#lldp tlv-select {[<tlv>]...}</code>	Enable the transmission of one or more optional LLDP TLVs in LLDP-MED advertisements through this port as required. The mac-phy-config TLV is transmitted in LLDP-MED advertisements whether or not it is enabled by this command. Default: all mandatory TLVs are enabled.
38	<code>awplus(config-if)#lldp med-tlv-select {[capabilities] [network-policy] [location] [power-management-ext] [inventory-management]}</code> <code>awplus(config-if)#lldp med-tlv-select all</code> <code>awplus(config-if)#no lldp med-tlv-select {[capabilities] [network-policy] [location] [power-management-ext] [inventory-management]}</code> <code>awplus(config-if)#no lldp med-tlv-select all</code>	Enable or disable the transmission of optional LLDP-MED TLVs in LLDP-MED advertisements through these ports as required. Default: capabilities, network-policy, location, power-management are enabled.
39	<code>awplus(config-if)#exit</code>	Return to global configuration mode.
40	<code>awplus(config)#exit</code>	Return to privileged exec mode.
Clear data		
If necessary, you can clear either neighbor information or LLDP statistics for particular ports or all ports.		
41	<code>awplus#clear lldp table [interface <port-list>]</code>	Clear the information from the table of neighbor information.
42	<code>awplus#clear lldp statistics [interface <port-list>]</code>	Clear LLDP statistics (packet and event counters).

Configure Authentication for Voice VLAN

Use the following procedure with LLDP-MED and Voice VLAN to configure 802.1X port authentication and dynamic VLAN assignment using the local RADIUS server on the switch to which the voice endpoint devices are connected.

This procedure assumes that you have already:

- configured Voice VLAN and LLDP-MED using the procedure in Table 77-5 on page 77.14
- set `switchport voice vlan` to dynamic in the above procedure

This procedure configures the local RADIUS server. If your configuration uses one or more remote RADIUS servers instead, set the IP addresses of the remote RADIUS servers using the `radius-server host` command (Step 3 on page 18), and skip all the steps that configure the local RADIUS server (Step 3 on page 18 to Step 14 on page 19).

Table 77-6: Configuration procedure for Voice VLAN with RADIUS authentication and dynamic VLAN

Configure the IP address of the RADIUS host.	
1. <code>awplus#configure terminal</code>	Enter Global Configuration mode.
2. <code>awplus(config)#radius-server host 127.0.0.1 key <key-string></code>	Configure the IP address for the RADIUS server to be the local loopback address, so that RADIUS requests are sent to the local RADIUS server. Set the key that Network Access Servers (NAS) will need to use to get access to this RADIUS server. RADIUS server hosts configured using this command are included in the default RADIUS server group.
Enable the local RADIUS server.	
3. <code>awplus(config)#radius-server local</code>	Enter RADIUS Server Configuration mode.
4. <code>awplus(config-radsrv)#server enable</code>	Enable the local RADIUS server.
5. <code>awplus(config-radsrv)#nas 127.0.0.1 key <key-string></code>	Set the switch as a client device (Network Access Server), to allow it to send authentication requests to the local RADIUS server. Use the same loopback IP address and key as in the <code>radius-server host</code> command used in Step 2 on page 18.
Configure a local RADIUS user group for connected PCs.	
6. <code>awplus(config-radsrv)#group <user-group-name></code>	Create a local RADIUS server user group for PCs connected to the switch, and enter RADIUS Server Group Configuration mode.
7. <code>awplus(config-radsrv-group)#vlan {<vid> <vlan-name>}</code>	Set the VLAN ID for the user group. This will assign the untagged VLAN ID to authenticated ports for PCs connected to the switch. To create multiple user groups for PCs with different VLANs, repeat these two steps.
8. <code>awplus(config-radsrv-group)#exit</code>	Return to RADIUS Server Configuration mode.
Configure a local RADIUS user group for connected phones.	
9. <code>awplus(config-radsrv)#group <user-group-name></code>	Create a new local RADIUS server user group for phones connected to the switch, and enter RADIUS Server Group Configuration mode.

Table 77-6: Configuration procedure for Voice VLAN with RADIUS authentication and dynamic VLAN(Continued)

10.	<code>awplus(config-radsrv-group)#vlan {<vid> <vlan-name>}</code>	Configure the local RADIUS user group for connected phones to use the same VLAN as the PCs in Step 7 , so that the phones have access to the same untagged VLAN as the PCs.
11.	<code>awplus(config-radsrv-group)#egress-vlan-id <vid> tagged</code>	Set the Egress-VLAN ID attribute for the user group, and set it to send tagged frames. This will assign the tagged VLAN ID to authenticated ports for phones connected to the switch. To create multiple user groups for phones with different VLANs, repeat these two steps.
12.	<code>awplus(config-radsrv-group)#exit</code>	Return to RADIUS Server Configuration mode.
Add users to the local RADIUS server.		
13.	<code>awplus(config-radsrv)#user <radius-user-name> password <user-password> group <user-group></code>	Add RADIUS user names and passwords to the local RADIUS server for authenticating PCs and phones. Assign the corresponding RADIUS server user groups configured in Step 6 and Step 9 . See the user (RADIUS server) command on page 62.34 .
14.	<code>awplus(config-radsrv)#exit</code>	Return to Global Configuration mode.
Create VLANs.		
15.	<code>awplus(config)#vlan database</code>	Enter VLAN Database Configuration mode.
16.	<code>awplus(config-vlan)#vlan <vid-range></code>	Create the VLANs corresponding to the VLAN IDs that will be allocated to the authenticated ports, as configured in Step 7 , Step 10 , and Step 11 .
17.	<code>awplus(config-vlan)#exit</code>	Return to Global Configuration mode.
Configure 802.1X port authentication.		
18.	<code>awplus(config)#aaa authentication dot1x default group radius</code>	Enable 802.1X port authentication and set it to use the default group of RADIUS servers that contains all RADIUS server hosts configured using the radius-server host command—in this procedure, the default group consists of the local RADIUS server.
19.	<code>awplus(config)#interface <port-list></code>	Enter interface configuration mode for the ports that have users (PCs and phones) connected to them.
20.	<code>awplus(config-if)#dot1x port-control auto</code>	Enable 802.1X for port authentication on these ports.
21.	<code>awplus(config-if)#auth host-mode multi-suplicant</code>	Configure the ports to use multi-suplicant mode for authentication, so that the phone and PC can be dynamically allocated to different VLANs.
22.	<code>awplus(config-if)#auth dynamic-vlan-creation</code>	Configure the ports to accept dynamic VLAN allocation. In this procedure, the RADIUS server user groups for both the PCs and the phones use the same VLAN (Step 7 and Step 10), so the default rule (deny) allows them both the access they need to the port VLAN. For other options, see the auth dynamic-vlan-creation command on page 57.4 . Default: deny differently assigned VLAN IDs.
23.	<code>awplus(config-if)#exit</code>	Return to Global Configuration mode.
24.	<code>awplus(config)#exit</code>	Return to Privileged Exec mode.

Table 77-6: Configuration procedure for Voice VLAN with RADIUS authentication and dynamic VLAN(Continued)

Review the authentication configuration.

25. <code>awplus#show radius local-server group [<user-group-name>]</code> <code>awplus#show radius local-server nas [<ip-address>]</code> <code>awplus#show radius local-server user [<user-name>]</code>	Check the local RADIUS server configuration.
26. <code>awplus#show vlan {all brief dynamic static <1-4094>}</code>	Check the VLAN configuration.
27. <code>awplus#show dot1x [all]</code>	Check the 802.1X authentication configuration.

Chapter 78: LLDP Commands



Introduction.....	78.2
Command List.....	78.2
clear lldp statistics.....	78.2
clear lldp table.....	78.3
debug lldp.....	78.4
lldp faststart-count.....	78.5
lldp holdtime-multiplier.....	78.6
lldp management-address.....	78.7
lldp med-notifications.....	78.8
lldp med-tlv-select.....	78.9
lldp non-strict-med-tlv-order-check.....	78.11
lldp notification-interval.....	78.12
lldp notifications.....	78.13
lldp reinit.....	78.14
lldp run.....	78.15
lldp timer.....	78.16
lldp tlv-select.....	78.17
lldp transmit receive.....	78.19
lldp tx-delay.....	78.20
location civic-location configuration.....	78.21
location civic-location identifier.....	78.25
location civic-location-id.....	78.26
location coord-location configuration.....	78.27
location coord-location identifier.....	78.29
location coord-location-id.....	78.30
location elin-location.....	78.31
location elin-location-id.....	78.32
show debugging lldp.....	78.33
show lldp.....	78.34
show lldp interface.....	78.35
show lldp local-info.....	78.37
show lldp neighbors.....	78.41
show lldp neighbors detail.....	78.43
show lldp statistics.....	78.46
show lldp statistics interface.....	78.48
show location.....	78.50

Introduction

LLDP and LLDP-MED can be configured using the commands in this chapter, or by using SNMP with the LLDP-MIB and LLDP-EXT-DOT1-MIB (“Public MIBs” on page 76.58). The Voice VLAN feature can be configured using commands in [Chapter 17, VLAN Commands](#). For more information about LLDP, see [Chapter 77, LLDP Introduction](#).

LLDP can transmit a lot of data about the network. Typically, the network information gathered using LLDP is transferred to a Network Management System by SNMP. For security reasons, we recommend using SNMPv3 for this purpose ([Chapter 74, SNMP Introduction](#), [Chapter 75, SNMP Commands](#)).

LLDP operates over physical ports only. For example, it can be configured on switch ports that belong to static or dynamic channel groups, but not on the channel groups themselves.

Command List

This chapter contains an alphabetical list of commands used to configure LLDP.

clear lldp statistics

This command clears all LLDP statistics (packet and event counters) associated with specified ports. If no port list is supplied, LLDP statistics for all ports are cleared.

Syntax `clear lldp statistics [interface <port-list>]`

Parameter	Description
<port-list>	The ports for which the statistics are to be cleared.

Mode Privileged Exec

Examples To clear the LLDP statistics for ports 1.0.1 and 1.0.7, use the command:

```
awplus# clear lldp statistics interface port1.0.1,port1.0.7
```

To clear all LLDP statistics for all ports, use the command:

```
awplus# clear lldp statistics
```

Related Commands [show lldp statistics](#)
[show lldp statistics interface](#)

clear lldp table

This command clears the table of LLDP information received from neighbors through specified ports. If no port list is supplied, neighbor information is cleared for all ports.

Syntax `clear lldp table [interface <port-list>]`

Parameter	Description
<code><port-list></code>	The ports for which the neighbor information table is to be cleared.

Mode Privileged Exec

Examples To clear the table of neighbor information received through ports 1.0.1 and 1.0.7, use the command:

```
awplus# clear lldp table interface port1.0.1,port1.0.7
```

To clear the entire table of neighbor information received through all ports, use the command:

```
awplus# clear lldp table
```

Related Commands [show lldp neighbors](#)

debug lldp

This command enables specific LLDP debug for specified ports. When LLDP debugging is enabled, diagnostic messages are entered into the system log. If no port list is supplied, the specified debugging is enabled for all ports.

The no version of this command disables specific LLDP debug for specified ports. If no port list is supplied, the specified debugging is disabled for all ports.

Syntax

```
debug lldp {[rx][rxpkt][tx][txpkt]} [interface [<port-list>]]
debug lldp operation
no debug lldp {[rx][rxpkt][tx][txpkt]} [interface [<port-list>]]
no debug lldp operation
no debug lldp all
```

Parameter	Description
rx	LLDP receive debug
rxpkt	Raw LLDPDUs received in hex format
tx	LLDP transmit debug
txpkt	Raw Tx LLDPDUs transmitted in hex format
<port-list>	The ports for which debug is to be configured.
operation	Debug for LLDP internal operation on the switch.
all	Disables all LLDP debugging for all ports.

Default By default no debug is enabled for any ports.

Mode Privileged Exec

Examples To enable debugging of LLDP receive on ports 1.0.1 and 1.0.7, use the command:

```
awplus# debug lldp rx interface port1.0.1,port1.0.7
```

To enable debugging of LLDP transmit with packet dump on all ports, use the command:

```
awplus# debug lldp tx txpkt
```

To disable debugging of LLDP receive on ports 1.0.1 and 1.0.7, use the command:

```
awplus# no debug lldp rx interface port1.0.1,port1.0.7
```

To turn off all LLDP debugging on all ports, use the command:

```
awplus# no debug lldp all
```

Related Commands [show debugging lldp](#)
[show running-config lldp](#)
[terminal monitor](#)

lldp faststart-count

Use this command to set the fast start count for LLDP-MED. The fast start count determines how many fast start advertisements LLDP sends from a port when it starts sending LLDP-MED advertisements from the port, for instance, when it detects a new LLDP-MED capable device.

The no version of this command resets the LLDP-MED fast start count to the default (3).

Syntax `lldp faststart-count <1-10>`
`no lldp faststart-count`

Parameter	Description
lldp	Link Layer Discovery Protocol (LLDP)
faststart-count	Set the fast start count for LLDP-MED
<1-10>	The number of fast start advertisements to send.

Default The default fast start count is 3.

Mode Global Configuration

Examples To set the fast start count to 5, use the command:

```
awplus# configure terminal
awplus(config)# lldp faststart-count 5
```

To reset the fast start count to the default setting (3), use the command:

```
awplus# configure terminal
awplus(config)# no lldp faststart-count
```

Related Commands [show lldp](#)

lldp holdtime-multiplier

This command sets the holdtime multiplier value. The transmit interval is multiplied by the holdtime multiplier to give the Time To Live (TTL) value that is advertised to neighbors.

The no version of this command sets the multiplier back to its default value.

Syntax `lldp holdtime-multiplier <2-10>`
`no lldp holdtime-multiplier`

Parameter	Description
<2-10>	The multiplier factor

Default The default holdtime multiplier value is 4.

Mode Global Configuration

Usage The Time-To-Live defines the period for which the information advertised to the neighbor is valid. If the Time-To-Live expires before the neighbor receives another update of the information, then the neighbor discards the information from its database.

Examples To set the holdtime multiplier to 2, use the commands:

```
awplus# configure terminal
awplus(config)# lldp holdtime-multiplier 2
```

To set the holdtime multiplier back to its default value, use the commands:

```
awplus# configure terminal
awplus(config)# no lldp holdtime-multiplier 2
```

Related Commands [show lldp](#)

lldp management-address

This command sets the IPv4 address to be advertised to neighbors (in the Management Address TLV) via the specified ports. This address will override the default address for these ports.

The no version of this command clears the user-configured management IP address advertised to neighbors via the specified ports. The advertised address reverts to the default.

Syntax `lldp management-address <ipaddr>`
`no lldp management-address`

Parameter	Description
<ipaddr>	The IPv4 address to be advertised to neighbors, in dotted decimal format. This must be one of the IP addresses already configured on the device.

Default The loopback interface primary IPv4 address if set, else the primary IPv4 interface address of the lowest numbered VLAN the port belongs to, else the MAC address of the device's baseboard if no VLAN IP addresses are configured for the port.

Mode Interface Configuration

Usage To see the management address that will be advertised, use the [show lldp interface command on page 78.35](#) or [show lldp local-info command on page 78.37](#).

Examples To set the management address advertised by ports 1.0.1 and 1.0.7, to be 192.168.1.6, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1,port1.0.7
awplus(config-if)# lldp management-address 192.168.1.6
```

To clear the user-configured management address advertised by ports 1.0.1 and 1.0.7, and revert to using the default address, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1,port1.0.7
awplus(config-if)# no lldp management-address
```

Related Commands [show lldp interface](#)
[show lldp local-info](#)

lldp med-notifications

Use this command to enable LLDP to send LLDP-MED Topology Change Detected SNMP notifications relating to the specified ports. The switch sends an SNMP event notification when a new LLDP-MED compliant IP Telephony device is connected to or disconnected from a port on the switch.

Use the no version of this command to disable the sending of LLDP-MED Topology Change Detected notifications relating to the specified ports.

Syntax `lldp med-notifications`
`no lldp med-notifications`

Default The sending of LLDP-MED notifications is disabled by default.

Mode Interface Configuration

Examples To enable the sending of LLDP-MED Topology Change Detected notifications relating to ports 1.0.1 and 1.0.7, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1,port1.0.7
awplus(config-if)# lldp med-notifications
```

To disable the sending of LLDP-MED notifications relating to ports 1.0.1 and 1.0.7, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1,port1.0.7
awplus(config-if)# no lldp med-notifications
```

Related Commands [lldp notification-interval](#)
[lldp notifications](#)
[snmp-server enable trap](#)
[show lldp interface](#)

lldp med-tlv-select

Use this command to enable LLDP-MED Organizationally Specific TLVs for transmission in LLDP advertisements via the specified ports. The LLDP-MED Capabilities TLV must be enabled before any of the other LLDP-MED Organizationally Specific TLVs are enabled.

Use the no version of this command to disable the specified LLDP-MED Organizationally Specific TLVs for transmission in LLDP advertisements via these ports. In order to disable the LLDP-MED Capabilities TLV, you must also disable the rest of these TLVs. Disabling all these TLVs disables LLDP-MED advertisements.

Syntax

```
lldp med-tlv-select {[capabilities] [network-policy] [location]
                    [power-management-ext] [inventory-management]}

lldp med-tlv-select all

no lldp med-tlv-select {[capabilities] [network-policy] [location]
                       [power-management-ext] [inventory-management]}

no lldp med-tlv-select all
```

Parameter	Description
capabilities	LLDP-MED Capabilities TLV. When this is enabled, the MAC/PHY Configuration/Status TLV from IEEE 802.3 Organizationally Specific TLVs is also automatically included in LLDP-MED advertisements, whether or not it has been explicitly enabled by the lldp tlv-select command.
network-policy	Network Policy TLV. This TLV is transmitted if Voice VLAN parameters have been configured using the commands: ■ switchport voice dscp ■ switchport voice vlan ■ switchport voice vlan priority
location	Location Identification TLV. This TLV is transmitted if location information has been configured using the commands: ■ location elin-location-id ■ location civic-location identifier ■ location civic-location configuration ■ location coord-location identifier ■ location coord-location configuration ■ location elin-location
power-management-ext	Extended Power-via-MDI TLV. This TLV is transmitted if the port is PoE capable, and PoE is enabled (power-inline enable command on page 23.7).
inventory-management	Inventory Management TLV Set, including the following TLVs: ■ Hardware Revision ■ Firmware Revision ■ Software Revision ■ Serial Number ■ Manufacturer Name ■ Model Name ■ Asset ID

Parameter	Description
all	All LLDP-MED Organizationally Specific TLVs.

Default By default LLDP-MED Capabilities, Network Policy, Location Identification and Extended Power-via-MDI TLVs are enabled. Therefore, if LLDP is enabled using the [lldp run](#) command, by default LLDP-MED advertisements are transmitted on ports that detect LLDP-MED neighbors connected to them.

Mode Interface Configuration

Usage LLDP-MED TLVs are only sent in advertisements via a port if there is an LLDP-MED-capable device connected to it. To see whether there are LLDP-MED capable devices connected to the ports, use the [show lldp neighbors](#) command on [page 78.41](#).

Examples To enable inclusion of the Inventory TLV Set in advertisements transmitted via ports 1.0.1 and 1.0.7, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1,port1.0.7
awplus(config-if)# lldp med-tlv-select inventory-management
```

To exclude the Inventory TLV Set in advertisements transmitted via ports 1.0.1 and 1.0.7, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1,port1.0.7
awplus(config-if)# no lldp med-tlv-select inventory-management
```

To disable LLDP-MED advertisements transmitted via ports 1.0.1 and 1.0.7, disable all these TLVs using the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1,port1.0.7
awplus(config-if)# no lldp med-tlv-select all
```

Related Commands

- [lldp tlv-select](#)
- [location elin-location-id](#)
- [location civic-location identifier](#)
- [location civic-location configuration](#)
- [location coord-location identifier](#)
- [location coord-location configuration](#)
- [location elin-location](#)
- [show lldp interface](#)
- [switchport voice dscp](#)
- [switchport voice vlan](#)
- [switchport voice vlan priority](#)

lldp non-strict-med-tlv-order-check

Use this command to enable non-strict order checking for LLDP-MED advertisements it receives. That is, use this command to enable LLDP to receive and store TLVs from LLDP-MED advertisements even if they do not use standard TLV order.

Use the no version of this command to disable non-strict order checking for LLDP-MED advertisements, that is, to set strict TLV order checking, so that LLDP discards any LLDP-MED TLVs that occur before the LLDP-MED Capabilities TLV in an advertisement.

Syntax `lldp non-strict-med-tlv-order-check`
 `no lldp non-strict-med-tlv-order-check`

Default By default TLV non-strict order checking for LLDP-MED advertisements is disabled. That is, strict order checking is applied to LLDP-MED advertisements, according to ANSI/TIA-1057, and LLDP-MED TLVs in non-standard order are discarded.

Mode Global Configuration

Usage The ANSI/TIA-1057 specifies standard order for TLVs in LLDP-MED advertisements, and specifies that if LLDP receives LLDP advertisements with non-standard LLDP-MED TLV order, the TLVs in non-standard order should be discarded. This implementation of LLDP-MED follows the standard: it transmits TLVs in the standard order, and by default discards LLDP-MED TLVs that occur before the LLDP-MED Capabilities TLV in an advertisement. However, some implementations of LLDP transmit LLDP-MED advertisements with non-standard TLV order. To receive and store the data from these non-standard advertisements, enable non-strict order checking for LLDP-MED advertisements using this command.

Examples To enable strict TLV order checking, use the commands:

```
awplus# configure terminal
awplus(config)# lldp tlv-order-check
```

To disable strict TLV order checking, use the commands:

```
awplus# configure terminal
awplus(config)# no lldp tlv-order-check
```

Related Commands [show running-config lldp](#)

lldp notification-interval

This command sets the notification interval. This is the minimum interval between LLDP SNMP notifications (traps) of each kind (LLDP Remote Tables Change Notification and LLDP-MED Topology Change Notification).

The no version of this command sets the notification interval back to its default value.

Syntax `lldp notification-interval <5-3600>`
`no lldp notification-interval`

Parameter	Description
<5-3600>	The interval in seconds

Default The default notification interval is 5 seconds.

Mode Global Configuration

Examples To set the notification interval to 20 seconds, use the commands:

```
awplus# configure terminal
awplus(config)# lldp notification-interval 20
```

To set the notification interval back to its default value, use the commands:

```
awplus# configure terminal
awplus(config)# no lldp notification-interval
```

Related Commands [lldp notifications](#)
[show lldp](#)

lldp notifications

This command enables the sending of LLDP SNMP notifications (traps) relating to specified ports.

The no version of this command disables the sending of LLDP SNMP notifications for specified ports.

Syntax `lldp notifications`
 `no lldp notifications`

Default The sending of LLDP SNMP notifications is disabled by default.

Mode Interface Configuration

Examples To enable sending of LLDP SNMP notifications for ports 1.0.1 and 1.0.7, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1,port1.0.7
awplus(config-if)# lldp notifications
```

To disable sending of LLDP SNMP notifications for ports 1.0.1 and 1.0.7, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1,port1.0.7
awplus(config-if)# no lldp notifications
```

Related Commands `lldp notification-interval`
 `show lldp interface`
 `snmp-server enable trap`

lldp reinit

This command sets the value of the reinitialization delay. This is the minimum time after disabling LLDP on a port before it can reinitialize.

The no version of this command sets the reinitialization delay back to its default setting.

Syntax `lldp reinit <1-10>`

`no lldp reinit`

Parameter	Description
<1-10>	The delay in seconds

Default The default reinitialization delay is 2 seconds.

Mode Global Configuration

Examples To set the reinitialization delay to 3 seconds, use the commands:

```
awplus# configure terminal
awplus(config)# lldp reinit 3
```

To set the reinitialization delay back to its default value, use the commands:

```
awplus# configure terminal
awplus(config)# no lldp reinit
```

Related Commands [show lldp](#)

lldp run

This command enables the operation of LLDP on the device.

The no version of this command disables the operation of LLDP on the device. The LLDP configuration remains unchanged.

Syntax lldp run
 no lldp run

Default LLDP is disabled by default.

Mode Global Configuration

Examples To enable LLDP operation, use the commands:

```
awplus# configure terminal
awplus(config)# lldp run
```

To disable LLDP operation, use the commands:

```
awplus# configure terminal
awplus(config)# no lldp run
```

Related Commands [show lldp](#)

lldp timer

This command sets the value of the transmit interval. This is the interval between regular transmissions of LLDP advertisements.

The no version of this command sets the transmit interval back to its default value.

Syntax `lldp timer <5-32768>`

`no lldp timer`

Parameter	Description
<5-32768>	The transmit interval in seconds. The transmit interval must be at least four times the transmission delay timer (lldp tx-delay command on page 78.20).

Default The default transmit interval is 30 seconds.

Mode Global Configuration

Examples To set the transmit interval to 90 seconds, use the commands:

```
awplus# configure terminal
awplus(config)# lldp timer 90
```

To set the transmit interval back to its default value, use the commands:

```
awplus# configure terminal
awplus(config)# no lldp timer
```

Related Commands [lldp tx-delay](#)
[show lldp](#)

lldp tlv-select

This command enables one or more optional TLVs, or all TLVs, for transmission in LLDP advertisements via the specified ports. The TLVs can be specified in any order; they are placed in LLDP frames in a fixed order (as described in IEEE 802.1AB). The mandatory TLVs (Chassis ID, Port ID, Time To Live, End of LLDPDU) are always included in LLDP advertisements.

In LLDP-MED advertisements the MAC/PHY Configuration/Status TLV will be always be included regardless of whether it is selected by this command.

The no version of this command disables the specified optional TLVs, or all optional TLVs, for transmission in LLDP advertisements via the specified ports.

Syntax

```
lldp tlv-select {[<tlv>]...}

lldp tlv-select all

no lldp tlv-select {[<tlv>]...}

no lldp tlv-select all
```

Parameter	Description
<tlv>	The TLV to transmit in LLDP advertisements. One of these keywords: ■ port-description (specified by the description (interface) command on page 12.2) ■ system-name (specified by the hostname command on page 8.11) ■ system-description ■ system-capabilities ■ management-address ■ port-vlan ■ port-and-protocol-vlans ■ vlan-names ■ protocol-ids ■ mac-phy-config ■ power-management (Power Via MDI TLV) ■ link-aggregation ■ max-frame-size
all	all TLVs

Default By default no optional TLVs are included in LLDP advertisements. The MAC/PHY Configuration/Status TLV (mac-phy-config) is included in LLDP-MED advertisements whether or not it is selected by this command.

Mode Interface Configuration

Examples To include the management-address and system-name TLVs in advertisements transmitted via ports 1.0.1 and 1.0.7, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1,port1.0.7
awplus(config-if)# lldp tlv-select management-address system-name
```

To include all optional TLVs in advertisements transmitted via ports 1.0.1 and 1.0.7, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1,port1.0.7
awplus(config-if)# lldp tlv-select all
```

To exclude the management-address and system-name TLVs from advertisements transmitted via ports 1.0.1 and 1.0.7, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1,port1.0.7
awplus(config-if)# no lldp tlv-select management-address system-name
```

To exclude all optional TLVs from advertisements transmitted via ports 1.0.1 and 1.0.7, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1,port1.0.7
awplus(config-if)# no lldp tlv-select all
```

Related Commands

- description (interface)
- hostname
- lldp med-tlv-select
- show lldp interface
- show lldp local-info

lldp transmit receive

This command enables transmission and/or reception of LLDP advertisements to or from neighbors through the specified ports.

The no version of this command disables transmission and/or reception of LLDP advertisements through specified ports.

Syntax `lldp {[transmit][receive]}`
`no lldp {[transmit][receive]}`

Parameter	Description
<code>transmit</code>	Enable or disable transmission of LLDP advertisements via this port or ports
<code>receive</code>	Enable or disable reception of LLDP advertisements via this port or ports

Default LLDP advertisement transmission and reception are enabled on all ports by default.

Mode Interface Configuration

Examples To enable transmission of LLDP advertisements on ports 1.0.1 and 1.0.7, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1,port1.0.7
awplus(config-if)# lldp transmit
```

To enable LLDP advertisement transmission and reception on ports 1.0.1 and 1.0.7, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1,port1.0.7
awplus(config-if)# lldp transmit receive
```

To disable LLDP advertisement transmission and reception on ports 1.0.1 and 1.0.7, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1,port1.0.7
awplus(config-if)# no lldp transmit receive
```

Related Commands [show lldp interface](#)

lldp tx-delay

This command sets the value of the transmission delay timer. This is the minimum time interval between transmitting LLDP advertisements due to a change in LLDP local information.

The no version of this command sets the transmission delay timer back to its default setting.

Syntax `lldp tx-delay <1-8192>`

`no lldp tx-delay`

Parameter	Description
<1-8192>	The transmission delay in seconds. The transmission delay cannot be greater than a quarter of the transmit interval (lldp timer command on page 78.16).

Default The default transmission delay timer is 2 seconds.

Mode Global Configuration

Examples To set the transmission delay timer to 12 seconds, use the commands:

```
awplus# configure terminal
awplus(config)# lldp tx-delay 12
```

To set the transmission delay timer back to its default value, use the commands:

```
awplus# configure terminal
awplus(config)# no lldp tx-delay
```

Related Commands [lldp timer](#)
[show lldp](#)

location civic-location configuration

Use these commands to configure a civic address location. The country parameter must be specified first, and at least one of the other parameters must be configured before the location can be assigned to a port.

Use the no versions of this command to delete civic address parameters from the location.

Syntax

```
country <country>
state <state>
no state
county <county>
no county
city <city>
no city
division <division>
no division
neighborhood <neighborhood>
no neighborhood
street-group <street-group>
no street-group
leading-street-direction <leading-street-direction>
no leading-street-direction
trailing-street-suffix <trailing-street-suffix>
no trailing-street-suffix
street-suffix <street-suffix>
no street-suffix
house-number <house-number>
no house-number
house-number-suffix <house-number-suffix>
no house-number-suffix
landmark <landmark>
no landmark
additional-information <additional-information>
no additional-information
name <name>
no name
postalcode <postalcode>
no postalcode
```

```

building <building>
no building
unit <unit>
no unit
floor <floor>
no floor
room <room>
no room
place-type <place-type>
no place-type
postal-community-name <postal-community-name>
no postal-community-name
post-office-box <post-office-box>
no post-office-box
additional-code <additional-code>
no additional-code
seat <seat>
no seat
primary-road-name <primary-road-name>
no primary-road-name
road-section <road-section>
no road-section
branch-road-name <branch-road-name>
no branch-road-name
sub-branch-road-name <sub-branch-road-name>
no sub-branch-road-name
street-name-pre-modifier <street-name-pre-modifier>
no street-name-pre-modifier
streetname-post-modifier <streetname-post-modifier>
no streetname-post-modifier

```

Parameter	Description
<country>	Upper-case two-letter country code, as specified in ISO 3166.
<state>	State (Civic Address (CA) Type 1): national subdivisions (state, canton, region)
<county>	County (CA Type 2): County, parish, gun (JP), district (IN)

Parameter	Description
<code><city></code>	City (CA Type 3): city, township, shi (JP)
<code><division></code>	City division (CA Type 4): City division, borough, city district, ward, chou (JP)
<code><neighborhood></code>	Neighborhood (CA Type 5): neighborhood, block
<code><street-group></code>	Street group (CA Type 6): group of streets below the neighborhood level
<code><leading-street-direction></code>	Leading street direction (CA Type 16)
<code><trailing-street-suffix></code>	Trailing street suffix (CA Type 17)
<code><street-suffix></code>	Street suffix (CA Type 18): street suffix or type
<code><house-number></code>	House number (CA Type 19)
<code><house-number-suffix></code>	House number suffix (CA Type 20)
<code><landmark></code>	Landmark or vanity address (CA Type 21)
<code><additional-information></code>	Additional location information (CA Type 22)
<code><name></code>	Name (CA Type 23): residence and office occupant
<code><postal-code></code>	Postal/zip code (CA Type 24)
<code><building></code>	Building (CA Type 25): structure
<code><unit></code>	Unit (CA Type 26): apartment, suite
<code><floor></code>	Floor (CA Type 27)
<code><room></code>	Room (CA Type 28)
<code><place-type></code>	Type of place (CA Type 29)
<code><postal-community-name></code>	Postal community name (CA Type 30)
<code><post-office-box></code>	Post office box (P.O. Box) (CA Type 31)
<code><additional-code></code>	Additional code (CA Type 32)
<code><seat></code>	Seat (CA Type 33): seat (desk, cubicle, workstation)
<code><primary-road-name></code>	Primary road name (CA Type 34)
<code><road-section></code>	Road section (CA Type 35)
<code><branch-road-name></code>	Branch road name (CA Type 36)
<code><sub-branch-road-name></code>	Sub-branch road name (CA Type 37)
<code><street-name-pre-modifier></code>	Street name pre-modifier (CA Type 38)
<code><street-name-post-modifier></code>	Street name post-modifier (CA Type 39)

Default By default no civic address location information is configured.

Mode Civic Address Location Configuration

Usage The country parameter must be configured before any other parameters can be configured; this creates the location. The country parameter cannot be deleted. One or more of the other parameters must be configured before the location can be assigned to a port. The country parameter must be entered as an upper-case two-letter country code, as specified in *ISO 3166*. All other parameters are entered as alpha-numeric strings. Do not configure all the civic address parameters (this would generate TLVs that are too long). Configure a subset of these parameters—enough to consistently and precisely identify the location of the device. If the location is to be used for Emergency Call Service (ECS), the particular ECS application may have guidelines for configuring the civic address location. For more information about civic address format, see “[LLDP-MED: Location Identification TLV](#)” on page 77.7.

To specify the civic address location, use the [location civic-location identifier command on page 78.25](#). To delete the civic address location, use the no version of the [location civic-location identifier](#) command. To assign the civic address location to particular ports, so that it can be advertised in TLVs from those ports, use the command [location civic-location-id command on page 78.26](#).

Examples To configure civic address location 1 with location "27 Nazareth Avenue, Christchurch, New Zealand" in civic-address format, use the commands:

```
awplus# configure terminal
awplus(config)# location civic-location identifier 1
awplus(config-civic)# country NZ
awplus(config-civic)# city Christchurch
awplus(config-civic)# primary-road-name Nazareth
awplus(config-civic)# street-suffix Avenue
awplus(config-civic)# house-number 27
```

Related Commands [location civic-location-id](#)
[location civic-location identifier](#)
[show lldp local-info](#)
[show location](#)

location civic-location identifier

Use this command to enter the Civic Address Location Configuration mode to configure the specified location.

Use the no version of this command to delete a civic address location. This also removes the location from any ports it has been assigned to.

Syntax `location civic-location identifier <civic-loc-id>`
 `no location civic-location identifier <civic-loc-id>`

Parameter	Description
<code><civic-loc-id></code>	A unique civic address location ID, in the range 1 to 4095.

Default By default there are no civic address locations.

Mode Global Configuration

Usage To configure the location information for this civic address location identifier, use the [location civic-location configuration command on page 78.21](#). To associate this civic location identifier with particular ports, use the [location elin-location-id command on page 78.32](#).

Up to 400 locations can be configured on the switch for each type of location information, up to a total of 1200 locations.

Examples To enter Civic Address Location Configuration mode for the civic address location with ID 1, use the commands:

```
awplus# configure terminal
awplus(config)# location civic-location identifier 1
awplus(config-civic)#
```

To delete the civic address location with ID 1, use the commands:

```
awplus# configure terminal
awplus(config)# no location civic-location identifier 1
```

Related Commands [location civic-location-id](#)
 [location civic-location configuration](#)
 [show location](#)
 [show running-config lldp](#)

location civic-location-id

Use this command to assign a civic address location to the ports. The civic address location must already exist. This replaces any previous assignment of civic address location for the ports. Up to one location of each type can be assigned to a port.

Use the no version of this command to remove a location identifier from the ports.

Syntax `location civic-location-id <civic-loc-id>`
`no location civic-location-id [<civic-loc-id>]`

Parameter	Description
<code><civic-loc-id></code>	Civic address location ID, in the range 1 to 4095.

Default By default no civic address location is assigned to ports.

Mode Interface Configuration

Usage The civic address location associated with a port can be transmitted in Location Identification TLVs via the port.

Before using this command, create the location using the following commands:

- [location civic-location identifier command on page 78.25](#)
- [location civic-location configuration command on page 78.21](#)

If a civic-address location is deleted using the no version of the [location civic-location identifier](#) command, it is automatically removed from all ports.

Examples To assign the civic address location 1 to port1.0.1, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1
awplus(config-if)# location civic-location-id 1
```

To remove a civic address location from port1.0.1, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1
awplus(config-if)# no location civic-location-id
```

Related Commands [lldp med-tlv-select](#)
[location civic-location identifier](#)
[location civic-location configuration](#)
[show location](#)

location coord-location configuration

Use this command to configure a coordinate-based location. All parameters must be configured before assigning this location identifier to a port.

Syntax

```
latitude <latitude>
lat-resolution <lat-resolution>
longitude <longitude>
long-resolution <long-resolution>
altitude <altitude> {meters|floor}
alt-resolution <alt-resolution>
datum {wgs84|nad83-navd|nad83-mllw}
```

Parameter	Description
<lat-resolution>	Latitude resolution, as a number of valid bits, in the range 0 to 34.
<latitude>	Latitude value in degrees in the range -90.0 to 90.0
<long-resolution>	Longitude resolution, as a number of valid bits, in the range 0 to 34.
<longitude>	Longitude value in degrees, in the range -180.0 to 180.0.
<alt-resolution>	Altitude resolution, as a number of valid bits, in the range 0 to 30. A resolution of 0 can be used to indicate an unknown value.
<altitude>	Altitude value, in meters or floors.
meters	The altitude value is in meters.
floors	The altitude value is in floors.
datum	The geodetic system (or datum) that the specified coordinate values are based on.
wgs84	World Geodetic System 1984.
nad83-navd	North American Datum 1983 - North American Vertical Datum.
nad83-mllw	North American Datum 1983 - Mean Lower Low Water vertical datum.

Default By default no coordinate location information is configured.

Mode Coordinate Configuration

Usage Latitude and longitude values are always stored internally, and advertised in the Location Identification TLV, as 34-bit fixed-point binary numbers, with a 25-bit fractional part, irrespective of the number of digits entered by the user. Likewise altitude is stored as a 30-bit fixed point binary number, with an 8-bit fractional part. Because the user-entered decimal values are stored as fixed point binary numbers, they cannot always be represented exactly—the stored binary number is converted to a decimal number for display in the output of the

[show location command on page 78.50](#). For example, a user-entered latitude value of "2.77" degrees is displayed as "2.7699999809265136718750000".

The lat-resolution, long-resolution, and alt-resolution parameters allow the user to specify the resolution of each coordinate element as the number of valid bits in the internally-stored binary representation of the value. These resolution values can be used by emergency services to define a search area.

To specify the coordinate identifier, use the [location coord-location identifier command on page 78.29](#). To remove coordinate information, delete the coordinate location by using the no version of that command. To associate the coordinate location with particular ports, so that it can be advertised in TLVs from those ports, use the [location elin-location-id command on page 78.32](#).

Example To configure the location for the White House in Washington DC, which has the coordinates based on the WGS84 datum of 38.89868 degrees North (with 22 bit resolution), 77.03723 degrees West (with 22 bit resolution), and 15 meters height (with 9 bit resolution), use the commands:

```
awplus# configure terminal
awplus(config)# location coord-location identifier 1
awplus(config-coord)# la-resolution 22
awplus(config-coord)# latitude 38.89868
awplus(config-coord)# lo-resolution 22
awplus(config-coord)# longitude -77.03723
awplus(config-coord)# alt-resolution 9
awplus(config-coord)# altitude 15 meters
awplus(config-coord)# datum wgs84
```

Related Commands [location coord-location-id](#)
[location coord-location identifier](#)
[show lldp local-info](#)
[show location](#)

location coord-location identifier

Use this command to enter Coordinate Location Configuration mode for this coordinate location.

Use the no version of this command to delete a coordinate location. This also removes the location from any ports it has been assigned to.

Syntax location coord-location identifier *<coord-loc-id>*
no location coord-location identifier *<coord-loc-id>*

Parameter	Description
<i><coord-loc-id></i>	A unique coordinate location identifier, in the range 1 to 4095.

Default By default there are no coordinate locations.

Mode Global Configuration

Usage Up to 400 locations can be configured on the switch for each type of location information, up to a total of 1200 locations.

To configure this coordinate location, use the [location coord-location configuration command on page 78.27](#). To associate this coordinate location with particular ports, so that it can be advertised in TLVs from those ports, use the [location coord-location-id command on page 78.30](#).

Examples To enter Coordinate Location Configuration mode to configure the coordinate location with ID 1, use the commands:

```
awplus# configure terminal
awplus(config)# location coord-location identifier 1
awplus(config-coord)#
```

To delete coordinate location 1, use the commands:

```
awplus# configure terminal
awplus(config)# no location coord-location identifier 1
```

Related Commands [location coord-location-id](#)
[location coord-location configuration](#)
[show lldp local-info](#)
[show location](#)

location coord-location-id

Use this command to assign a coordinate location to the ports. The coordinate location must already exist. This replaces any previous assignment of coordinate location for the ports. Up to one location of each type can be assigned to a port.

Use the no version of this command to remove a location from the ports.

Syntax `location coord-location-id <coord-loc-id>`
`no location coord-location-id [<coord-loc-id>]`

Parameter	Description
<code><coord-loc-id></code>	Coordinate location ID, in the range 1 to 4095.

Default By default no coordinate location is assigned to ports.

Mode Interface Configuration

Usage The coordinate location associated with a port can be transmitted in Location Identification TLVs via the port.

Before using this command, configure the location using the following commands:

- [location coord-location identifier command on page 78.29](#)
- [location coord-location configuration command on page 78.27](#)

If a coordinate location is deleted using the no version of the [location coord-location identifier](#) command, it is automatically removed from all ports.

Examples To assign coordinate location 1 to port1.0.1, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1
awplus(config-if)# location coord-location-id 1
```

To remove a coordinate location from port1.0.1, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1
awplus(config-if)# no location coord-location-id
```

Related Commands [lldp med-tlv-select](#)
[location coord-location identifier](#)
[location coord-location configuration](#)
[show location](#)

location elin-location

Use this command to create or modify an ELIN location.

Use the no version of this command to delete an ELIN location, and remove it from any ports it has been assigned to.

Syntax `location elin-location <elin> identifier <elin-loc-id>`
`no location elin-location identifier <elin-loc-id>`

Parameter	Description
<elin>	Emergency Location Identification Number (ELIN) for Emergency Call Service (ECS), in the range 10 to 25 digits long. In North America, ELINs are typically 10 digits long.
<elin-loc-id>	A unique ELIN location identifier, in the range 1 to 4095.

Default By default there are no ELIN location identifiers.

Mode Global Configuration

Usage Up to 400 locations can be configured on the switch for each type of location information, up to a total of 1200 locations.

To assign this ELIN location to particular ports, so that it can be advertised in TLVs from those ports, use the [location elin-location-id command on page 78.32](#).

Examples To create a new ELIN location with ID 1, and configure it with ELIN "1234567890", use the commands:

```
awplus# configure terminal
awplus(config)# location elin-location 1234567890 identifier 1
```

To delete existing ELIN location with ID 1, use the commands:

```
awplus# configure terminal
awplus(config)# no location elin-location identifier 1
```

Related Commands [location elin-location-id](#)
[show lldp local-info](#)
[show location](#)

location elin-location-id

Use this command to assign an ELIN location to the ports. The ELIN location must already exist. This replaces any previous assignment of ELIN location for the ports. Up to one location of each type can be assigned to a port.

Use the no version of this command to remove a location identifier from the ports.

Syntax `location elin-location-id <elin-loc-id>`
 `no location elin-location-id [<elin-loc-id>]`

Parameter	Description
<code><elin-loc-id></code>	ELIN location identifier, in the range 1 to 4095.

Default By default no ELIN location is assigned to ports.

Mode Interface Configuration

Usage An ELIN location associated with a port can be transmitted in Location Identification TLVs via the port.

Before using this command, configure the location using the [location elin-location command on page 78.31](#).

If an ELIN location is deleted using the no version of one of the [location elin-location](#) command, it is automatically removed from all ports.

Examples To assign ELIN location 1 to port1.0.1, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1
awplus(config-if)# location elin-location-id 1
```

To remove an ELIN location from port1.0.1, use the commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1
awplus(config-if)# no location elin-location-id
```

Related Commands [lldp med-tlv-select](#)
 [location elin-location](#)
 [show location](#)

show debugging lldp

This command displays LLDP debug settings for specified ports. If no port list is supplied, LLDP debug settings for all ports are displayed.

Syntax `show debugging lldp [interface <port-list>]`

Parameter	Description
<port-list>	The ports for which the LLDP debug settings are shown

Mode Privileged Exec

Examples To display LLDP debug settings for ports 1.0.1 to 1.0.9, use the command:

```
awplus# show debugging lldp interface port1.0.1-1.0.9
```

```
LLDP Debug settings:
Debugging for LLDP internal operation is on
Port      Rx      RxPkt   Tx      TxPkt
-----
1.0.1     Yes     Yes     No      No
1.0.2     Yes     No      No      No
1.0.3     No      No      No      No
1.0.4     Yes     Yes     Yes     No
1.0.5     Yes     No      Yes     No
1.0.6     No      No      Yes     No
1.0.7     Yes     Yes     Yes     Yes
1.0.8     Yes     No      Yes     Yes
1.0.9     No      No      Yes     Yes
```

To display LLDP debug settings for all ports, use the command:

```
awplus# show debugging lldp
```

Table 78-1: Parameters in the output from the show debugging lldp command

Parameter	Meaning
Port	Port name.
Rx	Whether debugging of LLDP receive is enabled on the port.
RxPkt	Whether debugging of LLDP receive packet dump is enabled on the port.
Rx	Whether debugging of LLDP transmit is enabled on the port.
RxPkt	Whether debugging of LLDP transmit packet dump is enabled on the port.

Related Commands `debug lldp`

show lldp

This command displays LLDP status and global configuration settings.

Syntax `show lldp`

Mode Privileged Exec

Examples To display LLDP status and global configuration settings, use the command:

```
awplus# show lldp
```

Figure 78-1: Example output from the show lldp command

```
awplus# show lldp

LLDP Global Configuration:                [Default Values]
LLDP Status ..... Enabled                [Disabled]
Notification Interval ..... 5 secs       [5]
Tx Timer Interval ..... 30 secs          [30]
Hold-time Multiplier ..... 4             [4]
(Computed TTL value ..... 120 secs)
Reinitialization Delay .... 2 secs       [2]
Tx Delay ..... 2 secs                   [2]
Fast Start Count ..... 5                [3]

LLDP Global Status:
Total Neighbor Count ..... 47
Neighbors table last updated 0 hrs 0 mins 43 secs ago
```

Output

Table 78-2: Parameters in the output from the show lldp command

Output Parameter	Meaning
LLDP Status	Whether LLDP is enabled. Default is disabled.
Notification Interval	Minimum interval between LLDP notifications.
Tx Timer Interval	Transmit interval between regular transmissions of LLDP advertisements.
Hold-time Multiplier	The holdtime multiplier. The transmit interval is multiplied by the holdtime multiplier to give the Time To Live (TTL) value that is advertised to neighbors.
Reinitialization Delay	The reinitialization delay. This is the minimum time after disabling LLDP transmit on a port before it can reinitialize again.
Tx Delay	The transmission delay. This is the minimum time interval between transmitting advertisements due to a change in LLDP local information.
Fast Start Count	The number of times fast start advertisements are sent for LLDP-MED.
Total Neighbor Count	Number of LLDP neighbors discovered on all ports.
Neighbors table last updated	The time since the LLDP neighbor table was last updated.

Related Commands `show lldp interface`
`show running-config lldp`

show lldp interface

This command displays LLDP configuration settings for specified ports. If no port list is specified, LLDP configuration for all ports is displayed.

Syntax `show lldp interface [<port-list>]`

Parameter	Description
<port-list>	The ports for which the LLDP configuration settings are to be shown.

Mode Privileged Exec

Examples To display LLDP configuration settings for ports 1.0.1 to 1.0.8, use the command:

```
awplus# show lldp interface port1.0.1-1.0.8
```

To display LLDP configuration settings for all ports, use the command:

```
awplus# show lldp interface
```

Figure 78-2: Example output from the show lldp interface command

```
awplus# show lldp interface port1.0.1-1.0.8
LLDP Port Status and Configuration:

* = LLDP is inactive on this port because it is a mirror analyser port
Notification Abbreviations:
  RC = LLDP Remote Tables Change      TC = LLDP-MED Topology Change
TLV Abbreviations:
  Base: Pd = Port Description          Sn = System Name
        Sd = System Description       Sc = System Capabilities
        Ma = Management Address
  802.1: Pv = Port VLAN ID             Pp = Port And Protocol VLAN ID
        Vn = VLAN Name                Pi = Protocol Identity
  802.3: Mp = MAC/PHY Config/Status    Po = Power Via MDI (PoE)
        La = Link Aggregation         Mf = Maximum Frame Size
  MED:  Mc = LLDP-MED Capabilities     Np = Network Policy
        Lo = Location Identification  Pe = Extended PoE      In = Inventory

Optional TLVs Enabled for Tx
Port    Rx/Tx  Notif  Management Addr  Base    802.1    802.3    MED
-----
1.0.1   Rx Tx   RC --   192.168.100.123 PdSnSdScMa -----
*1.0.2   -- Tx   RC --   192.168.100.123 PdSnSdScMa -----
1.0.3   Rx Tx   RC --   192.168.100.123 Pd--SdScMa PvPpVnPi -----
1.0.4   -- --   RC --   192.168.100.123 PdSnSd--Ma -----
1.0.5   Rx Tx   RC TC   192.168.100.123 PdSnSdScMa PvPpVnPi -----
1.0.6   Rx Tx   RC TC   192.168.100.123 Pd----ScMa -----
1.0.7   Rx Tx   -- TC   192.168.100.123 PdSnSdScMa PvPpVnPi MpPoLaMf McNpLoPeIn
1.0.8   Rx Tx   -- TC   192.168.1.1   PdSn--ScMa PvPpVnPi -----
```

Table 78-3: Parameters in the output of the show lldp interface command

Output Parameter	Meaning
Port	Port name.
Rx	Whether reception of LLDP advertisements is enabled on the port.
Tx	Whether transmission of LLDP advertisements is enabled on the port.
Notif	Whether sending SNMP notification for LLDP is enabled on the port. ■ RM = Remote Tables Change Notification ■ TP = LLDP-MED Topology Change Notification
Management Addr	Management address advertised to neighbors.
Base TLVs Enabled for Tx	List of optional Base TLVs enabled for transmission: ■ Pd = Port Description ■ Sn = System Name ■ Sd = System Description ■ Sc = System Capabilities ■ Ma = Management Address
802.1 TLVs Enabled for Tx	List of optional 802.1 TLVs enabled for transmission: ■ Pv = Port VLAN ID ■ Pp = Port And Protocol VLAN ID ■ Vn = VLAN Name ■ Pi = Protocol Identity
802.3 TLVs Enabled for Tx	List of optional 802.3 TLVs enabled for transmission: ■ Mp = MAC/PHY Configuration/Status ■ Po = Power Via MDI (PoE) ■ La = Link Aggregation ■ Mf = Maximum Frame Size
MED TLVs Enabled for Tx	List of optional LLDP-MED TLVs enabled for transmission: ■ Mc = LLDP-MED Capabilities ■ Np = Network Policy ■ Lo = Location Information, ■ Pe = Extended Power-Via-MDI ■ In = Inventory

Related Commands [show lldp](#)
[show running-config lldp](#)

show lldp local-info

This command displays local LLDP information that can be transmitted through specified ports. If no port list is entered, local LLDP information for all ports is displayed.

Syntax `show lldp local-info [base] [dot1] [dot3] [med] [interface <port-list>]`

Parameter	Description
base	Information for base TLVs
dot1	Information for 802.1 TLVs
dot3	Information for 802.3 TLVs
med	Information for LLDP-MED TLVs
<port-list>	The ports for which the local information is to be shown.

Mode Privileged Exec

Usage Whether and which local information is transmitted in advertisements via a port depends on:

- whether the port is set to transmit LLDP advertisements (`lldp transmit receive` command on page 78.19)
- which TLVs it is configured to send (`lldp tlv-select` command on page 78.17, `lldp med-tlv-select` command on page 78.9).

Examples To display local information transmitted via port 1.0.1, use the command:

```
awplus# show lldp local-info interface port1.0.1
```

To display local information transmitted via all ports, use the command:

```
awplus# show lldp local-info
```

Figure 78-3: Example output from the show lldp local-info command

```
LLDP Local Information:

Local port1.0.1:
Chassis ID Type ..... MAC address
Chassis ID ..... 0015.77c9.7453
Port ID Type ..... Interface alias
Port ID ..... port1.0.1
TTL ..... 120
Port Description ..... [not configured]
System Name ..... awplus
System Description ..... Allied Telesis router/switch, AW+
v5.3.3
System Capabilities - Supported .. Bridge, Router
                  - Enabled .... Bridge, Router
Management Address ..... 192.168.1.6
Port VLAN ID (PVID) ..... 1
Port & Protocol VLAN - Supported . Yes
                  - Enabled ... No
                  - VIDs ..... 0
```

Figure 78-3: Example output from the show lldp local-info command (Continued)

```

VLAN Names ..... default
Protocol IDs ..... 9000, 0026424203000000, 888e01, aaaa03,
                    88090101, 00540000e302, 0800, 0806, 86dd
MAC/PHY Auto-negotiation ..... Supported, Enabled
  Advertised Capability ..... 1000BaseTFD, 100BaseTXFD, 100BaseTX,
                              10BaseTFD, 10BaseT
  Operational MAU Type ..... 1000BaseTFD (30)
Power Via MDI (PoE) ..... Supported, Enabled
  Port Class ..... PSE
  Pair Control Ability ..... Disabled
  Power Class ..... Unknown
Link Aggregation ..... Supported, Disabled
Maximum Frame Size ..... 1522
LLDP-MED Device Type ..... Network Connectivity
LLDP-MED Capabilities ..... LLDP-MED Capabilities, Network Policy,
                              Location Identification,
                              Extended Power - PSE, Inventory
Network Policy ..... [not configured]
Location Identification ..... Civic Address
  Country Code ..... NZ
  City ..... Christchurch
  Street Suffix ..... Avenue
  House Number ..... 27
  Primary Road Name ..... Nazareth
Location Identification ..... ELIN
  ELIN ..... 123456789012
Extended Power Via MDI (PoE) ..... PSE
  Power Source ..... Primary Power
  Power Priority ..... Low
  Power Value ..... 4.4 Watts
Inventory Management:
  Hardware Revision ..... A-0
  Firmware Revision ..... 1.1.0
  Software Revision ..... v5.3.3
  Serial Number ..... G1Q78900B
  Manufacturer Name ..... Allied Telesis Inc.
  Model Name ..... x600-48Ts/XP
  Asset ID ..... [zero length]

```

Output

Table 78-4: Parameters in the output from the show lldp local-info command

Parameter	Meaning
Chassis ID Type	Type of the Chassis ID.
Chassis ID	Chassis ID that uniquely identifies the local device.
Port ID Type	Type of the Port ID.
Port ID	Port ID of the local port through which advertisements are sent.
TTL	Number of seconds that the information advertised by the local port remains valid.
Port Description	Port description of the local port, as specified by the description (interface) command on page 12.2.
System Name	System name, as specified by the hostname command on page 8.11.
System Description	System description.
System Capabilities (Supported)	Capabilities that the local port supports.

Table 78-4: Parameters in the output from the show lldp local-info command(Continued)

Parameter	Meaning
System Capabilities (Enabled)	Enabled capabilities on the local port.
Management Addresses	Management address associated with the local port. To change this, use the lldp management-address command on page 78.7 .
Port VLAN ID (PVID)	VLAN identifier associated with untagged or priority tagged frames received via the local port.
Port & Protocol VLAN (Supported)	Whether Port & Protocol VLANs (PPV) is supported on the local port.
Port & Protocol VLAN (Enabled)	Whether the port is in one or more Port & Protocol VLANs.
Port & Protocol VLAN (VIDs)	List of identifiers for Port & Protocol VLANs that the port is in.
VLAN Names	List of VLAN names for VLANs that the local port is assigned to.
Protocol IDs	List of protocols that are accessible through the local port.
MAC/PHY Auto-negotiation	Auto-negotiation support and current status of the 802.3 LAN on the local port.
Power Via MDI (PoE)	PoE-capability and current status on the local port.
Port Class	Whether the device is a PSE (Power Sourcing Entity) or a PD (Powered Device)
Pair Control Ability	Whether power pair selection can be controlled
Power Pairs	Which power pairs are selected for power ("Signal Pairs" or "Spare Pairs") if pair selection can be controlled
Power Class	The power class of the PD device on the port (class 0, 1, 2, 3 or 4)
Link Aggregation	Whether the link is capable of being aggregated and it is currently in an aggregation.
Aggregated Port-ID	Aggregated port identifier.
Maximum Frame Size	The maximum frame size capability of the implemented MAC and PHY.
LLDP-MED Device Type	LLDP-MED device type
LLDP-MED Capabilities	Capabilities LLDP-MED capabilities supported on the local port.
Network Policy	List of network policies configured on the local port.
VLAN ID	VLAN identifier for the port for the specified application type
Tagged Flag	Whether the VLAN ID is to be used as tagged or untagged
Layer-2 Priority:	Layer-2 User Priority (in the range 0 to 7)

Table 78-4: Parameters in the output from the show lldp local-info command(Continued)

Parameter	Meaning
DSCP Value	Diffserv codepoint (in the range 0 to 63)
Location Identification	Location configured on the local port.
Extended Power Via MDI (PoE)	PoE-capability and current status of the PoE parameters for Extended Power-Via-MDI TLV on the local port.
Power Source	The power source the switch currently uses; either primary power or backup power.
Power Priority	The power priority configured on the port; either critical, high or low.
Power Value	The total power the switch can source over a maximum length cable to a PD device on the port. The value shows the power value in Watts from the PD side.
Inventory Management	Inventory information for the device.

Related Commands [description \(interface\)](#)
[hostname](#)
[lldp transmit receive](#)

show lldp neighbors

This command displays a summary of information received from neighbors via specified ports. If no port list is supplied, neighbor information for all ports is displayed.

Syntax `show lldp neighbors [interface <port-list>]`

Parameter	Description
<port-list>	The ports for which the neighbor information is to be shown.

Mode Privileged Exec

Examples To display neighbor information received via ports 1.0.1 and 1.0.7 with LLDP-MED configuration, use the command:

```
awplus# show lldp neighbors interface port1.0.1,port1.0.7
```

Figure 78-4: Example output from the show lldp neighbors command

```
awplus# show lldp neighbors interface port1.0.1,port1.0.7
LLDP Neighbor Information:

Total number of neighbors on these ports .... 4

System Capability Codes:
  O = Other   P = Repeater   B = Bridge           W = WLAN Access Point
  R = Router  T = Telephone  C = DOCSIS Cable Device S = Station Only
LLDP-MED Device Type and Power Source Codes:
  1 = Class I   3 = Class III   PSE = PoE       Both = PoE&Local   Prim = Primary
  2 = Class II  N = Network Con.  Loc1 = Local    Unkn = Unknown    Back = Backup
```

Local Port	Neighbor Chassis ID	Neighbor Port ID	Neighbor Sys Name	System Cap.	MED Ty Pwr
1.0.1	002d.3044.7ba6	port1.0.2	awplus	OPBWRTCS	
1.0.1	0011.3109.e5c6	port1.0.3	AT-9924 switch/route...	--B-R---	
1.0.7	0000.10cf.8590	port3	AR-442S	--B-R---	
1.0.7	00ee.4352.df51	192.168.1.2	Jim's desk phone	--B--T--	3 PSE

To display neighbor information received via all ports, use the command:

```
awplus# show lldp neighbors
```

Output

Table 78-5: Parameters in the output from the show lldp neighbors command

Parameter	Meaning
Local Port	Local port on which the neighbor information was received.
Neighbor Chassis ID	Chassis ID that uniquely identifies the neighbor.
Neighbor Port Name	Port ID of the neighbor.
Neighbor Sys Name	System name of the LLDP neighbor.

Table 78-5: Parameters in the output from the show lldp neighbors command(Continued)

Parameter	Meaning
Neighbor Capability	Capabilities that are supported and enabled on the neighbor.
System Capability	System Capabilities of the LLDP neighbor.
MED Device Type	LLDP-MED Device class (Class I, II, III or Network Connectivity)
MED Power Source	LLDP-MED Power Source

Related Commands [show lldp neighbors detail](#)

show lldp neighbors detail

This command displays in detail the information received from neighbors via specified ports. If no port list is supplied, detailed neighbor information for all ports is displayed.

Syntax `show lldp neighbors detail [base] [dot1] [dot3] [med] [interface <port-list>]`

Parameter	Description
base	Information for base TLVs
dot1	Information for 802.1 TLVs
dot3	Information for 803.1 TLVs
med	Information for LLDP-MED TLVs
<port-list>	The ports for which the neighbor information is to be shown.

Mode Privileged Exec

Examples To display detailed neighbor information received via ports 1.0.1, use the command:

```
awplus# show lldp neighbors detail interface port1.0.1
```

Figure 78-5: Example output from the show lldp neighbors detail command

```
awplus# show lldp neighbors detail interface port1.0.1
LLDP Detailed Neighbor Information:

Local port1.0.1:
  Neighbors table last updated 0 hrs 0 mins 40 secs ago

  Chassis ID Type ..... MAC address
  Chassis ID ..... 0004.cd28.8754
  Port ID Type ..... Interface alias
  Port ID ..... port1.0.8
  TTL ..... 120 (secs)
  Port Description ..... [zero length]
  System Name ..... awplus
  System Description ..... Allied Telesis router/switch, AW+ v5.3.3
  System Capabilities - Supported .. Bridge, Router
                    - Enabled .... Bridge, Router
  Management Addresses ..... 0004.cd28.8754
  Port VLAN ID (PVID) ..... 1
  Port & Protocol VLAN - Supported . Yes
                    - Enabled ... Yes
                    - VIDs ..... 5
  VLAN Names ..... default, vlan5
  Protocol IDs ..... 9000, 0026424203000000, 888e01, 8100,
                    88090101, 00540000e302, 0800, 0806, 86dd
  MAC/PHY Auto-negotiation ..... Supported, Enabled
    Advertised Capability ..... 1000BaseTFD, 100BaseTXFD, 100BaseTX,
                                10BaseTFD, 10BaseT
    Operational MAU Type ..... 1000BaseTFD (30)
  Power Via MDI (PoE) ..... [not advertised]
  Link Aggregation ..... Supported, Disabled
  Maximum Frame Size ..... 1522 (Octets)
  LLDP-MED Device Type ..... Network Connectivity
```

Figure 78-5: Example output from the show lldp neighbors detail command(Continued)

LLDP-MED Capabilities	LLDP-MED Capabilities, Network Policy, Location Identification, Extended Power - PSE, Inventory
Network Policy	[not advertised]
Location Identification	[not advertised]
Extended Power Via MDI (PoE)	PD
Power Source	PSE
Power Priority	High
Power Value	4.4 Watts
Inventory Management:	
Hardware Revision	X1-0
Firmware Revision	1.1.0
Software Revision	5.3.3
Serial Number	M1NB73008
Manufacturer Name	Allied Telesis Inc.
Model Name	x900-12XT/S
Asset ID	[zero length]

To display detailed neighbor information received via all ports, use the command:

```
awplus# show lldp neighbors detail
```

Table 78-6: Parameters in the output from the show lldp neighbors detail command

Parameter	Meaning
Chassis ID Type	Type of the Chassis ID.
Chassis ID	Chassis ID that uniquely identifies the neighbor.
Port ID Type	Type of the Port ID.
Port ID	Port ID of the neighbor.
TTL	Number of seconds that the information advertised by the neighbor remains valid.
Port Description	Port description of the neighbor's port.
System Name	Neighbor's system name.
System Description	Neighbor's system description.
System Capabilities (Supported)	Capabilities that the neighbor supports.
System Capabilities (Enabled)	Capabilities that are enabled on the neighbor.
Management Addresses	List of neighbor's management addresses.
Port VLAN ID (PVID)	VLAN identifier associated with untagged or priority tagged frames for the neighbor port.
Port & Protocol VLAN (Supported)	Whether Port & Protocol VLAN is supported on the LLDP neighbor.
Port & Protocol VLAN (Enabled)	Whether Port & Protocol VLAN is enabled on the LLDP neighbor.
Port & Protocol VLAN (VIDs)	List of Port & Protocol VLAN identifiers.

Table 78-6: Parameters in the output from the show lldp neighbors detail

Parameter	Meaning
VLAN Names	List of names of VLANs that the neighbor's port belongs to.
Protocol IDs	List of protocols that are accessible through the neighbor's port.
MAC/PHY Auto-negotiation	Auto-negotiation configuration and status
Power Via MDI (PoE)	PoE configuration and status of 802.3 Power-Via-MDI TLV
Link Aggregation	Link aggregation information
Maximum Frame Size	The maximum frame size capability
LLDP-MED Device Type	LLDP-MED Device type
LLDP-MED Capabilities	LLDP-MED capabilities supported
Network Policy	List of network policies
Location Identification	Location information
Extended Power Via MDI (PoE)	PoE-capability and current status
Inventory Management	Inventory information

Related Commands [show lldp neighbors](#)

show lldp statistics

This command displays the global LLDP statistics (packet and event counters).

Syntax `show lldp statistics`

Mode Privileged Exec

Examples To display global LLDP statistics information, use the command:

```
awplus# show lldp statistics
```

Figure 78-6: Example output from the show lldp statistics command

```
awplus# show lldp statistics
Global LLDP Packet and Event counters:

Frames:    Out ..... 345
           In ..... 423
           In Errored ..... 0
           In Dropped ..... 0
TLVs:      Unrecognized ..... 0
           Discarded ..... 0
Neighbors: New Entries ..... 20
           Deleted Entries ..... 20
           Dropped Entries ..... 0
           Entry Age-outs ..... 20
```

Table 78-7: Parameters in the output from the show lldp statistics command

Parameter	Meaning
Frames Out	Number of LLDPDU frames transmitted.
Frames In	Number of LLDPDU frames received.
Frames In Errored	Number of invalid LLDPDU frames received.
Frames In Dropped	Number of LLDPDU frames received and discarded for any reason.
TLVs Unrecognized	Number of LLDP TLVs received that are not recognized but the TLV type is in the range of reserved TLV types.
TLVs Discarded	Number of LLDP TLVs discarded for any reason.
Neighbors New Entries	Number of times the information advertised by neighbors has been inserted into the neighbor table.
Neighbors Deleted Entries	Number of times the information advertised by neighbors has been removed from the neighbor table.

Table 78-7: Parameters in the output from the show lldp statistics command(Continued)

Parameter	Meaning
Neighbors Dropped Entries	Number of times the information advertised by neighbors could not be entered into the neighbor table because of insufficient resources.
Neighbors Entry Age-Outs Entries	Number of times the information advertised by neighbors has been removed from the neighbor table because the information TTL interval has expired.

Related Commands [clear lldp statistics](#)
[show lldp statistics interface](#)

show lldp statistics interface

This command displays the LLDP statistics (packet and event counters) for specified ports. If no port list is supplied, LLDP statistics for all ports are displayed.

Syntax `show lldp statistics interface [<port-list>]`

Parameter	Description
<port-list>	The ports for which the statistics are to be shown.

Mode Privileged Exec

Examples To display LLDP statistics information for ports 1.0.1 and 1.0.7, use the command:

```
awplus# show lldp statistics interface port1.0.1,port1.0.7
```

Figure 78-7: Example output from the show lldp statistics interface command

```

awplus# show lldp statistics interface port1.0.1,port1.0.7

LLDP Packet and Event Counters:

port1.0.1
  Frames:    Out ..... 27
             In ..... 22
             In Errored ..... 0
             In Dropped ..... 0
  TLVs:      Unrecognized ..... 0
             Discarded ..... 0
  Neighbors: New Entries ..... 3
             Deleted Entries ..... 0
             Dropped Entries ..... 0
             Entry Age-outs ..... 0

port1.0.17
  Frames:    Out ..... 15
             In ..... 18
             In Errored ..... 0
             In Dropped ..... 0
  TLVs:      Unrecognized ..... 0
             Discarded ..... 0
  Neighbors: New Entries ..... 1
             Deleted Entries ..... 0
             Dropped Entries ..... 0
             Entry Age-outs ..... 0

```

To display LLDP statistics information for all ports, use the command:

```
awplus# show lldp statistics interface
```

Table 78-8: Parameters in the output of the show lldp statistics interface command

Output Parameter	Meaning
Frames Out	Number of LLDPDU frames transmitted.
Frames In	Number of LLDPDU frames received.

Table 78-8: Parameters in the output of the show lldp statistics interface

Output Parameter	Meaning
Frames In Errored	Number of invalid LLDPDU frames received.
Frames In Dropped	Number of LLDPDU frames received and discarded for any reason.
TLVs Unrecognized	Number of LLDP TLVs received that are not recognized but the TLV type is in the range of reserved TLV types.
TLVs Discarded	Number of LLDP TLVs discarded for any reason.
Neighbors New Entries	Number of times the information advertised by neighbors has been inserted into the neighbor table.
Neighbors Deleted Entries	Number of times the information advertised by neighbors has been removed from the neighbor table.
Neighbors Dropped Entries	Number of times the information advertised by neighbors could not be entered into the neighbor table because of insufficient resources.
Neighbors Entry Age-outs Entries	Number of times the information advertised by neighbors has been removed from the neighbor table because the information TTL interval has expired.

Related Commands [clear lldp statistics](#)
[show lldp statistics](#)

show location

Use this command to display selected location information configured on the switch.

Syntax

```
show location {civic-location|coord-location|elin-location}
show location {civic-location|coord-location|elin-location}
    identifier {<civic-loc-id>|<coord-loc-id>|<elin-loc-id>}
show location {civic-location|coord-location|elin-location} interface
    <port-list>
```

Parameter	Description
civic-location	Display civic location information
coord-location	Display coordinate location information
elin-location	Display ELIN location information
<civic-loc-id>	Civic address location identifier, in the range 1 to 4095.
<coord-loc-id>	Coordinate location identifier, in the range 1 to 4095.
<elin-loc-id>	ELIN location identifier, in the range 1 to 4095.
<port-list>	Ports to display information about.

Mode Privileged Exec

Examples To display a civic address location configured on port1.0.1, use the command:

```
awplus# show location civic-location interface port1.0.1
```

Figure 78-8: Example output from the show location command

```
awplus# show location civic-location interface port1.0.1
Port      ID      Element Type      Element Value
-----
1.0.1     1      Country           NZ
          City           Christchurch
          Street-suffix   Avenue
          House-number    27
          Primary-road-name Nazareth
```

To display coordinate location information configured on the identifier 1, use the command:

```
awplus# show location coord-location identifier 1
```

Figure 78-9: Example output from the show location command

```
awplus# show location coord-location identifier 1
ID  Element Type                Element Value
-----
1   Latitude Resolution         15 bits
    Latitude                    38.8986481130123138427734375 degrees
    Longitude Resolution        15 bits
    Longitude                    130.2323232293128967285156250 degrees
    Altitude Resolution         10 bits
    Altitude                    2.500000000 meters
    Map Datum                   WGS 84
```

The coordinate location information displayed may differ from the information entered because it is stored in binary format. For more information, see the [location coord-location configuration command on page 78.27](#).

To display all ELIN location information configured on the switch, use the command:

```
awplus# show location elin-location
```

Figure 78-10: Example output from the show location command

```
awplus# show location elin-location
ID  ELIN
-----
1   1234567890
2   5432154321
```

Related Commands

- [location elin-location-id](#)
- [location civic-location identifier](#)
- [location civic-location configuration](#)
- [location coord-location identifier](#)
- [location coord-location configuration](#)
- [location elin-location](#)

Chapter 79: SMTP Commands



Command List	79.2
debug mail	79.2
delete mail	79.3
mail	79.4
mail from	79.5
mail smtpserver	79.5
show counter mail	79.6
show mail	79.6

Command List

This chapter provides an alphabetical reference for commands used to configure SMTP.

For information about modifying or redirecting the output from show commands to a file, see [“Controlling “show” command output” on page 1.33.](#)

debug mail

This command turns on debugging for sending emails.

The no form turns off debugging for sending emails.

Syntax debug mail
 no debug mail

Mode Privileged Exec mode

Examples To turn on debugging for sending emails, use the command:

```
awplus#debug mail
```

To turn off debugging for sending emails, use the command:

```
awplus#no debug mail
```

Related Commands delete mail
 mail
 mail from
 mail smtpserver
 show mail
 show counter mail

delete mail

This command deletes mail from the queue.

Syntax `delete mail [mail-id <mail-id>|all]`

Parameter	Description
<mail-id>	Deletes a single mail from the mail queue
<mail-id>	An unique mail ID number. Use the show mail command to display this for an item of mail.
all	Delete all the mail in the queue.

Mode Privileged Exec mode

Examples To delete mail from the queue, use the commands:

```
awplus# delete mail 20060912142356.1234
```

```
awplus# delete mail all
```

Related Commands [debug mail](#)
[mail](#)
[mail from](#)
[mail smtpserver](#)
[show mail](#)

mail

This command sends an email using the SMTP protocol. If you specify a file the text inside the file is sent in the message body.

If you do not specify the to, file, or subject parameters, the CLI prompts you for the missing information.

Before you can send mail using this command, you must specify the sending email address using the [mail from](#) command and a mail server using the [mail smtpserver](#) command.

Syntax `mail [{to <to>|subject <subject>|file <filename>}]`

Parameter	Description
to	The email recipient.
	<to> Email address
subject	Description of the subject of this email. Use quote marks when the subject text contains spaces.
	<subject> String
file	File to insert as text into the message body
	<filename> String

Mode Privileged Exec mode

Examples To send an email to `rei@nerv.com` with the subject `dummy plug configuration`, and with the message body inserted from the file `plug.conf` use the command:

```
awplus# mail rei@nerv.com subject dummy plug configuration
filename plug.conf
```

Related Commands [debug mail](#)
[delete mail](#)
[mail from](#)
[mail smtpserver](#)
[show mail](#)
[show counter mail](#)

mail from

This command sets an email address for the 'mail from' SMTP command. You must specify a sending email address with this command before you can send any email.

Syntax `mail from <from>`

Parameter	Description
<from>	The email address that the mail is sent from.

Mode Global Configuration mode

Examples To set the email address you are sending mail from to "kaji@nerv.com, use the command:

```
awplus(config)#mail from kaji@nerv.com
```

Related Commands

- delete mail
- mail
- mail smtpserver
- show mail

mail smtpserver

This command sets the IP address of the SMTP server that your device sends email to. You must specify a mail server with this command before you can send any email.

Syntax `mail smtpserver <ip-address>`

Parameter	Description
<ip-address>	Internet Protocol (IP) Address for the mail server specified

Mode Global Configuration mode

Examples To specify a mail server at 192.168.0.1, use the command:

```
awplus#mail smtpserver 192.168.0.1
```

Related Commands

- debug mail
- delete mail
- mail
- mail from
- show mail
- show counter mail

show counter mail

This command displays the mail counters.

Syntax `show counter mail`

Mode Exec and Privileged Exec mode

Output Figure 79-1: Example output from the show counter mail command

```
Mail Client (SMTP) counters
Mails Sent      ..... 0
Mails Sent Fails ..... 1
```

Parameter	Meaning
Mails Sent	The number of emails sent successfully since the last device restart.
Mails Sent Fails	The number of emails the device failed to send since the last device restart.

Examples To show the emails in the queue use the command:

```
awplus# show counter mail
```

Related Commands [debug mail](#)
[delete mail](#)
[mail](#)
[mail from](#)
[show mail](#)

show mail

This command displays the emails in the queue.

Syntax `show mail`

Mode Privileged Exec mode

Examples To display the emails in the queue use the command:

```
awplus# show mail
```

Related Commands [delete mail](#)
[mail](#)
[show counter mail](#)

Chapter 80: RMON Introduction



Introduction.....	80.2
Overview	80.2
Configuration Example	80.3

Introduction

The chapter describes the Remote Network MONitoring (RMON) service on the switch, and describes a configuration example showing how to set up an RMON alarm.

This RMON alarm configuration example described creates SNMP traps and log messages when the rate of receipt of Broadcast packets on a switch port exceeds a threshold, and creates SNMP traps and log messages when the rate of receipt of Broadcast packets on a switch drops below a lower threshold.

For detailed information about the commands used to configure RMON, see [Chapter 81, RMON Commands](#)

RMON is disabled by default in AlliedWare Plus™. No RMON alarms or events are configured.

Overview

The Remote Network MONitoring (RMON) MIB (RFC2819) was developed by the IETF to support monitoring and protocol analysis of LANs with a focus on Layer 1 and 2 information in networks. RMON is an industry standard that provides the functionality in network analyzers.

An RMON implementation operates in a client/server model. Monitoring devices (or 'probes') contain RMON agents that collect information and analyze packets. The probes are servers and the Network Management applications that communicate with them are clients. While agent configuration and data collection uses SNMP, RMON operates differently than SNMP systems:

- Probes have responsibility for data collection and processing, reducing SNMP traffic and reducing processing load for clients.
- Information is only transmitted to the management application when required, not polled.

RMON is mainly used for 'flow-based' monitoring, while SNMP is mainly used for 'device-based' management. RMON data collected deals mainly with traffic patterns on the network, and SNMP data collected usually deals with the status of individual devices on the network.

One disadvantage of flow based monitoring is that remote devices have much more of the management burden, and require more resources. AlliedWare Plus minimizes the management and resources burden by implementing a subset of the RMON MIB group to provide a minimal RMON agent implementation supporting statistics, history, alarms, and events.

The RMON groups supported in AlliedWare Plus are:

- Statistics - collects ethernet statistics on a switch port, such as utilization and collisions.
- History - collects a history of ethernet statistics on a switch port.
- Alarms - monitor a MIB object for a specified interval, trigger an alarm at a specified value (the 'rising threshold'), and resets the alarm at another value (the 'falling threshold'). Alarms are used with events to trigger alarms, which generate logs or SNMP traps.
- Events - specify the action to take when an event is triggered by an alarm. The action of an event can generate a log or an SNMP trap.

Configuration Example

This configuration example sets up an RMON alarm to create SNMP traps and log messages. This RMON alarm creates SNMP traps and log messages when the rate of receipt of Broadcast packets on a switch port exceeds a threshold, and creates SNMP traps and log messages when the rate of receipt of Broadcast packets on a switch port drops below a lower threshold.

Step 1: Set up an RMON collection on the switch port that is being monitored.

Use the following commands to configure this functionality:

```
awplus# configure terminal
awplus(config)# interface port1.0.4
awplus(config-if)# rmon collection stats 4
```

This will cause the software to build a table in which it stores statistics relating to the switch port.

Step 2: Define an RMON event that will be called by the Alarm when the thresholds are passed.

Create this as a 'trap and log' event, so that both an SNMP trap and a log message will be generated. The trap will be sent to the SNMP community named 'public'.

Use the following command to configure this functionality:

```
awplus(config-if)# rmon event 10 log trap public
```

Step 3: Create the RMON alarm.

Every 5 seconds, the alarm checks the broadcast packet counter in RMON collection stats 4. If the change in the value of that counter over the 5 second interval exceeds 5000 (1000 broadcasts per second), the alarm will trigger the event defined in step 2 above.

Additionally, when the rate broadcast falls below 500 broadcasts per 5 seconds, then the alarm will trigger the event defined in step 2 above again.

Use the below command to configure this functionality:

```
awplus(config-if)# rmon alarm 5 etherStatsBroadcastPkts.4
                    interval 5 delta rising-threshold 5000
                    event 10 falling-threshold 500 event 10
```

For the variable 'etherStatsBroadcastPkts.4' in this command, note that '.4' refers to the index number of the RMON collection stats 4 as defined on port1.0.4. So, 'etherStatsBroadcastPkts.4' refers to 'Received broadcasts' in RMON collection stats 4. Further counters for RMON are defined in section 5 of RFC 1757.

Step 4: Enable RMON traps.

To ensure that the SNMP trap is sent, you need to enable RMON traps, and you need to define a trap host in SNMP. Use the below commands to configure this functionality:

```
awplus# configure terminal

awplus(config)# snmp-server

awplus(config)# snmp-server enable trap rmon

awplus(config)# snmp-server community public

awplus(config)# snmp-server host 192.168.2.254 version 2c
public
```

Note that the resulting log message will be of the form listed below:

```
RMON [1024]: Alarm Index 5 alarm Rising Threshold 5000 alarm
Value 5117 alarm Rising event Index 10 event description
RMON_SNMP
```


Chapter 81: RMON Commands



Command List	81.2
rmon alarm	81.2
rmon collection history	81.4
rmon collection stats	81.5
rmon event	81.6
show rmon alarm	81.7
show rmon event	81.8
show rmon history	81.9
show rmon statistics	81.10

Command List

This chapter provides an alphabetical reference for commands used to configure Remote Monitoring (RMON).

For an introduction to RMON and an RMON configuration example, see [Chapter 80, RMON Introduction](#)

RMON is disabled by default in AlliedWare Plus™. No RMON alarms or events are configured.

For information about modifying or redirecting the output from show commands to a file, see [“Controlling “show” command output” on page 1.33.](#)

rmon alarm

Use this command to configure an RMON alarm to monitor the value of an SNMP object, and to trigger specified events when the monitored object crosses specified thresholds.

To specify the action taken when the alarm is triggered, use the event index of an event defined by the [rmon event](#) command.

Use the no form of this command to remove the alarm configuration.

Note: Only alarms for switch port interfaces, not for VLAN interfaces, can be configured.

Syntax

```
rmon alarm <alarm-index> <oid> interval <1-65535> {delta|absolute}
    rising-threshold <1-65535> event <rising-event-index>
    falling-threshold <1-65535> event <falling-event-index>
    [owner <owner>]

no rmon alarm <alarm-index>
```

Parameter	Description
<alarm-index>	<1-65535> Alarm entry index value.
<oid>	The variable SNMP MIB Object Identifier (OID) name to be monitored, in the format etherStatsEntry.field.<stats-index>. For example, etherStatsEntry.5.22 is the OID for the etherStatsPkts field in the etherStatsEntry table for the interface defined by the <stats-index> 22 in the rmon collection stats command.
interval	Polling interval in seconds
delta	The RMON MIB alarmSampleType: the change in the monitored MIB object value between the beginning and end of the polling interval.
absolute	The RMON MIB alarmSampleType: the value of the monitored MIB object.
rising-threshold	Rising threshold value of the alarm entry
<rising-event-index>	<1-65535> The event to be triggered when the monitored object value reaches the rising threshold value. This is an event index of an event specified by the rmon event command.
falling-threshold	Falling threshold value of the alarm entry

Parameter	Description
<code><falling-event-index></code>	<code><1-65535></code> The event to be triggered when the monitored object value reaches the falling threshold value. This is an event index of an event specified by the rmon event command.
<code>owner</code>	Arbitrary owner name to identify the alarm entry.

Mode Global Configuration

Default By default, there are no alarms.

Usage Note that the SNMP MIB Object Identifier (OID) indicated in the command syntax with `<oid>` must be specified as a dotted decimal value with the form `etherStatsEntry.field.<stats-index>`.

Example To configure an alarm to monitor the change per minute in the `etherStatsPkt` value for interface 22 (defined by `stats-index 22` in the [rmon collection stats](#) command), to trigger event 2 (defined by the [rmon event](#) command) when it reaches the rising threshold 400, and to trigger event 3 when it reaches the falling threshold 200, and identify this alarm as belonging to Maria, use the commands:

```
awplus# configure terminal
awplus(config)# rmon alarm 229 etherStatsEntry.22.5 interval 60
                  delta rising-threshold 400 event 2 falling-
                  threshold 200 event 3 owner maria
```

Related Commands [rmon collection stats](#)
[rmon event](#)

rmon collection history

Use this command to create a history statistics control group to store a specified number of snapshots (buckets) of the standard RMON statistics for the switch port, and to collect these statistics at specified intervals. If there is sufficient memory available, then the device will allocate memory for storing the set of buckets that comprise this history control.

Use the no form of this command to remove the specified history control configuration.

Note: Only a history for switch port interfaces, not for VLAN interfaces, can be collected.

Syntax `rmon collection history <history-index> [buckets <1-65535>]
[interval <1-3600>] [owner <owner>]
no rmon collection history <history-index>`

Parameter	Description
<history-index>	<1-65535> A unique RMON history control entry index value
interval	Polling interval in seconds. Default 1800 second polling interval.
buckets	Number of requested buckets to store snapshots. Default 50 buckets.
owner	Owner name to identify the entry

Mode Interface Configuration

Default The default interval is 1800 seconds and the default buckets is 50 buckets.

Examples

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# rmon collection history 200 buckets 500
interval 600 owner herbert
```

rmon collection stats

Use this command to enable the collection of RMON statistics on a switch port, and assign an index number by which to access these collected statistics.

Use the no form of this command to stop collecting RMON statistics on this switch port.

Note: Only statistics for switch port interfaces, not for VLAN interfaces, can be collected.

Syntax `rmon collection stats <collection-index> [owner <owner>]`
`no rmon collection stats <collection-index>`

Parameter	Description
<collection-index>	<1-65535> Give this collection of statistics an index number to uniquely identify it. This is the index to use to access the statistics collected for this switch port.
<owner>	An arbitrary owner name to identify this statistics collection entry.

Mode Interface Configuration

Default Ethernet statistics probe is not running.

Examples

```
awplus# configure terminal
awplus(config)# interface port1.1.3
awplus(config-if)# rmon collection stats 200 owner myrtle
```

rmon event

Use this command to create an event definition for a log or a trap or both. The event index for this event can then be referred to by the [rmon alarm](#) command.

Use the no form of this command to remove the event definition.

Note: Only the events for switch port interfaces, not for VLAN interfaces, can be collected.

Syntax

```
rmon event <event-index> [description <description>|owner <owner>|
    trap <trap>]

rmon event <event-index> [log [description <description>|
    owner <owner>|trap <trap>] ]

rmon event <event-index> [log trap [description <description>|
    owner <owner>] ]

no rmon event <event-index>
```

Parameter	Description
<event-index>	<1-65535> Unique event entry index value
log	Log event type
trap	Trap event type
log trap	Log and trap event type
<community-string>	The SNMP community to send the trap to
<description>	Event entry description
<owner>	Owner name to identify the entry

Mode Global Configuration

Default No default event is configured.

Examples

```
awplus# configure terminal
awplus(config)# rmon event 299 log description cond3 owner
alfred
```

Related Commands [rmon alarm](#)

show rmon alarm

Use this command to display the alarms and threshold configured for the RMON probe.

Note: Only the alarms for switch port interfaces, not for VLAN interfaces, can be shown.

Syntax `show rmon alarm`

Mode User Exec and Privileged Exec

Examples

```
awplus# show rmon alarm
```

Related Commands [rmon alarm](#)

show rmon event

Use this command to display the events configured for the RMON probe.

Note: Only the events for switch port interfaces, not for VLAN interfaces, can be shown.

Syntax show rmon event

Mode User Exec and Privileged Exec

Output Example output from the show rmon event command

```
awplus#sh rmon event
event Index = 787
  Description TRAP
  Event type log & trap
  Event community name gopher
  Last Time Sent = 0
  Owner RMON_SNMP

event Index = 990
  Description TRAP
  Event type trap
  Event community name teabo
  Last Time Sent = 0
  Owner RMON_SNMP
```

Note: The following etherStats counters are not currently available for Layer 3 interfaces:

- etherStatsBroadcastPkts
- etherStatsCRCAlignErrors
- etherStatsUndersizePkts
- etherStatsOversizePkts
- etherStatsFragments
- etherStatsIabbers
- etherStatsCollisions
- etherStatsPkts64Octets
- etherStatsPkts65to127Octets
- etherStatsPkts128to255Octets
- etherStatsPkts256to511Octets
- etherStatsPkts512to1023Octets
- etherStatsPkts1024to1518Octets

Examples

```
awplus# show rmon event
```

Related Commands rmon event

show rmon history

Use this command to display the parameters specified on all the currently defined RMON history collections on the device.

Note: Only the history for switch port interfaces, not for VLAN interfaces, can be shown.

Syntax show rmon history

Mode User Exec and Privileged Exec

Output Example output from the show rmon history command

```
awplus#sh rmon history
  history index = 56
    data source ifindex = 4501
    buckets requested = 34
    buckets granted = 34
    Interval = 2000
    Owner Andrew

  history index = 458
    data source ifindex = 5004
    buckets requested = 400
    buckets granted = 400
    Interval = 1500
    Owner trev
=====
```

Note: The following etherStats counters are not currently available for Layer 3 interfaces:

- etherStatsBroadcastPkts
- etherStatsCRCAlignErrors
- etherStatsUndersizePkts
- etherStatsOversizePkts
- etherStatsFragments
- etherStatslabbers
- etherStatsCollisions
- etherStatsPkts64Octets
- etherStatsPkts65to127Octets
- etherStatsPkts128to255Octets
- etherStatsPkts256to511Octets
- etherStatsPkts512to1023Octets
- etherStatsPkts1024to1518Octets

Examples

```
awplus# show rmon history
```

Related Commands rmon collection history

show rmon statistics

Use this command to display the current values of the statistics for all the RMON statistics collections currently defined on the device.

Note: Only statistics for switch port interfaces, not for VLAN interfaces, can be shown.

Syntax show rmon statistics

Mode User Exec and Privileged Exec

Examples

```
awplus# show rmon statistics
```

Output Example output from the show rmon statistics command

```
awplus#show rmon statistics
  rmon collection index 45
  stats->ifindex = 4501
  input packets 1279340, bytes 85858960, dropped 00, multicast packets 1272100
  output packets 7306090, bytes 268724, multicast packets 7305660 broadcast
  packets 290
  rmon collection index 679
  stats->ifindex = 5013
  input packets 00, bytes 00, dropped 00, multicast packets 00
  output packets 8554550, bytes 26777324, multicast packets 8546690 broadcast
  packets 7720
```

Note: The following etherStats counters are not currently available for Layer 3 interfaces:

- etherStatsBroadcastPkts
- etherStatsCRCAlignErrors
- etherStatsUndersizePkts
- etherStatsOversizePkts
- etherStatsFragments
- etherStatsIabbers
- etherStatsCollisions
- etherStatsPkts64Octets
- etherStatsPkts65to127Octets
- etherStatsPkts128to255Octets
- etherStatsPkts256to511Octets
- etherStatsPkts512to1023Octets
- etherStatsPkts1024to1518Octets

Related Commands rmon collection stats

Chapter 82: Triggers Introduction



Introduction.....	82.2
Configuring a Trigger	82.2
Troubleshooting Triggers	82.4

Introduction

The Trigger facility provides a powerful mechanism for automatic and timed management of your device by automating the execution of commands in response to certain events. For example, you can use triggers to deactivate a service during the weekends, or to collect diagnostic information when the CPU usage is high.

A *trigger* is an ordered sequence of scripts that is executed when a certain event occurs. A *script* is a sequence of commands stored as a plaintext file on a file subsystem accessible to the device, such as Flash memory. Each trigger may reference multiple scripts and any script may be used by any trigger. When an event activates a trigger, the trigger executes the scripts associated with it in sequence. One script is executed completely before the next script begins. Various types of triggers are supported, each activated in a different way.

Configuring a Trigger

The following describes the general steps to configure a trigger. For specific configuration examples, see [Chapter 83, Triggers Configuration](#).

Step 1: Create a configuration script

Create a configuration script with the commands you would like executed when the trigger conditions are met. To create the configuration script using the CLI, use the command:

```
awplus#edit [<filename>]
```

Alternatively, you can create a script on a PC then load it onto your device using the [copy \(URL\)](#) command.

Step 2: Enter the trigger configuration mode

You must be in the Global Configuration mode to reach the Trigger Configuration mode. Use the command:

```
awplus#configure terminal
```

To create a trigger, and enter its configuration mode, use the command:

```
awplus(config)#trigger <1-250>
```

Step 3: Set the trigger type

The trigger type determines how the trigger is activated. To set the trigger to activate:

« when CPU usage reaches a certain level, use the command:

```
awplus(config-trigger)#type cpu <1-100> [up|down|any]
```

« when the link status of a particular interface changes, use the command:

```
awplus(config-trigger)#type interface <interface> [up|down|any]
```

« when the RAM usage reaches a certain level, use the command:

```
awplus(config-trigger)#type memory <1-100> [up|down|any]
```

« periodically after a set number of minutes, use the command:

```
awplus(config-trigger)#type periodic <1-1440>
```

« when a ping poll identifies that a target device's status has changed, use the command:

```
awplus(config-trigger)#type ping-poll <1-100> {up|down}
```

« if your device reboots, use the command:

```
awplus(config-trigger)#type reboot
```

« when a stacking link goes up or down, use the command:

```
awplus(config-trigger)#type stack link {up|down}
```

« at a specific time of the day, use the command:

```
awplus(config-trigger)#type time <hh:mm>
```

Step 4: Set the time and days that the trigger can activate on

By default triggers can activate at any time of the day, on all days. If you want your trigger to activate only during a specific time of the day, use the command:

```
awplus(config-trigger)#time {[after <hh:mm:ss>][before <hh:mm:ss>]}
```

If you want your trigger to activate only on a specific date, use the command:

```
awplus(config-trigger)# day <1-31> <month> <2000-2035>
```

If you want the trigger to activate only on specific days of the week, use the command:

```
awplus(config-trigger)# day <weekday>
```

Note that you can set either a specific date, or specific weekdays, but not both.

Step 5: Specify how often the trigger can activate

By default, triggers can activate an unlimited number of times, as long as the trigger conditions are met. To set a limit on the number of times a trigger can activate, use the command:

```
awplus(config-trigger)#repeat {forever|no|once|yes|<1-4294967294>}
```

Your device maintains two counters that track the number of times a trigger has activated. One counts the total number of times the trigger is activated and is only reset if the device restarts, or when the trigger is destroyed. The other counter tracks the permitted number of repetitions. To reset this counter, use the [repeat command on page 84.6](#).

Step 6: Add the script to the trigger

You can add up to five scripts to the trigger. When a trigger is activated, it executes the scripts in sequence, with the lowest numbered script activated first. The first script runs to completion before the next script begins. To add a script, use the command:

```
awplus(config-trigger)#script <1-5> {<filename>}
```

Step 7: Specify a description for the trigger

Specify a description for the trigger, so that you can easily identify the trigger in show commands and log output. Use the command:

```
awplus(config-trigger)#description <description>
```

Step 8: Verify the trigger's configuration

To check the configuration of the trigger, use the command:

```
awplus#show trigger [<1-250>|counter|full]
```

Troubleshooting Triggers

You can use the trigger diagnostic mode and trigger debugging to test your triggers and troubleshoot any issues.

Diagnostic mode is set per trigger. In this mode the trigger activates if its trigger conditions are met, but does not run any of its scripts. Your device generates a log message to indicate that the trigger was activated. To place a trigger in diagnostic mode, enter the trigger's configuration mode and use the command:

```
awplus(config-trigger)#test
```

To start debugging for triggers, use the command:

```
awplus#debug trigger
```

This generates detailed messages about how your device is processing the trigger commands and activating the triggers.

Enabling and Disabling

Triggers are enabled by default. This allows the trigger to activate as soon as its trigger conditions are met. If you need to disable a trigger but do not want to delete the trigger, use the command:

```
awplus(config-trigger)#no active
```

To enable the trigger again, use the command:

```
awplus(config-trigger)#active
```

To delete the trigger, use the command:

```
awplus(config)#no trigger <1-250>
```

Chapter 83: Triggers Configuration



Introduction.....	83.2
Restrict Internet Access	83.2
Capturing Unusual CPU and RAM Activity.....	83.3
Seeing Daily Statistics.....	83.5

Introduction

The chapter describes how to configure triggers to:

- restricting internet access during work hours
- change the gateway set when a device becomes unreachable
- tracking unusual CPU or RAM usage by your device

For more information about triggers, see [Chapter 82, Triggers Introduction](#) and [Chapter 84, Trigger Commands](#).

Restrict Internet Access

In the following configuration the ACME company wants to restrict its employees from accessing popular video sharing websites as this is causing bandwidth problems during work hours. The ACME company is happy for workers to access the site after work hours.

Employee PCs at ACME are on vlan2. Two triggers with associated scripts are needed:

- Trigger one activates at 8.30am and runs a script called shutdown.scp. This script adds commands to restrict access to the specified sites
- Trigger two activates at 5.30pm and runs the script called open.scp. This script removes the configuration specified by shutdown.scp.

1. Create the shutdown.scp script

Create a configuration script using Access Control List commands to restrict users on vlan2 from accessing the specific sites.

2. Create the open.scp script

Create a script to remove the ACL configuration specified in the shutdown.cfg file.

3. Configure trigger 1

To create trigger one, use the command:

```
awplus(config)#trigger 1
```

Set the trigger to activate at 8:30 am, by using the command:

```
awplus(config-trigger)#type time 08:30
```

Set the trigger to activate on Monday, Tuesday, Wednesday, Thursday and Friday:

```
awplus(config-trigger)#day mon tue wed thur fri
```

Add the script shutdown.scp to the trigger, by using the command:

```
awplus(config-trigger)#script 1 shutdown.scp
```

Specify a helpful description, such as stops access to video sharing sites. Use the command:

```
awplus(config-trigger)#description stops access to video  
sharing sites
```

4. Configure trigger 2

To create trigger two, use the command:

```
awplus(config)#trigger 1
```


Set the trigger to activate at 5.30pm:

```
awplus(config-trigger)#type time 17:30
```

Set the trigger to activate on Monday, Tuesday, Wednesday, Thursday and Friday:

```
awplus(config-trigger)#day mon tue wed thur fri
```

To add the script open.scp, use the command:

```
awplus(config-trigger)#script 1 open.scp
```

Specify a helpful description, such as access allowed to video sharing sites. Use the command:

```
awplus(config-trigger)#description access allowed to video
sharing sites
```

5. Verify the configuration

To check the configuration of the triggers, use the command:

```
awplus#show trigger
```

Capturing Unusual CPU and RAM Activity

The following configuration allows you to troubleshoot high CPU or RAM usage by the device. It uses two triggers to capture show output, and places this output in a file.

- Trigger three activates the script cpu-usage.scp when CPU usage is over 90% and can activate up to 5 times
- Trigger four activates the script ram-usage.scp when RAM usage is over 95%, and can activate up to 10 times

1. Create the cpu-usage.scp configuration script

Create a script with the appropriate show command:

```
awplus#show cpu | redirect showcpu.txt
```

The output of the show cpu command has been redirected into a file. It is not possible to display trigger script output on the terminal. Redirecting the command output to a file means it is available for later inspection.

If the trigger activates on more than one occasion the contents of showcpu.txt will be overwritten with the latest output. To keep a full record for all activations of this trigger an ASH shell script can be added to the trigger to manage the output of the configuration script. For example:

```
#!/bin/ash
date >> showcpu_bkup.txt
cat showcpu.txt >> showcpu_bkup.txt
```

This script concatenates that date and time of activation and the contents of showcpu.txt onto the end of the backup file showcpu_bkup.txt in flash memory.

Note that the files may grow large accumulating data and consume available flash memory.

2. Create the ram-usage.scp configuration script

Create a script with the appropriate show command:

```
awplus#show memory | redirect showmem.txt
```

The output of the show memory command has been redirected into a file. It is not possible to display trigger script output on the terminal. Redirecting the command output to a file means it is available for later inspection.

If the trigger activates on more than one occasion the contents of showcpu.txt will be overwritten with the latest output. To keep a full record for all activations of this trigger an ASH shell script can be added to the trigger to manage the output of the configuration script. For example:

```
#!/bin/ash
date >> showmem_bkup.txt
cat showmem.txt >> showmem_bkup.txt
```

This script concatenates that date and time of activation and the contents of showmem.scp onto the end of the backup file showmem_bkup.scp in flash memory.

Note that the files may grow large accumulating data and consume available flash memory.

3. Configure trigger 3

To create trigger three, use the command:

```
awplus(config)#trigger 3
```

Set the trigger to activate when CPU usage exceeds 80%, use the command:

```
awplus(config-trigger)#type cpu 90 up
```

Add the script cpu-usage.scp to the trigger, by using the command:

```
awplus(config-trigger)#script 1 cpu-usage.scp
```

4. Configure trigger 4

To create trigger four, use the command:

```
awplus(config)#trigger 4
```

Set the trigger to activate when RAM usage exceeds 95%, use the command:

```
awplus(config-trigger)#type cpu 95 up
```

Add the script cpu-usage.scp to the trigger, by using the command:

```
awplus(config-trigger)#script 1 ram-usage.scp
```

5. Verify the configuration

To check the configuration of the triggers, use the command:

```
awplus#show trigger
```

Seeing Daily Statistics

The ACME company has recently set up QoS on its traffic to give traffic different priorities to the ISP. ACME wants to assess how much traffic is dropped with the QoS bandwidths set over the next week. To do this, they want to generate an hourly report on QoS traffic on the first day that this is implemented.

- Trigger five activates the script `qos-stats.scp` every 60 minutes. The trigger is set to only activate during work hours.

1. Create the `qos-stats.scp` script

Create a configuration script with the appropriate show commands.

2. Configure trigger 5

To create trigger five, use the command:

```
awplus(config)#trigger 5
```

Set the trigger to activate periodically every 60 minutes:

```
awplus(config-trigger)#type periodic 60
```

Set the trigger to activate only during the hours of 8:00am and 6:00pm:

```
awplus(config-trigger)#time after 8:00 before 18:00
```

Add the script `qos-stats.scp` to the trigger, by using the command:

```
awplus(config-trigger)#script 1 qos-stats.scp
```

3. Verify the configuration

To check the configuration of the triggers, use the command:

```
awplus#show trigger
```


Chapter 84: Trigger Commands



Command List	84.2
active (trigger)	84.2
day	84.3
debug trigger	84.4
description (trigger)	84.5
repeat	84.6
script	84.7
show running-config trigger	84.8
show trigger	84.9
test	84.12
time (trigger)	84.13
trap	84.15
trigger	84.16
trigger activate	84.17
type cpu	84.18
type interface	84.19
type memory	84.20
type periodic	84.21
type ping-poll	84.22
type reboot	84.22
type stack master-fail	84.23
type stack member	84.24
type stack link	84.25
type time	84.26

Command List

This chapter provides an alphabetical reference for commands used to configure Triggers. For more information, see [Chapter 82, Triggers Introduction](#) and [Chapter 83, Triggers Configuration](#).

For information about modifying or redirecting the output from show commands to a file, see [“Controlling “show” command output” on page 1.33](#).

active (trigger)

This command enables a trigger. This allows the trigger to activate when its trigger conditions are met.

The no parameter disables a trigger. While in this state the trigger cannot activate when its trigger conditions are met.

Syntax active
 no active

Mode Trigger Configuration

Examples To enable trigger 172, so that it can activate when its trigger conditions are met, use the commands:

```
awplus# configure terminal
awplus(config)# trigger 172
awplus(config-trigger)# active
```

To disable trigger 182, preventing it from activating when its trigger conditions are met, use the commands:

```
awplus# configure terminal
awplus(config)# trigger 182
awplus(config-trigger)# no active
```

Related Commands [show trigger](#)
 [trigger](#)

day

This command specifies the days or date that the can trigger activate on. You can specify either:

- A specific date
- A specific day of the week
- A list of days of the week
- every day

By default, the trigger can activate on any day.

Syntax `day every-day`
`day <1-31> <month> <2000-2035>`
`day <weekday>`

Parameter	Description
<code>every-day</code>	Sets the trigger so that it can activate on any day.
<code><1-31></code>	Day of the month the trigger is permitted to activate on.
<code><month></code>	Sets the month that the trigger is permitted to activate on. Valid keywords are: january, february, march, april, may, june, july, august, september, october, november, and december.
<code><2000-2035></code>	Sets the year that the trigger is permitted to activate in.
<code><weekday></code>	Sets the days of the week that the trigger can activate on. You can specify one or more week days in a space separated list. Valid keywords are: monday, tuesday, wednesday, thursday, friday, saturday, and sunday.

Mode Trigger Configuration

Examples To permit trigger 55 to activate on the 1st of June 2008, use the commands:

```
awplus# configure terminal
awplus(config)# trigger 55
awplus(config-trigger)# day 1 Jun 2008
```

To permit trigger 12 to activate on a Mondays, Wednesdays and Fridays, use the commands:

```
awplus# configure terminal
awplus(config)# trigger 12
awplus(config-trigger)# day monday wednesday friday
```

Related Commands `show trigger`
`trigger`

debug trigger

This command enables trigger debugging. This generates detailed messages about how your device is processing the trigger commands and activating the triggers.

The no form disables trigger debugging.

Syntax `debug trigger`
 `no debug trigger`

Mode Privilege Exec

Examples To start trigger debugging, use the command:

```
awplus# debug trigger
```

To stop trigger debugging, use the command:

```
awplus# no trigger
```

Related Commands `show trigger`
 `test`
 `trigger`

description (trigger)

This command adds an optional description to help you identify the trigger. This description is displayed in show command outputs and log messages.

The no parameter removes a trigger's description. The show command outputs and log messages stop displaying a description for this trigger.

Syntax `description <description>`

`no description`

Parameter	Description
<code><description></code>	A word or phrase that uniquely identifies this trigger or its purpose. Valid characters are any printable character and spaces, up to a maximum of 40 characters.

Mode Trigger Configuration

Examples To give trigger 240 the description `daily status report`, use the commands:

```
awplus# configure terminal
awplus(config)# trigger 240
awplus(config-trigger)# description daily status report
```

To remove the description from trigger 36, use the commands:

```
awplus# configure terminal
awplus(config)# trigger 36
awplus(config-trigger)# no description
```

Related Commands `show trigger`
`test`
`trigger`

repeat

This command specifies the number of times that a trigger is permitted to activate. This allows you to specify whether you want the trigger to activate:

- only the first time that the trigger conditions are met
- a limited number of times that the trigger conditions are met
- an unlimited number of times

Once the trigger has reached the limit set with this command, the trigger remains in your configuration but cannot be activated. Use the repeat command again to reset the trigger so that it is activated when its trigger conditions are met.

By default, triggers can activate an unlimited number of times. To reset a trigger to this default, specify either yes or forever.

Syntax repeat {forever|no|once|yes|<1-4294967294>}

Parameter	Description
yes forever	The trigger repeats indefinitely, or until disabled.
no once	The trigger activates only once.
<1-4294967294>	The trigger repeats the set number of times.

Mode Trigger Configuration

Examples To allow trigger 21 to activate only once, use the commands:

```
awplus# configure terminal
awplus(config)# trigger 21
awplus(config-trigger)# repeat no
```

To allow trigger 22 to activate an unlimited number of times whenever its trigger conditions are met, use the commands:

```
awplus# configure terminal
awplus(config)# trigger 22
awplus(config-trigger)# repeat forever
```

To allow trigger 23 to activate only the first 10 times the conditions are met, use the commands:

```
awplus# configure terminal
awplus(config)# trigger 23
awplus(config-trigger)# repeat 10
```

Related Commands [show trigger](#)
[trigger](#)

script

This command specifies one or more scripts that are to be run when the trigger activates. You can add up to five scripts to a single trigger.

The sequence in which the trigger runs the scripts is specified by the number you set before the name of the script file. One script is executed completely before the next script begins.

Scripts may be either ASH shell scripts, indicated by a .sh filename extension suffix, or AlliedWare Plus™ scripts, indicated by a .scp filename extension suffix. AlliedWare Plus™ scripts only need to be readable.

The no parameter removes one or more scripts from the trigger's script list. The scripts are identified by either their name, or by specifying their position in the script list. The all parameter removes all scripts from the trigger.

Syntax

```
script <1-5> {<filename>}
no script {<1-5>|<filename>|all}
```

Parameter	Description
<1-5>	The position of the script in execution sequence. The trigger runs the lowest numbered script first.
<filename>	The path to the script file.

Mode Trigger Configuration

Examples To configure trigger 71 to run the script flash:/cpu_trig.sh in position 3 when the trigger activates, use the commands:

```
awplus# configure terminal
awplus(config)# trigger 71
awplus(config-trigger)# script 3 flash:/cpu_trig.sh
```

To configure trigger 99 to run the scripts flash:/reconfig.scp, flash:/cpu_trig.sh and flash:/email.scp in positions 2, 3 and 5 when the trigger activates, use the following commands:

```
awplus# configure terminal
awplus(config)# trigger 99
awplus(config-trigger)# script 2 flash:/reconfig.scp 3 flash:/
cpu_trig.sh 5 flash:/email.scp
```

To remove the scripts 1, 3 and 4 from trigger 71's script list, use the commands:

```
awplus# configure terminal
awplus(config)# trigger 71
awplus(config-trigger)# no script 1 3 4
```

To remove the script flash:/cpu_trig.sh from trigger 71's script list, use the commands:

```
awplus# configure terminal
awplus(config)# trigger 71
awplus(config-trigger)# no script flash:/cpu_trig.sh
```

To remove all the scripts from trigger 71's script list, use the commands:

```
awplus# configure terminal
awplus(config)# trigger 71
awplus(config-trigger)# no script all
```

Related Commands [show trigger](#)
[trigger](#)

show running-config trigger

This command displays the current running configuration of the trigger utility.

Syntax `show running-config trigger`

Mode Privileged Exec

Examples To display the current configuration of the trigger utility, use the command:

```
awplus# show running-config trigger
```

Related Commands [show trigger](#)

show trigger

This command displays configuration and diagnostic information about the triggers configured on the device. Specify the show trigger command without any options to display a summary of the configuration of all triggers.

Syntax `show trigger [<1-250>|counter|full]`

Parameter	Description
<1-250>	Displays detailed information about a specific trigger, identified by its trigger ID.
counter	Displays statistical information about all triggers.
full	Displays detailed information about all triggers.

Mode Privileged Exec

Examples To get summary information about all triggers, use the following command:

```
awplus# show trigger
```

Figure 84-1: Example output from the **show trigger** command

TR#	Type & Details	Name	Ac	Te	Repeat	#Scr	Days/Date
001	CPU (80% any)	Busy CPU	Y	N	5	1	smtwtfs
005	Periodic (30 min)	Regular status check	Y	N	Continuous	1	-mtwtf-
007	Memory (85% up)	High mem usage	Y	N	8	1	smtwtfs
011	Time (00:01)	Weekend access	Y	N	Continuous	1	-----s
013	Reboot		Y	N	Continuous	2	smtwtfs
017	Interface (vlan1 ...	Change config for...	Y	N	Once	1	2-apr-2008
019	Ping-poll (5 up)	Connection to svr1	Y	N	Continuous	1	smtwtfs

Table 84-1: Parameters in output of the show trigger command

Parameter	Description
TR#	Trigger identifier (ID).
Type & Details	The trigger type, followed by the trigger details in brackets.
Name	Descriptive name of the trigger configured with the description (trigger) command.
Ac	Whether the trigger is active (Y), or inactive (N).
Te	Whether the trigger is in test mode (Y) or not (N).
Repeat	Whether the trigger repeats continuously, and if not, the configured repeat count for the trigger. To see the number of times a trigger has activated, use the show trigger <1-250> command.
#Scr	Number of scripts associated with the trigger.
Days/Date	Days or date when the trigger may be activated. For the days options, the days are shown as a seven character string representing Sunday to Saturday. A hyphen indicates days when the trigger cannot be activated.

To display detailed information about trigger 1, use the command:

```
awplus# show trigger 1
```

Figure 84-2: Example output from the **show trigger** command for a specific trigger

```
awplus#sho trigger 1

Trigger Configuration Details
-----
Trigger ..... 1
Description ..... dispaly cpu usage when pass 80%
Type and details ..... CPU (80% up)
Days ..... 26-nov-2007
After ..... 00:00:00
Before ..... 23:59:59
Active ..... Yes
Test ..... No
Repeat ..... 123 (0)
Modified ..... Tue Dec 20 02:26:03 1977
Number of activations ..... 0
Last activation ..... not activated
Number of scripts ..... 1
    1. shocpu.scp
    2. <not configured>
    3. <not configured>
    4. <not configured>
    5. <not configured>
-----
```

To display detailed information about all triggers, use the command:

```
awplus# show trigger full
```

Figure 84-3: Example output from the **show trigger full** command

```
Trigger Configuration Details
-----
Trigger ..... 1
Name ..... Busy CPU
Type and details ..... CPU (80% up)
Days ..... smtwtfS
Active ..... Yes
Test ..... No
Repeat ..... Continuous
Modified ..... Fri Feb 2 17:05:16 2007
Number of activations ..... 0
Last activation ..... not activated
Number of scripts ..... 2
    1. flash:/cpu_alert.sh
    2. flash:/reconfig.scp
    3. <not configured>
    4. <not configured>
    5. <not configured>

Trigger ..... 5
Name ..... Regular status check
Type and details ..... Periodic (30 min)
Days ..... smtwtfS
Active ..... Yes
Test ..... No
Repeat ..... 5 (2)
Modified ..... Fri Feb 2 17:18:44 2007
Number of activations ..... 0
Last activation ..... Fri Feb 2 18:00:00 2007
```

Figure 84-3: Example output from the **show trigger full** command (Continued)

```

Number of scripts ..... 1
 1. flash:/stat_check.scp
 2. <not configured>
 3. <not configured>
 4. <not configured>
 5. <not configured>
-----

```

Table 84-2: Parameters in output of the show trigger full and show trigger commands for a specific trigger

Parameter	Description
Trigger	The ID of the trigger.
Description/Name	Descriptive name of the trigger.
Type and details	The trigger type and its activation conditions.
Days	The days on which the trigger is permitted to activate.
Date	The date on which the trigger is permitted to activate. Only displayed if configured, in which case it replaces “Days”.
Active	Whether or not the trigger is permitted to activate.
Test	Whether or not the trigger is operating in diagnostic mode.
Repeat	Whether the trigger repeats an unlimited number of times (Continuous) or for a set number of times. When the trigger can repeat only a set number of times, then the number of times the trigger has been activated is displayed in brackets.
Modified	The date and time of the last time that the trigger was modified.
Number of activations	Number of times the trigger has been activated since the last restart of the device.
Last activation	The date and time of the last time that the trigger was activated.
Number of scripts	How many scripts are associated with the trigger, followed by the names of the script files in the order in which they run.

To display counter information about all triggers use the command:

```
awplus# show trigger counter
```

Figure 84-4: Example output from the **show trigger counter** command

```

awplus#sho trigger counter

Trigger Module Counters
-----
Trigger activations ..... 0
Time triggers activated today ..... 0
Periodic triggers activated today ..... 0
Interface triggers activated today ..... 0
Resource triggers activated today ..... 0
Reboot triggers activated today ..... 0
Ping-poll triggers activated today ..... 0
Stack master fail triggers activated today .... 0
Stack member triggers activated today ..... 0
Stack xem-stk triggers activated today ..... 0
-----

```

Table 84-3: Parameters in output of the show trigger counter command

Parameter	Description
Trigger activations	Number of times a trigger has been activated.
Time triggers activated today	Number of times a time trigger has been activated today.
Periodic triggers activated today	Number of times a periodic trigger has been activated today.
Interface triggers activated today	Number of times an interface trigger has been activated today.
Resource triggers activated today	Number of times a CPU or memory resource trigger has been activated today.
Ping-poll triggers activated today	Number of times a ping-poll trigger has been activated today.

Related Commands [trigger](#)

test

This command puts the trigger into a diagnostic mode. In this mode the trigger may activate but when it does it will not run any of the trigger's scripts. A log message will be generated to indicate when the trigger has been activated.

The no parameter takes the trigger out of diagnostic mode, restoring normal operation. When the trigger activates the scripts associated with the trigger will be run, as normal.

Syntax test
no test

Mode Trigger Configuration

Examples To put trigger 5 into diagnostic mode, where no scripts will be run when the trigger activates, use the commands:

```
awplus# configure terminal
awplus(config)# trigger 5
awplus(config-trigger)# test
```

To take trigger 205 out of diagnostic mode, restoring normal operation, use the commands:


```
awplus# configure terminal
awplus(config)# trigger 205
awplus(config-trigger)# no test
```

Related Commands [show trigger](#)
[trigger](#)

time (trigger)

This command specifies the time of day when the trigger is permitted to activate. The after parameter specifies the start of a time period that extends to midnight during which trigger may activate. By default the value of this parameter is 00:00:00 (am); that is, the trigger may activate at any time. The before parameter specifies the end of a time period beginning at midnight during which the trigger may activate. By default the value of this parameter is 23:59:59; that is, the trigger may activate at any time. If the value specified for before is later than the value specified for after, a time period from "after" to "before" is defined, during which the trigger may activate. This command is not applicable to time triggers (type time).

The following figure illustrates how the before and after parameters operate.



Syntax time {[after <hh:mm:ss>][before <hh:mm:ss>]}

Parameter	Description
after <hh:mm:ss>	The earliest time of day when the trigger may be activated.
before <hh:mm:ss>	The latest time of day when the trigger may be activated.

Mode Trigger Configuration

Examples To allow trigger 63 to activate between midnight and 10:30am, use the commands:

```
awplus# configure terminal
awplus(config)# trigger 63
awplus(config-trigger)# time before 10:30:00
```

To allow trigger 64 to activate between 3:45pm and midnight, use the commands:

```
awplus# configure terminal
awplus(config)# trigger 64
awplus(config-trigger)# time after 15:45:00
```

To allow trigger 65 to activate between 10:30am and 8:15pm, use the commands:

```
awplus# configure terminal
awplus(config)# trigger 65
awplus(config-trigger)# time after 10:30:00 before 20:15:00
```

Related Commands `show trigger`
`trigger`

trap

This command enables the specified trigger to send SNMP traps.

Use the no trap command to disable the sending of SNMP traps from the specified trigger.

Syntax trap
no trap

Default SNMP traps are enabled by default for all defined triggers.

Mode Trigger Configuration

Usage You must configure SNMP before using traps with triggers. See the following SNMP chapters:
[Chapter 74, SNMP Introduction](#)
[Chapter 75, SNMP Commands](#)
[Chapter 76, SNMP MIBs](#)

Since SNMP traps are enabled by default for all defined triggers, a common usage will be for the no trap command to disable SNMP traps from a specified trap if the trap is only periodic. Refer in particular to [AT-TRIGGER-MIB](#) for further information about the relevant SNMP MIB.

Examples To enable SNMP traps to be sent from trigger 5, use the commands:

```
awplus# configure terminal
awplus(config)# trigger 5
awplus(config-trigger)# trap
```

To disable SNMP traps being sent from trigger 205, use the commands:

```
awplus# configure terminal
awplus(config)# trigger 205
awplus(config-trigger)# no trap
```

Related Commands trigger
show trigger

trigger

This command is used to access the Trigger Configuration mode for the specified trigger. Once Trigger Configuration mode has been entered the trigger type information can be configured and the trigger scripts and other operational parameters can be specified. At a minimum the trigger type information must be specified before the trigger can become active.

The no parameter removes a specified trigger and all configuration associated with it.

Syntax trigger <1-250>
 no trigger <1-250>

Parameter	Description
<1-250>	A trigger ID.

Mode Global Configuration

Examples To enter trigger configuration mode for trigger 12 use the command:

```
awplus# trigger 12
```

To completely remove all configuration associated with trigger 12, use the command:

```
awplus# no trigger 12
```

Related Commands show trigger
 trigger activate

trigger activate

This command is used to manually activate a specified trigger from the Privileged Exec mode, which has been configured with the trigger command from the Global Configuration mode.

Syntax `trigger activate <1-250>`

Parameter	Description
<1-250>	A trigger ID.

Mode Privileged Exec

Usage This command manually activates a trigger without the normal trigger conditions being met. The trigger is activated even if it is configured as inactive. The scripts associated with the trigger will be executed even if the trigger is in the diagnostic test mode.

Triggers activated manually do not have their repeat counts decremented or their 'last triggered' time updated, and do not result in updates to the '[type] triggers today' counters.

Examples To manually activate trigger 12 use the command:

```
awplus# trigger activate 12
```

Related Commands [show trigger](#)
[trigger](#)

type cpu

This command configures a trigger to activate based on CPU usage level. Selecting the up option causes the trigger to activate when the CPU usage exceeds the specified usage level. Selecting the down option causes the trigger to activate when CPU usage drops below the specified usage level. Selecting any causes the trigger to activate in both situations. The default value is any.

Syntax `type cpu <1-100> [up|down|any]`

Parameter	Description
<1-100>	The percentage of CPU usage at which to trigger.
up	Activate when CPU usage exceeds the specified level.
down	Activate when CPU usage drops below the specified level
any	Activate when CPU usage passes the specified level in either direction

Mode Trigger Configuration

Examples To configure trigger 28 to be a CPU trigger that activates when CPU usage exceeds 80% use the following commands:

```
awplus# configure terminal
awplus(config)# trigger 28
awplus(config-trigger)# type cpu 80 up
```

To configure trigger 5 to be a CPU trigger that activates when CPU usage either rises above or drops below 65%, use the following commands:

```
awplus# configure terminal
awplus(config)# trigger 5
awplus(config-trigger)# type cpu 65
```

or

```
awplus# configure terminal
awplus(config)# trigger 5
awplus(config-trigger)# type cpu 65 any
```

Related Commands [show trigger](#)
[trigger](#)

type interface

This command configures a trigger to activate based on the link status of an interface. The trigger can be activated when the interface becomes operational by using the up option, or when the interface closes by using the down option. The trigger can also be configured to activate when either one of these events occurs by using the any option.

Syntax `type interface <interface> [up|down|any]`

Parameter	Description
<interface>	Interface name. This can be the name of a switch port, an eth-management port, or a VLAN.
up	Activate when interface becomes operational.
down	Activate when the interface closes.
any	Activate when any interface link status event occurs.

Mode Trigger Configuration

Examples To configure trigger 19 to be an interface trigger that activates when port1.1.2 becomes operational, use the following commands:

```
awplus# configure terminal
awplus(config)# trigger 19
awplus(config-trigger)# type interface port1.1.2 up
```

Related Commands [show trigger](#)
[trigger](#)

type memory

This command configures a trigger to activate based on RAM usage level. Selecting the up option causes the trigger to activate when memory usage exceeds the specified level. Selecting the down option causes the trigger to activate when memory usage drops below the specified level. Selecting any causes the trigger to activate in both situations. The default value is any.

Syntax `type memory <1-100> [up|down|any]`

Parameter	Description
<1-100>	The percentage of memory usage at which to trigger.
up	Activate when memory usage exceeds the specified level.
down	Activate when memory usage drops below the specified level.
any	Activate when memory usage passes the specified level in either direction.

Mode Trigger Configuration

Examples To configure trigger 12 to be a memory trigger that activates when memory usage exceeds 50% use the following commands:

```
awplus# configure terminal
awplus(config)# trigger 12
awplus(config-trigger)# type memory 50 up
```

To configure trigger 40 to be a memory trigger that activates when memory usage either rises above or drops below 65%, use the following commands:

```
awplus# configure terminal
awplus(config)# trigger 40
awplus(config-trigger)# type memory 65
```

or

```
awplus# configure terminal
awplus(config)# trigger 40
awplus(config-trigger)# type memory 65 any
```

Related Commands [show trigger](#)
[trigger](#)

type periodic

This command configures a trigger to be activated at regular intervals. The time period between activations is specified in minutes.

Syntax type periodic <1-1440>

Parameter	Description
<1-1440>	The number of minutes between activations.

Mode Trigger Configuration

Examples To configure trigger 44 to activate periodically at 10 minute intervals use the following commands:

```
awplus# configure terminal
awplus(config)# trigger 44
awplus(config-trigger)# type periodic 10
```

Related Commands show trigger
 trigger

type ping-poll

This command configures a trigger that activates when Ping Polling identifies that a target device's status has changed. This allows you to run a configuration script when a device becomes reachable or unreachable.

Syntax `type ping-poll <1-100> {up|down}`

Parameter	Description
<1-100>	The ping poll ID.
up	The trigger activates when ping polling detects that the target is reachable.
down	The trigger activates when ping polling detects that the target is unreachable.

Mode Trigger Configuration

Examples To configure trigger 106 to activate when ping poll 12 detects that its target device is now unreachable, use the following commands:

```
awplus# configure terminal
awplus(config)# trigger 106
awplus(config-trigger)# type ping-poll 12 down
```

Related Commands [show trigger](#)
[trigger](#)

type reboot

This command configures a trigger that activates when your device is rebooted.

Syntax `type reboot`

Mode Trigger Configuration

Examples To configure trigger 32 to activate when your device reboots, use the following commands:

```
awplus# configure terminal
awplus(config)# trigger 32
awplus(config-trigger)# type reboot
```

Related Commands [show trigger](#)
[trigger](#)

type stack master-fail

This command (configured to the stack) initiates the action of a pre-configured trigger to occur when the stack enters the fail-over state.

Syntax type stack master-fail

Parameter	Description
type	Configure a particular type of trigger
stack	Virtual Chassis Stacking (VCS)
master-fail	To activate the trigger action if the master stack member fails

Mode Trigger Configuration

Examples To configure trigger 86 to activate when stack master fail-over event occurs, use the commands:

```
awplus# configure terminal
awplus(config)# trigger 86
awplus(config-trigger)# type stack master-fail
```

Related Commands trigger
 type stack member
 type stack link

type stack member

This command (configured to the stack) initiates the action of a pre-configured trigger to occur when a switch either joins or leaves the stack.

Syntax type stack member {join|leave}

Parameter	Description
type	Configure a particular type of trigger
stack	Virtual Chassis Stacking (VCS)
member	The stack member event to activate the trigger
join	Neighbor join event
leave	Neighbor leave event

Mode Trigger Configuration

Examples To configure a pre-configured trigger number 86 to activate when a new switch joins the stack
Note that the number 86 has no particular significance; you can assign any (previously created) numbered trigger

```
awplus# configure terminal
awplus(config)# trigger 86
awplus(config-trigger)# type stack member join
```

Related Commands trigger
 type stack master-fail
 type stack link

type stack link

This command (configured to the stack) initiates the action of a pre-configured trigger to occur when a stacking link is either activated or deactivated.

Syntax `type stack link {up|down}`

Parameter	Description
type	Configure a particular type of trigger
stack	Virtual Chassis Stacking (VCS)
link	Stacking link
up	Stack link up event
down	Stack link down event

Mode Trigger Configuration

Examples To configure trigger 86 to activate when the stack link down event occurs, use the commands:

```
awplus# configure terminal
awplus(config)# trigger 86
awplus(config-trigger)# type stack link down
```

Related Commands `show trigger`
`trigger`
`type stack master-fail`

type time

This command configures a trigger that activates at a specified time of day.

Syntax `type time <hh:mm>`

Parameter	Description
<code><hh:mm></code>	The time to activate the trigger.

Mode Trigger Configuration

Examples To configure trigger 86 to activate at 15:53, use the following commands:

```
awplus# configure terminal
awplus(config)# trigger 86
awplus(config-trigger)# type time 15:53
```

Related Commands `show trigger`
 `trigger`

Chapter 85: Ping Polling Introduction



Introduction.....	85.2
How Ping Polling Works	85.2
Configuring Ping Polling.....	85.4
Creating a Polling Instance	85.4
Customizing a Polling Instance.....	85.5
Troubleshooting Ping Polling	85.6
Interaction with Other Protocols.....	85.6

Introduction

Ping polling lets your device regularly check whether it can reach other hosts on a network. It works by sending ICMP Echo Requests to a host and waiting for replies sent back. If ping polling indicates that a host's status has changed, then your device can respond to the new status. When a host is unreachable, ping polling continues monitoring the host's reachability.

You can configure triggers to activate when ping polling determines that the host's status has changed. For example, you could configure a trigger to run a script that opens and configures an alternative link if the host at the other end of a preferred link becomes unavailable. You could then configure a second trigger to run a script that automatically returns traffic to the preferred link as soon as it is available again.

How Ping Polling Works

To determine a host's reachability, your device regularly sends ICMP Echo Request packets ("pings") to the host. As long as your device receives ping responses from the host, it considers the host to be reachable. If your device does not receive a reply to a set number of ICMP Echo Requests, it considers that the host is unreachable. It continues to try to ping the device, at an increased rate. After it receives a set number of responses, it considers the device to be reachable again.


By default, a polling instance sends a ping every 30 seconds as long as it is receiving replies. The frequency of this polling is controlled by the `normal-interval` command. When a reply is not received, the polling instance increases the frequency at which it polls the device. This frequency is controlled by the `critical-interval` command, and by default, is set to send a packet every one second. It maintains this higher rate of polling until it has received sufficient consecutive replies.

The polling instance determines whether a device is reachable or unreachable based on the settings of the `fail-count`, `sample-size`, and `up-count` commands. To determine whether a device is reachable, the polling instance counts the number of failed pings within a set sample size. The sample size is set by the `sample-size` command, and by default is 5 ping responses. Within the sample size, the number of failed pings that means that the device is down is set by the `fail-count` command. By default this is set to 5. Once a polling instance has determined that a device is unreachable, it must receive a set number of consecutive replies before it changes the device's status back to reachable. This number is configured with the `up-count` command.

The following figure illustrates a polling instance where the device becomes unreachable, then reachable. It uses this configuration:

```
awplus(config-ping-poll)#fail-count 4
awplus(config-ping-poll)#sample-size 5
awplus(config-ping-poll)#up-count 3
awplus(config-ping-poll)#critical-interval 1
awplus(config-ping-poll)#normal-interval 30
```


Figure 85-1: Interaction between states and parameters for ping polling



On some operating systems, some servers may respond to a ping even if no other functionality is available, and therefore remain in an Up state while malfunctioning.

Responding to status changes

To configuring your device to determine and respond to changes in a device's reachability, you will need to:

- create a polling instance to periodically ping the device
- create scripts to run when the device becomes unreachable and when it becomes reachable again
- configure triggers to run these scripts

To set a trigger to activate when a device's status changes, its trigger type must be ping-poll. This is with the following command in the trigger's configuration mode:

```
awplus(config-trigger)#type ping-poll <1-100> {up|down}
```

where up activates the trigger when the device is reachable, and down activates the trigger when the device is unreachable.

If you use triggers to open a backup link to a remote device in the event of the primary link failing (rather than the remote device failing), the backup link and primary link must point to different IP addresses on the remote device. Otherwise, when the backup link points to the IP address that your device is polling, your device receives ping replies through the backup link, considers the device to be reachable again, and attempts to reopen the primary link instead of using the backup link.

See [Chapter 82, Triggers Introduction](#) for more information about configuring Triggers with Ping Polling.

Configuring Ping Polling

This section contains:

- [Creating a Polling Instance](#)
This explains how to quickly create a polling instance using the ping polling defaults.
- [Customizing a Polling Instance](#)
This explains how to customize a ping poll and explains the other ping poll commands.
- [Troubleshooting Ping Polling](#)
This explains how to use the debugging and monitoring commands for ping polling.

Creating a Polling Instance

The Ping Polling feature in the AlliedWare Plus™ OS allows you to easily configure polling instances with a minimum of commands. To configure a ping poll suitable for most network situations:

1. Create a polling instance by using the command:

```
awplus(config)#ping-poll <1-100>
```

The range <1-100> identifies the polling instance in the trigger commands and in other ping poll commands. Your device can poll up to 100 IP addresses at once.

2. Set the IP address of the device you are polling by using the command:

```
awplus(config-ping-poll)#ip {<ip_address>}
```

3. Enable the polling instance by using the command:

```
awplus(config-ping-poll)#active
```

4. If desired, set an optional description to identify the polling instance, by using the command:

```
awplus(config-ping-poll)#description <description>
```

You do not need to configure any other commands for most networks, because convenient defaults exist for all other ping poll settings. The following table summarizes the default configuration created.

Command	Default
Critical-interval	1 second
Fail-count	5
Length	32 bytes
Normal-interval	30 seconds
Sample-size	5
Source-ip	The IP address of the interface from which the ping packets are transmitted

Command	Default
Time-out	1 second
Up-count	30

Customizing a Polling Instance

Once you've created a polling instance using the **ping-poll** and **ip (ping polling)** command, you may wish to customize the polling instance for your network.

Packet size If you find that larger packet types in your network are not reaching the polled device while smaller ones such as ping do, you can increase the data bytes included in the ping packets sent by the polling instance. This encourages the polling instance to change the device's status to unreachable when packet of the size you are interested in are being dropped. To change the number of bytes sent in the data portion of the ping packets, use the command:

```
awplus(config-ping-poll)#length <4-1500>
```

Response timeout The polling instance determines that a device hasn't responded to a ping if one second elapses without a response to the ping. In networks where ping packets have a low priority, you may need to set the allowed response time to a longer time period. To change this, use the command:

```
awplus(config-ping-poll)#time-out <1-30>
```

Polling frequency By default, a polling instance polls a reachable device every 30 seconds. You can change this by using the command:

```
awplus(config-ping-poll)#normal-interval <1-65536>
```

Once the polling instance has determined that a ping has failed, it starts polling the device at the frequency set as the critical interval—by default, one second. To change the frequency set by the critical interval, use the command:

```
awplus(config-ping-poll)#critical-interval <1-65536>
```

The critical interval enables the polling instance to quickly observe changes in the state of the device, and should be set to a much lower value than the normal interval.

Configuring when the device's status changes The number of pings that the polling instance examines to consider a change in state is controlled by the interaction of the **sample-size**, **fail-count**, and **up-count** commands. See [“How Ping Polling Works” on page 85.2](#) for an example showing this interaction.

To determine whether a device is reachable, the polling instance counts the number of failed pings within a sample of a set size. The sample size is 5 pings by default. To change the sample size, use the command:

```
awplus(config-ping-poll)#sample-size <1-100>
```

To change the number of failed pings that the sample must have, use the command:

```
awplus(config-ping-poll)#fail-count <1-100>
```

If the sample size and fail count are the same, the unanswered pings must be consecutive. If the sample size is greater than the fail count, a device that does not always reply to pings may be declared unreachable.

The upcount is the number of consecutive pings that must be answered for the polling instance to consider the device reachable again. To change this from the default of 30, use the command:

```
awplus(config-ping-poll)#up-count <1-100>
```

Checking the configuration

To check the settings and status of the polling instance, use the command:

```
awplus(config-ping-poll)#show ping-poll [<1-100>|state {up|down}] [brief]
```

Troubleshooting Ping Polling

To disable a polling instance, use the command:

```
awplus(config-ping-poll)#no active
```

The polling instance no longer sends ICMP echo requests to the polled device and the counters for this polling instance are reset.

To clear the counters and change the status of a device to unreachable, enter the Privileged Exec mode and use the command:

```
awplus#clear ping-poll {<1-100>|all}
```

The polling instance changes to the polling frequency specified with the `critical-interval` command. The device status changes to reachable once the device responses have reached the `up-count`.

To start debugging for ping polling, use the command:

```
awplus#debug ping-poll <1-100>
```

Interaction with Other Protocols

Ping polling does not work if the polled host, your device, or any intermediate routers or switches are configured to drop ICMP Echo Requests and Replies.

Ping and Traceroute

Ping and Traceroute are not affected by ping polling. You can enter ping and trace commands at any time and independent of the polling.

Chapter 86: Ping Polling Commands



Command List	86.2
active (ping polling)	86.2
clear ping-poll	86.3
critical-interval	86.4
debug ping-poll	86.5
description (ping polling)	86.6
fail-count	86.7
ip (ping polling)	86.8
length (ping poll data)	86.9
normal-interval	86.10
ping-poll	86.11
sample-size	86.12
show counter ping-poll	86.13
show ping-poll	86.15
source-ip	86.19
timeout (ping polling)	86.20
up-count	86.21

Command List

This chapter provides an alphabetical reference for commands used to configure Ping Polling. For more information, see [Chapter 85, Ping Polling Introduction](#).

For information about modifying or redirecting the output from show commands to a file, see [“Controlling “show” command output” on page 1.33](#).

Table 86-1: The following table lists the default values when configuring a ping poll.

Default	Value
Critical-interval	1 second
Description	No description
Fail-count	5
Length	32 bytes
Normal-interval	30 seconds
Sample-size	5
Source-ip	The IP address of the interface from which the ping packets are transmitted
Time-out	1 second
Up-count	30

active (ping polling)

This command enables a ping poll instance. The polling instance sends ICMP echo requests to the device with the IP address specified by the [ip \(ping polling\)](#) command.

By default, polling instances are disabled. When a polling instance is enabled, it assumes that the device it is polling is unreachable.

The no form disables a ping poll instance. The polling instance no longer sends ICMP echo requests to the polled device. This also resets all counters for this polling instance.

Syntax active
no active

Mode Ping Polling Configuration

Examples To activate the ping poll 43, use the commands:

```
awplus(config)#ping-poll 43
awplus(config-ping-poll)#active
```

To disable the ping poll and reset its counters, use the command:

```
awplus(config-ping-poll)#no active
```

Related Commands [debug ping-poll](#)
[ip \(ping polling\)](#)
[ping-poll](#)
[show ping-poll](#)

clear ping-poll

This command resets the specified ping poll, or all ping poll instances. This clears the ping counters, and changes the status of polled devices to unreachable. The polling instance changes to the polling frequency specified with the [critical-interval](#) command. The device status changes to reachable once the device responses have reached the [up-count](#).

Syntax `clear ping-poll {<1-100>|all}`

Parameter	Description
<1-100>	A ping poll ID number. The specified ping poll instance has its counters cleared, and the status of the device it polls is changed to unreachable.
all	Clears the counters and changes the device status of all polling instances.

Mode Privileged Exec

Examples To reset the ping poll 12, use the command:

```
awplus#clear ping-poll 12
```

To reset all ping polls, use the command:

```
awplus#clear ping-poll all
```

Related Commands [active \(ping polling\)](#)
[ping-poll](#)
[show ping-poll](#)

critical-interval

This command specifies the time period in seconds between pings when the polling instance has not received a reply to at least one ping, and when the device is unreachable.

This command enables the device to quickly observe changes in state, and should be set to a much lower value than the [normal-interval](#) command.

The no form sets the critical interval to the default of one second.

Syntax `critical-interval <1-65536>`
`no critical-interval`

Parameter	Description
<1-65536>	Time in seconds between pings, when the device has failed to a ping, or the device is unreachable. Default: 1

Mode Ping Polling Configuration

Examples To set the critical interval to 2 seconds for the polling instance 99, use the commands:

```
awplus(config)#ping-poll 99
awplus(config-ping-poll)#critical-interval 2
```

To reset the critical interval to the default of one second, use the command:

```
awplus(config-ping-poll)#no critical-interval
```

Related Commands [fail-count](#)
[normal-interval](#)
[sample-size](#)
[show ping-poll](#)
[timeout \(ping polling\)](#)
[up-count](#)

debug ping-poll

This command enables ping poll debugging for the specified ping poll. This generates detailed messages about ping execution.

The no parameter disables ping poll debugging for the specified ping poll.

Syntax `debug ping-poll <1-100>`
`no debug ping-poll <1-100>`

Parameter	Description
<1-100>	A unique ping poll ID number.

Mode Privileged Exec

Examples To enable debugging for ping poll 88, use the command:

```
awplus#debug ping-poll 88
```

To disable debugging for ping poll 88, use the command:

```
awplus#no debug ping-poll 88
```

Related Commands `active (ping polling)`
`clear ping-poll`
`ping-poll`
`show ping-poll`

description (ping polling)

This command specifies a string to describe the polling instance. This allows the polling instance to be recognized easily in show commands. Setting this command is optional.

By default ping polls do not have a description.

The no form delete the description set using this command.

Syntax `description <description>`
`no description`

Parameter	Description
<code><description></code>	The description of the target. Valid characters are any printable character and spaces. There is no maximum character length.

Mode Ping Polling Configuration

Example To add the text "Primary Gateway" to describe the ping poll 45, use the commands:

```
awplus(config)#ping-poll 45
```

```
awplus(config-ping-poll)#description Primary Gateway
```

To delete the description set for the ping poll, use the command:

```
awplus(config-ping-poll)#no description
```

Related Commands `ping-poll`
`show ping-poll`

fail-count

This command specifies the number of pings that must be unanswered, within the total number of pings specified by the [sample-size](#) command, for the polling instance to consider the device unreachable.

If the number set by the [sample-size](#) command and the fail-count commands are the same, then the unanswered pings must be consecutive. If the number set by the [sample-size](#) command is greater than the number set by the fail-count command, then a device that does not always reply to pings may be declared unreachable.

The no parameter resets the fail count to the default.

Syntax `fail-count <1-100>`

`no fail-count`

Parameter	Description
<1-100>	The number of pings within the sample size that a reachable device must fail to respond to before it is classified as unreachable. Default: 5

Mode Ping Polling Configuration

Examples To specify the number of pings that must fail within the sample size to determine that a device is unreachable, use the command:

```
awplus(config-ping-poll)#fail-count 5
```

To reset the fail-count to its default value of 5, use the command:

```
awplus(config-ping-poll)#no fail-count
```

Related Commands

- [critical-interval](#)
- [normal-interval](#)
- [ping-poll](#)
- [sample-size](#)
- [show ping-poll](#)
- [timeout \(ping polling\)](#)
- [up-count](#)

ip (ping polling)

This command specifies the IPv4 address of the device you are polling.

Syntax `ip {<ip_address>}`

Parameter	Description
<code><ip_address></code>	An IPv4 address in dotted decimal notation.

Mode Ping Polling Configuration

Examples To set ping poll 5 to poll the device with the IP address “192.168.0.1”, use the command:

```
awplus(config)#ping-poll 5
awplus(config-ping-poll)#ip 192.168.0.1
```

Related Commands `ping-poll`
`source-ip`
`show ping-poll`

length (ping poll data)

This command specifies the number of data bytes to include in the data portion of the ping packet. This allows you to set the ping packets to a larger size if you find that larger packet types in your network are not reaching the polled device, while smaller packets are getting through. This encourages the polling instance to change the device's status to unreachable when the network is dropping packets of the size you are interested in.

The no parameter resets the data bytes to the default of 32 bytes.

Syntax length <4-1500>

no length

Parameter	Description
<4-1500>	The number of data bytes to include in the data portion of the ping packet. Default: 32

Mode Ping Polling Configuration

Examples To specify that the ping poll 12 sends ping packet with a data portion of 56 bytes, use the command:

```
awplus(config)#ping poll 12
```

```
awplus(config-ping-poll)#length 56
```

To reset the number of data bytes in the ping packet to the default value of 32 bytes, use the command:

```
awplus(config-ping-poll)#no length
```

Related Commands ping-poll
show ping-poll

normal-interval

This command specifies the time period between pings when the device is reachable.

The no parameter resets the time period to the default value of 30 seconds.

Syntax normal-interval <1-65536>
 no normal-interval

Parameter	Description
<1-65536>	Time in seconds between pings when the target is reachable. Default: 30

Mode Ping Polling Configuration

Examples To specify a time period of 60 seconds between pings when the device is reachable, use the command:

```
awplus(config-ping-poll)#normal-interval 60
```

To reset the interval to the default value of 30 seconds, use the command:

```
awplus(config-ping-poll)#no normal-interval
```

Related Commands critical-interval
 fail-count
 ping-poll
 sample-size
 show ping-poll
 timeout (ping polling)
 up-count

ping-poll

This command enters the ping poll configuration mode. If a ping poll exists with the specified number, then this command enters its configuration mode. If no ping poll exists with the specified number, then this command creates a new ping poll with this ID number.

To configure a ping poll, create a ping poll using this command, and use the [ip \(ping polling\)](#) command to specify the device you want the polling instance to poll. It is not necessary to specify any further commands unless you want to change a command's default.

The no parameter deletes the specified ping poll.

Syntax `ping-poll <1-100>`
`no ping-poll <1-100>`

Parameter	Description
<1-100>	A unique ping poll ID number.

Mode Global Configuration

Examples To create ping poll 3 and enter its configuration mode, use the command:

```
awplus(config)#ping-poll 3
```

To delete ping poll 3, use the command:

```
awplus(config)#no ping-poll 3
```

Related Commands [active \(ping polling\)](#)
[clear ping-poll](#)
[debug ping-poll](#)
[description \(ping polling\)](#)
[ip \(ping polling\)](#)
[length \(ping poll data\)](#)
[show ping-poll](#)
[source-ip](#)

sample-size

This command sets the total number of pings that the polling instance inspects when determining whether a device is unreachable. If the number of pings specified by the fail-count command go unanswered within the inspected sample, then the device is declared unreachable.

If the numbers set in this command and [fail-count](#) command are the same, the unanswered pings must be consecutive. If the number set by this command is greater than that set with the [fail-count](#) command, a device that does not always reply to pings may be declared unreachable.

You cannot set this command's value lower than the [fail-count](#) value.

The polling instance uses the number of pings specified by the [up-count](#) command to determine when a device is reachable.

The no parameter resets this command to the default value.

Syntax `sample-size <1-100>`

`no sample size`

Parameter	Description
<1-100>	Number of pings that determines critical and up counts. Default: 5

Mode Ping Polling Configuration

Examples To set the sample-size to 50, use the command:

```
awplus(config-ping-poll)#sample-size 50
```

To reset sample-size to the default of 5, use the command:

```
awplus(config-ping-poll)#no sample-size
```

Related Commands

- [critical-interval](#)
- [fail-count](#)
- [normal-interval](#)
- [ping-poll](#)
- [show ping-poll](#)
- [timeout \(ping polling\)](#)
- [up-count](#)

show counter ping-poll

This command displays the counters for ping polling.

Syntax `show counter ping-poll [<1-100>]`

Parameter	Description
<1-100>	A unique ping poll ID number. This displays the counters for the specified ping poll only. If you do not specify a ping poll, then this command displays counters for all ping polls.

Mode Exec and Privileged Exec

Output Figure 86-1: Example output from the **show counter ping-poll** command

```

Ping-polling counters
Ping-poll: 1
PingsSent          ..... 15
PingsFailedUpState ..... 0
PingsFailedDownState ..... 0
ErrorSendingPing    ..... 2
CurrentUpCount      ..... 13
CurrentFailCount    ..... 0
UpStateEntered      ..... 0
DownStateEntered    ..... 0

Ping-poll: 2
PingsSent          ..... 15
PingsFailedUpState ..... 0
PingsFailedDownState ..... 0
ErrorSendingPing    ..... 2
CurrentUpCount      ..... 13
CurrentFailCount    ..... 0
UpStateEntered      ..... 0
DownStateEntered    ..... 0

Ping-poll: 5
PingsSent          ..... 13
PingsFailedUpState ..... 0
PingsFailedDownState ..... 2
ErrorSendingPing    ..... 2
CurrentUpCount      ..... 9
CurrentFailCount    ..... 0
UpStateEntered      ..... 0
DownStateEntered    ..... 0

```

Table 86-2: Parameters in output of the show counter ping-poll command

Parameter	Meaning
Ping-poll	The ID number of the polling instance.
PingsSent	The total number of pings generated by the polling instance.
PingsFailedUpState	The number of unanswered pings while the target device is in the Up state. This is a cumulative counter for multiple occurrences of the Up state.

Table 86-2: Parameters in output of the show counter ping-poll command

Parameter	Meaning
PingsFailedDownState	Number of unanswered pings while the target device is in the Down state. This is a cumulative counter for multiple occurrences of the Down state.
ErrorSendingPing	The number of pings that were not successfully sent to the target device. This error can occur when your device does not have a route to the destination.
CurrentUpCount	The current number of sequential ping replies.
CurrentFailCount	The number of ping requests that have not received a ping reply in the current sample-size window.
UpStateEntered	Number of times the target device has entered the Up state.
DownStateEntered	Number of times the target device has entered the Down state.

Examples To display counters for the polling instances, use the command:

```
awplus#show counter ping-poll
```

Related Commands [debug ping-poll](#)
[ping-poll](#)
[show ping-poll](#)

show ping-poll

This command displays the settings and status of ping polls.

Syntax `show ping-poll [<1-100>|state {up|down}] [brief]`

Parameter	Description
<1-100>	Displays settings and status for the specified polling instance.
state	Displays polling instances based on whether the device they are polling is currently reachable or unreachable.
up	Displays polling instance where the device state is reachable.
down	Displays polling instances where the device state is unreachable.
brief	Displays a summary of the state of ping polls, and the devices they are polling.

Mode Exec and Privileged Exec

Output Figure 86-2: Example output from the **show ping-poll brief** command

```

Ping Poll Configuration
-----
Id Enabled State Destination
-----
1  Yes      Down  192.168.0.1
2  Yes      Up    192.168.0.100

```

Table 86-3: Parameters in output of the show ping-poll brief command

Parameter	Meaning
Id	The ID number of the polling instance, set when creating the polling instance with the <code>ping-poll</code> command.
Enabled	Whether the polling instance is enabled or disabled.

Parameter	Meaning
State	The current status of the device being polled:
	Up The device is reachable.
	Down The device is unreachable.
	Critical Up The device is reachable but recently the polling instance has not received some ping replies, so the polled device may be going down.
	Critical Down The device is unreachable but the polling instance received a reply to the last ping packet, so the polled device may be coming back up.
Destination	The IP address of the polled device, set with the ip (ping polling) command.

Figure 86-3: Example output from the **show ping-poll** command

```

Ping Poll Configuration
-----

Poll 1:
Description                : Primary Gateway
Destination IP address      : 192.168.0.1
Status                     : Down
Enabled                    : Yes
Source IP address          : 192.168.0.10
Critical interval          : 1
Normal interval            : 30
Fail count                 : 10
Up count                   : 5
Sample size                : 50
Length                    : 32
Timeout                   : 1
Debugging                  : Enabled

Poll 2:
Description                : Secondary Gateway
Destination IP address      : 192.168.0.100
Status                     : Up
Enabled                    : Yes
Source IP address          : Default
Critical interval          : 5
Normal interval            : 60
Fail count                 : 20
Up count                   : 30
Sample size                : 100
Length                    : 56
Timeout                   : 2
Debugging                  : Enabled

```

Table 86-4: Parameters in output of the show ping-poll command

Parameter	Meaning								
Description	Optional description set for the polling instance with the description (ping polling) command.								
Destination IP address	The IP address of the polled device, set with the ip (ping polling) command.								
Status	The current status of the device being polled: <table> <tr> <td>Up</td><td>The device is reachable.</td></tr> <tr> <td>Down</td><td>The device is unreachable.</td></tr> <tr> <td>Critical Up</td><td>The device is reachable but recently the polling instance has not received some ping replies, so the polled device may be going down.</td></tr> <tr> <td>Critical Down</td><td>The device is unreachable but the polling instance received a reply to the last ping packet, so the polled device may be coming back up.</td></tr> </table>	Up	The device is reachable.	Down	The device is unreachable.	Critical Up	The device is reachable but recently the polling instance has not received some ping replies, so the polled device may be going down.	Critical Down	The device is unreachable but the polling instance received a reply to the last ping packet, so the polled device may be coming back up.
Up	The device is reachable.								
Down	The device is unreachable.								
Critical Up	The device is reachable but recently the polling instance has not received some ping replies, so the polled device may be going down.								
Critical Down	The device is unreachable but the polling instance received a reply to the last ping packet, so the polled device may be coming back up.								
Enabled	Whether the polling instance is enabled or disabled. The active (ping polling) and no active commands enable and disable a polling instance.								

Table 86-4: Parameters in output of the show ping-poll command(Continued)

Parameter	Meaning
Source IP address	The source IP address sent in the ping packets. This is set using the source-ip command.
Critical interval	The time period in seconds between pings when the polling instance has not received a reply to at least one ping, and when the device is unreachable. This is set with the critical-interval command.
Normal interval	The time period between pings when the device is reachable. This is set with the normal-interval command.
Fail count	The number of pings that must be unanswered, within the total number of pings specified by the sample-size command, for the polling instance to consider the device unreachable. This is set using the fail-count command.
Up count	The number of consecutive pings that the polling instance must receive a reply to before classifying the device reachable again. This is set using the up-count command.
Sample size	The total number of pings that the polling instance inspects when determining whether a device is unreachable. This is set using the sample-size command.
Length	The number of data bytes to include in the data portion of the ping packet. This is set using the length (ping poll data) command.
Timeout	The time in seconds that the polling instance waits for a response to a ping packet. This is set using the timeout (ping polling) command.
Debugging	Indicates whether ping polling debugging is Enabled or Disabled. This is set using the debug ping-poll command.

Examples To display the ping poll settings and the status of all the polls, use the command:

```
awplus#show ping-poll
```

To display a summary of the ping poll settings, use the command:

```
awplus#show ping-poll brief
```

To display the settings for ping poll 6, use the command:

```
awplus#show ping-poll 6
```

To display a summary of the state of ping poll 6, use the command:

```
awplus#show ping-poll 6 brief
```

To display the settings of ping polls that have reachable devices, use the command:

```
awplus#show ping-poll state up
```

To display a summary of ping polls that have unreachable devices, use the command:

```
awplus#show ping-poll 6 state down brief
```

Related Commands [debug ping-poll](#)
[ping-poll](#)

source-ip

This command specifies the source IP address to use in ping packets.

By default, the polling instance uses the address of the interface through which it transmits the ping packets. It uses the device's local interface IP address when it is set. Otherwise, the IP address of the interface through which it transmits the ping packets is used.

The no form resets the source IP in the packets to the device's local interface IP address.

Syntax `source-ip {<ip_address>}`
`no source-ip`

Parameter	Description
<ip_address>	An IPv4 address in dotted decimal notation.

Mode Ping Polling Configuration

Examples To configure the polling instance to use the source IP address 192.168.0.1 in ping packets, use the command:

```
awplus(config-ping-poll)#source-ip 192.168.0.1
```

To reset the source IP address to the device's local interface IP address, use the command:

```
awplus(config-ping-poll)#no source-ip
```

Related Commands `description (ping polling)`
`ip (ping polling)`
`length (ping poll data)`
`ping-poll`
`show ping-poll`

timeout (ping polling)

This command specifies the time in seconds that the polling instance waits for a response to a ping packet. You may find a higher time-out useful in networks where ping packets have a low priority.

The no parameter resets the set time out to the default of one second.

Syntax `time-out <1-30>`
`no time-out`

Parameter	Description
<1-30>	Length of time, in seconds, that the polling instance waits for a response from the polled device. Default: 1

Mode Ping Polling Configuration

Examples To specify the time-out as 5 seconds, use the command:

```
awplus(config-ping-poll)#timeout 5
```

To reset the time-out to its default of 1 second, use the command:

```
awplus(config-ping-poll)#no timeout
```

Related Commands [critical-interval](#)
[fail-count](#)
[normal-interval](#)
[ping-poll](#)
[sample-size](#)
[show ping-poll](#)
[up-count](#)

up-count

This command sets the number of consecutive pings that the polling instance must receive a reply to before classifying the device reachable again.

The no parameter resets the up count to the default of 30.

Syntax up-count <1-100>

no up-count

Parameter	Description
<1-100>	Number of replied pings before an unreachable device is classified as reachable. Default: 30

Mode Ping Polling Configuration

Examples To set the upcount to 5 consecutive pings, use the command:

```
awplus(config-ping-poll)#up-count 5
```

To reset the upcount to the default value of 30 consecutive pings, use the command:

```
awplus(config-ping-poll)#no up-count
```

Related Commands

- critical-interval
- fail-count
- normal-interval
- ping-poll
- sample-size
- show ping-poll
- timeout (ping polling)

Part 8: Virtual Chassis Stacking



This part contains the following chapters:

- [Chapter 87 Stacking Introduction](#)
- [Chapter 88 Stacking Commands](#)

Chapter 87: Stacking Introduction



VCS Introduction.....	87.2
VCS Supported Platforms.....	87.2
Features of Virtual Chassis Stacking	87.2
The Physical Stack	87.3
Two Switch Stack Configuration	87.3
Resilient Stacked Topology.....	87.6
Stack Formation	87.8
The Role of the Stack Master.....	87.8
Stack Management VLAN	87.9
Stack Member Failure and Recovery	87.12
Fixed or Virtual MAC Addressing.....	87.12
Stack Resiliency Link.....	87.13
VCS Failure Recovery.....	87.15
Stack Maintenance.....	87.16
Software Version Auto Synchronization.....	87.17
Introduction	87.17
How Autosynchronization Works.....	87.17

VCS Introduction

This chapter describes Virtual Chassis Stacking (VCS), its features, and basic connection examples.

A Virtual Chassis Stack (VCS) is a group of physically separate switches that are connected so as to function as a single logical switch. In order to function as a VCS, its component switches are connected using high-speed stacking links. Version 5.3.3-0.1 supports a maximum of four devices per stack on the x600 series switches and two devices per stack on the x900 and SwitchBlade x908 series switches.

VCS Supported Platforms

VCS is supported on the following switch types:

- x900-24XT, x900-24XS, x900-24XT-N
- x900-12XT/s
- SwitchBlade® x908, and
- x600 series.

Switches must be of the same product type to exist within the same stack. The principles of product / stack compatibility is shown in the following table.

Table 87-1: Stacking compatibility by product type

Product Types	x900-24XS, x900-24XT, x900-24XT-N	Via XEM-STK ports.
Product Type	x900-12XT/s	Via XEM-STK ports.
Product Type	SwitchBlade® x908	Via either XEM-STK ports, or high speed rear chassis ports.
Product Type	x600 (all variants)	Via AT-StackXG ports.

Features of Virtual Chassis Stacking

Creating a VCS greatly eases network management, because you can configure all the stacked devices via a single IP address. Creating a VCS will often eliminate your need to configure protocols such as VRRP and Spanning Tree. VCS also enables you to create highly resilient networks. This resiliency can be applied in several ways.

Within the stack itself, switch interconnection is via two links. The second link is able to provide an alternative data path, thus the stack will continue to function if a single switch fails. Degraded performance might occur however, due to the reduced VCS bandwidth.

User ports can also be made extremely resilient by utilizing link aggregation. Aggregated links can span ports, modules, and even switches within the stack. Creating aggregated links that span multiple switches within a stack creates an extremely resilient configuration. Communication will still exist even if a switch and its aggregated ports fail. Refer to [Figure 87-6 on page 87.6](#).


The Physical Stack

A stack - depending on the switch types used - can comprise from 2 to 4 individual stack members interconnected via high speed stacking links. A stack always has a primary stack member called the *stack master*, and can contain up to 3 other stack members.

AT-StackXG Modules, Cables, and Connections

The stacks are connected using VCS Stacking Modules (AT-StackXG). The AT-StackXG module is located in the bay at the rear of the switch. [Figure 87-1](#) shows a VCS Stacking module.

Figure 87-1: VCS Stacking Module (AT-StackXG)




The following cables are used to connect the stacking ports of x600 series switches:

- High Speed Stacking Cable (0.5 meter long) AT-StackXG/0.5-00
- High Speed Stacking Cable (1 meter long) AT-StackXG/1-00

Two Switch Stack Configuration

This configuration, shown in [Figure 87-2](#), uses two switches that are connected back to back via two high-speed stacking links. Note that stacking ports labeled 1 must connect to stacking ports labeled 2. In this configuration the stack can still function using only a single high speed link.

Figure 87-2: Back-to-Back Topology (x600 Switches)



Resiliency Link

The resiliency link carries no network data. Its function is to provide additional stack status information to enable the stack members to more accurately decide whether it is appropriate for one of them to take over the role as stack master if the existing master fails. See [“Stack Resiliency Link” on page 87.13](#).

A resiliency link operates using a resiliency link VLAN to which resiliency link switch ports can become members.

Resiliency Link Configurations via Switch Ports

Two resiliency-link configurations that connect to switch ports are shown below: [Figure 87-3](#) shows the resiliency link connecting in a ring topology, whilst [Figure 87-4](#) shows the resiliency link connecting to the switch ports via a network hub. In both configurations, the resiliency link connections are made using the ResiliencyLink VLAN and attaching the switch ports to the VLAN. For more information on using the resiliency link commands see: [stack resiliencylink command on page 88.27](#) and [switchport resiliencylink command on page 88.32](#).

Figure 87-3: Resiliency link connecting to switch ports over the ResiliencyLink VLAN






Figure 87-4: Resiliency link connecting to switch ports over the ResiliencyLink VLAN Using a network hub.



Ring Configuration

A virtual stack using x600 switches can comprise up to 4 stack members connected in a ring topology. Figure 87-5 shows a ring comprising 3 stacked x600 series switches. Because an alternate path is provided between the stack members, this topology offers a very resilient configuration.


Figure 87-5: VCS Ring Topology Using x600 Switches



Resilient Stacked Topology

Where network connectivity uptime is a major criteria, you can use virtual chassis stacking to create highly reliable network configurations. The network shown in [Figure 87-6](#) employs duplicate links and switches to create a stacked network that offers extremely reliable user connectivity.

Figure 87-6: VCS Resilient Stacked Topology Example



This network employs two SwitchBlade® x908 switches to form an expandable network core. These switches are stacked and so appear as a single logical switch (note that smaller switches such as the x600 can be also be used to form the stacked core).


This network topology supplies multiple dual connections to a number of downstream distribution switches that can in turn connect to user devices. Similarly, the dual network paths provide very reliable connectivity to the server aggregation portion of the network.

Employing link aggregation rather than spanning tree to manage the parallel paths, enables the bandwidth of both data links to be utilized under normal conditions, whilst enabling a single data link to operate should its partner link fail.

Stack Formation

As previously mentioned, a VCS always contains a master plus a number of stack members. To be part of a stack, a switch must connect to other potential stack members via dedicated stacking ports. These ports are contained within a dedicated stacking module, the AT-StackXG. This module is located in the stacking bay at the rear of the switch. [Figure 87-7](#) shows a stacking AT-StackXG module.

Figure 87-7: VCS Stacking Module (AT-StackXG)



Once the switches have been physically connected to form a stack, powering all the members on automatically sets off a number of processes that enable the stack members to detect the presence of the other stack members and form themselves into a VCS.

The Role of the Stack Master

In addition to being a member of its VCS stack, the stack master manages functions such as software version control and distribution, routing processing, and network management.

Selecting the Stack Master

The stack members are able to automatically select which switch will become the stack master. This selection is based on two components:

1. The stack member's priority setting.
2. The stack member's MAC address.

For both components, the lower the number the higher the priority. To set the stack priority, run the [stack priority command on page 88.24](#). Note that changes to these settings will not take effect until the next master re-election. To display these components run the [show stack command on page 88.15](#).

The master is the switch with the lowest 'priority setting', or if no 'priority settings' are configured, the switch with the lowest MAC address will become the stack master. When a stack member is initially booted, its priority value defaults to 128. Therefore if all switches retain their defaults, then the stack master will be determined by MAC address comparison.

The stack also assigns a Stack Member-ID number to each member. This number provides a unique reference number for switches within the stack; it plays no part in selecting the stack master. The Stack Member-ID is the entity used as the first digit of the three component port identifier numbers. For example, port number 2.0.14 has the Stack Member-ID of 2.

Note: *This last point is an important one to remember when using configuration scripts. You should ensure that you modify your configuration scripts to match any changes you have made to the Stack Member-ID assignments.*

Note: The ability to independently set both a stack member's priority and its ID means that the stack master does not need to have an ID of 1; although configuration is simplified by arranging for ID 1 to be the device with the lowest priority value - and thereby forcing it to be the stack master. If you create a stack using new switches, the following (simplified) process should ensure that the master member has an ID of 1.

New switches are shipped with a Stack Member-ID of 1 and a priority of 128. If four such switches are created as a stack, the switch with the lowest MAC address will be selected to be the stack master (because all priority settings are 128). The remaining three stack member devices will then reboot. The stack master does not reboot and retains its Stack Member-ID of 1.

You can change the Stack Member-ID by using the [stack renumber command on page 88.25](#).

Common Stack Configuration

Once the switches have configured themselves into a VCS stack, they all share the same configuration information and startup scripts.

Stack Management VLAN

Managing the stack is the same as managing an individual switch. You can connect to the asynchronous console port of any stack member, or you can set an IP address on a network VLAN (for example, VLAN 1) and use SSH for remote access.

As the switches form themselves into a stack, each switch creates a common stack management VLAN and a management IP address. Both the VLAN ID and the IP address are internal entities that are used between the stacked switches, via the AT-StackXG interfaces, and therefore do not appear on the user network.

Initially the stack assigns the default VLAN tag ID of 4094 to the management VLAN, and assigns an IP address from the subnet 192.168.255.0 / 28 to this VLAN as the management IP address. Once the stack has formed, you can change both these settings. To change the VLAN ID use the [stack management vlan command on page 88.23](#). To change the management IP address use the [stack management subnet command on page 88.22](#). Note however, that you must keep the 28 bit subnet mask, (/28 or 255.255.255.240). Also note that because the stack's internal address mapping tables will register the management VLAN ID and the management IP address, these must be unique across the stack's internal and external network. To view the current settings for the stack management VLAN ID and IP address, use the [show stack command on page 88.15](#).

Stack member identification

When a switch becomes a member of a VCS Stack it is assigned a Stack Member-ID. Stack status information is displayed on the STACK LEDs shown on the switch's front panel shown [Figure 87-8](#) below. The following LEDs indicate the switch's status within the stack.

To observe the Stack Member-ID of the switch, you first run the [show stack indicator command on page 88.19](#). Running this command causes the MASTER LED (located within the STATUS LED column) to initially turn off. A flash sequence then appears followed by a pause. The number of flashes within each sequence is the same as the Stack Member-ID of the switch. For example, if the switch had the Stack Member-ID 4, then the MASTER LED would flash 4 times followed by a pause, then 4 times again. Note that the MSTR LED that is located within the STACK LED column, does not perform this function.

Figure 87-8: Stack Status LEDs




Figure 87-9: Stacking LED Functions

LED	State	Description
Stack LEDs		
MSTR	Green ON	The switch is the Stack Master.
	Green OFF	The switch is acting as a stack back-up member.
1- L/A	Green ON	Link on stacking port 1 is active.
	Green Flashing	Indicates traffic flowing through stacking port 1
	Green OFF	Link on stacking port 1 is inactive.
2- L/A	Green ON	Link on stacking port 2 is active.
	Green Flashing	Indicates traffic flowing through stacking port 2.
	Green OFF	Link on stacking port 2 is inactive.
PRES	Green ON	Stacking Module (AT-StackXG) or Loopback Module (AT-LBM) has been inserted, i.e. is PRESENT.
Status LEDs		
MASTER	Green ON	The switch is the Stack Master.
	Green Flashing	When the show stack indicator command is activated, this LED will flash with a pattern that indicates the stack member ID of the switch.

Running commands on specific stack members

In some situations you may want to obtain information that is specific to a particular stack member. To achieve this you can use the remote-command feature. For example, to see the processes running on stack member 3, you can run the following remote-command:

```
awplus# remote-command 3 show process
```

For more information and options on this feature, see [remote-command command on page 88.6](#) of this manual.

Running QoS within a VCS stack

In general you can apply the same principles when configuring QoS on a VCS stack as you would for single switch; however there are a few specific changes that you will need to make.

Switches within a VCS stack, exchange their stack management information and user data over their high speed inter-stacking links. The stack management information is pre-assigned to the egress queue 7. This is the highest value queue, and (in a stacked configuration) its traffic should not be shared with any user data. However, any CoS tagging of 7 applied to the incoming data will automatically be assign to queue 7 as it crosses the internal stacking links. You will therefore need to reconfigure your CoS to Queue settings to ensure that no user data is sent to queue 7.

To prevent this from happening, we recommend that you make appropriate changes to your queue settings (mappings) to reflect the stacking requirement previously described. For more information on this topic, see [“Mapping CoS tags to traffic types” on page 52.12](#).

This process should include (but not be limited to) running the following command to ensure that any remaining user packets still carrying a CoS 7 tag, will be mapped to egress queue 6.

To remap priority CoS traffic to egress queue 6, run the following command.

```
awplus# config terminal

awplus(config)# mls qos map cos-queue 7 to 6
```

Stack Member Failure and Recovery

Fixed or Virtual MAC Addressing

A VCS Stack operates using a single virtual MAC address. This address is configurable by using the [stack virtual-mac command on page 88.31](#).

Stack virtual-MAC Command Enabled

When the [stack virtual-mac](#) command is enabled, the stack uses a virtual MAC address that is either manually entered, or has been randomly selected from an allocated pool of MAC addresses. The stack will then always use this MAC address even if the stack master fails or is removed from the stack. In this situation, the new elected master will still retain the originally configured virtual MAC address.

The virtual MAC address will be used for all external ports, and VLAN interfaces, except the management VLAN. Although each individual switch in the stack retains its own native MAC address; this is only used over the stack management VLAN.

Note: When a switch joins an existing stack that is using virtual MAC addressing, the new member switch must have its stack virtual-MAC command enabled. During the stack membership process the new stack member will be assigned the virtual-MAC that is currently operated by the stack. This value will overwrite any value that is already configured within the new member switch.

Virtual-MAC format and value

The virtual-MAC address is selected from within the range 0000.cd37.0000 to 0000.cd37.0FFF. This can be considered as a MAC prefix component of 0000.cd37.0xxx. Where xxx is called the stack virtual-chassis-ID, and has the range 000 to FFF.

Manually selected virtual address

To manually select a virtual-MAC address you enable the stack virtual-MAC feature by using the commands:

```
awplus# configure terminal
awplus(config)# stack virtual-mac
```

Then configure the [stack virtual-chassis-id command on page 88.30](#) to set a stack virtual-chassis-ID of your chosen value - entered as a decimal number within the range 0 to 4095. The value 120 is used in the following example:

```
awplus# configure terminal
awplus(config)# stack virtual-chassis-id 120
```


Automatically selected virtual address

If you set the `stack virtual-mac` command without entering a value for the stack virtual-chassis-ID, the switch will randomly select a virtual-chassis-ID from the allocated range.

Note: For resilient operation, you should set the stack virtual-chassis-ID in your fallback configuration to be a different value to the one configured for normal operation.

Stack virtual-MAC Command Disabled

When the `stack virtual-mac` command is disabled, the stack will use the MAC address of the current Master. If the stack master fails, the stack MAC address changes to reflect the new master's MAC address. If the stack MAC address does change, ARP tables of devices on the network will update to reflect the change in MAC address via `ip gratuitous-arp-link` command on page 25.16.

Stack Resiliency Link

The purpose of the resiliency link is to provide the stack members with status information that enables them to detect whether the stack master is still operational after it has suffered either a power-down or software lock-up. This enables the other stack members to either operate in the fall-back mode, or to re-elect a new stack master. The “State Change Table” on page 87.13 shows how the stack members respond to various problems occurring on the master node.

Stack Recovery States

The following state-change-table shows stack member failure conditions and recovery actions in situations where the resiliency link is present or absent.

Table 87-2: State Change Table

Event on Master Node	Reaction on Master	Reaction on Stack Member	Reaction on Stack Member
		With Resiliency Link	Without Resiliency Link
Both stack links removed	No change	Fallback action ¹	Re-elect master ²
XEM-STK Removed or Faulty	No change	Fallback action ¹	Re-elect master ²
Hardware reset (or fault)	Reset / offline	Re-elect master	Re-elect master ²
Run the no stack enable command ³	No change	Fallback action ¹	Not allowed Displays Error Message
Software application problem (lock-up or continual crashes)	Reboot as stack member	Re-elect master	Re-elect master
Software crash or lock-up	Frozen ⁴	Re-elect master	Re-elect master
Power-down or PSU failure	Powered down	Re-elect master	Re-elect master
Event on Stack Member Node	Reaction on Master	Reaction on Stack Member	Reaction on Stack Member
Both stack links removed	No change	Fallback action ¹	Re-elect master ²
XEM-STK removed or faulty	No change	Fallback action ¹	Re-elect master ²
Hardware reset (or fault)	No change	Reset/offline	Reset/offline

Table 87-2: State Change Table

Run the no stack enable command ³	No change	Fallback action ¹	Fallback action ¹
Software application failover (lock-up or continual crashes)	No change	Re-boot as slave	Reboot as stack member
software crash or lock-up	No change	Frozen ⁴	Frozen ⁴
Power-down / PSU failure	No change	Powered Down	Powered down

1. The fallback action on a slave is first to run the fallback config script. Where there is no fallback script, the switch will disable all its switch ports.
2. The stack member assumes the role of stack master. In specific situations this condition could result in a stack containing two masters. This would present problems with network management and the control of links that were previously aggregated.
3. The following situation will apply to a switch that has been removed from the stack by the using the “no stack enable” command:
 - « The switch will be unaware of further faults within the stack it was previously a member of.
 - « Should this switch then be powered down, all links previously shutdown (as a result of running the “no stack enable command”) will remain down.
4. If the slave's ports are still up, this may cause downstream switches with trunked ports to operate incorrectly.

VCS Failure Recovery

If the stack master either fails, or is removed, the other stack members will decide which of two actions to take.

1. Fallback action.
2. Re-elect a new stack master.

Note that a master fail-over will be slower than a stack member failure, and will require the restart (reconvergence) of routing protocols such as RIP.

Table 87-2 shows how the stack (non-master) members would respond to various problems occurring on the stack master stack.

Fallback Action

To initiate this action, the remaining stack members will disable all ports, then re-enable them using the fallback config file.

In order to provide an efficient alternative configuration, you should create a fallback config file that reflects the most appropriate working configuration for the failures that you feel are most likely to occur. One way to do this is to create a fall back file from your working system, then edit this file to provide an appropriate backup system configuration. See [stack fallback-config command on page 88.21](#).

Note: The stack fallback-config command will be deprecated in a future release. The redundancy provided by the fallback-config will be supported on future releases, but it will be configured in a different way. Information will be provided in future release notes on how to migrate your current fallback configuration to new functionality.

Re-elect New Stack Master

The stack members automatically determine which of them becomes the new VCS master.

Recombining Separated Stacks

When two separated stack units (stubs) are reconnected, a condition known as 'multiple master' will be detected. In this situation, a new VCS master is elected based upon the lowest Priority ID or (where both members have the same Priority ID) the lowest MAC address. The 'losing' master and the other prospective stack members will then reboot and join the new stack as ordinary stack members.

Stack Maintenance

Adding a Stack Member

An unstacked switch can be added to an existing stack (hot swapped in) with minimal impact on traffic. To do this, power down the new member switch, then connect its stacking ports and power on the switch. The switch will boot as a member of the stack.

Note: The existing Stack Member-ID and the device MAC address will have no effect on the status of the new member switch. The stack will admit the new device as ordinary stack member and allocate it a new Stack Member-ID if its ID is one that already exists.

However, for good practice we recommend pre-configuring the new member with settings that are appropriate for when the new switch becomes a stack member. This is to avoid unexpected situations occurring when the stack is rebooted. For example, if the new member had a priority setting that was lower than 128 and all the existing stack members were configured with the default; then, when the stack is rebooted, the new member would be elected as the stack master.

Replacing a Stack Member

A stack member can be removed from a stack (hot swap out) with minimal impact on stack traffic. To do this power-down the stack member, disconnect its AT-StackXG ports. Insert the new stack member, reconnect the stacking ports and power-up the new stack member.

You can seamlessly swap a stack member switch into the stack to replace another with the same configuration. This provides a simple way to replace an out of service switch with minimal impact, and minimal administration requirement. You should configure the replacement switch with the same member ID as its replacement prior to its insertion into the stack.

Repairing a Broken Stub

Stack stubs occur when a fault results in stack splitting into two, with one of the stack members takes on the role of stack master. Where (unknown to some of the stack members) the master is still active, the result can be two independently operating stacks. These are termed stubs.

When two stub stacks are reconnected, a dual master situation will be detected, and the console log will display the message, 'duplicate master' was detected. This situation results in the re-election of the stack master. The losing master will return to being a stack member.

Note: Stubs are unlikely to occur where resiliency links are used.

Software Version Auto Synchronization

Introduction

Different software releases have functional and operational differences between them. To maintain consistent behavior across the stack, all new member switches must be running the same software release before they can fully join the stack.

Manually upgrading the software release of each new stack member joins a stack would be a cumbersome process. The VCS software version auto synchronization feature automates this process by ensuring the same software release is used on all stack members, and automatically upgrading stack members where required.

How Autosynchronization Works

Software version comparison

When the stack is formed, it elects one of its switches to become the master. The software release running on the stack master will then become the software version used throughout the stack. After a master is elected, all the stack members compare their current software version with the version that is running on the stack master.

If the comparison process detects differences between software versions, the software version synchronization feature will automatically copy the master's software release onto the appropriate stack members. Once the software release has successfully been copied, this version will become the boot software for that particular stack member, which will then reboot in order to load the new software release.

If a software version running on a stack member is incompatible with that running on the master, and software-auto-synchronization is turned off, then that switch will be removed as a stack member. See [stack software-auto-synchronize command on page 88.29](#).

When auto-synchronization upgrades a stack member, the member's current running software will be set as the backup software release. If there are any problems loading the new software, this backup will be used to recover. If the stack member does not have enough free flash space for the new release, then the new release will replace the oldest release file in flash, which is determined by the oldest software build date. If the current release is the only release file in flash, then the current release will be overwritten.

Autosynchronization Limitations

Because the stack master's software version gets applied to the rest of the stack, care must be taken to ensure the correct switch is elected master. If the master is running an older software release, then software version auto synchronization may actually downgrade the software releases running on other stack members. For configuring which stack member becomes the master, see the [stack priority command on page 88.24](#).

Software auto-synchronization will not work if stack members are booting using either one-off boot or from TFTP or ymodem. In these situations, any stack members running different software will boot as standalone devices.

If software-auto-synchronization is configured as off for a stack member that is running a different software release to the master, by applying the command, no stack software-auto-synchronize, then that switch will boot as a standalone device. For more information, see the [stack software-auto-synchronize command on page 88.29](#).

Incompatible Software Releases

The auto-synchronization feature will not always work if there have been significant VCS or system changes between the two different software releases. The VCS discovery of other stack members uses an internal 'stack S/W version' to detect compatibility between builds.

If the VCS software between two stack members is incompatible, the software auto-synchronization feature will not work. Instead, a "incompatible stack S/W version" log message will be displayed and both stack members will boot as standalone devices. This is an undesirable situation because both devices may load the same configuration file, which could cause network conflicts. In order to avoid this situation when upgrading the stack to a new major release, ensure the 'boot system' command succeeds.

In general, the software-auto-synchronize feature will always work between maintenance releases, such as between 5.3.2-0.1 and 5.3.2-0.2, but may not work between major releases that have new VCS features, such as between 5.2.2-0.9 and 5.3.2-0.2.

Upgrading Stack Software Reliably

When upgrading a stack to a new software release, the [boot system command on page 7.5](#) will automatically synchronize the new software release across all stack members. However, this command can sometimes fail to set the release on a backup member due to insufficient free flash space for the new release file. If this occurs when upgrading to a new major software release, try deleting some files on the backup member to free up flash memory space, and then rerun the [boot system](#) command.

If you are unsure which files to delete, the following process may assist you:

Substitute awplus for the hostname in the configuration, and use awplus-3 for stack member-3, and so on.

```
dir awplus-2/flash:*
```

Look for any `.rel` (release) files, or `.tgz` and `.gz` (diagnostic) files that are no longer needed. Then use the full filepath displayed in the `dir` output as the file to delete. For example:

```
delete awplus-2/flash:/r1-5.2.1-0.9.rel
```

Chapter 88: Stacking Commands



Introduction.....	88.2
debug stack.....	88.3
reboot.....	88.4
reload.....	88.5
remote-command.....	88.6
show counter stack.....	88.8
show debugging stack.....	88.13
show running-config stack.....	88.14
show stack.....	88.15
show stack full-debug	88.18
show stack indicator	88.19
stack enable.....	88.20
stack fallback-config.....	88.21
stack management subnet	88.22
stack management vlan.....	88.23
stack priority.....	88.24
stack renumber	88.25
stack renumber cascade.....	88.26
stack resiliencylink.....	88.27
stack software-auto-synchronize	88.29
stack virtual-chassis-id	88.30
stack virtual-mac	88.31
switchport resiliencylink.....	88.32

Introduction

This chapter provides an alphabetized reference for each of the Stacking Commands. Also note the following stacking trigger commands that are documented in the Triggers chapter:

[type stack master-fail command on page 84.23](#)
[type stack member command on page 84.24](#)
[type stack link command on page 84.25](#)

In addition to the stacking commands shown in this chapter, stacking content also exists in the following commands:

[hostname command on page 8.11](#)
[reboot command on page 88.4](#)
[show cpu command on page 8.15](#)
[show cpu history command on page 8.19](#)
[show exception log](#)
[show file systems command on page 7.25](#)
[show memory command on page 8.22](#)
[show memory allocations command on page 8.24](#)
[show memory history command on page 8.26](#)
[show process command on page 8.29](#)
[show running-config stack command on page 88.14](#)
[show system command on page 8.32](#)

debug stack

This command enables the Virtual Chassis Stacking (VCS) debugging facilities.

Syntax `debug stack [link|topology|trace]`
`no debug stack [link|topology|trace]`

Parameter	Description
no	Negate a command or set its defaults
debug	Debugging functions
stack	Virtual Chassis Stack (VCS)
link	Stacking neighbor discovery events on stack links
topology	Stacking topology discovery messages
trace	Notable stacking events

Default Stack trace debugging is enabled.

Mode Privileged Exec and Global Configuration

Usage This command enables the Virtual Chassis Stacking (VCS) debugging facilities. It can only be entered on the stack master.

The command displays debug information about the stacked devices. If no parameter is specified, all the stack debugging information will be displayed, including link events, topology discovery messages and all notable stacking events. If link parameter is specified, only the link events debugging information will be displayed.

Examples To enable debugging, enter the following command on the stack master:

```
awplus# debug stack
```

To enable link debugging, enter the following command on the stack master:

```
awplus# debug stack link
```

To enable topology discovery debugging, enter the following command on the stack master:

```
awplus# debug stack topology
```

To enable stack trace debugging, enter the following command on the stack master:

```
awplus# debug stack trace
```

reboot

This command is an alias to the [reload command on page 88.5](#). This command currently halts and performs a cold restart on either the whole stack, or a selected stack member.

Syntax `reboot [stack-member <1-8>]`

Parameter	Description
<code>reboot</code>	Halt and perform a cold restart
<code>stack-member</code>	Reboot will only operate on a specific stack member
<code><1-8></code>	The ID of the stack member that needs to be rebooted

Mode Privileged Exec

Usage This command currently halts and perform a cold restart on either a specific device or a whole device stack.

For stand alone devices:

Executing this command will reboot the device. Before the reboot occurs, you will receive a confirmation request saying: "reboot system? (y/n):".

For stacked devices:

To reboot a selected device within a stack, you enter the stack-member parameter and specify the stack member ID (1 to 8) of the device you want to reboot. Before the reboot occurs, you will receive a confirmation request saying: "reboot stack-member <specific stack-member ID> system? (y/n):".

If the specified stack member ID does not exist in the current stack, the command will be rejected.

Executing this command with no parameters specified, will reboot all devices in the stack. Before the reboot occurs, you will receive a confirmation request saying: "Are you sure you want to reboot the whole stack? (y/n):".

Examples To reboot the entire stack:

```
awplus# reboot
Are you sure you want to reboot the whole stack? (y/n): y
```

To reboot a specific stack member:

```
awplus# reboot stack-member 3
reboot stack-member 3 system? (y/n): y
```

Related Commands [reload](#)

reload

This command currently halts and performs a cold restart on either the whole stack, or a selected stack member. It performs the same function as the [reboot command on page 88.4](#).

Syntax `reload [stack-member <1-8>]`

Parameter	Description
<code>reload</code>	Halt and perform a cold restart
<code>stack-member</code>	Reload will only operate on a specific stack member
<code><1-8></code>	The ID of the stack member that needs to be reloaded

Mode Privileged Exec

Usage This command currently halts and perform a cold restart on either a specific device or a whole device stack.

For stand alone devices:

Executing this command will reload the device. Before the reload occurs, you will receive a confirmation request saying: "reboot system? (y/n):".

For stacked devices:

To reload a selected device within a stack, you enter the stack-member parameter and specify the stack member ID (1 to 8) of the device you want to reboot. Before the reload occurs, you will receive a confirmation request saying: "reboot stack-member <specific stack-member ID> system? (y/n):".

If the specified stack member ID does not exist in the current stack, the command will be rejected.

Executing this command with no parameters specified, will reload all devices in the stack. Before the reload occurs, you will receive a confirmation request saying: "Are you sure you want to reboot the whole stack? (y/n):".

Examples To reload the entire stack:

```
awplus# reload
Are you sure you want to reboot the whole stack? (y/n): y
```

To reload a specific stack member:

```
awplus# reload stack-member 3
reboot stack-member 3 system? (y/n): y
```

Related Commands [reboot](#)

remote-command

Executes a number of host-directed commands that are specific to stack members.

Syntax `remote-command <1-8>`
`show [cpu|counter|file|memory|process|stack|system]`

Remote-command	Remote stack member command, description
<1-8>	The ID of the stack member where the command should be executed on.
cpu	selects the show cpu command on page 8.15
counter	selects the show counter stack command on page 88.8
file	selects the show file command on page 7.24
memory	selects the show memory command on page 8.22
process	selects the show process command on page 8.29
stack	selects the show stack command on page 88.15
system	selects the show system command on page 8.32
show CPU history	selects the show cpu history command on page 8.19
show CPU sort pri	selects the show cpu command on page 8.15 to run with the parameters sort and pri selected.
show CPU sort runtime	selects the show cpu command on page 8.15 to run with the parameters sort and runtime selected.
show CPU sort sleep	selects the show cpu command on page 8.15 to run with the parameters sort and pri selected.
show CPU sort thrds	selects the show cpu command on page 8.15 to run with the parameters sort and thrds selected.
show exception log	selects the show exception log command on page 10.42
show file systems	selects the show file systems command on page 7.25
show log permanent	selects the show file systems command on page 7.25
show log permanent	selects the show log permanent command on page 10.48
show log permanent tail	selects the tail parameter of the show log permanent command on page 10.48 command.
show memory	selects the show memory command on page 8.22 .
show memory history	selects the history parameter of the show memory command on page 8.22 .
show memory sort peak	selects the sort and peak parameters of the show memory command on page 8.22 .

Remote-command(Continued)	Remote stack member command,
show memory sort size	selects the sort and size parameters of the show memory command on page 8.22 .
show memory sort stk	selects the sort and stk parameters of the show memory command on page 8.22 .
show process	selects the show process command on page 8.29 .
show process sort cpu	selects the sort and cpu parameters of the show process command on page 8.29 .
show process sort mem	selects the sort and mem parameters of the show process command on page 8.29 .
show stack	selects the show stack command on page 88.15 .
show stack detail	selects the details parameter of the show stack command on page 88.15 .
show system	selects the details parameter of the show stack command on page 88.15 .
show system environment	selects the show system command on page 8.32 .
show system pluggable	selects the pluggable parameter of the show system command on page 8.32 .
show system serialnumber	selects the serialnumber parameter of the show system command on page 8.32 .

Default None

Mode Privileged Exec, and can be also be used in the same mode as the equivalent non-remote command.

Usage This command is used only from the master to execute a command subset that is specific to stack members. If the member ID is not used by any current stack member, the command will be rejected.

Example To execute show system command on stack member 2:

```
awplus# remote-command 2 show system
```

show counter stack

Displays stacking counter information.

Syntax `show counter stack`

Parameter	Description
show	show running system information
stack	virtual chassis stacking
counters	stacking counters

Default All counters are reset when the stack member is rebooted.

Mode Exec and Privileged Exec

Usage If this command is entered on the stack master, it will display all the stacking counter information for every stack member.

When used as a host-directed command, it will display only the stacking counter information for the specific stack member.

Examples To display the stacking counter information about the whole stack, use the following command on the stack master.

```
awplus# show counter stack
```

To display the stacking counter information about stack member 2, use the command:

```
awplus# remote-command 2 show counter stack
```

Figure 88-1: Example output from the show counter stack command

```

Virtual Chassis Stacking counters

Stack member 1:

Topology Event counters
Units joined          ..... 1
Units left            ..... 0
Links up              ..... 1
Links down            ..... 0
ID conflict            ..... 0
Master conflict        ..... 0
Master failover        ..... 0
Master elected          ..... 1
Master discovered      ..... 0
SW autoupgrades        ..... 0

Stack Port 1 Topology Event counters
Link up                ..... 3
Link down              ..... 2
Nbr re-init            ..... 0
Nbr incompatible       ..... 0
Nbr 2way comms         ..... 1
Nbr full comms         ..... 1

Stack Port 2 Topology Event counters
Link up                ..... 0
Link down              ..... 0
Nbr re-init            ..... 0
Nbr incompatible       ..... 0
Nbr 2way comms         ..... 0
Nbr full comms         ..... 0

Stack Port 2 Topology Event counters
Link up                ..... 0
Link down              ..... 0
Nbr re-init            ..... 0
Nbr incompatible       ..... 0
Nbr 2way comms         ..... 0
Nbr full comms         ..... 0

Topology Message counters
Tx Total               ..... 4
Tx Hellos               ..... 4
Tx Topo DB              ..... 0
Tx Topo update          ..... 0
Tx Link event           ..... 0
Tx Reinitialise         ..... 0
Tx Port 1               ..... 4
Tx Port 2               ..... 0
Tx 1-hop transport      ..... 4
Tx Layer-2 transport    ..... 0
Rx Total               ..... 1
Rx Hellos               ..... 1
Rx Topo DB              ..... 0
Rx Topo update          ..... 0
Rx Link event           ..... 0
Rx Reinitialise         ..... 0
Rx Port 1               ..... 1
Rx Port 2               ..... 0
Rx 1-hop transport      ..... 1
Rx Layer-2 transport    ..... 0

Topology Error counters
Version unsupported     ..... 0
Product unsupported     ..... 0
XEM unsupported         ..... 0
Too many units          ..... 0
Invalid messages        ..... 0

```

Figure 88-1: Example output from the show counter stack command(Continued)

```

Stack member 2:

Topology Event counters
Units joined          ..... 1
Units left            ..... 0
Links up              ..... 1
Links down            ..... 0
ID conflict            ..... 0
Master conflict        ..... 0
Master failover        ..... 0
Master elected          ..... 1
Master discovered      ..... 0
SW autoupgrades        ..... 0

Stack Port 1 Topology Event counters
Link up                ..... 0
Link down              ..... 0
Nbr re-init            ..... 0
Nbr incompatible       ..... 0
Nbr 2way comms         ..... 0
Nbr full comms         ..... 1

Stack Port 2 Topology Event counters
Link up                ..... 1
Link down              ..... 0
Nbr re-init            ..... 0
Nbr incompatible       ..... 0
Nbr 2way comms         ..... 1
Nbr full comms         ..... 0

Topology Message counters
Tx Total                ..... 1
Tx Hellos                ..... 1
Tx Topo DB               ..... 0
Tx Topo update           ..... 0
Tx Link event            ..... 0
Tx Reinitialise          ..... 0
Tx Port 1                ..... 0
Tx Port 2                ..... 1
Tx 1-hop transport       ..... 1
Tx Layer-2 transport     ..... 0
Rx Total                 ..... 2
Rx Hellos                 ..... 2
Rx Topo DB               ..... 0
Rx Topo update           ..... 0
Rx Link event            ..... 0
Rx Reinitialise          ..... 0
Rx Port 1                ..... 0
Rx Port 2                ..... 2
Rx 1-hop transport       ..... 2
Rx Layer-2 transport     ..... 0

Topology Error counters
Version unsupported      ..... 0
Product unsupported      ..... 0
XEM unsupported          ..... 0
Too many units           ..... 0
Invalid messages         ..... 0

```


Table 88-1: Parameters in the output of the show counter stack command

Parameters	Description
Topology Event Counters	
Units joined	Number of times that the stack acquires a member
Units left	Number of times that the stack loses a member
Links up	Number of times that a stack link is up in the stack
Links down	Number of times that a stack link is down in the stack
ID conflict	Number of times that stack member ID conflicts
Master conflict	Number of times that stack master conflict occurs
Master failover	Number of times that stack master fails
Master elected	Number of times that stack master is elected
Master discovered	Number of times that stack master is discovered
SW autoupgrades	Number of times that the software in the stack members are auto upgraded
Stack port counters	
Link up	Number of times that this unit's physical stack link has come up
Link down	Number of times that this unit's physical stack link has come down
Nbr re-init	Number of times that the neighbour is detected as having reinitialised
Nbr incompatible	Number of times that the neighbour is detected as incompatible
Nbr 2way comms	Number of times that the neighbour is in two way communication status.
Nbr full comms	Number of times that the neighbour is in full communication status.
Topology message counters	
Total	Number of total topology messages
Hellos	Number of hello messages
Topology DB	Number of topology database messages
Topology update	Number of topology database update messages
Link event	Number of link events messages
Reinitialise	Number of reinitialise messages
1-hop transport	Number of 1-hop transport messages
Layer-2 transport	Number of layer 2 transport messages
Link event	Number of link events messages
Reinitialise	Number of reinitialise messages

Table 88-1: Parameters in the output of the show counter stack command(Continued)

Parameters	Description
1-hop transport	Number of 1-hop transport messages
Layer-2 transport	Number of layer 2 transport messages
Topology error counters	Reasons why a neighboring unit could not join the stack
Version unsupported	Number of stack software version unsupported errors
Product unsupported	Number of Product unsupported errors
XEM unsupported	Number of XEM unsupported errors
Too many units	Number of too may units errors
Invalid messages	Number of invalid messages

```

Virtual Chassis Stacking counters information

Stack member 2:

Topology Event Counters
-----
Units joined ..... 3      Units left ..... 1
Links up ..... 6         Links down ..... 2
ID conflict ..... 1       Master conflict ..... 0
Master failover ..... 0   Master elected ..... 1
Master discovered ..... 0 SW autoupgrades ..... 0
Unit renumbered ..... 0  Unit reinitialised .... 0
Unit master ..... 1     Unit slave ..... 0

Stack port 2.1.1 counters
  Link up ..... 1        Link down ..... 0
  Nbr re-init ..... 1    Nbr incompatible ... 0
  Nbr 2way comms ..... 2 Nbr full comms..... 2
<output truncated>

```

Related Commands [show stack](#)

show debugging stack

This command shows which debugging modes are currently enabled for virtual chassis stacking.

Syntax `show debugging stack`

Parameter	Description
show	Show running system information
debugging	Debugging functions
Stack	Virtual Chassis Stacking

Mode Privileged Exec

Usage To display the stack debugging mode status, use the command:

```
awplus# show debugging stack
```

Figure 88-2: Example output from the show debugging stack command

```
Virtual Chassis Stacking debugging status:
VCS link debugging is on
VCS topology debugging is on
VCS trace debugging is on
```

Example To display the stacking modes status, use the command:

```
awplus# show debugging stack
```

Related Commands [debug stack](#)
[remote-command](#)

show running-config stack

This command displays the running system information specific to the virtual chassis stack.

```
show running-config stack
```

Parameter	Description
show	Show running system information
running-config	Current operating configuration
stack	Virtual Chassis Stacking (VCS)

Mode Privileged Exec and Global Configuration

Example To display the stacking running configuration information, use the command:

```
awplus# show running-config stack
```

Output [Figure 88-3: Example output from the show running-config stack command on page 88.14](#)

```
stack management vlan 4000
stack management subnet 192.168.0.0
stack fallback-config flash:/fallback.cfg
no stack 1 software-auto-synchronize
no stack 4 software-auto-synchronize
stack 2 priority 0
```

Related Commands [remote-command](#)
[show running-config](#)

show stack

Displays information about current stack members.

Syntax `show stack [detail]`

Parameter	Description
show	Show running system information
stack	Virtual Chassis Stacking
detail	Detailed information display

Default Displays summary information only.

Mode Exec and Privileged Exec

Usage This command displays information about current stack members. If the detail parameter is specified, additional information will be displayed for each stack member. By default, only summary information is displayed.

This command can be entered on any stack member as a host-directed command. However, all stack members display the same stacking information.

Examples To display basic information about the stack, use the command:

```
awplus# show stack
```

Apply the command to a specific stack member (in this case, stack member 2):

```
awplus# remote-command 2 show stack
```

To display the detailed stacking information about the whole stack:

```
awplus# show stack detail
```

Apply the command for detailed information for a specific stack member (in this case, stack member 2):

```
awplus# remote-command 2 show stack detail
```

Figure 88-4: Example output from the show stack command

Virtual Chassis Stacking summary information				
ID	Pending ID	MAC address	Priority	Role
1	-	0000.cd24.f651	128	Active Master
2	-	0000.cd24.ff57	128	Backup Member

Table 88-2: Parameters in the output from the show stack command

Parameter	Description
ID	Stack member ID
MAC address	Stack member MAC address
Priority	Stack member master election priority (between 1 and 255) Note that the lowest number has the highest priority.
Role	Stack member's role in the stack, this can be one of: ■ Active Master ■ Disabled Master (The temporary master when there is a communication break within the stack and no fallback script exists. In this state all switch ports within the stack are disabled) ■ Fallback Master (The temporary master selected by the fallback script, when there is a communication break within the stack) ■ Backup Member (a device other than the stack master)

Figure 88-5: Example output from the show stack detail command

```

Virtual Chassis Stacking detailed information

Stack Status:
-----
--
Normal operation
Operational Status           Enabled
Management VLAN ID          4094
Management VLAN subnet address 192.168.255.0

Stack member 1:
-----
--
ID                           1
Pending ID                   -
MAC address                   0000.cd28.070d
Last role change              Wed May  7 22:31:58 2008
Product type                  SwitchBlade x908
SwitchBlade x908 Stacking Ports Disabled (XEM-STK Present)
Role                          Active Master
Priority                       128
Host name                     awplus
S/W version auto synchronization On
Fallback config               Not configured
Port 1.1.1 status             Learnt neighbour 2
Port 1.1.2 status             Learnt neighbour 2

Stack member 2:
-----
--
ID                           2
Pending ID                   -
MAC address                   0000.cd29.716d
Last role change              Wed May  7 23:47:21 2008
Product type                  SwitchBlade x908
SwitchBlade x908 Stacking Ports Disabled (XEM-STK Present)
Role                          Backup Member
Priority                       128
Host name                     awplus-2
S/W version auto synchronization On
Fallback config               Not configured
Port 2.1.1 status             Learnt neighbour 1
Port 2.1.2 status             Learnt neighbour 1

```

Table 88-3: Parameters in the output from the show stack detail command

Parameter	Description
Stack Status	The stack's overall status Note that a warning is issued if the stack is not connected in a standard ring topology.
Operational Status	The status of the stack; either enabled or disabled
Management VLAN ID	The VLAN ID currently used for stack management; default 4094
Management VLAN subnet address	The current stacking management VLAN subnet address
ID	Stack member ID.
Pending ID	The pending stack member ID. This can be changed by the stack renumber command on page 88.25 . If there is no pending ID, the "-" symbol will display.
MAC address	Stack member's hardware MAC address. Note that frames from devices within a stacked virtual chassis will carry the source address of the stack master.
Last role change	The date and time when the stack member last changed its role in the stack.
Product type	Stack member product type; for example SwitchBlade x908.
Switchblade x908 Stacking Ports	The status of the chassis rear stacking ports. Only on the SwitchBlade x908.
Role	Stack member's role in the stack (either master or backup).
Priority	The priority for election of stack master (between 0 to 255). The lowest number has the highest priority. Note that where stack members have the same priority setting, the switch with the lowest MAC address will become the stack master.
Host name	The host name of the stack member.
Auto upgrade	Whether the software-auto-configuration feature is turned on or off.
Fallback config	The current fallback configuration file configured in the stack. This can be either: ■ Configured ■ Not configured ■ <file path> (file exists) ■ <file path> (file not found)
Port status	The status of the stack port, can be "Down", "Neighbour incompatible", "Discovering neighbour" or "Learnt neighbour <neighbour member ID>"

Related Commands [show counter stack](#)
[stack software-auto-synchronize](#)

show stack full-debug

Displays a detailed history of important debug-level log messages relating to current stack members.

```
show stack full-debug [<stack-member>]
```

Parameter	Description
<stack-member>	The number of a single stack member, in the range 1-8.
detail	Displays full debug information.

Default Displays debug information for all stack members.

Mode Exec and Privileged Exec

Usage This command can be entered on any stack member as a host-directed command. However, all stack members display the same stacking information. Note that this command is provided for AT support staff, and is not intended for general use.

Example To display detailed debug information about stack member 2, use the command:

```
awplus# show stack full-debug 2
```

show stack indicator

This command enables you to physically identify a specific stack member. This command will flash the Master Status LED for the stack member specified. The pattern will be a number of flashes in quick succession followed by a longer pause; where the number of flashes equals the stack member ID.

Syntax `show stack indicator [<stack-member>|all] [timeout<timeout-period>]`

Parameter	Description
<stack-member>	The ID of the stack member to be identified (1-8). Default is All
all	Will flash the Master Status LED on each stack member with its own appropriate ID pattern.
<timeout-period>	The time period (in seconds) that the indication will display. Default is 30 seconds.

Mode Exec and Privileged Exec

Examples To find stack member 2 by flashing its Master Status LED, use the command:

```
awplus# show stack indicator 2
```

To find stack member 2 by flashing its Master Status LED for 1 minute, use the command:

```
awplus# show stack indicator 2 timeout 60
```

stack enable

This command is used on a stackable stand-alone switch, to manually turn on virtual chassis stacking feature and XEM-STK links.

By default, VCS feature starts automatically at the device start-up when XEM-STK is detected.

This command is run on a switch that has previously been removed from the stack (by using the no stack enable command) in order to return its stack membership member.

The no variant of this command (no stack <1-8> enable) will remove a selected stack member switch from the virtual chassis stack.

Syntax stack enable
 no stack <1-8> enable

Parameter	Description
stack	Manage VCS feature
enable	Enable Virtual Chassis Stacking

Mode Global Configuration

Usage Running the no stack enable <1-8> command will remove the selected stack member from the VCS stack. At this point the removed member will either act as a stand alone master, or apply the action defined in the fallback script. Where no fallback configuration exists, the switch will disable all of its ports. At this point the switch can only be accessed via its console port.

To return the switch to stack membership, you first run the stack enable command. Note that to do this you must have either direct connectivity (via the console port), or network connectivity (setup via the fallback script). Then you must run the [reboot command on page 88.4](#). This will reboot the switch and it will re-join the stack as an ordinary member.

Note the following conditions of applying the no stack <1-8> enable command:

- If the specified member ID is not used by any current stack member, the command will be rejected.
- If the specified member is a stack master, this command will be rejected.

Caution: *Disabling a stack member can significantly degrade the throughput capability of the stack. Also ensure that the fallback configuration produces a workable operation, i.e. that required paths are not unintentionally blocked.*

Example To turn on stacking on a stackable stand-alone unit, use the command:

```
awplus# configure terminal
awplus(config)# stack enable
```

stack fallback-config

This command is used to set the fallback configuration file to use if the stack splits into stubs due to connectivity failures.

Syntax `stack fallback-config <url>`
`no stack fallback-config`

Parameter	Description
stack	Virtual Chassis Stacking (VCS)
fallback-config	the stack stub configuration to use if the stack master fails
<url>	The URL of the stack fallback configuration file
no	Negates the operation of the stack fallback-config command

Mode Global Configuration

Usage This command is used to select the fallback configuration file to be used if a connectivity fault causes the stack splits into stubs. The stack splits into stubs when:

- connectivity is lost between stack members and the stack master across the inter-stack connection.
- the stack master is assumed to be still online, but is no longer reachable by all stack members.

In a stub scenario, the remaining stack members cannot use the same stack configuration, because this will result in potential configuration conflicts, particularly where static channels terminate on different stacking units.

The fallback-config allows the remaining stack members to continue processing network traffic to some degree, without clashing with the existing stack's configuration. Configuring a fallback-configuration also means that the isolated stub members can still be accessible via a management IP address, and so can be re-configured on the fly.

Caution: *It is important that any ports that are configured as trunked ports across master and slave stack members are disabled at their slave termination when operating in the fallback configuration. Otherwise the trunked ports will not function correctly on the switch connected downstream.*

Note: *The stack fallback-config command will be deprecated in a future release. The redundancy provided by the fallback-config will be supported on future releases, but it will configured in a different way. Information will be provided in future release notes on how to migrate your current fallback configuration to new functionality.*

Example

```
awplus# configure terminal
awplus(config)# stack fallback-config flash:/stk_stb.conf
%This command will be deprecated in a future release. No action is
%needed now, but please consult the release notes prior to your next
%upgrade.
```

Related Commands [stack resiliencylink](#)

stack management subnet

This command configures the stack's VLAN subnet management address.

Use the `no stack management subnet` command to reset the stack's VLAN subnet management address back to the default address and mask (192.168.255.0/28).

Syntax `stack management subnet <ip-address>`

`no stack management subnet`

Parameter	Description
<code>stack</code>	Virtual Chassis Stacking (VCS)
<code>management</code>	Stack management VLAN configuration
<code>subnet</code>	Subnet address of the VCS management VLAN
<code><ip-address></code>	The new subnet address for VCS management VLAN
<code>no</code>	Sets the stack management VLAN subnet address back to its default value of 192.168.255.0.

Mode Global Configuration

Default The default stacking management VLAN subnet address is 192.168.255.0 with a subnet mask 255.255.255.240 or /28.

Usage This command is used only in the master and configures the stack management VLAN subnet address.

The management VLAN will be used for high speed communication between stacked units via the inter-stack connection. Although this command enables you to change the IP address command, the subnet mask must always remain as shown.

The VCS management IP subnet is solely used internally to the stacked devices, and cannot be reached external to the stack. You should only change the VCS management VLAN subnet address if it causes a conflict within your network.

Note that several separate stacks can use the same default management VLAN subnet address even though their user ports may share the same external network. If the VCS subnet address is changed, then the configuration for any new units must also be updated before they are inserted into the stack.

If the management VLAN subnet address is changed by this command, you can use the `no stack management subnet` command reset it to its default value.

Example To set the management VLAN subnet address to 192.168.255.144:

```
awplus# configure terminal
```

```
awplus(config)# stack management subnet 192.168.255.144
```

Related Commands [stack management vlan](#)

stack management vlan

This command configures the virtual stack management VLAN ID. It can only be entered from the stack master.

Use the `no stack management vlan` command to change the virtual stack management VLAN ID back to the default (VLAN ID 4094).

Syntax

```
stack management vlan <2-4094>
no stack management vlan <2-4094>
```

Parameter	Description
stack	Virtual Chassis Stacking (VCS)
management	VCS management VLAN configuration
vlan	VCS management VLAN
<2-4094>	VCS management VLAN ID. Default: 4094.
no	Sets the stack management VLAN command back to its default value of 4094.

Default VLAN ID 4094

Mode Global Configuration

Usage This command is used only in the master and configures the VCS management VLAN ID.

The management VLAN is used for high speed communication between stacked units via the XEM-STK or the two back panel stacking ports (SwitchBlade® x908 only). This command enables you to change the ID of this VLAN.

The default stacking management VLAN ID is 4094, which is the last configurable VLAN ID in the switch.

The VCS management VLAN is created and configured automatically so that the VCS VLAN cannot be used in the stack's VLAN configuration commands (such as `awplus(config-vlan)# vlan <VCS management VLAN ID>`).

The management VLAN should only be changed if the default VCS VLAN ID needs to be used in the stack's VLAN configuration.

Warning When the command is entered, the updated management VLAN configuration will take effect once the stack is restarted.

If the management VLAN ID is changed by this command, you can use the `no stack management vlan` command to change it back to default value.

Examples To set the management VLAN to 4000, enter the following commands:

```
awplus# configure terminal
awplus(config)# stack management vlan 4000
```

To reset the management VLAN back to the default (4094), enter the following commands:

```
awplus# configure terminal
awplus(config)# no stack management vlan
```

Related Commands [stack management subnet](#)

stack priority

This command changes a specific stack member's stack ID and its master-election priority.

Syntax `stack <1-8> priority <0-255>`
`no stack <1-8> priority`

Parameter	Description
no	Changes the stack priority back to its defaults value.
stack	Manage VCS feature.
<1-8>	The ID of the stack member that needs to be configured. Note that when using the show stack indicator command, it is easier to count the MASTER LED pattern when stack IDs use the numbers 1 to 4.
priority	The stack member's election priority value. The lowest value is assigned the highest priority. Default:128.
<0-255>	The stack member's new priority value.

Mode Global Configuration

Usage This command is used to change the value of a specific stack member's master-election priority. If the specified member ID is not used by any current stack member, the command will be rejected.

The election criteria selects the stack member with the lowest priority value to become the stack master. Where two stack members both have the same lowest priority value, then the stack member with the lowest MAC address will be elected as master.

Note: Assigning a new priority value will not immediately change the current stack master. In order to force a master re-election after the new priority value is assigned, use `reboot stack-member <master's ID>` to reboot the current stack master, a new stack master will then be elected based on the new priority values.

Example To change the priority of stack member 4 to be 2, use the commands:

```
awplus# configure terminal
awplus(config)# stack 4 priority 2
```

Validation Command [show stack](#)

stack renumber

Changes the ID of a specific stack member.

Syntax `stack <member's-existingID> renumber <member's-newID>`

Parameter	Description
stack	Virtual Chassis Stack
<member's-existingID>	The the stack member ID to be renumbered - also referred to as the "current member ID". Can have a value in the range 1 to 8. We recommend that you use only numbers 1 to 2, for a 2 unit stack, and 1 to 4, for a four unit stack.
renumber	Change the existing stack member ID
<member's-newID>	The stack member's new ID - also referred to as the new member ID. Can have a value in the range 1 to 8. Note that when operating two member stacks, we advise using stack IDs 1 and 2.

Default Every stack unit will initially try to use stack member ID of 1.

Mode Global Configuration

Usage This command is used to change the ID of a specific stack member - primarily when exchanging stack members. The changes made by this command will not take effect until the switch is rebooted.

Note: This command does not alter any of the stacks's existing configuration, apart from the member-ID specified. For example, if stack member 2 were removed from the stack and a new stack unit is assigned the member 2 stack ID then the interface configuration that existed for the removed stack member 2 will be applied to the new stack member 2.

The *current member ID* must already be assigned to an existing stack member. To avoid duplicating IDs, a warning message will appear if you assign a *new member ID* that is currently assigned to another stack member. However, you can continue to rename the stack member IDs and remove ID duplications. If you do not remove the duplications, then the device with the highest root priority will be allocated this ID. Once you have removed any duplicate IDs, you can reboot the switch to implement your changes.

Note that the configured member-ID is saved immediately on the renumbered member, and so is not reliant on using the `copy running-config` command for it to take effect

Example To change the stack member ID 2 to be member ID 3, use the commands:

```
awplus# configure terminal
awplus(config)# stack 2 renumber 3
```

Validation Command `show stack`

stack renumber cascade

This command is used to renumber the members of a stack so that their IDs are ordered sequentially, relative to the member's physical position within the stack.

Caution: *Changing the stack numbering will upset the existing stack member configurations such as port settings etc. This command is intended for use when the stack is either initially commissioned, or has undergone a major reconfiguration. In this situation you run the **stack renumber** command (which will automatically reboot the switch), then configure the stack members to meet the new requirements.*

Syntax `stack <1-8> renumber cascade [<1-8>]`

Parameter	Description
<1-8>	The ID of the stack member that to start renumbering from
renumber	Change the existing stack member ID
cascade	Renumber the existing stack member ID in cascade order
<1-8>	The new ID for the first member renumbered

Default If no member-ID is specified, the member will take the default ID of 1.

Mode Global Configuration

Usage This command is used to renumber the members of a stack so that their member's IDs are ordered sequentially, based on physical order of the XEM-STK connections. This would normally be done either when the stack is initially configured or following a major reconfiguration.

This command is equivalent to pressing and holding the select button on the XEM-STK to renumber the stack members. The renumber will start on the specified stack member. If that member ID is not used by any of the existing stack member, the command will be rejected.

The starting stack member will be renumbered with the new member-ID specified, or the default of member ID of 1. The stack ID of the next physically will be the starting members ID +1, for example member ID 2. This renumbering will continue in cascading order around the stack members.

The changes will take place immediately and reboot all stack members. For this reason a confirmation prompt follows this command entry, asking whether you are sure you want to renumber and reboot the entire stack.

Example

```
awplus(config)# stack 1 renumber cascade
Any existing interface configuration may no longer be valid
Are you sure you want to renumber and reboot the entire stack?
(y/n): y
```

Related Commands `show stack`
`stack renumber`

stack resiliencylink

This command configures the resiliency link used by Virtual Chassis Stacking. The interface used is a dedicated VLAN (resiliencylink VLAN) to which switch ports may become members. This VLAN is dedicated to the resiliency link function and must not be the stack management VLAN.

Syntax `stack resiliencylink <interface>`
 `no stack resiliencylink`

Mode Global Configuration

Usage The resiliency-link is only used when a slave loses connectivity with the master via the stacking cables. Such a communication loss would occur if:

- a XEM-STK is removed or fails,
- two or more XEM-STK cables are unplugged or fail,
- the stack master itself fails due to a reboot or power failure.

The resiliency-link allows the slave to determine if the master is still present in the network by the reception of health-check messages sent by the master over the resiliency-link interface.

Reply health-check messages are received if the master is still online, but the stack will now split into two different 'stubs'. The stub containing the existing master will continue operating as normal. The members in the masterless stub will now use the fallback-config configuration to form a second temporary stack. This utilizes the remaining stack members' resources without conflicting directly with the master's configuration. If no fallback-config was specified for the stack, then the masterless stub members will disable their switch ports.

If no health-check messages are received, then the master is assumed to be completely offline, and so the other stack members can safely take over the master's configuration.

Caution: *The purpose of the resiliency link is to enable the stack members (particularly the backup master) to check the status of the master under fault conditions. If the resiliency link is not configured, and the master loses communication with its other stack members, then Virtual Chassis Stacking will assume the master is NOT present in the network, which could cause network conflicts if the master is still on line. Note that this is a change to the stacking of releases prior to version 5.3.1.*

Example To set the resiliency link to be eth0

```
awplus# configure terminal
awplus(config)# stack resiliencylink eth0
```

Example To set the resiliency link to be VLAN 4093.

First use the `stack resiliencylink` command to create the resiliency vlan 4093

```
awplus# configure terminal
awplus(config)# stack resiliencylink vlan4093
```

Next use the [switchport resiliencylink](#) command to assign the resiliencylink vlan to the interface port, in this case port1.0.1.

```
awplus# configure terminal
awplus(config)# interface port1.0.1
awplus(config-if)# switchport resiliencylink
```

Related Commands [show stack](#)
 [stack fallback-config](#)

stack software-auto-synchronize

This command is used only on the stack master and enables the software version auto-synchronization feature either on a specified stack member or all stack members and candidates¹.

Use the no form of this command to turn the software version auto synchronization feature off.

1. A stack candidate is a switch that is about to join a stack.

Syntax `stack {all|<1-8>} software-auto-synchronize`
`no stack {all|<1-8>} software-auto-synchronize`

Parameter	Description
software-auto-synchronize	Initiate the software version auto-synchronization process

Default All the stack members have the stack software-auto-synchronize feature enabled by default.

Mode Global Configuration

Usage This command is used to enable the software version auto-synchronization feature for either a specific stack member or all stack members and candidates.

Note that if a stack candidate attempts to join a stack, but is running a software release that is different to the other stack members, then the software version auto-synchronization feature will copy the master's software release onto the new candidate. If the software version auto-synchronization feature is not enabled, then the candidate will be rejected from the stack.

Note that the software version auto-synchronization feature may also result in the stack candidate downgrading its software release if the master is running an older software version.

Examples To turn on the software-auto-synchronize feature on stack member 2, which was previously turned off, use the following commands:

```
awplus# configure terminal
```

```
awplus(config)# stack 2 software-auto-synchronize
```

To turn on the software-auto-synchronize feature for all stack members, which were previously turned off, use the following commands:

```
awplus# configure terminal
```

```
awplus(config)# stack all software-auto-synchronize
```

Validation Command `show stack`

stack virtual-chassis-id

This command specifies the VCS virtual chassis ID. The ID selected will determine which virtual MAC address the stack will use. The MAC address assigned to a stack must be unique within its network.

Note: The command will not take effect until the switch has been rebooted.

Syntax `stack virtual-chassis-id <id>`

Parameter	Description
stack	the Virtual Chassis Stack (VCS)
virtual-chassis-id	the virtual id assigned to the stack
<id>	the value of the id - enter a number in the range 0 to 4095

Mode Global Configuration

Usage The virtual-chassis-id entered will form the last 12 bits of a pre selected MAC prefix component; that is, 0000.cd370xxx. If you enable the VCS virtual MAC address feature (by using the [stack virtual-mac](#) command) without using the [stack virtual-chassis-id](#) command to select the virtual-chassis-id, then the stack will select a virtual-chassis-id from a number within the assigned range.

Example To set the stack virtual-chassis-id to 63 use the commands

```
awplus# configure terminal
awplus(config)# stack virtual-chassis-id 63
```

This will result in a virtual MAC address of: 0000.cd37.003f.

Related Commands [show running-config](#)
[show stack \[detail\]](#)
[stack virtual-mac](#)

stack virtual-mac

This command enables the VCS virtual MAC address feature. For more information on this topic refer to: [“Fixed or Virtual MAC Addressing” on page 87.12](#). With this command set, the value applied for the virtual MAC address is determined by the setting of the command [stack virtual-chassis-id](#) command on page 88.30.

Note: This command will not take effect until the switch has been rebooted.

Syntax stack virtual-mac
 no stack virtual mac

Parameter	Description
stack	the Virtual Chassis Stack (VCS)
virtual-mac	enables the virtual MAC address feature
no	The no prefix disables the virtual-mac address feature

Mode Global Configuration

Example

```
awplus# configure terminal
awplus(config)# stack virtual mac
```

Related Commands [show running-config](#)
 [show stack \[detail\]](#)
 [stack virtual-chassis-id](#)

switchport resiliencylink

This command configures the switch port to be a member of the stack resiliency link VLAN. Note that this switchport will only be used for stack resiliency-link traffic and will not perform any other function, or carry any other traffic.

The no variant of this command removes the switchport from the resiliency link VLAN.

Syntax `switchport resiliencylink`
 `no switchport resiliencylink`

Mode Global Configuration

Examples To set the resiliency link to be VLAN 4093.

First use the [stack resiliencylink](#) command to create the resiliency `vlan4093`

```
awplus# configure terminal
awplus(config)# stack resiliencylink vlan4093
```

Next use the [switchport resiliencylink](#) command to assign the resiliencylink vlan to the interface port, in this case `port1.0.1`.

```
awplus# configure terminal
awplus(config)# interface port1.0.1
awplus(config-if)# switchport resiliencylink
```

Appendix A: Command List

A

aaa accounting auth-mac default.....	59.2
aaa accounting auth-web default	59.4
aaa accounting dot1x.....	59.6
aaa accounting login	59.8
aaa accounting update	59.10
aaa authentication auth-mac.....	59.11
aaa authentication auth-web	59.13
aaa authentication dot1x.....	59.14
aaa authentication login	59.16
aaa group server	59.18
accept-lifetime.....	34.2
access-list (extended)	51.2
access-list (IP)	51.4
access-list (MAC)	51.12
access-list (standard)	51.3
access-list extended (named)	51.14
access-list standard (named)	51.20
accounting login	59.19
activate	11.2
active (trigger).....	84.2
active (ping polling).....	86.2
address-family	40.4
advertisement-interval.....	67.2
aggregate-address (BGP)	40.5
aggregate-address (RIPng)	36.2
area authentication.....	38.3
area default-cost	38.4
area filter-list.....	38.5
area nssa.....	38.6
area range.....	38.8
area stub.....	38.9
area virtual-link.....	38.10
arp (IP address MAC address).....	25.3
arp-aging-timeout.....	25.2
attribute	62.2
auth critical.....	57.3
auth dynamic-vlan-creation	57.4
auth guest-vlan.....	57.6
auth host-mode	57.8
auth max-supplicant.....	57.9
auth reauthentication.....	57.10
auth roaming disconnected.....	57.11
auth roaming enable.....	57.13
auth supplicant-mac	57.15

auth timeout quiet-period.....	57.17
auth timeout reauth-period.....	57.18
auth timeout server-timeout.....	57.19
auth timeout supp-timeout.....	57.20
authentication.....	62.5
auth-mac enable.....	57.21
auth-mac method.....	57.22
auth-mac reauth-relearning.....	57.23
auth-web enable.....	57.24
auth-web forward.....	57.25
auth-web max-auth-fail.....	57.27
auth-web method.....	57.28
auth-web-server http-redirect.....	57.29
auth-web-server ipaddress.....	57.30
auth-web-server ping-poll enable.....	57.31
auth-web-server ping-poll failcount.....	57.32
auth-web-server ping-poll interval.....	57.33
auth-web-server ping-poll reauth-fresh.....	57.34
auth-web-server ping-poll timeout.....	57.35
auth-web-server port.....	57.36
auth-web-server redirect-url.....	57.37
auth-web-server session-keep.....	57.38
auth-web-server ssl.....	57.39
auth-web-server sslport.....	57.40
auto-cost reference bandwidth.....	38.12
auto-summary.....	40.6

B

backpressure.....	15.2
bandwidth.....	38.13
banner exec.....	8.2
banner login (SSH).....	65.2
banner login (system).....	8.4
banner motd.....	8.5
bgp aggregate-nexthop-check.....	40.7
bgp always-compare-med.....	40.8
bgp bestpath as-path ignore.....	40.9
bgp bestpath compare-confed-aspath.....	40.9
bgp bestpath compare-routerid.....	40.10
bgp bestpath med.....	40.11
bgp client-to-client reflection.....	40.12
bgp cluster-id.....	40.13
bgp confederation identifier.....	40.14
bgp confederation peers.....	40.15
bgp config-type.....	40.16
bgp dampening.....	40.17
bgp default ipv4-unicast.....	40.18
bgp default local-preference.....	40.19
bgp deterministic-med.....	40.20
bgp enforce-first-as.....	40.21
bgp fast-external-failover.....	40.22
bgp graceful-restart.....	40.23
bgp log-neighbor-changes.....	40.24
bgp memory maxallocation.....	40.25
bgp multiple-instance.....	40.26

bgp rfc1771-path-select.....	40.26
bgp rfc1771-strict.....	40.27
bgp router-id.....	40.27
bgp scan-time.....	40.28
bgp update-delay.....	40.29
boot backup.....	7.4
boot config-file.....	7.4
boot system.....	7.5
bootfile.....	73.2

C

capability opaque.....	38.13
capability restart.....	38.14
cd.....	7.5
channel-group mode.....	21.3
circuit-failover.....	67.3
class.....	53.2
class-map.....	53.3
clear aaa local user lockout.....	59.20
clear arp-cache.....	25.4
clear bgp (ASN).....	40.32
clear bgp (ip address).....	40.31
clear bgp *.....	40.30
clear bgp external.....	40.33
clear bgp peer-group.....	40.34
clear bgp view.....	40.35
clear exception log.....	10.2
clear ip bgp (ASN).....	40.40
clear ip bgp (ip address).....	40.37
clear ip bgp *.....	40.36
clear ip bgp dampening.....	40.38
clear ip bgp external.....	40.41
clear ip bgp flap-statistics.....	40.39
clear ip bgp peer-group.....	40.42
clear ip bgp view.....	40.44
clear ip igmp group.....	43.3
clear ip igmp interface.....	43.4
clear ip igmp.....	43.2
clear ip mroute statistics.....	44.3
clear ip mroute.....	44.2
clear ip ospf process.....	38.14
clear ip pim sparse-mode bsr rp-set *.....	46.2
clear ip prefix-list.....	51.20
clear ip rip route.....	34.4
clear ipv6 mld group.....	49.3
clear ipv6 mld interface.....	49.4
clear ipv6 mld.....	49.2
clear ipv6 neighbors.....	27.3
clear ipv6 rip route.....	36.3
clear lacp counters.....	21.2
clear line console.....	5.2
clear line vty.....	5.2
clear lldp statistics.....	78.2
clear lldp table.....	78.3
clear log buffered.....	10.4

clear log permanent	10.5
clear log	10.3
clear loop-protection counters	15.3
clear mac address-table dynamic	15.5
clear mac address-table static	15.4
clear mls qos interface policer-counters	53.4
clear ping-poll	86.3
clear port counter	15.6
clear power-inline counters interface	23.2
clear radius local-server statistics	62.6
clear spanning-tree detected protocols (RSTP and MSTP)	19.2
clear ssh	65.3
clear test interface	13.2
clear vlan statistics	17.2
clock set	8.6
clock summer-time date	8.7
clock summer-time recurring	8.8
clock timezone	8.9
compatible rfc1583	38.15
configure terminal	4.2
copy (local)	7.8
copy (URL)	7.11
copy current-software	7.6
copy debug	7.7
copy local-radius-user-db (from file)	62.7
copy local-radius-user-db (to file)	62.8
copy running-config	7.9
copy startup-config	7.10
copy web-auth-https-file	57.41
copy zmodem	7.12
critical-interval	86.4
crypto key destroy hostkey	65.4
crypto key destroy userkey	65.5
crypto key generate hostkey	65.6
crypto key generate userkey	65.7
crypto key pubkey-chain knownhosts	65.8
crypto key pubkey-chain userkey	65.10
crypto pki enroll local local-radius-all-users	62.10
crypto pki enroll local user	62.11
crypto pki enroll local	62.9
crypto pki export local pem	62.12
crypto pki export local pkcs12	62.13
crypto pki trustpoint local	62.14

D

day	84.3
deadtime (RADIUS server group)	60.2
debug aaa	59.21
debug bgp	40.45
debug crypto	62.15
debug dot1x	55.2
debug epsr	69.2
debug igmp	43.5
debug ip irdp	25.7
debug ip packet interface	25.5

debug ipv6 rip	36.4
debug lacp	21.5
debug lldp	78.4
debug mail	79.2
debug mld	49.5
debug mstp (RSTP and STP)	19.3
debug nsm mcast	44.3
debug nsm packet	8.10
debug nsm	8.10
debug ospf events	38.16
debug ospf ifsm	38.17
debug ospf lsa	38.18
debug ospf nsm	38.19
debug ospf nsm	38.20
debug ospf packet	38.21
debug ospf route	38.22
debug pim dense-mode all	48.2
debug pim dense-mode context	48.3
debug pim dense-mode decode	48.3
debug pim dense-mode encode	48.4
debug pim dense-mode fsm	48.4
debug pim dense-mode mrt	48.5
debug pim dense-mode nexthop	48.5
debug pim dense-mode nsm	48.6
debug pim dense-mode vif	48.6
debug pim sparse-mode timer	46.4
debug pim sparse-mode	46.3
debug ping-poll	86.5
debug platform packet	15.7
debug power-inline	23.4
debug radius	60.3
debug rip	34.5
debug snmp	75.2
debug ssh client	65.11
debug ssh server	65.12
debug stack	88.3
debug trigger	84.4
debug vrrp events	67.4
debug vrrp packet	67.5
debug vrrp	67.4
default log buffered	10.6
default log console	10.7
default log email	10.8
default log host	10.9
default log monitor	10.10
default log permanent	10.11
default-action	53.5
default-information originate (OSPF)	38.23
default-information originate (RIP)	34.6
default-information originate (RIPng)	36.5
default-metric (OSPF)	38.24
default-metric (RIP)	34.7
default-metric (RIPng)	36.6
default-router	73.3
delete debug	7.14
delete mail	79.3
delete	7.13

description (interface).....	12.2
description (ping polling).....	86.6
description (QOS policy map).....	53.6
description (trigger).....	84.5
dir	7.15
disable (Privileged Exec mode)	4.2
disable (VRRP)	67.5
distance (BGP)	40.46
distance (OSPF)	38.25
distance (RIP)	34.8
distribute-list (OSPF)	38.27
distribute-list (RIP)	34.9
distribute-list (RIPng)	36.7
dns-server	73.4
do	4.3
domain-name.....	73.5
dos	51.21
dot1x control-direction	55.3
dot1x eap.....	55.4
dot1x eapol-version.....	55.5
dot1x initialize interface.....	55.6
dot1x keytransmit	55.7
dot1x max-reauth-req.....	55.8
dot1x port-control	55.9
dot1x timeout tx-period	55.11
duplex	15.8

E

echo	11.3
edit URL.....	7.17
edit.....	7.16
egress-rate-limit	53.7
egress-vlan-id	62.16
egress-vlan-name	62.17
enable (Privileged Exec mode).....	4.3
enable (VRRP).....	67.6
enable password	5.3
end.....	4.4
epsr configuration.....	69.4
epsr datavlan	69.5
epsr enhancedrecovery enable	69.6
epsr mode master controlvlan primaryport.....	69.7
epsr mode transit controlvlan	69.8
epsr state.....	69.9
epsr trap	69.10
epsr	69.3
erase startup-config.....	7.17
erase web-auth-https-file	57.41
exception coredump size	10.12
exec-timeout.....	5.5
exit	4.4
exit-address-family	40.47

F

fail-count	86.7
flowcontrol	15.9

G

group	62.19

H

help	4.5
host area	38.28
host	73.6
hostname	8.11

I

instance priority (MSTP)	19.6
instance vlan (MSTP)	19.7
interface (to configure)	12.3
interface (VRRP)	67.6
interface tunnel	29.2
ip access-group	51.23
ip address dhcp	73.7
ip address	25.9
ip as-path access-list	40.48
ip community-list expanded	40.50
ip community-list standard	40.52
ip community-list	40.49
ip dhcp bootp ignore	73.8
ip dhcp option	73.9
ip dhcp pool	73.11
ip dhcp-relay agent-option checking	73.13
ip dhcp-relay agent-option	73.12
ip dhcp-relay information policy	73.15
ip dhcp-relay maxhops	73.16
ip dhcp-relay max-message-length	73.17
ip dhcp-relay server-address	73.18
ip directed-broadcast	25.13
ip domain-list	25.10
ip domain-lookup	25.11
ip domain-name	25.12
ip extcommunity-list expanded	40.54
ip extcommunity-list standard	40.56
ip forward-protocol udp	25.15
ip gratuitous-arp-link	25.16
ip helper-address	25.18
ip igmp access-group	43.7
ip igmp immediate-leave	43.8
ip igmp last-member-query-count	43.9
ip igmp last-member-query-interval	43.10
ip igmp limit	43.11
ip igmp mroute-proxy	43.13

ip igmp proxy-service.....	43.14
ip igmp querier-timeout	43.15
ip igmp query-holdtime.....	43.16
ip igmp query-interval.....	43.18
ip igmp query-max-response-time	43.19
ip igmp ra-option (Router Alert)	43.20
ip igmp robustness-variable.....	43.20
ip igmp snooping fast-leave	43.22
ip igmp snooping mrouter.....	43.23
ip igmp snooping querier	43.24
ip igmp snooping report-suppression	43.25
ip igmp snooping routermode.....	43.26
ip igmp snooping tcn query solicit.....	43.28
ip igmp snooping	43.21
ip igmp source-address-check.....	43.29
ip igmp ssm-map enable.....	43.30
ip igmp ssm-map static.....	43.31
ip igmp static-group	43.32
ip igmp version.....	43.33
ip igmp	43.6
ip irdp address preference	25.20
ip irdp broadcast.....	25.21
ip irdp holdtime.....	25.22
ip irdp lifetime	25.23
ip irdp maxadvertinterval	25.24
ip irdp minadvertinterval	25.25
ip irdp multicast.....	25.26
ip irdp preference.....	25.27
ip irdp	25.19
ip local-proxy-arp	25.28
ip mroute	44.4
ip multicast route-limit.....	44.5
ip multicast-routing.....	44.6
ip name-server	25.29
ip ospf authentication.....	38.29
ip ospf authentication-key	38.30
ip ospf cost.....	38.31
ip ospf database-filter	38.32
ip ospf dead-interval	38.33
ip ospf disable all.....	38.34
ip ospf hello-interval	38.35
ip ospf message-digest-key.....	38.36
ip ospf mtu	38.37
ip ospf mtu-ignore	38.38
ip ospf network	38.39
ip ospf priority.....	38.40
ip ospf resync-timeout.....	38.41
ip ospf retransmit-interval.....	38.42
ip ospf transmit-delay	38.43
ip pim accept-register list.....	46.6
ip pim anycast-rp	46.7
ip pim bsr-border	46.8
ip pim bsr-candidate	46.9
ip pim cisco-register-checksum group-list	46.10
ip pim cisco-register-checksum	46.9
ip pim crp-cisco-prefix.....	46.11
ip pim dense-mode passive.....	48.7

ip pim dense-mode	48.7
ip pim dr-priority	46.12
ip pim exclude-genid	46.13
ip pim hello-holdtime (PIM-DM)	48.8
ip pim hello-holdtime (PIM-SM)	46.14
ip pim hello-interval (PIM-DM)	48.9
ip pim hello-interval (PIM-SM)	46.15
ip pim ignore-rp-set-priority	46.16
ip pim jp-timer	46.16
ip pim max-graft-retries	48.10
ip pim neighbor-filter (PIM-DM)	48.11
ip pim neighbor-filter (PIM-SM)	46.17
ip pim propagation-delay	48.12
ip pim register-rate-limit	46.18
ip pim register-rp-reachability	46.18
ip pim register-source	46.19
ip pim register-suppression	46.20
ip pim rp-address	46.21
ip pim rp-candidate	46.23
ip pim rp-register-kat	46.24
ip pim sparse-mode passive	46.26
ip pim sparse-mode	46.25
ip pim spt-threshold group-list	46.28
ip pim spt-threshold	46.27
ip pim ssm	46.29
ip pim state-refresh origination-interval	48.13
ip prefix-list	51.25
ip proxy-arp	25.30
ip radius source-interface	60.4
ip rip authentication key-chain	34.10
ip rip authentication mode	34.13
ip rip authentication string	34.16
ip rip receive version	34.18
ip rip receive-packet	34.17
ip rip send version 1-compatible	34.21
ip rip send version	34.20
ip rip send-packet	34.19
ip rip split-horizon	34.22
ip route	32.2
ip vrrp authentication mode	67.7
ip vrrp authentication string	67.8
ipv6 access-list extended (Named)	51.27
ipv6 access-list standard (Named)	51.31
ipv6 address	27.3
ipv6 forwarding	27.4
ipv6 mld access-group	49.6
ipv6 mld limit	49.7
ipv6 mld snooping fast-leave	49.10
ipv6 mld snooping mrouter	49.11
ipv6 mld snooping report-suppression	49.12
ipv6 mld snooping	49.9
ipv6 mld ssm-map enable	49.13
ipv6 mld ssm-map static	49.14
ipv6 mld static-group	49.15
ipv6 nd managed-config-flag	27.5
ipv6 nd other-config-flag	27.6
ipv6 nd prefix	27.7

ipv6 nd ra-interval	27.8
ipv6 nd ra-lifetime	27.9
ipv6 nd reachable-time.....	27.10
ipv6 nd suppress-ra.....	27.11
ipv6 neighbor	27.12
ipv6 rip split-horizon.....	36.8
ipv6 route	27.13
ipv6 router rip	36.9
ip (ping polling)	86.8

K

key chain.....	34.24
key.....	34.23
key-string	34.25

L

lACP port-priority.....	21.6
lACP system-priority.....	21.7
lACP timeout.....	21.7
lease	73.19
length (console display)	5.6
length (ping poll data).....	86.9
license.....	7.18
line.....	5.7
lldp faststart-count	78.5
lldp holdtime-multiplier	78.6
lldp management-address.....	78.7
lldp med-notifications.....	78.8
lldp med-tlv-select.....	78.9
lldp non-strict-med-tlv-order-check.....	78.11
lldp notification-interval.....	78.12
lldp notifications	78.13
lldp reinit.....	78.14
lldp run	78.15
lldp timer	78.16
lldp tlv-select	78.17
lldp transmit receive.....	78.19
lldp tx-delay	78.20
location civic-location configuration	78.21
location civic-location identifier	78.25
location civic-location-id.....	78.26
location coord-location configuration	78.27
location coord-location identifier	78.29
location coord-location-id	78.30
location elin-location	78.31
location elin-location-id.....	78.32
log buffered (filter).....	10.14
log buffered size	10.17
log buffered.....	10.13
log console (filter)	10.19
log console	10.18
log email (filter)	10.23
log email time	10.26
log email.....	10.22

log host (filter).....	10.29
log host time	10.32
log host.....	10.28
log monitor (filter)	10.34
log permanent (filter).....	10.38
log permanent size	10.41
log permanent.....	10.37
login authentication.....	59.22
logout	4.5
loop-protection action	15.12
loop-protection timeout	15.13
loop-protection	15.11

M

mac access-group.....	51.32
mac address-table acquire.....	15.13
mac address-table ageing-time	15.14
mac address-table static	15.15
mac address-table thrash-limit.....	15.16
mail from	79.5
mail smtpserver	79.5
mail	79.4
match access-group.....	53.8
match as-path	41.2
match community	41.3
match cos.....	53.9
match dscp.....	53.10
match inner-cos.....	53.11
match inner-vlan.....	53.12
match interface	41.4
match ip address.....	41.5
match ip next-hop	41.7
match ip-precedence	53.13
match ipv6 address.....	41.9
match ipv6 next-hop.....	41.10
match mac-type.....	53.14
match metric.....	41.11
match origin.....	41.12
match protocol	53.15
match route-type.....	41.13
match tag.....	41.14
match tcp-flags.....	53.18
match vlan	53.19
max-concurrent-dd	38.44
max-fib-routes.....	8.12
maximum-access-list	51.33
maximum-area	38.45
maximum-paths.....	32.3
maximum-prefix.....	34.26
max-static-routes.....	8.13
mirror interface.....	15.17
mkdir.....	7.19
mls qos enable	53.20
mls qos map cos-queue to	53.21
mls qos map premark-dscp to.....	53.22

move debug.....	7.21
move.....	7.20
mtu	12.4
multicast.....	44.7

N

nas	62.20
neighbor (OSPF).....	38.46
neighbor (RIP).....	34.27
neighbor (RIPng).....	36.10
neighbor activate	40.58
neighbor advertisement-interval.....	40.59
neighbor allowas-in.....	40.60
neighbor as-origination-interval.....	40.61
neighbor attribute-unchanged.....	40.62
neighbor capability dynamic.....	40.63
neighbor capability graceful-restart	40.64
neighbor capability orf prefix-list	40.65
neighbor capability route-refresh	40.66
neighbor collide-established	40.67
neighbor default-originate	40.68
neighbor description.....	40.69
neighbor distribute-list.....	40.70
neighbor dont-capability-negotiate	40.71
neighbor ebgp-multihop.....	40.72
neighbor enforce-multihop.....	40.73
neighbor filter-list.....	40.74
neighbor interface	40.75
neighbor maximum-prefix.....	40.76
neighbor next-hop-self.....	40.77
neighbor override-capability.....	40.78
neighbor passive.....	40.79
neighbor peer-group (adding a neighbor)	40.80
neighbor peer-group (creating a peer-group)	40.81
neighbor port.....	40.82
neighbor prefix-list	40.83
neighbor remote-as.....	40.84
neighbor remove-private-AS.....	40.85
neighbor restart-time	40.86
neighbor route-map.....	40.87
neighbor route-reflector-client	40.88
neighbor route-server-client	40.90
neighbor send-community	40.91
neighbor shutdown.....	40.92
neighbor soft-reconfiguration inbound	40.93
neighbor strict-capability-match	40.94
neighbor timers	40.95
neighbor transparent-as.....	40.96
neighbor transparent-nexthop.....	40.97
neighbor unsuppress-map	40.98
neighbor update-source	40.99
neighbor version	40.100
neighbor weight.....	40.101
network (BGP)	40.102
network (DHCP)	73.20

network (RIP)	34.28
network area.....	38.47
network synchronization	40.103
next-server	73.21
no debug all	8.12
no police.....	53.23
normal-interval.....	86.10
ntp access-group.....	71.2
ntp authenticate	71.3
ntp authentication-key	71.3
ntp broadcastdelay	71.4
ntp master	71.4
ntp peer	71.6
ntp server.....	71.7
ntp trusted-key	71.7

O

offset-list (RIP).....	34.29
offset-list (RIPng).....	36.11
optimistic-nd.....	25.31
option.....	73.22
ospf abr-type.....	38.48
ospf restart grace-period.....	38.49
ospf restart helper.....	38.50
ospf router-id.....	38.51
overflow database external.....	38.53
overflow database.....	38.52

P

passive-interface (OSPF)	38.54
passive-interface (RIP)	34.30
passive-interface (RIPng)	36.12
ping ipv6	27.14
ping	25.32
ping-poll	86.11
platform bist	15.18
platform vlan-stacking-tpid	15.19
polarity.....	15.20
police single-rate action	53.24
police twin-rate action drop-red	53.26
policy-map	53.28
power-inline allow-legacy	23.5
power-inline description.....	23.6
power-inline enable	23.7
power-inline max.....	23.8
power-inline priority.....	23.10
power-inline usage-threshold	23.12
preempt-mode	67.9
priority	67.10
priority-queue.....	53.28
private-vlan association	17.4
private-vlan.....	17.3
privilege level.....	5.7
pwd.....	7.21

R

radius-server deadtime.....	60.5
radius-server host.....	60.6
radius-server key.....	60.10
radius-server local.....	62.21
radius-server retransmit.....	60.11
radius-server timeout.....	60.13
range.....	73.24
reboot.....	88.4
recv-buffer-size (RIP).....	34.30
recv-buffer-size (RIPng).....	36.13
redistribute (OSPF).....	38.55
redistribute (RIP).....	34.31
redistribute (RIPng).....	36.14
redistribute route-map.....	40.104
region (MSTP).....	19.8
reload.....	88.5
remark new-cos.....	53.30
remark-map.....	53.29
remote-command.....	88.6
repeat.....	84.6
restart bgp graceful.....	40.105
restart ospf graceful.....	38.56
restart rip graceful.....	34.32
revision (MSTP).....	19.9
rip restart grace-period.....	34.32
rmdir.....	7.22
rmon alarm.....	81.2
rmon collection history.....	81.4
rmon collection stats.....	81.5
rmon event.....	81.6
route (RIP).....	34.33
route (RIPng).....	36.15
route-map.....	41.15
router bgp view.....	40.107
router bgp.....	40.106
router ip irdp.....	25.33
router ipv6 rip.....	36.16
router ospf.....	38.57
router rip.....	34.34
router vrrp.....	67.11
router-id.....	38.58

S

sample-size.....	86.12
script.....	84.7
send-lifetime.....	34.35
server (Server Group).....	60.15
server auth-port.....	62.22
server enable.....	62.23
service advanced-vty.....	5.8
service dhcp-relay.....	73.25
service dhcp-server.....	73.26
service http.....	5.9

service password-encryption	5.10
service power-inline	23.13
service ssh	65.13
service telnet	5.11
service terminal-length	5.12
service test	13.3
service-policy input	53.32
set aggregator	41.17
set as-path	41.18
set atomic-aggregate	41.19
set comm-list delete	41.20
set community	41.21
set dampening	41.23
set extcommunity	41.25
set ip next-hop (PBR)	53.33
set ip next-hop (route map)	41.26
set ipv6 next-hop	41.27
set local-preference	41.28
set metric	41.29
set metric-type	41.30
set origin	41.31
set originator-id	41.32
set tag	41.33
set weight	41.34
show access-list	51.35
show arp	25.34
show auth-mac diagnostics	57.43
show auth-mac interface	57.44
show auth-mac sessionstatistics	57.46
show auth-mac statistics interface	57.47
show auth-mac supplicant interface	57.48
show auth-mac supplicant	57.47
show auth-mac	57.42
show auth-web diagnostics	57.50
show auth-web interface	57.51
show auth-web sessionstatistics	57.53
show auth-web statistics interface	57.54
show auth-web supplicant interface	57.56
show auth-web supplicant	57.55
show auth-web	57.49
show auth-web-server	57.57
show banner login	65.14
show bgp memory maxallocation	40.108
show boot	7.23
show class-map	53.34
show cli	4.6
show clock	8.14
show counter dhcp-client	73.27
show counter dhcp-relay	73.28
show counter dhcp-server	73.30
show counter mail	79.6
show counter ntp	71.8
show counter ping-poll	86.13
show counter snmp-server	75.3
show counter stack	88.8
show cpu history	8.19
show cpu	8.15

show crypto key hostkey	65.15
show crypto key pubkey-chain knownhosts	65.16
show crypto key pubkey-chain userkey	65.17
show crypto key userkey	65.18
show crypto pki certificates local-radius-all-users	62.26
show crypto pki certificates user	62.27
show crypto pki certificates	62.24
show crypto pki trustpoints	62.28
show debugging aaa	59.23
show debugging bgp	40.109
show debugging dot1x	55.12
show debugging epsr	69.11
show debugging igmp	43.34
show debugging ip packet	25.35
show debugging ipv6 rip	36.16
show debugging lacp	21.9
show debugging lldp	78.33
show debugging mstp	19.10
show debugging nsm	8.21
show debugging ospf	38.58
show debugging pim dense-mode	48.14
show debugging pim sparse-mode	46.30
show debugging power-inline	23.14
show debugging radius	60.17
show debugging rip	34.36
show debugging snmp	75.6
show debugging stack	88.13
show debugging vrrp	67.11
show dhcp lease	73.31
show dot1x diagnostics	55.15
show dot1x interface	55.16
show dot1x sessionstatistics	55.21
show dot1x statistics interface	55.22
show dot1x supplicant interface	55.25
show dot1x supplicant	55.23
show dot1x	55.13
show epsr counters	69.13
show epsr word counters	69.12
show epsr word	69.12
show epsr	69.11
show etherchannel detail	21.11
show etherchannel summary	21.12
show etherchannel	21.10
show exception log	10.42
show file systems	7.25
show file	7.24
show flowcontrol interface	15.21
show history	4.6
show hosts	25.36
show interface access-group	51.34
show interface brief	12.6
show interface status	12.7
show interface switchport	15.22
show interface	12.5
show ip access-list	51.37
show ip bgp attribute-info	40.111
show ip bgp cidr-only	40.112

show ip bgp community.....	40.113
show ip bgp community-info.....	40.114
show ip bgp community-list	40.114
show ip bgp dampening	40.115
show ip bgp filter-list.....	40.116
show ip bgp inconsistent-as	40.117
show ip bgp longer-prefixes.....	40.118
show ip bgp neighbors.....	40.119
show ip bgp paths.....	40.121
show ip bgp prefix-list	40.121
show ip bgp quote-regexp	40.122
show ip bgp regexp	40.122
show ip bgp route-map	40.123
show ip bgp scan	40.123
show ip bgp summary	40.124
show ip bgp view neighbors	40.126
show ip bgp view summary	40.127
show ip bgp view	40.125
show ip bgp	40.110
show ip community-list.....	40.128
show ip dhcp binding	73.32
show ip dhcp pool.....	73.33
show ip dhcp server statistics.....	73.37
show ip dhcp-relay	73.36
show ip dhcp server summary.....	73.38
show ip domain-list.....	25.36
show ip domain-name.....	25.37
show ip extcommunity-list.....	40.128
show ip forwarding.....	25.37
show ip igmp groups.....	43.35
show ip igmp interface	43.36
show ip igmp snooping mrouter	43.38
show ip igmp snooping routermode	43.38
show ip igmp snooping statistics	43.39
show ip interface brief.....	25.38
show ip irdp interface	25.40
show ip irdp.....	25.39
show ip mroute.....	44.8
show ip mvif	44.10
show ip name-server.....	25.42
show ip ospf border-routers	38.61
show ip ospf database asbr-summary	38.63
show ip ospf database external.....	38.64
show ip ospf database network.....	38.65
show ip ospf database nssa-external.....	38.67
show ip ospf database opaque-area.....	38.69
show ip ospf database opaque-as.....	38.70
show ip ospf database opaque-link.....	38.71
show ip ospf database router.....	38.72
show ip ospf database summary	38.74
show ip ospf database.....	38.62
show ip ospf interface.....	38.76
show ip ospf neighbor	38.77
show ip ospf route	38.79
show ip ospf virtual-links	38.80
show ip ospf.....	38.59
show ip pim dense-mode interface detail.....	48.16

show ip pim dense-mode interface	48.15
show ip pim dense-mode mroute.....	48.17
show ip pim dense-mode neighbor detail	48.18
show ip pim dense-mode neighbor.....	48.18
show ip pim dense-mode nexthop	48.19
show ip pim sparse-mode bsr-router	46.30
show ip pim sparse-mode interface detail	46.32
show ip pim sparse-mode interface	46.31
show ip pim sparse-mode mroute detail	46.34
show ip pim sparse-mode mroute.....	46.33
show ip pim sparse-mode neighbor.....	46.36
show ip pim sparse-mode nexthop.....	46.37
show ip pim sparse-mode rp mapping	46.38
show ip pim sparse-mode rp-hash.....	46.38
show ip prefix-list.....	51.38
show ip protocols bgp.....	40.129
show ip protocols ospf	38.81
show ip protocols rip.....	34.36
show ip rip database.....	34.37
show ip rip interface	34.38
show ip rip.....	34.37
show ip route database	32.6
show ip route summary.....	32.7
show ip route	32.4
show ip rpf	44.11
show ipv6 access-list.....	51.39
show ipv6 forwarding	27.15
show ipv6 interface brief.....	27.16
show ipv6 mld groups	49.17
show ipv6 mld interface	49.18
show ipv6 mld snooping mrouter	49.19
show ipv6 mld snooping statistics.....	49.20
show ipv6 neighbors.....	27.17
show ipv6 protocols rip.....	36.17
show ipv6 rip database	36.19
show ipv6 rip interface	36.20
show ipv6 rip	36.18
show ipv6 route summary	27.18
show ipv6 route.....	27.17
show lacp sys-id.....	21.13
show lacp-counter	21.13
show license	7.27
show list.....	4.7
show lldp interface	78.35
show lldp local-info	78.37
show lldp neighbors detail	78.43
show lldp neighbors.....	78.41
show lldp statistics interface	78.48
show lldp statistics	78.46
show lldp.....	78.34
show location	78.50
show log config.....	10.45
show log permanent.....	10.48
show log	10.43
show loop-protection.....	15.23
show mac address-table thrash-limit.....	15.25
show mac address-table.....	15.24

show mail.....	79.6
show memory allocations.....	8.24
show memory history.....	8.26
show memory pools.....	8.28
show memory.....	8.22
show mirror interface.....	15.27
show mirror.....	15.26
show mls qos interface policer-counters.....	53.37
show mls qos interface queue-counters.....	53.38
show mls qos interface storm-status.....	53.39
show mls qos interface.....	53.34
show mls qos maps cos-queue.....	53.40
show mls qos maps premark-dscp.....	53.41
show nsm client.....	8.29
show ntp associations.....	71.9
show ntp status.....	71.10
show ping-poll.....	86.15
show platform bist.....	15.29
show platform classifier statistics utilization brief.....	15.30
show platform power-inline.....	23.15
show platform table port.....	15.32
show platform.....	15.28
show policy-map.....	53.42
show port etherchannel.....	21.14
show port-security interface.....	15.36
show port-security intrusion.....	15.37
show power-inline counters.....	23.18
show power-inline interface detail.....	23.23
show power-inline interface.....	23.20
show power-inline.....	23.16
show privilege.....	5.12
show process.....	8.29
show radius local-server group.....	62.29
show radius local-server nas.....	62.30
show radius local-server statistics.....	62.31
show radius local-server user.....	62.32
show radius statistics.....	60.20
show radius.....	60.17
show rmon alarm.....	81.7
show rmon event.....	81.8
show rmon history.....	81.9
show rmon statistics.....	81.10
show route-map.....	41.35
show router-id.....	8.31
show running-config access-list.....	7.30
show running-config as-path access-list.....	7.31
show running-config bgp.....	7.32
show running-config community-list.....	7.33
show running-config full.....	7.34
show running-config interface.....	7.35
show running-config ip pim dense-mode.....	7.37
show running-config ip pim sparse-mode.....	7.37
show running-config ip route.....	7.38
show running-config ipv6 access-list.....	7.38
show running-config ipv6 mroute.....	7.39
show running-config ipv6 prefix-list.....	7.39
show running-config ipv6 route.....	7.40

show running-config key chain.....	7.40
show running-config lldp	7.41
show running-config log.....	10.50
show running-config power-inline	7.43
show running-config prefix-list.....	7.42
show running-config route-map.....	7.44
show running-config router vrrp	67.12
show running-config router	7.45
show running-config router-id	7.46
show running-config snmp	75.6
show running-config ssh	65.19
show running-config stack	88.14
show running-config switch lacp.....	7.48
show running-config switch radius-server	7.48
show running-config switch vlan.....	7.49
show running-config switch	7.47
show running-config trigger	84.8
show running-config.....	7.29
show snmp-server community	75.7
show snmp-server group.....	75.8
show snmp-server user.....	75.8
show snmp-server view.....	75.9
show snmp-server.....	75.7
show spanning-tree mst config	19.15
show spanning-tree mst detail interface	19.18
show spanning-tree mst detail.....	19.16
show spanning-tree mst instance interface.....	19.20
show spanning-tree mst instance	19.19
show spanning-tree mst interface.....	19.21
show spanning-tree mst	19.14
show spanning-tree.....	19.11
show ssh client.....	65.21
show ssh server allow-users.....	65.23
show ssh server deny-users.....	65.24
show ssh server	65.22
show ssh	65.20
show stack full-debug.....	88.18
show stack indicator	88.19
show stack	88.15
show startup-config.....	7.50
show static-channel-group	21.15
show storm-control	15.38
show system environment.....	8.34
show system interrupts.....	8.35
show system pci device	8.36
show system pci tree	8.37
show system pluggable detail	8.39
show system pluggable.....	8.38
show system serialnumber.....	8.41
show system.....	8.32
show tech-support	8.42
show telnet.....	5.13
show trigger	84.9
show users.....	5.13
show version.....	7.51
show vlan classifier group.....	17.6
show vlan classifier interface group.....	17.6

show vlan classifier rule.....	17.7
show vlan private-vlan	17.7
show vlan statistics.....	17.8
show vlan	17.5
show vrrp (session).....	67.13
show vrrp.....	67.12
shutdown	12.9
snmp trap link-status suppress.....	75.11
snmp trap link-status.....	75.10
snmp-server community.....	75.13
snmp-server contact.....	75.14
snmp-server enable trap	75.15
snmp-server engineID local	75.17
snmp-server group	75.18
snmp-server host.....	75.19
snmp-server location.....	75.21
snmp-server source-interface.....	75.22
snmp-server user	75.23
snmp-server view	75.25
snmp-server	75.12
source-ip.....	86.19
spanning-tree autoedge (RSTP and MSTP)	19.22
spanning-tree cisco-interoperability (MSTP).....	19.23
spanning-tree edgeport (RSTP and MSTP).....	19.24
spanning-tree enable	19.25
spanning-tree errdisable-timeout enable	19.26
spanning-tree errdisable-timeout interval.....	19.27
spanning-tree force-version.....	19.28
spanning-tree forward-time.....	19.29
spanning-tree guard root	19.30
spanning-tree hello-time.....	19.31
spanning-tree link-type	19.32
spanning-tree max-age	19.33
spanning-tree max-hops (MSTP)	19.34
spanning-tree mode.....	19.35
spanning-tree mst configuration.....	19.35
spanning-tree mst instance path-cost	19.37
spanning-tree mst instance priority	19.38
spanning-tree mst instance	19.36
spanning-tree path-cost	19.39
spanning-tree portfast (STP).....	19.40
spanning-tree portfast bpdu-filter	19.41
spanning-tree portfast bpdu-guard.....	19.42
spanning-tree priority (bridge priority)	19.44
spanning-tree priority (port priority).....	19.45
spanning-tree transmit-holdcount.....	19.46
speed	15.39
ssh client	65.27
ssh server allow-users	65.31
ssh server authentication.....	65.32
ssh server deny-users	65.33
ssh server scp.....	65.34
ssh server sftp.....	65.34
ssh server	65.29
ssh.....	65.25
stack enable	88.20
stack fallback-config.....	88.21

stack management subnet.....	88.22
stack management vlan.....	88.23
stack priority.....	88.24
stack renumber cascade.....	88.26
stack renumber.....	88.25
stack resiliencylink.....	88.27
stack software-auto-synchronize.....	88.29
stack virtual-chassis-id.....	88.30
stack virtual-mac.....	88.31
static-channel-group.....	21.16
storm-action.....	53.43
storm-control level.....	15.40
storm-downtime.....	53.44
storm-protection.....	53.45
storm-rate.....	53.46
storm-window.....	53.47
subnet-mask.....	73.39
summary-address.....	38.82
switchport access vlan.....	17.9
switchport enable vlan.....	17.10
switchport mode access.....	17.11
switchport mode private-vlan.....	17.12
switchport mode trunk.....	17.13
switchport port-security aging.....	15.42
switchport port-security maximum.....	15.43
switchport port-security violation.....	15.44
switchport port-security.....	15.41
switchport private-vlan host-association.....	17.14
switchport private-vlan mapping.....	17.15
switchport resiliencylink.....	88.32
switchport trunk allowed vlan.....	17.16
switchport trunk native vlan.....	17.18
switchport vlan-stacking (double tagging).....	17.19
switchport voice dscp.....	17.20
switchport voice vlan priority.....	17.23
switchport voice vlan.....	17.21
synchronization.....	40.130
system territory.....	8.45

T

tcpdump.....	25.43
telnet server.....	5.15
telnet.....	5.14
terminal length.....	5.16
terminal monitor.....	8.46
test interface.....	13.4
test.....	84.12
thrash-limiting.....	15.45
time (trigger).....	84.13
timeout (ping polling).....	86.20
timers (BGP).....	40.131
timers (RIP).....	34.39
timers (RIPng).....	36.21
timers spf.....	38.83
traceroute ipv6.....	27.19

traceroute	25.43
trap	84.15
trigger activate	84.17
trigger	84.16
trust dscp	53.48
tunnel dscp	29.3
tunnel mode ipv6ip	29.4
tunnel source	29.5
tunnel ttl	29.6
type cpu	84.18
type interface	84.19
type memory	84.20
type periodic	84.21
type ping-poll	84.22
type reboot	84.22
type stack link	84.25
type stack master-fail	84.23
type stack member	84.24
type time	84.26

U

undebg all pim dense-mode	48.20
undebg all pim sparse-mode	46.39
undebg bgp	40.132
undebg ipv6 rip	36.22
undebg nsm packet	8.47
undebg nsm	8.46
undebg rip	34.40
undebg vrrp events	67.14
undebg vrrp packet	67.14
undebg vrrp	67.13
up-count	86.21
user (RADIUS server)	62.34
username	5.17

V

version	34.41
virtual-ip	67.15
vlan (RADIUS server)	62.36
vlan classifier activate	17.25
vlan classifier group	17.26
vlan classifier rule ipv4	17.27
vlan classifier rule proto	17.28
vlan database	17.30
vlan statistics	17.31
vlan	17.24
vrrp vmac	67.15

W

wait	11.4
write file	7.52
write memory	7.52

write terminal	7.52
wrr-queue egress-rate-limit queues.....	53.49
wrr-queue weight queues	53.50

Appendix B: Changes in this Software Version

This appendix lists the changes made in Version 5.3.3-0.1.

- [New and Changed Features \(Table B-1 on page B.I\)](#)
- [New and Changed Commands: \(Table B-2 on page B.II\)](#)
- [New and Changed MIBs: \(Table B-3 on page B.IX\)](#)

Clicking on a topic in the Feature column will take you to the appropriate section of the manual.

Table B-1: New and Changed Features

Feature	Status	Chapter/Section	Description
Fixed or Virtual MAC Addressing	New	Stacking Introduction	A VCS Stack can now operate using a single “virtual” MAC address. This feature is enabled using the stack virtual-mac-command and the address is set by using the stack virtual-chassis-id command.
Power over Ethernet (PoE)	New	Power over Ethernet Introduction	Power over Ethernet (PoE) is a technology allowing powered devices, such as IP telephones, to receive power over existing LAN cabling.
Roaming Authentication	New	Authentication Configuration	When network security is required, the usability of network security must be considered. The Roaming Authentication feature improves the usability of network security by enabling users to move within the network without requiring them to re-authenticate each time they move.
VLAN Statistics	New	VLAN Introduction	This feature provides a series of data counters each able to count both the number of received frames and the number of received bytes (octets) belonging to a particular VLAN.
LLDP-MED	New	LLDP Introduction	LLDP for Media Endpoint Devices (LLDP-MED), is an extension of LLDP used between LAN network connectivity devices, such as this switch, and the media endpoint devices connected to them, such as IP phones.
Voice VLAN	New	LLDP Introduction	The Voice VLAN feature uses LLDP-MED to convey configuration information for the voice traffic to the IP phone. In response, the IP phone sends voice traffic according to this configuration.

Table B-2: New and Changed Commands

Feature	Status	Chapter/Section	Description
auth critical	Modified	Authentication Commands	This command can now be configured on static channel group (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
auth dynamic-vlan-creation	Modified	Authentication Commands	This command can now be configured on static channel group (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
auth guest-vlan	Modified	Authentication Commands	This command can now be configured on static channel group (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
auth host-mode	Modified	Authentication Commands	This command can now be configured on static channel group (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
auth max-suppliant	Modified	Authentication Commands	This command can now be configured on static channel group (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
auth reauthentication	Modified	Authentication Commands	This command can now be configured on static channel group (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
auth roaming disconnected	New	Authentication Commands	This command enables the roaming authentication feature on an authenticated interface that is link down, so a supplicant does not need to be reauthenticated when moved between authenticated interfaces.
auth roaming enable	New	Authentication Commands	This command enables the roaming authentication feature on an authenticated interface that is link up, so a supplicant does not need to be reauthenticated when moved between authenticated interfaces.
auth supplicant-mac	Modified	Authentication Commands	This command can now be configured on static channel group (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
auth timeout quiet-period	Modified	Authentication Commands	This command can now be configured on static channel (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
auth timeout reauth-period	Modified	Authentication Commands	This command can now be configured on static channel (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
auth timeout server-timeout	Modified	Authentication Commands	This command can now be configured on static channel (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
auth timeout supp-timeout	Modified	Authentication Commands	This command can now be configured on static channel (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.

Table B-2: New and Changed Commands(Continued)

Feature	Status	Chapter/Section	Description
auth-mac enable	Modified	Authentication Commands	This command can now be configured on static channel (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
auth-mac method	Modified	Authentication Commands	This command can now be configured on static channel (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
auth-mac reauth-relearning	Modified	Authentication Commands	This command can now be configured on static channel (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
auth-web enable	Modified	Authentication Commands	This command can now be configured on static channel (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
auth-web forward	Modified	Authentication Commands	This command can now be configured on static channel (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
auth-web max-auth-fail	Modified	Authentication Commands	This command can now be configured on static channel (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
auth-web method	Modified	Authentication Commands	This command can now be configured on static channel (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
auto-summary	New	BGP Commands	Use this command to enable sending summarized routes by a BGP speaker to its peers in the router configuration mode or in the address-family configuration mode. BGP uses auto-summary to advertise summarized routes.
clear power-inline counters interface	New	Power over Ethernet Commands	This command clears all the Power over Ethernet (PoE) counters supported in the Power Ethernet MIB (RFC 3621) from a specified port, a range of ports, or all ports on the Power Sourcing Equipment (PSE).
clear radius local-server statistics	New	Local RADIUS Server Commands	This command clears the statistics stored on the switch for the Local RADIUS Server, the NAS (Network Access Server), and Local RADIUS Server users.
clear vlan statistics	New	VLAN Commands	This command resets the counters for either a specific vlan statistics instance or (by not specifying an instance) resets all instances.
debug power-inline	New	Power over Ethernet Commands	This command enables the specified Power over Ethernet (PoE) debugging messages.
default-metric (OSPF)	Modified	OSPF Commands	This command sets default metric values for the OSPF routing protocol. The minimum metric value that can be set is now 1.
dot1x control-direction	Modified	802.1X Commands	This command can now be configured on static channel group (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.

Table B-2: New and Changed Commands(Continued)

Feature	Status	Chapter/Section	Description
dot1x eapol-version	Modified	802.1X Commands	This command can now be configured on static channel group (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
dot1x initialize interface	Modified	802.1X Commands	This command can now be configured on static channel group (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
dot1x keytransmit	Modified	802.1X Commands	This command can now be configured on static channel group (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
dot1x max-reauth-req	Modified	802.1X Commands	This command can now be configured on static channel group (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
dot1x port-control	Modified	802.1X Commands	This command can now be configured on static channel group (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
dot1x timeout tx-period	Modified	802.1X Commands	This command can now be configured on static channel group (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
egress-vlan-id	New	Local RADIUS Server Commands	Use this command to configure the standard RADIUS attribute 'Egress-VLANID (56)' for the local RADIUS Server user group.
egress-vlan-name	New	Local RADIUS Server Commands	Use this command to configure the standard RADIUS attribute 'Egress-VLAN-Name (58)' for the Local RADIUS Server user group.
ip extcommunity-list standard	Modified	BGP Commands	Use this command to create and delete a standard extended community list. This command has been modified to include new parameters to add the route target and the site of origin of the extended community to a standard extended community list.
ip igmp limit	Modified	IGMP Multicast Commands	The maximum number of group membership entries is now configurable to a value within the range 2 to 512.
ip pim propagation-delay	Modified	PIM-DM Commands	This command now has a range of <1000-5000> milliseconds with a default <1000> milliseconds propagation delay. Earlier releases had a default propagation delay of <500> milliseconds within a <500-5000> range.
ipv6 mld limit	Modified	MLD Snooping Commands	AW+ 5.3.3-0.1 release software allows a configurable range of <2-2097152> group memberships using this command. Earlier AW+ software releases allow a configurable range of <1-2097152> group memberships.

Table B-2: New and Changed Commands(Continued)

Feature	Status	Chapter/Section	Description
lldp faststart-count	New	LLDP Commands	Use this command to set the fast start count for LLDP-MED. The fast start count determines how many fast start messages LLDP sends when it starts transmitting LLDP-MED advertisements from a port.
lldp med-notifications	New	LLDP Commands	Use this command to enable LLDP to send LLDP-MED Topology Change Detected SNMP notifications relating to the specified ports.
lldp med-tlv-select	New	LLDP Commands	Use this command to enable or disable LLDP-MED Organizationally Specific TLVs for transmission in LLDP advertisements via the specified ports.
lldp non-strict-med-tlv-order-check	New	LLDP Commands	Use this command to enable non-strict TLV order checking on receiving LLDP-MED LLDPDUs.
lldp tlv-select	Modified	LLDP Commands	This command now allows the selection of additional optional TLVs: MAC/PHY Configuration/Status, Power Via MDI, Link Aggregation, and Maximum Frame Size TLVs.
lldp transmit receive	Modified	LLDP Commands	The default for this command has changed. By default, both transmission and reception of LLDP advertisements are now enabled on all ports when LLDP is enabled by the lldp run command.
location civic-location configuration	New	LLDP Commands	Use these commands to configure a civic address location.
location civic-location identifier	New	LLDP Commands	Use this command to enter the Civic Address Location Configuration mode to configure the specified location.
location civic-location-id	New	LLDP Commands	Use this command to assign a civic address location to the ports.
location coord-location configuration	New	LLDP Commands	Use this command to configure a coordinate-based location.
location coord-location identifier	New	LLDP Commands	Use this command to enter the Coordinate Configuration mode to configure this location.
location coord-location-id	New	LLDP Commands	Use this command to assign a coordinate location to the ports.
location elin-location	New	LLDP Commands	Use this command to create or modify an ELIN location.
location elin-location-id	New	LLDP Commands	Use this command to assign an ELIN location to the ports.
mtu	Modified	Interface Commands	The MTU (Maximum Transmission Unit) size for an interface specified by this command has changed from <64-9208> bytes to <68-9208> bytes. The negated form of this command now restores the default MTU size of 1500 bytes.
power-inline allow-legacy	New	Power over Ethernet Commands	This command enables detection of pre-IEEE 802.3af Power Ethernet standard legacy Powered Devices (PDs).
power-inline description	New	Power over Ethernet Commands	This command adds a description for a Powered Device (PD) connected to a port.

Table B-2: New and Changed Commands(Continued)

Feature	Status	Chapter/Section	Description
power-inline enable	New	Power over Ethernet Commands	This command enables Power over Ethernet (PoE) to detect a connected Powered Device (PD) and supply power from the Power Sourcing Equipment (PSE).
power-inline max	New	Power over Ethernet Commands	This command sets the maximum power supplied to a Power over Ethernet (PoE) port.
power-inline priority	New	Power over Ethernet Commands	This command sets the Power over Ethernet (PoE) priority level of a PoE port to one of three available priority levels.
power-inline usage-threshold	New	Power over Ethernet Commands	This command sets the level at which the Power Sourcing Equipment (PSE) detects that the power supplied to all Powered Devices (PDs) has reached a critical level of the nominal power rating for the PSE.
service power-inline	New	Power over Ethernet Commands	This command enables Power over Ethernet (PoE) globally on the Power Sourcing Equipment (PSE) for all PoE ports.
set community	Modified	Route Map Commands	This command adds a community set clause to a route map entry. Autonomous System (AS) numbers can now be entered in integer format <1-65535> in addition to AA:NN format.
show auth-mac diagnostics	Modified	Authentication Commands	This command can now show configured static channel (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
show auth-mac interface	Modified	Authentication Commands	This command can now show configured static channel (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
show auth-mac sessionstatistics	Modified	Authentication Commands	This command can now show configured static channel (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
show auth-mac statistics interface	Modified	Authentication Commands	This command can now show configured static channel (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
show auth-mac supplicant interface	Modified	Authentication Commands	This command can now show configured static channel (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
show auth-web diagnostics	Modified	Authentication Commands	This command can now show configured static channel (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
show auth-web interface	Modified	Authentication Commands	This command can now show configured static channel (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
show auth-web sessionstatistics	Modified	Authentication Commands	This command can now show configured static channel (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
show auth-web statistics interface	Modified	Authentication Commands	This command can now show configured static channel (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
show auth-web supplicant interface	Modified	Authentication Commands	This command can now show configured static channel (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.

Table B-2: New and Changed Commands(Continued)

Feature	Status	Chapter/Section	Description
show debugging power-inline	New	Power over Ethernet Commands	This command displays Power over Ethernet (PoE) debug settings.
show dot1x diagnostics	Modified	802.1X Commands	This command can now show static channel group (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
show dot1x interface	Modified	802.1X Commands	This command can now show static channel group (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
show dot1x sessionstatistics	Modified	802.1X Commands	This command can now show static channel group (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
show dot1x statistics interface	Modified	802.1X Commands	This command can now show static channel group (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
show dot1x supplicant interface	Modified	802.1X Commands	This command can now show static channel group (or static aggregator) and dynamic (or LACP) channel group interfaces in addition to switch ports.
show interface	Modified	Interface Commands	This command now also displays link status SNMP notification and suppression settings.
show interface status	New	Interface Commands	Use this command to display the status of specified interfaces, or all interfaces.
show ip pim dense-mode interface	Modified	PIM-DM Commands	This command now also displays the number of configured and active PIM Dense Mode interfaces, and the maximum number of PIM-DM interfaces that can be configured.
show ip pim sparse-mode interface	Modified	PIM-SM Commands	This command now also displays the number of configured and active PIM Sparse Mode interfaces, and the maximum number of PIM-SM interfaces that can be configured.
show lldp	Modified	LLDP Commands	This command now also displays the fast start count for LLDP-MED.
show lldp interface	Modified	LLDP Commands	This command now displays additional TLVs and a notification setting for LLDP-MED.
show lldp local-info	Modified	LLDP Commands	This command now displays additional information for LLDP-MED, and has new options for selecting which local information to display.
show lldp neighbors	Modified	LLDP Commands	This command now also displays LLDP-MED neighbor information for the ports.
show lldp neighbors detail	Modified	LLDP Commands	This command now displays additional information for LLDP-MED, and has new options for selecting which detailed neighbor information to display.
show location	New	LLDP Commands	Use this command to display location information configured on the switch.
show platform classifier statistics utilization brief	New	Switching Commands	This command displays the total memory space, and free memory space of CAM (Content-Addressable Memory).
show platform power-inline	New	Power over Ethernet Commands	This command is only for Allied Telesis Field Support and Developer use when debugging PoE.

Table B-2: New and Changed Commands(Continued)

Feature	Status	Chapter/Section	Description
<code>show power-inline</code>	New	Power over Ethernet Commands	This command displays the Power over Ethernet (PoE) status for all ports on the Power Sourcing Equipment (PSE).
<code>show power-inline interface</code>	New	Power over Ethernet Commands	This command displays a summary of Power over Ethernet (PoE) information for specified ports.
<code>show power-inline interface detail</code>	New	Power over Ethernet Commands	This command displays detailed information for specified Power over Ethernet (PoE) port(s) on the Power Sourcing Equipment (PSE).
<code>show power-inline counters</code>	New	Power over Ethernet Commands	This command displays Power over Ethernet (PoE) event counters for ports on the PSE (Power Sourcing Equipment). The PoE event counters displayed correspond with the objects in the PoE MIB (RFC 3621).
<code>show running-config power-inline</code>	New	File Management Commands	Use this command to show the Power over Ethernet (PoE) running system status and configuration details.
<code>show vlan statistics</code>	New	VLAN Commands	This command displays the current configuration for either a specific vlan statistics instance, or (by not specifying an instance) displays all vlan VLAN statistics instances.
<code>snmp trap link-status</code>	New	SNMP Commands	Use this command to enable or disable the sending of link status SNMP notifications (traps) for the interfaces.
<code>snmp trap link-status suppress</code>	New	SNMP Commands	Use this command to enable or disable the suppression of link status SNMP notifications (traps) for the interfaces after a threshold is crossed.
<code>snmp-server enable trap</code>	Modified	SNMP Commands	This command can now enable the switch to send power-inline (PoE) and VRRP notifications (traps). This command can no longer enable link status notifications; see the snmp trap link-status command.
<code>stack virtual-chassis-id</code>	New	Stacking Commands	This command specifies the VC Stack virtual chassis ID. The ID selected will determine which virtual MAC address the stack will use. The MAC address assigned to a stack must be unique within its network.
<code>stack virtual-mac</code>	New	Stacking Commands	This command enables the VC Stack virtual MAC address feature.
<code>switchport voice dscp</code>	New	VLAN Commands	Use this command to configure the layer 3 DSCP value advertised when the transmission of LLDP-MED network policy for voice devices is enabled.
<code>switchport voice vlan</code>	New	VLAN Commands	Use this command to configure the Voice VLAN tagging advertised when the transmission of LLDP-MED network policy for voice devices is enabled.
<code>switchport voice vlan priority</code>	New	VLAN Commands	Use this command to configure the Voice VLAN user priority advertised when the transmission of LLDP-MED network policy for voice devices is enabled.
<code>vlan statistics</code>	New	VLAN Commands	This command creates a VLAN statistics instance, and enables you to add one or more ports to a defined counter instance. This command can only be applied to switch ports. You cannot apply it to aggregated links or eth ports.

Table B-2: New and Changed Commands(Continued)

Feature	Status	Chapter/Section	Description
wait	New	Scripting Commands	This command pauses execution of the active script for the specified period of time.

Table B-3: New and Changed MIBs

Feature	Status	Chapter/Section	Description
AT-BOARDS-MIB	New	SNMP MIBs	A new MIB has been added to support the x600-24Ts-POE switch.
AT-PRODUCT-MIB	New	SNMP MIBs	A new MIB has been added to support the x600-24Ts-POE switch.
AT-VLAN-MIB	New	SNMP MIBs	This new MIB defines objects for managing VLANs. The MIB contains a sub tree for managing VLAN statistics.
LLDP-EXT-DOT3-MIB	New	SNMP MIBs	The LLDP-EXT-DOT3-MIB is based on IEEE Standard 802.1AB-2005, Annex G, IEEE 802.3 Organizationally Specific TLVs, Section G.7.1, IEEE 802.3 LLDP extension MIB module.
LLDP-EXT-MED-MIB	New	SNMP MIBs	The LLDP-EXT-MED-MIB is based on ANSI/TIA-1057- 2006, Section 13.3, LLDP-MED MIB Definition.
POE-MIB	New	SNMP MIBs	The POE-MIB is based on RFC 3621, Power Ethernet MIB. RFC 3621 supports the IEEE 802.3af standard.
VRRP-MIB	New	SNMP MIBs	The VRRP-MIB is based on RFC 2787, Definitions of Managed Objects for the Virtual Router Redundancy Protocol. All objects with read-write and read-create access are implemented as read-only.

Appendix C: GUI Reference

Introduction.....	1.2
Installing and Setting-up the GUI	1.3
System Requirements.....	1.3
Installing the GUI to your switch using an SD card	1.3
Installing the GUI to Your Switch Via TFTP server	1.5
Using the GUI.....	1.7
System > Status > System Details.....	1.8
System > Status > System Date and Time.....	1.9
System > Status > Top Ten Utilised Ports.....	1.9
System > File Management > Copy File.....	1.13
System > File Management > Move File.....	1.14
System > Stacking > Configure Stacking.....	1.16
System > Stacking > Configure Stack Member.....	1.17
System > License Management > Add Feature License.....	1.19
Switching > Ports > Monitor Port.....	1.22
Switching > Ports > Configure Port.....	1.23
Switching > VLANs > Add VLAN.....	1.26
Switching > Link Aggregation > Add Static Channel.....	1.29
Switching > Link Aggregation > Add Dynamic Channel.....	1.29
IP > IP Interfaces > Configure Primary IP Address	1.32
IP > IP Interfaces > Add Secondary IP Address	1.32
IP > Static Routes > Add Static Route.....	1.34
IP > DNS > Add DNS Server	1.37
IP > IGMP Snooping > Configure Interface	1.39
Management > NTP > Add NTP Association.....	1.46
Management > Logs > Export Logs.....	1.51

Introduction

This appendix describes how to install, configure and use the Graphical User Interface (GUI) on switches running the AlliedWare Plus™ OS. The GUI provides extensive monitoring and essential configuration functionality for Allied Telesis switches via a web browser. This document explains how to install the GUI using either an SD card or via a TFTP server.

The GUI functionality is provided via a Java applet file. Before you can use the GUI to manage your switches, you must download the Java applet file, and install it to your switch's flash file system.

Once the Java applet file is present in your switch's flash, no specific commands are required to enable the GUI, or to inform the switch which Java applet file to use. Instead, when an incoming browser connection is established with the switch, the switch will automatically send the most recent compatible Java applet file that is present in its flash file system.

Different versions of the Java applet file will be compatible with different versions of the AlliedWare Plus OS. The AlliedWare Plus OS automatically determines if a Java applet file is compatible, so the Java applet file that is delivered to your browser will always be compatible with the AlliedWare Plus OS version running on the switch to which you have connected.

Note which products and software version the GUI works with, along with PC and browser specifications listed. You may need to install and run the latest Java Runtime Environment that you can download from the Sun site so your browser can fully support the GUI Java applet.

Installing and Setting-up the GUI

This section shows you how to install and setup the AlliedWare Plus GUI:

System Requirements

To install and run the AlliedWare Plus GUI you will require the following system products and setup:

- PC Platform:
Windows XP SP2 and up / Windows Vista SP1 and up
- Browser: (must support Java Runtime Environment (JRE) version 6)
Microsoft Internet Explorer 7.0 and up / Mozilla Firefox 2.0 and up

Installing the GUI to your switch using an SD card

Step 1: Download a GUI Java applet

The GUI Java applet file is available in a compressed (zip) file with the AlliedWare Plus operating system software from the Support area of the Allied Telesis Website: <http://www.alliedtelesis.com>. Download the Java applet file. This file will have .zip file name extension. You need to extract the Java .jar file from the compressed .zip file. The version number of the software applet file (.jar) gives the earliest version of the software file (.rel) that the GUI can operate with.

Step 2: Copy the GUI Java applet .jar file to an SD card.

Insert the SD card in the SD slot on the front of your switch. Connect to the management port, then login to the switch.

Copy the GUI Java applet to your switch, using the below commands:

```
awplus# copy card:/<filename.jar> flash:/
```

Where **<filename.jar>** is the GUI Java applet file you downloaded in step 1.

Step 3: Assigning IP addresses

Use the following commands to assign the IP addresses for connecting to the Java applet.

```
awplus# configure terminal
awplus(config)# interface vlan1
awplus(config-if)# ip address <address>/<prefix-length>
```

Where **<address>** is the IP address that you will subsequently browse to when you connect to the GUI Java applet. For example, to give the switch an IP address of 192.168.2.6, with a subnet mask of 255.255.255.0, use the following command:

```
awplus(config-if)# ip address 192.168.2.6/24
```

Step 4: Configuring the Gateway

Configure your switch with a default gateway, if necessary, using these commands:

```
awplus(config-if)# exit  
awplus(config)# ip route 0.0.0.0/0 <gateway-address>
```

Where <gateway-address> is the IP address for your gateway device. Note that you do not need to define a default gateway if you browse to the switch from within its own subnet.

Step 5: Creating a user account


In order to log into the GUI, you must first create a user account. Use the following commands to setup a user account

```
awplus(config)# username <username> privilege 15 guiuser  
password <password>
```

Note that you can create multiple users to log into the GUI. See the AlliedWare Plus Software Reference for information about the username command.

Step 6: Logging into the GUI

Start a browser then enter the IP address you configured in step 3 as the URL. You will then be presented with a login screen after the GUI Java applet has started. You can then Log in with the username and password that you defined previously in the earlier step, named [Creating a user account](#).



Installing the GUI to Your Switch Via TFTP server

Step 1: Download a GUI Java applet file from the support site:

The GUI Java applet file is available in a compressed (zip) file with the AlliedWare Plus operating system software from the Support area of the Allied Telesis Website: <http://www.alliedtelesis.com>. Download the Java applet file. This file will have .zip file name extension. You need to extract the Java .jar file from the compressed .zip file. The version number of the software applet file (.jar) gives the earliest version of the software file (.rel) that the GUI can operate with.

Step 2: Copy the GUI applet

Copy the GUI applet .jar file onto a TFTP server. Ensure this TFTP server is enabled and ready for the switch. Connect to the management port of the switch, then login to the switch. Do not connect to the management port of the TFTP server

Step 3: Assign the IP addresses:

Use the following commands to configure your switch with an appropriate IP address:

```
awplus# configure terminal
awplus(config)# interface vlan1
awplus(config-if)# ip address <address>/<prefix-length>
```

Where <address> is the IP address that you will subsequently browse to when you connect to the GUI Java applet. For example, to give the switch an IP address of 192.168.2.6, and a subnet mask of 255.255.255.0, use the following command:

```
awplus(config-if)# ip address 192.168.2.6/24
```

Use the following commands to configure your switch with a default gateway::

```
awplus(config-if)# exit
awplus(config)# ip route 0.0.0.0/0 <gateway-address>
```

Step 4: Configure the Default Gateway

In necessary, use the following commands to configure the default gateway.

```
awplus(config-if)# exit
awplus(config)# ip route 0.0.0.0/0 <gateway address>
```

Where <gateway-address> is the IP address for your gateway device. Note that you do not need to define a default gateway if you browse to the switch from within its own subnet.

Step 5: Copy the GUI Java applet to your switch

Use the following commands to copy the GUI Java applet to your switch:

```
awplus# copy tftp://<server-address>/
<filename.jar> flash:/
```

Where *<server-address>* is the IP address for the TFTP server, and where *<filename.jar>* is the GUI Java applet file you downloaded in step 1.

Step 6: Create a user account

In order to log into the GUI, you must first create a user account. Use the following commands to setup a user account

```
awplus(config)# username <username> privilege 15 guiuser  
password <password>
```

Note that you can create multiple users to log into the GUI. See the AlliedWare Plus Software Reference for information about the username command.

Step 7: Logging into the GUI

Start a browser then enter the IP address you configured in step 3 as the URL. You will then be presented with a login screen after the GUI Java applet has started. You can then Log in with the username and password that you defined previously in step 6.



Using the GUI

This section explains how to use the AlliedWare Plus GUI. It assumes that you have installed the GUI on your switches and have the setup the browser on your PC. This procedure is covered in “Installing and Setting-up the GUI” on page C.3.

In this section each screen is presented by its tab name and explains the content of the screen components.


System > Status

The System > Status menu tab enables you to display and configure basic system information.

The CPU Used % and Memory Free % graphs provide a brief history of CPU and memory usage.

Note: For systems equipped and configured using VCStack, there is a separate tab for each stack member with the system name displayed on each tab.

Menu Tab Figure C-1: Example showing the **System > Status** menu tab:



Description

Display Label / Field	Description
System / Name	Specifies the network name of the system, as set with the 'hostname' command in the CLI.
System / Started	Date and time the switch was last booted.
System / Uptime	Elapsed time since the last boot.

Display Label / Field	Description(Continued)
System / Contact	Contact details for system maintenance.
System / Location	Location of the switch
System / Description	Description of the switch, including manufacturer, model, and software version.
Top Ten Utilised Ports	Displays a sorted list of the ten most used ports listed by port and its utilisation. You can rearrange and resort the list by port or utilisation.

Description


Configuration Button / Field	Description
Configure System Details	Add or modify System Name, System Contact, System Location.
Configure System Details / System Name	Configures the network name of the system.
Configure System Details / System Contact	Configures the contact information for the system, from 0 to 255 characters long. Valid characters are any printable characters and spaces.
Configure System Details / System Location	Configures the location of the system, from 0 to 255 characters long. Valid characters are any printable characters and spaces.

System > Status > System Details

The System > Status > System Details dialog allows you to configure basic system information.

Configuration Dialog

Figure C-2: Example showing **System > Status > Configure System Details** dialog:



Description


Label / Field / Button	Description
System Name	Enter the network name of the system.
System Contact	Enter the contact information for the system, from 0 to 255 characters long. Valid characters are any printable characters and spaces.
System Location	Enter the location of the system, from 0 to 255 characters long. Valid characters are any printable characters and spaces.

System > Status > System Date and Time

The System > Status > System Date and Time dialog allows you to configure the date and time for the switch.

Configuration Dialog

Figure C-3: Example showing **System > Status > System Date and Time** dialog:



Description


Label / Field / Button	Description
System Name	Enter the network name of the system.
System Contact	Enter the contact information for the system, from 0 to 255 characters long. Valid characters are any printable characters and spaces.
System Location	Enter the location of the system, from 0 to 255 characters long. Valid characters are any printable characters and spaces.

System > Status > Top Ten Utilised Ports

The System > Status > Top Ten Utilised Port dialog allows you to monitor port utilisation on the switch.

Configuration Dialog

Figure C-4: Example showing **System > Status > Top Ten Utilised Ports** dialog:



Description


Label / Field / Button	Description
Port	Displays up to ten ports that are used the most on the switch. You can sort by ascending or descending port order.
Utilisation	Displays the utilisation percentage for the port. You can sort by ascending or descending utilisation percentage.

System > Identity

The System > Identity menu tab displays physical properties, software version and configuration file name.

Note: For systems equipped and configured using VCStack there is a separate tab for each stack member with the system name displayed on each tab.

Menu Tab Figure C-5: Example showing the **System > Identity** menu tab:



Description


Label / Field / Button	Description
HARDWARE	Displays the board, bay, model, revision and serial number of the switch main board and any installed XEMs.
MAC Address	Displays the MAC Address of the switch in hexadecimal in the format HHHH.HHHH.HHHH.
SOFTWARE	Displays the software release file name, software version, boot loader version, and configuration file name loaded on the switch.
MEMORY	Displays the amount of installed RAM and flash, plus the remaining Flash available on the switch.

System > Environment Monitoring

The System > Environment Monitoring menu tab allows you to display the status of the environmental properties, such as all voltages and temperatures, which the system monitors.

Note: For systems equipped and configured using VCStack there is a separate tab for each stack member with the system name displayed on each tab.

Menu Tab Figure C-6: Example showing the **System > Environment Monitoring** menu tab:




Description

Label / Field / Button	Description
Chassis	Displays the operational status of chassis voltages and temperatures for the switch.
Fan	Displays the operational status of the switch fans.
XEM	Displays the operational status of voltages, temperatures, and fans for any installed XEMs.
PSU	Displays the operational status of temperatures and fans for any installed pluggable PSUs.

System > File Management

The System > File Management menu tab allows you to create, copy, delete, upload or download files to and from the switch.

Menu Tab Figure C-7: Example showing the **System > File Management** menu tab:



Description: File System

Label / Field / Button	Description
File System	Displays file names, file dates, and file sizes of files in Flash, NVS or SD-card.
File System / Add Folder	Select the folder you want to create a new sub-folder in then click on the Add Folder icon located directly below the File System label.
File System / Rename File or Folder	Select the file or folder you want to rename then click on the Rename File or Folder icon located directly below the File System label.
File System / Copy File or Folder	Select the file or folder you want to rename then click on the Copy File or Folder icon located directly below the File System label. Choose the Destination Folder from the drop down list in the Copy File dialog then select OK to copy the file or folder to the chosen destination.
File System / Move File or Folder	Select the file or folder you want to move then click on the Move File or Folder icon located directly below the File System label. Choose the Destination Folder from the drop down list in the Move File dialog then select OK to move the file or folder to the chosen destination.

Description: System Configuration

Label / Field / Button	Description(Continued)
File System / Download File	Select the file you want to download then click on the Download File icon located directly below the File System label.
File System / Upload File	Select the file you want to upload then click on the Upload File icon located directly below the File System label.


Label / Field / Button	Description
System Configuration	Configures running and backup software, GUI software, and configuration files in Flash or card memory available on the switch.
System Configuration / Next Boot Firmware	Choose the Next Boot Firmware .rel file and path from the drop down list then click Set to make this file the firmware that starts after reboot.
System Configuration / Backup Boot Firmware	Choose the Backup Boot Firmware .rel file and path from the drop down list then click Set to make this file the fallback boot firmware at reboot.
System Configuration / GUI Files	Choose the GUI Files .jar file and path from the drop down list then click Set to make this file the GUI file that you connect to after reboot.
System Configuration / Config Files	Choose the Config Files .cfg file and path from the drop down list then click Set to make this file the config file that the switch uses at reboot.

System > File Management > Copy File

The System > File Management > Copy File dialog allows you to copy release and configuration files.

Configuration Dialog

Figure C-8: Example showing **System > File Management > Copy File** dialog:



Description


Label / Field / Button	Description
Destination Folder	Enter the destination folder to copy the selected file to.

System > File Management > Move File

The System > File Management > Move File dialog allows you to move release and configuration files.

Configuration Dialog

Figure C-9: Example showing **System > File Management > Move File** dialog:




Description

Label / Field / Button	Description
Destination Folder	Enter the destination folder to move the selected file to.

System > Stacking

The System > Stacking menu tab allows you to display and monitor a summary of the identity and status of stack members, plus you can also configure the VLAN ID and IP subnets used for internal VCS stack communication.

Menu Tab Figure C-10: Example showing the **System > Stacking** menu tab:



Description: Stack Status

Label / Field / Button	Description
Stacking Management / Stack Status	The stack's overall status. Note that a warning is issued if the stack is not connected in a standard ring topology.
Stacking Management / Management VLAN ID	The VLAN ID currently used for stack management. The default stack management VLAN ID is 4094.
Stacking Management / Next Boot VLAN ID	The VCS management VLAN ID to be assigned after the next reboot.
Stacking Management / Next Boot VLAN Subnet	The stacking management VLAN subnet address after rebooting.
Configure Stacking	Configures the VCS management VLAN ID and the subnet address of the VCS management VLAN.

Description:
Stacking
Management


Label / Field / Button	Description
Stack Status / Stack ID	The Stack member ID.
Stack Status / Pending ID	The Stack member ID to be assigned to the device after the next reboot.
Stack Status / Product Type	The Stack member product type; for example, SwitchBlade x908.
Stack Status / Role	Stack member's role in the stack (either master or backup).
Stack Status / Host Name	The host name of the Stack member.
Stack Status / MAC Address	Stack member's hardware MAC address. Note that frames from devices within a stacked virtual chassis will carry the source address of the stack master.
Stack Status / Priority	The priority for election of stack master (0 to 255). The lowest number has the highest priority. Note that where stack members have the same priority setting, the switch with the lowest MAC address will become the stack master.
Stat Status / Port Status	The status of the stack port, can be: "Down", "Neighbour incompatible", "Discovering neighbour", or "Learnt neighbour <neighbour member ID>".

System > Stacking > Configure Stacking

The System > Stacking > Configure Stacking dialog allows you to configure the VLAN ID and IP subnets used for internal VCStack communication.

Configuration
Dialog

Figure C-11: Example showing **System > Stacking > Configure Stacking** dialog:


Description


Label / Field / Button	Description
Management VLAN ID	Enter the VLAN ID for stack management. The default stack management VLAN ID is 4094.
Management VLAN subnet	Enter the subnet address of the VCS management VLAN.

System > Stacking > Configure Stack Member

The System > Stacking > Configure Stack Member dialog allows you to configure the Pending ID, Priority, Software Version Auto Synchronization and Operational Status used for internal VCSStack communication.

Configuration Dialog

Figure C-12: Example showing **System > Stacking > Configure Stack Member** dialog:



Description

Label / Field / Button	Description
Pending ID	Enter the Pending ID for the stack member.
Priority	Enter the Priority for the stack member.
Software Version Auto Sync	Select the enabled or disabled options to enable or disable the Software Version Auto Synchronization feature for the stack member.
Operational Status	Select the enabled or disabled options to enable or disable the stack member.


System > License Management

The System > License Management menu tab allows you to view, add and delete feature licenses.

Note: For systems equipped and configured using VCStack there is a separate tab for each stack member with the system name displayed on each tab.

Note: If a license is added to, or deleted from, a stack member then the same action must be taken on all other stack members. Otherwise incompatible licensing will occur and affected devices will not rejoin the stack following a reboot.

Menu Tab Figure C-13: Example showing the **System > License Management** menu tab:



Description


Label / Field / Button	Description
License List / License Name	Name of the license bundle.
License List / Type	The type of license activated on the switch: full or temporary.
License Details / Index	Index identifying entry.
License Details / Name	Name of the license bundle.
License Details / Customer	Customer name.
License Details / Quantity	Quantity of licenses included in the feature key.
License Details / Type	Full or Temporary license types.
License Details / Issued	Date the key was generated.
License Details / Expiration	Expiry date for a Temporary license.
License Details / Features	List of features enabled by the license.

System > License Management > Add Feature License

The System > License Management > Add Feature License dialog allows you add feature licenses by specifying the license name and the license key.

Configuration Dialog

Figure C-14: Example showing **System > License Management > Add Feature License** dialog:

**Description**

Label / Field / Button	Description
License Name	Enter the license name of the software feature.
License Key	Enter the encrypted license key to enable this software feature.

Switching > Ports


The Example showing **System > License Management > Add Feature License** dialog: menu tab allows you to view, and configure Layer 1 properties:

- Right-clicking a port allows you to select monitoring or configuration dialogs for the selected port.
- The monitoring dialog displays port status, statistics and a brief utilization history.
- The configuration dialog allows you to configure Administrative State, Auto Negotiation, Speed and Duplex settings for the port.

Note: Speed and Duplex settings can only be changed if Auto Negotiation is disabled.

Note: For systems equipped and configured using VCStack there is a separate tab for each stack member with the system name displayed on each tab.


Menu Tab Figure C-15: Example showing the **Switching > Ports** menu tab:



Description

Label / Field / Button	Description
Ports	Displays port number, link and administrative status, duplex mode, speed and uptime (in milliseconds) for the selected port.

Menu Tab Figure C-16: Example showing the **Switching > Ports > ALL** menu tab:



Port	Description	Link State	Admin State	Duplex	Speed	Uptime
eth0		up	up	Full	100 Mbps	119 hrs 37 mins 2...
port1.0.1		up	up	Full	100 Mbps	169 hrs 27 mins 5...
port1.0.2		down	up	auto	auto	0 millisecond
port1.0.3		up	up	Full	1000 Mbps	119 hrs 43 mins 5...
port1.0.4		down	up	auto	auto	0 millisecond
port1.0.5		down	up	auto	auto	0 millisecond
port1.0.6		down	up	auto	auto	0 millisecond
port1.0.7		down	up	auto	auto	0 millisecond
port1.0.8		down	up	auto	auto	0 millisecond
port1.0.9		down	up	auto	auto	0 millisecond
port1.0.10		down	up	auto	auto	0 millisecond
port1.0.11		down	up	auto	auto	0 millisecond
port1.0.12		down	up	auto	auto	0 millisecond
port2.0.1		down	up	auto	auto	0 millisecond
port2.0.2		down	up	auto	auto	0 millisecond
port2.0.3		down	up	auto	auto	0 millisecond
port2.0.4		down	up	auto	auto	0 millisecond
port2.0.5		down	up	auto	auto	0 millisecond
port2.0.6		down	up	auto	auto	0 millisecond
port2.0.7		down	up	auto	auto	0 millisecond
port2.0.8		down	up	auto	auto	0 millisecond
port2.0.9		down	up	auto	auto	0 millisecond
port2.0.10		down	up	auto	auto	0 millisecond
port2.0.11		down	up	auto	auto	0 millisecond
port2.0.12		down	up	auto	auto	0 millisecond

Legend Figure C-17: Example showing **Switching > Ports > Legend**:




Switching > Ports > Monitor Port

The Example showing **System > License Management > Add Feature License** dialog: dialog allows you monitor port counters.

Configuration Dialog

Figure C-18: Example showing the **Switching > Ports > Monitor Port** dialog:



Description


Label / Field / Button	Description
Port Details	Monitors the bay, port, duplex, speed, administrative state and link states for the selected port.
Counters	Monitors the counters for bytes received/transmitted, unicast packets received/transmitted, multicast packets received/transmitted, broadcast packets received/transmitted, dropped packets received/transmitted, and errors received/transmitted for the selected port.
Port Utilisation%	Monitors and graphs the usage percentage for the selected port.

Switching > Ports > Configure Port

The Example showing **System > License Management > Add Feature License** dialog: dialog allows you configure Administrative State, Auto Negotiation, Speed and Duplex settings for the selected port.

Configuration Dialog

Figure C-19: Example showing the **Switching > Ports > Configure Port** dialog:



Description

Label / Field / Button	Description
Admin State	Select up or down from the drop down list in this dialog to specify the administrative state for the selected port.
Auto Negotiation	Select disabled or enabled from the drop down list in this dialog to specify auto negotiation for the selected port. Note that selecting enabled to enable Auto Negotiation will disable Speed and Duplex options, indicated by greyed out options.
Speed	Select 10 Mbps, 100 Mbps, 1000 Mbps, 10 Gbps, or auto from the drop down list in this dialog to specify the speed setting for the selected port. Note that the options for speed settings are only available if Auto Negotiation has been disabled for the selected port.
Duplex	Select full, half, or auto from the drop down list in this dialog to specify the duplex setting for the selected port. Note that the options for duplex settings are only available if Auto Negotiation has been disabled for the selected port.


Switching > VLANs

The Example showing **System > License Management > Add Feature License** dialog: menu tab allows you to view, and configure Layer 2 properties:

- Right-clicking a port allows you to select a VLAN to be tagged or untagged for the port, or to remove a port from the VLAN.
- Define VLANs before assigning VLANs to ports on the front panel of the switch.
- Selecting the **+** icon (under the VLAN Interface label on the VLAN tab below the front panel illustration) allows you to add a VLAN by specifying the VLAN ID and VLAN Name.
- Selecting the **x** icon (under the VLAN Interface label below the front panel illustration) allows you to delete a VLAN (except for the default VLAN 1 that is assigned to all ports).

Note: For systems equipped and configured using VCStack there is a separate tab for each stack member with the system name displayed on each tab.


Menu Tab Figure C-20: Example showing the **Switching > VLANs** menu tab:




Description

Label / Field / Button	Description
Port Based / VLAN ID	The VID of the VLAN that is enabled or disabled in the range 1-4094.
Port Based / VLAN Name	The ASCII name of the VLAN with a maximum length of 32 characters.
Port Based / State	The state of the VLAN, either enabled ('ACTIVE' displayed) or disabled ('INACTIVE' displayed).

Menu Tab Figure C-21: Example showing the **Switching > VLANs > ALL** menu tab:



Legend Figure C-22: Example showing **Switching > VLANs > Legend**:




Switching > VLANs > Add VLAN

The Example showing **System > License Management > Add Feature License** dialog: dialog allows you add a VLAN by specifying the VLAN ID and VLAN Name.

Configuration Dialog

Figure C-23: Example showing the **Switching > VLANs > Add VLAN** dialog:



Description

Label / Field / Button	Description
VLAN ID	Enter the VID of the VLAN that is enabled or disabled in the range <1-4094>.
VLAN Name	Enter the ASCII name of the VLAN with a maximum length of 32 characters.

Switching > Link Aggregation

The Switching > Link Aggregation menu tab allows you to view, and configure layer 2 properties:


- Right-clicking a port allows you to select assign or remove the port to a Static Channel or a Dynamic Channel (LACP - Link Aggregation Control Protocol) group.
- Define Static Channel or Dynamic Channel (LACP) groups before assigning them to ports on the front panel of the switch.
- Selecting the + icon (located below the front panel illustration of your switch) allows you to add a Static Channel or Dynamic Channel (LACP) group by specifying the Channel ID.

Note: Up to 31 Static Channel groups and up to 99 Dynamic Channel (LACP) groups can be defined on a switch.

- Selecting the x icon (located below the front panel illustration of your switch) allows you to delete a Static Channel or Dynamic Channel (LACP) group.

Note: For systems equipped and configured using VCStack there is a separate tab for each stack member with the system name displayed on each tab.


Menu Tab Figure C-24: Example showing the **Switching > Link Aggregation** menu tab:




Description

Label / Field / Button	Description
Static Channels	Display or specify a static channel group number for an aggregated link. Up to 31 static channel groups can be created on the switch.
Dynamic Channels (LACP)	Display or specify a dynamic channel group number for an LACP link. Up to 99 dynamic channel groups can be created on the switch.

Menu Tab Figure C-25: Example showing the **Switching > Link Aggregation > ALL** menu tab:



Legend Figure C-26: Example showing **Switching > Link Aggregation > Legend**:



Switching > Link Aggregation > Add Static Channel

The Switching > Link Aggregation > Add Static Channel dialog allows you to assign the selected port to a Static Channel group.

Configuration Dialog Figure C-27: Example showing the **Switching > Link Aggregation > Add Static Channel** dialog:




Description

Label / Field / Button	Description
Channel ID	Specify a static channel group number for an interface. Up to 31 static channel groups can be created on the switch.

Switching > Link Aggregation > Add Dynamic Channel

The Switching > Link Aggregation > Add Static Channel dialog allows you to assign the selected port to a Dynamic Channel (LACP) group.

Configuration Dialog Figure C-28: Example showing **Switching > Link Aggregation > Add Dynamic Channel** dialog:



Description

Label / Field / Button	Description
Channel ID	Specify a dynamic (LACP) channel group number for an interface. Up to 99 dynamic (LACP) channel groups can be created on the switch.


Switching > FDB Table

The Switching > FDB Table menu tab allows you to view the contents of the Layer 2 Forwarding Database Table.

You can change the FDB Table view to display horizontally or vertically by selecting the table view icon above the FDB Table.

You can also sort or rearrange the display of the FDB Table by Port, MAC Address, or Forwarding Status by selecting the relevant column or by dragging the relevant column respectively.

Menu Tab Figure C-29: Example showing the **Switching > FDB Table** menu tab:



Port	MAC Address	Status
port1.0.1	0000.b48a.e07a	learned
port1.0.1	0000.b48e.2762	learned
port1.0.1	0000.b4ab.1587	learned
port1.0.1	0000.b4ac.c4b3	learned
port1.0.1	0000.b4ac.c7c1	learned
port1.0.11	0000.cd00.0000	mgmt
port1.0.1	0000.cd03.00d7	learned
port1.0.1	0000.cd20.10f8	learned
port1.0.1	0000.cd27.bf43	learned
0	0000.cd29.bff9	self
port1.0.1	0002.b94c.3e64	learned
port1.0.1	0002.b363.3600	learned
port1.0.1	0002.b399.70f5	learned
port1.0.1	0004.23b1.c8c6	learned
0	0009.41fd.d1b9	self
port1.0.1	000c.6ede.cd45	learned
port1.0.1	000e.2e0a.c29c	learned
port1.0.1	000e.2e0d.043d	learned
port1.0.1	000e.2e5f.c79e	learned
port1.0.1	000e.2e5f.cdfc	learned
port1.0.1	000e.2e65.9b90	learned
port1.0.1	000e.2e6a.b6e1	learned
port1.0.1	000e.2e6e.5589	learned
port1.0.1	0013.20c7.924b	learned
port1.0.1	001c.f015.0add	learned

Description

Label / Field / Button	Description
FDB Table	Displays the FDB (Forwarding Database) table for the switch that shows all the available ports, MAC addresses, and port status.


IP > IP Interfaces

The IP > IP Interfaces menu tab allows you to view and specify the Primary and Secondary IP Addresses for VLAN and `eth0` management port interfaces.

Note: You may only define a Secondary IP Address for an interface after first defining its Primary IP Address.

- Select an interface then use the pen shaped icon under the Primary IP Address label to configure an IP address. You can delete an assigned Primary IP Address in the Configure Primary IP Address dialog as displayed after selecting the icon under Primary IP Address.
- Select an interface with a Primary IP Address already defined to configure a Secondary IP Address, using the **+** icon under the Secondary IP Address label.
- Remove a selected Secondary IP Address using the **x** icon under the Secondary IP Address label.

Menu Tab Figure C-30: Example showing the **IP > IP Interfaces** menu tab:



Description


Label / Field / Button	Description
Primary IP Address	Displays and configures primary IP addressing for VLANs and <code>eth0</code> management port interfaces that are defined on the switch and assigned to ports.
Secondary IP Address	Displays and configures secondary IP addressing for VLANs and <code>eth0</code> management port interfaces that are defined on the switch and assigned to ports.

IP > IP Interfaces > Configure Primary IP Address

The IP > IP Interfaces > Configure Primary IP Address dialog allows you to configure a primary address with an IP address and a prefix length for the selected interface.

Configuration Dialog

Figure C-31: Example showing the **IP > IP Interfaces > Configure Primary IP Address** dialog:



Description


Label / Field / Button	Description
IP Address	Enter or remove an IPv4 Address in dotted decimal notation (i.e. A.B.C.D).
Prefix Length	Enter the Prefix for the IPv4 Address with the integer as used for slash notation (i.e. 24 instead of /24), not dotted decimal notation (i.e. 255.255.255.0).

IP > IP Interfaces > Add Secondary IP Address

The Example showing the **IP > IP Interfaces > Configure Primary IP Address** dialog: dialog allows you to add a secondary address with an IP address and a prefix length for the selected interface (only if the selected interface already has a primary address configured).

Configuration Dialog

Figure C-32: Example showing the **IP > IP Interfaces > Add Secondary IP Address** dialog:



Description

Label / Field / Button	Description
IP Address	Enter an IPv4 Address in dotted decimal notation (i.e. A.B.C.D).
Prefix Length	Enter the Prefix for the IPv4 Address with the integer as used for slash notation (i.e. 24 instead of /24), not dotted decimal notation (i.e. 255.255.255.0).


IP > Static Routes

The **Example** showing the **IP > IP Interfaces > Configure Primary IP Address** dialog: menu tab allows you to view, add, and delete static IP routes configured on the switch. Static routes are specified using destination IP addresses, masks, and gateways.

You can also sort or rearrange the display of the Static Routes by Destination, Gateway, or Mask by selecting the relevant column or by dragging the relevant column respectively.

- Selecting the + icon allows you to define a Static Route specifying destination and gateway IPv4 addresses with a dotted decimal format subnet mask.
- Selecting the x icon allows you to delete a defined Static Route.

Menu Tab Figure C-33: Example showing the **IP > Static Routes** menu tab:



Description


Label / Field / Button	Description
Static Routes / Destination	The IPv4 address of the destination subnet address.
Static Routes / Gateway	The IPv4 address of the gateway device.
Static Routes / Mask	The subnet mask in dotted decimal notation (for example, 255.255.255.0 instead of the slash notation /24).

IP > Static Routes > Add Static Route

The IP > Static Routes > Add Static Route dialog allows you to add a static IP routes on the switch. Static routes are specified using destination IP addresses, masks, and gateways.

Configuration Dialog

Figure C-34: Example showing the **IP > Static Routes > Add Static Route** dialog:



Description

Label / Field / Button	Description
Destination	Enter the IPv4 address of the destination subnet address.
Mask	Enter the subnet mask in dotted decimal notation (for example, 255.255.255.0 instead of the slash notation /24).
Gateway	Enter the IPv4 address of the gateway device.


IP > ARP

The IP > ARP menu tab allows you to view the contents of the ARP (Address Resolution Protocol) Table.

You can change the ARP Entries view to display horizontally or vertically by selecting the table view icon above the ARP Entries.

You can also sort or rearrange the display of the ARP Entries by Interface, IP Address, MAC Address, or Type by selecting the relevant column or by dragging the relevant column respectively.

Menu Tab Figure C-35: Example showing the **IP > ARP** menu tab:



Description


Label / Field / Button	Description
ARP Entries / Interface	Interface over which the switch is accessed, usually a VLAN.
ARP Entries / IP Address	IP address of the network device this ARP entry maps to.
ARP Entries / MAC Address	Hardware address of the switch in hexadecimal format HHHH.HHHH.HHHH.
ARP Entries / Type	Indicates whether the ARP entry is a Static or Dynamic ARP entry. Static ARP entries are added and dynamic ARP entries are learned.

IP > DNS

The IP > DNS menu tab allows you to display and configure DNS (Domain Name System) server entries for the switch.

- Selecting the + icon allows you to define a DNS Server specifying the IPv4 address.
- Selecting the x icon allows you to delete a defined DNS Server.

Figure C-36: Example showing the **IP > DNS** menu tab:



Description


Label / Field / Button	Description
DNS	DNS Server IPv4 address.

IP > DNS > Add DNS Server

The IP > DNS > Add DNS Server dialog allows you to add DNS (Domain Name System) server entries for the switch.

Configuration Dialog

Figure C-37: Example showing the **IP > DNS > Add DNS Server** dialog:



Description


Label / Field / Button	Description
DNS	Enter an IPv4 address in dotted decimal notation (i.e. A.B.C.D) for the DNS (Domain Name System) Server you want to specify.

IP > IGMP Snooping

Menu Tab The IP > IGMP Snooping menu tab displays basic IGMP Snooping and Multicast Routing Interface information.

You can also configure IGMP Snooping on individual ports by selecting the VLAN interface that the port is a member of then clicking on the pen shaped icon to display the Configure IGMP Snooping dialog, where you can enable or disable IGMP snooping on desired ports.

Menu Tab Figure C-38: Example showing the IP > IGMP Snooping menu tab:



Description


Label / Field / Button	Description
IGMP Snooping / IGMP Snooping	Displays and configures IGMP Snooping for a specified VLAN interface.
IGMP Snooping / Multicast Routing Interface	Displays and configures the specified port in the VLAN as a multicast router for IGMP Snooping.

IP > IGMP Snooping > Configure Interface

The IP > IGMP Snooping > Configure Interface dialog allows you to configure IGMP Snooping on individual ports. First select the VLAN interface that the port is a member of then enable or disable IGMP snooping on desired ports from this dialog.

Configuration Dialog

Figure C-39: Example showing the **IP > IGMP Snooping > Configure Interface** dialog:



Description

Label / Field / Button	Description
VLAN Interface Status	Displays whether the selected VLAN is enabled or disabled.
Port Interface	Select the check box for a given port to allocate it to the VLAN.


Resiliency and High Availability > STP

The Resiliency and High Availability > STP menu tab allows you to view the configuration and status of spanning tree data: for the switch as a whole and for each port.

You can also sort or rearrange the display of the Port State table by Port, Port Priority, Port State, STP Enabled, Port Path Cost, or Designated Bridge ID by selecting the relevant column or by dragging the relevant column respectively.

Note: STP is not configurable through the GUI. Refer to the relevant STP chapters in the AlliedWare Plus Software Reference to configure STP using the CLI instead.

Menu Tab Figure C-40: Example showing the **Resiliency and High Availability > STP** menu tab:



The screenshot shows the Allied Telesis Cycle I GUI with the 'Resiliency and High Availability' menu tab selected. The 'STP' sub-tab is active, displaying the following information:

Switch State

Mode:	Rapid	Root Path Cost:	0
Status:	Enabled	Max Age:	20
Bridge ID:	8000.0000.cd28.bff9	Hello Time:	2
Root ID:	8000.0000.cd28.bff9	Forward Delay:	15

Port State

Port	Port Priority	Port State	STP Enabled	Port Path Cost	Designated Bridge ID
se5	128	disabled	disabled	20000000	8000.0000.cd28.bff9
po7	128	disabled	disabled	20000000	8000.0000.cd28.bff9
port1.0.1	128	forwarding	enabled	20000000	8000.0000.cd28.bff9
port1.0.2	128	disabled	disabled	20000000	8000.0000.cd28.bff9
port1.0.3	128	disabled	disabled	20000000	8000.0000.cd28.bff9
port1.0.4	128	disabled	disabled	20000000	8000.0000.cd28.bff9
port1.0.7	128	disabled	disabled	20000000	8000.0000.cd28.bff9
port1.0.8	128	disabled	disabled	20000000	8000.0000.cd28.bff9
port2.0.1	128	disabled	disabled	20000000	8000.0000.cd28.bff9

Topology Change

Topology Change: 1

Time Since Topology Change: 51 hours 28 minutes 9 seconds

The bottom right corner of the GUI shows the date and time: 18/12/08 17:50.

**Description:
Switch State**

Label / Field / Button	Description
Switch State / Mode	Spanning Tree Mode displayed: STP (Spanning Tree Protocol), RSTP (Rapid Spanning Tree Protocol), or MSTP (Multiple Spanning Tree Protocol).
Switch State / Status	Status of the Spanning Tree Mode: enabled or disabled.
Switch State / Bridge ID	Bridge ID, comprising the port priority followed by its MAC address.
Switch State / Root ID	Root Bridge ID, comprising the root priority followed by its MAC address.
Switch State / Root Path Cost	Sum of the costs for each path between the bridge port and the root bridge.
Switch State / Max Age	Time in seconds that the dynamic spanning tree configuration information is stored in the switch before it is discarded.
Switch State / Hello Time	Time in seconds between the transmission of switch spanning tree configuration information, when the switch is the Root Bridge of the spanning tree or is trying to become the Root Bridge.
Switch State / Forward Delay	Time in seconds to control how fast a port changes its spanning tree state when moving towards the forwarding state. This value is used only when the switch is acting as the root bridge. Note that Forward Delay, Max Age, and Hello Time are interrelated.

**Description:
Port State**

Label / Field / Button	Description
Port State / Port	Switch port number in the format 'portX.Y.Z' where X is the switch, Y is the XEM, and Z is the individual switch port number.
Port State / Port Priority	The lower the port priority, the higher the likelihood of the port becoming part of the active network topology.
Port State / Port State	Displays the spanning tree state for the port as configured in the CLI with 'spanning-tree' commands. Indicates spanning tree states of: disabled, blocking, listening, learning, and forwarding.
Port State / STP Enabled	Displays whether spanning-tree is enabled or disabled. Spanning tree is enabled by default.
Port State / Port Path Cost	The cost of a path for the port that determine the total cost path. The lower the total cost, the higher the priority of the path.
Port State / Designated Bridge ID	The unique parent for each bridge that connects it to the next LAN on the path towards the root bridge.

**Description:
Topology Change**

Label / Field / Button	Description
Topology Change / Topology Change	The number of STP Topology Changes that have occurred since the switch was rebooted.
Topology Change / Time Since Topology Change	The time in hours and seconds since the previous STP Topology Change occurred.


Resiliency and High Availability > EPSR

The Resiliency and High Availability > EPSR menu tab allows you to display the properties and status of any EPSR domains configured on the switch.

You can also sort or rearrange the display of the EPSR Port State table by Node Type, Domain Name, Domain ID, State, Control VLAN, Primary Port, Primary Port Status, Secondary Port, or Secondary Port Status by selecting the relevant column or by dragging the relevant column respectively.

Note: EPSR is not configurable through the GUI. Refer to the relevant EPSR chapters in the AlliedWare Plus Software Reference to configure EPSR using the CLI instead.

Menu Tab Figure C-41: Example showing the **Resiliency and High Availability > EPSR** menu tab:



Description


Label / Field / Button	Description
EPSR Port State Table / Node Type	Displays master or transit node as configured in the CLI with the 'epsr mode' command.
EPSR Port State Table / Domain Name	Displays the domain name. A set of instances across a ring is called a domain.
EPSR Port State Table / Domain ID	Displays the assigned domain number for the domain name.
EPSR Port State Table / State	Displays the EPSR state as configured in the CLI with the 'epsr state' commands.
EPSR Port State Table / Control VLAN	Displays the control VLAN as configured in the CLI with the 'epsr mode controlvlan' command.

Label / Field / Button	Description(Continued)
EPSR Port State Table / Primary Port	Displays the master node primary port interface name as configured in the CLI with the 'epsr mode primaryport' command.
EPSR Port State Table / Primary Port Status	Displays the master node primary port interface status: up or down.
EPSR Port State Table / Secondary Port	Displays the assigned secondary port interface name.
EPSR Port State Table / Secondary Port Status	Displays the assigned secondary port interface status: up or down.

Management > Device Utilities

The Management > Device Utilities menu tab allows you to perform pings and reboot the switch from the GUI.

Menu Tab Figure C-42: Example showing the **Management > Device Utilities** menu tab:




Description

Label / Field / Button	Description
Ping Utility / Host	Enter the IPv4 address or the URL that you want to ping in this field.
Ping Utility / Perform Ping	Select this button to ping the IPv4 address or URL that you entered in the Host field.
System Uptime	Displays the elapsed time since the last reboot in hours, minutes, and seconds.
Reboot Device	Select this button to reboot your switch. You will need to login to the GUI again after you reboot your switch. Rebooting closes all Telnet / SSH / SNMP sessions on your switch.

Management > NTP

The Management > NTP menu tab allows you to display and configure Network Time Protocol (NTP) peer configurations on the switch.

Menu Tab Figure C-43: Example showing the **Management > NTP** menu tab:



Description

Label / Field / Button	Description
Associations / Address	The NTP peer or NTP server IPv4 address.
Associations / Status	Indicates association status, and displays 'master(synced)', 'master(unsynced)', 'selected', 'candidate', 'configured', or 'unknown'.
Associations / Configured	Indicates if the association is configured or not, and displays 'configured' or 'dynamic'.
Associations / Reference Clock	The IPv4 address for the reference clock.
Associations / Stratum	The number of hops between the server and the accurate time source.
Associations / Reach	Shows whether or not the NTP server responded to the last request, which indicates the reachability of the NTP peer.
Associations / Delay	The round trip delay between the device and the server.


Label / Field / Button	Description(Continued)
Associations / Offset	The difference between the device clock and the server clock, relative to the server clock, in milliseconds..
Associations / Dispersion	The lowest measure of error associated with peer offset based on delay.

Management > NTP > Add NTP Association

The Management > NTP > Add NTP Association dialog allows you configure Network Time Protocol (NTP) peer configurations on the switch.

Configuration Dialog

Figure C-44: Example showing the **Management > NTP > Add NTP Association**



dialog:

Description


Label / Field / Button	Description
Address	Enter the NTP IPv4 address for the NTP peer or NTP server used.
Mode	Select one of the <code>server</code> or <code>peer</code> options from the drop down list to specify the NTP Mode used. When using NTP server mode, the NTP server will not accept updates from clients for updates to the server's time settings. The NTP server is configured to synchronize the NTP clients. When using NTP peer mode, each device shares its time information with the other, and each device can also provide time synchronization to the other.
Preference	Select one of the <code>unknown</code>, <code>not preferred</code>, or <code>preferred</code> options from the drop down list to specify the NTP Preference used. NTP Preference is used to configure an NTP server, so the NTP server is given preference to synchronize the NTP clients.
Version	Select one of the <code>unknown</code> , <code>version 1</code> , <code>version 2</code> , <code>version 3</code> , or <code>version 3</code> options from the drop down list to specify the NTP Version used.
Key Number	Enter the NTP Key Number for NTP authentication, which allows NTP to authenticate the associations with other systems for security purposes. The NTP Key Number is an integer in the range <1-4294967295>. The MD5 (Message-Digest algorithm 5) key type is supported to encrypt the NTP Key Number used for authentication.

Management > Remote CLI Access

The Management > Remote CLI Access menu tab allows you to enable, disable and configure Telnet and SSH.

You can create Telnet or SSH connections to the switch, and you can view a list of all current active CLI sessions on the switch from this tab.

Menu Tab Figure C-45: Example showing the **Management > Remote CLI Access** menu tab:



Description

Label / Field / Button	Description
Telnet / Status	Displays the current Telnet status, either 'enabled' or 'disabled'.
Telnet / Configure Settings	Configures the Telnet Status. Select 'enabled' or 'disabled' to configure the status of the Telnet server on the switch.
Telnet / Start Session	Starts a Telnet session to use the CLI. After starting a Telnet session you will need to login to the switch to use the CLI.
SSH / Status	Displays the current SSH status, either 'enabled' or 'disabled'.
SSH / Configure Settings	Configures the SSH Status. Select 'enabled' or 'disabled' to configure the status of the SSH server on the switch. Note that relevant certificates must be installed to initiate an SSH session.
SSH / Start Session	Starts a secure SSH session to use the CLI. After starting an SSH session you will need to login to the switch to use the CLI.

Description


Label / Field / Button	Description
Active Sessions / Connection Type	A Console connection or a VTY connection.
Active Sessions / Username	Login name for a user.
Active Sessions / Privilege Level	The privilege set for a user for VTY or console connection. Privilege levels range from 1-15 with 15 the highest privilege level. Privilege levels are used in the CLI to enable or disable access to different configuration modes and commands. Privilege levels 1-14 only enables users to view system configuration and system behavior. Privilege level 15 enables users to globally configure all the interfaces on a switch.
Active Sessions / Idle Time	Time in seconds that the SSH Server waits to receive data from the SSH Client. The SSH Server disconnects when the Idle Time limit is reached.
Active Sessions / IP Address	The IPv4 address for the VTY connection.

Management > Remote CLI Access > Telnet Settings

The Management > Remote CLI Access > Telnet Settings dialog allows you to enable or disable Telnet.

Configuration Dialog

Figure C-46: Example showing **Management > Remote CLI Access > Telnet Settings** dialog:

**Description**


Label / Field / Button	Description
Status	Select enabled or disabled from the drop down list on this dialog to enable or disable Telnet respectively on the switch.

Management > Remote CLI Access > SSH Settings

The Management > Remote CLI Access > SSH Settings dialog allows you to enable or disable SSH.

Configuration Dialog

Figure C-47: Example showing the **Management > Remote CLI Access > SSH Settings** dialog:




Description

Label / Field / Button	Description
Status	Select enabled or disabled from the drop down list on this dialog to enable or disable SSH respectively on the switch.

Management > Logs

The Management >Logs menu tab allows you to view the switch logs, and export the switch logs as .csv format files.

Menu Tab Figure C-48: Example showing the **Management > Logs** menu tab:



Description


Label / Field / Button	Description
Logs	Display, select and export the available switch log files for troubleshooting use.
Source	Select the buffered log or the permanent log available on the switch to display or export to a .csv format file for use in a spreadsheet.
Source / Refresh Log	Select this button to display an updated buffered or permanent log..
Source / Export Log	Select this option to export the log to a .csv format file for use in a spreadsheet.

Management > Logs > Export Logs

The Management > Logs > Export Logs dialog allows you to export the switch logs as .csv format files.

Configuration Dialog

Figure C-49: Example showing the **Management > Logs > Export Logs** dialog:



Description

Label / Field / Button	Description
File name:	Enter the file name for the exported log file.
Files of type:	Select .csv files to export the log file as a comma separated file, so each column of the log file can be formatted in a spreadsheet.

